

Mediant™ 600 & Mediant 1000

VoIP Media Gateways

Analog & Digital Lines

User's Manual



Version 6.6

April 2013

Document # LTRT-83313



Table of Contents

1	Overview	19
1.1	Mediant 600	19
1.2	Mediant 1000	20
1.3	SIP Overview	21
Getting Started with Initial Connectivity.....		25
2	Assigning the OAMP IP Address	27
2.1	Web Interface.....	27
2.2	BootP/TFTP Server.....	29
2.3	CLI.....	30
2.4	FXS Voice Menu Guidance.....	31
Management Tools		35
3	Introduction	37
4	Web-Based Management.....	39
4.1	Getting Acquainted with the Web Interface.....	39
4.1.1	Computer Requirements.....	39
4.1.2	Accessing the Web Interface.....	40
4.1.3	Areas of the GUI	41
4.1.4	Toolbar Description.....	42
4.1.5	Navigation Tree	43
4.1.5.1	Displaying Navigation Tree in Basic and Full View.....	43
4.1.5.2	Showing / Hiding the Navigation Pane.....	44
4.1.6	Working with Configuration Pages	45
4.1.6.1	Accessing Pages.....	45
4.1.6.2	Viewing Parameters	46
4.1.6.3	Modifying and Saving Parameters	47
4.1.6.4	Working with Tables.....	48
4.1.7	Searching for Configuration Parameters	51
4.1.8	Working with Scenarios	52
4.1.8.1	Creating a Scenario.....	52
4.1.8.2	Accessing a Scenario.....	54
4.1.8.3	Editing a Scenario	55
4.1.8.4	Saving a Scenario to a PC	56
4.1.8.5	Loading a Scenario to the Device	57
4.1.8.6	Deleting a Scenario.....	57
4.1.8.7	Quitting Scenario Mode.....	58
4.1.9	Creating a Login Welcome Message.....	58
4.1.10	Getting Help.....	59
4.1.11	Logging Off the Web Interface.....	60
4.2	Viewing the Home Page.....	61
4.2.1	Assigning a Port Name	64
4.3	Configuring Web User Accounts	64
4.3.1	Basic User Accounts Configuration	66
4.3.2	Advanced User Accounts Configuration.....	68
4.4	Displaying Login Information upon Login	71
4.5	Configuring Web Security Settings	72

4.6	Web Login Authentication using Smart Cards	72
4.7	Configuring Web and Telnet Access List	73
4.8	Configuring RADIUS Settings	74
5	CLI-Based Management.....	75
5.1	Enabling CLI using Telnet.....	75
5.2	Enabling CLI using SSH and RSA Public Key	75
5.3	Establishing a CLI Session	77
5.4	CLI Commands	78
5.4.1	Status Commands	78
5.4.2	Ping Command.....	81
5.4.3	Test Call (TC) Commands.....	81
5.4.4	Management Commands	82
5.4.5	Configuration Commands.....	83
5.4.6	PSTN Commands.....	83
5.4.7	LDAP Commands.....	84
6	SNMP-Based Management.....	85
6.1	Configuring SNMP Community Strings.....	85
6.2	Configuring SNMP Trap Destinations	86
6.3	Configuring SNMP Trusted Managers	87
6.4	Configuring SNMP V3 Users.....	88
7	EMS-Based Management.....	91
8	INI File-Based Management.....	93
8.1	INI File Format	93
8.1.1	Configuring Individual ini File Parameters.....	93
8.1.2	Configuring Table ini File Parameters	93
8.1.3	General ini File Formatting Rules	95
8.2	Loading an ini File.....	95
8.3	Modifying an ini File	96
8.4	Secured Encoded ini File	96
General System Settings		97
9	Configuring Certificates	99
9.1	Replacing the Device's Certificate	99
9.2	Loading a Private Key	100
9.3	Mutual TLS Authentication.....	102
9.4	Configuring Certificate Revocation Checking (OCSP)	102
9.5	Self-Signed Certificates.....	104
9.6	Loading Certificate Chain for Trusted Root.....	104
10	Date and Time.....	105
10.1	Configuring Date and Time Manually.....	105
10.2	Automatic Date and Time through SNTP Server	105
General VoIP Configuration.....		107

11 Network	109
11.1 Ethernet Interface Configuration	109
11.2 Ethernet Interface Redundancy	109
11.3 Configuring IP Network Interfaces	110
11.3.1 Assigning NTP Services to Application Types	115
11.3.2 Multiple Interface Table Configuration Rules	115
11.3.3 Troubleshooting the Multiple Interface Table	116
11.3.4 Networking Configuration Examples	117
11.3.4.1 One VoIP Interface for All Applications	117
11.3.4.2 VoIP Interface per Application Type	117
11.3.4.3 VoIP Interfaces for Combined Application Types	118
11.3.4.4 VoIP Interfaces with Multiple Default Gateways	119
11.4 Configuring the IP Routing Table	119
11.4.1 Interface Column	121
11.4.2 Routing Table Configuration Summary and Guidelines	122
11.4.3 Troubleshooting the Routing Table	122
11.5 Configuring Quality of Service	123
11.6 Disabling ICMP Redirect Messages	125
11.7 DNS	125
11.7.1 Configuring the Internal DNS Table	125
11.7.2 Configuring the Internal SRV Table	127
11.8 Configuring NFS Settings	128
11.9 Network Address Translation Support	130
11.9.1 Device Located behind NAT	130
11.9.1.1 Configuring STUN	131
11.9.1.2 Configuring a Static NAT IP Address for All Interfaces	132
11.9.1.3 Configuring NAT Translation per IP Interface	133
11.9.2 Remote UA behind NAT	134
11.9.2.1 First Incoming Packet Mechanism	135
11.10 Configuring General Media Settings	135
11.10.1.1 No-Op Packets	135
11.11 Robust Receipt of Media Streams	136
11.12 Multiple Routers Support	136
11.13 IP Multicasting	136
12 Security	137
12.1 Configuring Firewall Settings	137
12.2 Configuring General Security Settings	141
12.3 IPsec and Internet Key Exchange	141
12.3.1 Enabling IPsec	142
12.3.2 Configuring IP Security Proposal Table	143
12.3.3 Configuring IP Security Associations Table	144
12.4 Intrusion Detection System	148
12.4.1 Enabling IDS	148
12.4.2 Configuring IDS Policies	149
12.4.3 Assigning IDS Policies	152
12.4.4 Viewing IDS Alarms	154
13 Media	157
13.1 Configuring Voice Settings	157
13.1.1 Configuring Voice Gain (Volume) Control	157
13.1.2 Silence Suppression (Compression)	158

13.1.3	Echo Cancellation.....	158
13.2	Fax and Modem Capabilities.....	159
13.2.1	Fax/Modem Operating Modes	160
13.2.2	Fax/Modem Transport Modes	160
13.2.2.1	T.38 Fax Relay Mode	160
13.2.2.2	G.711 Fax / Modem Transport Mode	162
13.2.2.3	Fax Fallback.....	162
13.2.2.4	Fax/Modem Bypass Mode	163
13.2.2.5	Fax / Modem NSE Mode.....	164
13.2.2.6	Fax / Modem Transparent with Events Mode	165
13.2.2.7	Fax / Modem Transparent Mode.....	165
13.2.2.8	RFC 2833 ANS Report upon Fax/Modem Detection	166
13.2.3	V.34 Fax Support.....	166
13.2.3.1	Bypass Mechanism for V.34 Fax Transmission.....	167
13.2.3.2	Relay Mode for T.30 and V.34 Faxes	167
13.2.4	V.152 Support.....	168
13.2.5	Fax Transmission behind NAT	168
13.3	Configuring RTP/RTCP Settings.....	169
13.3.1	Configuring the Dynamic Jitter Buffer.....	169
13.3.2	Comfort Noise Generation	170
13.3.3	Dual-Tone Multi-Frequency Signaling	171
13.3.3.1	Configuring DTMF Transport Types.....	171
13.3.3.2	Configuring RFC 2833 Payload	172
13.3.4	RTP Multiplexing (ThroughPacket).....	173
13.3.5	Configuring RTP Base UDP Port.....	174
13.4	Configuring IP Media Settings.....	175
13.4.1	Answer Machine Detector (AMD)	175
13.4.2	Automatic Gain Control (AGC)	179
13.5	Configuring Analog Settings.....	180
13.6	Configuring DSP Templates.....	181
13.7	DSP Channel Resources for Transcoding	181
13.8	Configuring Media Realms.....	183
13.8.1	Configuring Quality of Experience per Media Realm	185
13.8.2	Configuring Bandwidth Management per Media Realm.....	188
13.9	Configuring Server for Media Quality of Experience	190
13.10	Configuring Media Security	191
14	Services	193
14.1	Routing Based on LDAP Active Directory Queries	193
14.1.1	Configuring the LDAP Server	193
14.1.2	Configuring the Device's LDAP Cache.....	194
14.1.3	Active Directory based Tel-to-IP Routing for Microsoft Lync.....	196
14.1.3.1	Querying the AD and Routing Priority	197
14.1.3.2	Configuring AD-Based Routing Rules.....	199
14.1.3.3	Querying the AD for Calling Name	201
14.2	Least Cost Routing.....	202
14.2.1	Overview	202
14.2.2	Configuring LCR	204
14.2.2.1	Enabling the LCR Feature.....	204
14.2.2.2	Configuring Cost Groups.....	206
14.2.2.3	Configuring Time Bands for Cost Groups	207
14.2.2.4	Assigning Cost Groups to Routing Rules.....	208

15 Enabling Applications.....	209
16 Control Network	211
16.1 Configuring SRD Table	211
16.2 Configuring SIP Interface Table	212
16.3 Configuring IP Groups.....	214
16.4 Configuring Proxy Sets Table	219
17 SIP Definitions	225
17.1 Configuring SIP Parameters	225
17.2 Configuring Account Table.....	225
17.3 Configuring Proxy and Registration Parameters.....	228
17.3.1 SIP Message Authentication Example	229
17.4 Configuring SIP Message Manipulation	231
17.5 Configuring SIP Message Policy Rules.....	235
18 Coders and Profiles	239
18.1 Configuring Coders	239
18.2 Configuring Coder Groups	242
18.3 Configuring Tel Profile.....	243
18.4 Configuring IP Profiles	245
Gateway and IP-to-IP Application	251
19 Introduction	253
20 IP-to-IP Routing Application.....	255
20.1 Theory of Operation	256
20.1.1 Proxy Sets	257
20.1.2 IP Groups.....	257
20.1.3 Inbound and Outbound IP Routing Rules.....	258
20.1.4 Accounts	259
20.2 IP-to-IP Routing Configuration Example	259
20.2.1 Step 1: Enable the IP-to-IP Capabilities	261
20.2.2 Step 2: Configure the Number of Media Channels.....	261
20.2.3 Step 3: Define a Trunk Group for the Local PSTN	262
20.2.4 Step 4: Configure the Proxy Sets	262
20.2.5 Step 5: Configure the IP Groups	265
20.2.6 Step 6: Configure the Account Table.....	266
20.2.7 Step 7: Configure IP Profiles for Voice Coders	267
20.2.8 Step 8: Configure Inbound IP Routing.....	268
20.2.9 Step 9: Configure Outbound IP Routing.....	270
20.2.10 Step 10: Configure Destination Phone Number Manipulation.....	272
21 Digital PSTN.....	273
21.1 Configuring Trunk Settings.....	273
21.2 TDM and Timing.....	276
21.2.1 Configuring TDM Bus Settings	276
21.2.2 Clock Settings.....	276
21.2.2.1 Recovering Clock from PSTN Line Interface	276
21.2.2.2 Configuring Internal Clock as Clock Source	277

21.3	Configuring CAS State Machines.....	277
21.4	Configuring Digital Gateway Parameters.....	280
21.5	Tunneling Applications.....	281
21.5.1	TDM Tunneling.....	281
21.5.1.1	DSP Pattern Detector.....	284
21.5.2	QSIG Tunneling.....	284
21.6	ISDN Non-Facility Associated Signaling (NFAS).....	285
21.6.1	NFAS Interface ID.....	286
21.6.2	Working with DMS-100 Switches.....	286
21.6.3	Creating an NFAS-Related Trunk Configuration.....	287
21.6.4	Performing Manual D-Channel Switchover in NFAS Group.....	288
21.7	ISDN Overlap Dialing.....	288
21.7.1	Collecting ISDN Digits and Sending Complete Number in SIP.....	288
21.7.2	Interworking ISDN Overlap Dialing with SIP According to RFC 3578.....	289
21.8	Redirect Number and Calling Name (Display).....	290
22	Trunk Group.....	291
22.1	Configuring Trunk Group Table.....	291
22.2	Configuring Trunk Group Settings.....	293
23	Manipulation.....	299
23.1	Configuring General Settings.....	299
23.2	Configuring Source/Destination Number Manipulation Rules.....	299
23.3	Manipulating Number Prefix.....	305
23.4	SIP Calling Name Manipulations.....	306
23.5	Configuring Redirect Number IP to Tel.....	309
23.6	Manipulating Redirected and Diverted Numbers for Call Diversion.....	312
23.7	Mapping NPI/TON to SIP Phone-Context.....	313
23.8	Configuring Release Cause Mapping.....	315
23.8.1	Fixed Mapping of SIP Response to ISDN Release Reason.....	316
23.8.2	Fixed Mapping of ISDN Release Reason to SIP Response.....	318
23.8.3	Reason Header.....	320
23.8.4	Mapping PSTN Release Cause to SIP Response.....	320
23.9	Numbering Plans and Type of Number.....	321
24	Routing.....	323
24.1	Configuring General Routing Parameters.....	323
24.2	Configuring Outbound IP Routing Table.....	323
24.3	Configuring Inbound IP Routing Table.....	332
24.4	IP Destinations Connectivity Feature.....	335
24.5	Alternative Routing for Tel-to-IP Calls.....	336
24.5.1	Alternative Routing Based on IP Connectivity.....	336
24.5.2	Alternative Routing Based on SIP Responses.....	338
24.5.3	PSTN Fallback.....	340
24.6	Alternative Routing for IP-to-Tel Calls.....	340
24.6.1	Alternative Routing to Trunk upon Q.931 Call Release Cause Code.....	340
24.6.2	Alternative Routing to an IP Destination upon a Busy Trunk.....	341
25	Configuring DTMF and Dialing.....	343
25.1	Dialing Plan Features.....	344
25.1.1	Digit Mapping.....	344
25.1.2	External Dial Plan File.....	345

26	Configuring Supplementary Services	347
26.1	Call Hold and Retrieve	348
26.2	Call Pickup	350
26.3	BRI Suspend and Resume.....	350
26.4	Consultation Feature.....	351
26.5	Call Transfer.....	351
26.5.1	Consultation Call Transfer	351
26.5.2	Consultation Transfer for QSIG Path Replacement	352
26.5.3	Blind Call Transfer	352
26.6	Call Forward.....	353
26.6.1	Call Forward Reminder Ring	354
26.6.2	Call Forward Reminder (Off-Hook) Special Dial Tone	354
26.6.3	Call Forward Reminder Dial Tone (Off-Hook) upon Spanish SIP Alert-Info.....	355
26.6.4	BRI Call Forwarding.....	356
26.7	Call Waiting	356
26.8	Message Waiting Indication	357
26.9	Caller ID	359
26.9.1	Caller ID Detection / Generation on the Tel Side	359
26.9.2	Debugging a Caller ID Detection on FXO.....	359
26.9.3	Caller ID on the IP Side	360
26.10	Three-Way Conferencing	361
26.11	Emergency E911 Phone Number Services.....	362
26.11.1	FXS Device Emulating PSAP using DID Loop-Start Lines.....	363
26.11.2	FXO Device Interworking SIP E911 Calls from Service Provider's IP Network to PSAP DID Lines	365
26.11.3	Pre-empting Existing Calls for E911 IP-to-Tel Calls.....	369
26.11.4	Enhanced 9-1-1 Support for Lync Server 2010.....	369
26.11.4.1	About E9-1-1 Services	370
26.11.4.2	Microsoft Lync Server 2010 and E9-1-1.....	371
26.11.4.3	AudioCodes ELIN Gateway for Lync Server 2010 E9-1-1 Calls to PSTN	
	375	
26.11.4.4	Configuring AudioCodes ELIN Gateway	379
26.12	Multilevel Precedence and Preemption.....	381
26.12.1	MLPP Preemption Events in SIP Reason Header	383
26.12.2	Precedence Ring Tone.....	384
26.13	Denial of Collect Calls	385
26.14	Configuring ISDN Supplementary Services	385
26.15	Advice of Charge Services for Euro ISDN	387
26.16	Configuring Voice Mail	388
27	Analog Gateway	389
27.1	Configuring Keypad Features	389
27.2	Configuring Metering Tones.....	390
27.3	Configuring Charge Codes.....	391
27.4	Configuring FXO Settings	392
27.5	Configuring Authentication.....	393
27.6	Configuring Automatic Dialing.....	394
27.7	Configuring Caller Display Information.....	396
27.8	Configuring Call Forward	397
27.9	Configuring Caller ID Permissions	399

27.10	Configuring Call Waiting.....	400
27.11	Rejecting Anonymous Calls	401
27.12	Configuring FXS Distinctive Ringing and Call Waiting Tones per Source/Destination Number	401
27.13	FXS/FXO Coefficient Types	402
27.14	FXO Operating Modes	403
27.14.1	FXO Operations for IP-to-Tel Calls.....	403
27.14.1.1	One-Stage Dialing	403
27.14.1.2	Two-Stage Dialing	405
27.14.1.3	DID Wink	405
27.14.2	FXO Operations for Tel-to-IP Calls.....	406
27.14.2.1	Automatic Dialing	406
27.14.2.2	Collecting Digits Mode.....	407
27.14.2.3	FXO Supplementary Services	407
27.14.3	Call Termination on FXO Devices	408
27.14.3.1	Calls Termination by PBX	408
27.14.3.2	Call Termination before Call Establishment.....	409
27.14.3.3	Ring Detection Timeout.....	409
27.15	Remote PBX Extension between FXO and FXS Devices.....	409
27.15.1	Dialing from Remote Extension (Phone at FXS)	410
27.15.2	Dialing from PBX Line or PSTN.....	410
27.15.3	Message Waiting Indication for Remote Extensions	411
27.15.4	Call Waiting for Remote Extensions	411
27.15.5	FXS Gateway Configuration	412
27.15.6	FXO Gateway Configuration.....	413

Stand-Alone Survivability Application.....415

28 Overview417

28.1	SAS Operating Modes	417
28.1.1	SAS Outbound Mode.....	418
28.1.1.1	Normal State	418
28.1.1.2	Emergency State.....	418
28.1.2	SAS Redundant Mode.....	419
28.1.2.1	Normal State	420
28.1.2.2	Emergency State.....	420
28.1.2.3	Exiting Emergency and Returning to Normal State	420
28.2	SAS Routing.....	421
28.2.1	SAS Routing in Normal State	421
28.2.2	SAS Routing in Emergency State.....	423

29 SAS Configuration425

29.1	General SAS Configuration.....	425
29.1.1	Enabling the SAS Application.....	425
29.1.2	Configuring Common SAS Parameters.....	426
29.2	Configuring SAS Outbound Mode.....	428
29.3	Configuring SAS Redundant Mode	429
29.4	Configuring Gateway Application with SAS	429
29.4.1	Gateway with SAS Outbound Mode	430
29.4.2	Gateway with SAS Redundant Mode	431
29.5	Advanced SAS Configuration.....	433
29.5.1	Manipulating URI user part of Incoming REGISTER.....	433
29.5.2	Manipulating Destination Number of Incoming INVITE	434
29.5.3	SAS Routing Based on IP-to-IP Routing Table	437

29.5.4	Blocking Calls from Unregistered SAS Users.....	441
29.5.5	Configuring SAS Emergency Calls.....	441
29.5.6	Adding SIP Record-Route Header to SIP INVITE.....	442
29.5.7	Re-using TCP Connections.....	443
29.5.8	Replacing Contact Header for SIP Messages.....	443
29.6	Viewing Registered SAS Users.....	444
30	SAS Cascading.....	445
<hr/>		
IP Media Capabilities.....		447
31	Overview.....	449
32	Transcoding using Third-Party Call Control.....	451
32.1	Using RFC 4117.....	451
32.2	Using RFC 4240 - NetAnn 2-Party Conferencing.....	451
33	Conference Server.....	453
33.1	Simple Conferencing (NetAnn).....	453
33.1.1	SIP Call Flow.....	453
33.1.2	Creating a Conference.....	454
33.1.3	Joining a Conference.....	454
33.1.4	Terminating a Conference.....	454
33.1.5	PSTN Participants.....	455
33.2	Advanced Conferencing (MSCML).....	455
33.2.1	Creating a Conference.....	455
33.2.2	Joining a Conference.....	456
33.2.3	Modifying a Conference.....	457
33.2.4	Applying Media Services on a Conference.....	457
33.2.5	Active Speaker Notification.....	458
33.2.6	Terminating a Conference.....	458
33.3	Conference Call Flow Example.....	459
34	Announcement Server.....	467
34.1	NetAnn Interface.....	467
34.1.1	Playing a Local Voice Prompt.....	467
34.1.2	Playing using HTTP/NFS Streaming.....	467
34.1.3	Supported Attributes.....	468
34.2	MSCML Interface.....	469
34.2.1	Operation.....	470
34.2.2	Playing Announcements.....	471
34.2.3	Playing Announcements and Collecting Digits.....	471
34.2.4	Playing Announcements and Recording Voice.....	472
34.2.5	Stopping the Playing of an Announcement.....	473
34.2.6	Relevant Parameters.....	474
34.2.7	Signal Events Notifications.....	474
34.3	Voice Streaming.....	476
34.3.1	Voice Streaming Features.....	476
34.3.1.1	Basic Streaming Play.....	476
34.3.1.2	Supported File Formats.....	476
34.3.1.3	Play from Offset.....	476
34.3.1.4	Remote File Systems.....	476
34.3.1.5	Using Proprietary Scripts.....	476
34.3.1.6	Dynamic HTTP URLs.....	476

34.3.1.7	Play LBR Audio File	477
34.3.1.8	Basic Record	477
34.3.1.9	Remove DTMF Digits at End of Recording	477
34.3.1.10	Record Files Using LBR	477
34.3.1.11	Modifying Streaming Levels Timers	478
34.3.2	Using File Coders with Different Channel Coders	478
34.3.2.1	Playing a File	479
34.3.2.2	Recording a File	479
34.3.3	Maximum Concurrent Playing and Recording	479
34.3.4	LBR Coders Support	480
34.3.5	HTTP Recording Configuration	480
34.3.6	NFS Configuration Using the ini File	481
34.3.7	Supported HTTP Servers	481
34.3.7.1	Tuning the Apache Server	481
34.3.8	Supporting NFS Servers	482
34.3.8.1	Solaris-Based NFS Servers	483
34.3.8.2	Linux-Based NFS Servers	484
34.3.9	Common Troubleshooting	484
34.4	Announcement Call Flow Example	486

Maintenance.....489

35 Basic Maintenance.....491

35.1	Resetting the Device	491
35.2	Remotely Resetting Device using SIP NOTIFY	492
35.3	Locking and Unlocking the Device	493
35.4	Saving Configuration	494

36 Replacing Modules.....495

37 Resetting Channels.....497

37.1	Resetting an Analog Channel	497
37.2	Restarting a B-Channel	497

38 Software Upgrade.....499

38.1	Loading Auxiliary Files	499
38.1.1	Call Progress Tones File	502
38.1.1.1	Distinctive Ringing	504
38.1.2	Prerecorded Tones File	506
38.1.3	Voice Prompts File	507
38.1.4	CAS Files	507
38.1.5	Dial Plan File	508
38.1.5.1	Creating a Dial Plan File	508
38.1.5.2	Dialing Plans for Digit Collection	508
38.1.5.3	Dial Plan Prefix Tags for IP-to-Tel Routing	510
38.1.5.4	Obtaining IP Destination from Dial Plan File	512
38.1.5.5	Modifying ISDN-to-IP Calling Party Number	512
38.1.6	User Information File	514
38.1.6.1	User Information File for PBX Extensions and "Global" Numbers	514
38.1.6.2	Enabling the User Info Table	516
38.1.7	AMD Sensitivity File	516

39 Software License Key.....519

39.1	Obtaining the Software License Key File	519
39.2	Installing the Software License Key	520

39.2.1	Installing Software License Key using Web Interface	520
39.2.2	Loading via BootP/TFTP.....	522
39.3	Software Upgrade Wizard.....	522
39.4	Backing Up and Loading Configuration File.....	526
40	Automatic Update.....	527
40.1	BootP Request and DHCP Discovery upon Device Initialization	527
40.2	Obtaining IP Address Automatically using DHCP.....	529
40.3	Configuring Automatic Update	529
40.4	Automatic Configuration Methods	531
40.4.1	Local Configuration Server with BootP/TFTP.....	531
40.4.2	DHCP-based Configuration Server	532
40.4.3	Configuration using DHCP Option 67.....	532
40.4.4	TFTP Configuration using DHCP Option 66.....	533
40.4.5	HTTP-based Automatic Updates.....	533
40.4.6	Configuration using FTP or NFS	534
40.4.7	Configuration using AudioCodes EMS	534
40.5	Loading Files Securely (Disabling TFTP).....	534
40.6	Remotely Triggering Auto Update using SIP NOTIFY	535
41	Restoring Factory Defaults	537
41.1	Restoring Defaults using CLI	537
41.2	Restoring Defaults using Hardware Reset Button.....	537
41.3	Restoring Defaults using an ini File.....	538
Status, Performance Monitoring and Reporting		539
42	System Status	541
42.1	Viewing Device Information.....	541
42.2	Viewing Ethernet Port Information	542
43	Carrier-Grade Alarms.....	543
43.1	Viewing Active Alarms.....	543
43.2	Viewing Alarm History	543
44	Performance Monitoring.....	545
44.1	Viewing MOS per Media Realm	545
44.2	Viewing Trunk Utilization.....	546
45	VoIP Status	549
45.1	Viewing Trunks & Channels Status.....	549
45.2	Viewing Analog Port Information.....	551
45.3	Viewing NFAS Groups and D-Channel Status.....	551
45.4	Viewing Active IP Interfaces.....	552
45.5	Viewing Performance Statistics.....	552
45.6	Viewing Call Counters.....	553
45.7	Viewing Registered Users.....	555
45.8	Viewing Registration Status	556
45.9	Viewing Call Routing Status.....	557

45.10 Viewing IP Connectivity.....	558
46 Reporting Information to External Party	561
46.1 RTP Control Protocol Extended Reports (RTCP XR)	561
46.2 Generating Call Detail Records.....	564
46.2.1 Configuring CDR Reporting	564
46.2.2 CDR Field Description	565
46.2.2.1 CDR Fields for Gateway/IP-to-IP Application	565
46.2.2.2 Release Reasons in CDR	568
46.3 Configuring RADIUS Accounting	571
46.4 Event Notification using X-Detect Header	574
46.5 Querying Device Channel Resources using SIP OPTIONS	576
Diagnosics	577
47 Syslog and Debug Recordings	579
47.1 Syslog Message Format	579
47.1.1 Event Representation in Syslog Messages	580
47.1.2 Identifying AudioCodes Syslog Messages using Facility Levels	582
47.1.3 Syslog Fields for Automatic Machine Detection	582
47.1.4 SNMP Alarms in Syslog Messages	583
47.2 Configuring Syslog Settings	583
47.3 Configuring Debug Recording	584
47.4 Filtering Syslog Messages and Debug Recordings	585
47.4.1 Filtering IP Network Traces	587
47.5 Viewing Syslog Messages	588
47.6 Collecting Debug Recording Messages	589
48 Self-Testing.....	591
49 Analog Line Testing.....	593
50 Testing SIP Signaling Calls	595
50.1 Configuring Test Call Endpoints.....	595
50.1.1 Starting, Stopping and Restarting Test Calls.....	598
50.1.2 Viewing Test Call Statistics.....	599
50.2 Configuring DTMF Tones for Test Calls.....	600
50.3 Configuring Basic Test Call.....	601
50.4 Test Call Configuration Examples.....	602
Appendix	605
51 Dialing Plan Notation for Routing and Manipulation.....	607
52 Configuration Parameters Reference	609
52.1 Networking Parameters.....	609
52.1.1 Ethernet Parameters.....	609
52.1.2 Multiple VoIP Network Interfaces and VLAN Parameters	610
52.1.3 Routing Parameters.....	611
52.1.4 Quality of Service Parameters.....	612
52.1.5 NAT and STUN Parameters	614
52.1.6 NFS Parameters	615

52.1.7	DNS Parameters.....	616
52.1.8	DHCP Parameters.....	617
52.1.9	NTP and Daylight Saving Time Parameters.....	618
52.2	Management Parameters.....	619
52.2.1	General Parameters.....	619
52.2.2	Web Parameters.....	619
52.2.3	Telnet Parameters.....	623
52.2.4	SNMP Parameters.....	623
52.2.5	Serial Parameters.....	626
52.3	Debugging and Diagnostics Parameters.....	627
52.3.1	General Parameters.....	627
52.3.2	SIP Test Call Parameters.....	629
52.3.3	Syslog, CDR and Debug Parameters.....	630
52.3.4	Resource Allocation Indication Parameters.....	633
52.3.5	BootP Parameters.....	634
52.4	Security Parameters.....	635
52.4.1	General Parameters.....	635
52.4.2	HTTPS Parameters.....	636
52.4.3	SRTP Parameters.....	637
52.4.4	TLS Parameters.....	640
52.4.5	SSH Parameters.....	642
52.4.6	IPSec Parameters.....	643
52.4.7	OCSP Parameters.....	644
52.4.8	IDS Parameters.....	645
52.5	RADIUS Parameters.....	646
52.6	SIP Media Realm Parameters.....	648
52.7	Control Network Parameters.....	650
52.7.1	IP Group, Proxy, Registration and Authentication Parameters.....	650
52.7.2	Network Application Parameters.....	661
52.8	General SIP Parameters.....	662
52.9	Coders and Profile Parameters.....	690
52.10	Channel Parameters.....	694
52.10.1	Voice Parameters.....	694
52.10.2	Coder Parameters.....	697
52.10.3	DTMF Parameters.....	698
52.10.4	RTP, RTCP and T.38 Parameters.....	699
52.11	Gateway and IP-to-IP Parameters.....	704
52.11.1	Fax and Modem Parameters.....	704
52.11.2	DTMF and Hook-Flash Parameters.....	709
52.11.3	Digit Collection and Dial Plan Parameters.....	714
52.11.4	Voice Mail Parameters.....	716
52.11.5	Supplementary Services Parameters.....	721
52.11.5.1	Caller ID Parameters.....	721
52.11.5.2	Call Waiting Parameters.....	725
52.11.5.3	Call Forwarding Parameters.....	728
52.11.5.4	Message Waiting Indication Parameters.....	729
52.11.5.5	Call Hold Parameters.....	731
52.11.5.6	Call Transfer Parameters.....	732
52.11.5.7	Three-Way Conferencing Parameters.....	734
52.11.5.8	MLPP and Emergency Call Parameters.....	736
52.11.5.9	Call Cut-Through Parameters.....	742
52.11.5.10	Automatic Dialing Parameters.....	743
52.11.5.11	Direct Inward Dialing Parameters.....	743
52.11.5.12	ISDN BRI Parameters.....	745
52.11.5.13	TTY/TDD Parameters.....	746

52.11.6 PSTN Parameters.....	747
52.11.6.1 General Parameters	747
52.11.6.2 TDM Bus and Clock Timing Parameters.....	752
52.11.6.3 CAS Parameters	754
52.11.6.4 ISDN Parameters	757
52.11.7 ISDN and CAS Interworking Parameters	764
52.11.8 Answer and Disconnect Supervision Parameters	779
52.11.9 Tone Parameters	783
52.11.9.1 Telephony Tone Parameters.....	783
52.11.9.2 Tone Detection Parameters	790
52.11.9.3 Metering Tone Parameters	792
52.11.10 Telephone Keypad Sequence Parameters	793
52.11.11 General FXO Parameters.....	796
52.11.12 Trunk Groups and Routing Parameters	799
52.11.13 IP Connectivity Parameters.....	805
52.11.14 Alternative Routing Parameters	806
52.11.15 Number Manipulation Parameters.....	808
52.12 Least Cost Routing Parameters	818
52.13 LDAP Parameters	819
52.14 Standalone Survivability Parameters	821
52.15 IP Media Parameters	826
52.16 Auxiliary and Configuration File Name Parameters	834
52.17 Automatic Update Parameters	836
53 DSP Templates	839
53.1 Analog Interfaces	839
53.2 BRI Interfaces	840
53.3 E1/T1 Interfaces.....	841
53.4 Media Processing Interfaces.....	842
54 Selected Technical Specifications.....	845
54.1 Mediant 600	845
54.2 Mediant 1000	847

Notice

This document describes the AudioCodes Mediant 600 and Mediant 1000 Voice-over-IP (VoIP) SIP media gateways.

Information contained in this document is believed to be accurate and reliable at the time of printing. However, due to ongoing product improvements and revisions, AudioCodes cannot guarantee accuracy of printed material after the Date Published nor can it accept responsibility for errors or omissions. Before consulting this document, check the corresponding Release Notes regarding feature preconditions and/or specific support in this release. In cases where there are discrepancies between this document and the Release Notes, the information in the Release Notes supersedes that in this document. Updates to this document and other documents as well as software files can be downloaded by registered customers at <http://www.audiocodes.com/downloads>.

© Copyright 2013 AudioCodes Ltd. All rights reserved.

This document is subject to change without notice.

Date Published: April-29-2013

Trademarks

AudioCodes, AC, AudioCoded, Ardito, CTI2, CTI², CTI Squared, HD VoIP, HD VoIP Sounds Better, InTouch, IPmedia, Mediant, MediaPack, NetCoder, Netrake, Nuera, Open Solutions Network, OSN, Stretto, TrunkPack, VMAS, VoicePacketizer, VoIPerfect, VoIPerfectHD, What's Inside Matters, Your Gateway To VoIP and 3GX are trademarks or registered trademarks of AudioCodes Limited. All other products or trademarks are property of their respective owners. Product specifications are subject to change without notice.

WEEE EU Directive

Pursuant to the WEEE EU Directive, electronic and electrical waste must not be disposed of with unsorted waste. Please contact your local recycling authority for disposal of this product.

Customer Support

Customer technical support and service are generally provided by AudioCodes' Distributors, Partners, and Resellers from whom the product was purchased. For technical support for products purchased directly from AudioCodes, or for customers subscribed to AudioCodes Customer Technical Support (ACTS), contact support@audiocodes.com.

Abbreviations and Terminology

Each abbreviation, unless widely used, is spelled out in full when first used.

Throughout this manual, unless otherwise specified, the term *device* refers to the Mediant 600 and Mediant 1000.

Related Documentation

Manual Name
SIP CPE Release Notes
Mediant 600 Hardware Installation Manual
Mediant 1000 Hardware Installation Manual
CPE Configuration Guide for IP Voice Mail
DConvert User's Guide
CPTWizard User's Guide
SNMP User's Guide
AcBootP Utility User's Guide

Notes and Warnings



Note: The scope of this document does not fully cover security aspects for deploying the device in your environment. Security measures should be done in accordance with your organization's security policies. For basic security guidelines, you should refer to AudioCodes *Recommended Security Guidelines* document.



Note: Before configuring the device, ensure that it is installed correctly as instructed in the *Hardware Installation Manual*.



Note: This device is considered an **INDOOR** unit and therefore must be installed only indoors.



Notes:

- By default, the device supports export-grade (40-bit and 56-bit) encryption due to US government restrictions on the export of security technologies. To enable 128-bit and 256-bit encryption on your device, contact your AudioCodes sales representative.
- This device includes software developed by the OpenSSL Project for use in the OpenSSL Toolkit (<http://www.openssl.org/>).
- This device includes cryptographic software written by Eric Young (eay@cryptsoft.com).

Documentation Feedback

AudioCodes continually strives to produce high quality documentation. If you have any comments (suggestions or errors) regarding this document, please fill out the Documentation Feedback form on our Web site at <http://www.audiocodes.com/downloads>.

1 Overview

This section provides an overview of the Mediant 1000 and Mediant 600 media gateways.

1.1 Mediant 600

The Mediant 600 (hereafter referred to as *device*) is a cost-effective, wireline Voice-over-IP (VoIP) Session Initiation Protocol (SIP)-based media gateway. It is designed to interface between Time-Division Multiplexing (TDM) and IP networks in enterprises, small and medium businesses (SMB), and CPE application service providers. Incorporating AudioCodes' innovative VoIP technology, the device enables rapid time-to-market and reliable cost-effective deployment of next-generation networks.

The device is based on VoIPerfect, AudioCodes underlying, best-of-breed, media gateway core technology. The device provides superior voice technology for connecting legacy telephone and PBX systems to IP networks, as well as seamlessly connecting IP-PBXs to the PSTN. The device also provides SIP trunking capabilities for Enterprises operating with multiple Internet Telephony Service Providers (ITSP) for VoIP services. The device is fully interoperable with multiple vendors of IP-PBXs, IP Centrex application servers, softswitches, gateways, proxy servers, IP phones, Session Border Controllers and firewalls.

The device supports the following interfaces:

- Up to two E1/T1/J1 spans (including fractional E1/T1)
- Up to eight ISDN Basic Rate Interface (BRI) interfaces
- Up to four FXO interfaces (RJ-11 ports) - for connecting analog lines of an enterprise's PBX or the PSTN to the IP network
- Up to four FXS interfaces (RJ-11 ports) - for connecting legacy telephones, fax machines, and modems to the IP network. Optionally, the FXS interfaces can be connected to the external trunk lines of a PBX.

When deployed with a combination of FXO and FXS modules, the device can be used as a PBX for Small Office Home Office (SOHO) users, and businesses not equipped with a PBX. These interfaces can be provided in one of the following configurations:

- 1 x E1/T1 port (can support also Fractional E1/T1)
- 2 x E1/T1 ports
- 4 x BRI ports (supporting up to 8 voice calls)
- 8 x BRI ports (supporting up to 16 voice calls)
- 4 x BRI ports and 1 x E1/T1 port
- 4 x BRI ports and 4 x FXS ports
- 4 x BRI ports and 4 x FXO ports
- 4 x FXS ports and 1 x E1/T1 port
- 4 x FXO ports and 1 x E1/T1 port

The device supports various ISDN PRI protocols such as EuroISDN, North American NI2, Lucent™ 4/5ESS, Nortel™ DMS-100 and others, supporting different variants of CAS protocols, including MFC R2, E&M immediate start, E&M delay dial / start, loop- and ground-start signaling. The device also supports various ISDN BRI protocols such as ETSI 5ESS and QSIG over BRI. The device also provides dual Ethernet 10/100Base-TX ports for IP redundancy.

Intelligently packaged in a stackable 1U chassis, the compact device can be mounted on a desk or in a standard 19-inch rack.

The device provides a variety of management and provisioning tools, including an HTTP-based embedded Web server, Telnet, Element Management System (EMS), and Simple

Network Management Protocol (SNMP). The user-friendly, Web interface provides remote configuration using a Web browser (such as Microsoft™ Internet Explorer™).

1.2 Mediant 1000

The Mediant 1000 (hereafter referred to as *device*) is a best-of-breed Voice-over-IP (VoIP) Session Initiation Protocol (SIP) Media Gateway, using field-proven, market-leading technology, implementing analog and digital cutting-edge technology. The device is designed to seamlessly interface between Time-Division Multiplexing (TDM) and Internet Protocol (IP) networks, providing superior voice quality and optimized packet voice streaming (voice, fax, and data traffic) over IP networks.

The device is best suited for small-to-medium sized (SME) enterprises, branch offices, and residential media gateway solutions. The device is a highly scalable and modular system that matches the density requirements for smaller environments, while meeting service providers' demands for growth.

The device is ideal for connecting an enterprise's legacy telephones, fax machines, and Private Branch Exchange (PBX) systems to IP-based telephony networks, as well as for seamlessly connecting IP-based PBX architecture to the Public Switched Telephone Network (PSTN). The device also provides SIP trunking capabilities (including IP-to-IP call routing) for Enterprises operating with multiple Internet Telephony Service Providers (ITSP) for VoIP services. In addition to operating as a pure media gateway, the device incorporates an open platform, known as the Open Solutions Network (OSN) server, allowing additional deployment options by hosting third-party partner VoIP applications such as IP-PBX, Calling Card, and IP-PBX redundancy.

The device also provides conferencing services over VoIP networks. This is supported by an optional Media Processing Module (MPM) that can be housed in the device's chassis. The MPM module also provides IP Media channels for use on various Media Server applications.

The device is fully interoperable with multiple vendor gateways, softswitches, SIP servers, gatekeepers, proxy servers, IP phones, session border controllers (SBC), and firewalls. The device is designed to meet regulatory approval (including Safety, EMC, and Telecom for USA, EU and other countries).

Intelligently packaged in a stackable and compact 1U chassis, it can be mounted on a desk, a wall, or in a standard 19-inch rack. The device is supplied with two integral mounting brackets for facilitating rack installation.

The device is equipped with two 10/100Base-TX Ethernet ports for connection to the IP network. The second Ethernet port is used for 1+1 Ethernet redundancy.

The device supports mixed digital and analog interface configurations:

■ Digital:

- The device supports multiples of 1, 2, or 4 E1/T1/J1 spans for connecting the PSTN/PBX to the IP network. The digital modules provide RJ-48 ports. The digital module can be configured with up to 1 or 2 paired spans for switching to the PSTN in case of power or network failure (PSTN Fallback).
- The device also supports ISDN Basic Rate Interface (BRI) modules for connecting BRI-based PSTN or PBX lines to the IP network. Each BRI module supports four BRI ports (RJ-45). Up to five BRI modules can be housed in the device, supporting up to 20 BRI digital ports. The BRI module can be configured as 'Lifeline' telephone interfaces, switching to the PSTN in case of power failure or network problems.
- Depending on configuration, the device can provide IP Media channels at the expense of PSTN channels. These channels may be used for Media Server applications.

- **Analog:** The device's analog interface supports up to 24 analog ports (four ports per analog module) in various Foreign Exchange Office (FXO) or Foreign Exchange Station (FXS) configurations, supporting up to 24 simultaneous VoIP calls. The device

supports up to six analog modules, each module providing four analog RJ-11 ports. The FXO module can be used to connect analog lines of an enterprise's PBX or the PSTN to the IP network. The FXS module can be used to connect legacy telephones, fax machines, and modems to the IP network. Optionally, the FXS module can be connected to the external trunk lines of a PBX. When deployed with a combination of FXO and FXS modules, the device can be used as a PBX for Small Office Home Office (SOHO) users, and businesses not equipped with a PBX.

- **Media Processing Module (MPM):** The MPM module provides IP media channels for conferencing and media server functionality. The device can house up to three MPM modules.

The device has enhanced hardware and software capabilities to ease its installation and to maintain voice quality. If the measured voice quality falls beneath a pre-configured value, or the path to the destination is disconnected, the device assures voice connectivity by 'falling' back to the PSTN. In the event of network problems or power failures, calls can be routed back to the PSTN without requiring routing modifications in the PBX. Further reliability is provided by dual Ethernet ports and an optional dual AC power supply.

The device supports various ISDN PRI protocols such as EuroISDN, North American NI2, Lucent™ 4/5ESS, Nortel™ DMS-100 and others. It also supports various ISDN BRI protocols such as ETSI 5ESS and QSIG over BRI. It also supports different variants of CAS protocols for E1 and T1 spans, including MFC R2, E&M immediate start, E&M delay dial / start, loop start and ground start.

The device provides a variety of management and provisioning tools, including an HTTP-based embedded Web server, Telnet, Element Management System (EMS), and Simple Network Management Protocol (SNMP). The user-friendly, Web interface provides remote configuration using a Web browser (such as Microsoft™ Internet Explorer™).

1.3 SIP Overview


Session Initiation Protocol (SIP) is an application-layer control (signaling) protocol used on the gateway for creating, modifying, and terminating sessions with one or more participants. These sessions can include Internet telephone calls, media announcements, and conferences.

SIP invitations are used to create sessions and carry session descriptions that enable participants to agree on a set of compatible media types. SIP uses elements called Proxy servers to help route requests to the user's current location, authenticate and authorize users for services, implement provider call-routing policies and provide features to users.

SIP also provides a registration function that enables users to upload their current locations for use by Proxy servers. SIP implemented in the gateway, complies with the Internet Engineering Task Force (IETF) RFC 3261 (refer to <http://www.ietf.org>).

The SIP call flow, shown in the figure below, describes SIP messages exchanged between two devices during a basic call. In this call flow example, device 10.8.201.158 with phone number 6000, dials device 10.8.201.161 with phone number 2000.

Figure 1-1: SIP Call Flow



■ **F1 INVITE - 10.8.201.108 to 10.8.201.161:**

```

INVITE sip:2000@10.8.201.161;user=phone SIP/2.0
Via: SIP/2.0/UDP 10.8.201.108;branch=z9hG4bKacsiJkDGd
From: <sip:6000@10.8.201.108>;tag=1c5354
To: <sip:2000@10.8.201.161>
Call-ID: 534366556655skKw-6000--2000@10.8.201.108
CSeq: 18153 INVITE
Contact: <sip:8000@10.8.201.108;user=phone>
User-Agent: Audiocodes-Sip-Gateway/Mediant 1000/v.6.60.010.006
Supported: 100rel,em
Allow: REGISTER,OPTIONS,INVITE,ACK,CANCEL,BYE,
NOTIFY,PRACK,REFER,INFO
Content-Type: application/sdp
Content-Length: 208

v=0
o=AudiocodesGW 18132 74003 IN IP4 10.8.201.108
s=Phone-Call
c=IN IP4 10.8.201.108
t=0 0
m=audio 4000 RTP/AVP 8 96
a=rtpmap:8 pcma/8000
a=rtpmap:96 telephone-event/8000
a=fmtp:96 0-15
a=ptime:20
    
```

- **F2 TRYING - 10.8.201.161 to 10.8.201.108:**

```
SIP/2.0 100 Trying
Via: SIP/2.0/UDP 10.8.201.108;branch=z9hG4bKacsiJkDGd
From: <sip:6000@10.8.201.108>;tag=1c5354
To: <sip:2000@10.8.201.161>
Call-ID: 534366556655skKw-6000--2000@10.8.201.108
Server: Audiocodes-Sip-Gateway/Mediant 1000/v.6.60.010.006
CSeq: 18153 INVITE
Content-Length: 0
```

- **F3 RINGING 180 - 10.8.201.161 to 10.8.201.108:**

```
SIP/2.0 180 Ringing
Via: SIP/2.0/UDP 10.8.201.108;branch=z9hG4bKacsiJkDGd
From: <sip:6000@10.8.201.108>;tag=1c5354
To: <sip:2000@10.8.201.161>;tag=1c7345
Call-ID: 534366556655skKw-6000--2000@10.8.201.108
Server: Audiocodes-Sip-Gateway/Mediant 1000/v.6.60.010.006
CSeq: 18153 INVITE
Supported: 100rel,em
Content-Length: 0
```



Note: Phone 2000 answers the call and then sends a SIP 200 OK response to device 10.8.201.108.

- **F4 200 OK - 10.8.201.161 to 10.8.201.108:**

```
SIP/2.0 200 OK
Via: SIP/2.0/UDP 10.8.201.108;branch=z9hG4bKacsiJkDGd
From: <sip:6000@10.8.201.108>;tag=1c5354
To: <sip:2000@10.8.201.161>;tag=1c7345
Call-ID: 534366556655skKw-6000--2000@10.8.201.108
CSeq: 18153 INVITE
Contact: <sip:2000@10.8.201.161;user=phone>
Server: Audiocodes-Sip-Gateway/Mediant 1000/v.6.60.010.006
Supported: 100rel,em
Allow: REGISTER,OPTIONS,INVITE,ACK,CANCEL,BYE,
NOTIFY,PRACK,REFER,INFO
Content-Type: application/sdp
Content-Length: 206

v=0
o=AudiocodesGW 30221 87035 IN IP4 10.8.201.161
s=Phone-Call
c=IN IP4 10.8.201.10
t=0 0
m=audio 7210 RTP/AVP 8 96
a=rtpmap:8 pcma/8000
a=ptime:20
a=rtpmap:96 telephone-event/8000
a=fmtp:96 0-15
```

- **F5 ACK - 10.8.201.108 to 10.8.201.10:**

```
ACK sip:2000@10.8.201.161;user=phone SIP/2.0
Via: SIP/2.0/UDP 10.8.201.108;branch=z9hG4bKacZYpJWxZ
From: <sip:6000@10.8.201.108>;tag=1c5354
To: <sip:2000@10.8.201.161>;tag=1c7345
Call-ID: 534366556655skKw-6000--2000@10.8.201.108
User-Agent: Audiocodes-Sip-Gateway/Mediant 1000/v.6.60.010.006
CSeq: 18153 ACK
Supported: 100rel,em
Content-Length: 0
```



Note: Phone 6000 goes on-hook and device 10.8.201.108 sends a BYE to device 10.8.201.161 and a voice path is established.

- **F6 BYE - 10.8.201.108 to 10.8.201.10:**

```
BYE sip:2000@10.8.201.161;user=phone SIP/2.0
Via: SIP/2.0/UDP 10.8.201.108;branch=z9hG4bKacRKCVBud
From: <sip:6000@10.8.201.108>;tag=1c5354
To: <sip:2000@10.8.201.161>;tag=1c7345
Call-ID: 534366556655skKw-6000--2000@10.8.201.108
User-Agent: Audiocodes-Sip-Gateway/Mediant 1000/v.6.60.010.006
CSeq: 18154 BYE
Supported: 100rel,em
Content-Length: 0
```

- **F7 OK 200 - 10.8.201.10 to 10.8.201.108:**

```
SIP/2.0 200 OK
Via: SIP/2.0/UDP 10.8.201.108;branch=z9hG4bKacRKCVBud
From: <sip:6000@10.8.201.108>;tag=1c5354
To: <sip:2000@10.8.201.161>;tag=1c7345
Call-ID: 534366556655skKw-6000--2000@10.8.201.108
Server: Audiocodes-Sip-Gateway/Mediant 1000/v.6.60.010.006
CSeq: 18154 BYE
Supported: 100rel,em
Content-Length: 0
```

Part I

Getting Started with Initial Connectivity

2 Assigning the OAMP IP Address

The device is shipped with a factory default IP address for its operations, administration, maintenance, and provisioning (OAMP) interface, as shown in the table below:

Default VoIP OAMP IP Address

IP Address	Value
IP Address	10.1.10.10
Subnet Mask	255.255.0.0
Default Gateway IP Address	0.0.0.0

The default IP address can be used for initially accessing the device, using any of its management tools (i.e., embedded Web server, EMS, or Telnet). Once accessed, you can change this default IP address to correspond with your networking scheme in which the device is deployed. After changing the IP address, you can re-access the device with this new OAMP IP address and start configuring and managing the device as desired.

This section describes the different methods for changing the device's default IP address to suit your networking environment:

- Embedded command line interface (CLI) - see 'CLI' on page 30
- Embedded HTTP/S-based Web server - see 'Web Interface' on page 27
- Bootstrap Protocol (BootP) - see BootP/TFTP Server on page 29
- FXS telephone voice menu - see FXS Voice Menu Guidance on page 31


2.1 Web Interface

The procedure below describes how to assign a new OAMP IP address using the Web interface.


➤ **To assign an OAMP address using the Web interface:**

1. Disconnect the network cables (if connected) from the device.
2. Connect one of the Ethernet ports located on the CPU module directly to the network interface of your computer, using a straight-through Ethernet cable.

Figure 2-1: Cabling to PC



3. Change the IP address and subnet mask of your computer to correspond with the default IP address and subnet mask of the device.
4. Access the Web interface:
 - a. On your computer, start a Web browser and in the URL address field, enter the default IP address of the device; the Web interface's Login screen appears:

Figure 2-2: Web Login Screen



Web Login

Username
Admin

Password

Remember Me Login

- b. In the 'Username' and 'Password' fields, enter the default login user name ("Admin" - case-sensitive) and password ("Admin" - case-sensitive), and then click **Login**; the device's Web interface is accessed.
5. Change the default IP address to one that corresponds with your network:
 - a. Open the Multiple Interface Table page (**Configuration** tab > **VoIP** menu > **Network** submenu > **IP Settings**).

Figure 2-3: IP Settings Page (Single Network Interface)


IP Settings

Single IP Settings	
IP Address	10.1.10.10
Subnet Mask	255.255.0.0
Default Gateway Address	0.0.0.0

VoIP DNS Settings

DNS Primary Server IP	
DNS Secondary Server IP	

Multiple Interface Settings

Multiple Interface Table	
--------------------------	--

Submit

- b. Select the 'Index' radio button corresponding to the "OAMP + Media + Control" application type, and then click **Edit**.
 - c. Change the IP address, subnet mask, and Default Gateway IP address to correspond with your network IP addressing scheme.
 - d. Click **Apply**, and then click **Done** to validate your settings.
6. Save your settings to the flash memory with a device reset (see Resetting the Device on page 491).
7. Disconnect the computer from the device and then reconnect the device to your network.

2.2 BootP/TFTP Server

You can assign an IP address to the device using BootP/TFTP protocols. This can be done using the AudioCodes AcBootP utility (supplied) or any standard compatible BootP server.




Note: You can also use the AcBootP utility to load the software file (.cmp) and configuration file (.ini). For a detailed description of the AcBootP utility, refer to *AcBootP Utility User's Guide*.

➤ **To assign an IP address using BootP/TFTP:**

1. Start the AcBootP utility.
2. Select the **Preferences** tab, and then set the 'Timeout' field to "50".
3. Select the **Client Configuration** tab, and then click the **Add New Client** button.

Figure 2-4: BootP Client Configuration Screen



4. Configure the following fields:
 - 'Client MAC': Enter the device's MAC address. The MAC address is printed on the label located on the underside of the device. Ensure that the check box to the right of the field is selected in order to enable the client.
 - 'Client IP': Enter the new IP address (in dotted-decimal notation) that you want to assign the device.
 - 'Subnet': Enter the new subnet mask (in dotted-decimal notation) that you want to assign the device.
 - 'Gateway': Enter the IP address of the Default Gateway (if required).
5. Click **Apply** to save the new client.
6. Physically reset the device by powering it down and then up again. This enables the device to receive its new networking parameters through the BootP process.


2.3 CLI

The procedure below describes how to assign an OAMP IP address, using CLI.

➤ **To assign an OAMP IP address using CLI:**

1. Connect the RS-232 port of the device to the serial communication port on your computer. For more information, refer to the *Hardware Installation Manual*.

Figure 2-5: Serial Cabling to PC



2. Establish serial communication with the device using a terminal emulator program (such as HyperTerminal) with the following communication port settings:
 - Baud Rate: 115,200 bps
 - Data Bits: 8
 - Parity: None
 - Stop Bits: 1
 - Flow Control: None
3. At the prompt, type the following command to access the configuration folder, and then press Enter:


```
conf
```
4. At the prompt, type the following command to view the current network settings, and then press Enter:


```
GCP IP
```
5. At the prompt, typing the following command to change the network settings, and then press Enter:


```
SCP IP <ip_address> <subnet_mask> <default_gateway>
```

You must enter all three network parameters, each separated by a space, for example:

```
SCP IP 10.13.77.7 255.255.0.0 10.13.0.1
```
6. At the prompt, type the following command to save the settings and reset the device, and then press Enter:


```
SAR
```

2.4 FXS Voice Menu Guidance

You can assign an IP address that suits your networking scheme using a standard touch-tone telephone connected to one of the FXS ports. The FXS voice menu can also be used to query and modify basic configuration parameters.



Notes: If you want to disable the FXS voice menu, do one of the following:

- Set the VoiceMenuPassword parameter to 'disable'.
- Change the Web login password for the Admin user from its default value (i.e., "Admin") to any other value, and then reset the device.

➤ **To assign an IP address using the voice menu:**

1. Connect a telephone to one of the FXS ports.
2. Lift the handset and dial *****12345** (three stars followed by the digits 1, 2, 3, 4, and 5).
3. Wait for the 'configuration menu' voice prompt to be played.
4. To change the IP address:
 - a. Press **1** followed by the pound key (**#**); the current IP address of the device is played.
 - b. Press the **#** key.
 - c. Dial the new IP address, using the star (*) key instead of periods (.), e.g., 192*168*0*4, and then press **#** to finish.
 - d. Review the new IP address, and then press **1** to save.
5. To change the subnet mask:
 - a. Press **2** followed by the **#** key; the current subnet mask of the device is played.
 - b. Press the **#** key.
 - c. Dial the new subnet mask (e.g., 255*255*0*0), and then press **#** to finish.
 - d. Review the new subnet mask, and then press **1** to save.
6. To change the Default Gateway IP address:
 - a. Press **3** followed by the **#** key; the current Default Gateway address is played.
 - b. Press the **#** key.
 - c. Dial the new Default Gateway address (e.g., 192*168*0*1), and then press **#** to finish.
 - d. Review the new Default Gateway address, and then press **1** to save.
7. Hang up (on-hook) the handset.

Alternatively, initial configuration may be performed using an HTTP server, as discussed in the 'Automatic Update' on page 527. The Voice Menu may be used to specify the configuration URL.

➤ **To set a configuration URL:**

1. Obtain the IP address of the configuration HTTP server (e.g., 36.44.0.6).
2. Connect a telephone to one of the FXS ports.
3. Lift the handset and dial *****12345** (three stars followed by the digits 1, 2, 3, 4, and 5).
4. Wait for the "configuration menu" voice prompt to be played.
5. Dial **31** followed by the **#** key; the current IP address is played.
6. To change the IP address:
 - a. Press the **#** key.
 - b. Dial the configuration server's IP address. Use the star (*) key instead of dots ("."), e.g., 36*44*0*6, and then press **#** to finish.
 - c. Review the configuration server's IP address, and then press **1** to save.
7. Dial **32** followed by the **#** key, and then do the following to change the configuration file name pattern:
 - a. Press the **#** key.
 - b. Select one of the patterns listed in the table below (*aa.bb.cc.dd* denotes the IP address of the configuration server):

#	Configuration File Name Pattern	Description
1	http://aa.bb.cc.dd/config.ini	Standard config.ini.
2	https://aa.bb.cc.dd/config.ini	Secure HTTP.
3	http://aa.bb.cc.dd/audiocodes/<MAC>.ini	The device's MAC address is appended to the file name (e.g., http://36.44.0.6/audiocodes/00908f012300.ini).
4	http://aa.bb.cc.dd:8080/config.ini	HTTP on port 8080.
5	http://aa.bb.cc.dd:1400/config.ini	HTTP on port 1400.
6	http://aa.bb.cc.dd/cgi-bin/acconfig.cgi?mac=<MAC>&ip=<IP>	Generating configuration per IP/MAC address dynamically, using a CGI script. See perl example below.

- a. Press the selected pattern code, and then press **#** to finish.
8. Press **1** to save, and then hang up the handset. The device retrieves the configuration from the HTTP server.

The following is an example perl CGI script, suitable for most Apache-based HTTP servers for generating configuration dynamically per pattern #6 above. Copy this script to /var/www/cgi-bin/acconfig.cgi on your Apache server and edit it as required:

```
#!/usr/bin/perl
use CGI;
$query = new CGI;
$mac = $query->param('mac');
$ip = $query->param('ip');
print "Content-type: text/plain\n\n";
print "; INI file generator CGI\n";
print "; Request for MAC=$mac IP=$ip\n\n";
print <<"EOF";
```

```
SyslogServerIP = 36.44.0.15
EnableSyslog = 1
SSHServerEnable = 1
EOF
```

The table below lists the configuration parameters that can be viewed and modified using the voice menu:

Voice Menu Configuration Parameters

Item Number at Menu Prompt	Description
1	IP address.
2	Subnet mask.
3	Default Gateway IP address.
4	Primary DNS server IP address.
7	DHCP enable / disable.
31	Configuration server IP address.
32	Configuration file name pattern.
99	Voice menu password (initially 12345). Note: The voice menu password can also be changed using the Web interface or <i>ini</i> file parameter VoiceMenuPassword.

Reader's Notes

Part II

Management Tools

3 Introduction

This part provides an overview of the various management tools that can be used to configure the device. It also provides step-by-step procedures on how to configure the management settings.

The following management tools can be used to configure the device:

- Embedded HTTP/S-based Web server - see 'Web-based Management' on page [39](#)
- Command Line Interface (CLI) - see 'CLI-Based Management' on page [75](#)
- AudioCodes Element Management System - see EMS-Based Management on page [91](#)
- Simple Network Management Protocol (SNMP) browser software - see 'SNMP-Based Management' on page [85](#)
- Configuration *ini* file - see 'INI File-Based Management' on page [93](#)

**Notes:**

- Some configuration settings can only be done using a specific management tool. For example, some configuration can only be done using the Configuration *ini* file method.
- Throughout this manual, where a parameter is mentioned, its corresponding Web, CLI, and ini parameter is mentioned. The *ini* file parameters are enclosed in square brackets [...].
- For a list and description of all the configuration parameters, see 'Configuration Parameters Reference' on page [609](#).

Reader's Notes

4 Web-Based Management

The device provides an embedded Web server (hereafter referred to as *Web interface*), supporting fault management, configuration, accounting, performance, and security (FCAPS), including the following:

- Full configuration
- Software and configuration upgrades
- Loading auxiliary files, for example, the Call Progress Tones file
- Real-time, online monitoring of the device, including display of alarms and their severity
- Performance monitoring of voice calls and various traffic parameters

The Web interface provides a user-friendly, graphical user interface (GUI), which can be accessed using any standard Web browser (e.g., Microsoft™ Internet Explorer).

Access to the Web interface is controlled by various security mechanisms such as login user name and password, read-write privileges, and limiting access to specific IP addresses.



Notes:

- The Web interface allows you to configure most of the device's settings. However, additional configuration parameters may exist that are not available in the Web interface and which can only be configured using other management tools.
- Some Web interface pages and/or parameters are available only for certain hardware configurations or software features. The software features are determined by the installed Software License Key (see 'Loading Software License Key' on page 522).

4.1 Getting Acquainted with the Web Interface

This section provides a description of the Web interface.

4.1.1 Computer Requirements

The client computer requires the following to work with the Web interface of the device:

- A network connection to the device
- One of the following Web browsers:
 - Microsoft™ Internet Explorer™ (Version 6.0 and later)
 - Mozilla Firefox® (Versions 5 through 9.0)
- Recommended screen resolutions: 1024 x 768 pixels, or 1280 x 1024 pixels



Note: Your Web browser must be JavaScript-enabled to access the Web interface.


4.1.2 Accessing the Web Interface

The procedure below describes how to access the Web interface.

➤ **To access the Web interface:**

1. Open a standard Web browser (see 'Computer Requirements' on page 39).
2. In the Web browser, specify the IP address of the device (e.g., <http://10.1.10.10>); the Web interface's Login window appears, as shown below:

Figure 4-1: Web Login Screen



3. In the 'Username' and 'Password' fields, enter the case-sensitive, user name and password respectively.
4. Click **Login**; the Web interface is accessed, displaying the Home page. For a detailed description of the Home page, see 'Viewing the Home Page' on page 61.

Notes:


- The default username and password is "Admin". To change the login user name and password, see 'Configuring the Web User Accounts' on page 64.
- If you want the Web browser to remember your password, select the 'Remember Me' check box and then agree to the browser's prompt (depending on your browser) to save the password for future logins. On your next login attempt, simply press the Tab or Enter keys to auto-fill the 'Username' and 'Password' fields, and then click **Login**.



4.1.3 Areas of the GUI

The areas of the Web interface's GUI are shown in the figure below and described in the subsequent table.

Figure 4-2: Main Areas of the Web Interface GUI



Description of the Web GUI Areas

Item #	Description
1	Displays AudioCodes (corporate) logo image.
2	Displays the product name.
3	Toolbar, providing frequently required command buttons. For more information, see 'Toolbar Description' on page 42.
4	Displays the username of the Web user that is currently logged in.
5	Navigation bar, providing the following tabs for accessing various functionalities in the Navigation tree: <ul style="list-style-type: none"> ▪ Configuration, Maintenance, and Status & Diagnostics tabs: Access the configuration menus (see 'Working with Configuration Pages' on page 45) ▪ Scenarios tab: Creates configuration scenarios (see Working with Scenarios on page 52) ▪ Search tab: Enables a search engine for searching configuration parameters (see 'Searching for Configuration Parameters' on page 51)
6	Navigation tree, displaying a tree-like structure of elements (configuration menus, Scenario steps, or search engine) pertaining to the selected tab on the Navigation bar. For more information, see 'Navigation Tree' on page 43.
7	Work pane, displaying the configuration page of the selected menu in the Navigation tree. This is where configuration is done. For more information, see 'Working with Configuration Pages' on page 45.

4.1.4 Toolbar Description

The toolbar provides frequently required command buttons, described in the table below:

Description of Toolbar Buttons

Icon	Button Name	Description
	Submit	Applies parameter settings to the device (see 'Saving Configuration' on page 494). Note: This icon is grayed out when not applicable to the currently opened page.
	Burn	Saves parameter settings to flash memory (see 'Saving Configuration' on page 494).
	Device Actions	Opens a drop-down list with frequently needed commands: <ul style="list-style-type: none"> ▪ Load Configuration File: Opens the Configuration File page for loading an <i>ini</i> file to the device (see 'Backing Up and Loading Configuration File' on page 526). ▪ Save Configuration File: Opens the Configuration File page for saving the <i>ini</i> file to a folder on a computer (see 'Backing Up and Loading Configuration File' on page 526). ▪ Reset: Opens the Maintenance Actions page for performing various maintenance procedures such as resetting the device (see 'Resetting the Device' on page 491). ▪ Software Upgrade Wizard: starts the Software Upgrade wizard for upgrading the device's software (see 'Software Upgrade Wizard' on page 522).
	Home	Opens the Home page (see 'Viewing the Home Page' on page 61).
	Help	Opens the Online Help topic of the currently opened configuration page (see 'Getting Help' on page 59).
	Log off	Logs off a session with the Web interface (see 'Logging Off the Web Interface' on page 60).



Note: If you modify a parameter that takes effect only after a device reset, after you click the **Submit** button in the configuration page, the toolbar displays "Reset", as shown in the figure below. This is a reminder that you need to later save your settings to flash memory and reset the device.

Figure 4-3: "Reset" Displayed on Toolbar




4.1.5 Navigation Tree

The Navigation tree is located in the Navigation pane and displays a tree-like structure of menus pertaining to the selected tab on the Navigation bar. You can drill-down to the required page item level to open its corresponding page in the Work pane.

The terminology used throughout this manual for referring to the hierarchical structure of the tree is as follows:

- *Menu*: first level (highest level)
- *Submenu*: second level - contained within a menu
- *Page item*: last level (lowest level in a menu) - contained within a menu or submenu

Figure 4-4: Navigating in Hierarchical Menu Tree (Example)



Note: The figure above is used only as an example. The displayed menus depend on supported features based on the Software License Key installed on your device.

4.1.5.1 Displaying Navigation Tree in Basic and Full View


You can view an expanded or reduced display of the Navigation tree. This affects the number of displayed menus and submenus in the tree. The expanded (*Full*) view displays all the menus pertaining to the selected configuration tab; the reduced (*Basic*) view displays only commonly used menus. This is relevant when using the configuration tabs

(i.e., **Configuration**, **Maintenance**, and **Status & Diagnostics**) on the Navigation bar. The advantage of the Basic view is that it prevents "cluttering" of the Navigation tree with menus that may not be required.

➤ **To toggle between Full and Basic view:**

- To display a reduced menu tree, select the **Basic** option (default).
- To display all the menus and submenus in the Navigation tree, select the **Full** option.

Figure 4-5: Basic and Full View Options



Notes:

- After you reset the device, the Web GUI is displayed in Basic view.
- When in Scenario mode (see Scenarios on page 52), the Navigation tree is displayed in Full view.

4.1.5.2 Showing / Hiding the Navigation Pane


You can hide the Navigation pane to provide more space for elements displayed in the Work pane. This is especially useful when the Work pane displays a wide table. The arrow button located below the Navigation bar is used to hide and show the pane.

➤ **To hide and show the Navigation pane:**

- **To hide the Navigation pane:** Click the left-pointing arrow ; the pane is hidden and the button is replaced by the right-pointing arrow button.

- **To show the Navigation pane:** Click the right-pointing arrow ; the pane is displayed and the button is replaced by the left-pointing arrow button.

Figure 4-6: Show and Hide Button (Navigation Pane in Hide View)



4.1.6 Working with Configuration Pages

The configuration pages contain the parameters for configuring the device and are displayed in the Work pane.

4.1.6.1 Accessing Pages

The configuration pages are accessed by clicking the required page item in the Navigation tree.

➤ To open a configuration page:

1. On the Navigation bar, click the required tab (**Configuration**, **Maintenance**, or **Status & Diagnostics**); the menus pertaining to the selected tab appear in the Navigation tree.
2. Navigate to the required page item, by performing the following:
 - Drill-down using the **plus**  sign to expand the menu and submenus.
 - Drill-up using the **minus**  sign to collapse the menu and submenus.
3. Click the required page item; the page opens in the Work pane.

You can also access previously opened pages by clicking the Web browser's **Back** button until you have reached the required page. This is useful if you want to view pages in which you have performed configurations in the current Web session.

Notes:

- You can also access certain pages from the **Device Actions** button located on the toolbar (see 'Toolbar Description' on page 42).
- To view all the menus in the Navigation tree, ensure that the Navigation tree is in Full view (see 'Displaying Navigation Tree in Basic and Full View' on page 43).
- To get Online Help for the currently displayed page, see 'Getting Help' on page 59.
- Certain pages may not be accessible or may be read-only, depending on the access level of your Web user account (see 'Configuring Web User Accounts' on page 64). If a page is read-only, "Read-Only Mode" is displayed at the bottom of the page.



4.1.6.2 Viewing Parameters

Some pages allow you to view a reduced or expanded display of parameters. The Web interface provides two methods for displaying page parameters:

- Displaying "basic" and "advanced" parameters - see 'Displaying Basic and Advanced Parameters' on page 46
- Displaying parameter groups - see 'Showing / Hiding Parameter Groups' on page 47


4.1.6.2.1 Displaying Basic and Advanced Parameters

Some pages provide a toggle button that allows you to show and hide parameters that typically are used only in certain deployments. This button is located on the top-right corner of the page and has two display states:

- **Advanced Parameter List** button with down-pointing arrow: click this button to display all parameters.
- **Basic Parameter List** button with up-pointing arrow: click this button to show only common (*basic*) parameters.

The figure below shows an example of a page displaying basic parameters only. If you click the **Advanced Parameter List** button (shown below), the page will also display the advanced parameters.

Figure 4-7: Toggling between Basic and Advanced View



Notes:


- When the Navigation tree is in Full mode (see 'Navigation Tree' on page 43), configuration pages display all their parameters.
- If a page contains only basic parameters, the **Basic Parameter List** button is not displayed.
- If you reset the device, the Web pages display only the basic parameters.
- The basic parameters are displayed in a dark blue background.



4.1.6.2.2 Showing / Hiding Parameter Groups

Some pages provide groups of parameters, which can be hidden or shown. To toggle between hiding and showing a group, simply click the group title button that appears above each group. The button appears with a down-pointing or up-pointing arrow, indicating that it can be collapsed or expanded when clicked, respectively.


Figure 4-8: Expanding and Collapsing Parameter Groups



4.1.6.3 Modifying and Saving Parameters

When you modify a parameter value on a page, the **Edit**  symbol appears to the right of the parameter. This indicates that the parameter has been modified, but has yet to be applied (submitted). After you apply your modifications, the  symbol disappears.

Figure 4-9: Edit Symbol after Modifying Parameter Value



- **To save configuration changes on a page to the device's volatile memory (RAM), do one of the following:**

- On the toolbar, click the **Submit**  button.
- At the bottom of the page, click the **Submit**  button.


When you click **Submit**, modifications to parameters with on-the-fly capabilities are immediately applied to the device and take effect. Parameters displayed on the page with the lightning  symbol take effect only after a device reset. For resetting the device, see 'Resetting the Device' on page 491.



Note: Parameters saved to the volatile memory (by clicking **Submit**), revert to their previous settings after a hardware or software reset, or if the device is powered down. Therefore, to ensure parameter changes (whether on-the-fly or not) are retained, save ('burn') them to the device's non-volatile memory, i.e., flash (see 'Saving Configuration' on page 494).

If you enter an invalid parameter value (e.g., not in the range of permitted values) and then click **Submit**, a message box appears notifying you of the invalid value. In addition, the parameter value reverts to its previous value and is highlighted in red, as shown in the figure below:

Figure 4-10: Value Reverts to Previous Valid Value




4.1.6.4 Working with Tables

This section describes how to work with configuration tables, which are provided in basic or enhanced design, depending on the configuration page.

4.1.6.4.1 Basic Design Tables

A few of the tables in the Web interface are in basic design format. The figure below displays a typical table in the basic design format and the subsequent table describes its command buttons.

Figure 4-11: Adding an Index Entry to a Table



Basic Table Design Description


Item #	Button / Field	
1	Add Index (or Add) button	Adds an index entry row to the table.
2	Edit	Edits the selected row.
3	Delete	Removes the selected row from the table.
4	'Add Index' field	Defines the index number. When adding a new row, enter the required index number in this field, and then click Add

Item #	Button / Field	Index.
5	Index radio button	Selects the row for editing and deleting.
-	Compact button	Organizes the index entries in ascending, consecutive order, starting from index 0. For example, assume you have three index entries, 0, 4 and 6. After you click Compact , index entry 4 is re-assigned to index 1 and index entry 6 is re-assigned to index 2.
-	Apply button	Saves the row configuration. Click this button after you add or edit each index entry.

4.1.6.4.2 Enhanced Design Tables


Most of the tables in the Web interface are designed in the enhanced table format. The figure below displays a typical table in the enhanced design format and the subsequent table describes its command buttons and areas.

Figure 4-12: Displayed Details Pane



Enhanced Table Design Description

Item #	Button	
1	Add	Adds a new index entry row to the table. When you click this button, a dialog box appears with parameters for configuring the new entry. When you have completed configuration, click the Submit button in the dialog box to add it to the table.
2	Edit	Edits the selected row.
3	Delete	Removes the selected row from the table. When you click this button, a confirmation box appears requesting you to confirm deletion. Click Delete to accept deletion.

Item #	Button	
		
4	Show/Hide	Toggles between displaying and hiding the full configuration of a selected row. This configuration is displayed below the table (see Item #6) and is useful for large tables that cannot display all its columns in the work pane.
5	-	Selected index row entry for editing, deleting and showing configuration.
6	-	Displays the full configuration of the selected row when you click the Show/Hide button.
7	-	Links to access additional configuration tables related to the current configuration.


If the configuration of an entry row is invalid, the index of the row is highlighted in red, as shown below:

Figure 4-13: Invalid Configuration with Index Highlighted in Red



The table also enables you to define the number of rows to display on the page and to navigate between pages displaying multiple rows. This is done using the page navigation area located below the table, as shown in the figure below:

Figure 4-14: Viewing Table Rows per Page



Row Display and Page Navigation

Item #	Description
1	Defines the page that you want to view. Enter the required page number or use the following page navigation buttons: <ul style="list-style-type: none"> ▪  - Displays the next page ▪  - Displays the last page ▪  - Displays the previous page ▪  - Displays the first page
2	Defines the number of rows to display per page. You can select 5 or 10, where the

Item #	Description
	default is 10.
3	Displays the currently displayed page number.

4.1.7 Searching for Configuration Parameters

You can locate the exact Web page on which a specific parameter appears, by using the device's Search feature. The Web parameter's corresponding *ini* file parameter name is used as the search key. The search key can include the full parameter name (e.g., "EnableIPSec") or a substring of it (e.g., "sec"). If you search for a substring, all parameters containing the specified substring in their names are listed in the search result.




Note: If an *ini* file parameter is not configurable in the Web interface, the search fails.

➤ To search for a parameter:

1. On the Navigation bar, click the **Search** tab; the Search engine appears in the Navigation pane.
2. In the field alongside the **Search** button, enter the parameter name or a substring of the name for which you want to search. If you have done a previous search for such a parameter, instead of entering the required string, you can use the 'Search History' drop-down list to select the string saved from a previous search.
3. Click **Search**; a list of found parameters based on your search key appears in the Navigation pane. Each searched result displays the following:
 - *ini* file parameter name
 - Link (in green) to the Web page on which the parameter appears
 - Brief description of the parameter
 - Menu navigation path to the Web page on which the parameter appears
4. In the searched list, click the required parameter (green link) to open the page on which the parameter appears; the relevant page opens in the Work pane and the searched parameter is highlighted in the page for easy identification, as shown in the figure below:

Figure 4-15: Searched Result Screen



Search Description

Item #	Description
1	Search field for entering search key and Search button for activating the search process.
2	Search results listed in Navigation pane.
3	Found parameter, highlighted on relevant Web page

4.1.8 Working with Scenarios

The Web interface allows you to create your own menu (*Scenario*) of up to 20 pages, selected from the menus in the Navigation tree (i.e., pertaining to the **Configuration**, **Maintenance**, and **Status & Diagnostics** tabs). Each page in the Scenario is referred to as a *Step*. For each Step, you can select up to 25 parameters on the page to include in the Scenario. Therefore, the Scenario feature is useful in that it allows you quick-and-easy access to commonly used configuration parameters specific to your network environment. When you log in to the Web interface, your Scenario is displayed in the Navigation tree.

Instead of creating a new Scenario, you can load a saved Scenario on a computer to the device (see 'Loading a Scenario to the Device' on page 57).


4.1.8.1 Creating a Scenario

The procedure below describes how to create a Scenario.

➤ **To create a Scenario:**

1. On the Navigation bar, click the **Scenarios** tab; a message box appears, requesting you to confirm creation of a Scenario:

Figure 4-16: Create Scenario Confirmation Message Box




Note: If a Scenario already exists, the Scenario Loading message box appears.

2. Click **OK**; the Scenario mode appears in the Navigation tree as well as the menus of the **Configuration** tab.
3. In the 'Scenario Name' field, enter an arbitrary name for the Scenario.
4. On the Navigation bar, click the **Configuration** or **Maintenance** tab to display their respective menus in the Navigation tree.
5. In the Navigation tree, select the required page item for the Step, and then in the page itself, select the required parameters by selecting the check boxes corresponding to the parameters.
6. In the 'Step Name' field, enter a name for the Step.
7. Click the **Next** button located at the bottom of the page; the Step is added to the

- Scenario and appears in the Scenario Step list.
8. Repeat steps 5 through 7 to add additional Steps (i.e., pages).
 9. When you have added all the required Steps for your Scenario, click the **Save & Finish** button located at the bottom of the Navigation tree; a message box appears informing you that the Scenario has been successfully created.
 10. Click **OK**; the Scenario mode is quit and the menu tree of the **Configuration** tab appears in the Navigation tree.

Figure 4-17: Creating a Scenario



Scenario Description

Item #	Description
1	Selected page item in the Navigation tree whose page contains the parameter that you want to add to the Scenario Step.
2	Name of a Step that has been added to the Scenario.
3	'Scenario Name' field for defining a name for the Scenario.
4	'Step Name' field for defining a name for a Scenario Step.
5	Save & Finish button to save your Scenario.
6	Selected parameter(s) that you want added to a Scenario Step.
7	Next button to add the current Step to the Scenario and enables you to add additional Steps.

Notes:



- You can add up to 20 Steps per Scenario, where each Step can contain up to 25 parameters.
- When in Scenario mode, the Navigation tree is in 'Full' display (i.e., all menus are displayed in the Navigation tree) and the configuration pages are in 'Advanced Parameter List' display (i.e., all parameters are shown in the pages). This ensures accessibility to all parameters when creating a Scenario. For a description on the Navigation tree views, see 'Navigation Tree' on page 43.
- If you previously created a Scenario and you click the **Create Scenario** button, the previously created Scenario is deleted and replaced with the one you are creating.
- Only Security Administrator Web users can create Scenarios.


4.1.8.2 Accessing a Scenario

Once you have created the Scenario, you can access it by following the procedure below:

➤ **To access the Scenario:**

1. On the Navigation bar, select the **Scenario** tab; a message box appears, requesting you to confirm the loading of the Scenario.
2. Click **OK**; the Scenario and its Steps appear in the Navigation tree, as shown in the example below:

Figure 4-18: Scenario Example



Loaded Scenario Description

Item #	Description
1	Scenario name.
2	Scenario Steps.
3	Scenario configuration command buttons.

Item #	Description
4	Parameters available on a page for the selected Scenario Step. These are displayed in a blue background; unavailable parameters are displayed in a gray or light-blue background.
5	Navigation buttons for navigating between Scenario Steps: <ul style="list-style-type: none"> <li data-bbox="352 450 1134 517">▪ Next  button to open the next Step listed in the Scenario <li data-bbox="352 517 1241 584">▪ Previous  button to open the previous Step listed in the Scenario



Note: If you reset the device while in Scenario mode, after the device resets, you are returned once again to the Scenario mode.

4.1.8.3 Editing a Scenario

You can modify a Scenario as described in the procedure below.



Note: Only Security Administrator Web users can edit a Scenario.

➤ To edit a Scenario:

1. Open the Scenario.
2. Click the **Edit Scenario** button located at the bottom of the Navigation pane; the 'Scenario Name' and 'Step Name' fields appear.
3. You can perform the following edit operations:
 - **Add Steps:**
 - a. On the Navigation bar, select the desired tab (i.e., **Configuration** or **Maintenance**); the tab's menu appears in the Navigation tree.
 - b. In the Navigation tree, navigate to the desired page item; the corresponding page opens in the Work pane.
 - c. On the page, select the required parameters by marking their corresponding check boxes.
 - d. Click **Next**.
 - **Add or Remove Parameters:**
 - a. In the Navigation tree, select the required Step; the corresponding page opens in the Work pane.
 - b. To add parameters, select the check boxes corresponding to the desired parameters.
 - c. To remove parameters, clear the check boxes corresponding to the desired parameters.
 - d. Click **Next**.

- **Edit Step Name:**
 - a. In the Navigation tree, select the required Step.
 - b. In the 'Step Name' field, modify the Step name.
 - c. On the page, click **Next**.
 - **Edit Scenario Name:**
 - a. In the 'Scenario Name' field, edit the Scenario name.
 - b. On the displayed page, click **Next**.
 - **Remove a Step:**
 - a. In the Navigation tree, select the required Step; the corresponding page opens in the Work pane.
 - b. On the page, clear all the check boxes corresponding to the parameters.
 - c. Click **Next**.
4. After clicking **Next**, a message box appears notifying you of the change. Click **OK**.
 5. Click **Save & Finish**; a message box appears informing you that the Scenario has been successfully modified. The Scenario mode is exited and the menus of the **Configuration** tab appear in the Navigation tree.

4.1.8.4 Saving a Scenario to a PC

You can save a Scenario (as a *dat* file) to a folder on your computer. This is useful when you need multiple Scenarios to represent different deployments. Once you create a Scenario and save it to your computer, you can then keep on saving modifications to it under different Scenario file names. When you require a specific network environment setup, you can load the suitable Scenario file from your computer (see 'Loading a Scenario to the Device' on page 57).

➤ **To save a Scenario to a computer:**

1. On the Navigation bar, click the **Scenarios** tab; the Scenario appears in the Navigation tree.
2. Click the **Get/Send Scenario File** button, located at the bottom of the Navigation tree; the Scenario File page appears, as shown below:

Figure 4-19: Scenario File Page



3. Click the **Get Scenario File** button; the File Download window appears.
4. Click **Save**, and then in the Save As window navigate to the folder to where you want to save the Scenario file. When the file is successfully downloaded to your computer, the Download Complete window appears.
5. Click **Close** to close the window.

4.1.8.5 Loading a Scenario to the Device

The procedure below describes how to load a previously saved Scenario file (*data* file) from your computer to the device. For saving a Scenario, see 'Saving a Scenario to a PC' on page 56.

➤ **To load a Scenario to the device:**

1. On the Navigation bar, click the **Scenarios** tab; the Scenario appears in the Navigation tree.
2. Click the **Get/Send Scenario File** button, located at the bottom of the Navigation tree; the Scenario File page appears.
3. Click the **Browse** button, and then navigate to the Scenario file saved on your computer.
4. Click the **Send File** button.



Notes:

- You can only load a Scenario file to a device that has the same hardware configuration as the device on which it was created.
- The loaded Scenario replaces any existing Scenario.
- You can also load a Scenario file using BootP, by loading an ini file that contains the ini file parameter ScenarioFileName (see Web and Telnet Parameters on page 619). The Scenario file must be located in the same folder as the ini file. For information on using AudioCodes AcBootP utility, refer to AcBootP Utility User's Guide.


4.1.8.6 Deleting a Scenario

You can delete the Scenario, as described in the procedure below.

➤ **To delete the Scenario:**

1. On the Navigation bar, click the **Scenarios** tab; a message box appears, requesting you to confirm:
2. Click **OK**; the Scenario mode appears in the Navigation tree.
3. Click the **Delete Scenario File** button; a message box appears requesting confirmation for deletion.

Figure 4-20: Message Box for Confirming Scenario Deletion



4. Click **OK**; the Scenario is deleted and the Scenario mode closes.



Note: You can also delete a Scenario using the following alternative methods:

- Loading an empty *dat* file (see 'Loading a Scenario to the Device' on page 57).
- Loading an *ini* file with the ScenarioFileName parameter set to no value (i.e., ScenarioFileName = "").


4.1.8.7 Quitting Scenario Mode

Follow the procedure below to quit the Scenario mode.

➤ **To quit the Scenario mode:**

1. On the Navigation bar, click any tab except the **Scenarios** tab, or click the **Cancel Scenarios** button located at the bottom of the Navigation tree; a message box appears, requesting you to confirm exiting Scenario mode, as shown below.

Figure 4-21: Confirmation Message Box for Exiting Scenario Mode



2. Click **OK** to exit.

4.1.9 Creating a Login Welcome Message

You can create a Welcome message box that is displayed on the Web Login page for logging in to the Web interface. The figure below displays an example of a Welcome message:

Figure 4-22: User-Defined Web Welcome Message after Login

Note

 ***** This is a Welcome message **

Web Login

Username

Password

Remember Me

To enable and create a Welcome message, use the WelcomeMessage table ini file parameter. If this parameter is not configured, no Welcome message is displayed.

ini File Parameter for Welcome Login Message

Parameter	Description
[WelcomeMessage]	<p>Enables and defines a Welcome message that appears on the Web Login page for logging in to the Web interface.</p> <p>The format of this parameter is as follows: [WelcomeMessage] FORMAT WelcomeMessage_Index = WelcomeMessage_Text; [WelcomeMessage]</p> <p>For Example: [WelcomeMessage] FORMAT WelcomeMessage_Index = WelcomeMessage_Text; WelcomeMessage 1 = "*****"; WelcomeMessage 2 = "***** This is a Welcome message ***"; WelcomeMessage 3 = "*****"; [WelcomeMessage]</p> <p>Each index row represents a line of text in the Welcome message box. Up to 20 lines (or rows) of text can be defined.</p>

4.1.10 Getting Help

The Web interface provides you with context-sensitive Online Help. The Online Help provides brief descriptions of parameters pertaining to the currently opened page.

- To view the Help topic of a currently opened page:

1. On the toolbar, click the **Help**  button; the Help topic pertaining to the opened page appears, as shown below:

Figure 4-23: Help Topic for Current Page



2. To view a description of a parameter, click the **plus**  sign to expand the parameter. To collapse the description, click the **minus**  sign.

- To close the Help topic, click the **close**  button located on the top-right corner of the Help topic window or simply click the **Help**  button.



Note: Instead of clicking the **Help** button for each page you open, you can open it once for a page and then simply leave it open. Each time you open a different page, the Help topic pertaining to that page is automatically displayed.


4.1.11 Logging Off the Web Interface

The procedure below describes how to log off the Web interface.

➤ **To log off the Web interface:**

- On the toolbar, click the **Log Off**  icon; the following confirmation message box appears:

Figure 4-24: Log Off Confirmation Box



- Click **OK**; you are logged off the Web session and the Web Login dialog box appears enabling you to re-login, if required.

4.2 Viewing the Home Page

The Home page is displayed when you access the device's Web interface. The Home page provides you with a graphical display of the device's front panel, showing color-coded status icons for various operations device.

➤ **To access the Home page:**

- On the toolbar, click the **Home**  icon.

Figure 4-25: Home Page of Mediant 600





Figure 4-26: Home Page of Mediant 1000



Note: The displayed number and type of telephony interfaces depends on the ordered hardware configuration.

In addition to the color-coded status information depicted on the graphical display of the device, the Home page displays various read-only information in the General Information pane:

- **IP Address:** IP address of the device
- **Subnet Mask:** Subnet mask address of the device
- **Default Gateway Address:** Default gateway used by the device
- **Digital Port Number:** Number of digital PRI ports (depending on ordered hardware configuration)
- **BRI Port Number:** Number of BRI ports (depending on ordered hardware configuration)
- **Analog Port Number:** Number of analog (FXS, FXO) ports (depending on ordered hardware configuration)
- **Firmware Version:** Software version running on the device
- **Protocol Type:** Signaling protocol currently used by the device (i.e. SIP)

■ **Gateway Operational State:**

- "LOCKED": device is locked (i.e. no new calls are accepted)
- "UNLOCKED": device is not locked
- "SHUTTING DOWN": device is currently shutting down

To perform these operations, see 'Basic Maintenance' on page 491.

The table below describes the areas of the Home page.

Home Page Description

Item #	Description		
1	Displays the highest severity of an active alarm raised (if any) by the device: <ul style="list-style-type: none"> ▪ Green: No alarms ▪ Red: Critical alarm ▪ Orange: Major alarm ▪ Yellow: Minor alarm To view active alarms, click the Alarms area to open the Active Alarms page (see Viewing Active Alarms on page 543).		
2	Module slot number.		
3	Module type (e.g., FXS, FXO, and DIGITAL)		
4	Module status icon: <ul style="list-style-type: none"> ▪  (green): Module has been inserted or is correctly configured ▪  (gray): Module was removed and "Reserved" is displayed ▪  (red): Module failure and "Failure" is displayed 		
5	Port (trunk or channel) status icon.		
	Icon	Trunk Description (Digital Module)	Channel Description (Analog Module)
	 (grey)	Disable: Trunk not configured (not in use)	Idle: Channel is currently on-hook
	 (green)	Active - OK: Trunk synchronized	Call Connected: Active RTP stream
	 (yellow)	RAI Alarm: Remote Alarm Indication (RAI), also known as the Yellow Alarm	-
	 (red)	LOS / LOF Alarm: Loss due to LOS (Loss of Signal) or LOF (Loss of Frame)	Not Connected: No analog line is connected to this port or port out of service due to Serial Peripheral Interface (SPI) failure (applicable only to FXO interfaces)
	 (blue)	AIS Alarm: Alarm Indication Signal (AIS), also known as the Blue Alarm	Handset Offhook: Channel is off-hook, but there is no active RTP session
	 (light orange)	D-Channel Alarm: D-channel alarm	-

Item #	Description
	<div style="display: flex; align-items: center;">  <div style="margin-left: 10px;">NFAS Alarm</div> <div style="margin-left: 100px;">-</div> </div> <p>(dark orange)</p> <p>If you click a port, a shortcut menu appears with commands allowing you to do the following:</p> <ul style="list-style-type: none"> ▪ Reset channel (Analog ports only): Resets the analog port (see Resetting an Analog Channel on page 497) ▪ Port Settings: Displays trunk status (see 'Viewing Trunk and Channel Status' on page 549) and analog port status (see 'Viewing Analog Port Information' on page 551) ▪ Update Port Info: Assigns a name to the port (see 'Assigning a Port Name' on page 64)
6	Dry Contact (normally open) status icon <ul style="list-style-type: none"> ▪  (green): Dry Contact is open (normal) ▪  (red): Dry contact is closed
7	Dry Contact (normally closed) status icon: <ul style="list-style-type: none"> ▪  (green): Dry Contact is closed (normal) ▪  (red): Dry contact is open
8	CPU module.
9	Ethernet port status icons: <ul style="list-style-type: none"> ▪  (green): Ethernet link is working ▪  (gray): Ethernet link is not connected <p>To view detailed Ethernet port information, click these icons to open the Ethernet Port Information page (see Viewing Ethernet Port Information on page 542).</p>
10	Fan tray unit status icon: <ul style="list-style-type: none"> ▪  (green): Fan tray operating ▪  (red): Fan tray failure
11	Power Supply Unit 1 status icon: <ul style="list-style-type: none"> ▪  (green): Power supply is operating ▪  (red): Power supply failure or no power supply unit installed <p>Note: This is applicable only to Mediant 1000.</p>
12	Power Supply Unit 2 status indicator. See Item #11 for a description. <p>Note: This is applicable only to Mediant 1000.</p>

4.2.1 Assigning a Port Name

The Home page allows you to assign an arbitrary name or a brief description to each port. This description appears as a tooltip when you move your mouse over the port.




Note: Only alphanumerical characters can be used in the port description.

➤ **To add a port description:**


1. Click the required port icon; a shortcut menu appears, as shown below:

Figure 4-27: Shortcut Menu in Home Page (Example of Mediant 1000)



2. From the shortcut menu, choose **Update Port Info**; a text box appears.

Figure 4-28: Entering Port Name in Home Page (Example of Mediant 1000)



3. Type a brief description for the port, and then click **Apply Port Info**.

4.3 Configuring Web User Accounts

You can create up to 10 Web user accounts for the device. Up to five Web users can simultaneously be logged in to the device's Web interface. Web user accounts prevent unauthorized access to the Web interface, enabling login access only to users with correct credentials (i.e., username and password). Each Web user account is composed of the following attributes:

- **Username and password:** Credentials that enable authorized login access to the Web interface.
- **Access level (user type):** Access privileges specifying what the user can view in the Web interface and its read/write privileges. The table below describes the different types of Web user account access levels:

Access Levels of Web User Accounts

User Access Level	Numeric Representation*	Privileges
Master	220	Read / write privileges for all pages. Can create all user types, including additional Master users and Security Administrators. It can delete all users except the last Security Administrator.
Security Administrator	200	Read / write privileges for all pages. It can create all user types and is the only one that can create the first Master user. Note: There must be at least one Security Administrator.
Administrator	100	Read / write privileges for all pages except security-related pages, which are read-only.
Monitor	50	No access to security-related and file-loading pages; read-only access to other pages.
No Access	0	No access to any page. Note: This access level is not applicable when using advanced Web user account configuration in the Web Users table.

* The numeric representation of the access level is used only to define accounts in a RADIUS server (the access level ranges from 1 to 255).

By default, the device is pre-configured with the following two Web user accounts:

Pre-configured Web User Accounts

User Access Level	Username (Case-Sensitive)	Password (Case-Sensitive)
Security Administrator	Admin	Admin
Monitor	User	User

After you log in to the Web interface, the username is displayed on the toolbar.

If the Web session is idle (i.e., no actions are performed) for more than five minutes, the Web session expires and you are once again requested to login with your username and password. Users can be banned for a period of time upon a user-defined number of unsuccessful login attempts. Login information (such as how many login attempts were made and the last successful login time) can be presented to the user.

➤ **To prevent user access after a specific number of failed logins:**

1. From the 'Deny Access On Fail Count' drop-down list, select the number of failed logins after which the user is prevented access to the device for a user-defined time (see next step).
2. In the 'Deny Authentication Timer' field, enter the interval (in seconds) that the user needs to wait before a new login attempt from the same IP address can be done after reaching the number of failed login attempts (defined in the previous step).


Notes:

- For security, it's recommended that you change the default username and password.
- The Security Administrator user can change all attributes of all Web user accounts. Web users with access levels other than Security Administrator can change only their password and username.
- To restore the two Web user accounts to default settings (usernames and passwords), set the *ini* file parameter `ResetWebPassword` to 1.
- To log in to the Web interface with a different Web user, click the **Log off** button and then login with with a different username and password.
- You can set the entire Web interface to read-only (regardless of Web user access levels), by using the *ini* file parameter `DisableWebConfig` (see 'Web and Telnet Parameters' on page 619).
- You can define additional Web user accounts using a RADIUS server (see 'Configuring RADIUS Settings' on page 74).
- For secured HTTP connection (HTTPS), see 'Automatic Update' on page 527.

4.3.1 Basic User Accounts Configuration

This section describes basic Web user account configuration. This is relevant only if the two default, pre-configured Web user accounts - Security Administrator ("Admin") and Monitor ("User") - are sufficient for your management scheme.

For the Security Administrator, you can change only the username and password; not its access level. For the Monitor user, you can change username and password as well as access level (Administrator, Monitor, or No Access).


Notes:

- The access level of the Security Administrator cannot be modified.
- The access level of the second user account can be modified only by the Security Administrator.
- The username and password can be a string of up to 19 characters. When you log in to the Web interface, the username and password string values are case-sensitive, according to your configuration.
- Up to two users can be logged in to the Web interface at the same time, and they can be of the same user.

- **To configure the two pre-configured Web user accounts:**
- 1. Open the Web User Accounts page (**Configuration** tab > **System** menu > **Web User Accounts**). If you are logged in as Security Administrator, both Web user accounts are displayed (as shown below). If you are logged in with the second user account, only the details of this user account are displayed.

Figure 4-29: WEB User Accounts Page (for Users with 'Security Administrator' Privileges)

Current Logged User: Admin	
▼ Account Data for User: Admin	
User Name	Admin <input type="text"/> <input type="button" value="Change User Name"/>
Access Level	Security Administratc ▼ <input type="button" value="Change Access Level"/>
▼ Fill in the following 3 fields to change the password	
Current Password	<input type="text"/>
New Password	<input type="text"/>
Confirm New Password	<input type="text"/> <input type="button" value="Change Password"/>
▼ Account Data for User: User	
User Name	User <input type="text"/> <input type="button" value="Change User Name"/>
Access Level	User Monitor ▼ <input type="button" value="Change Access Level"/>
▼ Fill in the following 3 fields to change the password	
Current Password	<input type="text"/>
New Password	<input type="text"/>
Confirm New Password	<input type="text"/> <input type="button" value="Change Password"/>
▼ Web Users Table	
Create Web Users Table	<input type="button" value="Create Table"/>

2. To change the username of an account:
 - a. In the 'User Name' field, enter the new user name.
 - b. Click **Change User Name**; if you are currently logged in to the Web interface with this account, the 'Web Login' dialog box appears.
 - c. Log in with your new user name.
3. To change the password of an account:
 - a. In the 'Current Password' field, enter the current password.
 - b. In the 'New Password' and 'Confirm New Password' fields, enter the new password.
 - c. Click **Change Password**; if you are currently logged in to the Web interface with this account, the 'Web Login' dialog box appears.
 - d. Log in with your new password.
4. To change the access level of the optional, second account:
 - a. Under the **Account Data for User: User** group, from the 'Access Level' drop-down list, select a new access level user.
 - b. Click **Change Access Level**; the new access level is applied immediately.

4.3.2 Advanced User Accounts Configuration

This section describes advanced Web user account configuration. This is relevant if you need the following management scheme:

- Enhanced security settings per Web user (e.g., limit session duration)
- More than two Web user accounts (up to 10 Web user accounts)
- Master users

This advanced Web user configuration is done in the Web Users table, which is initially accessed from the Web User Accounts page (see procedure below). Once this table is accessed, subsequent access immediately opens the Web Users table instead of the Web User Accounts page.



Notes:

- Only the Security Administrator user can **initially** access the Web Users table.
- Only Security Administrator and Master users can add, edit, or delete users.
- Admin users have read-only privileges in the Web Users table. Monitor users have no access to this page.
- If you delete a user who is currently in an active Web session, the user is immediately logged off by the device.
- All users can change their own passwords. This is done in the WEB Security Settings page (see 'Configuring Web Security Settings' on page 72).
- To remove the Web Users table and revert to the Web User Accounts page with the pre-configured, default Web user accounts, set the ResetWebPassword *ini* file parameter to 1. This also deletes all other Web users.
- Once the Web Users table is accessed, Monitor users and Admin users can only change their passwords in the Web Security Settings page (see 'Configuring Web Security Settings' on page 72). The new password must have at least four different characters than the previous password. (The Security Administrator users and Master users can change their passwords in the Web Users table and in the Web Security Settings page.)
- This table can only be configured using the Web interface.

➤ To add Web user accounts with advanced settings:

1. Open the Web Users Table page:
 - Upon initial access:
 - a. Open the Web User Accounts page (**Configuration** tab > **System** menu > **Web User Accounts**).
 - b. Under the **Web Users Table** group, click the **Create Table** button.
 - Subsequent access: **Configuration** tab > **System** menu > **Web User Accounts**.

The Web Users table appears, listing the two default, pre-configured Web use accounts - Security Administrator ("Admin") and Monitor ("User"):

Figure 4-30: Web Users Table Page

Index	Username	Password	Status	Password Age	Session Limit	Session Timeout	Block Duration	User Level
0	Admin	*	Valid	0	2	60	60	SecAdmin
1	User	*	Valid	0	2	60	60	Monitor

Page 1 of 1 View 1 - 2 of 2

2. Click the **Add** button; the following dialog box is displayed:

Figure 4-31: Web Users Table - Add Record Dialog Box

Add Record ✕

Index:

Username:

Password:

Status: ▼

Password Age:

Session Limit:

Session Timeout:

Block Duration:

User Level: ▼

3. Add a user as required. For a description of the parameters, see the table below.
4. Click **Submit**.

Web User Parameters Description

Parameter	Description
Web: Username	Defines the Web user's username. The valid value is a string of up to 40 alphanumeric characters, including the period ".", underscore "_", and hyphen "-" signs.
Web: Password	Defines the Web user's password. The valid value is a string of 8 to 40 ASCII characters, which must include the following: <ul style="list-style-type: none"> ▪ At least eight characters ▪ At least two letters that are upper case (e.g., "AA") ▪ At least two letters that are lower case (e.g., "aa") ▪ At least two numbers ▪ At least two signs (e.g., the dollar "\$" sign) ▪ No spaces in the string ▪ At least four characters different to the previous password

Parameter	Description
Web: Status	<p>Defines the status of the Web user.</p> <ul style="list-style-type: none"> ▪ New = (Default) User is required to change its password on the next login. When the user logs in to the Web interface, the user is immediately prompted to change the current password. ▪ Valid = User can log in to the Web interface as normal. ▪ Failed Access = This state is automatically set for users that exceed a user-defined number of failed login attempts, set by the 'Deny Access on Fail Count' parameter (see 'Configuring Web Security Settings' on page 72). These users can log in only after a user-defined timeout configured by the 'Block Duration' parameter (see below) or if their status is changed (to New or Valid) by a System Administrator or Master. ▪ Old Account = This state is automatically set for users that have not accessed the Web interface for a user-defined number of days, set by the 'User Inactivity Timer' (see 'Configuring Web Security Settings' on page 72). These users can only log in to the Web interface if their status is changed (to New or Valid) by a System Administrator or Master. <p>Notes:</p> <ul style="list-style-type: none"> ▪ The Old Account status is applicable only to Admin and Monitor users; System Administrator and Master users can be inactive indefinitely. ▪ For security, it is recommended to set the status of a newly added user to New in order to enforce password change.
Web: Password Age	<p>Defines the duration (in days) of the validity of the password. When this duration elapses, the user is prompted to change the password; otherwise, access to the Web interface is blocked.</p> <p>The valid value is 0 to 10000, where 0 means that the password is always valid. The default is 90.</p>
Web: Session Limit	<p>Defines the maximum number of Web interface sessions allowed for the user. In other words, this allows the same user account to log in to the device from different sources (i.e., IP addresses).</p> <p>The valid value is 0 to 5. The default is 2.</p> <p>Note: Up to 5 users can be logged in to the Web interface at any given.</p>
Web: Session Timeout	<p>Defines the duration (in minutes) of Web inactivity of a logged-in user, after which the user is automatically logged off the Web interface.</p> <p>The valid value is 0 to 100000. The default is according to the settings of the 'Session Timeout' global parameter (see 'Configuring Web Security Settings' on page 72).</p>
Web: Block Duration	<p>Defines the duration (in seconds) for which the user is blocked when the user exceeds a user-defined number of failed login attempts. This is configured by the 'Deny Access On Fail Count' parameter (see 'Configuring Web Security Settings' on page 72).</p> <p>The valid value is 0 to 100000, where 0 means that the user can do as many login failures without getting blocked. The default is according to the settings of the 'Deny Authentication Timer' parameter (see 'Configuring Web Security Settings' on page 72).</p> <p>Note: The 'Deny Authentication Timer' parameter relates to failed Web logins from specific IP addresses.</p>

Parameter	Description
Web: User Level	<p>Defines the user's access level.</p> <ul style="list-style-type: none"> ▪ Monitor = (Default) Read-only user. This user can only view Web pages and access to security-related pages is denied. ▪ Admin = Read/write privileges for all pages, except security-related pages including the Web Users table where this user has only read-only privileges. ▪ SecAdmin = Read/write privileges for all pages. This user is the Security Administrator. ▪ Master-User = Read/write privileges for all pages. This user also functions as a security administrator. <p>Notes:</p> <ul style="list-style-type: none"> ▪ At least one Security Administrator must exist. The last remaining Security Administrator cannot be deleted. ▪ The first Master user can be added only by a Security Administrator user. ▪ Additional Master users can be added, edited and deleted only by Master users. ▪ If only one Master user exists, it can be deleted only by itself. ▪ Master users can add, edit, and delete Security Administrators (but cannot delete the last Security Administrator). ▪ Only Security Administrator and Master users can add, edit, and delete Admin and Monitor users.

4.4 Displaying Login Information upon Login


The device can display login information immediately upon Web login.

➤ **To enable display of user login information upon a successful login:**

1. Open the WEB Security Settings page (**Configuration** tab > **System** menu > **Management** submenu > **WEB Security Settings**).
2. From the 'Display Login Information' drop-down list, select **Yes**.
3. Click **Submit** to apply your changes.

Once enabled, the Login Information window is displayed upon a successful login, as shown in the example below:

Figure 4-32: Login Information Window



Login Information	
Last Login Privilege	Security Administrator
Last Failed Login Time	15:04:19
Last Failed Login Date	10/06/2012
Last Failed Login IP	10.13.2.11
Login Attempts Since Last Success	2
Last Success Login Time	15:03:32
Last Success Login Date	10/06/2012
Last Success Login IP	10.13.2.11

Close

4.5 Configuring Web Security Settings

The WEB Security Settings page is used to define a secure Web access communication method. For a description of these parameters, see 'Web and Telnet Parameters' on page 619.

➤ **To define Web access security:**

1. Open the WEB Security Settings page (**Configuration** tab > **System** menu > **Management** submenu > **WEB Security Settings**).

Figure 4-33: Web & Telnet Access List Page - Add New Entry

▼ General	
Voice Menu Password	12345
HTTP Authentication Mode	Web Based Authentication ▼
⚡ Secured Web Connection (HTTPS)	HTTP and HTTPS ▼
Requires Client Certificates for HTTPS connection	Disable ▼
⚡ HTTPS Cipher String	RC4:EXP
▼ Session	
Session Timeout (minutes)	60
▼ Access Block Parameters	
Deny Authentication Timer	60
Deny Access On Fail Count	3 ▼
Display Login Information	No ▼

2. Configure the parameters as required.
3. Click **Submit** to apply your changes.
4. To save the changes to flash memory, see 'Saving Configuration' on page 494.

4.6 Web Login Authentication using Smart Cards

You can enable Web login authentication using certificates from a third-party, common access card (CAC) with user identification. When a user attempts to access the device through the Web browser (HTTPS), the device retrieves the Web user's login username (and other information, if required) from the CAC. The user attempting to access the device is only required to provide the login password. Typically, a TLS connection is established between the CAC and the device's Web interface, and a RADIUS server is implemented to authenticate the password with the username. Therefore, this feature implements a two-factor authentication - what the user has (i.e., the physical card) and what the user knows (i.e., the login password).

This feature is enabled using the EnableMgmtTwoFactorAuthentication parameter.



Note: For specific integration requirements for implementing a third-party smart card for Web login authentication, contact your AudioCodes representative.

➤ **To log in to the Web interface using CAC:**

1. Insert the Common Access Card into the card reader.
2. Access the device using the following URL: `https://<host name or IP address>`; the device prompts for a username and password.
3. Enter the password only. As some browsers require that the username be provided, it's recommended to enter the username with an arbitrary value.

4.7 Configuring Web and Telnet Access List

The Web & Telnet Access List page is used to define IP addresses (up to ten) that are permitted to access the device's Web, Telnet, and SSH interfaces. Access from an undefined IP address is denied. If no IP addresses are defined, this security feature is inactive and the device can be accessed from any IP address. The Web and Telnet Access List can also be defined using the *ini* file parameter `WebAccessList_x` (see 'Web and Telnet Parameters' on page 619).

➤ **To add authorized IP addresses for Web, Telnet, and SSH interfaces access:**

1. Open the Web & Telnet Access List page (**Configuration** tab > **System** menu > **Management** submenu > **Web & Telnet Access List**).

Figure 4-34: Web & Telnet Access List Page - Add New Entry

2. To add an authorized IP address, in the 'Add an authorized IP address' field, enter the required IP address, and then click **Add New Entry**; the IP address you entered is added as a new entry to the Web & Telnet Access List table.

Figure 4-35: Web & Telnet Access List Table

Delete Row	Authorized IP Address
1 <input type="checkbox"/>	10.13.2.11
2 <input type="checkbox"/>	10.13.2.12

3. To delete authorized IP addresses, select the Delete Row check boxes corresponding

to the IP addresses that you want to delete, and then click **Delete Selected Addresses**; the IP addresses are removed from the table and these IP addresses can no longer access the Web and Telnet interfaces.

4. To save the changes to flash memory, see 'Saving Configuration' on page 494.



Notes:

- The first authorized IP address in the list must be your PC's (terminal) IP address; otherwise, access from your PC is denied.
- Delete your PC's IP address last from the 'Web & Telnet Access List' page. If it is deleted before the last, subsequent access to the device from your PC is denied.

4.8 Configuring RADIUS Settings

The RADIUS Settings page is used for configuring the Remote Authentication Dial In User Service (RADIUS) accounting parameters. For a description of these parameters, see 'Configuration Parameters Reference' on page 609.

➤ **To configure RADIUS:**

1. Open the RADIUS Settings page (**Configuration** tab > **System** menu > **Management** submenu > **RADIUS Settings**).

Figure 4-36: RADIUS Parameters Page

▼ General RADIUS Setting	
Enable RADIUS Access Control	Disable
Use RADIUS for Web/Telnet Login	Disable
RADIUS Authentication Server IP Address	0.0.0.0
RADIUS Authentication Server Port	1645
RADIUS Shared Secret	••••••••
▼ General RADIUS Authentication	
Default Access Level	200
Device Behavior Upon RADIUS Timeout	Verify Access Locally
Local RADIUS Password Cache Mode	Reset Timer Upon Access
Local RADIUS Password Cache Timeout [sec]	300
RADIUS VSA Vendor ID	5003
RADIUS VSA Access Level Attribute	35

2. Configure the parameters as required.
3. Click **Submit** to apply your changes.
4. To save the changes to flash memory, see 'Saving Configuration' on page 494.

5 CLI-Based Management

This section provides an overview of the CLI-based management and configuration relating to CLI management. The device's CLI-based management interface can be accessed using the RS-232 serial port or by using Secure SHell (SSH) or Telnet through the Ethernet interface.



Notes:

- For security, CLI is disabled by default.
- For information on accessing the CLI interface through the RS-232 port interface, see 'CLI' on page 30.
- CLI is used only for debugging and mainly allows you to view various information regarding device configuration and performance.

5.1 Enabling CLI using Telnet

The device's CLI can be accessed using Telnet. Secure Telnet using Secure Socket Layer (SSL) can be configured whereby information is not transmitted in the clear. If SSL is used, a special Telnet client is required on your PC to connect to the Telnet interface over a secured connection; examples include C-Kermit for UNIX and Kermit-95 for Windows.

For security, some organizations require the display of a proprietary notice upon starting a Telnet session. You can use the configuration ini file parameter, `WelcomeMessage` to configure such a message (see [Creating a Login Welcome Message](#) on page 58).

➤ To enable Telnet:

1. Open the Telnet/SSH Settings page (**Configuration** tab > **System** menu > **Management** > **Telnet/SSH Settings**).

Figure 5-1: Telnet Settings on Telnet/SSH Settings Page

Telnet Settings	
Embedded Telnet Server	Enable Unsecured ▼
Telnet Server TCP Port	23
⚡ Telnet Server Idle Timeout	0

2. Set the 'Embedded Telnet Server' parameter to **Enable Unsecured** or **Enable Secured** (i.e, SSL).
3. Configure the other Tenet parameters as required. For a description of these parameters, see [Telnet Parameters](#) on page 623.
4. Click **Submit**.
5. Save the changes to flash memory with a device reset.

5.2 Enabling CLI using SSH and RSA Public Key

The device's CLI can be accessed using Telnet. However, unless configured for TLS, Telnet is not secure as it requires passwords to be transmitted in clear text. To overcome this, Secure SHell (SSH) is used, which is the de-facto standard for secure CLI. SSH 2.0 is a protocol built above TCP, providing methods for key exchange, authentication, encryption, and authorization.

SSH requires appropriate client software for the management PC. Most Linux distributions have OpenSSH pre-installed; Windows-based PCs require an SSH client software such as


PuTTY, which can be downloaded from <http://www.chiark.greenend.org.uk/~sgtatham/putty/>.

By default, SSH uses the same username and password as the Telnet and Web server. SSH supports 1024/2048-bit RSA public keys, providing carrier-grade security. Follow the instructions below to configure the device with an administrator RSA key as a means of strong authentication.

➤ **To enable SSH and configure RSA public keys for Windows (using PuTTY SSH):**

1. Start the PuTTY Key Generator program, and then do the following:
 - a. Under the 'Parameters' group, do the following:
 - ◆ Select the **SSH-2 RSA** option.
 - ◆ In the 'Number of bits in a generated key' field, enter "1024" bits.
 - b. Under the 'Actions' group, click **Generate** and then follow the on-screen instructions.
 - c. Under the 'Actions' group, click **Save private key** to save the new private key to a file (*.ppk) on your PC.
 - d. Under the 'Key' group, select the displayed encoded text between "ssh-rsa" and "rsa-key-....", as shown in the example below:

Figure 5-2: Selecting Public RSA Key in PuTTY



2. Open the Telnet/SSH Settings page (**Configuration** tab > **System** menu > **Management** > **Telnet/SSH Settings**), and then do the following:
 - a. Set the 'Enable SSH Server' parameter to **Enable**.
 - b. Paste the public key that you copied in Step 1.d into the 'Admin Key' field, as shown below:

Figure 5-3: SSH Settings - Pasting Public RSA Key in 'Admin Key' Field

SSH Settings	
Enable SSH Server	Enable
Server Port	22
Admin Key	AAAAB3NzaC1yc2EAAAABJQAAAIBh4d5kzHckyRml3fawnb2b/Csod/d2FDobjcGw/bogDYzLlR89hCfu/GE5ADWbur6FPxniM7ehhUcMpkE2NzqZnz752VmiE3xEWch451mre/n7Jjs3kUcjHzGdo1aXG2UgF82ag+y0pnu4WuukDBk+m1ALMdMQNEVH5k6cw==rsa-key-20080910
Require Public Key	Enable
Max Payload Size	32768
Max Binary Packet Size	35000
Enable Last Login Message	Enable
Max Login Attempts	3

- c. For additional security, you can set the 'Require Public Key' to **Enable**. This ensures that SSH access is only possible by using the RSA key and not by using user name and password.
 - d. Configure the other SSH parameters as required. For a description of these parameters, see SSH Parameters on page 642.
 - e. Click **Submit**.
3. Start the PuTTY Configuration program, and then do the following:
 - a. In the 'Category' tree, drill down to **Connection**, then **SSH**, and then **Auth**; the 'Options controlling SSH authentication' pane appears.
 - b. Under the 'Authentication parameters' group, click **Browse** and then locate the private key file that you created and saved in Step 4.
 4. Connect to the device with SSH using the username "Admin"; RSA key negotiation occurs automatically and no password is required.
- **To configure RSA public keys for Linux (using OpenSSH 4.3):**
1. Run the following command to create a new key in the admin.key file and to save the public portion to the admin.key.pub file:


```
ssh-keygen -f admin.key -N "" -b 1024
```
 2. Open the admin.key.pub file, and then copy the encoded string from "ssh-rsa" to the white space.
 3. Open the Telnet/SSH Settings page (**Configuration** tab > **System** menu > **Management** > **Telnet/SSH Settings**), and then paste the value copied in Step 2 into the 'Admin Key' field.
 4. Click **Submit**.
 5. Connect to the device with SSH, using the following command:


```
ssh -i admin.key xx.xx.xx.xx
```

 where xx.xx.xx.xx is the device's IP address. RSA-key negotiation occurs automatically and no password is required.

5.3 Establishing a CLI Session

The procedure below describes how to establish a CLI session with the device.



Notes:

- The default login username and password are both "Admin" (case-sensitive).
- Only the primary User Account, which has Security Administration access level (200) can access the device using Telnet. For configuring the username and password, see Configuring Web User Accounts on page 64.

- **To establish a CLI session with the device:**
1. Establish a Telnet or SSH session with the device using its OAMP IP address.
 2. Log in to the session using the username and password assigned to the Admin user of the Web interface.
 3. At the login prompt, type the username, and then press Enter:


```
login: Admin
```
 4. At the password prompt, type the password, and then press Enter:

```

password: Admin
After logging in, the current directory (root), available commands, available
subdirectories, and a welcome message are displayed at the CLI prompt:
login: Admin
password:
ready. Type "exit" to close the connection.
SIP/ SECurity/ PStn/ DebugRecording/ MGmt/ ControlProtocol/ CONFiguration/
IPNetworking/ TPAApp/ BSP/
PING SHow
/>
    
```

5.4 CLI Commands

The CLI commands are used mainly to display current configuration and performance. These commands are organized in subdirectories. When the CLI session starts, you are located in the 'root' directory.

To access a subdirectory, type its name, and then press Enter. The CLI commands can be entered in an abbreviated format by typing only the letters shown in upper case (i.e., capital letters). For example, the **CHangePassWord** command can be entered by typing **chpw**. If you know the full path to a command inside one of the subdirectories, the short format can be used to run it directly. For example, the **PERformance** command in the **MGmt** subdirectory may be run directly by typing **/mg/perf**.

The following table summarizes the basic CLI commands:

Table 1: Basic CLI Commands

Purpose	Commands	Description
Help	h	Displays the help for a specific command, action, or parameter.
Navigation	cd	Enters another directory.
	cd root	Navigates to the root directory (/).
	..	Goes up one level.
	exit	Terminates the CLI session.

5.4.1 Status Commands

The following table summarizes the Show commands and their corresponding options.

Table 2: Show CLI Commands

Command	Short Format	Arguments	Description
SHow	sh	info tdm dsp ip log	Displays operational data. <ul style="list-style-type: none"> ▪ info: Displays general device information ▪ tdm: Displays PSTN-related information ▪ dsp: Displays DSP resource information ▪ ip: Displays information about IP interfaces
SHow INFO	sh info	-	Displays device hardware information, versions, uptime, temperature reading, and the last reset reason.

Command	Short Format	Arguments	Description
SHow TDM	sh tdm	status perf summary	Displays the alarm status and performance statistics for E1/T1 trunks.
SHow DSP	sh dsp	status perf	Displays status and version for each DSP device, along with overall performance statistics.
SHow IP	sh ip	conf perf route	Displays IP interface status and configuration, along with performance statistics. Note: The display format may change according to the configuration.
SHow LOG	sh log	[stop]	Displays (or stops displaying) Syslog messages in the CLI session.

Example:

```

/>sh info
Board type: gateway SDH, firmware version 6.60.000.020
Uptime: 0 days, 0 hours, 3 minutes, 54 seconds
Memory usage: 63%
Temperature reading: 39 C
Last reset reason:
Board was restarted due to issuing of a reset from Web interface
Reset Time : 7.1.2012 21.51.13

/>sh tdm status
Trunk 00: Active
Trunk 01: Active
Trunk 02: Not Configured

/>sh tdm perf
DS1 Trunk Statistics (statistics for 948 seconds):
Trunk #   B-Channel   Call count RTP packet RTP packet Activity
          utilization   Tx    Rx    Seconds
0         1         1    2865    0        57
1        20        20   149743    0    3017
2         0         0     0     0     0
3         0         0     0     0     0

/>sh dsp status
DSP firmware: 491096AE8 Version:0660.03 Used=0 Free=480 Total=480
DSP device 0: Active   Used=16 Free= 0 Total=16
DSP device 1: Active   Used=16 Free= 0 Total=16
DSP device 2: Active   Used=16 Free= 0 Total=16
DSP device 3: Active   Used=16 Free= 0 Total=16
DSP device 4: Active   Used=16 Free= 0 Total=16
DSP device 5: Active   Used=16 Free= 0 Total=16
DSP device 6: Inactive
DSP device 7: Inactive
DSP device 8: Inactive
DSP device 9: Inactive
DSP device 10: Inactive
DSP device 11: Inactive
DSP device 12: Active   Used=16 Free= 0 Total=16
DSP device 13: Active   Used=16 Free= 0 Total=16
DSP device 14: Active   Used=16 Free= 0 Total=16

```

```

DSP device 15: Active  Used=16  Free= 0  Total=16
DSP device 16: Active  Used=16  Free= 0  Total=16
DSP device 17: Active  Used=16  Free= 0  Total=16
DSP device 18: Inactive
PSEC - DSP firmware: AC491IPSEC Version: 0660.03
CONFERENCE - DSP firmware: AC491256C Version: 0660.03
/>sh dsp perf
DSP Statistics (statistics for 968 seconds):
Active DSP resources: 480
Total DSP resources: 480
DSP usage %: 100
/>sh ip perf
Networking Statistics (statistics for 979 seconds):
IP KBytes TX: 25
IP KBytes RX: 330
IP KBytes TX per second: 0
IP KBytes RX per second: 1
IP Packets TX: 1171
IP Packets RX: 5273
IP Packets TX per second: 3
IP Packets RX per second: 12
Peak KByte/s TX in this interval: 18
Peak KByte/s RX in this interval: 4
Discarded packets: 186
DHCP requests sent: 0
IPSec Security Associations: 0
/>/mg/perf reset
Done.
/>sh ip perf
Networking Statistics (statistics for 2 seconds):
IP KBytes TX: 2
IP KBytes RX: 4
IP KBytes TX per second: 0
IP KBytes RX per second: 1
IP Packets TX: 24
IP Packets RX: 71
IP Packets TX per second: 3
IP Packets RX per second: 12
Peak KByte/s TX in this interval: 18
Peak KByte/s RX in this interval: 4
Discarded packets: 0
DHCP requests sent: 0
IPSec Security Associations: 0
/>sh ip conf
Interface  IP Address          Subnet Mask          Default Gateway
-----  -
OAM        10.4.64.13            55.255.0.0           10.4.0.1
Media     10.4.64.13            255.255.0.0          10.4.0.1
Control   10.4.64.13            255.255.0.0          10.4.0.1
MAC address: 00-90-8f-04-5c-e9
/>sh ip route
Destination  Mask          Gateway          Intf  Flags
-----  -
0.0.0.0      0.0.0.0       10.4.0.1         OAM  A S
10.4.0.0     255.255.0.0   10.4.64.13       OAM  A L
127.0.0.0    255.0.0.0     127.0.0.1        AR   S
127.0.0.1    255.255.255.255  127.0.0.1        A L   H
Flag legend: A=Active R=Reject L=Local S=Static E=rEdirect
M=Multicast
    
```

```
B=Broadcast H=Host I=Invalid
End of routing table, 4 entries displayed.
```

5.4.2 Ping Command

The Ping command is described in the following table:

Table 3: Ping Command

Command	Short Format	Arguments	Description
PING	ping	[-n count] [-l size] [-w timeout] [-p cos] ip-address	Sends ICMP echo request packets to a specified IP address. <ul style="list-style-type: none"> count: number of packets to send. size: payload size in each packet. timeout: time (in seconds) to wait for a reply to each packet. cos: Class-of-Service (as per 802.1p) to use.

Example:

```
/>ping 10.31.2.10
Ping process started for address 10.31.2.10. Process ID - 27.
Reply from 10.31.2.10: bytes=0 time<0ms
Ping statistics for 10.31.2.10:
Packets:Sent = 4, Received = 4, Lost 0 (0% loss),
Approximate round trip times in milli-seconds:
Minimum = 0ms, Maximum = 0ms, Average = 0ms
```

5.4.3 Test Call (TC) Commands

The Test Call commands can be used to simulate an IP-to-PSTN call.



Note: Only one test call can be activated at a given time.

Table 4: Test Call Command

Command	Short Format	Sub-Commands
/SIP/TestCall	/sip/tc	set dest set src set cid set DTMFs display connect

Table 5: Sub-Commands of Test (TC) Command

Sub-Command	Arguments	Description
set dest	<number>	Sets the Destination Number for the test call.

Sub-Command	Arguments	Description
set src	<number>	Sets the Source Number for the test call.
set cid	<display string>	Sets the Display Name for the test call.
set DTMFs	<DTMF pattern>	Sets the pattern of DTMFs that is played to the PSTN side after the test call is connected.
display	-	Displays all the set parameters for the test call. These values can be manually set using the set commands or defaults.
connect	<destination number> <source number> <caller ID> <time>	Generates the test call toward the PSTN side using the set parameters. If no arguments are defined in the connect command line, the test call uses the values defined using the set commands (or defaults). Note: There is no option for defining only the <time> value without specifying all the other arguments that appear before it.

Example:

```

/SIP>tc
TestCall - TC
Manage Test Tel-Link Call.
Usage:
    TC set dest <number>
    TC set src <number>
    TC set cid <display string>
    TC set DTMFs <dtmf string>
    TC display
    TC connect [dest-number] [src number] [CID] [time]

/SIP>tc display
Test Call configuration
  Dest number: 402
  Src number: 700
  Cid display: TESTING
  DTMFs String 112233
  Time After DTMF are sent: 20 sec

/SIP>tc connect
Start Test call.
Receive ALERT Event
Receive Connect
Wait more 20 seconds before disconnecting
Receive SS_TIMER_EV Event
Send Release To Call
Receive RELEASE_ACK Event
Receive SS_TIMER_EV Event
    
```

5.4.4 Management Commands

The commands under the **MGmt** directory, described in the table below, display current performance values.

Table 6: CLI Management Command

Command	Short Format	Arguments	Description
/MGmt/PERformance	/mg/perf	basic control dsp net ds1 reset	Displays performance statistics. The <i>reset</i> argument clears all statistics to zero.

5.4.5 Configuration Commands

The commands under the **CONFigure** directory query and modify the current device configuration. The following commands are available:

Table 7: Configuration CLI Commands

Command	Short Format	Arguments	Description
SetConfigParam IP	/conf/scp ip	ip-addr subnet def-gw	Sets the IP address, subnet mask, and default gateway address of the device (on-the-fly). Note: This command may cause disruption of service. The CLI session may disconnect since the device changes its IP address.
RestoreFactorySettings	/conf/rfs		Restores all parameters to factory settings.
SaveAndRestart	/conf/sar		Saves all current configurations to the non-volatile memory and resets the device.
ConfigFile	/conf/cf	view get set	Retrieves the full <i>ini</i> file from the device and allows loading a new <i>ini</i> file directly in the CLI session. Note: The argument <i>view</i> displays the file, page by page. The argument <i>get</i> displays the file without breaks.

5.4.6 PSTN Commands

The commands under the **PSTN** directory allow you to perform various PSTN actions.

Table 8: PSTN CLI Command

Command	Short Format	Arguments	Description
PstnLoopCommands	PS/PH/PLC	<TrunkId> <LoopCode> <BChannel>	Activates a loopback on a specific trunk and B-channel. For loopback on the entire trunk, set BChannel=(-1). The valid value options for LoopCode include the following: <ul style="list-style-type: none"> 0 = NO_LOOPS 1 = REMOTE_LOOP (whole trunk only) 2 = LINE_PAYLOAD_LOOP (whole trunk only) 3 = LOCAL_ALL_CHANNELS_LOOP (whole trunk only)
PstnSendAlarm	PS/PH/PSA	<TrunkId> <AlarmSendCode>	Sends an alarm signal at the Tx interface or on a specific Trunk ID. The valid value options for AlarmSendCode include the

Command	Short Format	Arguments	Description
			following: <ul style="list-style-type: none"> ▪ 0 = NO_ALARMS (means stop sending AIS) ▪ 1 = AIS_ALARM ▪ 2 = STOP_RAI_ALARM ▪ 3 = SEND_RAI_ALARM
DeleteCasFile	PS/CAS/DCF	<TableIndex>	Deletes all the device's CAS files when <TableIndex> is set to -1 (other options are currently not supported).

5.4.7 LDAP Commands

The commands under the **IPNetworking\OpenLdap** directory allow you to perform various Lightweight Directory Access Protocol (LDAP) actions.

Table 9: LDAP Commands

Sub-Command	Arguments	Description
LdapStatus	-	Displays the LDAP connection status.
LdapSearch	<search key> <attribute1> [<attribute 2> ...<attribute 5>]	Searches an LDAP server. The parameters enclosed by [] are optional.
LDapOpen	-	Opens a connection to the LDAP server using parameters provided in the configuration file.
LDapSetDebugmode	<mode>	Sets the LdapDebugLevelMode parameter. Possible levels 0-3.
LDapGetDebugmode	-	Gets the LdapDebugLevelMode parameter value

6 SNMP-Based Management

The device provides an embedded SNMP Agent to operate with a third-party SNMP Manager (e.g., element management system or EMS) for operation, administration, maintenance, and provisioning (OAMP) of the device. The SNMP Agent supports standard Management Information Base (MIBs) and proprietary MIBs, enabling a deeper probe into the interworking of the device. The SNMP Agent can also send unsolicited events (SNMP traps) towards the SNMP Manager. All supported MIB files are supplied to customers as part of the release.

This section provides configuration relating to SNMP management.



Note: For more information on SNMP support such as SNMP traps, refer to the *SNMP User's Guide*.

6.1 Configuring SNMP Community Strings

The SNMP Community String page allows you to configure up to five read-only and up to five read-write SNMP community strings and to configure the community string that is used for sending traps.

For detailed descriptions of the SNMP parameters, see 'SNMP Parameters' on page 623.

➤ **To configure the SNMP community strings:**

1. Open the SNMP Community String page (**Configuration** tab > **System** menu > **Management** submenu > **SNMP** submenu > **SNMP Community String**).

Delete	Community String	Access Level
<input type="checkbox"/>		Read Only
<input type="checkbox"/>		Read / Write
<input type="checkbox"/>		Read / Write
<input type="checkbox"/>		Read / Write
<input type="checkbox"/>		Read / Write
<input type="checkbox"/>		Read / Write

<input type="checkbox"/> Disable SNMP		<input type="text" value="No"/>
Trap Community String		<input type="text" value="trapuser"/>
Trap Manager Host Name		<input type="text"/>

2. Configure the SNMP community strings parameters according to the table below.
3. Click **Submit** to apply your changes.
4. To save the changes to flash memory, see 'Saving Configuration' on page 494.

To delete a community string, select the **Delete** check box corresponding to the community string that you want to delete, and then click **Submit**.

SNMP Community String Parameters Description

Parameter	Description
Community String	<ul style="list-style-type: none"> Read Only [SNMPReadOnlyCommunityString_x]: Up to five read-only community strings (up to 19 characters each). The default string is 'public'. Read / Write [SNMPReadWriteCommunityString_x]: Up to five read / write community strings (up to 19 characters each). The default string is 'private'.
Trap Community String [SNMPTrapCommunityString]	Community string used in traps (up to 19 characters). The default string is 'trapuser'.

6.2 Configuring SNMP Trap Destinations

The SNMP Trap Destinations page allows you to configure up to five SNMP trap managers. You can associate a trap destination with SNMPv2 users and specific SNMPv3 users. Associating a trap destination with SNMPv3 users sends encrypted and authenticated traps to the SNMPv3 destination. By default, traps are sent unencrypted using SNMPv2.

➤ **To configure SNMP trap destinations:**

1. Open the SNMP Trap Destinations page (**Configuration** tab > **System** menu > **Management** submenu > **SNMP** > **SNMP Trap Destinations**).

Figure 6-1: SNMP Trap Destinations Page

		IP Address	Trap Port	Trap User	Trap Enable
<input checked="" type="checkbox"/>	SNMP Manager 1	0.0.0.0	162	v2cParams ▾	Enable ▾
<input checked="" type="checkbox"/>	SNMP Manager 2	0.0.0.0	162	hq-snmpv3 ▾	Enable ▾
<input type="checkbox"/>	SNMP Manager 3	0.0.0.0	162	v2cParams ▾	Enable ▾
<input type="checkbox"/>	SNMP Manager 4	0.0.0.0	162	v2cParams ▾	Enable ▾
<input type="checkbox"/>	SNMP Manager 5	0.0.0.0	18	v2cParams ▾	Enable ▾

2. Configure the SNMP trap manager parameters according to the table below.
3. Select the check box corresponding to the SNMP Manager that you wish to enable.
4. Click **Submit** to apply your changes.



Note: Only row entries whose corresponding check boxes are selected are applied when clicking **Submit**; otherwise, settings revert to their defaults.

SNMP Trap Destinations Parameters Description

Parameter	Description
Web: SNMP Manager [SNMPManagerIsUsed_x]	Enables the SNMP Manager to receive traps and checks the validity of the configured destination (IP address and port number). <ul style="list-style-type: none"> [0] (check box cleared) = (Default) Disables SNMP Manager [1] (check box selected) = Enables SNMP Manager
Web: IP Address [SNMPManagerTableIP_x]	Defines the IP address (in dotted-decimal notation, e.g., 108.10.1.255) of the remote host used as the SNMP Manager. The device sends SNMP traps to this IP address.
Trap Port [SNMPManagerTrapPort_x]	Defines the port number of the remote SNMP Manager. The device sends SNMP traps to this port. The valid value range is 100 to 4000. The default is 162.
Web: Trap User [SNMPManagerTrapUser]	Associates a trap user with the trap destination. This determines the trap format, authentication level, and encryption level. <ul style="list-style-type: none"> v2cParams (default) = SNMPv2 user community string SNMPv3 user configured in 'Configuring SNMP V3 Users' on page 88
Trap Enable [SNMPManagerTrapSendingEnable_x]	Activates the sending of traps to the SNMP Manager. <ul style="list-style-type: none"> [0] Disable [1] Enable (Default)

6.3 Configuring SNMP Trusted Managers

The SNMP Trusted Managers page allows you to configure up to five SNMP Trusted Managers, based on IP addresses. By default, the SNMP agent accepts SNMP Get and Set requests from any IP address, as long as the correct community string is used in the request. Security can be enhanced by using Trusted Managers, which is an IP address from which the SNMP agent accepts and processes SNMP requests.



Notes: The SNMP Trusted Managers table can also be configured using the table ini file parameter, SNMPTrustedMgr_x (see 'SNMP Parameters' on page 623).

➤ **To configure SNMP Trusted Managers:**

1. Open the SNMP Trusted Managers page (**Configuration** tab > **System** menu > **Management** submenu > **SNMP** submenu > **SNMP Trusted Managers**).

Figure 6-2: SNMP Trusted Managers

Delete	Trusted Managers IP Address	
<input type="checkbox"/>	SNMP Trusted Manager 1	<input type="text" value="0.0.0.0"/>
<input type="checkbox"/>	SNMP Trusted Manager 2	<input type="text" value="0.0.0.0"/>
<input type="checkbox"/>	SNMP Trusted Manager 3	<input type="text" value="0.0.0.0"/>
<input type="checkbox"/>	SNMP Trusted Manager 4	<input type="text" value="0.0.0.0"/>
<input type="checkbox"/>	SNMP Trusted Manager 5	<input type="text" value="0.0.0.0"/>

2. Select the check box corresponding to the SNMP Trusted Manager that you want to enable and for whom you want to define an IP address.
3. Define an IP address in dotted-decimal notation.
4. Click **Submit** to apply your changes.
5. To save the changes, see 'Saving Configuration' on page 494.

6.4 Configuring SNMP V3 Users

The SNMP v3 Users page allows you to configure authentication and privacy for up to 10 SNMP v3 users.

➤ **To configure SNMP v3 users:**

1. Open the SNMP v3 Users page (**Configuration** tab > **System** menu > **Management** submenu > **SNMP** submenu > **SNMP V3 Users**).
2. Click **Add**; the following dialog box appears:

Figure 6-3: SNMP V3 Setting Page - Add Record Dialog Box

3. Configure the SNMP V3 Setting parameters according to the table below.
4. Click **Submit** to apply your settings.
5. To save the changes, see 'Saving Configuration' on page 494.

**Notes:**

- If you delete a user that is associated with a trap destination (in 'Configuring SNMP Trap Destinations' on page 86), the configured trap destination becomes disabled and the trap user reverts to default (i.e., SNMPv2).
- The SNMP v3 Users table can also be configured using the table ini file parameter, SNMPUsers (see 'SNMP Parameters' on page 623).

SNMP V3 Users Parameters

Parameter	Description
Index [SNMPUsers_Index]	The table index. The valid range is 0 to 9.
User Name [SNMPUsers_Username]	Name of the SNMP v3 user. This name must be unique.
Authentication Protocol [SNMPUsers_AuthProtocol]	Authentication protocol of the SNMP v3 user. <ul style="list-style-type: none"> ▪ [0] None (default) ▪ [1] MD5 ▪ [2] SHA-1
Privacy Protocol [SNMPUsers_PrivProtocol]	Privacy protocol of the SNMP v3 user. <ul style="list-style-type: none"> ▪ [0] None (default) ▪ [1] DES ▪ [2] 3DES ▪ [3] AES-128 ▪ [4] AES-192 ▪ [5] AES-256
Authentication Key [SNMPUsers_AuthKey]	Authentication key. Keys can be entered in the form of a text password or long hex string. Keys are always persisted as long hex strings and keys are localized.
Privacy Key [SNMPUsers_PrivKey]	Privacy key. Keys can be entered in the form of a text password or long hex string. Keys are always persisted as long hex strings and keys are localized.
Group [SNMPUsers_Group]	The group with which the SNMP v3 user is associated. <ul style="list-style-type: none"> ▪ [0] Read-Only (default) ▪ [1] Read-Write ▪ [2] Trap Note: All groups can be used to send traps.

Reader's Notes

7 EMS-Based Management

AudioCodes Element Management System (EMS) is an advanced solution for standards-based management of gateways within VoP networks, covering all areas vital for the efficient operation, administration, management and provisioning (OAM&P) of AudioCodes' families of gateways. The EMS enables Network Equipment Providers (NEPs) and System Integrators (SIs) the ability to offer customers rapid time-to-market and inclusive, cost-effective management of next-generation networks. The standards-compliant EMS uses distributed SNMP-based management software, optimized to support day-to-day Network Operation Center (NOC) activities, offering a feature-rich management framework. It supports fault management, configuration and security.



Note: For more information on using the EMS tool, refer to the *EMS User's Manual* and *EMS Server IOM Manual*.

Reader's Notes

8 INI File-Based Management

The device can be configured using an ini file, which is a text-based file with an *ini* file extension name that can be created using any standard text-based editor such as Notepad. Each configuration element of the device has a corresponding ini file parameter that you can use in the ini file for configuring the device. When you have created the ini file with your ini file parameter settings, you apply these settings to the device by installing (loading) the ini file to the device.



Notes:

- For a list and description of the *ini* file parameters, see 'Configuration Parameters Reference' on page 609.
- To restore the device to default settings using the *ini* file, see 'Restoring Factory Defaults' on page 527.

8.1 INI File Format

The *ini* file can be configured with any number of parameters. These *ini* file parameters can be one of the following types:

- Individual parameters - see 'Configuring Individual ini File Parameters' on page 93
- Table parameters - see 'Configuring Table ini File Parameters' on page 93

8.1.1 Configuring Individual ini File Parameters

The syntax for configuring individual *ini* file parameters in the ini file is as follows:

- An optional, subsection name (or group name) enclosed in square brackets "[...]". This is used to conveniently group similar parameters by their functionality.
- Parameter name, followed by an equal "=" sign and then its value.
- Comments must be preceded by a semicolon ";".

```
[subsection name]
parameter name = value
parameter name = value
; this is a comment line
; for example:
[System Parameters]
SyslogServerIP = 10.13.2.69
EnableSyslog = 1
```

For general *ini* file formatting rules, see 'General ini File Formatting Rules' on page 95.

8.1.2 Configuring Table ini File Parameters

The table ini file parameters allow you to configure tables, which include multiple parameters (*columns*) and row entries (*indices*). When loading an *ini* file to the device, it's recommended to include only tables that belong to applications that are to be configured (dynamic tables of other applications are empty, but static tables are not).

The table ini file parameter is composed of the following elements:

- **Title of the table:** The name of the table in square brackets, e.g., [MY_TABLE_NAME].
- **Format line:** Specifies the columns of the table (by their string names) that are to be

configured.

- The first word of the Format line must be "FORMAT", followed by the Index field name and then an equal "=" sign. After the equal sign, the names of the columns are listed.
- Columns must be separated by a comma ",".
- The Format line must only include columns that can be modified (i.e., parameters that are not specified as read-only). An exception is Index fields, which are mandatory.
- The Format line must end with a semicolon ";".
- **Data line(s):** Contain the actual values of the columns (parameters). The values are interpreted according to the Format line.
 - The first word of the Data line must be the table's string name followed by the Index field.
 - Columns must be separated by a comma ",".
 - A Data line must end with a semicolon ";".
- **End-of-Table Mark:** Indicates the end of the table. The same string used for the table's title, preceded by a backslash "\", e.g., [\MY_TABLE_NAME].

The following displays an example of the structure of a table ini file parameter.

```
[Table_Title]
; This is the title of the table.
FORMAT Index = Column_Name1, Column_Name2, Column_Name3;
; This is the Format line.
Index 0 = value1, value2, value3;
Index 1 = value1, $$, value3;
; These are the Data lines.
[ \Table_Title ]
; This is the end-of-the-table-mark.
```

The table ini file parameter formatting rules are listed below:

- Indices (in both the Format and the Data lines) must appear in the same order. The Index field must never be omitted.
- The Format line can include a subset of the configurable fields in a table. In this case, all other fields are assigned with the pre-defined default values for each configured line.
- The order of the fields in the Format line isn't significant (as opposed to the Index fields). The fields in the Data lines are interpreted according to the order specified in the Format line.
- The double dollar sign (\$\$) in a Data line indicates the default value for the parameter.
- The order of the Data lines is insignificant.
- Data lines must match the Format line, i.e., it must contain exactly the same number of Indices and Data fields and must be in exactly the same order.
- A row in a table is identified by its table name and Index field. Each such row may appear only once in the *ini* file.
- Table dependencies: Certain tables may depend on other tables. For example, one table may include a field that specifies an entry in another table. This method is used to specify additional attributes of an entity, or to specify that a given entity is part of a larger entity. The tables must appear in the order of their dependency (i.e., if Table X is referred to by Table Y, Table X must appear in the *ini* file before Table Y).

For general *ini* file formatting rules, see 'General ini File Formatting Rules' on page 95.

The table below displays an example of a table ini file parameter:

```
[ CodersGroup0 ]
FORMAT CodersGroup0_Index = CodersGroup0_Name, CodersGroup0_pTime,
CodersGroup0_rate, CodersGroup0_PayloadType, CodersGroup0_Sce;
```

```
CodersGroup0 0 = g711Alaw64k, 20, 0, 255, 0;  
CodersGroup0 1 = eg711Ulaw, 10, 0, 71, 0;  
[ \CodersGroup0 ]
```



Note: Do not include read-only parameters in the table ini file parameter as this can cause an error when attempting to load the file to the device.

8.1.3 General ini File Formatting Rules

The *ini* file must adhere to the following formatting rules:

- The *ini* file name must not include hyphens "-" or spaces; if necessary, use an underscore "_" instead.
- Lines beginning with a semi-colon ";" are ignored. These can be used for adding remarks in the *ini* file.
- A carriage return (i.e., Enter) must be done at the end of each line.
- The number of spaces before and after the equals sign "=" is irrelevant.
- Subsection names for grouping parameters are optional.
- If there is a syntax error in the parameter name, the value is ignored.
- Syntax errors in the parameter's value can cause unexpected errors (parameters may be set to the incorrect values).
- Parameter string values that denote file names (e.g., CallProgressTonesFileName) must be enclosed with inverted commas, e.g., CallProgressTonesFileName = 'cpt_usa.dat'.
- The parameter name is not case-sensitive.
- The parameter value is not case-sensitive, except for coder names.
- The *ini* file must end with at least one carriage return.

8.2 Loading an ini File

You can load an *ini* file to the device using the following methods:

- Web interface, using any of the following pages:
 - Configuration File - see 'Backing Up and Loading Configuration File' on page 526
 - Load Auxiliary Files - see 'Loading Auxiliary Files' on page 499
- AudioCodes AcBootP utility, which uses Bootstrap Protocol (BootP) and acts as a TFTP server. For information on using the AcBootP utility, refer to AcBootP Utility User's Guide.
- Any standard TFTP server. This is done by storing the ini file on a TFTP server and then having the device download the file from it.

When loaded to the device, the configuration settings of the *ini* file are saved to the device's non-volatile memory. If a parameter is not included in the loaded *ini* file, the following occurs:

- Using the Load Auxiliary Files page: Current settings for parameters that were not included in the loaded ini file are retained.
- All other methods: The default is assigned to the parameters that were not included in the loaded ini file and thereby, overriding values previously configured for these parameters.

**Notes:**

- For a list and description of the *ini* file parameters, see 'Configuration Parameters Reference' on page 609.
- Some parameters are configurable only through the *ini* file (and not the Web interface).
- To restore the device to default settings using the *ini* file, see 'Restoring Factory Defaults' on page 527.

8.3 Modifying an ini File

You can modify an *ini* file currently used by the device. Modifying an *ini* file instead of loading an entirely new *ini* file preserves the device's current configuration.

➤ **To modify an *ini* file:**

1. Save the device's configuration as an *ini* file on your computer, using the Web interface (see 'Loading an ini File' on page 95).
2. Open the *ini* file using a text file editor such as Notepad, and then modify the *ini* file parameters as required.
3. Save the modified *ini* file, and then close the file.
4. Load the modified *ini* file to the device (see 'Loading an ini File' on page 95).



Tip: Before loading the *ini* file to the device, verify that the file extension of the file is *.ini*.

8.4 Secured Encoded ini File

The *ini* file contains sensitive information that is required for the functioning of the device. The file may be loaded to the device using TFTP or HTTP. These protocols are not secure and are vulnerable to potential hackers. To overcome this security threat, the AudioCodes DConvert utility allows you to binary-encode (encrypt) the *ini* file before loading it to the device. For more information, refer to *DConvert Utility User's Guide*.

**Notes:**

- The procedure for loading an encoded *ini* file is identical to the procedure for loading an unencoded *ini* file (see 'Loading an ini File' on page 95).
- If you download from the device (to a folder on your computer) an *ini* file that was loaded encoded to the device, the file is saved as a regular *ini* file (i.e., unencoded).

Part III

General System Settings

9 Configuring Certificates

The Certificates page allows you to configure X.509 certificates, which are used for secure management of the device, secure SIP transactions, and other security applications.



Note: The device is shipped with an active TLS setup. Thus, configure certificates only if required.

9.1 Replacing the Device's Certificate

The device is supplied with a working TLS configuration consisting of a unique self-signed server certificate. If an organizational Public Key Infrastructure (PKI) is used, you may wish to replace this certificate with one provided by your security administrator.

➤ **To replace the device's certificate:**

1. Your network administrator should allocate a unique DNS name for the device (e.g., dns_name.corp.customer.com). This DNS name is used to access the device and therefore, must be listed in the server certificate.
2. If the device is operating in HTTPS mode, then set the 'Secured Web Connection (HTTPS)' parameter (HTTPSOnly) to **HTTP and HTTPS** (see 'Configuring Web Security Settings' on page 72). This ensures that you have a method for accessing the device in case the new certificate does not work. Restore the previous setting after testing the configuration.
3. Open the Certificates page (**Configuration** tab > **System** menu > **Certificates**).
4. Under the **Certificate Signing Request** group, do the following:
 - a. In the 'Subject Name [CN]' field, enter the DNS name.
 - b. Fill in the rest of the request fields according to your security provider's instructions.
 - c. Click the **Create CSR** button; a textual certificate signing request is displayed in the area below the button:

Figure 9-1: Certificate Signing Request Group


Certificate Signing Request	
Subject Name [CN]	audio.com
Organizational Unit [OU] (optional)	Headquarters
Company name [O] (optional)	Corporate
Locality or city name [L] (optional)	Poughkeepsie
State [ST] (optional)	New York
Country code [C] (optional)	US
<input type="button" value="Create CSR"/>	
After creating the CSR, copy the text below (including the BEGIN/END lines) and send it to your Certification Authority for signing.	
<pre> -----BEGIN CERTIFICATE REQUEST----- MIIBtjCCAR8CAQAwZjESMBAGA1UEAxMJVXVkaW8uY29tMRUwEwYDVQQLExIZWFK cXVhcnRlcnMxZjAQBGNVBAOTCUNVcnBvcnF0ZTEVMBMGA1UEBxMMUG91Z2hrZWVw c211MREwDwYDVQQIEWh0ZKcgW9yazELMAkGA1UEBhMCVVwz8wDQYJKoZIhvcN AQEBBQADgY0AMIGJAoGBAPhpf2t4oLy3FRk5Bw7FLZFWCXQ7nvuocHtu7Nns071M xL7Of8YoL63eeIK2eDo8nm6rJO677z/AHWJmF65pAK1CbOIPgoZNS0g6+5JAmJAA 1LNUnoqjEsR7CF32uv01H//gFkhy5z1eNvObI+25Fn38aJzEXc8DkGwZ19rROqRZ AgMBAAQgADANBgkqhkiG9w0BAQQAQFAOBgQDihdqbc1zkhDlFr+5BRu8cKyGUXEM6 q7FGjFXAfzk1MmgnBMc/MyfSGTbawrQF7p6dNj60D1vmuCPf6Gzz5m2uqc6LqoIi nLnQpVcmbdva/B1QyEpfBqHzqpULJ8CseSrry3ru23AZeDUByyho90IKRbAp//+3 ZvnZze5M5CBSLg== -----END CERTIFICATE REQUEST----- </pre>	

load them over a physically-secure connection such as a back-to-back Ethernet cable connected directly to the managing computer.

➤ **To replace the device's private key:**

1. Your security administrator should provide you with a private key in either textual PEM (PKCS #7) or PFX (PKCS #12) format. The file may be encrypted with a short pass-phrase, which should be provided by your security administrator.
2. If the device is operating in HTTPS mode, then set the 'Secured Web Connection (HTTPS)' field (HTTPSOnly) to **HTTP and HTTPS** (see 'Configuring Web Security Settings' on page 72). This ensures that you have a method for accessing the device in case the new configuration does not work. Restore the previous setting after testing the configuration.
3. Open the Certificates page (**Configuration** tab > **System** menu > **Certificates**) and scroll down to the **Upload certificate files from your computer** group.

Figure 9-3: Upload Certificate Files from your Computer Group



4. Fill in the 'Private key pass-phrase' field, if required.
5. Click the **Browse** button corresponding to the 'Send Private Key' field, navigate to the key file, and then click **Send File**.
6. If the security administrator has provided you with a device certificate file, load it using the 'Send Device Certificate' field.
7. After the files successfully load to the device, save the configuration with a device reset (see 'Saving Configuration' on page 494); the Web interface uses the new configuration.
8. Open the Certificates page again, and verify that under the **Certificate information** group (at the top of the page) the 'Private key' read-only field displays "OK"; otherwise, consult your security administrator.
9. If the device was originally operating in HTTPS mode and you disabled it in Step 2, then enable it by setting the 'Secured Web Connection (HTTPS)' field to **HTTPS Only**.

9.3 Mutual TLS Authentication

By default, servers using TLS provide one-way authentication. The client is certain that the identity of the server is authentic. When an organizational PKI is used, two-way authentication may be desired - both client and server should be authenticated using X.509 certificates. This is achieved by installing a client certificate on the managing PC and loading the root CA's certificate to the device's Trusted Root Certificate Store. The Trusted Root Certificate file may contain more than one CA certificate combined, using a text editor.

Since X.509 certificates have an expiration date and time, the device must be configured to use NTP (see 'Simple Network Time Protocol Support' on page 105) to obtain the current date and time. Without the correct date and time, client certificates cannot work.

➤ To enable mutual TLS authentication for HTTPS:

1. Set the 'Secured Web Connection (HTTPS)' field to **HTTPS Only** (see 'Configuring Web Security Settings' on page 72) to ensure you have a method for accessing the device in case the client certificate does not work. Restore the previous setting after testing the configuration.
2. Open the Certificates page (see 'Replacing the Device's Certificate' on page 99).
3. In the **Upload certificate files from your computer** group, click the **Browse** button corresponding to the 'Send Trusted Root Certificate Store ...' field, navigate to the file, and then click **Send File**.
4. When the operation is complete, set the 'Requires Client Certificates for HTTPS connection' field to **Enable** (see 'Configuring Web Security Settings' on page 72).
5. Save the configuration with a device reset (see 'Saving Configuration' on page 494).

When a user connects to the secured Web interface of the device:

- If the user has a client certificate from a CA that is listed in the Trusted Root Certificate file, the connection is accepted and the user is prompted for the system password.
- If both the CA certificate and the client certificate appear in the Trusted Root Certificate file, the user is not prompted for a password (thus, providing a single-sign-on experience - the authentication is performed using the X.509 digital signature).
- If the user does not have a client certificate from a listed CA or does not have a client certificate, the connection is rejected.



Notes:

- The process of installing a client certificate on your PC is beyond the scope of this document. For more information, refer to your operating system documentation, and/or consult your security administrator.
- The root certificate can also be loaded via the Automatic Update facility, using the HTTPSRootFileName *ini* file parameter.
- You can enable the device to check whether a peer's certificate has been revoked by an Online Certificate Status Protocol (OCSP) server (see Configuring Certificate Revocation Checking (OCSP) on page 102).

9.4 Configuring Certificate Revocation Checking (OCSP)

Some Public-Key Infrastructures (PKI) can revoke a certificate after it has been issued. You can configure the device to check whether a peer's certificate has been revoked, using the Online Certificate Status Protocol (OCSP). When OCSP is enabled, the device queries the OCSP server for revocation information whenever a peer certificate is received (IPSec, TLS client mode, or TLS server mode with mutual authentication).

➤ **To configure OCSP:**

1. Open the General Security Settings page (**Configuration** tab > **VoIP** menu > **Security** > **General Security Settings**).

Figure 9-4: OCSP Parameters

OCSP Settings	
Enable OCSP Server	Enable
Primary Server IP	212.10.5.6
Secondary Server IP	0.0.0.0
Server Port	2560
Default Response When Server Unreachable	Reject

2. Configure the OCSP parameters as required. For a description of these parameters, see OCSP Parameters on page 644.
3. Click **Submit**.



Notes:

- The device does not query OCSP for its own certificate.
- Some PKIs do not support OCSP but generate Certificate Revocation Lists (CRLs). For such cases, set up an OCSP server such as OCSPD.

9.5 Self-Signed Certificates

The device is shipped with an operational, self-signed server certificate. The subject name for this default certificate is 'ACL_nnnnnnn', where *nnnnnnn* denotes the serial number of the device. However, this subject name may not be appropriate for production and can be changed while still using self-signed certificates.


➤ **To change the subject name and regenerate the self-signed certificate:**

1. Before you begin, ensure the following:
 - You have a unique DNS name for the device (e.g., dns_name.corp.customer.com). This name is used to access the device and should therefore, be listed in the server certificate.
 - No traffic is running on the device. The certificate generation process is disruptive to traffic and should be executed during maintenance time.
2. Open the Certificates page (see 'Replacing the Device's Certificate' on page 99).
3. In the 'Subject Name [CN]' field, enter the fully-qualified DNS name (FQDN) as the certificate subject, select the desired private key size (in bits), and then click **Generate self-signed**; after a few seconds, a message appears displaying the new subject name.
4. Save the configuration with a device reset (see 'Saving Configuration' on page 494) for the new certificate to take effect.

9.6 Loading Certificate Chain for Trusted Root

A certificate chain is a sequence of certificates where each certificate in the chain is signed by the subsequent certificate. The last certificate in the list of certificates is the Root CA certificate, which is self-signed. The purpose of a certificate chain is to establish a chain of trust from a child certificate to the trusted root CA certificate. The CA vouches for the identity of the child certificate by signing it. A client certificate is considered trusted if one of the CA certificates up the certificate chain is found in the server certificate directory.

Figure 9-5: Certificate Chain Hierarchy



For the device to trust a whole chain of certificates, you need to combine the certificates into one text file (using a text editor). Once done, upload the file using the 'Trusted Root Certificate Store' field in the Certificates page.



Notes: The maximum supported size of the combined file of trusted chain of certificates is 100,000 bytes (including the certificate's headers).

10 Date and Time

The date and time of the device can be configured manually or it can be obtained automatically from a Simple Network Time Protocol (SNTP) server.

10.1 Configuring Date and Time Manually

The date and time of the device can be configured manually.

➤ **To manually configure the device's date and time, using the Web interface:**

1. Open the Regional Settings page (**Configuration** tab > **System** menu > **Regional Settings**).

Figure 10-1: Regional Settings Page

Year	Month	Day	Hour	Minutes	Seconds
2010	2	4	10	21	46

2. Enter the current date and time of the geographical location in which the device is installed.
3. Click the **Submit** button.



Notes:

- If the device is configured to obtain the date and time from an SNTP server, the fields on this page are read-only, displaying the received date and time.
- After performing a hardware reset, the date and time are returned to their defaults and thus, should be updated.

10.2 Automatic Date and Time through SNTP Server

The Simple Network Time Protocol (SNTP) client functionality generates requests and reacts to the resulting responses using the NTP version 3 protocol definitions (according to RFC 1305). Through these requests and responses, the NTP client synchronizes the system time to a time source within the network, thereby eliminating any potential issues should the local system clock 'drift' during operation. By synchronizing time to a network time source, traffic handling, maintenance, and debugging become simplified for the network administrator.

The NTP client follows a simple process in managing system time: the NTP client requests an NTP update, receives an NTP response, and then updates the local system clock based on a configured NTP server within the network.

The client requests a time update from a specified NTP server at a specified update interval. In most situations, this update interval is every 24 hours based on when the system was restarted. The NTP server identity (as an IP address or FQDN) and the update interval are user-defined, or an SNMP MIB object.

When the client receives a response to its request from the identified NTP server, it must be interpreted based on time zone or location offset that the system is to a standard point of reference called the Universal Time Coordinate (UTC). The time offset that the NTP client uses is configurable.

If required, the clock update is performed by the client as the final step of the update process. The update is performed in such a way as to be transparent to the end users. For instance, the response of the server may indicate that the clock is running too fast on the

client. The client slowly robs bits from the clock counter to update the clock to the correct time. If the clock is running too slow, then in an effort to catch the clock up, bits are added to the counter, causing the clock to update quicker and catch up to the correct time. The advantage of this method is that it does not introduce any disparity in the system time that is noticeable to an end user or that could corrupt call timeouts and timestamps.

The procedure below describes how to configure SNTP.

➤ **To configure SNTP using the Web interface:**

1. Open the Application Settings page (**Configuration** tab > **System** menu > **Application Settings**).

Figure 10-2: SNTP Configuration in Application Settings Page

▼ NTP Settings	
NTP Server DN/IP	212.13.4.5
NTP UTC Offset	Hours: 0 Minutes: 0
NTP Updated Interval	Hours: 24 Minutes: 0
NTP Secondary Server IP	
▼ Day Light Saving Time	
Day Light Saving Time	Enable
DST Mode	Day of month
Start Time	Sep 02 0 : 0
End Time	Apr 07 0 : 0
Offset [min]	60
Day of Month Start	Sep Sunday First 0 : 0
Day of Month End	Apr Sunday First 0 : 0

2. Configure the NTP parameters:
 - 'NTP Server DN/IP' (NTPServerIP) - defines the IP address or FQDN of the NTP server.
 - 'NTP UTC Offset' (NTPServerUTCOffset) - defines the time offset in relation to the UTC. For example, if your region is 2 hours ahead of the UTC, enter "2".
 - 'NTP Updated Interval' (NTPUpdateInterval) - defines the period after which the date and time of the device is updated.
 - 'NTP Secondary Server IP' (NTPSecondaryServerIP) - defines the secondary NTP server.
3. Configure daylight saving, if required:
 - 'Day Light Saving Time' (DayLightSavingTimeEnable) - enables daylight saving time.
 - 'DST Mode' - Determines the range type for configuring the start and end date for daylight saving:
 - ◆ **Day of Year:** The range is configured by date of month, for example, from January 4 to August 31.
 - ◆ **Day of month:** The range is configured by day of month, for example, from the second Sunday of May January to the last Sunday of August.
 - 'Start Time' (DayLightSavingTimeStart) and 'End Time' (DayLightSavingTimeEnd) - defines the period for which daylight saving time is relevant.
 - 'Offset' (DayLightSavingTimeOffset) - defines the offset in minutes to add to the time for daylight saving. For example, if your region has daylight saving of one hour, the time received from the NTP server is 11:00, and the UTC offset for your region is +2 (i.e., 13:00), you need to enter "60" to change the local time to 14:00.
4. Verify that the device is set to the correct date and time. You can do this by viewing the date and time in the Regional Settings page, as described in 'Configuring Date and Time Manually' on page 105.

Part IV

General VoIP Configuration

11 Network

This section describes the network-related configuration.

11.1 Ethernet Interface Configuration

The device's Ethernet connection can be configured, using the *ini* file parameter `EthernetPhyConfiguration`, to one of the following modes:

- **Manual:**
 - 10Base-T Half-Duplex or 10Base-T Full-Duplex
 - 100Base-TX Half-Duplex or 100Base-TX Full-Duplex
- **Auto-Negotiation:** chooses common transmission parameters such as speed and duplex mode

The Ethernet connection should be configured according to the following recommended guidelines:

- When the device's Ethernet port is configured for Auto-Negotiation, the opposite port must also operate in Auto-Negotiation. Auto-Negotiation falls back to Half-Duplex mode when the opposite port is not in Auto-Negotiation mode, but the speed in this mode is always configured correctly. Configuring the device to Auto-Negotiation mode while the opposite port is set manually to Full-Duplex is invalid as it causes the device to fall back to Half-Duplex mode while the opposite port is Full-Duplex. Any mismatch configuration can yield unexpected functioning of the Ethernet connection.
- When configuring the device's Ethernet port manually, the same mode (i.e., Half Duplex or Full Duplex) and speed must be configured on the remote Ethernet port. In addition, when the device's Ethernet port is configured manually, it is invalid to set the remote port to Auto-Negotiation. Any mismatch configuration can yield unexpected functioning of the Ethernet connection.
- It's recommended to configure the port for best performance and highest bandwidth (i.e., Full Duplex with 100Base-TX), but at the same time adhering to the guidelines listed above.



Note: For remote configuration, the device should be in the correct Ethernet setting prior to the time this parameter takes effect. When, for example, the device is configured using BootP/TFTP, the device performs many Ethernet-based transactions prior to reading the *ini* file containing this device configuration parameter. To resolve this problem, the device always uses the last Ethernet setup mode configured. In this way, if you want to configure the device to operate in a new network environment in which the current Ethernet setting of the device is invalid, you should first modify this parameter in the current network so that the new setting holds next time the device is restarted. After reconfiguration has completed, connect the device to the new network and restart it. As a result, the remote configuration process that occurs in the new network uses a valid Ethernet configuration

11.2 Ethernet Interface Redundancy

The device supports Ethernet redundancy by providing two Ethernet ports, located on the CPU module. The Ethernet port redundancy feature is enabled using the *ini* file parameter `MIIRedundancyEnable`. By default, this feature is disabled.

When Ethernet redundancy is implemented, the two Ethernet ports can be connected to the same switch (segment / hub). In this setup, one Ethernet port is active and the other is

redundant. If an Ethernet connection failure is detected, the CPU module switches over to the redundant Ethernet port. The CPU issues a Major alarm notifying of the failed physical port. If the first Ethernet port connection is restored, the Major alarm is cleared. The first physical port now becomes the redundant Ethernet port in case of failure with the active physical port (which is currently the second physical port).

When the CPU module loses all Ethernet connectivity, a Critical alarm is generated:


- When MIIRedundancyEnable is disabled: the alarm is generated when the single physical connection is lost. The alarm is cleared when the single physical connection is restored.
- When MIIRedundancyEnable is enabled: the alarm is generated when both physical connections are lost. The alarm is cleared when one or both of the physical connections are restored.

11.3 Configuring IP Network Interfaces

You can configure a single VoIP network interface for all applications, which includes OAMP (management traffic), call control (SIP messages), and media (RTP traffic), or you can configure multiple logical, IP network interfaces for these applications. A need often arises to have logically separated network segments for these applications for administration and security. This can be achieved by employing Layer-2 VLANs and Layer-3 subnets.

The figure below illustrates a typical network architecture where the device is configured with three network interfaces for the OAMP, call control, and media applications. The device is connected to a VLAN-aware switch for directing traffic from and to the device to the three separated Layer-3 broadcast domains according to VLAN tags (middle pane).

Figure 11-1: Multiple Network Interfaces



The Multiple Interface Table page allows you to configure these network interfaces. Each row of the table defines a logical IP interface with the following attributes:

- Application type allowed on the interface:
 - Control - call control signaling traffic (i.e., SIP)

- Media - RTP traffic
- Operations, Administration, Maintenance and Provisioning (OAMP) - management (such as Web- and SNMP-based management)
- IP address and subnet mask represented by prefix length
- VLAN ID (if VLANs are enabled)
- Default Gateway - traffic from this interface destined to a subnet that does not meet any of the routing rules, local or static routes, are forwarded to this gateway (as long this application type is allowed on this interface.
- Primary and secondary DNS IP address (optional)

You can configure up to 16 interfaces, consisting of up to 15 Control and Media interfaces and 1 OAMP interface.

This page also provides VLAN-related parameters for enabling VLANs and defining the Native VLAN ID. This is the VLAN ID to which incoming, untagged packets are assigned. You can also configure Quality of Service (QoS) by assigning VLAN priorities and Differentiated Services (DiffServ) for the supported Class of Service (CoS). For configuring Quality of Service (QoS), see 'Configuring the QoS Settings' on page 123.

Complementing the Multiple Interface table is the IP Routing table, which allows you to define static routing rules for non-local hosts/subnets. For more information, see 'Configuring the IP Routing Table' on page 119.

**Notes:**

- When adding more than one interface, ensure that you enable VLANs using the 'VLAN Mode' (VLANMode) parameter.
- When booting using BootP/DHCP protocols (see the 'Automatic Update' on page 527), an IP address is obtained from the server. This address is used as the OAMP address for this session, overriding the IP address configured in the Multiple Interface table. The address specified in this table takes effect only after you save the configuration to the device's flash memory. This enables the device to use a temporary IP address for initial management and configuration, while retaining the address configured in this table for deployment.
- To configure firewall rules (access list) for allowing or blocking packets received from specific IP network interfaces, see 'Configuring Firewall Settings' on page 137.
- The Multiple Interface table can also be configured using the table ini file parameter, InterfaceTable (see 'Networking Parameters' on page 609).

- To configure IP network interfaces:
- 5. Open the IP Settings page (**Configuration** tab > **VoIP** menu > **Network** submenu > **IP Settings**).

Figure 11-2: IP Settings Page (Single Network Interface)



Note: The IP Settings page appears only in the following circumstances:

- Upon initial configuration (i.e., IP interfaces have never been configured).
- The Multiple Interface Table button has not been clicked in any previous access to this page and only a single IP address has been configured.
- The device has been restored to default settings.

If you have clicked the Multiple Interface Table button or have configured multiple interfaces using any other non-Web management tool, the Multiple Interface Table page appears instead of the IP Settings page.

- 6. To access the Multiple Interface table so that you can configure multiple network interfaces, click the Multiple Interface Table button, located under the Multiple Interface Settings group; a confirmation message box appears:

Figure 11-3: Confirmation Message for Accessing the Multiple Interface Table

- 7. Click OK; the Multiple Interface Table page appears:

Index	Application Type	IP Address	Prefix Length	Gateway	VLAN ID	Interface Name	Primary DNS Server IP Address	Secondary DNS Server IP Address
0	OAMP + Media + Control	10.13.4.13	16	10.13.0.1	1	O-M+C	0.0.0.0	0.0.0.0

<ul style="list-style-type: none"> ⚡ VLAN Mode: Disable Native VLAN ID: 1 	IP Interface Status Table
---------------------------------------------------------------------------------------------------	---------------------------

- 8. In the 'Add Index' field, enter the desired index number for the new interface, and then click **Add Index**; the index row is added to the table.

9. Configure the interface according to the table below.
10. Click the **Apply** button; the interface is added to the table and the **Done** button appears.
11. Click **Done** to validate the interface. If the interface is not valid (e.g., if it overlaps with another interface in the table or if it does not adhere to the other rules as summarized in 'Multiple Interface Table Configuration Summary and Guidelines' on page 115), a warning message is displayed.
12. Save the changes to flash memory and reset the device (see 'Saving Configuration' on page 494).

To view configured network interfaces that are currently active, click the IP Interface Status Table  button. For more information, see Viewing Active IP Interfaces on page 552.

Multiple Interface Table Parameters Description

Parameter	Description
Table parameters	
Index [InterfaceTable_Index]	Table index row of the interface. The range is 0 to 15.
Web: Application Type EMS: Application Types [InterfaceTable_ApplicationTypes]	<p>Defines the applications allowed on the interface.</p> <ul style="list-style-type: none"> ▪ [0] OAMP = Operations, Administration, Maintenance and Provisioning (OAMP) applications (e.g., Web, Telnet, SSH, and SNMP). ▪ [1] Media = Media (i.e., RTP streams of voice). ▪ [2] Control = Call Control applications (e.g., SIP). ▪ [3] OAMP + Media = OAMP and Media applications. ▪ [4] OAMP + Control = OAMP and Call Control applications. ▪ [5] Media + Control = Media and Call Control applications. ▪ [6] OAMP + Media + Control = All application types are allowed on the interface. <p>Note: For valid configuration, see 'Multiple Interface Table Configuration Rules' on page 115.</p>
Web/EMS: IP Address [InterfaceTable_IPAddress]	<p>Defines the IPv4 IP address in dotted-decimal notation.</p> <p>Note: For valid configuration, see 'Multiple Interface Table Configuration Rules' on page 115.</p>
Web/EMS: Prefix Length [InterfaceTable_PrefixLength]	<p>Defines the prefix length of the related IP address. This is a Classless Inter-Domain Routing (CIDR)-style representation of a dotted-decimal subnet notation. The CIDR-style representation uses a suffix indicating the number of bits which are set in the dotted-decimal format. For example, 192.168.0.0/16 is synonymous with 192.168.0.0 and subnet 255.255.0.0. This CIDR lists the number of '1' bits in the subnet mask (i.e., replaces the standard dotted-decimal representation of the subnet mask for IPv4 interfaces). For example, a subnet mask of 255.0.0.0 is represented by a prefix length of 8 (i.e., 11111111 00000000 00000000 00000000) and a subnet mask of 255.255.255.252 is represented by a prefix length of 30 (i.e., 11111111 11111111 11111111 11111100).</p> <p>The prefix length is a Classless Inter-Domain Routing (CIDR) style presentation of a dotted-decimal subnet notation. The CIDR-style presentation is the latest method for interpretation of IP addresses. Specifically, instead of using eight-bit address blocks, it uses the variable-length subnet masking technique to allow allocation on arbitrary-length prefixes.</p>

Parameter	Description
	<p>The prefix length for IPv4 can range from 0 to 30.</p> <p>Note: For valid configuration, see 'Multiple Interface Table Configuration Rules' on page 115.</p>
Web/EMS: Gateway [InterfaceTable_Gateway]	<p>Defines the IP address of the default gateway for the interface. When traffic is sent from this interface to an unknown destination (i.e., not in the same subnet and not defined for any static routing rule), it is forwarded to this default gateway.</p> <p>Note: For valid configuration, see 'Multiple Interface Table Configuration Rules' on page 115.</p>
Web/EMS: VLAN ID [InterfaceTable_VlanID]	<p>Defines a VLAN ID for the interface. Incoming traffic tagged with this VLAN ID is routed to the corresponding interface. Outgoing traffic from this interface is tagged with this VLAN ID.</p> <p>Notes:</p> <ul style="list-style-type: none"> For valid configuration, see 'Multiple Interface Table Configuration Rules' on page 115. To enable VLANs, use the 'VLAN Mode' parameter.
Web/EMS: Interface Name [InterfaceTable_InterfaceName]	<p>Defines a name for this interface. This name is used in various configuration tables to associate this network interface with other configuration entities such as Media Realms. It is also displayed in management interfaces (Web, CLI, and SNMP) for clarity where it has no functional use.</p> <p>The valid value is a string of up to 16 characters.</p> <p>Note: For valid configuration, see 'Multiple Interface Table Configuration Rules' on page 115.</p>
Web/EMS: Primary DNS Server IP address [InterfaceTable_PrimaryDNSServerIPaddress]	<p>(Optional) Defines the primary DNS server's IP address (in dotted-decimal notation), which is used for translating domain names into IP addresses for the interface.</p> <p>By default, no IP address is defined.</p>
Web/EMS: Secondary DNS Server IP address [InterfaceTable_SecondaryDNSServerIPaddress]	<p>(Optional) Defines the secondary DNS server's IP address (in dotted-decimal notation), which is used for translating domain names into IP addresses for the interface.</p> <p>By default, no IP address is defined.</p>
General Parameters	
Web/EMS: VLAN Mode [VLANMode]	<p>Enables VLANs tagging (IEEE 802.1Q).</p> <ul style="list-style-type: none"> [0] Disable (default) [1] Enable <p>Notes:</p> <ul style="list-style-type: none"> For this parameter to take effect, a device reset is required. To operate with multiple network interfaces, VLANs must be enabled. VLANs are available only when booting the device from flash. When booting using BootP/DHCP protocols, VLANs are disabled to allow easier maintenance access. In this scenario, multiple network interface capabilities are unavailable.
Web/EMS: Native VLAN ID	<p>Defines the Native VLAN ID. This is the VLAN ID to which untagged incoming traffic is assigned. Outgoing packets sent to this VLAN are</p>

Parameter	Description
[VLANNativeVLANID]	<p>sent only with a priority tag (VLAN ID = 0).</p> <p>When the Native VLAN ID is equal to one of the VLAN IDs listed in the Multiple Interface table (and VLANs are enabled), untagged incoming traffic is considered as incoming traffic for that interface. Outgoing traffic sent from this interface is sent with the priority tag (tagged with VLAN ID = 0).</p> <p>When the Native VLAN ID is different to any value in the 'VLAN ID' column in the table, untagged incoming traffic is discarded and all outgoing traffic is tagged.</p> <p>The default Native VLAN ID is 1.</p> <p>Note: If this parameter is not configured (i.e., default is 1) and one of the interfaces has a VLAN ID set to 1, this interface is still considered the 'Native' VLAN. If you do not wish to have a 'Native' VLAN ID and want to use VLAN ID 1, set this parameter to a value other than any VLAN ID in the table.</p>

11.3.1 Assigning NTP Services to Application Types

You can associate the Network Time Protocol (NTP) application with the OAMP or Control application type. This is done using the EnableNTPasOAM ini file parameter.

11.3.2 Multiple Interface Table Configuration Rules

The Multiple Interface table configuration must adhere to the following rules:

- Multiple Control and Media interfaces can be configured with overlapping IP addresses and subnets.
- The prefix length replaces the dotted-decimal subnet mask presentation and must have a value of 0-30 for IPv4 addresses.
- Only one OAMP interface must be configured and this must be an IPv4 address. This OAMP interface can be combined with Media and Control.
- At least one Control interface must be configured with an IPv4 address.
- At least one Media interface must be configured with an IPv4 address.
- The application types **may** be mixed, for example: The network interface types can be combined:
 - Example 1:
 - ◆ One combined OAMP-Media-Control interface with an IPv4 address
 - Example 2:
 - ◆ One OAMP interface with an IPv4 address
 - ◆ One or more Control interfaces with IPv4 addresses
 - ◆ One or more Media interfaces with IPv4 interfaces (with VLANs)
 - Example 3:
 - ◆ One combined OAMP-Media interface with an IPv4 address
 - ◆ One or more combined Media-Control interfaces with IPv4 addresses.
- Each network interface can be configured with a Default Gateway. The address of the Default Gateway must be in the same subnet as the associated interface. Additional static routing rules can be configured in the IP Routing table.
- The interface name must be configured (mandatory) and unique for each interface,

and can include up to 16 characters.

- For IPv4 addresses, the 'Interface Mode' column must be set to IPv4 Manual (numeric value 10).
- Each network interface must be assigned a unique VLAN ID.
- When configuring more than one IP interface of the same address family, VLANs must be enabled.
- For network configuration to take effect, you must save the configuration to the device's flash memory (burn) with a device reset.



Notes:

- When configuring the network interfaces and VLANs in the Multiple Interface table using the Web interface, it is recommended to check that your configuration is valid, by clicking the Done button in the Multiple Interface Table page.
- Upon device start up, the Multiple Interface table is parsed and passes comprehensive validation tests. If any errors occur during this validation phase, the device sends an error message to the Syslog server and falls back to a "safe mode", using a single interface and no VLANs. Ensure that you view the Syslog messages that the device sends in system startup to see if any errors occurred.

11.3.3 Troubleshooting the Multiple Interface Table

If any of the Multiple Interface table guidelines are violated, the device falls back to a "safe mode" configuration, consisting of a single IPv4 interface without VLANs. For more information on validation failures, consult the Syslog messages.

Validation failures may be caused by one of the following:

- One of the Application Types (OAMP, Control, or Media) are missing in the IPv4 interfaces.
- There are too many interfaces for Application Type, OAMP. There is only one interface defined, but the 'Application Types' column is not set to **OAMP + Media + Control** (numeric value 6).
- An IPv4 interface was defined with 'Interface Type' other than **IPv4 Manual** (10).
- Two interfaces have the same VLAN ID value while VLANs are enabled.
- Two interfaces have the same name.

Apart from these validation errors, connectivity problems may be caused by one of the following:

- Trying to access the device with VLAN tags while booting from BootP/DHCP.
- Trying to access the device with untagged traffic when VLANs are on and Native VLAN is not configured properly.
- The IP Routing table is not configured properly.

11.3.4 Networking Configuration Examples

This section provides configuration examples of networking interfaces.

11.3.4.1 One VoIP Interface for All Applications

This example describes the configuration of a single VoIP interface for all applications:

1. **Multiple Interface table:** Configured with a single interface for OAMP, Media and Control:

Example of Single VoIP Interface in Multiple Interface Table

Index	Application Type	IP Address	Prefix Length	Default	VLAN ID	Interface Name
0	OAMP, Media & Control	192.168.85.14	16	192.168.0.1	1	myInterface

2. VLANs are not required and the Native VLAN ID is irrelevant. Class of Service parameters may have default values.
3. **IP Routing table:** Two routes are configured for directing traffic for subnet 201.201.0.0/16 to 192.168.0.2, and all traffic for subnet 202.202.0.0/16 to 192.168.0.3:

Example of IP Routing Table

Destination IP Address	Prefix Length	Gateway IP Address	Metric
201.201.0.0	16	192.168.0.2	1
202.202.0.0	16	192.168.0.3	1

4. The NTP applications remain with their default application types.

11.3.4.2 VoIP Interface per Application Type

This example describes the configuration of three VoIP interfaces; one for each application type:

1. **Multiple Interface table:** Configured with three interfaces, each for a different application type, i.e., one for OAMP, one for Call Control, and one for RTP Media, and each with a different VLAN ID and default gateway:

Example of VoIP Interfaces per Application Type in Multiple Interface Table

Index	Application Type	IP Address	Prefix Length	Gateway	VLAN ID	Interface Name
0	OAMP	192.168.85.14	16	0.0.0.0	1	ManagementIF
1	Control	200.200.85.14	24	200.200.85.1	200	myControlIF
2	Media	211.211.85.14	24	211.211.85.1	211	myMediaIF

2. VLANs are required and the Native VLAN ID is the same VLAN ID as the Management interface (configured for Index 0):
 - 'VLAN Mode' is set to Enable.
 - 'Native VLAN ID' field is set to "1".
3. **IP Routing table:** A routing rule is required to allow remote management from a host in 176.85.49.0 / 24:

Example IP Routing Table

Destination IP Address	Prefix Length	Gateway IP Address	Metric	Interface Name
176.85.49.0	24	192.168.0.1	1	-

1. All other parameters are set to their respective default values. The NTP application remains with its default application types.

11.3.4.3 VoIP Interfaces for Combined Application Types

This example describes the configuration of multiple interfaces for the following applications:

- One interface for the OAMP application.
- Interfaces for Call Control and Media applications.

1. **Multiple Interface table:**

Example of VoIP Interfaces of Combined Application Types in Multiple Interface Table

Index	Application Type	IP Address	Prefix Length	Gateway	VLAN ID	Interface Name
0	OAMP	192.168.85.14	16	192.168.0.1	1	Mgmt
1	Media & Control	200.200.85.14	24	200.200.85.1	201	MediaCntrl1
2	Media & Control	200.200.86.14	24	200.200.86.1	202	MediaCntrl2

2. VLANs are required and the Native VLAN ID is the same VLAN ID as the Management interface (index 0):
 - 'VLAN Mode' is set to Enable.
 - 'Native VLAN ID' field is set to "1".
3. **IP Routing table:** A routing rule is required to allow remote management from a host in 176.85.49.0/24:

Example of IP Routing Table

Destination IP Address	Prefix Length	Gateway IP Address	Metric	Interface Name
176.85.49.0	24	192.168.0.10	1	-

4. The NTP application is configured (using the ini file) to serve as OAMP applications:

```
EnableNTPasOAM = 1
```

11.3.4.4 VoIP Interfaces with Multiple Default Gateways

Below is a configuration example using default gateways per IP network interface. In this example, the default gateway 200.200.85.1 is available for applications allowed on Interface #1, whereas outgoing management traffic (originating on Interface #0) is never directed to this default gateway.

Configured Default Gateway Example

Index	Application Type	IP Address	Prefix Length	Gateway	VLAN ID	Interface Name
0	OAMP	192.168.085.214	16	0.0.0.0	100	Mgmt
1	Media & Control	200.200.85.14	24	200.200.85.1	200	CntrlMedia

A separate IP routing table enables you to configure static routing rules. Configuring the following static routing rules enables OAMP applications to access peers on subnet 17.17.0.0 through the gateway 192.168.0.1.

Separate Routing Table Example

Destination IP Address	Prefix Length	Gateway IP Address	Metric	Interface Name	Status
17.17.0.0	16	192.168.0.1	1	0	Active

11.4 Configuring the IP Routing Table

The IP Routing Table page allows you to define up to 30 static IP routing rules for the device. These rules can be associated with a network interface (defined in the Multiple Interface table) and therefore, the routing decision is based on the source subnet/VLAN. If not associated with an IP interface, the static IP rule is based on destination IP address. Traffic destined to the subnet specified in the routing rule is re-directed to the defined gateway, reachable through the specified interface. Before sending an IP packet, the device searches this table for an entry that matches the requested destination host/network. If such an entry is found, the device sends the packet to the indicated router. If no explicit entry is found, the packet is sent to the default gateway.

➤ **To configure static IP routing:**

1. Open the IP Routing Table page (**Configuration** tab > **VoIP** menu > **Network** submenu > **IP Routing Table**).

Figure 11-4: IP Routing Table Page

IP Routing Table							
#	Delete Row	Destination IP Address	Prefix Length	Gateway IP Address	Metric	Interface Name	Status
1	<input type="checkbox"/>	169.254.254.252	30	0.0.0.0	0	InternalF	Active
2	<input type="checkbox"/>	10.9.0.0	16	0.0.0.0	0	Voice	Active
3	<input type="checkbox"/>	0.0.0.0	0	10.9.0.1	1	Voice	Active
4	<input type="checkbox"/>	0.0.0.0	0	169.254.254.253	2	InternalF	Active

Add a new table entry				
Destination IP Address	Prefix Length	Gateway IP Address	Metric	Interface Name
	16		1	

2. In the Add a new table entry table, add a new static routing rule according to the parameters described in the table below.
3. Click **Add New Entry**; the new routing rule is added to the IP routing table.

To delete a routing rule from the table, select the 'Delete Row' check box corresponding to the required routing rule, and then click **Delete Selected Entries**.



Notes:

- You can delete only inactive routing rules.
- The IP Routing table can also be configured using the table ini file parameter, StaticRouteTable.

IP Routing Table Description

Parameter	Description
Destination IP Address [StaticRouteTable_Destination]	Defines the IP address of the destination host/network. The destination can be a single host or a whole subnet, depending on the Prefix Length configured for this routing rule.
Prefix Length [StaticRouteTable_PrefixLength]	Defines the Classless Inter-Domain Routing (CIDR)-style representation of a dotted-decimal subnet notation, of the destination host/network. The CIDR-style representation uses a suffix indicating the number of bits that are set in the dotted-decimal format. For example, 16 is synonymous with subnet 255.255.0.0.

Parameter	Description
	The address of the host/network you want to reach is determined by an AND operation that is applied to the fields 'Destination IP Address' and 'Prefix Length'. For example, to reach the network 10.8.x.x, enter 10.8.0.0 in the 'Destination IP Address' field and 16 in the 'Prefix Length'. As a result of the AND operation, the value of the last two octets in the 'Destination IP Address' field is ignored. To reach a specific host, enter its IP address in the 'Destination IP Address' field and 32 in the 'Prefix Length' field.
Gateway IP Address [StaticRouteTable_Gateway]	Defines the IP address of the router (next hop) used for traffic destined to the subnet/host as defined in the 'Destination IP Address' / 'Prefix Length' field. Note: The Gateway address must be in the same subnet as the IP address of the interface over which you configure this static routing rule.
Metric	Defines the number of hops needed to reach the specified destination. Note: The recommended value for this parameter is 1. This parameter must be set to a number greater than 0 for the routing rule to be valid. Routing entries with Hop Count equals 0 are local routes set automatically by the device.
Interface Name [StaticRouteTable_InterfaceName]	Assigns a network interface through which the 'Gateway IP Address' is reached. This is the string value as configured for the network interface in the 'Interface Name' field of the Multiple Interface table (see 'Configuring IP Network Interfaces' on page 110). Note: The IP address of the 'Gateway IP Address' field must be in the same subnet as this interface's IP address.
Status	Read-only field displaying the status of the static IP route: <ul style="list-style-type: none"> "Active" - routing rule is used by the device. "Inactive" - routing rule is not applied. When the destination IP address is not on the same segment with the next hop or the interface does not exist, the route state changes to "Inactive".

11.4.1 Interface Column

This example describes the configuration of static IP routing rules.

1. Configure network interfaces in the Multiple Interface table, as shown below:

Configured Network Interfaces in Multiple Interface Table

Index	Application Type	IP Address	Prefix Length	Gateway	VLAN ID	Interface Name
0	OAMP	192.168.0.2	16	192.168.0.1	501	Mng
1	Media & Control	10.32.174.50	24	10.32.174.1	2012	MediaCntrl
2	Media	10.33.174.50	24	10.33.174.1	2013	Media1
3	Control	10.34.174.50	24	10.34.174.1	2014	Cntrl1

2. Configure static IP Routing rules in the IP Routing table, as shown below:

Configured Static IP Routing Rules in IP Routing Table

Destination IP Address	Prefix Length	Gateway IP Address	Metric	Interface Name
10.31.174.0	24	192.168.11.1	1	Mng
174.96.151.15	24	10.32.174.12	1	MediaCntrl
10.35.174.0	24	10.34.174.240	1	Cntrl1

Note that the IP address configured in the 'Gateway IP Address' field (i.e., next hop) must reside on the same subnet as the IP address of the associated network interface that is specified in the 'Interface Name' field.

11.4.2 Routing Table Configuration Summary and Guidelines

The Routing table configurations must adhere to the following rules:

- Up to 30 different static routing rules can be configured.
- The 'Prefix Length' replaces the dotted-decimal subnet mask presentation. This column must have a value of 0-31 for IPv4 interfaces.
- The 'Gateway IP Address' field must be on the same subnet as the IP address of the associated interface specified in the 'Interface Name' field.
- The 'Metric' field must be set to 1.
- For the configuration settings to take effect, you must reset the device with a "burn" to flash memory.

11.4.3 Troubleshooting the Routing Table

When adding a new static routing rule, the added rule passes a validation test. If errors are found, the routing rule is rejected and is not added to the IP Routing table. Failed routing validations may result in limited connectivity (or no connectivity) to the destinations specified in the incorrect routing rule. For any error found in the Routing table or failure to configure a routing rule, the device sends a notification message to the Syslog server reporting the problem.

Common routing rule configuration errors may include the following:

- The IP address specified in the 'Gateway IP Address' field is unreachable from the interface specified in the 'Interface Name' field.
- The same destination is configured in two different routing rules.
- More than 30 routing rules have been configured.



Note: If an IP routing rule is required to access OAMP applications (for remote management, for example) and the route is not configured correctly, the route is not added and the device is not accessible remotely. To restore connectivity, the device must be accessed locally from the OAMP subnet and the required routes be configured.

11.5 Configuring Quality of Service

The QoS Settings page is used for configuring the Layer-2 and Layer-3 Quality of Service (QoS) parameters. Differentiated Services (DiffServ) is an architecture providing different types or levels of service for IP traffic. DiffServ (according to RFC 2474), prioritizes certain traffic types based on their priority, thereby, accomplishing a higher-level QoS at the expense of other traffic types. By prioritizing packets, DiffServ routers can minimize transmission delays for time-sensitive packets such as VoIP packets.

You can assign different VLAN priorities (IEEE 802.1p) and DiffServ to the supported Class of Service (CoS):

- Network Service class – network control traffic (ICMP, ARP)
- Premium Media service class – used for RTP media traffic
- Premium Control service class – used for call control (i.e., SIP) traffic
- Gold service class – used for streaming applications
- Bronze service class – used for OAMP applications

The Layer-2 QoS parameters define the values for the 3 priority bits in the VLAN tag of frames related to a specific service class (according to the IEEE 802.1p standard). The Layer-3 QoS parameters define the values of the DiffServ field in the IP Header of the frames related to a specific service class.

The mapping of an application to its CoS and traffic type is shown in the table below:

Traffic/Network Types and Priority

Application	Traffic / Network Types	Class-of-Service (Priority)
Debugging interface	Management	Bronze
Telnet	Management	Bronze
DHCP	Management	Network
Web server (HTTP)	Management	Bronze
SNMP GET/SET	Management	Bronze
Web server (HTTPS)	Management	Bronze
IPSec IKE	Determined by the service	Determined by the service
RTP traffic	Media	Premium media
RTCP traffic	Media	Premium media
T.38 traffic	Media	Premium media
SIP	Control	Premium control
SIP over TLS (SIPS)	Control	Premium control
Syslog	Management	Bronze
ICMP	Management	Determined by the initiator of the request
ARP listener	Determined by the initiator of the request	Network
SNMP Traps	Management	Bronze

Application	Traffic / Network Types	Class-of-Service (Priority)
DNS client	Varies according to DNS settings: <ul style="list-style-type: none"> ▪ OAMP ▪ Control 	Depends on traffic type: <ul style="list-style-type: none"> ▪ Control: Premium Control ▪ Management: Bronze
NTP	Varies according to the interface type associated with NTP (see 'Assigning NTP Services to Application Types' on page 115): <ul style="list-style-type: none"> ▪ OAMP ▪ Control 	Depends on traffic type: <ul style="list-style-type: none"> ▪ Control: Premium control ▪ Management: Bronze
NFS	NFSServers_VlanType in the NFSServers table	Gold

➤ **To configure QoS:**

1. Open the QoS Settings page (**Configuration** tab > **VoIP** menu > **Network** submenu > **QoS Settings**).

▼ Priority Settings	
Network Priority	<input type="text" value="7"/>
Media Premium Priority	<input type="text" value="6"/>
Control Premium Priority	<input type="text" value="6"/>
Gold Priority	<input type="text" value="4"/>
Bronze Priority	<input type="text" value="2"/>
▼ Differential Services	
Network QoS	<input type="text" value="48"/>
Media Premium QoS	<input type="text" value="46"/>
Control Premium QoS	<input type="text" value="40"/>
Gold QoS	<input type="text" value="26"/>
Bronze QoS	<input type="text" value="10"/>

2. Configure the QoS parameters as required.
3. Click **Submit** to apply your changes.
4. Save the changes to flash memory (see 'Saving Configuration' on page 494).

11.6 Disabling ICMP Redirect Messages

You can configure the device's handling of ICMP Redirect messages. These messages can either be rejected (ignored) or permitted.



Note: You can also configure this feature using the ini file parameter `DisableICMPRedirects` (see 'Routing Parameters' on page 611).

➤ **To configure the handling of ICMP Redirect messages:**

1. Open the Network Settings page (**Configuration** tab > **VoIP** menu > **Network** submenu > **Network Settings**).

Figure 11-5: Disabling ICMP Redirect in Network Settings Page

The screenshot shows a web interface with a dropdown menu. The dropdown is labeled 'Disable ICMP Redirects' and currently displays the option 'Enable'. The dropdown arrow is pointing downwards.

2. From the 'Disable ICMP Redirects' drop-down list, select the required option.
3. Click **Submit** to apply your changes.

11.7 DNS

You can use the device's embedded domain name server (DNS) or an external, third-party DNS to translate domain names into IP addresses. This is useful if domain names are used as the destination in call routing. The device supports the configuration of the following DNS types:

- Internal DNS table - see 'Configuring the Internal DNS Table' on page 125
- Internal SRV table - see 'Configuring the Internal SRV Table' on page 127

11.7.1 Configuring the Internal DNS Table

The Internal DNS Table page, similar to a DNS resolution, translates up to 20 host (domain) names into IP addresses. This functionality can be used when a domain name (FQDN) is configured as an IP destination for Tel-to-IP or IP-to-IP routing in the Outbound IP Routing Table. Up to four different IP addresses can be assigned to the same host name. This is typically needed for alternative Tel-to-IP call routing.




Notes:

- The device initially attempts to resolve a domain name using the Internal DNS table. If the domain name isn't listed in the table, the device performs a DNS resolution using an external DNS server for the related IP network interface, configured in the Multiple Interface table (see 'Configuring IP Network Interfaces' on page 110).
- You can also configure the DNS table using the table ini file parameter, `DNS2IP` (see 'DNS Parameters' on page 616).

- **To configure the internal DNS table:**
- 1. Open the Internal DNS Table page (**Configuration** tab > **VoIP** menu > **Network** submenu > **DNS** submenu > **Internal DNS Table**).
- 2. Click **Add**; the following dialog box appears:

Figure 11-6: Internal DNS Table - Add Record Dialog Box



Index	0
Domain Name	dnscompany.com
First IP Address	10.8.2.15
Second IP Address	10.8.4.20
Third IP Address	10.8.16.17
Fourth IP Address	0.0.0.0

- 3. Configure the DNS rule, as required. For a description of the parameters, see the table below.
- 4. Click **Submit**; the DNS rule is added to the table.

Internal DNS Table Parameter Description

Parameter	Description
Domain Name [Dns2Ip_DomainName]	Defines the host name to be translated. The valid value is a string of up to 31 characters.
First IP Address [Dns2Ip_FirstIpAddress]	Defines the first IP address (in dotted-decimal format notation) to which the host name is translated.
Second IP Address [Dns2Ip_SecondIpAddress]	Defines the second IP address (in dotted-decimal format notation) to which the host name is translated.
Third IP Address [Dns2Ip_ThirdIpAddress]	Defines the third IP address (in dotted-decimal format notation) to which the host name is translated.
Fourth IP Address [Dns2Ip_FourthIpAddress]	Defines the fourth IP address (in dotted-decimal format notation) to which the host name is translated.

11.7.2 Configuring the Internal SRV Table

The Internal SRV Table page resolves host names to DNS A-Records. Three different A-Records can be assigned to each host name, where each A-Record contains the host name, priority, weight, and port.



Notes:

- If the Internal SRV table is configured, the device initially attempts to resolve a domain name using this table. If the domain name isn't found, the device performs a Service Record (SRV) resolution using an external DNS server configured in the Multiple Interface table (see 'Configuring IP Network Interfaces' on page 110).
- The Internal SRV table can also be configured using the table ini file parameter, SRV2IP (see 'DNS Parameters' on page 616).

➤ To configure the Internal SRV table:

1. Open the Internal SRV Table page (**Configuration** tab > **VoIP** menu > **Network** submenu > **DNS** submenu > **Internal SRV Table**).
2. Click **Add**; the following dialog box appears:

Figure 11-7: Internal SRV Table Page

Add Record	
Index	<input type="text" value="0"/>
Domain Name	<input type="text"/>
Transport Type	UDP
DNS Name 1	<input type="text"/>
Priority 1	<input type="text" value="0"/>
Weight 1	<input type="text" value="0"/>
Port 1	<input type="text" value="0"/>
DNS Name 2	<input type="text"/>
Priority 2	<input type="text" value="0"/>
Weight 2	<input type="text" value="0"/>
Port 2	<input type="text" value="0"/>
DNS Name 3	<input type="text"/>
Priority 3	<input type="text" value="0"/>
Weight 3	<input type="text" value="0"/>
Port 3	<input type="text" value="0"/>

3. Configure the SRV rule, as required. For a description of the parameters, see the table below.
4. Click **Submit**; the SRV rule is added to the table.

Internal SRV Table Parameter Description

Parameter	Description
Domain Name [Srv2lp_InternalDomain]	Defines the host name to be translated. The valid value is a string of up to 31 characters.
Transport Type [Srv2lp_TransportType]	Defines the transport type. <ul style="list-style-type: none"> ▪ [0] UDP (default) ▪ [1] TCP ▪ [2] TLS
DNS Name (1-3) [Srv2lp_Dns1/2/3]	Defines the first, second or third DNS A-Record to which the host name is translated.
Priority (1-3) [Srv2lp_Priority1/2/3]	Defines the priority of the target host. A lower value means that it is more preferred.
Weight (1-3) [Srv2lp_Weight1/2/3]	Defines a relative weight for records with the same priority.
Port (1-3) [Srv2lp_Port1/2/3]	Defines the TCP or UDP port on which the service is to be found.

11.8 Configuring NFS Settings

Network File System (NFS) enables the device to access a remote server's shared files and directories and to handle them as if they're located locally. The device can use NFS to load *cmp*, *ini*, and auxiliary files through the Automatic Update mechanism (see 'Automatic Update' on page 527).

You can configure up to 16 different NFS file systems. As a file system, the NFS is independent of machine types, operating systems and network architectures. Note that an NFS file server can share multiple file systems. There must be a separate row for each remote file system shared by the NFS file server that needs to be accessed by the device.

➤ To add remote NFS file systems:

1. Open the Application Settings page (**Configuration** tab > **System** menu > **Application Settings**).
2. Under the 'NFS Settings' group, click the **NFS Table**  button; the NFS Table page appears.

- Click the **Add** button; the Add Record dialog box appears:

Figure 11-8: Add Record Dialog Box for NFS

Field	Value
Index	1
Host Or IP	10.13.4.5
Root Path	/audio_files
NFS Version	NFS Version 3
Authentication Type	Null
User ID	0
Group ID	1
Vlan Type	MEDIA

- Configure the NFS parameters according to the table below.
- Click the **Submit** button; the remote NFS file system is immediately applied, which can be verified by the appearance of the 'NFS mount was successful' message in the Syslog server.
- To save the changes to flash memory, see 'Saving Configuration' on page 494.

Notes:



- To avoid terminating current calls, a row must not be deleted or modified while the device is currently accessing files on that remote NFS file system.
- The combination of 'Host Or IP' and 'Root Path' must be unique for each row in the table. For example, the table must include only one row with a Host/IP of 192.168.1.1 and Root Path of /audio.
- The NFS table can also be configured using the table ini file parameter NFSServers (see 'NFS Parameters' on page 615)

NFS Settings Parameters

Parameter	Description
Index	The row index of the remote file system. The valid range is 1 to 16.
Host Or IP [NFSServers_HostOrIP]	The domain name or IP address of the NFS server. If a domain name is provided, a DNS server must be configured.
Root Path [NFSServers_RootPath]	Path to the root of the remote file system in the format: /[path]. For example, '/audio'.
NFS Version [NFSServers_NfsVersion]	NFS version used to access the remote file system. <ul style="list-style-type: none"> [2] NFS Version 2

Parameter	Description
]	<ul style="list-style-type: none"> [3] NFS Version 3 (default)
Authentication Type [NFSServers_AuthType]	Authentication method used for accessing the remote file system. <ul style="list-style-type: none"> [0] Null [1] Unix (default)
User ID [NFSServers_UID]	User ID used in authentication when using Unix. The valid range is 0 to 65537. The default is 0.
Group ID [NFSServers_GID]	Group ID used in authentication when using Unix. The valid range is 0 to 65537. The default is 1.
VLAN Type [NFSServers_VlanType]	The VLAN type for accessing the remote file system. <ul style="list-style-type: none"> [0] OAM [1] MEDIA (default) <p>Note: This parameter applies only if VLANs are enabled or if Multiple IPs is configured (see 'Configuring IP Network Interfaces' on page 110).</p>

11.9 Network Address Translation Support

Network Address Translation (NAT) is a mechanism that maps internal IP addresses (and ports) used within a private network to global IP addresses and vice versa, providing transparent routing to end hosts. The primary advantages of NAT include (1) reduction in the number of global IP addresses required in a private network (global IP addresses are only used to connect to the Internet) and (2) better network security by hiding the internal architecture.

The design of SIP creates a problem for VoIP traffic to pass through NAT. SIP uses IP addresses and port numbers in its message body. However, the NAT server is unable to modify the SIP messages and thus, can't change local addresses to global addresses.

This section discusses the device's solutions for overcoming NAT traversal issues.

11.9.1 Device Located behind NAT


Two different streams traverse through NAT - signaling and media. A device located behind a NAT, that initiates a signaling path has problems receiving incoming signaling responses as they are blocked by the NAT server. Therefore, the initiating device must inform the receiving device where to send the media. To resolve this NAT problem, the following solutions are provided by the device, listed in priority of the selected method used by the device:

- a. If configured, uses an external STUN server to assign a NAT address to all interfaces - see .Configuring STUN on page 131.
- b. If configured, uses the single Static NAT IP address for all interfaces - see 'Configuring a Static NAT IP Address for All Interfaces' on page 132.
- c. If configured, uses the NAT Translation table which configures NAT per interface - see Configuring NAT Translation per IP Interface on page 133.

If NAT is not configured by any of the above-mentioned methods, the device sends the packet according to its IP address configured in the Multiple Interface table.

The figure below illustrates the NAT problem faced by the SIP networks where the device is located behind a NAT:

Figure 11-9: Device behind NAT and NAT Issues



11.9.1.1 Configuring STUN

Simple Traversal of UDP through NATs (STUN), based on RFC 3489 is a client / server protocol that solves most of the NAT traversal problems. The STUN server operates in the public Internet and the STUN clients are embedded in end-devices located behind NAT. STUN is used for signaling and the media streams. STUN works with many existing NAT types and does not require any special behavior.

STUN enables the device to discover the presence (and types) of NATs and firewalls located between it and the public Internet. It provides the device with the capability to determine the public IP address and port allocated to it by the NAT. This information is later embedded in outgoing SIP / SDP messages and enables remote SIP user agents to reach the device. It also discovers the binding lifetime of the NAT - the refresh rate necessary to keep NAT 'pinholes' open.

On startup, the device sends a STUN Binding Request. The information received in the STUN Binding Response (IP address:port) is used for SIP signaling. This information is updated every user-defined period (NATBindingDefaultTimeout).

At the beginning of each call and if STUN is required (i.e., not an internal NAT call), the media ports of the call are mapped. The call is delayed until the STUN Binding Response (that includes a global IP:port) for each media (RTP, RTCP and T.38) is received.

Notes:

- STUN is applicable only to UDP connections (not TCP and TLS).
- STUN can't be used when the device is located behind a symmetric NAT.
- Use either the STUN server IP address (STUNServerPrimaryIP) or domain name (STUNServerDomainName) method, with priority to the first one.



➤ **To enable STUN:**

1. Open the Application Settings page (**Configuration** tab > **System** menu > **Application Settings**).

Figure 11-10: STUN Parameters in Application Settings Page

▼ STUN Settings	
⚡ Enable STUN	Enable ▼
⚡ STUN Server Primary IP	0.0.0.0
⚡ STUN Server Secondary IP	0.0.0.0

2. From the 'Enable STUN' (EnableSTUN) drop-down list, select **Enable** to enable the STUN feature.
3. Configure the STUN server address using one of the following methods:
 - Define the IP address of the primary and secondary (optional) STUN servers, using the 'STUN Server Primary IP' field (STUNServerPrimaryIP) and 'STUN Server Secondary IP' field. If the primary STUN server is unavailable, the device attempts to communicate with the second server.
 - Define the domain name of the STUN server using the *ini* file parameter, STUNServerDomainName. The STUN client retrieves all STUN servers with an SRV query to resolve this domain name to an IP address and port, sorts the server list, and uses the servers according to the sorted list.
4. Configure the default NAT binding lifetime (in secondsUse) using the *ini* file parameter, NATBindingDefaultTimeout. STUN refreshes the binding information after this time expires.

11.9.1.2 Configuring a Static NAT IP Address for All Interfaces

You can configure a global (public) IP address of the router to enable static NAT between the device and the Internet for all network interfaces. Thus, the device replaces the source IP address for media of all outgoing SIP messages sent on any of its network interfaces to this public IP address.



Note: The NAT IP address can also be configured using the ini file parameter, StaticNATIP.

➤ **To configure a single static NAT IP address for all interfaces:**

1. Open the SIP General Parameters page (**Configuration** tab > **VoIP** menu > **SIP Definitions** submenu > **General Parameters**).

Figure 11-11: Configuring Static NAT IP Address in SIP General Parameters Page

▼ SIP General	
⚡ NAT IP Address	0.0.0.0

2. In the 'NAT IP Address' field, enter the NAT IP address in dotted-decimal notation.
3. Click **Submit**.
4. Save the setting to the device's flash memory with a device reset (see 'Saving Configuration' on page 494).

11.9.1.3 Configuring NAT Translation per IP Interface

The NAT Translation table defines network address translation (NAT) rules for translating source IP addresses per VoIP interface (SIP control and RTP media traffic) into NAT IP addresses (*global* or *public*), when the device is located behind NAT. This allows, for example, the separation of VoIP traffic between different ITSP's, and topology hiding of internal IP addresses to the "public" network. Each IP interface (configured in the Multiple Interface table) can be associated with a NAT rule in this table, translating the source IP address and port of the outgoing packet into the NAT address (IP address and port range). The device's NAT traversal mechanism replaces the source IP address of SIP messages sent from a specified VoIP interface to a public IP address.



Note: The NAT Translation table can also be configured using the table ini file parameter, NATTranslation.

➤ **To configure NAT translation rules:**

1. Open the NAT Translation Table page (**Configuration** tab > **VoIP** menu > **Control Network** submenu > **NAT Translation Table**).
2. Click the **Add** button; the following dialog box appears:

Figure 11-12: NAT Translation Table Page

3. Configure the parameters as required. For a description of the parameters, see the table below:
4. Click **Submit** to apply your changes.
5. To save the changes to flash memory, see 'Saving Configuration' on page 494.

NAT Translation Table Parameters

Parameter	Description
Index [NATTranslation_Index]	Defines the table index entry. This table can include up to 32 entries.

Parameter	Description
Source Interface Name [NATTranslation_SourceInterfaceName]	Defines the name of the IP interface, as appears in the Multiple Interface table. Note: If the Multiple Interface table is not configured, the default Source IP Interface Name is "All". This represents the single IP interface for OAMP, Control, and Media (defined by the LocalOAMIPAddress, LocalOAMSubnetMask, and LocalOAMDefaultGW parameters).
Target IP Address [NATTranslation_TargetIPAddress]	Defines the global IP address. This address is set in the SIP Via and Contact headers as well as in the o= and c= SDP fields.
Source Start Port [NATTranslation_SourceStartPort]	Defines the optional starting port range (1-65536) of the IP interface, used as matching criteria for this NAT rule. If not configured, the match is done on the entire port range. Only IP addresses and ports of matched source ports will be replaced.
Source End Port [NATTranslation_SourceEndPort]	Defines the optional ending port range (1-65536) of the IP interface, used as matching criteria for this NAT rule. If not configured, the match is done on the entire port range. Only IP addresses and ports of matched source ports will be replaced.
Target Start Port [NATTranslation_TargetStartPort]	Defines the optional, starting port range (1-65536) of the global address. If not configured, the ports are not replaced. Matching source ports are replaced with the target ports. This address is set in the SIP Via and Contact headers, as well as in the o= and c= SDP fields.
Target End Port [NATTranslation_TargetEndPort]	Defines the optional, ending port range (1-65536) of the global address. If not configured, the ports are not replaced. Matching source ports are replaced with the target ports. This address is set in the SIP Via and Contact headers, as well as in the o= and c= SDP fields.


11.9.2 Remote UA behind NAT

If the remote User Agent with which the device needs to communicate with is located behind NAT, the device can resolve the problem of activating the RTP/RTCP/T.38 streams to an invalid IP address / UDP port.

To resolve this NAT traversal issue, the device offers the following features:

- First Incoming Packet Mechanism - see 'First Incoming Packet Mechanism' on page 135
- RTP No-Op packets according to the avt-rtp-noop draft - see 'No-Op Packets' on page 135

The figure below illustrates a typical network architecture where the remote UA is located behind NAT:



11.9.2.1 First Incoming Packet Mechanism

If the remote device resides behind a NAT device, it's possible that the device can activate the RTP/RTCP/T.38 streams to an invalid IP address / UDP port. To avoid such cases, the device automatically compares the source address of the first received incoming RTP/RTCP/T.38 stream with the IP address and UDP port of the remote device when the session was initially opened. If the two are not identical, then the destination IP address of the outgoing RTP packets is set to the source IP address of the first incoming packet. The RTP, RTCP and T.38 can thus have independent destination IP addresses and UDP ports.

To enable NAT resolution using the First Incoming Packet mechanism, set the `DisableNAT` *ini* file parameter to 1.

11.10 Configuring General Media Settings

The General Media Settings page allows you to configure various media parameters. For a detailed description of the parameters appearing on this page, see 'Configuration Parameters Reference' on page 609.

➤ To enable NAT resolution using the First Incoming Packet mechanism:

1. Open the General Media Settings page (**Configuration** tab > **VoIP** menu > **Media** submenu > **General Media Settings**).

Figure 11-14: General Media Settings Page



2. Set the 'NAT Traversal' parameter to **Enable**.
3. Click **Submit** to apply your changes.

The `EnableIpAddrTranslation` and `EnableUdpPortTranslation` parameters allow you to specify the type of compare operation that occurs on the first incoming packet. To compare only the IP address, set `EnableIpAddrTranslation` to 1, and `EnableUdpPortTranslation` to 0. In this case, if the first incoming packet arrives with only a difference in the UDP port, the sending addresses won't change. If both the IP address and UDP port need to be compared, then both parameters need to be set to 1.

11.10.1.1 No-Op Packets

The device's No-Op packet support can be used to verify Real-Time Transport Protocol (RTP) and T.38 connectivity, and to keep NAT bindings and Firewall pinholes open. The No-Op packets are available for sending in RTP and T.38 formats.

You can control the activation of No-Op packets by using the *ini* file parameter `NoOpEnable`. If No-Op packet transmission is activated, you can control the time interval in which No-Op packets are sent in the case of silence (i.e., no RTP or T.38 traffic). This is done using the *ini* file parameter `NoOpInterval`. For a description of the RTP No-Op *ini* file parameters, see 'Networking Parameters' on page 609.

- **RTP No-Op:** The RTP No-Op support complies with IETF Internet-Draft draft-wing-avt-rtp-noop-03 ("A No-Op Payload Format for RTP"). This IETF document defines a No-Op payload format for RTP. The draft defines the RTP payload type as dynamic. You can control the payload type with which the No-Op packets are sent. This is performed using the `RTPNoOpPayloadType` *ini* parameter (see 'Networking Parameters' on page 609). The default payload type is 120.
- **T.38 No-Op:** T.38 No-Op packets are sent only while a T.38 session is activated. Sent packets are a duplication of the previously sent frame (including duplication of the

sequence number).



Note: Receipt of No-Op packets is always supported.

11.11 Robust Receipt of Media Streams

The “robust-media” mechanism is an AudioCodes proprietary mechanism to filter out unwanted media (i.e., RTP, RTCP, and T.38) streams that are sent to the same port number on the device. In practice, the media RTP/RTCP ports may receive additional multiple unwanted media streams as result of traces of previous calls, call control errors, or deliberate attacks. When more than one media stream reaches the device on the same port number, the “robust-media” mechanism detects the valid media stream and ignores the rest.

11.12 Multiple Routers Support

Multiple routers support is designed to assist the device when it operates in a multiple routers network. The device learns the network topology by responding to Internet Control Message Protocol (ICMP) redirections and caches them as routing rules (with expiration time).

When a set of routers operating within the same subnet serve as devices to that network and intercommunicate using a dynamic routing protocol, the routers can determine the shortest path to a certain destination and signal the remote host the existence of the better route. Using multiple router support, the device can utilize these router messages to change its next hop and establish the best path.



Note: Multiple Routers support is an integral feature that doesn't require configuration.

11.13 IP Multicasting

The device supports IP Multicasting level 1, according to RFC 2236 (i.e., IGMP version 2) for RTP channels. The device is capable of transmitting and receiving multicast packets.

12 Security

This section describes the VoIP security-related configuration.

12.1 Configuring Firewall Settings

The device provides an internal firewall that enables you to configure network traffic filtering rules (*access list*). You can add up to 50 firewall rules. The access list offers the following firewall possibilities:

- Block traffic from known malicious sources
- Allow traffic only from known "friendly" sources, and block all other traffic
- Mix allowed and blocked network sources
- Limit traffic to a user-defined rate (blocking the excess)
- Limit traffic to specific protocols, and specific port ranges on the device

For each packet received on the network interface, the table is scanned from top to bottom until the first matching rule is found. This rule can either permit (*allow*) or deny (*block*) the packet. Once a rule in the table is located, subsequent rules further down the table are ignored. If the end of the table is reached without a match, the packet is accepted.

Notes:


- This firewall applies to a very low-level network layer and overrides all your other security-related configuration. Thus, if you have configured higher-level security features (e.g., on the Application level), you must also configure firewall rules to permit this necessary traffic. For example, if you have configured IP addresses to access the Web and Telnet interfaces in the Web Access List (see 'Configuring Web and Telnet Access List' on page 73), you must configure a firewall rule that permits traffic from these IP addresses.
- Only Security Administrator users or Master users can configure firewall rules.
- Setting the 'Prefix Length' field to **0** means that the rule applies to **all** packets, regardless of the defined IP address in the 'Source IP' field. Therefore, it is highly recommended to set this parameter to a value other than 0.
- It is recommended to add a rule at the end of your table that blocks all traffic and to add firewall rules above it that allow required traffic (with bandwidth limitations). To block all traffic, use the following firewall rule:
 - Source IP: 0.0.0.0
 - Prefix Length: 0 (i.e., rule matches all IP addresses)
 - Start Port - End Port: 0-65535
 - Protocol: **Any**
 - Action Upon Match: **Block**
- You can also configure the firewall settings using the table ini file parameter, AccessList (see 'Security Parameters' on page 635).



➤ **To add firewall rules:**

1. Open the Firewall Settings page (**Configuration** tab > **VoIP** menu > **Security** submenu > **Firewall Settings**).
2. Click the **Add** button; the following dialog box appears:

Figure 12-1: Firewall Settings Page - Add Record



3. Configure the firewall parameters, as required. For a description of the parameters, see the table below.
4. Click **Submit** to add the new firewall rule to the table.
5. Reset the device to activate the rules.

The table below provides an example of configured firewall rules:

Firewall Rule Examples

Parameter	Value per Rule				
	1	2	3	4	5
Source IP	12.194.231.76	12.194.230.7	0.0.0.0	192.0.0.0	0.0.0.0
Prefix Length	16	16	0	8	0
Start Port and End Port	0-65535	0-65535	0-65535	0-65535	0-65535
Protocol	Any	Any	icmp	Any	Any
Use Specific Interface	Enable	Enable	Disable	Enable	Disable
Interface Name	WAN	WAN	None	Voice-Lan	None
Byte Rate	0	0	40000	40000	0
Burst Bytes	0	0	50000	50000	0
Action Upon Match	Allow	Allow	Allow	Allow	Block

The firewall rules in the above configuration example do the following:

- **Rules 1 and 2:** Typical firewall rules that allow packets ONLY from specified IP addresses (e.g., proxy servers). Note that the prefix length is configured.
- **Rule 3:** A more "advanced" firewall rule - bandwidth rule for ICMP, which allows a maximum bandwidth of 40,000 bytes/sec with an additional allowance of 50,000 bytes. If, for example, the actual traffic rate is 45,000 bytes/sec, then this allowance would be consumed within 10 seconds, after which all traffic exceeding the allocated 40,000 bytes/sec is dropped. If the actual traffic rate then slowed to 30,000 bytes/sec, the allowance would be replenished within 5 seconds.
- **Rule 4:** Allows traffic from the LAN voice interface and limits bandwidth.
- **Rule 5:** Blocks all other traffic.

Internal Firewall Parameters

Parameter	Description
Source IP [AccessList_Source_IP]	Defines the IP address (or DNS name) or a specific host name of the source network (i.e., from where the incoming packet is received).
Source Port [AccessList_Source_Port]	Defines the source UDP/TCP ports (of the remote host) from where packets are sent to the device. The valid range is 0 to 65535. Note: When set to 0, this field is ignored and any source port matches the rule.
Prefix Length [AccessList_PrefixLen]	(Mandatory) Defines the IP network mask - 32 for a single host or the appropriate value for the source IP addresses. <ul style="list-style-type: none"> ■ A value of 8 corresponds to IPv4 subnet class A (network mask of 255.0.0.0). ■ A value of 16 corresponds to IPv4 subnet class B (network mask of 255.255.0.0). ■ A value of 24 corresponds to IPv4 subnet class C (network mask of 255.255.255.0). The IP address of the sender of the incoming packet is trimmed in accordance with the prefix length (in bits) and then compared to the parameter 'Source IP'. The default is 0 (i.e., applies to all packets). You must change this value to any of the above options. Note: A value of 0 applies to all packets, regardless of the defined IP address. Therefore, you must set this parameter to a value other than 0.
Start Port [AccessList_Start_Port]	Defines the destination UDP/TCP start port (on this device) to where packets are sent. The valid range is 0 to 65535. Note: When the protocol type isn't TCP or UDP, the entire range must be provided.
End Port [AccessList_End_Port]	Defines the destination UDP/TCP end port (on this device) to where packets are sent. The valid range is 0 to 65535. Note: When the protocol type isn't TCP or UDP, the entire range must be provided.

Parameter	Description
Protocol [AccessList_Protocol]	<p>Defines the protocol type (e.g., UDP, TCP, ICMP, ESP or 'Any') or the IANA protocol number in the range of 0 (Any) to 255.</p> <p>Note: This field also accepts the abbreviated strings 'SIP' and 'HTTP'. Specifying these strings implies selection of the TCP or UDP protocols, and the appropriate port numbers as defined on the device.</p>
Use Specific Interface [AccessList_Use_Specific_Interface]	<p>Determines whether you want to apply the rule to a specific network interface defined in the Multiple Interface table (i.e., packets received from that defined in the Source IP field and received on this network interface):</p> <ul style="list-style-type: none"> ▪ [0] Disable (default) ▪ [1] Enable <p>Notes:</p> <ul style="list-style-type: none"> ▪ If enabled, then in the 'Interface Name' field (described below), select the interface to which the rule is applied. ▪ If disabled, then the rule applies to all interfaces.
Interface Name [AccessList_Interface_ID]	<p>Defines the network interface to which you want to apply the rule. This is applicable if you enabled the 'Use Specific Interface' field. The list displays interface names as defined in the Multiple Interface table in 'Configuring IP Network Interfaces' on page 110.</p>
Packet Size [AccessList_Packet_Size]	<p>Defines the maximum allowed packet size.</p> <p>The valid range is 0 to 65535.</p> <p>Note: When filtering fragmented IP packets, this field relates to the overall (re-assembled) packet size, and not to the size of each fragment.</p>
Byte Rate [AccessList_Byte_Rate]	<p>Defines the expected traffic rate (bytes per second), i.e., the allowed bandwidth for the specified protocol. In addition to this field, the 'Burst Bytes' field provides additional allowance such that momentary bursts of data may utilize more than the defined byte rate, without being interrupted.</p> <p>For example, if 'Byte Rate' is set to 40000 and 'Burst Bytes' to 50000, then this implies the following: the allowed bandwidth is 40000 bytes/sec with extra allowance of 50000 bytes; if, for example, the actual traffic rate is 45000 bytes/sec, then this allowance would be consumed within 10 seconds, after which all traffic exceeding the allocated 40000 bytes/sec is dropped. If the actual traffic rate then slowed to 30000 bytes/sec, then the allowance would be replenished within 5 seconds.</p>
Burst Bytes [AccessList_Byte_Burst]	<p>Defines the tolerance of traffic rate limit (number of bytes).</p> <p>The default is 0.</p>
Action Upon Match [AccessList_Allow_Type]	<p>Defines the firewall action to be performed upon rule match.</p> <ul style="list-style-type: none"> ▪ "Allow" = (Default) Permits these packets ▪ "Block" = Rejects these packets
Match Count [AccessList_MatchCount]	<p>(Read-only) Displays the number of packets accepted or rejected by the rule.</p>

12.2 Configuring General Security Settings

The General Security Settings page is used to configure various security features. For a description of the parameters appearing on this page, refer 'Configuration Parameters Reference' on page 609.

➤ **To configure the general security parameters:**

1. Open the General Security Settings page (**Configuration** tab > **VoIP** menu > **Security** submenu > **General Security Settings**).

▼ IPsec Setting		
⚡ Enable IP Security	Disable	▼
IKE Certificate Ext Validate	Disable	▼
▼ TLS Settings		
TLS Version	SSL 2.0-3.0 and TLS 1.0	▼
Strict Certificate Extension Validation	Disable	▼
⚡ FIPS140 Mode	Disable	▼
Client Cipher String	ALL:!ADH	
▼ SIP TLS Settings		
TLS Client Re-Handshake Interval	0	
⚡ TLS Mutual Authentication	Disable	▼
Peer Host Name Verification Mode	Disable	▼
TLS Client Verify Server Certificate	Disable	▼
TLS Remote Subject Name		
▼ OCSP Settings		
Enable OCSP Server	Disable	▼
Primary Server IP	0.0.0.0	
Secondary Server IP	0.0.0.0	
Server Port	2560	
Default Response When Server Unreachable	Reject	▼

2. Configure the parameters as required.
3. Click **Submit** to apply your changes.
4. To save the changes to flash memory, refer to 'Saving Configuration' on page 494.

12.3 IPsec and Internet Key Exchange

IP security (IPsec) and Internet Key Exchange (IKE) protocols are part of the IETF standards for establishing a secured IP connection between two applications (also referred to as peers). Providing security services at the IP layer, IPsec and IKE are transparent to IP applications. IPsec and IKE are used together to provide security for control and management (e.g., SNMP and Web) protocols, but not for media (i.e., RTP, RTCP and T.38).

IKE is used to obtain the Security Associations (SA) between peers (the device and the application it's trying to contact). The SA contains the encryption keys and profile used by IPsec to encrypt the IP stream. IKE negotiation comprises the following two phases:

- **Main Mode** (creates a secured channel for the Quick mode by obtaining a "master" encryption key, without any prior keys, and authenticates the peers to each other):

- SA negotiation: The peers negotiate their capabilities using up to four proposals. Each proposal includes the Encryption method, Authentication algorithm, and the Diffie-Hellman (DH) group. The master key's lifetime is also negotiated.
- Key exchange (DH): The DH protocol creates the master key. DH requires both peers to agree on certain mathematical parameters, known as the "group".
- Authentication: The two peers authenticate one another using a pre-shared key configured in the IP Security Associations Table or by using certificate-based authentication.
- **Quick Mode** (creates the encrypted IPSec tunnel once initial security is set up):
 - SA negotiation: An IPSec SA is created by negotiating encryption and authentication capabilities using the same proposal mechanism as in Main mode.
 - Key exchange: A symmetrical key is created for encrypting IPSec traffic; the peers communicate with each other in encrypted form, secured by the previously negotiated "master" key.

IKE specifications summary:

- Authentication methods: pre-shared key or certificate-based authentication
- Main mode supported for IKE Phase 1
- DH group 1 or group 2
- Encryption algorithms: Data Encryption Standard (DES), Advanced Encryption Standard (AES), and 3DES
- Hash algorithms: SHA1 and MD5

IPSec is responsible for securing the IP traffic. This is accomplished by using the Encapsulation Security Payload (ESP) protocol to encrypt (and decrypt) the IP payload. This is configured in the IPSec Security Association table, which defines the IP peers to which IPSec security is applied.

IPSec specifications summary:

- Transport and Tunneling Mode
- Encapsulation Security Payload (ESP) only
- Encryption algorithms: AES, DES, and 3DES
- Hash types: SHA1 and MD5


12.3.1 Enabling IPSec

To enable IKE and IPSec processing, you must enable the IPSec feature, as described below.

➤ **To enable IPSec:**

1. Open the General Security Settings page (**Configuration** tab > **VoIP** menu > **Security** > **General Security Settings**).

Figure 12-2: Enabling IPSec



2. Set the 'Enable IP Security' parameter to **Enable**.
3. Click **Submit**, and then reset the device with a flash burn.

12.3.2 Configuring IP Security Proposal Table

The IP Security Proposal Table page is used to configure Internet Key Exchange (IKE) with up to four proposal settings. Each proposal defines an encryption algorithm, an authentication algorithm, and a Diffie-Hellman group identifier. The same set of proposals applies to both Main mode and Quick mode.



Note: You can also configure the IP Security Proposals table using the table ini file parameter IPsecProposalTable (see 'Security Parameters' on page 635).

➤ To configure IP Security Proposals:

1. Open the IP Security Proposal Table page (**Configuration** tab > **VoIP** menu > **Security** submenu > **IPSec Proposal Table**).
2. Click the **Add** button; the following dialog box appears:

Figure 12-3: IP Security Proposals Table - Add Record Dialog Box

3. Configure the parameters, as required. For a description of the parameters, see the table below.
4. Click **Submit**.
5. To save the changes to flash memory, see 'Saving Configuration' on page 494.

IP Security Proposals Table Configuration Parameters

Parameter Name	Description
Encryption Algorithm [IPsecProposalTable_EncryptionAlgorithm]	Defines the encryption (privacy) algorithm. <ul style="list-style-type: none"> ▪ [0] NONE ▪ [1] DES CBC ▪ [2] 3DES CBC ▪ [3] AES (default)
Authentication Algorithm [IPsecProposalTable_AuthenticationAlgorithm]	Defines the message authentication (integrity) algorithm. <ul style="list-style-type: none"> ▪ [0] NONE ▪ [2] HMAC SHA1 96 ▪ [4] HMAC MD5 96 (default)
Diffie Hellman Group [IPsecProposalTable_DHGroup]	Defines the length of the key created by the DH protocol for up to four proposals. For the <i>ini</i> file parameter, X denotes the proposal number (0 to 3). <ul style="list-style-type: none"> ▪ [0] Group 1 (768 Bits) = DH-786-Bit

Parameter Name	Description
	<ul style="list-style-type: none"> [1] Group 2 (1024 Bits) (default) = DH-1024-Bit

If no proposals are defined, the default settings (shown in the following table) are applied.

Default IPSec/IKE Proposals

Proposal	Encryption	Authentication	DH Group
Proposal 0	3DES	SHA1	Group 2 (1024 bit)
Proposal 1	3DES	MD5	Group 2 (1024 bit)
Proposal 2	3DES	SHA1	Group 1 (786 bit)
Proposal 3	3DES	MD5	Group 1 (786 bit)

12.3.3 Configuring IP Security Associations Table

The IP Security Associations Table page allows you to configure up to 20 peers (hosts or networks) for IP security (IPSec)/IKE. Each of the entries in this table controls both Main and Quick mode configuration for a single peer. Each row in the table refers to a different IP destination. IPSec can be applied to all traffic to and from a specific IP address. Alternatively, IPSec can be applied to a specific flow, specified by port (source or destination) and protocol type.

The destination IP address (and optionally, destination port, source port and protocol type) of each outgoing packet is compared to each entry in the table. If a match is found, the device checks if an SA already exists for this entry. If no SA exists, the IKE protocol is invoked and an IPSec SA is established and the packet is encrypted and transmitted. If a match is not found, the packet is transmitted without encryption.

This table can also be used to enable Dead Peer Detection (RFC 3706), whereby the device queries the liveliness of its IKE peer at regular intervals or on-demand. When two peers communicate with IKE and IPSec, the situation may arise in which connectivity between the two goes down unexpectedly. In such cases, there is often no way for IKE and IPSec to identify the loss of peer connectivity. As such, the Security Associations (SA) remain active until their lifetimes naturally expire, resulting in a "black hole" situation where both peers discard all incoming network traffic. This situation may be resolved by performing periodic message exchanges between the peers. When no reply is received, the sender assumes SA's are no longer valid on the remote peer and attempts to renegotiate.



Notes:

- Incoming packets whose parameters match one of the entries in the IP Security Associations table but is received without encryption, is rejected.
- If you change the device's IP address on-the-fly, you must then reset the device for IPSec to function properly.
- The proposal list must be contiguous.
- For security, once the IKE pre-shared key is configured, it is not displayed in any of the device's management tools.
- You can also configure the IP Security Associations table using the table ini file parameter IPsecSATable (see 'Security Parameters' on page 635).

➤ **To configure the IPsec Association table:**

1. Open the IP Security Associations Table page (**Configuration** tab > **VoIP** menu > **Security** submenu > **IPsec Association Table**).
2. Click the **Add** button; the following dialog box appears:

Figure 12-4: IP Security Associations Table Page - Add Record Dialog Box

3. Configure the parameters, as required. In the above figure, a single IPsec/IKE peer (10.3.2.73) is configured. Pre-shared key authentication is selected with the pre-shared key set to 123456789. In addition, a lifetime of 28800 seconds is set for IKE and a lifetime of 3600 seconds is set for IPsec. For a description of the parameters, see the table below.
4. Click **Submit**.
5. To save the changes to flash memory, see 'Saving Configuration' on page 494.

IP Security Associations Table Configuration Parameters

Parameter Name	Description
Operational Mode [IPsecSatable_IPsecMode]	Defines the IPsec mode of operation. <ul style="list-style-type: none"> ▪ [0] Transport (default) ▪ [1] Tunnel
Remote Endpoint Addr [IPsecSatable_RemoteEndpointAddressOrName]	Defines the IP address or DNS host name of the peer. Note: This parameter is applicable only if the Operational Mode is set to Transport.
Authentication Method [IPsecSatable_AuthenticationMethod]	Defines the method for peer authentication during IKE main mode. <ul style="list-style-type: none"> ▪ [0] Pre-shared Key (default) ▪ [1] RSA Signature = in X.509 certificate Note: For RSA-based authentication, both peers must be provisioned with certificates signed by a common CA. For more information on

Parameter Name	Description
	certificates, see 'Replacing the Device's Certificate' on page 99.
Shared Key [IPsecSatable_SharedKey]	<p>Defines the pre-shared key (in textual format). Both peers must use the same pre-shared key for the authentication process to succeed.</p> <p>Notes:</p> <ul style="list-style-type: none"> This parameter is applicable only if the Authentication Method parameter is set to pre-shared key. The pre-shared key forms the basis of IPSec security and therefore, it should be handled with care (the same as sensitive passwords). It is not recommended to use the same pre-shared key for several connections. Since the <i>ini</i> file is plain text, loading it to the device over a secure network connection is recommended. Use a secure transport such as HTTPS, or a direct crossed-cable connection from a management PC. After it is configured, the value of the pre-shared key cannot be retrieved.
Source Port [IPsecSatable_SourcePort]	<p>Defines the source port to which this configuration applies. The default is 0 (i.e., any port).</p>
Destination Port [IPsecSatable_DestPort]	<p>Defines the destination port to which this configuration applies. The default is 0 (i.e., any port).</p>
Protocol [IPsecSatable_Protocol]	<p>Defines the protocol type to which this configuration applies. Standard IP protocol numbers, as defined by the Internet Assigned Numbers Authority (IANA) should be used, for example:</p> <ul style="list-style-type: none"> 0 = Any protocol (default) 17 = UDP 6 = TCP
IKE SA Lifetime [IPsecSatable_Phase1SaLifetimeInSec]	<p>Defines the duration (in seconds) for which the negotiated IKE SA (Main mode) is valid. After this time expires, the SA is re-negotiated. The default is 0 (i.e., unlimited).</p> <p>Note: Main mode negotiation is a processor-intensive operation; for best performance, do not set this parameter to less than 28,800 (i.e., eight hours).</p>
IPSec SA Lifetime (sec) [IPsecSatable_Phase2SaLifetimeInSec]	<p>Defines the duration (in seconds) for which the negotiated IPSec SA (Quick mode) is valid. After this time expires, the SA is re-negotiated. The default is 0 (i.e., unlimited).</p> <p>Note: For best performance, a value of 3,600 (i.e., one hour) or more is recommended.</p>
IPSec SA Lifetime (Kbs) [IPsecSatable_Phase2SaLifetimeInKB]	<p>Defines the maximum volume of traffic (in kilobytes) for which the negotiated IPSec SA (Quick mode) is valid. After this specified volume is reached, the SA is re-negotiated. The default is 0 (i.e., the value is ignored).</p>
Dead Peer Detection Mode [IPsecSatable_DPDmode]	<p>Defines dead peer detection (DPD), according to RFC 3706.</p> <ul style="list-style-type: none"> [0] DPD Disabled (default) [1] DPD Periodic = DPD is enabled with message exchanges at regular intervals [2] DPD on demand = DPD is enabled with on-demand checks - message exchanges as needed (i.e., before sending data to the peer). If the liveliness of the peer is questionable, the device sends

Parameter Name	Description
	a DPD message to query the status of the peer. If the device has no traffic to send, it never sends a DPD message.
Remote Tunnel Addr [IPsecSatable_RemoteTunnelAddress]	Defines the IP address of the peer router. Note: This parameter is applicable only if the Operational Mode is set to Tunnel.
Remote Subnet Addr [IPsecSatable_RemoteSubnetIPAddress]	Defines the IP address of the remote subnet. Together with the Prefix Length parameter (below), this parameter defines the network with which the IPsec tunnel allows communication. Note: This parameter is applicable only if the Operational Mode is set to Tunnel.
Remote Prefix Length [IPsecSatable_RemoteSubnetPrefixLength]	Defines the prefix length of the Remote Subnet IP Address parameter (in bits). The prefix length defines the subnet class of the remote network. A prefix length of 16 corresponds to a Class B subnet (255.255.0.0); a prefix length of 24 corresponds to a Class C subnet (255.255.255.0). Note: This parameter is applicable only if the Operational Mode is set to Tunnel.
Interface Name [IPsecSatable_InterfaceName]	Assigns a network interface to this IPsec rule. The network interfaces are defined in the Multiple Interface table ('Interface Name' column) in 'Configuring IP Network Interfaces' on page 110

12.4 Intrusion Detection System

The device can be configured to detect malicious attacks on its system and send SNMP traps if malicious activity is identified. The Intrusion Detection System (IDS) is an important feature for Enterprises to ensure legitimate calls are not being adversely affected by attacks and to prevent Theft of Service and unauthorized access. If, for example, you identify the source (IP address) of the attack, you can add that source to your blacklist to prevent it from accessing your device.

There are many types of malicious attacks, the most common being:

- **Denial of service:** This can be Denial of Service (DoS) where an attacker wishing to prevent a server from functioning correctly directs a large amount of requests – sometimes meaningless and sometimes legitimate, or it can be Distributed Denial of Service (DDoS) where the attacker controls a large group of systems to coordinate a large scale DoS attack against a system:
 - Message payload tampering: Attacker may inject harmful content into a message, e.g., by entering meaningless or wrong information, with the goal of exploiting a buffer overflow at the target. Such messages can be used to probe for vulnerabilities at the target.
 - Message flow tampering: This is a special case of DoS attacks. These attacks disturb the ongoing communication between users. An attacker can then target the connection by injecting fake signaling messages into the communication channel (such as CANCEL messages).
 - Message Flooding: The most common DoS attack is where an attacker sends a huge amount of messages (e.g., INVITEs) to a target. The goal is to overwhelm the target's processing capabilities, thereby rendering the target inoperable.
- **SPAM over Internet Telephony (SPIT):** VoIP spam is unwanted, automatically dialed, pre-recorded phone calls using VoIP. It is similar to e-mail spam.
- **Theft of Service (ToS):** Service theft can be exemplified by phreaking, which is a type of hacking that steals service (i.e., free calls) from a service provider, or uses a service while passing the cost to another person.

The IDS configuration is based on IDS Policies, where each policy can be configured with a set of IDS rules. Each rule defines a type of malicious attack to detect and the number of attacks during an interval (threshold) before an SNMP trap is sent. Each policy is then applied to a target under attack (SIP interface) and/or source of attack (Proxy Set and/or subnet address).


12.4.1 Enabling IDS

The procedure below describes how to enable IDS.

➤ **To enable IDS:**

1. Open the IDS Global Parameters page (**Configuration** tab > **VoIP** menu > **Security** > **Intrusion Detection and Prevention** > **Global Parameters**).

Figure 12-5: Enabling IDS on IDS Global Parameters Page



2. From the 'Intrusion Detection System' drop-down list, select **Enable**.
3. Reset the device with a burn-to-flash for the setting to take effect (see Saving Configuration).

12.4.2 Configuring IDS Policies

Configuring IDS policies is a two-stage process done in the following tables:

1. **IDS Policy table:** Defines a name and description for the policy. You can define up to 20 policies.
2. **IDS Rules table:** Defines the actual IDS rules per policy. Each policy can be configured with up to 20 rules.



Note: A maximum of 100 IDS rules can be configured (regardless of how many rules are assigned to each policy).

By default and for your convenience, the device provides three pre-configured IDS policies with rules that can be used in your deployment if they meet your requirements:

- "DEFAULT_FEU": Policy for far-end users in the WAN
- "DEFAULT_PROXY": Policy for proxy server
- "DEFAULT_GLOBAL": Policy with global thresholds

These default policies are read-only.

➤ **To configure IDS policies:**

1. Open the IDS Policy Table page (**Configuration** tab > **VoIP** menu > **Security** > **Intrusion Detection and Prevention** > **Policy Table**).

Figure 12-6: IDS Policy Table with Default Rules

Index	Name	Description
0	DEFAULT_FEU	Default policy for FEU
1	DEFAULT_PROXY	Default policy for proxies
2	DEFAULT_GLOBAL	Default policy for global scope

Page 1 of 1 Show 10 records per page View 1 - 3 of 3

IDS Policy Table #0 Additional Configuration
[IDS Rule Table](#)

2. Add a Policy name:
 - a. Click **Add**.

Figure 12-7: IDS Policy Table - Add Record

Add Record	
Index	<input type="text" value="3"/>
Name	<input type="text" value="SIP-Trunk"/>
Description	<input type="text" value="for attacks from SIP Trunk"/>
<input type="button" value="Submit"/> <input type="button" value="Cancel"/>	

- b. Configure the parameters as described in the following table, and then click **Submit**.

Table 12-1: IDS Policy Table Parameters

Parameter	Description
Index CLI: policy [IDSPolicy_Index]	Defines the table row number for the policy.
Name CLI: rule [IDSPolicy_Description]	Defines a name for the policy. The valid value is a string of up to 20 characters.
Description [IDSPolicy_Name]	Defines an arbitrary description of the policy. The valid value is a string of up to 100 characters.

3. Add rules to the policy:
 - a. In the IDS Policy table, select the required policy and then click the **IDS Rule Table** link located below the table:

Figure 12-8: IDS Rule Table of Selected IDS Policy

Index	Reason	Threshold Scope	Threshold Window	Minor Alarm Threshold	Major Alarm Threshold	Critical Alarm Threshold
0	Connection abuse	IP	30	5	0	0
1	Malformed message	IP	30	15	0	0
2	Authentication failure	IP	600	20	0	0
3	Dialog establish failure	IP	300	30	0	0
4	Abnormal flow	IP	30	15	0	0

Selected Row #0

Reason:	Connection abuse	Minor-Alarm Threshold:	5
Threshold Scope:	IP	Major-Alarm Threshold:	0
Threshold Window:	30	Critical-Alarm Threshold:	0

- b. Click **Add**.

Figure 12-9: IDS Rule Table - Add Record

Index	0
Reason	Malformed message
Threshold Scope	IP
Threshold Window	30
Minor-Alarm Threshold	15
Major-Alarm Threshold	20
Critical-Alarm Threshold	25

Submit Cancel

- c. Configure the parameters as required, and then click **Submit**. For a description of these parameters, see the table below. The figure above shows an example configuration where if 15 malformed SIP messages are received within a period of 30 seconds, a minor alarm is sent. Every 30 seconds, the rule's counters are cleared.
 - d. To add more rules to the policy, repeat steps 1.b to 1.c.

Table 12-2: IDS Rule Table Parameters

Parameter	Description
Index CLI: rule-id [IDSRule_RuleID]	Defines the table row number for the rule.
Reason CLI: reason [IDSRule_Reason]	Defines the type of intrusion attack (malicious event). <ul style="list-style-type: none"> ▪ [0] Any = All events listed below are considered as attacks and are counted together. ▪ [1] Connection abuse (default) = TLS authentication failure. ▪ [2] Malformed message = <ul style="list-style-type: none"> ✓ Message exceeds a user-defined maximum message length (50K) ✓ Any SIP parser error ✓ Message Policy match (see Configuring SIP Message Policy Rules) ✓ Basic headers not present ✓ Content length header not present (for TCP) ✓ Header overflow ▪ [3] Authentication failure = <ul style="list-style-type: none"> ✓ Local authentication ("Bad digest" errors) ✓ Remote authentication (SIP 401/407 is sent if original message includes authentication) ▪ [4] Dialog establish failure = <ul style="list-style-type: none"> ✓ Classification failure (see Configuring Classification Rules) ✓ Routing failure ✓ Other local rejects (prior to SIP 180 response) ✓ Remote rejects (prior to SIP 180 response) ▪ [5] Abnormal flow = <ul style="list-style-type: none"> ✓ Requests and responses without a matching transaction user (except ACK requests) ✓ Requests and responses without a matching transaction (except ACK requests)
Threshold Scope CLI: threshold-scope [IDSRule_ThresholdScope]	Defines the source of the attacker to consider in the device's detection count. <ul style="list-style-type: none"> ▪ [0] Global = All attacks regardless of source are counted together during the threshold window. ▪ [2] IP = Attacks from each specific IP address are counted separately during the threshold window. ▪ [3] IP+Port = Attacks from each specific IP address:port are counted separately during the threshold window. This option is useful for NAT servers, where numerous remote machines use the same IP address but different ports. However, it is not recommended to use this option as it may degrade detection capabilities.
Threshold Window CLI: threshold-window [IDSRule_ThresholdWindow]	Defines the threshold interval (in seconds) during which the device counts the attacks to check if a threshold is crossed. The counter is automatically reset at the end of the interval. The valid range is 1 to 1,000,000. The default is 1.

Parameter	Description
Minor-Alarm Threshold CLI: minor-alm-thr [IDSRule_MinorAlarmThreshold]	Defines the threshold that if crossed a minor severity alarm is sent. The valid range is 1 to 1,000,000. A value of 0 or -1 means not defined.
Major-Alarm Threshold CLI: major-alm-thr [IDSRule_MajorAlarmThreshold]	Defines the threshold that if crossed a major severity alarm is sent. The valid range is 1 to 1,000,000. A value of 0 or -1 means not defined.
Critical-Alarm Threshold CLI: critical-alm-thr [IDSRule_CriticalAlarmThreshold]	Defines the threshold that if crossed a critical severity alarm is sent. The valid range is 1 to 1,000,000. A value of 0 or -1 means not defined.

12.4.3 Assigning IDS Policies

The IDS Match table enables you to use your configured IDS policies. This is done by assigning them to any or a combination of the following entities:


- **SIP Interface:** Detects malicious attacks (according to specified IDS Policy) on specific SIP Interface(s)
- **Proxy Sets:** Detects malicious attacks (according to specified IDS Policy) from specified Proxy Set(s)
- **Subnet addresses:** Detects malicious attacks (according to specified IDS Policy) from specified subnet address

Up to 20 IDS policy-matching rules can be configured.

➤ **To assign an IDS policy:**

1. Open the IDS Match Table page (**Configuration** tab > **VoIP** menu > **Security** > **Intrusion Detection and Prevention** > **Match Table**).
2. Click **Add**.

Figure 12-10: IDS Match Table - Add Record



The figure above shows a configuration example where the IDS Policy, "SIP Trunk" is applied to SIP Interfaces 1 and 2, and all source IP addresses outside of subnet 10.1.0.0/16 and IP address 10.2.2.2.

3. Configure the IDS matching parameters. For a description of these parameters, see the following table.
4. Click **Submit**.

Table 12-3: IDS Match Table Parameters

Parameter	Description
Index [IDSMATCH_Index]	Defines the table row number for the rule.
SIP Interface CLI: sip-interface [IDSMATCH_SIPInterface]	<p>Defines the SIP Interface(s) to which you want to assign the IDS policy. This indicates the SIP Interfaces that are being attacked. The entered value must be the ID of the SIP Interface. The following syntax is supported:</p> <ul style="list-style-type: none"> ▪ A comma-separated list of SIP Interface IDs (e.g., 1,3,4) ▪ A hyphen "-" indicates a range of SIP Interfaces (e.g., 3,4-7 means IDs 3, and 4 through 7) ▪ A prefix of an exclamation mark "!" means negation of the set (e.g., !3,4-7 means all indexes excluding 3, and excluding 4 through 7)
ProxySet CLI: proxy-set [IDSMATCH_ProxySet]	<p>Defines the Proxy Set(s) to which the IDS policy is assigned. This indicates the Proxy Sets from where the attacks are coming from. The following syntax is supported:</p> <ul style="list-style-type: none"> ▪ A comma-separated list of Proxy Set IDs (e.g., 1,3,4) ▪ A hyphen "-" indicates a range of Proxy Sets (e.g., 3,4-7 means IDs 3, and 4 through 7) ▪ A prefix of an exclamation mark "!" means negation of the set (e.g., !3,4-7 means all indexes excluding 3, and excluding 4 through 7) <p>Notes:</p> <ul style="list-style-type: none"> ▪ Only the IP address of the Proxy Set is considered (not the port). ▪ If a Proxy Set has multiple IP addresses, the device considers the Proxy Set as one entity and includes all its IP addresses in the same IDS count.
Subnet CLI: subnet [IDSMATCH_Subnet]	<p>Defines the subnet(s) to which the IDS policy is assigned. This indicates the subnets from where the attacks are coming from. The following syntax can be used:</p> <ul style="list-style-type: none"> ▪ Basic syntax is a subnet in CIDR notation (e.g., 10.1.0.0/16 means all sources with IP address in the range 10.1.0.0–10.1.255.255) ▪ An IP address can be specified without the prefix length to refer to the specific IP address. ▪ Each subnet can be negated by prefixing it with "!", which means all IP addresses outside that subnet. ▪ Multiple subnets can be specified by separating them with "&" (and) or " " (or) operations. For example: <ul style="list-style-type: none"> ✓ 10.1.0.0/16 10.2.2.2: includes subnet 10.1.0.0/16 and IP address 10.2.2.2. ✓ !10.1.0.0/16 & !10.2.2.2: includes all addresses except those of subnet 10.1.0.0/16 and IP address 10.2.2.2. Note that the exclamation mark "!" appears before each subnet. ✓ 10.1.0.0/16 & !10.1.1.1: includes subnet 10.1.0.0/16, except IP address 10.1.1.1.
Policy CLI: policy [IDSMATCH_Policy]	Selects the IDS policy, configured in 'Configuring IDS Policies' on page 149.

12.4.4 Viewing IDS Alarms

The device uses SNMP (and Syslog) to notify the detection of malicious attacks. The trap displays the IDS Policy and Rule, and the Policy-Match index.

The device sends the SNMP alarm, acIDSPolicyAlarm whenever a threshold of a specific IDS Policy rule is crossed. For each scope that crosses this threshold, the device sends an additional SNMP event (trap) - acIDSThresholdCrossNotification - indicating the specific details (IP address or IP address:port). If the trap severity level is raised, the alarm of the former severity is cleared and the device then sends a new alarm with the new severity.

The SNMP alarm is cleared after a user-defined period (configured by the ini file parameter, IDSAAlarmClearPeriod) during which no thresholds have been crossed. However, this "quiet" period must be at least twice the Threshold Window value (configured in 'Configuring IDS Policies' on page 149). For example, if IDSAAlarmClearPeriod is set to 20 sec and the Threshold Window is set to 15 sec, the IDSAAlarmClearPeriod parameter is ignored and the alarm is cleared only after 30 seconds (2 x 15 sec).

The figure below shows an example of IDS alarms in the Active Alarms table (Viewing Active Alarms), where a minor threshold alarm is cleared and replaced by a major threshold alarm:

Figure 12-11: IDS Alarms in Active Alarms Table

17	Minor	Board#1/IDSMATCH#2/IDSRULE#0	Policy 2 (Proxy): minor threshold (5) of signaling-msg cross in ip scope	24.10.2012, 9:48:53
18	cleared	Board#1/IDSMATCH#2/IDSRULE#0	Alarm cleared: Policy 2 (Proxy): minor threshold (5) of signaling-msg cross in ip scope	24.10.2012, 9:48:53
19	Major	Board#1/IDSMATCH#2/IDSRULE#0	Policy 2 (Proxy): major threshold (10) of signaling-msg cross in ip scope	24.10.2012, 9:48:53

You can also view the IDS alarms in the CLI:

- To view active IDS alarms:

```
show voip security ids active-alarm all
```
- To view all IP addresses that crossed the threshold for an active IDS alarm:

```
show voip security ids active-alarm match * rule *
```

The device also sends IDS notifications in Syslog messages to a Syslog server (if enabled - see Configuring Syslog). The table below shows the Syslog text message per malicious event:

Table 12-4: Types of Malicious Events and Syslog Text String

Type	Description	Syslog String
Connection Abuse	TLS authentication failure	abuse-tls-auth-fail
Malformed Messages	<ul style="list-style-type: none"> ▪ Message exceeds a user-defined maximum message length (50K) ▪ Any SIP parser error ▪ Message policy match ▪ Basic headers not present ▪ Content length header not present (for TCP) ▪ Header overflow 	<ul style="list-style-type: none"> ▪ malformed-invalid-msg-len ▪ malformed-parse-error ▪ malformed-message-policy ▪ malformed-miss-header ▪ malformed-miss-content-len ▪ malformed-header-overflow
Authentication Failure	<ul style="list-style-type: none"> ▪ Local authentication ("Bad digest" errors) ▪ Remote authentication (SIP 401/407 is sent if original message includes authentication) 	<ul style="list-style-type: none"> ▪ auth-establish-fail ▪ auth-reject-response

Type	Description	Syslog String
Dialog Establishment Failure	<ul style="list-style-type: none">▪ Classification failure▪ Routing failure▪ Other local rejects (prior to SIP 180 response)▪ Remote rejects (prior to SIP 180 response)	<ul style="list-style-type: none">▪ establish-classify-fail▪ establish-route-fail▪ establish-local-reject▪ establish-remote-reject
Abnormal Flow	<ul style="list-style-type: none">▪ Requests and responses without a matching transaction user (except ACK requests)▪ Requests and responses without a matching transaction (except ACK requests)	<ul style="list-style-type: none">▪ flow-no-match-tu▪ flow-no-match-transaction

Reader's Notes

13 Media

This section describes the media-related configuration.

13.1 Configuring Voice Settings

The Voice Settings page configures various voice parameters such as voice volume, silence suppression, and DTMF transport type. For a detailed description of these parameters, see 'Configuration Parameters Reference' on page 609.

➤ **To configure the voice parameters:**

1. Open the Voice Settings page (**Configuration** tab > **VoIP** menu > **Media** submenu > **Voice Settings**).

Voice Volume (-32 to 31 dB)	<input type="text" value="0"/>
Input Gain (-32 to 31 dB)	<input type="text" value="0"/>
Silence Suppression	Disable ▼
DTMF Transport Type	RFC2833 Relay DTMF ▼
DTMF Volume (-31 to 0 dB)	<input type="text" value="-11"/>
NTE Max Duration	<input type="text" value="-1"/>
CAS Transport Type	CASEventsOnly ▼
⚡ DTMF Generation Twist	<input type="text" value="0"/>
Echo Canceller	Enable ▼

2. Configure the Voice parameters as required.
3. Click **Submit** to apply your changes.
4. To save the changes to flash memory, see 'Saving Configuration' on page 494.

13.1.1 Configuring Voice Gain (Volume) Control

The device allows you to configure the level of the received (input gain) Tel-to-IP signal and the level of the transmitted (output gain) IP-to-Tel signal. The gain can be set between -32 and 31 decibels (dB).

The procedure below describes how to configure gain control using the Web interface:

➤ **To configure gain control using the Web interface:**

1. Open the Voice Settings page (**Configuration** tab > **VoIP** menu > **Media** submenu > **Voice Settings**).

Figure 13-1: Voice Volume Parameters in Voice Settings Page

Voice Volume (-32 to 31 dB)	<input type="text" value="0"/>
Input Gain (-32 to 31 dB)	<input type="text" value="0"/>

2. Configure the following parameters:
 - 'Voice Volume' (*VoiceVolume*) - Defines the voice gain control (in decibels) for IP-to-Tel

- 'Input Gain' (*InputGain*) - Defines the PCM input gain control (in decibels) for Tel-to-IP
3. Click **Submit** to apply your settings.

13.1.2 Silence Suppression (Compression)

Silence suppression (compression) is a method for conserving bandwidth on VoIP calls by not sending packets when silence is detected. The device uses its VAD feature to detect periods of silence in the voice channel during an established call. When silence is detected, it stops sending packets in the channel.

The procedure below describes how to enable silence suppression using the Web interface.

➤ **To enable silence suppression using the Web interface:**

1. Open the Voice Settings page (**Configuration** tab > **VoIP** menu > **Media** submenu > **Voice Settings**).

Figure 13-2: Enabling Silence Suppression in Voice Settings Page



2. Set the 'Silence Suppression' (*EnableSilenceCompression*) field to **Enable**.
3. Click **Submit** to apply your changes.

13.1.3 Echo Cancellation

The device supports adaptive linear (line) echo cancellation according to G.168-2002. Echo cancellation is a mechanism that removes echo from the voice channel. Echoes are reflections of the transmitted signal.

In this line echo, echoes are generated when two-wire telephone circuits (carrying both transmitted and received signals on the same wire pair) are converted to a four-wire circuit. Echoes are reflections of the transmitted signal, which result from impedance mismatch in the hybrid (bi-directional 2-wire to 4-wire converting device).


An estimated echo signal is built by feeding the decoder output signal to an RLS-like adaptive filter, which adapts itself to the characteristics of the echo path. The 'estimated echo signal' (the output of this filter) is then subtracted from the input signal (which is the sum of the desired input signal and the undesired echo) to provide a clean signal. To suppress the remaining residual echo, a Non Linear Processor (NLP) is used, as well as a double-talk (two people speak at the same time) detector that prevents false adaptation during near-end speech.

The procedure below describes how to configure echo cancellation using the Web interface:

➤ **To configure echo cancellation using the Web interface:**

1. Configure line echo cancellation:
 - a. Open the Voice Settings page (**Configuration** tab > **VoIP** menu > **Media** submenu > **Voice Settings**).

Figure 13-3: Enabling Echo Cancellation in Voice Settings Page



- b. Set the 'Echo Canceller' field (*EnableEchoCanceller*) to **Enable**.
 - c. Open the General Media Settings page (Configuration tab > VoIP menu > Media submenu > General Media Settings).

- d. From the 'Max Echo Canceller Length' drop-down list (MaxEchoCancellerLength), select the maximum echo path delay (tail length) for the echo canceller.



Note: The following additional echo cancellation parameters are configurable only through the *ini* file:

- *ECHybridLoss* - defines the four-wire to two-wire worst-case Hybrid loss
- *ECNLPMode* - defines the echo cancellation Non-Linear Processing (NLP) mode
- *EchoCancellerAggressiveNLP* - enables Aggressive NLP at the first 0.5 second of the call

13.2 Fax and Modem Capabilities

This section describes the device's fax and modem capabilities and corresponding configuration. The fax and modem configuration is done in the Fax/Modem/CID Settings page.



Notes:

- Unless otherwise specified, the configuration parameters mentioned in this section are available on this page.
- Some SIP parameters override these fax and modem parameters. For example, the IsFaxUsed parameter and V.152 parameters in Section 'V.152 Support' on page 168).
- For a detailed description of the parameters appearing on this page, see 'Configuration Parameters Reference' on page 609.

➤ **To access the fax and modem parameters:**

1. Open the Fax/Modem/CID Settings page (**Configuration** tab > **VoIP** menu > **Media** submenu > **Fax/Modem/CID Settings**).

Figure 13-4: Fax/Modem/CID Settings Page

General Settings	
Fax Transport Mode	RelayEnable
Caller ID Transport Type	Mute
Caller ID Type	Standard Bellcore
V.21 Modem Transport Type	Disable
V.22 Modem Transport Type	Enable Bypass
V.23 Modem Transport Type	Enable Bypass
V.32 Modem Transport Type	Enable Bypass
V.34 Modem Transport Type	Enable Bypass
Fax CNG Mode	Disable
CNG Detector Mode	Disable
Fax Relay Settings	
Fax Relay Redundancy Depth	0
Fax Relay Enhanced Redundancy Depth	4
Fax Relay ECM Enable	Enable
Fax Relay Max Rate (bps)	33600bps
Bypass Settings	
Fax/Modem Bypass Coder Type	G711Alaw_64
Fax/Modem Bypass Packing Factor	1
Fax Bypass Output Gain	0
Modem Bypass Output Gain	0

2. Configure the parameters, as required.
3. Click **Submit** to apply your changes.

13.2.1 Fax/Modem Operating Modes

The device supports two modes of operation:

- Fax/modem negotiation that is not performed during the establishment of the call.
- Voice-band data (VBD) mode for V.152 implementation (see 'V.152 Support' on page 168): fax/modem capabilities are negotiated between the device and the remote endpoint at the establishment of the call. During a call, when a fax/modem signal is detected, transition from voice to VBD (or T.38) is automatically performed and no additional SIP signaling is required. If negotiation fails (i.e., no match is achieved for any of the transport capabilities), fallback to existing logic occurs (according to the parameter `IsFaxUsed`).

13.2.2 Fax/Modem Transport Modes

The device supports the following transport modes for fax per modem type (V.22/V.23/Bell/V.32/V.34):

- T.38 fax relay (see 'T.38 Fax Relay Mode' on page 160)
- G.711 Transport: switching to G.711 when fax/modem is detected (see 'G.711 Fax / Modem Transport Mode' on page 162)
- Fax fallback to G.711 if T.38 is not supported (see 'Fax Fallback' on page 162)
- Fax and modem bypass: a proprietary method that uses a high bit rate coder (see 'Fax/Modem Bypass Mode' on page 163)
- NSE Cisco's Pass-through bypass mode for fax and modem (see 'Fax / Modem NSE Mode' on page 164)
- Transparent with events: passing the fax / modem signal in the current voice coder with adaptations (see 'Fax / Modem Transparent with Events Mode' on page 165)
- Transparent: passing the fax / modem signal in the current voice coder (see 'Fax / Modem Transparent Mode' on page 165)
- RFC 2833 ANS Report upon Fax/Modem Detection (see 'RFC 2833 ANS Report upon Fax/Modem Detection' on page 166)

'Adaptations' refer to automatic reconfiguration of certain DSP features for handling fax/modem streams differently than voice.

13.2.2.1 T.38 Fax Relay Mode

In Fax Relay mode, fax signals are transferred using the T.38 protocol. T.38 is an ITU standard for sending fax across IP networks in real-time mode. The device currently supports only the T.38 UDP syntax.

T.38 can be configured in the following ways:

- Switching to T.38 mode using SIP Re-INVITE messages (see 'Switching to T.38 Mode using SIP Re-INVITE' on page 161)
- Automatically switching to T.38 mode without using SIP Re-INVITE messages (see 'Automatically Switching to T.38 Mode without SIP Re-INVITE' on page 161)

When fax transmission ends, the reverse switching from fax relay to voice is automatically performed at both the local and remote endpoints.

You can change the fax rate declared in the SDP, using the 'Fax Relay Max Rate' parameter (`FaxRelayMaxRate`). This parameter does not affect the actual transmission rate. You can also enable or disable Error Correction Mode (ECM) fax mode using the 'Fax Relay ECM Enable' parameter (`FaxRelayECMEnable`).

When using T.38 mode, you can define a redundancy feature to improve fax transmission over congested IP networks. This feature is activated using the 'Fax Relay Redundancy Depth' parameter (FaxRelayRedundancyDepth) and the 'Fax Relay Enhanced Redundancy Depth' parameter (FaxRelayEnhancedRedundancyDepth). Although this is a proprietary redundancy scheme, it should not create problems when working with other T.38 decoders.

13.2.2.1.1 Switching to T.38 Mode using SIP Re-INVITE

In the Switching to T.38 Mode using SIP Re-INVITE mode, upon detection of a fax signal the terminating device negotiates T.38 capabilities using a Re-INVITE message. If the far-end device doesn't support T.38, the fax fails. In this mode, the 'Fax Transport Mode' parameter (FaxTransportMode) is ignored.

➤ **To configure T.38 mode using SIP Re-INVITE messages:**

1. In the SIP General Parameters page (**Configuration** tab > **VoIP** menu > **SIP Definitions** > **General Parameters**), set the 'Fax Signaling Method' parameter to **T.38 Relay** (IsFaxUsed = 1).
2. In the Fax/Modem/CID Settings page, configure the following optional parameters:
 - 'Fax Relay Redundancy Depth' (FaxRelayRedundancyDepth)
 - 'Fax Relay Enhanced Redundancy Depth' (FaxRelayEnhancedRedundancyDepth)
 - 'Fax Relay ECM Enable' (FaxRelayECMEnable)
 - 'Fax Relay Max Rate' (FaxRelayMaxRate)



Note: The terminating gateway sends T.38 packets immediately after the T.38 capabilities are negotiated in SIP. However, the originating device by default, sends T.38 (assuming the T.38 capabilities are negotiated in SIP) only after it receives T.38 packets from the remote device. This default behavior cannot be used when the originating device is located behind a firewall that blocks incoming T.38 packets on ports that have not yet received T.38 packets from the internal network. To resolve this problem, the device should be configured to send CNG packets in T.38 upon CNG signal detection (CNGDetectorMode = 1).

13.2.2.1.2 Automatically Switching to T.38 Mode without SIP Re-INVITE

In the Automatically Switching to T.38 Mode without SIP Re-INVITE mode, when a fax signal is detected, the channel automatically switches from the current voice coder to answer tone mode and then to T.38-compliant fax relay mode.

➤ **To configure automatic T.38 mode:**

1. In the SIP General Parameters page (**Configuration** tab > **VoIP** menu > **SIP Definitions** > **General Parameters**), set the 'Fax Signaling Method' parameter to **No Fax** (IsFaxUsed = 0).
2. In the Fax/Modem/CID Settings page, set the 'Fax Transport Mode' parameter to **RelayEnable** (FaxTransportMode = 1).
3. Configure the following optional parameters:
 - 'Fax Relay Redundancy Depth' (FaxRelayRedundancyDepth)
 - 'Fax Relay Enhanced Redundancy Depth' (FaxRelayEnhancedRedundancyDepth)

- 'Fax Relay ECM Enable' (FaxRelayECMEnable)
- 'Fax Relay Max Rate' (FaxRelayMaxRate)

13.2.2.2 G.711 Fax / Modem Transport Mode

In this mode, when the terminating device detects fax or modem signals (CED or AnsAM), it sends a Re-INVITE message to the originating device, requesting it to re-open the channel in G.711 VBD with the following adaptations:

- Echo Canceller = off
- Silence Compression = off
- Echo Canceller Non-Linear Processor Mode = off
- Dynamic Jitter Buffer Minimum Delay = 40
- Dynamic Jitter Buffer Optimization Factor = 13

After a few seconds upon detection of fax V.21 preamble or super G3 fax signals, the device sends a second Re-INVITE enabling the echo canceller (the echo canceller is disabled only on modem transmission).

A 'gpmd' attribute is added to the SDP according to the following format:

- **For G.711 A-law:**

```
a=gpmd:0 vbd=yes;ecan=on (or off for modems)
```

- **For G.711 μ -law:**

```
a=gpmd:8 vbd=yes;ecan=on (or off for modems)
```

The following parameters are ignored and automatically set to **Events Only**:

- 'Fax Transport Mode' (FaxTransportMode)
- 'Vxx ModemTransportType' (VxxModemTransportType)

➤ To configure fax / modem transparent mode:

- In the SIP General Parameters page (**Configuration** tab > **VoIP** menu > **SIP Definitions** > **General Parameters**), set the 'Fax Signaling Method' parameter to **G.711 Transport** (IsFaxUsed = 2).

13.2.2.3 Fax Fallback

In this mode, when the terminating device detects a fax signal, it sends a Re-INVITE message to the originating device with T.38. If the remote device doesn't support T.38 (replies with SIP response 415 "Media Not Supported"), the device sends a new Re-INVITE with G.711 VBD with the following adaptations:

- Echo Canceller = on
- Silence Compression = off
- Echo Canceller Non-Linear Processor Mode = off
- Dynamic Jitter Buffer Minimum Delay = 40
- Dynamic Jitter Buffer Optimization Factor = 13

When the device initiates a fax session using G.711, a 'gpmd' attribute is added to the SDP according to the following format:

- **For G.711A-law:**

```
a=gpmd:0 vbd=yes;ecan=on
```

- **For G.711 μ -law:**

```
a=gpmd:8 vbd=yes;ecan=on
```

In this mode, the 'Fax Transport Mode' (FaxTransportMode) parameter is ignored and automatically set to **Disable** (transparent mode).

➤ **To configure fax fallback mode:**

- In the SIP General Parameters page (**Configuration** tab > **VoIP** menu > **SIP Definitions > General Parameters**), set the 'Fax Signaling Method' parameter to **Fax Fallback** (IsFaxUsed = 3).

13.2.2.4 Fax/Modem Bypass Mode

In this proprietary mode, when fax or modem signals are detected, the channel automatically switches from the current voice coder to a high bit-rate coder, according to the 'Fax/Modem Bypass Coder Type' parameter (FaxModemBypassCoderType). The channel is also automatically reconfigured with the following fax / modem adaptations:

- Disables silence suppression
- Enables echo cancellation for fax
- Disables echo cancellation for modem
- Performs certain jitter buffering optimizations

The network packets generated and received during the bypass period are regular voice RTP packets (per the selected bypass coder), but with a different RTP payload type according to the following parameters:

- 'Fax Bypass Payload Type' (FaxBypassPayloadType)
- ModemBypassPayloadType (ini file)

During the bypass period, the coder uses the packing factor, configured by the 'Fax/Modem Bypass Packing Factor' parameter (FaxModemBypassM). The packing factor determines the number of coder payloads (each the size of FaxModemBypassBasicRTPPacketInterval) that are used to generate a single fax/modem bypass packet. When fax/modem transmission ends, the reverse switching, from bypass coder to regular voice coder is performed.

➤ **To configure fax / modem bypass mode:**

1. In the SIP General Parameters page (**Configuration** tab > **VoIP** menu > **SIP Definitions > General Parameters**), set the 'Fax Signaling Method' parameter to **No Fax** (IsFaxUsed = 0).
2. In the Fax/Modem/CID Settings page, do the following:
 - a. Set the 'Fax Transport Mode' parameter to **Bypass** (FaxTransportMode = 2).
 - b. Set the 'V.21 Modem Transport Type' parameter to **Enable Bypass** (V21ModemTransportType = 2).
 - c. Set the 'V.22 Modem Transport Type' parameter to **Enable Bypass** (V22ModemTransportType = 2).
 - d. Set the 'V.23 Modem Transport Type' parameter to **Enable Bypass** (V23ModemTransportType = 2).
 - e. Set the 'V.32 Modem Transport Type' parameter to **Enable Bypass** (V32ModemTransportType = 2).
 - f. Set the 'V.34 Modem Transport Type' parameter to **Enable Bypass** (V34ModemTransportType = 2).
3. Set the ini file parameter, BellModemTransportType to 2 (Bypass).
4. Configure the following optional parameters:
 - 'Fax/Modem Bypass Coder Type' (FaxModemBypassCoderType).
 - 'Fax Bypass Payload Type' (FaxBypassPayloadType) - in the RTP/RTCP Settings page (**Configuration** tab > **VoIP** menu > **Media > RTP/RTCP Settings**).
 - ModemBypassPayloadType (ini file).

- FaxModemBypassBasicRTPPacketInterval (ini file).
- FaxModemBypassDJBufMinDelay (ini file).



Note: When the device is configured for modem bypass and T.38 fax, V.21 low-speed modems are not supported and fail as a result.



Tip: When the remote (non-AudioCodes) gateway uses the G.711 coder for voice and doesn't change the coder payload type for fax or modem transmission, it is recommended to use the Bypass mode with the following configuration:

- EnableFaxModemInbandNetworkDetection = 1.
- 'Fax/Modem Bypass Coder Type' = same coder used for voice.
- 'Fax/Modem Bypass Packing Factor'(FaxModemBypassM) = same interval as voice.
- ModemBypassPayloadType = 8 if voice coder is A-Law or 0 if voice coder is Mu-Law.

13.2.2.5 Fax / Modem NSE Mode

In this mode, fax and modem signals are transferred using Cisco-compatible Pass-through bypass mode. Upon detection of fax or modem answering tone signal, the terminating device sends three to six special NSE RTP packets (configured by the NSEpayloadType parameter; usually to 100). These packets signal the remote device to switch to G.711 coder, according to the 'Fax/Modem Bypass Packing Factor' parameter. After a few NSE packets are exchanged between the devices, both devices start using G.711 packets with standard payload type (8 for G.711 A-Law and 0 for G.711 Mu-Law). In this mode, no Re-INVITE messages are sent. The voice channel is optimized for fax/modem transmission (same as for usual bypass mode).

The parameters defining payload type for AudioCodes proprietary Bypass mode -- 'Fax Bypass Payload Type' (RTP/RTCP Settings page) and ModemBypassPayloadType (ini file) -- are not used with NSE Bypass.

When configured for NSE mode, the device includes in its SDP the following line:

```
a=rtpmap:100 X-NSE/8000
```

Where 100 is the NSE payload type.

The Cisco gateway must include the following definition:

```
modem passthrough nse payload-type 100 codec g711alaw
```

➤ To configure NSE mode:

1. In the SIP General Parameters page (**Configuration** tab > **VoIP** menu > **SIP Definitions** > **General Parameters**), set the 'Fax Signaling Method' parameter to **No Fax** (IsFaxUsed = 0).
2. In the Fax/Modem/CID Settings page, do the following:
 - a. Set the 'Fax Transport Mode' parameter to **Bypass** (FaxTransportMode = 2).
 - b. Set the 'V.21 Modem Transport Type' parameter to **Enable Bypass** (V21ModemTransportType = 2).
 - c. Set the 'V.22 Modem Transport Type' parameter to **Enable Bypass** (V22ModemTransportType = 2).
 - d. Set the 'V.23 Modem Transport Type' parameter to **Enable Bypass** (V23ModemTransportType = 2).

- e. Set the 'V.32 Modem Transport Type' parameter to **Enable Bypass** (V32ModemTransportType = 2).
 - f. Set the 'V.34 Modem Transport Type' parameter to **Enable Bypass** (V34ModemTransportType = 2).
3. Set the ini file parameter, BellModemTransportType to 2 (Bypass).
4. Set the ini file parameter, NSEMode parameter to 1 (enables NSE).
5. Set the ini file parameter, NSEPayloadType parameter to 100.

13.2.2.6 Fax / Modem Transparent with Events Mode

In this mode, fax and modem signals are transferred using the current voice coder with the following automatic adaptations:

- Echo Cancellor = on (or off for modems)
- Echo Cancellor Non-Linear Processor Mode = off
- Jitter buffering optimizations

➤ **To configure fax / modem transparent with events mode:**

1. In the SIP General Parameters page (**Configuration** tab > **VoIP** menu > **SIP Definitions** > **General Parameters**), set the 'Fax Signaling Method' parameter to **No Fax** (IsFaxUsed = 0).
2. In the Fax/Modem/CID Settings page, do the following:
 - a. Set the 'Fax Transport Mode' parameter to **Events Only** (FaxTransportMode = 3).
 - b. Set the 'V.21 Modem Transport Type' parameter to **Events Only** (V21ModemTransportType = 3).
 - c. Set the 'V.22 Modem Transport Type' parameter to **Events Only** (V22ModemTransportType = 3).
 - d. Set the 'V.23 Modem Transport Type' parameter to **Events Only** (V23ModemTransportType = 3).
 - e. Set the 'V.32 Modem Transport Type' parameter to **Events Only** (V32ModemTransportType = 3).
 - f. Set the 'V.34 Modem Transport Type' parameter to **Events Only** (V34ModemTransportType = 3).
3. Set the ini file parameter, BellModemTransportType to 3 (transparent with events).

13.2.2.7 Fax / Modem Transparent Mode

In this mode, fax and modem signals are transferred using the current voice coder without notifications to the user and without automatic adaptations. It's possible to use Profiles (see 'Coders and Profiles' on page 239) to apply certain adaptations to the channel used for fax / modem. For example, to use the coder G.711, to set the jitter buffer optimization factor to 13, and to enable echo cancellation for fax and disable it for modem.

➤ **To configure fax / modem transparent mode:**

1. In the SIP General Parameters page (**Configuration** tab > **VoIP** menu > **SIP Definitions** > **General Parameters**), set the 'Fax Signaling Method' parameter to **No Fax** (IsFaxUsed = 0).
2. In the Fax/Modem/CID Settings page, do the following:
 - a. Set the 'Fax Transport Mode' parameter to **Disable** (FaxTransportMode = 0).
 - b. Set the 'V.21 Modem Transport Type' parameter to **Disable** (V21ModemTransportType = 0).

- c. Set the 'V.22 Modem Transport Type' parameter to **Disable** (V22ModemTransportType = 0).
 - d. Set the 'V.23 Modem Transport Type' parameter to **Disable** (V23ModemTransportType = 0).
 - e. Set the 'V.32 Modem Transport Type' parameter to **Disable** (V32ModemTransportType = 0).
 - f. Set the 'V.34 Modem Transport Type' parameter to **Disable** (V34ModemTransportType = 0).
3. Set the ini file parameter, BellModemTransportType to 0 (transparent mode).
 4. Configure the following optional parameters:
 - a. Coders table - (**Configuration** tab > **VoIP** menu > **Coders and Profiles** > **Coders**).
 - b. 'Dynamic Jitter Buffer Optimization Factor' (DJBufOptFactor) - RTP/RTCP Settings page (**Configuration** tab > **VoIP** menu > **Media** > **RTP/RTCP Settings**).
 - c. 'Silence Suppression' (EnableSilenceCompression) - Voice Settings page (**Configuration** tab > **VoIP** menu > **Media** > **Voice Settings**).
 - d. 'Echo Cancellor' (EnableEchoCancellor) - Voice Settings page.



Note: This mode can be used for fax, but is not recommended for modem transmission. Instead, use the Bypass (see 'Fax/Modem Bypass Mode' on page 163) or Transparent with Events modes (see 'Fax / Modem Transparent with Events Mode' on page 165) for modem.

13.2.2.8 RFC 2833 ANS Report upon Fax/Modem Detection

The device (terminator gateway) sends RFC 2833 ANS/ANSam events upon detection of fax and/or modem answer tones (i.e., CED tone). This causes the originator to switch to fax/modem. This parameter is applicable only when the fax or modem transport type is set to bypass, Transparent-with-Events, V.152 VBD, or G.711 transport. When the device is located on the originator side, it ignores these RFC 2833 events

- **To configure RFC 2833 ANS Report upon fax/modem detection:**
1. In the SIP General Parameters page (**Configuration** tab > **VoIP** menu > **SIP Definitions** > **General Parameters**), set the 'Fax Signaling Method' parameter to **No Fax** or **Fax Fallback** (IsFaxUsed = 0 or 3).
 2. In the Fax/Modem/CID Settings page, do the following:
 - a. Set the 'Fax Transport Mode' parameter to **Bypass** (FaxTransportMode = 2).
 - b. Set the 'V.xx Modem Transport Type' parameters to **Enable Bypass** (VxxModemTransportType = 2).
 3. Set the ini file parameter, FaxModemNTEMode to 1 (enables this feature).

13.2.3 V.34 Fax Support

V.34 fax machines can transmit data over IP to the remote side using various methods. The device supports the following modes for transporting V.34 fax data over IP:

- Bypass mechanism for V.34 fax transmission (see 'Bypass Mechanism for V.34 Fax Transmission' on page 167)
- T38 Version 0 relay mode, i.e., fallback to T.38 (see 'Relay Mode for T.30 and V.34 Faxes' on page 167)



Note: The CNG detector is disabled in all the subsequent examples. To disable the CNG detector, set the 'CNG Detector Mode' parameter (CNGDetectorMode) to **Disable**.

13.2.3.1 Bypass Mechanism for V.34 Fax Transmission

In this proprietary scenario, the device uses bypass (or NSE) mode to transmit V.34 faxes, enabling the full utilization of its speed.

➤ **To use bypass mode for T.30 and V.34 faxes:**

1. In the Fax/Modem/CID Settings page, do the following:
 - a. Set the 'Fax Transport Mode' parameter to **Bypass** (FaxTransportMode = 2).
 - b. Set the 'V.22 Modem Transport Type' parameter to **Enable Bypass** (V22ModemTransportType = 2).
 - c. Set the 'V.23 Modem Transport Type' parameter to **Enable Bypass** (V23ModemTransportType = 2).
 - d. Set the 'V.32 Modem Transport Type' parameter to **Enable Bypass** (V32ModemTransportType = 2).
 - e. Set the 'V.34 Modem Transport Type' parameter to **Enable Bypass** (V34ModemTransportType = 2).

➤ **To use bypass mode for V.34 faxes, and T.38 for T.30 faxes:**

1. In the Fax/Modem/CID Settings page, do the following:
 - a. Set the 'Fax Transport Mode' parameter to **Relay** (FaxTransportMode = 1).
 - b. Set the 'V.22 Modem Transport Type' parameter to **Enable Bypass** (V22ModemTransportType = 2).
 - c. Set the 'V.23 Modem Transport Type' parameter to **Enable Bypass** (V23ModemTransportType = 2).
 - d. Set the 'V.32 Modem Transport Type' parameter to **Enable Bypass** (V32ModemTransportType = 2).
 - e. Set the 'V.34 Modem Transport Type' parameter to **Enable Bypass** (V34ModemTransportType = 2).

13.2.3.2 Relay Mode for T.30 and V.34 Faxes

In this scenario, V.34 fax machines are forced to use their backward compatibility with T.30 faxes and operate in the slower T.30 mode.

➤ **To use T.38 mode for V.34 and T.30 faxes:**

1. In the Fax/Modem/CID Settings page, do the following:
 - a. Set the 'Fax Transport Mode' parameter to **Relay** (FaxTransportMode = 1).
 - b. Set the 'V.22 Modem Transport Type' parameter to **Disable** (V22ModemTransportType = 0).
 - c. Set the 'V.23 Modem Transport Type' parameter to **Disable** (V23ModemTransportType = 0).
 - d. Set the 'V.32 Modem Transport Type' parameter to **Disable** (V32ModemTransportType = 0).
 - e. Set the 'V.34 Modem Transport Type' parameter to **Disable** (V34ModemTransportType = 0).

13.2.4 V.152 Support

The device supports the ITU-T recommendation V.152 (Procedures for Supporting Voice-Band Data over IP Networks). Voice-band data (VBD) is the transport of modem, facsimile, and text telephony signals over a voice channel of a packet network with a codec appropriate for such signals.

For V.152 capability, the device supports T.38 as well as VBD codecs (i.e., G.711 A-law and G.711 μ -law). The selection of capabilities is performed using the coders table (see 'Configuring Coders' on page 239).

When in VBD mode for V.152 implementation, support is negotiated between the device and the remote endpoint at the establishment of the call. During this time, initial exchange of call capabilities is exchanged in the outgoing SDP. These capabilities include whether VBD is supported and associated RTP payload types ('gpmd' SDP attribute), supported codecs, and packetization periods for all codec payload types ('ptime' SDP attribute). After this initial negotiation, no Re-INVITE messages are necessary as both endpoints are synchronized in terms of the other side's capabilities. If negotiation fails (i.e., no match was achieved for any of the transport capabilities), fallback to existing logic occurs (according to the parameter `IsFaxUsed`).

Below is an example of media descriptions of an SDP indicating support for V.152. In the example, V.152 implementation is supported (using the dynamic payload type 96 and G.711 u-law as the VBD codec) as well as the voice codecs G.711 μ -law and G.729.

```
v=0
o=- 0 0 IN IPV4 <IPAdressA>
s=-
t=0 0
p=+1
c=IN IP4 <IPAdressA>
m=audio <udpPort A> RTP/AVP 18 0
a=ptime:10
a=rtpmap:96 PCMU/8000
a=gpmd: 96 vbd=yes
```

Instead of using VBD transport mode, the V.152 implementation can use alternative relay fax transport methods (e.g., fax relay over IP using T.38). The preferred V.152 transport method is indicated by the SDP 'pmft' attribute. Omission of this attribute in the SDP content means that VBD mode is the preferred transport mechanism for voice-band data. To configure T.38 mode, use the `CodersGroup` parameter.



Note: You can also configure the device to handle G.711 coders received in INVITE SDP offers as VBD coders, using the `HandleG711asVBD` parameter. For example, if the device is configured with G.729 and G.711 VBD coders and it receives an INVITE with an SDP offer containing G.729 and "regular" G.711 coders, it sends an SDP answer containing G.729 and G.711 VBD coders, allowing subsequent bypass (passthrough) sessions if fax / modem signals are detected during the call.

13.2.5 Fax Transmission behind NAT

The device supports transmission from fax machines (connected to the device) located inside (behind) a Network Address Translation (NAT). Generally, the firewall blocks T.38 (and other) packets received from the WAN, unless the device behind the NAT sends at least one IP packet from the LAN to the WAN through the firewall. If the firewall blocks T.38 packets sent from the termination IP fax, the fax fails.

To overcome this, the device sends No-Op ("no-signal") packets to open a pinhole in the NAT for the answering fax machine. The originating fax does not wait for an answer, but immediately starts sending T.38 packets to the terminating fax machine upon receipt of a

re-INVITE with T.38 only in the SDP, or T.38 and audio media in the SDP. This feature is configured using the T38FaxSessionImmediateStart parameter. The No-Op packets are enabled using the NoOpEnable and NoOpInterval parameters.

13.3 Configuring RTP/RTCP Settings

This section describes configuration relating to Real-Time Transport Protocol (RTP) and RTP Control Protocol (RTCP).

13.3.1 Configuring the Dynamic Jitter Buffer

Voice frames are transmitted at a fixed rate. If the frames arrive at the other end at the same rate, voice quality is perceived as good. However, some frames may arrive slightly faster or slower than the other frames. This is called jitter (delay variation) and degrades the perceived voice quality. To minimize this problem, the device uses a jitter buffer. The jitter buffer collects voice packets, stores them and sends them to the voice processor in evenly spaced intervals.

The device uses a dynamic jitter buffer that can be configured with the following:

- **Minimum delay:** Defines the starting jitter capacity of the buffer. For example, at 0 msec, there is no buffering at the start. At the default level of 10 msec, the device always buffers incoming packets by at least 10 msec worth of voice frames.
- **Optimization Factor:** Defines how the jitter buffer tracks to changing network conditions. When set at its maximum value of 12, the dynamic buffer aggressively tracks changes in delay (based on packet loss statistics) to increase the size of the buffer and doesn't decay back down. This results in the best packet error performance, but at the cost of extra delay. At the minimum value of 0, the buffer tracks delays only to compensate for clock drift and quickly decays back to the minimum level. This optimizes the delay performance but at the expense of a higher error rate.

The default settings of 10 msec Minimum delay and 10 Optimization Factor should provide a good compromise between delay and error rate. The jitter buffer 'holds' incoming packets for 10 msec before making them available for decoding into voice. The coder polls frames from the buffer at regular intervals in order to produce continuous speech. As long as delays in the network do not change (jitter) by more than 10 msec from one packet to the next, there is always a sample in the buffer for the coder to use. If there is more than 10 msec of delay at any time during the call, the packet arrives too late. The coder tries to access a frame and is not able to find one. The coder must produce a voice sample even if a frame is not available. It therefore compensates for the missing packet by adding a Bad-Frame-Interpolation (BFI) packet. This loss is then flagged as the buffer being too small. The dynamic algorithm then causes the size of the buffer to increase for the next voice session. The size of the buffer may decrease again if the device notices that the buffer is not filling up as much as expected. At no time does the buffer decrease to less than the minimum size configured by the Minimum delay parameter.

In certain scenarios, the **Optimization Factor is set to 13**: One of the purposes of the Jitter Buffer mechanism is to compensate for clock drift. If the two sides of the VoIP call are not synchronized to the same clock source, one RTP source generates packets at a lower rate, causing under-runs at the remote Jitter Buffer. In normal operation (optimization factor 0 to 12), the Jitter Buffer mechanism detects and compensates for the clock drift by occasionally dropping a voice packet or by adding a BFI packet.

Fax and modem devices are sensitive to small packet losses or to added BFI packets. Therefore, to achieve better performance during modem and fax calls, the Optimization Factor should be set to 13. In this special mode the clock drift correction is performed less frequently - only when the Jitter Buffer is completely empty or completely full. When such condition occurs, the correction is performed by dropping several voice packets

simultaneously or by adding several BFI packets simultaneously, so that the Jitter Buffer returns to its normal condition.

The procedure below describes how to configure the jitter buffer using the Web interface.

➤ **To configure jitter buffer using the Web interface:**

1. Open the RTP/RTCP Settings page (**Configuration** tab > **VoIP** menu > **Media** submenu > **RTP/RTCP Settings**). The relevant parameters are listed under the 'General Settings' group, as shown below:

Figure 13-5: Jitter Buffer Parameters in the RTP/RTCP Settings Page

▼ General Settings	
Dynamic Jitter Buffer Minimum Delay	<input type="text" value="10"/>
Dynamic Jitter Buffer Optimization Factor	<input type="text" value="10"/>

2. Set the 'Dynamic Jitter Buffer Minimum Delay' parameter (DJBufMinDelay) to the minimum delay (in msec) for the Dynamic Jitter Buffer.
3. Set the 'Dynamic Jitter Buffer Optimization Factor' parameter (DJBufOptFactor) to the Dynamic Jitter Buffer frame error/delay optimization factor.
4. Click **Submit** to apply your settings.

13.3.2 Comfort Noise Generation

The device can generate artificial background noise, called *comfort* noise, in the voice channel during periods of silence (i.e. when no call party is speaking). This is useful in that it reassures the call parties that the call is still connected. The device detects silence using its Voice Activity Detection (VAD) mechanism. When the Calling Tone (CNG) is enabled and silence is detected, the device transmits Silence Identifier Descriptors (SIDs) parameters to reproduce the local background noise at the remote (receiving) side.

The Comfort Noise Generation (CNG) support also depends on the silence suppression (SCE) setting for the coder used in the voice channel. For more information, see the description of the CNG-related parameters.

The procedure below describes how to configure CNG using the Web interface.

➤ **To configure CNG using the Web interface:**

1. Open the RTP/RTCP Settings page (**Configuration** tab > **VoIP** menu > **Media** submenu > **RTP/RTCP Settings**). The relevant parameters are listed under the 'General Settings' group, as shown below:

Figure 13-6: Comfort Noise Parameter in RTP/RTCP Settings Page

Comfort Noise Generation Negotiation	<input type="text" value="Enable"/>
--------------------------------------	-------------------------------------

2. Set the 'Comfort Noise Generation Negotiation' parameter (ComfortNoiseNegotiation) to **Enable**.
3. Click **Submit** to apply your changes.

13.3.3 Dual-Tone Multi-Frequency Signaling

This section describes the configuration of Dual-Tone Multi-Frequency (DTMF) signaling.

13.3.3.1 Configuring DTMF Transport Types

The device supports various methods for transporting DTMF digits over the IP network to the remote endpoint. These methods and their configuration are configured in the DTMF & Dialing page (**Configuration** tab > **VoIP** menu > **GW and IP to IP** > **DTMF and Supplementary** > **DTMF & Dialing**):

- **Using INFO message according to Nortel IETF draft:** DTMF digits are sent to the remote side in INFO messages. To enable this mode, define the following:
 - a. Set the 'Declare RFC 2833 in SDP' parameter to **No** (RxDTMFOption = 0).
 - b. Set the '1st Tx DTMF Option' parameter to **INFO (Nortel)** (TxDTMFOption = 1).**Note:** In this mode, DTMF digits are removed from the audio stream (and the 'DTMF Transport Type' parameter is automatically set to **Mute DTMF**).
- **Using INFO message according to Cisco's mode:** DTMF digits are sent to the remote side in INFO messages. To enable this mode, define the following:
 - a. Set the 'Declare RFC 2833 in SDP' parameter to **No** (RxDTMFOption = 0).
 - b. Set the '1st Tx DTMF Option' parameter to **INFO (Cisco)** (TxDTMFOption = 3).**Note:** In this mode, DTMF digits are removed from the audio stream (and the 'DTMF Transport Type' parameter is automatically set to **Mute DTMF**).
- **Using NOTIFY messages according to IETF Internet-Draft draft-mahy-sipping-signaled-digits-01:** DTMF digits are sent to the remote side using NOTIFY messages. To enable this mode, define the following:
 - a. Set the 'Declare RFC 2833 in SDP' parameter to **No** (RxDTMFOption = 0).
 - b. Set the '1st Tx DTMF Option' parameter to **NOTIFY** (TxDTMFOption = 2).**Note:** In this mode, DTMF digits are removed from the audio stream (and the 'DTMF Transport Type' parameter is automatically set to **Mute DTMF**).
- **Using RFC 2833 relay with Payload type negotiation:** DTMF digits are sent to the remote side as part of the RTP stream according to RFC 2833. To enable this mode, define the following:
 - a. Set the 'Declare RFC 2833 in SDP' parameter to **Yes** (RxDTMFOption = 3).
 - b. Set the '1st Tx DTMF Option' parameter to **RFC 2833** (TxDTMFOption = 4).**Note:** To set the RFC 2833 payload type with a value other than its default, use the RFC2833PayloadType parameter. The device negotiates the RFC 2833 payload type using local and remote SDP and sends packets using the payload type from the received SDP. The device expects to receive RFC 2833 packets with the same payload type as configured by this parameter. If the remote side doesn't include 'telephony-event' in its SDP, the device sends DTMF digits in transparent mode (as part of the voice stream).
- **Sending DTMF digits (in RTP packets) as part of the audio stream (DTMF Relay is disabled):** This method is typically used with G.711 coders. With other low-bit rate (LBR) coders, the quality of the DTMF digits is reduced. To enable this mode, define the following:
 - a. Set the 'Declare RFC 2833 in SDP' parameter to **No** (RxDTMFOption = 0).
 - b. Set the '1st Tx DTMF Option' parameter to **Not Supported** (TxDTMFOption = 0).
 - c. Set the ini file parameter, DTMFTransportType to 2 (i.e., transparent).

- **Using INFO message according to Korea mode:** DTMF digits are sent to the remote side in INFO messages. To enable this mode, define the following:
 - a. Set the 'Declare RFC 2833 in SDP' parameter to **No** (RxDTMFOption = 0).
 - b. Set the '1st Tx DTMF Option' parameter to **INFO (Cisco)** (TxDTMFOption = 3).**Note:** In this mode, DTMF digits are removed from the audio stream (and the 'DTMF Transport Type' parameter is automatically set to **Mute DTMF**).



Notes:

- The device is always ready to receive DTMF packets over IP in all possible transport modes: INFO messages, NOTIFY, and RFC 2833 (in proper payload type) or as part of the audio stream.
- To exclude RFC 2833 Telephony event parameter from the device's SDP, set the 'Declare RFC 2833 in SDP' parameter to **No**.

The following parameters affect the way the device handles the DTMF digits:

- TxDTMFOption, RxDTMFOption, RFC2833TxPayloadType, and RFC2833RxPayloadType
- MGCPDTMFDetectionPoint, DTMFVolume, DTMFTransportType, DTMFDigitLength, and DTMFInterDigitInterval

13.3.3.2 Configuring RFC 2833 Payload

The procedure below describes how to configure the RFC 2833 payload using the Web interface:

➤ **To configure RFC 2833 payload using the Web interface:**

1. Open the RTP/RTCP Settings page (**Configuration** tab > **VoIP** menu > **Media** submenu > **RTP/RTCP Settings**). The relevant parameters are listed under the 'General Settings' group, as shown below:

Figure 13-7: RFC 2833 Payload Parameters in RTP/RTCP Settings Page

RTP Redundancy Depth	<input type="text" value="0"/>
Packing Factor	<input type="text" value="1"/>
Basic RTP Packet Interval	<input type="text" value="Default"/> ▼
RFC 2833 TX Payload Type	<input type="text" value="96"/>
RFC 2833 RX Payload Type	<input type="text" value="96"/>
RFC 2198 Payload Type	<input type="text" value="104"/>
Fax Bypass Payload Type	<input type="text" value="102"/>
Enable RFC 3389 CN Payload Type	<input type="text" value="Enable"/> ▼

2. Configure the following parameters:
 - 'RTP Redundancy Depth' (RTPRedundancyDepth) - enables the device to generate RFC 2198 redundant packets.
 - 'Enable RTP Redundancy Negotiation' (EnableRTPRedundancyNegotiation) - enables the device to include the RTP redundancy dynamic payload type in the SDP, according to RFC 2198.
 - 'RFC 2833 TX Payload Type' (RFC2833TxPayloadType) - defines the Tx RFC 2833 DTMF relay dynamic payload type.

- 'RFC 2833 RX Payload Type' (RFC2833RxCPayloadType) - defines the Rx RFC 2833 DTMF relay dynamic payload type.
 - 'RFC 2198 Payload Type' (RFC2198PayloadType) - defines the RTP redundancy packet payload type according to RFC 2198.
3. Click **Submit** to apply your settings.

13.3.4 RTP Multiplexing (ThroughPacket)

The device's RTP Multiplexing (ThroughPacket™) feature is AudioCodes proprietary method for aggregating RTP streams from several channels when the device operates with another AudioCodes device. This feature reduces the bandwidth overhead caused by the attached Ethernet, IP, UDP, and RTP headers and reduces the packet/data transmission rate. It reduces the load on network routers and can typically save up to 50% (e.g., for G.723) on IP bandwidth. RTP multiplexing is accomplished by aggregating payloads from several channels into a single IP packet, which are sent to the same destination IP address. You can enable RTP multiplexing for all destinations as described in the procedure below or for specific IP destinations using IP Profiles (see 'Configuring IP Profiles' on page 245).



Notes:

- RTP Multiplexing must be enabled on both AudioCodes devices.
- When VLANs are implemented, the RTP Multiplexing mechanism is not supported.
- When RTP Multiplexing is used, call statistics are unavailable (as there is no RTCP flow).

The procedure below describes how to configure RTP multiplexing using the Web interface.

➤ To configure RTP multiplexing:

1. Open the RTP/RTCP Settings page (**Configuration** tab > **VoIP** menu > **Media** submenu > **RTP/RTCP Settings**). The RTP Multiplexing parameters are listed under the 'General Settings' group, as shown below:

Figure 13-8: Configuring RTP Multiplexing in RTP/RTCP Settings

Remote RTP Base UDP Port	8000
⚡ RTP Multiplexing Local UDP Port	20000
⚡ RTP Multiplexing Remote UDP Port	10000
⚡ RTP Base UDP Port	6000

2. Enable RTP Multiplexing by setting the 'Remote RTP Base UDP Port' parameter (RemoteBaseUDPPort) to a non-zero value. This port must be the same as the port set by the 'RTP Base UDP Port' field (BaseUDPPort) parameter at the remote device. Conversely, when configuring the remote device, its 'Remote RTP Base UDP Port' parameter value must be the same as this local device's 'RTP Base UDP Port' parameter value. These parameters identify and distribute the payloads from the received multiplexed IP packet to the relevant channels.
3. In the 'RTP Multiplexing Local UDP Port' parameter (L1L1ComplexTxUDPPort), set the local UDP port for outgoing multiplexed RTP packets.
4. In the 'RTP Multiplexing Remote UDP Port' parameter (L1L1ComplexRxUDPPort), set the destination UDP port for outgoing multiplexed packets. This also configures the local UDP port for incoming multiplexed RTP packets.

5. Click **Submit**.
6. Reset the device for the settings to take effect.

13.3.5 Configuring RTP Base UDP Port

You can configure the range of UDP ports for RTP, RTCP, and T.38. The UDP port range can be configured using media realms in the Media Realm table, allowing you to assign different port ranges (media realms) to different interfaces. However, if you do not use media realms, you can configure the lower boundary of the UDP port used for RTP, RTCP (RTP port + 1) and T.38 (RTP port + 2), using the 'RTP Base UDP Port' (BaseUDPport) parameter. For example, if the BaseUDPPort is set to 6000, then one channel may use the ports RTP 6000, RTCP 6001, and T.38 6002, while another channel may use RTP 6010, RTCP 6011, and T.38 6012.

The range of possible UDP ports is 6,000 to 64,000 (default base UDP port is 6000). The port range is calculated using the BaseUDPport parameter as follows: **BaseUDPPort to (BaseUDPPort + <channels -1> * 10)**

The default local UDP ports for audio and fax media streams is calculated using the following formula: **BaseUDPPort + (Channel ID * 10) + Port Offset**

Where the port offsets are as follows:

- **Audio RTP:** 0
- **Audio RTCP:** 1
- **Fax T.38:** 2

For example, the local T.38 UDP port for channel 30 is calculated as follows: **6000 + (30*10) + 2 = 6302**

The maximum (when all channels are required) UDP port range is calculated as follows:

- BaseUDPport to (BaseUDPport + 255*10) - for example, if the BaseUDPPort is set to 6,000, then the UDP port range is 6,000 to 8,550



Notes:

- The device allocates the UDP ports randomly to the channels.
- To configure the device to use the same port for both RTP and T.38 packets, set the T38UseRTPPort parameter to 1.
- If you are using Media Realms (see 'Configuring Media Realms' on page 183), the port range configured for the Media Realm must be within this range defined by the BaseUDPPort parameter.

The procedure below describes how to configure the RTP base UDP port using the Web interface.

➤ To configure the RTP base UDP port:

1. Open the RTP/RTCP Settings page (**Configuration** tab > **VoIP** menu > **Media** submenu > **RTP/RTCP Settings**). The relevant parameter is listed under the 'General Settings' group, as shown below:

Figure 13-9: RTP Based UDP Port in RTP/RTCP Settings Page

⚡ RTP Base UDP Port	6000
---------------------	------

2. Set the 'RTP Base UDP Port' parameter to the required value.
3. Click **Submit**.
4. Reset the device for the settings to take effect.

13.4 Configuring IP Media Settings

This section describes the configuration of various IP media features.

13.4.1 Answer Machine Detector (AMD)

The device provides answering machine detection (AMD) capabilities that can detect, for example, whether a human voice or an answering machine is answering the call. AMD is useful for automatic dialing applications.

The AMD feature is configured in the IPMedia Settings page (**Configuration** tab > **VoIP** > **Media** > **IPMedia Settings**), as shown below:

Figure 13-10: AMD Parameters in the IPMedia Settings Page

IPMedia Settings	
IPMedia Detectors	Disable
Enable Answer Detector	Disable
Answer Detector Activity Delay	0
Answer Detector Silence Time	10
Answer Detector Redirection	0
Answer Detector Sensitivity	0
Answer Machine Detector Sensitivity Parameter Suit	0
Answer Machine Detector Sensitivity	3
Answer Machine Detector Beep Detection Timeout	200
Answer Machine Detector Beep Detection Sensitivity	0

Before you can use the AMD feature, you must enable it as described in the procedure below:

➤ **To enable the AMD feature:**

1. Set the 'IPMedia Detectors' parameter (EnableDSPIPMDetectors) to **Enable**.
2. To enable voice detection once the AMD detects the answering machine, set the *ini* file parameter, EnableVoiceDetection to 1.

The device supports up to four AMD parameter suites, where each parameter suite defines the AMD sensitivity levels of detection. The detection sensitivity levels can range from 0 to 15, depending on the parameter suite. The level is selected using the 'Answer Machine Detector Sensitivity Level' parameter (AMDSensitivityLevel) parameter.

The Parameter Suite(s) can be loaded to the device in the Web interface as an auxiliary file (see 'Loading Auxiliary Files' on page 499) or loaded remotely through the ini file using the AMDSensitivityFileName and AMDSensitivityFileUrl parameters.

You can also configure AMD per call, based on the called number or Trunk Group. This is achieved by configuring AMD for a specific IP Profile and then assigning the IP Profile to a Trunk Group in the Inbound IP Routing table (PSTNPrefix parameter).

The device also supports the detection of beeps at the end of an answering machine message. This allows users of third-party, Application servers to leave voice messages after an answering machine plays a "beep" sound.

The device supports the following methods for detecting and reporting beeps:

- **Using the AMD detector:** This beep detector is integrated in the existing AMD feature. The beep detection timeout and beep detection sensitivity are configurable using the AMDBeepDetectionTimeout and AMDBeepDetectionSensitivity parameters, respectively. To enable the AMD beep detection, the X-Detect header in the received INVITE message must include "Request=AMD", and the AMDBeepDetectionMode parameter must be set to 1 or 2. If set to 1, the beep is detected only after Answering

Machine detection. If set to 2, the beep is detected even if the Answering Machine was not detected.

- **Using the Call Progress Tone detector:** To enable this detection mode, the X-Detect header in the received INVITE message must include "Request=CPT", and one or several beep tones (Tone Type #46) must be configured in the regular CPT file.

The device reports beep detection by sending a SIP INFO message containing a body with one of the following values:

- Type=AMD and SubType=Beep
- Type=CPT and SubType=Beep

Upon AMD activation, the device can send a SIP INFO message to an Application server notifying it of one of the following:

- Human voice has been detected
- Answering machine has been detected
- Silence (i.e., no voice detected) has been detected

The detected AMD type (e.g., voice) and success of detecting it correctly are also sent in CDR and Syslog messages.



Note: You can configure the device to disconnect IP-to-Tel calls upon detection of an answering machine on the Tel side, using the AMDmode parameter.

The table below shows the success rates of the AMD feature for correctly detecting live and fax calls:

Approximate AMD Detection Normal Sensitivity (Based on North American English)

AMD Detection Sensitivity	Performance	
	Success Rate for Live Calls	Success Rate for Answering Machine
0 (Best for Answering Machine)	-	-
1	82.56%	97.10%
2	85.87%	96.43%
3 (Default)	88.57%	94.76%
4	88.94%	94.31%
5	90.42%	91.64%
6	90.66%	91.30%
7 (Best for Live Calls)	94.72%	76.14%

Approximate AMD Detection High Sensitivity (Based on North American English)

AMD Detection Sensitivity	Performance	
	Success Rate for Live Calls	Success Rate for Answering Machine
0 (Best for Answering Machine)	72%	97%
1	77%	96%
2	79%	95%
3	80%	95%
4	84%	94%
5	86%	93%
6	87%	92%
7	88%	91%
8 (default)	90%	89%
9	90%	88%
10	91%	87%
11	94%	78%
12	94%	73%
13	95%	65%
14	96%	62%
15 (Best for Live Calls)	97%	46%



Note: The device's AMD feature is based on voice detection for North American English. If you want to implement AMD in a different language or region, you must provide AudioCodes with a database of recorded voices in the language on which the device's AMD mechanism can base its voice detector algorithms for detecting these voices. The data needed for an accurate calibration should be recorded under the following guidelines:

- Statistical accuracy: The number of recordings should be large (i.e., about 100) and varied. The calls must be made to different people, at different times. The calls must be made in the specific location in which the device's AMD mechanism is to operate.
- Real-life recording: The recordings should simulate real-life answering of a person picking up the phone without the caller speaking (until the AMD decision).
- Normal environment interferences: The environment should almost simulate real-life scenarios, i.e., not sterile but not too noisy either. Interferences, for example, could include background noises of other people talking, spikes, and car noises.

The SIP call flows below show an example of implementing the device's AMD feature. This scenario example allows a third-party Application server to play a recorded voice message to an answering machine.

1. Upon detection by the device of the answering machine, the device sends a SIP INFO message to the Application server:

```
INFO sip:sipp@172.22.2.9:5060 SIP/2.0
Via: SIP/2.0/UDP 172.22.168.249;branch=z9hG4bKac1566945480
Max-Forwards: 70
From: sut <sip:3000@172.22.168.249:5060>;tag=1c1505895240
To: sipp <sip:sipp@172.22.2.9:5060>;tag=1
Call-ID: 1-29758@172.22.2.9
CSeq: 1 INFO
Contact: <sip:56700@172.22.168.249>
Supported: em,timer,replaces,path,resource-priority
Allow:
REGISTER,OPTIONS,INVITE,ACK,CANCEL,BYE,NOTIFY,PRACK,REFER,INFO
,SUBSCRIBE,UPDATE
User-Agent: Audiocodes-Sip-Gateway/v.6.40A.040.004
Content-Type: application/x-detect
Content-Length: 30
Type= AMD
SubType= AUTOMATA
```

2. The device then detects the start of voice (i.e., the greeting message of the answering machine), and then sends the following to the Application server:

```
INFO sip:sipp@172.22.2.9:5060 SIP/2.0
Via: SIP/2.0/UDP 172.22.168.249;branch=z9hG4bKac482466515
Max-Forwards: 70
From: sut <sip:3000@172.22.168.249:5060>;tag=1c419779142
To: sipp <sip:sipp@172.22.2.9:5060>;tag=1
Call-ID: 1-29753@172.22.2.9
CSeq: 1 INFO
Contact: <sip:56700@172.22.168.249>
Supported: em,timer,replaces,path,resource-priority
Allow:
REGISTER,OPTIONS,INVITE,ACK,CANCEL,BYE,NOTIFY,PRACK,REFER,INFO
,SUBSCRIBE,UPDATE
User-Agent: Audiocodes-Sip-Gateway/v.6.40A.040.004
Content-Type: application/x-detect
Content-Length: 34
Type= PTT
SubType= SPEECH-START
```

3. Upon detection of the end of voice (i.e., end of the greeting message of the answering machine), the device sends the Application server the following:

```
INFO sip:sipp@172.22.2.9:5060 SIP/2.0
Via: SIP/2.0/UDP 172.22.168.249;branch=z9hG4bKac482466515
Max-Forwards: 70
From: sut <sip:3000@172.22.168.249:5060>;tag=1c419779142
To: sipp <sip:sipp@172.22.2.9:5060>;tag=1
Call-ID: 1-29753@172.22.2.9
CSeq: 1 INFO
Contact: <sip:56700@172.22.168.249>
Supported: em,timer,replaces,path,resource-priority
Allow:
REGISTER,OPTIONS,INVITE,ACK,CANCEL,BYE,NOTIFY,PRACK,REFER,INFO
,SUBSCRIBE,UPDATE
User-Agent: Audiocodes-Sip-Gateway/v.6.40A.040.004
Content-Type: application/x-detect
Content-Length: 34
```

```
Type= PTT
SubType= SPEECH-END
```

4. The Application server now sends its message to the answering message.

If the device detects voice and not an answering machine, the SIP INFO message includes:

```
Type= AMD
SubType= VOICE
```

If the device detects silence, the SIP INFO message includes the SubType **SILENT**.



Note: For information on Syslog fields for AMD, see 'Syslog Fields for Automatic Machine Detection' on page 582.

13.4.2 Automatic Gain Control (AGC)

Automatic Gain Control (AGC) adjusts the energy of the output signal to a required level (volume). This feature compensates for near-far gain differences. AGC estimates the energy of the incoming signal from the IP or PSTN, determined by the 'AGC Redirection' parameter, calculates the essential gain, and then performs amplification. Feedback ensures that the output signal is not clipped. You can configure the required Gain Slope in decibels per second using the 'AGC Slope' parameter and the required signal energy threshold using the 'AGC Target Energy' parameter.

When the AGC first detects an incoming signal, it begins operating in Fast Mode, which allows the AGC to adapt quickly when a conversation starts. This means that the Gain Slope is 8 dB/sec for the first 1.5 seconds. After this period, the Gain Slope is changed to the user-defined value. You can disable or enable the AGC's Fast Mode feature, using the *ini* file parameter AGCDisableFastAdaptation. After Fast Mode is used, the signal should be off for two minutes in order to have the feature turned on again.



Note: AGC is a customer ordered feature and thus, must be included in the Software License Key installed on the device.

The procedure below describes how to configure AGC using the Web interface:

➤ **To configure AGC using the Web interface:**

1. Open the IPMedia Settings page (**Configuration** tab > **VoIP** menu > **Media** submenu > **IPMedia Settings**). The AGC parameters are shown in the figure below:

Figure 13-11: AGC Parameters in IPMedia Settings Page

Enable AGC	Enable
AGC Slope	3
AGC Redirection	0
AGC Target Energy	19

2. Configure the following parameters:
 - 'Enable AGC' (*EnableAGC*) - Enables the AGC mechanism.
 - 'AGC Slope' (*AGCGainSlope*) - Determines the AGC convergence rate.

- 'AGC Redirection' (*AGCRedirection*) - Determines the AGC direction.
 - 'AGC Target Energy' - Defines the signal energy value (dBm) that the AGC attempts to attain.
3. Click **Submit** to apply your settings.



Note: Below are additional AGC parameters:

- AGCMinGain - Defines the minimum gain (in dB) by the AGC when activated
- AGCMaxGain - Defines the maximum gain (in dB) by the AGC when activated.
- AGCDisableFastAdaptation - Enables the AGC Fast Adaptation mode

13.5 Configuring Analog Settings

The Analog Settings page allows you to configure various analog parameters. For a detailed description of the parameters appearing on this page, see 'Configuration Parameters Reference' on page 609.

This page also selects the type (USA or Europe) of FXS and/or FXO coefficient information. The FXS coefficient contains the analog telephony interface characteristics such as DC and AC impedance, feeding current, and ringing voltage.

➤ **To configure the analog parameters:**

1. Open the Analog Settings page (**Configuration** tab > **VoIP** menu > **Media** submenu > **Analog Settings**).

Figure 13-12: Analog Settings Page

FXS_FXO Settings	
⚡ Analog TTX Voltage Level	0.5V
⚡ Analog Metering Type	12 kHz sinusoidal bursts
⚡ Min. Hook-Flash Detection Period [msec]	300
Max. Hook-Flash Detection Period [msec]	700
⚡ FXS Coefficient Type	USA
⚡ FXO Coefficient Type	USA

2. Configure the parameters as required.
3. Click **Submit** to apply your changes.
4. To save the changes to flash memory, see 'Saving Configuration' on page 494.

13.6 Configuring DSP Templates

The DSP Template determines the coders that can be used by the device and various other functionalities. For a list of DSP templates and the maximum number of channels supported by each coder, see 'DSP Templates' on page 839. You can select a single DSP Template.



Notes:

- If no entries are defined, the device uses the default DSP template (i.e., Template 0).
- A single DSP Template can also be configured using the ini file parameter, DSPVersionTemplateName.

➤ To select a DSP Template(s):

1. To use a single DSP Template:
 - a. Open the General Settings page (**Configuration** tab > **VoIP** menu > **Media** > **General Media Settings**).

Figure 13-13: Defining Single DSP Template in General Settings Page

The screenshot shows a web interface for 'General Settings'. Under the 'Media' menu, the 'General Media Settings' page is displayed. A field labeled 'DSP Version Template Number' with a lightning bolt icon on the left contains the value '4'.

- b. In the 'DSP Version Template Number' field, enter the required DSP Template number.
- c. Click **Submit**.
- d. Reset the device with a flash burn for the settings to take effect (see 'Saving Configuration' on page 494).

13.7 DSP Channel Resources for Transcoding

In addition to DSP resources (channels) required for PRI trunk interfaces, the device provides flexibility in making additional DSP resources available for IP-to-IP functionality. This is achieved by the following:

- Obtaining DSP resources from the Media Processing Module (MPM)
- "Borrowing" DSP resources from the PRI interfaces (i.e., TRUNKS module)

DSP channels are required for the following:

- **IP-to-IP application:** Each IP-to-IP call session includes two legs, requiring two DSP resources.



Note: In some scenarios, the IP-to-IP application does not require DSP resources.

To support these capabilities and to allow optimal management of the required DSP resources, you need to ensure suitable hardware and software configuration, as described below:

- **Hardware Configuration:** The device can obtain DSP resources using one of the following hardware configurations:
 - **MPM Modules:** MPM modules provide DSP resources for the IP-to-IP application, and/or IP media for IP media functionality such as IP-based conferencing. The device can house up to three MPM modules. When the MPM modules are installed in chassis slots #3, #4, and #5 (when not used for conferencing), the device supports up to 144 DSP resources (i.e., 72 transcoding sessions), where each module provides up to 48 DSP resources.



Notes:

- If the device is installed with all three MPM modules, no other telephony interface module can be installed in the device.
- It is recommended not to install an MPM module in Slot #6 as this reduces the available channels for transcoding from 40 to 20.

- **TRUNKS (PRI) Modules:** DSP resources can be obtained from installed PRI modules (thereby, "disabling" some trunk span interfaces).



Notes: DSP resources cannot be "borrowed" from span interfaces that use CAS.

- **Combination of MPM and PRI Modules:** DSP resources can be obtained from MPM and PRI modules. For example, to achieve 120 channels (with conferencing), you need to use two MPM modules (installed in slots #5 and #6) and one PRI module providing two PRI spans (installed in Slot #1).
- **Software Configuration:** The device must be configured as follows:
 - Set the MediaChannels parameter to the maximum number of required IP media channels, regardless of the module from where the channels are obtained.



Note: Setting the MediaChannels parameter to a value that is greater than the available DSP resources that is provided by the MPM module(s) can result in the "stealing" of DSP resources from the B-channels of the PRI spans.

- Set the IPmediaChannels parameter to the number of DSP channels that you want to "borrow" (use) from each PRI module for the IP-to-IP application. The setting below shows an example of borrowing DSP channels from PRI modules #1 and #2:

```
[IPMediaChannels]
FORMAT IPMediaChannels_Index = IPMediaChannels_ModuleID,
IPMediaChannels_DSPChannelsReserved;
IPMediaChannels 1 = 1, 15;
IPMediaChannels 2 = 2, 10;
[ \IPMediaChannels ]
```

**Notes:**

- If the device is not installed with an MPM module and you want the device to "borrow" DSP channels from the PRI modules, you must set the EnableIPMediaChannels parameter to 1. This parameter is automatically enabled when the device is installed with an MPM module.
- The value of IPMediaChannels_DSPChannelsReserved must be in multiples of 5.
- By default, the MPM module is set to the maximum number of IP media channels. Therefore, there is no need to define it with the IPmediaChannels parameter.
- By default, the IPMediaChannels_DSPChannelsReserved parameter for all PRI modules is set to 0 (i.e., no "borrowing" of IP media channels).

13.8 Configuring Media Realms

The Media Realm Table page allows you to define a pool of up to 64 SIP media interfaces, termed *Media Realms*. Media Realms allow you to divide a Media-type interface, which is configured in the Multiple Interface table, into several realms, where each realm is specified by a UDP port range. You can also define the maximum number of sessions per Media Realm. Once configured, Media Realms can be assigned to IP Groups (see 'Configuring IP Groups' on page 214) or SRDs (see 'Configuring SRD Table' on page 211).

Once you have configured a Media Realm, you can configure it with the following:

- Quality of Experience parameters for reporting to AudioCodes SEM server used for monitoring the quality of calls (see Configuring Quality of Experience Parameters per Media Realm on page 185)
- Bandwidth management (see 'Configuring Bandwidth Management per Media Realm' on page 188)


**Notes:**

- If different Media Realms are assigned to an IP Group and to an SRD, the IP Group's Media Realm takes precedence.
- For this setting to take effect, a device reset is required.
- The Media Realm table can also be configured using the table ini file parameter, CpMediaRealm.

➤ **To define a Media Realm:**

1. Open the Media Realm Table page (**Configuration** tab > **VoIP** menu > **Media** submenu > **Media Realm Configuration**).
2. Click the **Add** button; the following appears:

Figure 13-14: Media Realm Page - Add Record Dialog Box



3. Configure the parameters as required. See the table below for a description of each parameter
4. Click **Submit** to apply your settings.
5. Reset the device to save the changes to flash memory (see 'Saving Configuration' on page 494).

Media Realm Table Parameter Descriptions

Parameter	Description
Index [CpMediaRealm_Index]	Defines the required table index number.
Media Realm Name [CpMediaRealm_MediaRealmName]	Defines an arbitrary, identifiable name for the Media Realm. The valid value is a string of up to 40 characters. Notes: <ul style="list-style-type: none"> ▪ This parameter is mandatory. ▪ The name assigned to the Media Realm must be unique. ▪ This Media Realm name is used in the SRD and IP Groups table.
IPv4 Interface Name [CpMediaRealm_IPv4IF]	Assigns an IPv4 interface to the Media Realm. This is name of the interface as configured for the Interface Name field in the Multiple Interface table.
Port Range Start [CpMediaRealm_PortRangeStart]	Defines the starting port for the range of Media interface UDP ports. Notes: <ul style="list-style-type: none"> ▪ You must either configure all media realms with port ranges or all without; not some with and some without. ▪ The available UDP port range is calculated using the BaseUDPport parameter: <ul style="list-style-type: none"> ✓ BaseUDPport to BaseUDPport + 255*10 ▪ Port ranges over 60,000 must not be used. ▪ Media Realms must not have overlapping port ranges.

Parameter	Description
Number of Media Session Legs [CpMediaRealm_MediaSessionLeg]	Defines the number of media sessions associated with the range of ports. This is the number of media sessions available in the port range. For example, 100 ports correspond to 10 media sessions, since ports are allocated in chunks of 10.
Port Range End [CpMediaRealm_PortRangeEnd]	Read-only field displaying the ending port for the range of Media interface UDP ports. This field is calculated by adding the 'Media Session Leg' field (multiplied by the port chunk size) to the 'Port Range Start' field. A value appears once a row has been successfully added to the table.
Is Default [CpMediaRealm_IsDefault]	Defines the Media Realm as the default Media Realm. This default Media Realm is used when no Media Realm is configured for an IP Group or SRD for a specific call. <ul style="list-style-type: none"> ▪ [0] No (default) ▪ [1] Yes <p>Notes:</p> <ul style="list-style-type: none"> ▪ This parameter can be set to Yes for only one defined Media Realm. ▪ If this parameter is not configured, then the first Media Realm in the table is used as the default. ▪ If the table is not configured, then the default Media Realm includes all the configured media interfaces.

13.8.1 Configuring Quality of Experience per Media Realm

You can configure Quality of Experience (QoE) per Media Realm. This enables you to monitor and analyze media and signaling traffic, allowing you to detect problems causing service degradation. The device can save call information and statistics at call start, at call end, or at specific changes in the call. The information is stored as call records on an external server. The device connects, as a client, to the server using TLS over TCP.

You can specify the call parameters to monitor and configure their upper and lower thresholds. If these thresholds are exceeded, the device can be configured to do the following:

- Reports the change in the monitored parameter to the monitoring server (default).
- Sends RFC 2198 RTP redundancy packets on the call leg that crossed the threshold. This enables the device to adapt to the changed network status. In this option, you can also configure the redundancy depth. The channel configuration is unchanged if the change requires channel reopening. Currently, this option is applicable only when the monitored parameter is remote packet loss.

The device can be configured to monitor the following parameters on the local (i.e., at the device) or remote side:

- Packet loss
- Mean Opinion Score (MOS)
- Jitter
- Packet delay
- Residual Echo Return Loss (RERL)

At any given time during a call, each of these parameters can be in one of the following states according to its value in the last RTCP / RTCP XR packet:

- Gray - indicates that the value is unknown
- Green - indicates good call quality

- Yellow - indicates medium call quality
- Red - indicates poor call quality

The mapping between the values of the parameters and the color is according to the configured threshold of these parameters, per Media Realm. The call itself also has a state (color), which is the worst-state color of all the monitored parameters. Each time a color of a parameter changes, the device sends a report to the external server. A report is also sent at the end of each call.



Notes:

- The QoE feature is available only if the device is installed with the relevant Software License Key.
- To configure the address of the AudioCodes Session Experience Manager (SEM) server to where the device reports the QoE, see 'Configuring SEM Server for Media Quality of Experience' on page 190.
- You can also configure QoE per Media Realm using the table *ini* file parameter QOERules.

➤ **To configure QoE per Media Realm:**

1. Open the Media Realm Table page (**Configuration** tab > **VoIP** menu > **Media** submenu > **Media Realm Configuration**).
2. Select the Media Realm for which you want to configure Quality of Experience, and then click the **Quality Of Experience** link; the Quality Of Experience page appears.
3. Click the **Add** button; the following dialog box appears:

Figure 13-15: Quality of Experience Page - Add Record Dialog Box

Add Record	
Index	1
Monitored Parameter	MOS
Direction	Device Side
Profile	Low Sensitivity
Green Yellow Threshold	3.4
Green Yellow Hysteresis	0.1
Yellow Red Threshold	2.7
Yellow Red Hysteresis	0.1
Green Yellow Operation	Notify
Green Yellow Operation Details	1
Yellow Red Operation	Notify
Yellow Red Operation Details	1
<input type="button" value="Submit"/> <input type="button" value="Cancel"/>	

The figure above shows value thresholds for the MOS parameter, which are assigned using pre-configured values of the Low Sensitivity profile. In this example setting, if the MOS value changes by 0.1 (hysteresis) to 3.3 or 3.5, the device sends a report to the SEM indicating this change. If the value changes to 3.3, it sends a yellow state (i.e., medium quality); if the value changes to 3.5, it sends a green state.

4. Configure the parameters as required. See the table below for a description of each parameter.
5. Click **Submit** to apply your settings.

Quality of Experience Parameter Descriptions

Parameter	Description
Index [QOERules_RuleIndex]	Defines the table index entry. Up to four table row entries can be configured per Media Realm.
Monitored Parameter [QOERules_MonitoredParam]	Defines the parameter to monitor and report. <ul style="list-style-type: none"> ▪ [0] MOS (default) ▪ [1] Delay ▪ [2] Packet Loss ▪ [3] Jitter ▪ [4] RERL
Direction [QOERules_Direction]	Defines the monitoring direction. <ul style="list-style-type: none"> ▪ [0] Device Side (default) ▪ [1] Remote Side
Profile [QOERules_Profile]	Defines the pre-configured threshold profile to use. <ul style="list-style-type: none"> ▪ [0] No Profile = No profile is used and you need to define the thresholds in the parameters described below. ▪ [1] Low Sensitivity = Automatically sets the thresholds to low sensitivity values. Therefore, reporting is done only if changes in parameters' values is significant. ▪ [2] Default Sensitivity = Automatically sets the thresholds to a medium sensitivity. ▪ [3] High Sensitivity = Automatically sets the thresholds to high sensitivity values. Therefore, reporting is done for small fluctuations in parameters' values.
Green Yellow Threshold [QOERules_GreenYellowThreshold]	Defines the parameter threshold values between green (good quality) and yellow (medium quality) states.
Green Yellow Hysteresis [QOERules_GreenYellowHysteresis]	Defines the hysteresis (fluctuation) for the green-yellow threshold. When the threshold is exceeded by this hysteresis value, the device sends a report to the SEM indicating this change.
Yellow Red Threshold [QOERules_YellowRedThreshold]	Defines the parameter threshold values between yellow (medium quality) and red (poor quality). When this threshold is exceeded, the device sends a report to the SEM indicating this change.
Yellow Red Hysteresis [QOERules_YellowRedHysteresis]	Defines the hysteresis (fluctuation) for the yellow-red threshold. When the threshold is exceeded by this hysteresis value, the device sends a report to the SEM indicating this change.
Green Yellow Operation [QOERules_GreenYellowOperation]	Defines the action that is done if the green-yellow threshold is crossed. <ul style="list-style-type: none"> ▪ [1] Notify = (Default) Device sends a report to the SEM server. ▪ [2] Activate 2198 = RTP redundancy packets are sent to the relevant call leg. <p>Note: This field is applicable only if the monitored parameter is remote packet loss.</p>

Parameter	Description
Green Yellow Operation Details [QOERules_GreenYellowOperationDetails]	<p>Note: This field is currently not supported.</p> <p>Defines the desired RTP redundancy depth. The actual redundancy depth on the relevant call leg is the minimum between the desired depth and the maximum supported depth on that call leg.</p> <p>Note: This field is applicable only if the 'Green Yellow Operation' field is set to Activate 2198.</p>
Yellow Red Operation [QOERules_YellowRedOperation]	<p>Note: This field is currently not supported.</p> <p>Defines the action that is done if the yellow-red threshold is crossed.</p> <ul style="list-style-type: none"> ▪ [1] Notify = (Default) Device sends a report to the SEM server. ▪ [2] Activate 2198 = RTP redundancy packets are sent to the relevant call leg. ▪ Note: This field is applicable only if the monitored parameter is remote packet loss.
Yellow Red Operation Details [QOERules_YellowRedOperationDetails]	<p>Note: This field is currently not supported.</p> <p>Defines the desired RTP redundancy depth. The actual redundancy depth on the relevant call leg is the minimum between the desired depth and the maximum supported depth on that call leg.</p> <p>Note: This field is applicable only if the 'Yellow Red Operation' field is set to Activate 2198.</p>

13.8.2 Configuring Bandwidth Management per Media Realm

Bandwidth management enables you to configure bandwidth utilization thresholds per Media Realm which when exceeded, the device can do one of the following:

- Generate an appropriate SNMP alarm, which is cleared when the bandwidth utilization returns to normal.
- Block any additional calls on the Media Realm.

Bandwidth management includes the following bandwidth utilization states:

- Normal
- High threshold
- Critical threshold

When a transition occurs between two bandwidth threshold states, based on threshold and hysteresis values, the device executes the configured action. The transition possibilities include Normal-High threshold state changes and High-Critical threshold state changes. Thus, up to two thresholds can be configured per Media Realm; one for each state transition.

**Notes:**

- This feature is available only if the device is installed with the relevant Software License Key.
- For your bandwidth management settings to take effect, you must reset the device.
- You can also use the BWManagement *ini* file parameter to configure bandwidth management per Media Realm.

➤ **To configure bandwidth management rules per Media Realm:**

1. Open the Media Realm Table page (**Configuration** tab > **VoIP** menu > **Media** submenu > **Media Realm Configuration**).
2. Select the Media Realm for which you want to configure bandwidth management rules, and then click the **Bandwidth Management** link; the Bandwidth Management page appears.
3. Click the **Add** button; the following dialog box appears:

Figure 13-16: Bandwidth Management Page - Add record Dialog Box

The figure above shows an example where if the bandwidth for this Media Realm reaches 41,000 Bps (i.e., 40,000 plus 1,000 hysteresis), the device blocks any additional calls. If the bandwidth later decreases to 39,000 Bps (i.e., 40,000 minus 1,000 hysteresis), the device allows additional calls.

4. Configure the parameters as required. See the table below for a description of each parameter.
5. Click **Submit** to apply your settings.
6. Reset the device for your settings to take effect.

Bandwidth Management Parameter Descriptions

Parameter	Description
Index BWManagement_ThresholdIndex]	Defines the index of the table row entry. This index determines the bandwidth threshold type for the rule: <ul style="list-style-type: none"> ▪ [0] High Threshold Rule ▪ [1] Critical Threshold Rule
Rule Action [BWManagement_RuleAction]	Defines the action that the device performs when the configured threshold is exceeded: <ul style="list-style-type: none"> ▪ [0] Report Only (default) ▪ [1] No more calls

Parameter	Description
Threshold [BWManagement_Threshold]	Defines the bandwidth threshold in bytes per second (Bps). The default is 0.
Hysteresis [BWManagement_Hysteresis]	Defines the bandwidth fluctuation (change) from the threshold value at which the device performs the configured action. The default is 0.

13.9 Configuring Server for Media Quality of Experience

The device can be configured to report voice (media) quality of experience to AudioCodes Session Experience Manager (SEM) server, a plug-in for AudioCodes EMS. The reports include real-time metrics of the quality of the actual call experience and processed by the SEM.



Notes:

- To support this feature, the device must be installed with the relevant Software License Key.
- To configure the parameters to report and their thresholds per Media Realm, see 'Configuring Quality of Experience per Media Realm' on page 185.
- For information on the SEM server, refer to the *EMS User's Manual*.

➤ **To configure QoE reporting of media:**

1. Open the Media Quality of Experience page (**Configuration** tab > **VoIP** menu > **Media** submenu > **Media Quality of Experience**).

Figure 13-17: Media Quality of Experience Page

Quality of Experience	
⚡ Server Ip	0.0.0.0
Port	5000
⚡ Interface Name	DEFAULT
Connection Mode	VQMClient
Information Level	VQStandard
Use Mos LQ	Disable

2. Configure the parameters as required
 - 'Server Ip' (QOEServerIP) - defines the IP address of the SEM server
 - 'Port' (QOEPort) - defines the port of the SEM server
 - 'Interface Name' (QOEInterfaceName) - defines the device's IP network interface on which the SEM reports are sent
 - 'Use Mos LQ' (QOEUseMosLQ) - defines the reported MOS type (listening or conversational)
3. Click **Submit** to apply your changes.
4. To save the changes to flash memory, see 'Saving Configuration' on page 494.

13.10 Configuring Media Security

The device supports Secured RTP (SRTP) according to RFC 3711. SRTP is used to encrypt RTP and RTCP transport for protecting VoIP traffic. SRTP requires a key exchange mechanism that is performed according to RFC 4568 – “Session Description Protocol (SDP) Security Descriptions for Media Streams”. The key exchange is done by adding a 'crypto' attribute to the SDP. This attribute is used (by both sides) to declare the various supported cipher suites and to attach the encryption key. If negotiation of the encryption data is successful, the call is established.

SRTP supports the following cipher suites (all other suites are ignored):

- AES_CM_128_HMAC_SHA1_32
- AES_CM_128_HMAC_SHA1_80

When the device is the offering side, it generates an MKI of a size configured by the 'Master Key Identifier (MKI) Size' parameter. The length of the MKI is limited to four bytes. If the remote side sends a longer MKI, the key is ignored. The key lifetime field is not supported. However, if it is included in the key it is ignored and the call does not fail.

The device supports the following session parameters (as defined in RFC 4568, SDP Security Descriptions for Media Streams):

- UNENCRYPTED_SRTP
- UNENCRYPTED_SRTCP
- UNAUTHENTICATED_SRTP

Session parameters should be the same for the local and remote sides. When the device is the offering side, the session parameters are configured by the following parameter - 'Authentication On Transmitted RTP Packets', 'Encryption On Transmitted RTP Packets, and 'Encryption On Transmitted RTCP Packets'. When the device is the answering side, the device adjusts these parameters according to the remote offering. Unsupported session parameters are ignored, and do not cause a call failure.

Below is an example of crypto attributes usage:

```
a=crypto:1 AES_CM_128_HMAC_SHA1_80
inline:PsKoMpHlCg+b5X0YLuSvNrImEh/dAe
a=crypto:2 AES_CM_128_HMAC_SHA1_32
inline:IsPtLoGkBf9a+c6XVzRuMqHlDnEiAd
```

The device also supports symmetric MKI negotiation, whereby it can be configured to forward the MKI size received in the SDP offer crypto line in the SDP answer crypto line.

To configure the device's mode of operation if negotiation of the cipher suite fails, use the 'Media Security Behavior' parameter. This parameter can be set to enforce SRTP, whereby incoming calls that don't include encryption information are rejected.



Notes:

- For a detailed description of the SRTP parameters, see SRTP Parameters on page 637.
- When SRTP is used, the channel capacity may be reduced.

➤ **To configure media security:**

1. Open the Media Security page (**Configuration** tab > **VoIP** menu > **Media** submenu > **Media Security**).

General Media Security Settings	
Media Security	Disable
Media Security Behavior	Preferable
Authentication On Transmitted RTP Packets	Active
Encryption On Transmitted RTP Packets	Active
Encryption On Transmitted RTCP Packets	Active
SRTP Setting	
Master Key Identifier (MKI) Size	0
Enable symmetric MKI negotiation	Disable
SRTP offered Suites	
CIPHER SUITES AES CM 128 HMAC SHA1 80	<input checked="" type="checkbox"/>
CIPHER SUITES AES CM 128 HMAC SHA1 32	<input checked="" type="checkbox"/>
CIPHER SUITES ARIA CM 128 HMAC SHA1 80	<input checked="" type="checkbox"/>
CIPHER SUITES ARIA CM 192 HMAC SHA1 80	<input checked="" type="checkbox"/>

2. Configure the parameters as required.
3. Click **Submit** to apply your changes.
4. To save the changes to flash memory, see 'Saving Configuration' on page [494](#).

14 Services

This section describes configuration for various supported services.

14.1 Routing Based on LDAP Active Directory Queries

The device supports Lightweight Directory Access Protocol (LDAP), enabling call routing decisions based on information stored on a third-party LDAP server (or Microsoft's Active Directory™ enterprise directory server). This feature enables the usage of a single common, popular database to manage and maintain information regarding user's availability, presence, and location.

14.1.1 Configuring the LDAP Server

The basic LDAP mechanism is described below:

- **Connection:** The device connects and binds to the remote LDAP server either during the service's initialization (at device start-up) or whenever the LDAP server's IP address and port is changed. Service makes 10 attempts to connect and bind to the remote LDAP server with a timeout of 20 seconds between attempts. If connection fails, the service remains in disconnected state until either the LDAP server's IP address or port is changed.

If connection to the LDAP server later fails, the service attempts to reconnect, as described previously. The SNMP alarm `acLDAPLostConnection` is sent when connection is broken. Upon successful reconnection, the alarm is cleared.

Binding to the LDAP server can be anonymous or not. For anonymous binding, the `LDAPBindDN` and `LDAPPassword` parameters must not be defined or set to an empty string.

The address of the LDAP server can be a DNS name / FQDN configured by the `LDAPServerDomainName` parameter, or an IP address configured by the `LDAPServerIP` parameter.



Note: If you configure an FQDN, make sure that the `LDAPServerIP` parameter is left empty.

- **Search:** For the device to run a search using the LDAP service, the path to the directory's subtree (or DN) where the search is to be done must be configured using the `LDAPSearchDN` parameter. Up to three DNs can be configured. The search key, or *filter* in LDAP references, which defines the exact DN to be found and one or more attributes whose values should be returned, must also be defined.

If connection to the LDAP server is disrupted during the search, all search requests are dropped and an alarm indicating a failed status is sent to client applications.

The LDAP Settings page is used for configuring the LDAP server parameters. For a full description of these parameters, see 'Configuration Parameters Reference' on page 609.

➤ **To configure the LDAP server parameters:**

1. Open the LDAP Settings page (**Configuration** tab > **VoIP** menu > **Services** submenu > **LDAP Settings**).

Figure 14-1: LDAP Settings Page

LDAP Server Status	Connection Broken
⚡ LDAP Service	Disable
LDAP Server IP	0.0.0.0
LDAP Server Port	389
LDAP Server Max Respond Time	3000
LDAP Server Domain Name	
LDAP Search Dn	
LDAP Password	•••••
LDAP Bind DN	

The read-only 'LDAP Server Status' field displays one of the following possibilities:

- "Not Applicable"
 - "Connection Broken"
 - "Connecting"
 - "Connected"
2. Configure the parameters as required.
 3. Click **Submit** to apply your changes.
 4. To save the changes to flash memory, see 'Saving Configuration' on page 494.


14.1.2 Configuring the Device's LDAP Cache

The device provides an option for storing recent LDAP queries and responses in its local cache. The cache is used for subsequent queries and/or in case of LDAP server failure. The advantage of enabling this feature includes the following:

- Improves routing decision performance by using local cache for subsequent LDAP queries
- Reduces number of queries performed on an LDAP server and corresponding bandwidth consumption
- Provides partial survivability in case of intermittent LDAP server failure (or network isolation)

The handling of LDAP queries with the LDAP cache is shown in the flowchart below:

Figure 14-2: LDAP Query Process with Local LDAP Cache



The LDAP Settings page is used for configuring the LDAP cache parameters.




Notes:

- The LDAP cache parameters are available only if you have enabled the LDAP service (see 'Configuring the LDAP Server' on page 193).
- If on the first LDAP query, the result fails for at least one attribute and is successful for at least one, the partial result is cached. However, for subsequent queries, the device does not use the partially cached result, but does a new query with the LDAP server again.
- For a full description of the cache parameters, see 'Configuration Parameters Reference' on page 609.

➤ **To configure the LDAP cache parameters:**

1. Open the LDAP Settings page (**Configuration** tab > **VoIP** menu > **Services** submenu > **LDAP Settings**).

Figure 14-3: LDAP Settings Page - Cache Parameters



The screenshot shows the LDAP Settings page with the following configuration options:

LDAP Cache	
LDAP Cache Service	Enable
LDAP Cache Entry Timeout	1200
LDAP Cache Entry Removal Timeout	0

LDAP Cache Actions	
LDAP Refresh Cache By Key	<input type="text"/> <input type="button" value="Refresh"/>
LDAP Clear All Cache	<input type="button" value="Clear All"/>

2. Configure the parameters as required.
3. Click **Submit** to apply your changes.
4. To save the changes to flash memory, see 'Saving Configuration' on page 494.

The LDAP Settings page also provides you with the following buttons:

- **LDAP Refresh Cache By Key:** Refreshes a saved LDAP entry response in the cache of a specified LDAP search key. If a request with the specified key exists in the cache, the request is resent to the LDAP server.
- **LDAP Clear All Cache:** Removes all LDAP entries in the cache.

14.1.3 Active Directory based Tel-to-IP Routing for Microsoft Lync

Typically, enterprises wishing to deploy Microsoft® Lync™ Server 2010 (formerly known as Office Communication Server 2007) are faced with a complex, call routing dial plan when migrating users from their existing PBX or IP PBX to the Lync Server 2010 platform. As more and more end-users migrate to the new voice system, dialing plan management and PBX link capacity can be adversely impacted. To resolve this issue, enterprises can employ Microsoft's Active Directory (AD), which provides a central database to manage and maintain information regarding user's availability, presence, and location.

The device supports Tel-to-IP call routing decisions based on information stored on the AD. Based on queries sent to the AD, the device can route the Tel call to one of the following IP domains:

- Lync client (formally OCS) - users connected to Lync Server 2010 through the Mediation Server
- PBX or IP PBX - users not yet migrated to Lync Server 2010
- Mobile - mobile number
- Private - private telephone line for Lync users (in addition to the primary telephone line)

14.1.3.1 Querying the AD and Routing Priority

The device queries the AD using the initial destination number (i.e., called number). The query can return up to four user phone numbers, each pertaining to one of the IP domains (i.e., private number, Lync / OCS number, PBX / IP PBX number, and mobile number). The configuration parameters listed in the table below are used to configure the query attribute keys that defines the AD attribute that you wish to query in the AD:

Parameters for Configuring Query Attribute Key

Parameter	Queried User Domain (Attribute) in AD	Query or Query Result Example
MSLDAPPBXNumAttributeName	PBX or IP PBX number (e.g., "telephoneNumber" - default)	telephoneNumber=+3233554447
MSLDAPOCSNumAttributeName	Mediation Server / Lync client number (e.g., "msRTCSIP-line")	msRTCSIP-line=john.smith@company.com
MSLDAPMobileNumAttributeName	Mobile number (e.g., "mobile")	mobile=+3247647156
MSLDAPPrivateNumAttributeName	Any attribute (e.g., "msRTCSIP-PrivateLine") Note: Used only if set to same value as Primary or Secondary key.	msRTCSIP-PrivateLine=+3233554480
MSLDAPPrimaryKey	Primary Key query search instead of PBX key - can be any AD attribute	msRTCSIP-PrivateLine=+3233554480
MSLDAPSecondaryKey	Secondary Key query key search if Primary Key fails - can be any attribute	-

The process for querying the AD and subsequent routing based on the query results is as follows:

1. If the Primary Key is configured, it uses the defined string as a primary key instead of the one defined in MSLDAPPBXNumAttributeName. It requests the attributes which are described below.
2. If the primary query is not found in the AD and the Secondary Key is configured, it does a second query for the destination number using a second AD attribute key name, configured by the MSLDAPSecondaryKey parameter.
3. If none of the queries are successful, it routes the call to the original dialed destination number according to the routing rule matching the "LDAP_ERR" destination prefix number value, or rejects the call with a SIP 404 "Not Found" response.
4. For each query (primary or secondary), it requests to query the following attributes (if they're not configured as an empty string):
 - MSLDAPPBXNumAttributeName
 - MSLDAPOCSNumAttributeName
 - MSLDAPMobileNumAttributeName

In addition, it queries the special attribute defined in MSLDAPPrivateNumAttributeName, only if the query key (primary or secondary) is equal to its value.

5. If the query is found: The AD returns up to four attributes - Lync / OCS, PBX / IP PBX, private (only if it equals Primary or Secondary key), and mobile.

6. The device adds unique prefix keywords to the query results in order to identify the query type (i.e., IP domain). These prefixes are used as the prefix destination number value in the Outbound IP Routing table to denote the IP domains:
- "PRIVATE" (PRIVATE:<private_number>): used to match a routing rule based on query results of the private number (MSLDAPPrivateNumAttributeName)
 - "OCS" (OCS:<Lync_number>): used to match a routing rule based on query results of the Lync client number (MSLDAPOCSNumAttributeName)
 - "PBX" (PBX:<PBX_number>): used to match a routing rule based on query results of the PBX / IP PBX number (MSLDAPPBXNumAttributeName)
 - "MOBILE" (MOBILE:<mobile_number>): used to match a routing rule based on query results of the mobile number (MSLDAPMobileNumAttributeName)
 - "LDAP_ERR": used to match a routing rule based on a failed query result when no attribute is found in the AD



Note: These prefixes are involved only in the routing and manipulation processes; they are not used as the final destination number.


7. The device uses the Outbound IP Routing table to route the call based on the LDAP query result. The device routes the call according to the following priority:
1. **Private line:** If the query is done for the private attribute and it's found, then the device routes the call according to this attribute.
 2. **Mediation Server SIP address (Lync / OCS):** If the private attribute does not exist or is not queried, then the device routes the call to the Mediation Server (which then routes the call to the Lync client).
 3. **PBX / IP PBX:** If the Lync / OCS client is not found in the AD, it routes the call to the PBX / IP PBX.
 4. **Mobile number:** If the Lync / OCS client (or Mediation Server) is unavailable (e.g., SIP response 404 "Not Found" upon INVITE sent to Lync client), and the PBX / IP PBX is also unavailable, then the device routes the call to the user's mobile number (if exists in the AD).
 5. **Alternative route:** If the call routing to all the above fails (e.g., due to unavailable destination - call busy), the device can route the call to an alternative destination if an alternative routing rule is configured.
 6. **"Redundant" route:** If the query failed (i.e., no attribute found in the AD), the device uses the routing rule matching the "LDAP_ERR" prefix destination number value.



Note: For Enterprises implementing a PBX / IP PBX system, but yet to migrate to Lync Server 2010, if the PBX / IP PBX system is unavailable or has failed, the device uses the AD query result for the user's mobile phone number, routing the call through the PSTN to the mobile destination.

The flowchart below summarizes the device's process for querying the AD and routing the call based on the query results:

Figure 14-4: LDAP Query Flowchart



Note: If you are using the device's local LDAP cache, see 'Configuring the Device's LDAP Cache' on page 194 for the LDAP query process.

14.1.3.2 Configuring AD-Based Routing Rules

The procedure below describes how to configure Tel-to-IP routing based on LDAP queries.

- **To configure LDAP-based Tel-to-IP routing for Lync Server 2010:**
- 1. Configure the LDAP server parameters, as described in 'Configuring the LDAP Server' on page 193.
- 2. Configure the AD attribute names used in the LDAP query:
 - a. Open the Advanced Parameters page (**Configuration** tab > **VoIP** menu > **SIP Definitions** submenu > **Advanced Parameters**).

Figure 14-5: LDAP Parameters for Microsoft Lync Server 2010

▼ MS LDAP Settings	
MS LDAP OCS Number attribute name	msRTCSIP-PrimaryUserAddress
MS LDAP PBX Number attribute name	telephoneNumber
MS LDAP MOBILE Number attribute name	mobile

- b. Configure the LDAP attribute names as desired.

3. Configure AD-based Tel-to-IP routing rules:
 - a. Open the Outbound IP Routing Table page (Configuration tab > VoIP menu > GW and IP to IP submenu > Routing > Tel to IP Routing). For more information, see [Configuring Outbound IP Routing Table](#) on page 323.
 - b. Configure query-result routing rules for each IP domain (private, PBX / IP PBX, Lync / OCS clients, and mobile), using the LDAP keywords (case-sensitive) for the prefix destination number:
 - ◆ PRIVATE: Private number
 - ◆ OCS: Lync / OCS client number
 - ◆ PBX: PBX / IP PBX number
 - ◆ MOBILE: Mobile number
 - ◆ LDAP_ERR: LDAP query failure
 - c. Configure a routing rule for routing the initial Tel call to the LDAP server, using the value "LDAP" for denoting the IP address of the LDAP server.
 - d. For alternative routing, enable the alternative routing mechanism and configure corresponding SIP reasons for alternative routing. For this feature, alternative routing starts from the table row located under the LDAP query row.

The table below shows an example for configuring AD-based Tel-to-IP routing rules in the Outbound IP Routing Table:

AD-Based Tel-to-IP Routing Rule Configuration Examples

Index	Dest. Phone Prefix	Dest. IP Address
1	PRIVATE:	10.33.45.60
2	PBX:	10.33.45.65
3	OCS:	10.33.45.68
4	MOBILE:	10.33.45.100
5	LDAP_ERR	10.33.45.80
6	*	LDAP
7	*	10.33.45.72

The configured routing rule example is explained below:

- **Rule 1:** Sends call to private telephone line (at 10.33.45.60) upon successful AD query result for the private attribute.
- **Rule 2:** Sends call to IP PBX (at 10.33.45.65) upon successful AD query result for the PBX attribute.
- **Rule 3:** Sends call to Lync client (i.e., Mediation Server at 10.33.45.68) upon successful AD query result for the Lync attribute.
- **Rule 4:** Sends call to user's mobile phone number (to PSTN through the device's IP address at 10.33.45.100) upon successful AD query result for the Mobile attribute.
- **Rule 5:** Sends call to IP address of device (10.33.45.80) if AD query failure (e.g., no response from LDAP server or attribute not found).

- **Rule 6:** Sends query for original destination number of received call to the LDAP server.
- **Rule 7:** Alternative routing rule that sends the call of original dialed number to IP destination 10.33.45.72. This rule is applied in any of the following cases
 - LDAP functionality is disabled.
 - LDAP query is successful but call fails (due to, for example, busy line) to all the relevant attribute destinations (private, Lync, PBX, and mobile), and a relevant Tel-to-IP Release Reason (see Alternative Routing for Tel-to-IP Calls on page 336) has been configured.

Once the device receives the original incoming call, the first rule that it uses is Rule 6, which queries the AD server. When the AD replies, the device searches the table, from the first rule down, for the matching destination phone prefix (i.e., "PRIVATE:", "PBX:", "OCS:", "MOBILE:", and "LDAP_ERR:"), and then sends the call to the appropriate destination.

14.1.3.3 Querying the AD for Calling Name

The device can be configured to retrieve the calling name (display name) from Microsoft Active Directory (AD) for Tel-to-IP calls that are received without a calling name. The device queries the AD, based on the Calling Number search key and searches for the calling name attribute configured by the parameter, MSLDAPDisplayNameAttrName (e.g., "displayName"). The device uses the resultant calling name as the display name in the SIP From header of the sent INVITE message.

To configure this feature, the following keywords are used in the Calling Name Manipulation Table for Tel -> IP Calls table for the 'Prefix/Suffix to Add' fields, which can be combined with other characters:

- "\$LDAP-PBX": starts LDAP query using the MSLDAPPBXAttrName parameter as the search key
- "\$LDAP-MOBILE": starts LDAP query using MSLDAPMobileAttrName parameter as the search key

If the source (calling) number of the Tel-to-IP call matches the PBX / MOBILE (e.g., "telephoneNumber" and "mobile") number in the AD server, the device uses the resultant Display Name instead of the keyword(s).

For example, assume the following configuration in the Calling Name Manipulation Table for Tel -> IP Calls:

- 'Source Prefix' field is set to "4".
- 'Prefix to Add' field is set to "\$LDAP-PBX Office".

If the calling number is 4046 and the resultant LDAP query display name is "John Doe", the device sends the INVITE message with the following From header:

```
From: John Doe <sip:4064@company.com>\
```



Notes:

- The Calling Name Manipulation Table for Tel -> IP Calls table uses the numbers before manipulation, as inputs.
- The LDAP query uses the calling number after source number manipulation, as the search key value.

14.2 Least Cost Routing

This section provides a description of the device's least cost routing (LCR) feature and how to configure it.

14.2.1 Overview

The LCR feature enables the device to choose the outbound IP destination routing rule based on lowest call cost. This is useful in that it enables service providers to optimize routing costs for customers. For example, you may wish to define different call costs for local and international calls, or different call costs for weekends and weekdays (specifying even the time of call). The device sends the calculated cost of the call to a Syslog server (as Information messages), thereby enabling billing by third-party vendors.

LCR is implemented by defining Cost Groups and assigning them to routing rules in the Outbound IP Routing table. The device searches this routing table for matching routing rules, and then selects the rule with the lowest call cost. If two routing rules have identical costs, then the rule appearing higher up in the table is used (i.e., first-matched rule). If a selected route is unavailable, the device selects the next least-cost routing rule. However, even if a matched rule is not assigned a Cost Group, the device can select it as the preferred route over other matched rules with Cost Groups. This is determined according to the settings of the Default Cost parameter in the Routing Rule Groups table.

The Cost Group defines a fixed connection cost (*connection cost*) and a charge per minute (*minute cost*). Cost Groups can also be configured with time segments (*time bands*), which define connection cost and minute cost based on specific days of the week and time of day (e.g., from Saturday through Sunday, between 6:00 and 18:00). If multiple time bands are configured per Cost Group and a call spans multiple time bands, the call cost is calculated using only the time band in which the call was initially established.

In addition to Cost Groups, the device can calculate the call cost using an optional, user-defined average call duration value. The logic in using this option is that a Cost Group may be cheap if the call duration is short, but due to its high minute cost, may prove very expensive if the duration is lengthy. Thus, together with Cost Groups, the device can use this option to determine least cost routing. The device calculates the Cost Group call cost as follows: $\text{Total Call Cost} = \text{Connection Cost} + (\text{Minute Cost} * \text{Average Call Duration})$.

The below table shows an example of call cost when taking into consideration call duration. This example shows four defined Cost Groups and the total call cost if the average call duration is 10 minutes:

Call Cost Comparison between Cost Groups for different Call Durations

Cost Group	Connection Cost	Minute Cost	Total Call Cost per Duration	
			1 Minute	10 Minutes
A	1	6	7	61
B	0	10	10	100
C	0.3	8	8.3	80.3
D	6	1	7	16

If four matching routing rules are located in the routing table and each one is assigned a different Cost Group as listed in the table above, then the rule assigned Cost Group "D" is selected. Note that for one minute, Cost Groups "A" and "D" are identical, but due to the average call duration, Cost Group "D" is cheaper. Therefore, average call duration is an important factor in determining the cheapest routing role.

Below are a few examples of how you can implement LCR:

- **Example 1:** This example uses two different Cost Groups for routing local calls and international calls:

Two Cost Groups are configured as shown below:

Cost Group	Connection Cost	Minute Cost
1. "Local Calls"	2	1
2. "International Calls"	6	3

The Cost Groups are assigned to routing rules for local and international calls in the Outbound IP Routing table:

Routing Index	Dest Phone Prefix	Destination IP	Cost Group ID
1	2000	x.x.x.x	1 "Local Calls"
2	00	x.x.x.x	2 "International Calls"

- **Example 2:** This example shows how the device determines the cheapest routing rule in the Outbound IP Routing table:

The Default Cost parameter (global) in the Routing Rule Groups table is set to **Min**, meaning that if the device locates other matching LCR routing rules (with Cost Groups assigned), the routing rule without a Cost Group is considered the lowest cost route.

- The following Cost Groups are configured:

Cost Group	Connection Cost	Minute Cost
1. "A"	2	1
2. "B"	6	3

- The Cost Groups are assigned to routing rules in the Outbound IP Routing table:

Routing Index	Dest Phone Prefix	Destination IP	Cost Group ID
1	201	x.x.x.x	"A"
2	201	x.x.x.x	"B"
3	201	x.x.x.x	0
4	201	x.x.x.x	"B"

The device calculates the optimal route in the following index order: 3, 1, 2, and then 4, due to the following logic:

- Index 1 - Cost Group "A" has the lowest connection cost and minute cost
- Index 2 - Cost Group "B" takes precedence over Index 4 entry based on the first-matched method rule
- Index 3 - no Cost Group is assigned, but as the Default Cost parameter is set to **Min**, it is selected as the cheapest route
- Index 4 - Cost Group "B" is only second-matched rule (Index 1 is the first)


- Example 3:** This example shows how the cost of a call is calculated if the call spans over multiple time bands:

Assume a Cost Group, "CG Local" is configured with two time bands, as shown below:

Cost Group	Time Band	Start Time	End Time	Connection Cost	Minute Cost
CG Local	TB1	16:00	17:00	2	1
	TB2	17:00	18:00	7	2

Assume that the call duration is 10 minutes, occurring between 16:55 and 17:05. In other words, the first 5 minutes occurs in time band "TB1" and the next 5 minutes occurs in "TB2", as shown below:

Figure 14-6: LCR using Multiple Time Bands (Example)



The device calculates the call using the time band in which the call was initially established, regardless of whether the call spans over additional time bands:

$$\text{Total call cost} = \text{"TB1" Connection Cost} + (\text{"TB1" Minute Cost} \times \text{call duration}) = 2 + 1 \times 10 \text{ min} = 12$$

14.2.2 Configuring LCR

The following main steps need to be done to configure LCR:

1. Enable the LCR feature and configure the average call duration and default call connection cost - see 'Enabling LCR and Configuring Default LCR' on page 204.
2. Configure Cost Groups - see 'Configuring Cost Groups' on page 206.
3. Configure Time Bands for a Cost Group - see 'Configuring Time Bands for Cost Groups' on page 207.
4. Assign Cost Groups to outbound IP routing rules - see 'Assigning Cost Groups to Routing Rules' on page 208.

14.2.2.1 Enabling the LCR Feature

The procedure below describes how to enable the LCR feature. This also includes configuring the average call duration and default call cost for routing rules that are not assigned Cost Groups in the Outbound IP Routing table.



Note: The Routing Rule Groups table can also be configured using the table ini file parameter, RoutingRuleGroups.

➤ **To enable LCR:**

1. Open the Routing Rule Groups Table page (**Configuration** tab > **VoIP** menu > **Services** submenu > **Least Cost Routing** > **Routing Rule Groups Table**).
2. Click the **Add** button; the Add Record dialog box appears:

Figure 14-7: Routing Rule Groups Table - Add Record

3. Configure the parameters as required. For a description of the parameters, see the table below.
4. Click **Submit**; the entry is added to the Routing Rule Groups table.

Routing Rule Groups Table Description

Parameter	Description
Index [RoutingRuleGroups_Index]	Defines the table index entry. Note: Only one index entry can be configured.
LCR Enable [RoutingRuleGroups_LCREnable]	Enables the LCR feature: <ul style="list-style-type: none"> ▪ [0] Disabled (default) ▪ [1] Enabled
LCR Call Length [RoutingRuleGroups_LCRAverageCallLength]	Defines the average call duration (in minutes) and is used to calculate the variable portion of the call cost. This is useful, for example, when the average call duration spans over multiple time bands. The LCR is calculated as follows: cost = call connect cost + (minute cost * average call duration) The valid value range is 0-65533. The default is 1. For example, assume the following Cost Groups: <ul style="list-style-type: none"> ▪ "Weekend A": call connection cost is 1 and charge per minute is 6. Therefore, a call of 1 minute cost 7 units. ▪ "Weekend_B": call connection cost is 6 and charge per minute is 1. Therefore, a call of 1 minute cost 7 units. Therefore, for calls under one minute, "Weekend A" carries the lower cost. However, if the average call duration is more than one minute, then "Weekend B" carries the lower cost.

Parameter	Description
Default Cost [RoutingRuleGroups_L CRDefaultCost]	<p>Determines whether routing rules in the Outbound IP Routing table without an assigned Cost Group are considered a higher cost or lower cost route compared to other matched routing rules that are assigned Cost Groups.</p> <ul style="list-style-type: none"> ▪ [0] Lowest Cost = If the device locates other matching LCR routing rules, this routing rule is considered the lowest cost route and therefore, it is selected as the route to use (default.) ▪ [1] Highest Cost = If the device locates other matching LCR routing rules, this routing rule is considered as the highest cost route and therefore, is not used or used only if the other cheaper routes are unavailable. <p>Note: If more than one valid routing rule without a defined Cost Group exists, the device selects the first-matched rule.</p>

14.2.2.2 Configuring Cost Groups

The procedure below describes how to configure Cost Groups. Cost Groups are defined with a fixed call connection cost and a call rate (charge per minute). Once configured, you can configure Time Bands for each Cost Group. Up to 10 Cost Groups can be configured.



Note: The Cost Group table can also be configured using the table ini file parameter, CostGroupTable.

➤ **To configure Cost Groups:**

1. Open the Cost Group Table page (**Configuration** tab > **VoIP** menu > **Services** submenu > **Least Cost Routing** > **Cost Group Table**).
2. Click the **Add** button; the Add Record dialog box appears:

3. Configure the parameters as required. For a description of the parameters, see the table below.
4. Click **Submit**; the entry is added to the Cost Group table.

Cost Group Table Description

Parameter	Description
Index [CostGroupTable_Inde x]	Defines the table index entry.

Parameter	Description
Cost Group Name [CostGroupTable_CostGroupName]	Defines an arbitrary name for the Cost Group. The valid value is a string of up to 30 characters. Note: Each Cost Group must have a unique name.
Default Connect Cost [CostGroupTable_DefaultConnectionCost]	Defines the call connection cost (added as a fixed charge to the call) for a call outside the time bands. The valid value range is 0-65533. The default is 0. Note: When calculating the cost of a call, if the current time of the call is not within a time band configured for the Cost Group, then this default connection cost is used.
Default Time Cost [CostGroupTable_DefaultMinuteCost]	Defines the call charge per minute for a call outside the time bands. The valid value range is 0-65533. The default is 0. Note: When calculating the cost of a call, if the current time of the call is not within a time band configured for the Cost Group, then this default charge per minute is used.

14.2.2.3 Configuring Time Bands for Cost Groups

The procedure below describes how to configure Time Bands for a Cost Group. The time band defines the day and time range for which the time band is applicable (e.g., from Saturday 05:00 to Sunday 24:00) as well as the fixed call connection charge and call rate per minute for this interval. Up to 70 time bands can be configured, and up to 21 time bands can be assigned to each Cost Group.



Notes:

- You cannot define overlapping time bands.
- The Time Band table can also be configured using the table ini file parameter, CostGroupTimebands.

➤ To configure Time Bands for a Cost Group:

1. Open the Cost Group Table page (**Configuration** tab > **VoIP** menu > **Services** submenu > **Least Cost Routing** > **Cost Group Table**).
2. Select a Cost Group for which you want to assign Time Bands, and then click the **Time Band** link located below the table; the Time Band table for the selected Cost Group appears.
3. Click the **Add** button; the Add Record dialog box appears:

4. Configure the parameters as required. For a description of the parameters, see the table below.
5. Click **Submit**; the entry is added to the Time Band table for the relevant Cost Group.

Time Band Table Description

Parameter	Description
Index [CostGroupTimebands _TimebandIndex]	Defines the table index entry.
Start Time [CostGroupTimebands _StartTime]	Defines the day and time of day from when this time band is applicable. The format is ddd:hh:mm (e.g., sun:06:00), where: <ul style="list-style-type: none"> ▪ <i>ddd</i> is the day (i.e., sun, mon, tue, wed, thu, fri, or sat) ▪ <i>hh</i> and <i>mm</i> denote the time of day, where <i>hh</i> is the hour (00-23) and <i>mm</i> the minutes (00-59)
End Time [CostGroupTimebands _EndTime]	Defines the day and time of day until when this time band is applicable. For a description of the valid values, see the parameter above.
Connection Cost [CostGroupTimebands _ConnectionCost]	Defines the call connection cost during this time band. This is added as a fixed charge to the call. The valid value range is 0-65533. The default is 0. Note: The entered value must be a whole number (i.e., not a decimal).
Minute Cost [CostGroupTimebands _MinuteCost]	Defines the call cost per minute charge during this timeband. The valid value range is 0-65533. The default is 0. Note: The entered value must be a whole number (i.e., not a decimal).

14.2.2.4 Assigning Cost Groups to Routing Rules

Once you have configured your Cost Groups, you need to assign them to routing rules in the Outbound IP Routing table - see Configuring Outbound IP Routing Table on page 323.

15 Enabling Applications

The device supports the following main applications:

- Stand-Alone Survivability (SAS) application
- IP-to-IP application

The procedure below describes how to enable these applications. Once an application is enabled, the Web GUI provides menus and parameter fields relevant to the application.



Notes:

- This page displays the application only if the device is installed with the relevant Software License Key supporting the application (see 'Loading Software License Key' on page 522).
- The IP-to-IP application is applicable only to Mediant 1000.
- For configuring the SAS application, see 'Stand-Alone Survivability (SAS) Application' on page 415.
- For an overview of the IP-to-IP application and configuration examples, see IP-to-IP Routing Application on page 255.
- For enabling an application, a device reset is required.

➤ To enable an application:

1. Open the Applications Enabling page (**Configuration** tab > **VoIP** menu > **Applications Enabling** submenu > **Applications Enabling**).

⚡ SAS Application	Enable	▼
⚡ IP to IP Application	Disable	▼

2. From the relevant application drop-down list, select **Enable**.
3. Save (burn) the changes to the device's flash memory with a device reset (see 'Saving Configuration' on page 494).

Reader's Notes

16 Control Network

This section describes configuration of the network at the SIP control level.

16.1 Configuring SRD Table

The SRD Settings page allows you to configure up to 32 signaling routing domains (SRD). An SRD is configured with a unique name and assigned a Media Realm.

An SRD is a set of definitions together creating multiple, virtual multi-service IP gateways:

- Multiple and different SIP signaling interfaces (SRD associated with a SIP Interface) and RTP media (associated with a Media Realm) for multiple Layer-3 networks.
- Can operate with multiple gateway customers that may reside either in the same or in different Layer-3 networks as the device. This allows separation of signaling traffic between different customers. In such a scenario, the device is configured with multiple SRD's.

Typically, one SRD is defined for each group of SIP UAs (e.g. proxies, IP phones, application servers, gateways, and softswitches) that communicate with each other. This provides these entities with VoIP services that reside on the same Layer-3 network (must be able to communicate without traversing NAT devices and must not have overlapping IP addresses). Routing from one SRD to another is possible, whereby each routing destination (IP Group or destination address) indicates the SRD to which it belongs.

Once configured, you can use the SRD as follows:

- Associate it with a SIP Interface (see 'Configuring SIP Interface Table' on page 212)
- Associate it with an IP Group (see 'Configuring IP Groups' on page 214)
- Associate it with a Proxy Set (see 'Configuring Proxy Sets Table' on page 219)
- Define it as a Classification rule for the incoming SIP request (see Configuring Classification Rules)
- Use it as a destination IP-to-IP routing rule (see 'Configuring Outbound IP Routing Table' on page 323)

The SRD Settings page also displays the IP Groups, Proxy Sets, and SIP Interfaces associated with a selected SRD index.



Notes:

- On the SRD Settings page, you can also configure a SIP Interface in the SIP Interface table, instead of navigating to the SIP Interface Table page as described in 'Configuring SIP Interface Table' on page 212.
- The SRD table can also be configured using the table ini file parameter, SRD.

➤ To configure SRDs:

1. Open the SRD Settings page (**Configuration** tab > **VoIP** menu > **Control Network** submenu > **SRD Table**).

SRD Index	0 - Not Exist
Common Parameters	
SRD Name	<input type="text"/>
Media Realm	<input type="text"/>

2. From the 'SRD Index' drop-down list, select an index for the SRD, and then configure it according to the table below.
3. Click **Submit** to apply your changes.
4. To save the changes to flash memory, see 'Saving Configuration' on page 494.

SRD Table Parameters

Parameter	Description
SRD Name [SRD_Name]	Mandatory descriptive name of the SRD. The valid value can be a string of up to 21 characters.
Media Realm [SRD_MediaRealm]	Defines the Media Realm associated with the SRD. The entered string value must be identical (and case-sensitive) to the Media Realm name configured in the Media Realm table (see 'Configuring Media Realms' on page 183). The valid value is a string of up to 40 characters. Notes: <ul style="list-style-type: none"> ▪ If the Media Realm is later deleted from the Media Realm table, then this value becomes invalid in the SRD table. ▪ For configuring Media Realms, see 'Configuring Media Realms' on page 183.

16.2 Configuring SIP Interface Table

The SIP Interface table allows you to configure up to 32 SIP Interfaces. The SIP Interface defines a listening port and type (UDP, TCP, or TLS) for SIP signaling traffic on a specific logical IP network interface configured for the device (in the Multiple Interface table).

The SIP Interface is configured for a specific application (i.e., GatewayIP-to-IP, and SAS) and associated with an SRD. For each SIP Interface, you can assign a SIP message policy, enable TLS mutual authentication, enable TCP keepalive, and determine the SIP response sent upon classification failure.

SIP Interfaces can be used, for example, for the following:

- Using SIP signaling interfaces per call leg (i.e., each SIP entity communicates with a specific SRD).
- Using different SIP listening ports for a single or for multiple IP network interfaces.
- Differentiating between applications by creating SIP Interfaces per application.
- Separating signaling traffic between networks (e.g., different customers) to use different routing tables, manipulations, SIP definitions, and so on.



Note: The SIP Interface table can also be configured using the table *ini* file parameter, SIPInterface.

➤ **To configure the SIP Interface table:**

1. Open the SIP Interface Table page (**Configuration** tab > **VoIP** menu > **Control Network** submenu > **SIP Interface Table**).
2. Click the **Add** button; the following dialog box appears:

Add Record	
Index	<input type="text" value="0"/>
Network Interface	<input type="text" value="Not Configured"/>
Application Type	<input type="text" value="GW & IP2IP"/>
UDP Port	<input type="text" value="5060"/>
TCP Port	<input type="text" value="5060"/>
TLS Port	<input type="text" value="5061"/>
SRD	<input type="text" value="0"/>
Message Policy	<input type="text" value="None"/>
TLS Mutual Authentication	<input type="text" value="Not Configured"/>
TCP Keepalive Enable	<input type="text" value="No"/>
<input type="button" value="Submit"/> <input type="button" value="Cancel"/>	

- Click **Submit** to apply your settings.

SIP Interface Table Parameters

Parameter	Description
Network Interface [SIPInterface_NetworkInterface]	<p>Defines the Control-type IP network interface that you want to associate with the SIP Interface. This value string must be identical (including case-sensitive) to that configured in the 'Interface Name' field of the Multiple Interface table (see 'Configuring IP Network Interfaces' on page 110).</p> <p>The default is not configured.</p> <p>Note: SIP Interfaces that are assigned to a specific SRD must be defined with the same network interface. For example, if you define three SIP Interfaces for SRD ID #8, all these SIP Interfaces must be defined with the same network interface (e.g., "SIP1").</p>
Application Type [SIPInterface_ApplicationType]	<p>Defines the application type associated with the SIP Interface.</p> <ul style="list-style-type: none"> [0] GW/IP2IP (default) = Gateway / IP-to-IP application. [1] SAS = Stand-Alone Survivability (SAS) application.
UDP Port [SIPInterface_UDPPort]	<p>Defines the listening and source UDP port.</p> <p>The valid range is 1 to 65534. The default is 5060.</p> <p>Notes:</p> <ul style="list-style-type: none"> This port must be outside of the RTP port range. Each SIP Interface must have a unique signaling port (i.e., no two SIP Interfaces can share the same port - no port overlapping).
TCP Port [SIPInterface_TCPPort]	<p>Defines the listening TCP port.</p> <p>The valid range is 1 to 65534. The default is 5060.</p> <p>Notes:</p> <ul style="list-style-type: none"> This port must be outside of the RTP port range. Each SIP Interface must have a unique signaling port (i.e., no two SIP Interfaces can share the same port - no port overlapping).
TLS Port [SIPInterface_TLSPort]	<p>Defines the listening TLS port.</p> <p>The valid range is 1 to 65534. The default is 5061.</p> <p>Notes:</p>

Parameter	Description
	<ul style="list-style-type: none"> This port must be outside of the RTP port range. Each SIP Interface must have a unique signaling port (i.e., no two SIP Interfaces can share the same port - no port overlapping).
SRD [SIPInterface_SRD]	Assigns an SRD ID to the SIP Interface. The default is 0. Notes: <ul style="list-style-type: none"> Each SRD can be associated with up to two SIP Interfaces, where each SIP Interface pertains to a different Application Type (GW/IP-to-IP, SAS). SIP Interfaces that are assigned to a specific SRD must be defined with the same network interface. For example, if you define three SIP Interfaces for SRD ID #8, all these SIP Interfaces must be defined with the same network interface (e.g., "SIP1"). To configure SRDs, see 'Configuring SRD Table' on page 211.
Message Policy [SIPInterface_Message Policy]	Assigns a SIP message policy to the SIP interface. Note: To configure SIP message policies, see 'Configuring SIP Message Policy Rules'.
TLS Mutual Authentication [SIPInterface_TLSMutualAuthentication]	Enables TLS mutual authentication per SIP Interface. <ul style="list-style-type: none"> [-1] Not Configured = (Default) The SIPRequireClientCertificate global parameter setting is applied. [0] Disable = Device does not request the client certificate for TLS connection. [1] Enable = Device requires receipt and verification of the client certificate to establish the TLS connection.
TCP Keepalive Enable [SIPInterface_TCPKeepaliveEnable]	Enables the TCP Keep-Alive mechanism with the IP entity on this SIP interface. TCP keepalive can be used, for example, to keep a NAT entry open for clients located behind a NAT server or simply to check that the connection to the IP entity is available. <ul style="list-style-type: none"> [0] No (default) [1] Yes Note: For configuring TCP keepalive, use the following ini file parameters: TCP TCPKeepAliveTime, TCPKeepAliveInterval, and TCPKeepAliveRetry.

16.3 Configuring IP Groups

The IP Group Table page allows you to create up to 32 logical IP entities called *IP Groups*. An IP Group is an entity with a set of definitions such as a Proxy Set ID (see 'Configuring Proxy Sets Table' on page 219), which represents the IP address of the IP Group.

For the Gateway/IP-to-IP application, IP Groups are used for the following:

- SIP dialog registration and authentication (digest user/password) of a specific IP Group (Served IP Group, e.g., corporate IP-PBX) with another IP Group (Serving IP Group, e.g., ITSP). This is configured in the Account table (see Configuring Account Table on page 225).
- Call routing rules:

- **Outgoing IP calls (IP-to-IP or Tel-to-IP):** The IP Group identifies the source of the call and is used as the destination of the outgoing IP call (defined in the Outbound IP Routing Table). For Tel-to-IP calls, the IP Group (Serving IP Group) can be used as the IP destination to where all SIP dialogs that are initiated from a Trunk Group are sent (defined in Configuring Trunk Group Settings on page 293).
- **Incoming IP calls (IP-to-IP or IP-to-Tel):** The IP Group identifies the source of the IP call.
- **Number Manipulation rules to IP:** The IP Group is used to associate the rule with specific calls identified by IP Group.



Notes:

- IP Group ID 0 cannot be used. This IP Group is set to default values and is used by the device when IP Groups are not implemented.
- When operating with multiple IP Groups, the default Proxy server must not be used (i.e., the parameter IsProxyUsed must be set to 0).
- If different SRDs are configured in the IP Group and Proxy Set tables, the SRD defined for the Proxy Set takes precedence.
- You can also configure the IP Groups table using the table ini file parameter, IPGroup (see 'Configuration Parameters Reference' on page 609).

➤ **To configure IP Groups:**

1. Open the IP Group Table page (**Configuration** tab > **VoIP** menu > **Control Network** submenu > **IP Group Table**).
2. Click the **Add** button: the following dialog box appears:

3. Configure the IP Group parameters according to the table below.
4. Click **Submit**.
5. To save the changes to flash memory, see 'Saving Configuration' on page 494.

IP Group Parameters

Parameter	Description
Common Parameters	

Parameter	Description
Type [IPGroup_Type]	Defines the type of IP Group: <ul style="list-style-type: none"> ▪ [0] Server = Used when the destination address, configured by the Proxy Set, of the IP Group (e.g., ITSP, Proxy, IP-PBX, or Application server) is known. ▪ [1] User = Represents a group of users such as IP phones and softphones where their location is dynamically obtained by the device when REGISTER requests and responses traverse (or are terminated) by the device. These users are considered remote (far-end) users. Typically, this IP Group is configured with a Serving IP Group that represents an IP-PBX, Application or Proxy server that serves this User-type IP Group. Each SIP request sent by a user of this IP Group is proxied to the Serving IP Group. For registrations, the device updates its internal database with the AOR and contacts of the users. Digest authentication using SIP 401/407 responses (if needed) is performed by the Serving IP Group. The device forwards these responses directly to the SIP users. <p>To route a call to a registered user, a rule must be configured in the Outbound IP Routing Table. The device searches the dynamic database (by using the request URI) for an entry that matches a registered AOR or Contact. Once an entry is found, the IP destination is obtained from this entry, and a SIP request is sent to the destination.</p> The device also supports NAT traversal for the SIP clients located behind NAT. In this case, the device must be defined with a global IP address. <p>Note: This field is applicable only to the IP-to-IP application.</p>
Description [IPGroup_Description]	Defines a brief description for the IP Group. The valid value is a string of up to 29 characters. The default is an empty field.
Proxy Set ID [IPGroup_ProxySetId]	Assigns a Proxy Set ID to the IP Group. All INVITE messages destined to this IP Group are sent to the IP address configured for the Proxy Set. <p>Notes:</p> <ul style="list-style-type: none"> ▪ Proxy Set ID 0 must not be used; this is the device's default Proxy. ▪ The Proxy Set is applicable only to Server-type IP Groups. ▪ The SRD configured for this Proxy Set in the Proxy Set table is automatically assigned to this IP Group (see the 'SRD' field below). ▪ To configure Proxy Sets, see 'Configuring Proxy Sets Table' on page 219.
SIP Group Name [IPGroup_SIPGroupName]	Defines the SIP Request-URI host name used in INVITE and REGISTER messages sent to this IP Group, or the host name in the From header of INVITE messages received from this IP Group. The valid value is a string of up to 100 characters. The default is an empty field. <p>Notes:</p> <ul style="list-style-type: none"> ▪ If this parameter is not configured, the value of the global parameter, ProxyName is used instead (see 'Configuring Proxy and Registration Parameters' on page 228). ▪ If the IP Group is of User type, this parameter is used internally as a host name in the Request-URI for Tel-to-IP initiated calls. For example, if an incoming call from the device's T1 trunk is routed to a User-type IP Group, the device first creates the Request-URI

Parameter	Description
	(<destination_number>@<SIP Group Name>), and then it searches the internal database for a match.
Contact User [IPGroup_ContactUser]	<p>Defines the user part of the From, To, and Contact headers of SIP REGISTER messages, and the user part of the Contact header of INVITE messages received from this IP Group and forwarded by the device to another IP Group.</p> <p>Notes:</p> <ul style="list-style-type: none"> This parameter is applicable only to Server-type IP Groups. This parameter is overridden by the 'Contact User' parameter in the 'Account' table (see 'Configuring Account Table' on page 225).
Local Host Name [IPGroup_ContactName]	<p>Defines the host name (string) that the device uses in the SIP message's Via and Contact headers. This is typically used to define an FQDN as the host name. The device uses this string for Via and Contact headers in outgoing INVITE messages to a specific IP Group, and the Contact header in SIP 18x and 200 OK responses for incoming INVITE messages from a specific IP Group. The Inbound IP Routing table can be used to identify the source IP Group from where the INVITE message was received.</p> <p>If this parameter is not configured (default), these headers are populated with the device's dotted-decimal IP address of the network interface on which the message is sent.</p> <p>Note: To ensure proper device handling, this parameter should be a valid FQDN.</p>
SRD [IPGroup_SRD]	<p>Assigns an SRD to the IP Group. The default is 0.</p> <p>Notes:</p> <ul style="list-style-type: none"> For this parameter to take effect, a device reset is required. To configure SRDs, see Configuring SRD Table on page 211. For Server-type IP Groups, if you assign the IP Group with a Proxy Set ID (in the 'Proxy Set ID' field), the SRD field is automatically set to the SRD value assigned to the Proxy Set in the Proxy Set table.
Media Realm Name [IPGroup_MediaRealm]	<p>Assigns a Media Realm to the IP Group. The string value must be identical (including case-sensitive) to the Media Realm name defined in the Media Realm table.</p> <p>Notes:</p> <ul style="list-style-type: none"> For this parameter to take effect, a device reset is required. If the Media Realm is later deleted from the Media Realm table, then this value becomes invalid. For configuring Media Realms, see Configuring Media Realms on page 183.
IP Profile ID [IPGroup_ProfileId]	<p>Assigns an IP Profile to the IP Group. The default is 0.</p> <p>Note: To configure IP Profiles, see 'Configuring IP Profiles' on page 245.</p>
Gateway Parameters	
Always Use Route Table [IPGroup_AlwaysUseRouteTable]	<p>Defines the Request-URI host name in outgoing INVITE messages.</p> <ul style="list-style-type: none"> [0] No (default). [1] Yes = The device uses the IP address (or domain name) defined in the Outbound IP Routing Table (see Configuring the Outbound IP

Parameter	Description
	<p>Routing Table on page 323) as the Request-URI host name in outgoing INVITE messages, instead of the value configured in the 'SIP Group Name' field.</p> <p>Note: This parameter is applicable only to Server-type IP Groups.</p>
Routing Mode [IPGroup_RoutingMode]	<p>Defines the routing mode for outgoing SIP INVITE messages.</p> <ul style="list-style-type: none"> ▪ [-1] Not Configured = (Default) The routing is according to the selected Serving IP Group. If no Serving IP Group is selected, the device routes the call according to the Outbound IP Routing Table (see Configuring Outbound IP Routing Table on page 323). ▪ [0] Routing Table = The device routes the call according to the Outbound IP Routing Table. ▪ [1] Serving IP Group = The device sends the SIP INVITE to the selected Serving IP Group. If no Serving IP Group is selected, the default IP Group is used. If the Proxy server(s) associated with the destination IP Group is not alive, the device uses the Outbound IP Routing Table (if the parameter IsFallbackUsed is set 1, i.e., fallback enabled - see 'Configuring Proxy and Registration Parameters' on page 228). ▪ [2] Request-URI = The device sends the SIP INVITE to the IP address according to the received SIP Request-URI host name. <p>Notes:</p> <ul style="list-style-type: none"> ▪ This parameter is applicable only to the IP-to-IP application. ▪ This parameter is applicable only to Server-type IP Groups.
SIP Re-Routing Mode [IPGroup_SIPReRouting Mode]	<p>Defines the routing mode after a call redirection (i.e., a 3xx SIP response is received) or transfer (i.e., a SIP REFER request is received).</p> <ul style="list-style-type: none"> ▪ [-1] Not Configured (Default) ▪ [0] Standard = INVITE messages that are generated as a result of Transfer or Redirect are sent directly to the URI, according to the Refer-To header in the REFER message or Contact header in the 3xx response. ▪ [1] Proxy = Sends a new INVITE to the Proxy. This is applicable only if a Proxy server is used and the parameter AlwaysSendtoProxy is set to 0. ▪ [2] Routing Table = Uses the Routing table to locate the destination and then sends a new INVITE to this destination. <p>Notes:</p> <ul style="list-style-type: none"> ▪ When this parameter is set to [1] and the INVITE sent to the Proxy fails, the device re-routes the call according to the Standard mode [0]. ▪ When this parameter is set to [2] and the INVITE fails, the device re-routes the call according to the Standard mode [0]. If DNS resolution fails, the device attempts to route the call to the Proxy. If routing to the Proxy also fails, the Redirect / Transfer request is rejected. ▪ When this parameter is set to [2], the XferPrefix parameter can be used to define different routing rules for redirected calls. ▪ This parameter is ignored if the parameter AlwaysSendToProxy is set to 1.
Enable Survivability [IPGroup_EnableSurvivability]	<p>Defines how the device handles registration messages and whether Survivability mode is enabled for User-type IP Groups.</p> <ul style="list-style-type: none"> ▪ [0] Disable (default). ▪ [1] Enable if Necessary = Survivability mode is enabled only if the Serving IP Group is unavailable. The device saves in its Registration database the registration messages sent by the clients (e.g., IP

Parameter	Description
	<p>phones) belonging to the User-type IP Group. If communication with the Serving IP Group (e.g., IP-PBX) fails, the User-type IP Group enters into Survivability mode in which the device uses its database for routing calls between the clients of the User-type IP Group. In Survivability mode, the RTP packets between the clients always traverse through the device, and new registrations can also be processed. When the Serving IP Group is available again, the device returns to normal mode, sending INVITE and REGISTER messages to the Serving IP Group.</p> <ul style="list-style-type: none"> ▪ [2] Always Enable = Survivability mode is always enabled. The communication with the Serving IP Group is always considered as failed. The device uses its database for routing calls between the clients of the User-type IP Group. ▪ [3] Always Terminate Register = The registration messages received from the clients are saved in the device's registration database without forwarding them to the proxy server. Upon receipt of the registration message, the device returns a SIP 200 OK to the client. <p>Notes:</p> <ul style="list-style-type: none"> ▪ This parameter is applicable only to the IP-to-IP application. ▪ This parameter is applicable only to User-type IP Groups.
Serving IP Group ID [IPGroup_ServingIPGroup]	<p>If configured, INVITE messages initiated from the IP Group are sent to this Serving IP Group (range 1 to 9). In other words, the INVITEs are sent to the address defined for the Proxy Set associated with this Serving IP Group. The Request-URI host name in the INVITE messages are set to the value of the 'SIP Group Name' parameter defined for the Serving IP Group.</p> <p>Notes:</p> <ul style="list-style-type: none"> ▪ This parameter is applicable only to the IP-to-IP application. ▪ If the PreferRouteTable parameter is set to 1, the routing rules in the Outbound IP Routing Table take precedence over this 'Serving IP Group ID' parameter. ▪ If this parameter is not configured, the INVITE messages are sent to the default Proxy or according to the 'Outbound IP Routing Table'.

16.4 Configuring Proxy Sets Table

The Proxy Sets Table page allows you to define *Proxy Sets*. A Proxy Set is a group of Proxy servers defined by IP address or fully qualified domain name (FQDN). You can define up to 32 Proxy Sets, each with up to five Proxy server addresses. For each Proxy server address you can define the transport type (i.e., UDP, TCP, or TLS). In addition, Proxy load balancing and redundancy mechanisms can be applied per Proxy Set if it contains more than one Proxy address.

Proxy Sets can later be assigned to Server-type IP Groups (see 'Configuring IP Groups' on page 214). When the device sends an INVITE message to an IP Group, it is sent to the IP address or domain name defined for the Proxy Set that is associated with the IP Group. In other words, the Proxy Set represents the **destination** of the call. Typically, for IP-to-IP call routing, at least two Proxy Sets are defined for call destination – one for each leg (IP Group) of the call (i.e., both directions). For example, one Proxy Set for the Internet Telephony Service provider (ITSP) interfacing with one 'leg' of the device and another Proxy Set for the second SIP entity (e.g., ITSP) interfacing with the other 'leg' of the device.



Notes:

- Proxy Sets can be assigned only to Server-type IP Groups.
- The Proxy Set table can also be configured using two complementary tables:
 - Proxy Set ID with IP addresses: Table ini file parameter, ProxyIP.
 - Attributes for the Proxy Set: Table ini file parameter, ProxySet.

➤ **To configure Proxy Sets:**

1. Open the Proxy Sets Table page (**Configuration** tab > **VoIP** menu > **Control Network** submenu > **Proxy Sets Table**).

Figure 16-1: Proxy Sets Table Page

2. From the 'Proxy Set ID' drop-down list, select an ID for the desired group.
3. Configure the Proxy parameters, as required. For a description of the parameters, see the table below.
4. Click **Submit**.
5. To save the changes to flash memory, see 'Saving Configuration' on page 494.

Proxy Sets Table Parameters

Parameter	Description
Web: Proxy Set ID EMS: Index [ProxySet_Index]	Defines the Proxy Set identification number. The valid value is 0 to 31. Proxy Set ID 0 is used as the default Proxy Set. Note: Although not recommended, you can use both default Proxy Set (ID 0) and IP Groups for call routing. For example, in the Trunk Group Settings page (see Configuring Trunk Group Settings on page 293) you can configure a Serving IP Group to where you want to route specific Trunk

Parameter	Description
	<p>Group channels, and all other device channels then use the default Proxy Set. You can also use IP Groups in the Outbound IP Routing Table (see Configuring the Outbound IP Routing Table on page 323) to configure the default Proxy Set if the parameter <code>PreferRouteTable</code> is set to 1.</p> <p>To summarize, if the default Proxy Set is used, the INVITE message is sent according to the following preferences:</p> <ul style="list-style-type: none"> ▪ To the Trunk Group's Serving IP Group ID, as defined in the Trunk Group Settings table. ▪ According to the Outbound IP Routing Table if the parameter <code>PreferRouteTable</code> is set to 1. ▪ To the default Proxy. <p>Typically, when IP Groups are used, there is no need to use the default Proxy and all routing and registration rules can be configured using IP Groups and the Account tables (see 'Configuring Account Table' on page 225).</p>
<p>Proxy Address [ProxyIp_IpAddress]</p>	<p>Defines the address (and optionally, port number) of the Proxy server. Up to five addresses can be configured per Proxy Set.</p> <p>The address can be defined as an IP address in dotted-decimal notation (e.g., 201.10.8.1) or as an FQDN. You can also specify the selected port in the format, <IP address>:<port>.</p> <p>If you enable Proxy Redundancy (by setting the parameter <code>EnableProxyKeepAlive</code> to 1 or 2), the device can operate with multiple Proxy servers. If there is no response from the first (<i>primary</i>) Proxy defined in the list, the device attempts to communicate with the other (<i>redundant</i>) Proxies in the list. When a redundant Proxy is located, the device either continues operating with it until the next failure occurs or reverts to the primary Proxy (refer to the parameter <code>ProxyRedundancyMode</code>). If none of the Proxy servers respond, the device goes over the list again.</p> <p>The device also provides real-time switching (Hot-Swap mode) between the primary and redundant proxies (refer to the parameter <code>IsProxyHotSwap</code>). If the first Proxy doesn't respond to the INVITE message, the same INVITE message is immediately sent to the next Proxy in the list. The same logic applies to REGISTER messages (if <code>RegistrarIP</code> is not defined).</p> <p>Notes:</p> <ul style="list-style-type: none"> ▪ If <code>EnableProxyKeepAlive</code> is set to 1 or 2, the device monitors the connection with the Proxies by using keep-alive messages (OPTIONS or REGISTER). ▪ To use Proxy Redundancy, you must specify one or more redundant Proxies. ▪ When a port number is specified (e.g., domain.com:5080), DNS NAPTR/SRV queries aren't performed, even if <code>ProxyDNSQueryType</code> is set to 1 or 2.
<p>Transport Type [ProxyIp_TransportType]</p>	<p>Defines the transport type of the proxy server.</p> <ul style="list-style-type: none"> ▪ [0] UDP ▪ [1] TCP ▪ [2] TLS ▪ [-1] = Undefined <p>Note: If no transport type is selected, the value of the global parameter <code>SIPTransportType</code> is used.</p>
<p>Web/EMS: Enable</p>	<p>Enables the Keep-Alive mechanism with the Proxy server(s).</p>

Parameter	Description
Proxy Keep Alive [ProxySet_EnableProxyKeepAlive]	<ul style="list-style-type: none"> ▪ [0] Disable (default). ▪ [1] Using Options = Enables Keep-Alive with Proxy using SIP OPTIONS messages. ▪ [2] Using Register = Enables Keep-Alive with Proxy using SIP REGISTER messages. <p>If set to 'Using Options', the SIP OPTIONS message is sent every user-defined interval (configured by the parameter ProxyKeepAliveTime). If set to 'Using Register', the SIP REGISTER message is sent every user-defined interval (configured by the RegistrationTime parameter for the Gateway/IP-to-IP application). Any response from the Proxy, either success (200 OK) or failure (4xx response) is considered as if the Proxy is communicating correctly.</p> <p>Notes:</p> <ul style="list-style-type: none"> ▪ For Survivability mode for User-type IP Groups, this parameter must be enabled (1 or 2). ▪ This parameter must be set to 'Using Options' when Proxy redundancy is used. ▪ When this parameter is set to 'Using Register', the homing redundancy mode is disabled. ▪ When the active proxy doesn't respond to INVITE messages sent by the device, the proxy is tagged as 'offline'. The behavior is similar to a Keep-Alive (OPTIONS or REGISTER) failure. ▪ If this parameter is enabled and the proxy uses the TCP/TLS transport type, you can enable CRLF Keep-Alive mechanism, using the UsePingPongKeepAlive parameter.
Web: Proxy Keep Alive Time EMS: Keep Alive Time [ProxySet_ProxyKeepAliveTime]	<p>Defines the Proxy keep-alive time interval (in seconds) between Keep-Alive messages.</p> <p>The valid range is 5 to 2,000,000. The default is 60.</p> <p>Note: This parameter is applicable only if the parameter EnableProxyKeepAlive is set to 1 (OPTIONS). When the parameter EnableProxyKeepAlive is set to 2 (REGISTER), the time interval between Keep-Alive messages is determined by the RegistrationTime parameter for the Gateway/IP-to-IP application.</p>
Web: Proxy Load Balancing Method EMS: Load Balancing Method [ProxySet_ProxyLoadBalancingMethod]	<p>Enables the Proxy Load Balancing mechanism per Proxy Set ID.</p> <ul style="list-style-type: none"> ▪ [0] Disable = Load Balancing is disabled (default) ▪ [1] Round Robin ▪ [2] Random Weights <p>When the Round Robin algorithm is used, a list of all possible Proxy IP addresses is compiled. This list includes all IP addresses per Proxy Set, after necessary DNS resolutions (including NAPTR and SRV, if configured). After this list is compiled, the Proxy Keep-Alive mechanism (according to parameters EnableProxyKeepAlive and ProxyKeepAliveTime) tags each entry as 'offline' or 'online'. Load balancing is only performed on Proxy servers that are tagged as 'online'.</p> <p>All outgoing messages are equally distributed across the list of IP addresses. REGISTER messages are also distributed unless a RegistrarIP is configured.</p> <p>The IP addresses list is refreshed according to ProxyIPListRefreshTime. If a change in the order of the entries in the list occurs, all load statistics are erased and balancing starts over again.</p> <p>When the Random Weights algorithm is used, the outgoing requests are not distributed equally among the Proxies. The weights are received from</p>

Parameter	Description
	<p>the DNS server by using SRV records. The device sends the requests in such a fashion that each Proxy receives a percentage of the requests according to its' assigned weight. A single FQDN should be configured as a Proxy IP address. The Random Weights Load Balancing is not used in the following scenarios:</p> <ul style="list-style-type: none"> ▪ The Proxy Set includes more than one Proxy IP address. ▪ The only Proxy defined is an IP address and not an FQDN. ▪ SRV is not enabled (DNSQueryType). ▪ The SRV response includes several records with a different Priority value.
<p>Web/EMS: Is Proxy Hot-Swap [ProxySet_IsProxyHotSwap]</p>	<p>Enables the Proxy Hot-Swap redundancy mode.</p> <ul style="list-style-type: none"> ▪ [0] No (default) ▪ [1] Yes <p>If Proxy Hot-Swap is enabled, the SIP INVITE/REGISTER message is initially sent to the first Proxy/Registrar server. If there is no response from the first Proxy/Registrar server after a specific number of retransmissions (configured by the parameter HotSwapRtx), the message is resent to the next redundant Proxy/Registrar server.</p>
<p>Web/EMS: Redundancy Mode [ProxySet_ProxyRedundancyMode]</p>	<p>Determines whether the device switches back to the primary Proxy after using a redundant Proxy.</p> <ul style="list-style-type: none"> ▪ [-1] Not configured = (Default) The global parameter, ProxyRedundancyMode applies. ▪ [0] Parking = The device continues operating with a redundant (now active) Proxy until the next failure, after which it operates with the next redundant Proxy. ▪ [1] Homing = The device always attempts to operate with the primary Proxy server (i.e., switches back to the primary Proxy whenever it's available). <p>Notes:</p> <ul style="list-style-type: none"> ▪ To use the Proxy Redundancy mechanism, you need to enable the keep-alive with Proxy option, by setting the parameter EnableProxyKeepAlive to 1 or 2. ▪ If this parameter is configured, then the global parameter is ignored.
<p>Web/EMS: SRD Index [ProxySet_ProxySet_SRD]</p>	<p>Defines the SRD associated with the Proxy Set ID. The default is SRD 0.</p> <p>Notes:</p> <ul style="list-style-type: none"> ▪ For this parameter to take effect, a device reset is required. ▪ To configure SRDs, see Configuring SRD Table on page 211.

Reader's Notes

17 SIP Definitions

This section describes configuration of SIP parameters.

17.1 Configuring SIP Parameters

Many of the stand-alone SIP parameters associated with various features can be configured in the following pages:

- **SIP General Parameters page:** Provides SIP parameters for configuring general SIP features. To access this page, use the following path: **Configuration** tab > **VoIP** menu > **SIP Definitions** > **General Parameters**.
- **SIP Advanced Parameters page:** Provides SIP parameters for configuring advanced SIP features. To access this page, use the following path: **Configuration** tab > **VoIP** menu > **SIP Definitions** > **Advanced Parameters**.

For a description of these parameters, refer to the section corresponding to the feature or see 'Configuration Parameters Reference' on page [609](#).

17.2 Configuring Account Table

The Account Table page lets you define up to 32 Accounts per ("served") Trunk Group or source ("served") IP Group. Accounts are used to register and/or digest authenticate a Trunk Group or served IP Group, using a username and password, to a destination ("serving") IP Group. For example, the device can use the Account table to register an IP PBX, which is connected to the device, to an ITSP. The device sends the registration requests to the Proxy Set ID (see 'Configuring Proxy Sets Table' on page [219](#)) that is associated with the serving IP Group.

A Trunk Group or served IP Group can register to more than one serving IP Group (e.g., multiple ITSPs). This is done by configuring multiple entries in the Account table for the same Trunk Group or served IP Group, but with different serving IP Groups, user name/password, host name, and contact user values.

When using the Account table to register a Trunk Group, if all trunks belonging to the Trunk Group are down, the device un-registers the trunks. If any trunk belonging to the Trunk Group is returned to service, the device registers them again. This ensures, for example, that the Proxy does not send INVITEs to trunks that are out of service.

If registration to an IP Group fails for all accounts of a specific Trunk Group and if this Trunk Group includes all the channels in the Trunk Group, the Trunk Group is set to Out-Of-Service if the OOSOnRegistrationFail parameter is set to 1 (see 'Proxy & Registration Parameters' on page [228](#)).



Notes:

- For viewing Account registration status, see Viewing Endpoint Registration Status on page [556](#).
- The Account table can also be configured using the table ini file parameter, Account.

➤ To configure Accounts:

1. Open the Account Table page (**Configuration** tab > **VoIP** menu > **SIP Definitions** submenu > **Account Table**).

Index	Served Trunk Group	Served IP Group	Serving IP Group	Username	Password	Host Name	Register	ContactUser
1	1	3	1	#ipa	*	regiona	Yes	ITSFAA
2	1	3	2	#ipb	*	regionb	Yes	ITSFBE

2. In the 'Add' field, enter the desired table row index, and then click **Add**. A new row appears.
3. Configure the Account parameters according to the table below.
4. Click the **Apply** button to save your changes.
5. To save the changes, see 'Saving Configuration' on page 494.
6. To perform registration, click the **Register** button; to unregister, click **Unregister**. The registration method for each Trunk Group is according to the setting of the 'Registration Mode' parameter in the Trunk Group Settings page.

Account Table Parameters Description

Parameter	Description
Served Trunk Group CLI: served-trunk-group [Account_ServedTrunkGroup]	<p>Defines the Trunk Group ID that you want to register and/or authenticate to a destination IP Group (i.e., Serving IP Group).</p> <ul style="list-style-type: none"> ▪ For Tel-to-IP calls, the Served Trunk Group is the source Trunk Group from where the call originated. ▪ For IP-to-Tel calls, the Served Trunk Group is the HuntTrunk Group ID to which the call is sent. <p>Note: This parameter is applicable only to the Gateway application.</p>
Served IP Group [Account_ServedIPGroup]	<p>Defines the Source IP Group (e.g., IP-PBX) for which registration and/or authentication is done.</p> <p>Note: This parameter is applicable only to the SBC and IP-to-IP applications (not Gateway application).</p>
Serving IP Group [Account_ServingIPGroup]	<p>Defines the destination IP Group ID to where the SIP REGISTER requests, if enabled, are sent and authentication is done. The actual destination to where the REGISTER requests are sent is the IP address configured for the Proxy Set ID that is associated with the IP Group.</p> <p>Registration occurs only if:</p> <ul style="list-style-type: none"> ▪ Gateway application only: The 'Registration Mode' parameter is set to 'Per Account' in the Hunt Group Settings table (see Configuring Hunt Group Settings on page 293). ▪ The 'Register' parameter in the Account table is set to Yes. <p>For the Gateway and IP-to-IP applications:</p> <ul style="list-style-type: none"> ▪ For Tel-to-IP calls, the serving IP Group is the destination IP Group defined in the Trunk Group Settings table or Outbound IP Routing Table (see Configuring the Outbound IP Routing Table on page 323). ▪ For IP-to-Tel calls, the Serving IP Group is the 'Source IP Group ID' defined in the Inbound IP Routing Table (see Configuring the Inbound IP Routing Table on page 332). <p>Note: If no match is found in this table for incoming or outgoing calls, the username and password is taken from the following:</p> <ul style="list-style-type: none"> ▪ FXS interfaces: Authentication table (see Configuring Authentication) ▪ UserName and Password parameters on the Proxy & Registration page.
Username [Account_Username]	<p>Defines the digest MD5 Authentication user name.</p> <p>The valid value is a string of up to 50 characters.</p>

Parameter	Description
Password [Account_Password]	<p>Defines the digest MD5 Authentication password.</p> <p>The valid value is a string of up to 50 characters.</p> <p>Note: After you click the Apply button, this password is displayed as an asterisk (*).</p>
Host Name [Account_HostName]	<p>Defines the Address of Record (AOR) host name. It appears in REGISTER From/To headers as ContactUser@HostName. For successful registrations, this host name is also included in the INVITE request's From header URI.</p> <p>This parameter can be up to 49 characters.</p> <p>Note: If this parameter is not configured or if registration fails, the 'SIP Group Name' parameter configured in the IP Group table is used instead.</p>
Register [Account_Register]	<p>Enables registration.</p> <ul style="list-style-type: none"> ▪ [0] No (Default) ▪ [1] Yes <p>When enabled, the device sends REGISTER requests to the Serving IP Group. The host name (i.e., host name in SIP From/To headers) and Contact User (user in From/To and Contact headers) are taken from this table upon successful registration. See the example below:</p> <pre>REGISTER sip:xyz SIP/2.0 Via: SIP/2.0/UDP 10.33.37.78;branch=z9hG4bKac1397582418 From: <sip:ContactUser@HostName>;tag=1c1397576231 To: <sip: ContactUser@HostName > Call-ID: 1397568957261200022256@10.33.37.78 CSeq: 1 REGISTER Contact: <sip:ContactUser@10.33.37.78>;expires=3600 Expires: 3600 User-Agent: Sip-Gateway/v.6.00A.008.002 Content-Length: 0</pre> <p>Notes:</p> <ul style="list-style-type: none"> ▪ To activate registration, you also need to set the parameter 'Registration Mode' to 'Per Account' in the Trunk Group Settings table for the specific Trunk Group. ▪ The Trunk Group account registration is not affected by the parameter IsRegisterNeeded.
Contact User [Account_Contact User]	<p>Defines the AOR user name. This appears in REGISTER From/To headers as ContactUser@HostName, and in INVITE/200 OK Contact headers as ContactUser@<device's IP address>.</p> <p>Notes:</p> <ul style="list-style-type: none"> ▪ If this parameter is not configured, the 'Contact User' parameter in the IP Group table is used instead. ▪ If registration fails, then the user part in the INVITE Contact header contains the source party number.
Application Type [Account_ApplicationType]	<p>Defines the application type:</p> <ul style="list-style-type: none"> ▪ [0] GW/IP2IP = (Default) Gateway and IP-to-IP application.

17.3 Configuring Proxy and Registration Parameters

The Proxy & Registration page allows you to configure the Proxy server and registration parameters. For a description of the parameters appearing on this page, see 'Configuration Parameters Reference' on page 609.



Note: To view the registration status of endpoints with a SIP Registrar/Proxy server, see Viewing Endpoint Registration Status on page 556.

➤ **To configure the Proxy and registration parameters:**

1. Open the Proxy & Registration page (**Configuration** tab > **VoIP** menu > **SIP Definitions** submenu > **Proxy & Registration**).

Use Default Proxy	Yes
Proxy Set Table	
Proxy Name	<input type="text"/>
Redundancy Mode	Parking
Proxy IP List Refresh Time	60
Enable Fallback to Routing Table	Disable
Prefer Routing Table	No
Use Routing Table for Host Names and Profiles	Disable
Always Use Proxy	Disable
Redundant Routing Mode	Routing Table
SIP ReRouting Mode	Standard Mode
Enable Registration	Disable
Gateway Name	<input type="text"/>
Gateway Registration Name	<input type="text"/>
DNS Query Type	A-Record
Proxy DNS Query Type	A-Record
Subscription Mode	Per Endpoint
Number of RTX Before Hot-Swap	3
Use Gateway Name for OPTIONS	No
User Name	joe
Password	mikey
Cnonce	Default_Cnonce
Registration Mode	Per Endpoint
Set Out-Of-Service On Registration Failure	Disable
Challenge Caching Mode	None
Mutual Authentication Mode	Optional

2. Configure the parameters as required.
3. Click **Submit** to apply your changes.

➤ **To register or un-register the device to a Proxy/Registrar:**

- Click the **Register** button to register.
- Click **Un-Register** button to un-register.

Instead of registering the entire device, you can register specific entities as listed below by using the **Register** button located on the page in which these entities are configured:

- FXS/FXO endpoints, BRI endpoints, Trunk Groups - Trunk Group Table page (see Configuring Trunk Group Table on page 291)
- Accounts - Account table (see 'Configuring Account Table' on page 225)

Click the **Proxy Set Table**  button to Open the Proxy Sets Table page to configure groups of proxy addresses. Alternatively, you can open this page from the **Proxy Sets Table** page item (see 'Configuring Proxy Sets Table' on page 219 for a description of this page).

17.3.1 SIP Message Authentication Example

The device supports basic and digest (MD5) authentication types, according to SIP RFC 3261 standard. A proxy server might require authentication before forwarding an INVITE message. A Registrar/Proxy server may also require authentication for client registration. A proxy replies to an unauthenticated INVITE with a 407 Proxy Authorization Required response, containing a Proxy-Authenticate header with the form of the challenge. After sending an ACK for the 407, the user agent can then re-send the INVITE with a Proxy-Authorization header containing the credentials.

User agents, Redirect or Registrar servers typically use the SIP 401 Unauthorized response to challenge authentication containing a WWW-Authenticate header, and expect the re-INVITE to contain an Authorization header.

The following example shows the Digest Authentication procedure, including computation of user agent credentials:

1. The REGISTER request is sent to a Registrar/Proxy server for registration:

```
REGISTER sip:10.2.2.222 SIP/2.0
Via: SIP/2.0/UDP 10.1.1.200
From: <sip:122@10.1.1.200>;tag=1c17940
To: <sip:122@10.1.1.200>
Call-ID: 634293194@10.1.1.200
User-Agent: Sip-Gateway/Mediant 1000/v.6.60.010.006
CSeq: 1 REGISTER
Contact: sip:122@10.1.1.200:
Expires:3600
```

2. Upon receipt of this request, the Registrar/Proxy returns a 401 Unauthorized response:

```
SIP/2.0 401 Unauthorized
Via: SIP/2.0/UDP 10.2.1.200
From: <sip:122@10.2.2.222 >;tag=1c17940
To: <sip:122@10.2.2.222 >
Call-ID: 634293194@10.1.1.200
Cseq: 1 REGISTER
Date: Mon, 30 Jul 2012 15:33:54 GMT
Server: Columbia-SIP-Server/1.17
Content-Length: 0
WWW-Authenticate: Digest realm="audiocodes.com",
nonce="11432d6bce58ddf02e3b5e1c77c010d2",
stale=FALSE,
algorithm=MD5
```

3. According to the sub-header present in the WWW-Authenticate header, the correct REGISTER request is created.
4. Since the algorithm is MD5:
 - The username is equal to the endpoint phone number "122".
 - The realm return by the proxy is "audiocodes.com".
 - The password from the *ini* file is "AudioCodes".
 - The equation to be evaluated is "122:audiocodes.com:AudioCodes". According to the RFC, this part is called A1.
 - The MD5 algorithm is run on this equation and stored for future usage.
 - The result is "a8f17d4b41ab8dab6c95d3c14e34a9e1".
5. The par called A2 needs to be evaluated:
 - The method type is "REGISTER".
 - Using SIP protocol "sip".
 - Proxy IP from *ini* file is "10.2.2.222".
 - The equation to be evaluated is "REGISTER:sip:10.2.2.222".
 - The MD5 algorithm is run on this equation and stored for future usage.
 - The result is "a9a031cfddcb10d91c8e7b4926086f7e".
6. Final stage:
 - A1 result: The nonce from the proxy response is "11432d6bce58ddf02e3b5e1c77c010d2".
 - A2 result: The equation to be evaluated is "A1:11432d6bce58ddf02e3b5e1c77c010d2:A2".
 - The MD5 algorithm is run on this equation. The outcome of the calculation is the response needed by the device to register with the Proxy.
 - The response is "b9c45d0234a5abf5ddf5c704029b38cf".

At this time, a new REGISTER request is issued with the following response:

```
REGISTER sip:10.2.2.222 SIP/2.0
Via: SIP/2.0/UDP 10.1.1.200
From: <sip: 122@10.1.1.200>;tag=1c23940
To: <sip: 122@10.1.1.200>
Call-ID: 654982194@10.1.1.200
Server: Audiocodes-Sip-Gateway/Mediant 1000/v.6.60.010.006
CSeq: 1 REGISTER
Contact: sip:122@10.1.1.200:
Expires:3600
Authorization: Digest, username: 122,
realm="audiocodes.com",
nonce="11432d6bce58ddf02e3b5e1c77c010d2",
uri="10.2.2.222",
response="b9c45d0234a5abf5ddf5c704029b38cf"
```

7. Upon receiving this request and if accepted by the Proxy, the Proxy returns a 200 OK response, completing the registration transaction:

```
SIP/2.0 200 OK
Via: SIP/2.0/UDP 10.1.1.200
From: <sip: 122@10.1.1.200>;tag=1c23940
To: <sip: 122@10.1.1.200>
Call-ID: 654982194@10.1.1.200
Cseq: 1 REGISTER
Date: Thu, 26 Jul 2012 09:34:42 GMT
Server: Columbia-SIP-Server/1.17
Content-Length: 0
```

```
Contact: <sip:122@10.1.1.200>; expires="Thu, 26 Jul 2012
10:34:42 GMT"; action=proxy; q=1.00
Contact: <122@10.1.1.200:>; expires="Tue, 19 Jan 2038 03:14:07
GMT"; action=proxy; q=0.00
Expires: Thu, 26 Jul 2012 10:34:42 GMT
```

17.4 Configuring SIP Message Manipulation

The Message Manipulations page allows you to define up to 100 SIP message manipulation rules. Each manipulation rule can be assigned any Manipulation Set ID (0 to 19), enabling you to create groups (sets) of manipulation rules whereby rules of a group are configured with the same Manipulation Set ID number. To use these Manipulation Sets, you need to assign them to IP Groups in the IP Group table (see 'Configuring IP Groups' on page 214) where they can be applied to inbound and/or outbound SIP messages.

SIP message manipulation enables the normalization of SIP messaging fields between communicating network segments. For example, it allows service providers to design their own policies on the SIP messaging fields that must be present before a SIP call enters their network. Similarly, enterprises and small businesses may have policies for the information that can enter or leave their networks for policy or security reasons from a service provider. The manipulations can also be implemented to resolve incompatibilities between SIP devices inside the enterprise network.

SIP message manipulation supports the following:

- Addition of new headers.
- Removal of headers ("Black list").
- Modification of header components - value, header value (e.g., URI value of the P-Asserted-Identity header can be copied to the From header), call's parameter values.
- Deletion of SIP body (e.g., if a message body isn't supported at the destination network this body is removed).
- Translating one SIP response code to another.
- Topology hiding (generally present in SIP headers such as Via, Record Route, Route and Service-Route).
- Configurable identity hiding (information related to identity of subscribers for example, P-Asserted-Identity, Referred-By, Identity and Identity-Info).
- Apply conditions per rule - the condition can be on parts of the message or call's parameters.
- Multiple manipulation rules on the same SIP message.


The manipulation can be performed on message type (Method, Request/Response, and Response type) and multiple manipulation rules can be configured for the same SIP message.

For the Gateway / IP-to-IP application, manipulation rules can be assigned as follows:

- Manipulating inbound SIP INVITE messages: The Manipulation Set ID is selected using the "global" parameter, GWInboundManipulationSet. If this parameter is not configured, then no manipulation is done.
- Manipulating outbound SIP INVITE messages: The Manipulation Set ID is selected using the following logic:
 - a. According to the settings of the 'Outbound Message Manipulation Set' parameter configured for the destination IP Group (in the IP Group table). In other words, manipulation can be done per destination IP Group. If this parameter is not configured, see below.
 - b. According to the settings of the "global" parameter, GWOutboundManipulationSet. If this parameter is not configured, no manipulation is done.

The figure below illustrates a SIP message manipulation example:

Figure 17-1: SIP Header Manipulation Example



Notes:

- For a detailed description of the syntax for configuring SIP message manipulation rules, refer to *SIP Message Manipulations Quick Reference Guide*.
- For the IP-to-IP application, the outgoing message is re-created and thus, SIP headers that are not relevant to the outgoing SIP session (e.g., Referred-By) are not included in the outgoing message. Therefore, if required, manipulations on such headers should be handled in inbound manipulation.
- The values entered in the table are not case-sensitive.
- Each message can be manipulated twice - on the source leg and on the destination leg (i.e., source and destination IP Groups).
- Unknown SIP parts can only be added or removed.
- SIP manipulations do not allow you to remove or add mandatory SIP headers. They can only be modified and only on requests that initiate new dialogs. Mandatory SIP headers include To, From, Via, CSeq, Call-Id, and Max-Forwards.
- The Message Manipulations table can also be configured using the table *ini* file parameter, MessageManipulations.



- **To configure SIP message manipulation rules:**
- 1. Open the Message Manipulations page (**Configuration** tab > **VoIP** menu > **SIP Definitions** > **Msg Policy & Manipulation** > **Message Manipulations**).
- 2. Click the **Add** button; the following dialog box appears:

Figure 17-2: Message Manipulations Table - Add Record Dialog Box

- 3. Configure the SIP message manipulation rule as required. See the table below for a description of each parameter.
- 4. Click **Submit** to apply your changes.

The figure below displays an example of configured message manipulation rules:

- Index 0 - adds the suffix ".com" to the host part of the To header.
- Index 1 - changes the user part of the From header to the user part of the P-Asserted-ID.
- Index 2 - changes the user part of the SIP From header to "200".
- Index 3 - if the user part of the From header equals "unknown", then it is changed according to the srcIPGroup call's parameter.
- Index 4 - removes the Priority header from an incoming INVITE message.

Figure 17-3: Message Manipulations Page

Index	Manipulation Set ID	Message Type	Condition	Action Subject	Action Type	Action Value
0	0	invite.response.200		header.to.url.user	Add Prefix	'.com'
1	1	invite.response.200		header.from.url.user	Modify	header.p-asserted-id.url.user
2	2	invite.request		header.from.url.user	Modify	'200'
3	3	invite.request	header.from.url.user=='Unkn	header.from.url.user	Modify	param.ipq.src.user
4	4	invite.request		header.priority	Remove	

Message Manipulations Parameters

Parameter	Description
Index [MessageManipulations_Index]	Defines the table row index for the rule. The valid value is 0 to 99. The default is 0. Note: Each rule must be configured with a unique index.
Manipulation Set ID CLI: manipulation-set-id	Defines a Manipulation Set ID for the rule. You can define the same Manipulation Set ID for multiple rules to create a group of rules. The

Parameter	Description
[MessageManipulations_ManSetID]	Manipulation Set ID is used to assign the manipulation rules to an IP Group (in the IP Group table) for inbound and/or outbound messages. The valid value is 0 to 19. The default is 0.
Matching Characteristics	
Message Type [MessageManipulations_MessageType]	<p>Defines the SIP message type that you want to manipulate. The valid value is a string denoting the SIP message. For example:</p> <ul style="list-style-type: none"> ▪ Empty = rule applies to all messages ▪ Invite = rule applies to all INVITE requests and responses ▪ Invite.Request = rule applies to INVITE requests ▪ Invite.Response = rule applies to INVITE responses ▪ subscribe.response.2xx = rule applies to SUBSCRIBE confirmation responses <p>Note: Currently, SIP 100 Trying messages cannot be manipulated.</p>
Condition [MessageManipulations_Condition]	<p>Defines the condition that must exist for the rule to apply. The valid value is a string. For example:</p> <ul style="list-style-type: none"> ▪ header.from.url.user== '100' (indicates that the user part of the From header must have the value "100") ▪ header.contact.param.expires > '3600' ▪ header.to.url.host contains 'domain' ▪ param.call.dst.user != '100'
Operation	
Action Subject [MessageManipulations_ActionSubject]	Defines the SIP header upon which the manipulation is performed.
Action Type [MessageManipulations_ActionType]	<p>Defines the type of manipulation.</p> <ul style="list-style-type: none"> ▪ [0] Add (default) = adds new header/param/body (header or parameter elements). ▪ [1] Remove = removes header/param/body (header or parameter elements). ▪ [2] Modify = sets element to the new value (all element types). ▪ [3] Add Prefix = adds value at the beginning of the string (string element only). ▪ [4] Add Suffix = adds value at the end of the string (string element only). ▪ [5] Remove Suffix = removes value from the end of the string (string element only). ▪ [6] Remove Prefix = removes value from the beginning of the string (string element only).
Action Value [MessageManipulations_ActionValue]	<p>Defines a value (string) that you want to use in the manipulation. The syntax is as follows:</p> <ul style="list-style-type: none"> ▪ string/<message-element>/<call-param> + ▪ string/<message-element>/<call-param> <p>For example:</p> <ul style="list-style-type: none"> ▪ 'itsp.com' ▪ header.from.url.user

Parameter	Description
	<ul style="list-style-type: none"> ▪ param.call.dst.user ▪ param.call.dst.host + '.com' ▪ param.call.src.user + '<' + header.from.url.user + '@' + header.p-asserted-id.url.host + '>' <p>Note: Only single quotation marks must be used.</p>
Row Role [MessageManipulations_RowRole]	Determines which condition must be used for the rule of this table row. <ul style="list-style-type: none"> ▪ [0] Use Current Condition = The condition entered in this row must be matched in order to perform the defined action (default). ▪ [1] Use Previous Condition = The condition of the rule configured directly above this row must be used in order to perform the defined action. This option allows you to configure multiple actions for the same condition. <p>Note: When multiple manipulations rules apply to the same header, the next rule applies to the result string of the previous rule.</p>

17.5 Configuring SIP Message Policy Rules

You can configure SIP message policy rules for blocking (blacklist) unwanted incoming SIP messages or allowing (whitelist) receipt of desired messages. This feature allows you to define legal and illegal characteristics of a SIP message. Message policies can be applied globally (default) or per signaling domain by assigning it to a SIP interface in the SIP Interface table (see 'Configuring SIP Interface Table' on page 212).

This feature is helpful against VoIP fuzzing (also known as robustness testing), which sends different types of packets to its "victims" for finding bugs and vulnerabilities. For example, the attacker might try sending a SIP message containing either an over-sized parameter or too many occurrences of a parameter.

Each message policy rule can be configured with the following:

- Maximum message length
- Maximum SIP header length
- Maximum message body length
- Maximum number of headers
- Maximum number of bodies
- Option to send 400 "Bad Request" response if message request is rejected
- Blacklist and whitelist for defined SIP methods (e.g., INVITE)
- Blacklist and whitelist for defined SIP bodies



Note: The Message Policy table can also be configured using the table ini file parameter, MessagePolicy.

- **To configure SIP message policy rules:**
- 1. Open the Message Policy Table page (**Configuration** tab > **VoIP** menu > **SIP Definitions** > **Msg Policy & Manipulation** > **Message Policy Table**).
- 2. Click the **Add** button; the Add Record dialog box appears:

Figure 17-4: Message Policy Table - Add Record Dialog Box

The policy defined above limits SIP messages to 32,768 characters, headers to 256 characters, bodies to 512 characters, number of headers to 16, and only permits two bodies. Invalid requests are rejected. Only INVITE and BYE requests are permitted and there are no restrictions on bodies.

- 3. Configure the SIP message policy rule as required. See the table below for a description of each parameter.
- 4. Click **Submit** to apply your changes.
- 5. To save the changes to flash memory, see 'Saving Configuration' on page 494.

SIP Message Policy Parameters

Parameter	Description
Index [MessagePolicy_Index]	Defines the table index entry.
Max Message Length [MessagePolicy_MaxMessageLength]	Defines the maximum SIP message length. The valid value is up to 32,768 characters. The default is 32,768.
Max Header Length [MessagePolicy_MaxHeaderLength]	Defines the maximum SIP header length. The valid value is up to 512 characters. The default is 512.
Max Body Length [MessagePolicy_MaxBodyLength]	Defines the maximum SIP message body length. This is the value of the Content-Length header. The valid value is up to 1,024 characters. The default is 1,024.
Max Num Headers [MessagePolicy_MaxNumHeaders]	Defines the maximum number of SIP headers. The valid value is any number up to 32. The default is 32. Note: The device supports up to 20 SIP Record-Route headers that can be received in a SIP INVITE request or 200 OK response. If it receives more than this, it responds with a SIP 513 'Message Too Large'

Parameter	Description
	response.
Max Num Bodies [MessagePolicy_MaxNumBodies]	Defines the maximum number of bodies (e.g., SDP) in the SIP message. The valid value is any number up to 8. The default is 8.
Send Rejection [MessagePolicy_SendRejection]	Determines whether the device sends a 400 "Bad Request" response if a message request is rejected. <ul style="list-style-type: none"> ▪ [0] Policy Reject = (Default) If the message is a request, then the device sends a response to reject the request. ▪ [1] Policy Drop = The device ignores the message without sending any response.
Method List [MessagePolicy_MethodList]	Defines the SIP methods (e.g., INVITE\BYE) to which the rule applies. The syntax for entering the methods is as follows: <ul style="list-style-type: none"> ▪ Methods must be separated by a backslash (\). ▪ The entered value is not case sensitive.
Method List Type [MessagePolicy_MethodListType]	Determines the policy for the SIP methods. <ul style="list-style-type: none"> ▪ [0] Policy Blacklist = The specified methods (in the 'Method List' field) are rejected by the policy. ▪ [1] Policy Whitelist = (Default) The specified methods (in the 'Method List' field) are allowed by the policy.
Body List [MessagePolicy_BodyList]	Defines the SIP body (i.e., value of the Content-Type header) to which the rule applies.
Body List Type [MessagePolicy_BodyListType]	Determines the policy for the defined SIP body. <ul style="list-style-type: none"> ▪ [0] Policy Blacklist = The specified SIP body (in the 'Body List' field) is rejected by the policy. ▪ [1] Policy Whitelist = (Default) The specified SIP body (in the 'Body List' field) is allowed by the policy.

Reader's Notes

18 Coders and Profiles

This section describes configuration of the coders and SIP profiles parameters.

18.1 Configuring Coders

The Coders page allows you to configure up to 10 voice coders for the device. Each coder can be configured with packetization time (ptime), bit rate, payload type, and silence suppression. The first coder configured in the table has the highest priority and is used by the device whenever possible. If the remote side cannot use the first coder, the device attempts to use the next coder in the table, and so on.

Notes:

- A specific coder can only be configured once in the table.
- If packetization time and/or rate are not specified, the default is applied.
- Only the packetization time of the first coder in the coder list is declared in INVITE/200 OK SDP, even if multiple coders are defined.
- The device always uses the packetization time requested by the remote side for sending RTP packets. If not specified, the packetization time is assigned the default value.
- The value of several fields is hard-coded according to common standards (e.g., payload type of G.711 U-law is always 0). Other values can be set dynamically. If no value is specified for a dynamic field, a default is assigned. If a value is specified for a hard-coded field, the value is ignored.
- If silence suppression is not configured for a coder, the settings of the EnableSilenceCompression parameter is used.
- The G.722 coder provides Packet Loss Concealment (PLC) capabilities, ensuring higher voice quality.
- Both GSM-FR and MS-GSM coders use Payload Type 3. When using SDP, it isn't possible to differentiate between the two. Therefore, it is recommended not to select both coders simultaneously.
- For G.729, it's also possible to select silence suppression without adaptations.
- If G.729 is selected and silence suppression is disabled, the device includes 'annexb=no' in the SDP of the relevant SIP messages. If silence suppression is enabled or set to 'Enable w/o Adaptations', 'annexb=yes' is included. An exception to this logic is when the remote gateway is a Cisco device (IsCiscoSCEMode).
- For defining groups of coders, which can be assigned to Tel and IP Profiles, see 'Configuring Coder Groups' on page [242](#).
- For information on V.152 and implementation of T.38 and VBD coders, see 'Supporting V.152 Implementation' on page [168](#).
- The Coders table can also be configured using the table *ini* file parameter, CodersGroup.



➤ **To configure the device's coders:**

1. Open the Coders page (**Configuration** tab > **VoIP** menu > **Coders and Profiles** submenu > **Coders**).

Figure 18-1: Coders Table Page

Coder Name	Packetization Time	Rate	Payload Type	Silence Suppression
G.723.1	30	5.3	4	Disabled

2. From the 'Coder Name' drop-down list, select the required coder.
3. From the 'Packetization Time' drop-down list, select the packetization time (in msec) for the selected coder. The packetization time determines how many coder payloads are combined into a single RTP packet.
4. From the 'Rate' drop-down list, select the bit rate (in kbps) for the selected coder.
5. In the 'Payload Type' field, if the payload type (i.e., format of the RTP payload) for the selected coder is dynamic, enter a value from 0 to 120 (payload types of 'well-known' coders cannot be modified).
6. From the 'Silence Suppression' drop-down list, enable or disable the silence suppression option for the selected coder.
7. Repeat steps 2 through 6 for the next optional coders.
8. Click **Submit**.
9. To save the changes to flash memory, see 'Saving Configuration' on page 494.

The table below lists the supported coders:

Supported Coders

Coder Name	Packetization Time (msec)	Rate (kbps)	Payload Type	Silence Suppression
G.711 A-law [g711Alaw64k]	10, 20 (default), 30, 40, 50, 60, 80, 100, 120	64	8	<ul style="list-style-type: none"> ▪ [0] Disable ▪ [1] Enable
G.711 U-law [g711Ulaw64k]	10, 20 (default), 30, 40, 50, 60, 80, 100, 120	64	0	<ul style="list-style-type: none"> ▪ [0] Disable ▪ [1] Enable
G.711A-law_VBD [g711AlawVbd]	10, 20 (default), 30, 40, 50, 60, 80, 100, 120	64	Dynamic (0-127) Default is 180	N/A
G.711U-law_VBD [g711UlawVbd]	10, 20 (default), 30, 40, 50, 60, 80, 100, 120	64	Dynamic (0-127) Default is 120	N/A
G.722 [g722]	20 (default), 40, 60, 80, 100, 120	64 (default)	9	N/A

Coder Name	Packetization Time (msec)	Rate (kbps)	Payload Type	Silence Suppression
G.723.1 [g7231]	30 (default), 60, 90, 120, 150	<ul style="list-style-type: none"> ▪ [0] 5.3 (default) ▪ [1] 6.3 	4	<ul style="list-style-type: none"> ▪ [0] Disable ▪ [1] Enable
G.726 [g726]	10, 20 (default), 30, 40, 50, 60, 80, 100, 120	<ul style="list-style-type: none"> ▪ [0] 16 ▪ [1] 24 ▪ [2] 32 (default) ▪ [3] 40 	Dynamic (0-127) Default is 23	<ul style="list-style-type: none"> ▪ [0] Disable ▪ [1] Enable
G.727 ADPCM	10, 20 (default), 30, 40, 50, 60, 80, 100, 120	16, 24, 32, 40	Dynamic (0-127)	<ul style="list-style-type: none"> ▪ [0] Disable ▪ [1] Enable
G.729 [g729]	10, 20 (default), 30, 40, 50, 60, 80, 100	8	18	<ul style="list-style-type: none"> ▪ [0] Disable ▪ [1] Enable ▪ [2] Enable w/o Adaptations
GSM-FR [gsmFullRate]	20 (default), 40, 60, 80	13	3	<ul style="list-style-type: none"> ▪ [0] Disable ▪ [1] Enable
GSM-EFR [gsmEnhancedFullRate]	0, 20 (default), 30, 40, 50, 60, 80, 100	12.2	Dynamic (0-127)	<ul style="list-style-type: none"> ▪ [0] Disable ▪ [1] Enable
MS-GSM [gsmMS]	40 (default)	13	3	<ul style="list-style-type: none"> ▪ [0] Disable ▪ [1] Enable
AMR [Amr]	20 (default)	<ul style="list-style-type: none"> ▪ [0] 4.75 ▪ [1] 5.15 ▪ [2] 5.90 ▪ [3] 6.70 ▪ [4] 7.40 ▪ [5] 7.95 ▪ [6] 10.2 ▪ [7] 12.2 (default) 	Dynamic (0-127)	<ul style="list-style-type: none"> ▪ [0] Disable ▪ [1] Enable
QCELP [QCELP]	20 (default), 40, 60, 80, 100, 120	13	12	<ul style="list-style-type: none"> ▪ [0] Disable ▪ [1] Enable
EVRC [Evrc]	20 (default), 40, 60, 80, 100	<ul style="list-style-type: none"> ▪ [0] Variable (default) ▪ [1] 1/8 ▪ [3] 1/2 ▪ [4] Full 	Dynamic (0-127)	<ul style="list-style-type: none"> ▪ [0] Disable ▪ [1] Enable
iLBC [iLBC]	20 (default), 40, 60, 80, 100, 120 30 (default), 60, 90, 120	15 (default) 13	Dynamic (0-127)	<ul style="list-style-type: none"> ▪ [0] Disable ▪ [1] Enable
Transparent [Transparent]	10, 20 (default), 40, 60, 80, 100, 120	64	Dynamic (0-127)	<ul style="list-style-type: none"> ▪ [0] Disable ▪ [1] Enable
T.38 [t38fax]	N/A	N/A	N/A	N/A

18.2 Configuring Coder Groups

The Coder Group Settings page allows you to define up to 10 groups of coders (termed *Coder Groups*). For each Coder Group, you can define up to 10 coders configured with packetization time (ptime), rate, payload type, and silence suppression. The first coder in the Coder Group table has the highest priority and is used by the device whenever possible. If the remote side cannot use the first coder, the device attempts to use the next coder, and so on.

Coder Groups can be used as follows:

- Assigned to Tel Profiles in the Tel Profiles table (see [Configuring Tel Profiles](#) on page 243).
- Assigned to IP Profiles in the IP Profiles table (see ['Configuring IP Profiles'](#) on page 245).



Notes:

- A specific coder can be selected only once per Coder Group.
- For a list of supported coders, see ['Configuring Coders'](#) on page 239.
- The Coder Group Settings table can also be configured using the table *ini* file parameter, `CodersGroup`.

➤ **To configure Coder Groups:**

1. Open the Coder Group Settings page (**Configuration** tab > **VoIP** menu > **Coders and Profiles** submenu > **Coders Group Settings**).

Figure 18-2: Coder Group Settings Page

Coder Group ID: 1				
Coder Name	Packetization Time	Rate	Payload Type	Silence Suppression
G.723.1	30	5.3	4	Disabled

2. From the 'Coder Group ID' drop-down list, select a Coder Group ID.
3. From the 'Coder Name' drop-down list, select the first coder for the Coder Group.
4. From the 'Packetization Time' drop-down list, select the packetization time (in msec) for the coder. The packetization time determines how many coder payloads are combined into a single RTP packet.
5. From the 'Rate' drop-down list, select the bit rate (in kbps) for the coder you selected.
6. In the 'Payload Type' field, if the payload type (i.e., format of the RTP payload) for the coder you selected is dynamic, enter a value from 0 to 120 (payload types of common coders cannot be modified).
7. From the 'Silence Suppression' drop-down list, enable or disable the silence suppression option for the coder you selected.

8. Repeat steps 3 through 7 for the next coders (optional).
9. Repeat steps 2 through 8 for the next coder group (optional).
10. Click **Submit** to apply your changes.

18.3 Configuring Tel Profile

The Tel Profile Settings table allows you to define up to nine configuration profiles for Tel calls. These profiles are termed *Tel Profiles*. The Tel Profile Settings table contains a list of parameters, which can also be configured globally for all calls using their corresponding "global" parameters. The only difference between the Tel Profile parameters and the global parameters regarding description may be their default values.

Tel Profiles provide high-level adaptation when the device interworks between different equipment and protocols (at both the Tel and IP sides), each of which may require different handling by the device. Once configured, Tel Profiles can be assigned to specific channels (trunks). Therefore, Tel Profiles enable you to assign special configuration settings for device handling of specific calls. For example, if specific channels require the use of the G.711 coder, you can configure a Tel Profile with this coder and assign it to these channels. Tel Profiles are assigned to channels in the Trunk Group Table (see [Configuring the Trunk Group Table on page 291](#))).

The procedure below describes how to configure Tel Profiles using the Web interface.



Note: Tel Profiles can also be configured using the table *ini* file parameter, `TelProfile` (see 'Configuration Parameters Reference' on page [609](#))

➤ **To configure Tel Profiles:**

1. Open the Tel Profile Settings page (**Configuration** tab > **VoIP** menu > **Coders and Profiles** submenu > **Tel Profile Settings**).

Profile ID	1
Profile Name	mike
Profile Parameters	
Profile Preference	1
Fax Signaling Method	No Fax
Dynamic Jitter Buffer Minimum Delay [msec]	10
Dynamic Jitter Buffer Optimization Factor	10
RTP IP DiffServ	46
Signaling DiffServ	40
Voice Volume (-32 to 31 dB)	0
DTMF Volume (-31 to 0 dB)	-11
Input Gain (-32 to 31 dB)	0
Enable Digit Delivery	Disable
Enable Polarity Reversal	Enable
Enable Current Disconnect	Disable
MWI Analog Lamp	Disable
MWI Display	Disable
Dial Plan Index	-1
Echo Canceler	Enable
Flash Hook Period	700
Enable Early Media	Disable
Progress Indicator to IP	Not Configured
Enable DID Wink	Disable
Dialing Mode	Two Stages
Enable Voice Mail Delay	Enable
Disconnect Call on Detection of Busy Tone	Enable
Time For Reorder Tone [sec]	255
Enable 911 PSAP	Disable
Enable AGC	Disable
EC NLP Mode	Adaptive NLP
Swap Tel To IP Phone Numbers	Disable
Coder Group	
Coder Group	Default Coder Group

2. From the 'Profile ID' drop-down list, select the Tel Profile index.
3. In the 'Profile Name' field, enter an arbitrary name that enables you to easily identify the Tel Profile.
4. From the 'Profile Preference' drop-down list, select the priority of the Tel Profile, where **1** is the lowest priority and **20** the highest. If both IP and Tel profiles apply to the same

call, the coders and other common parameters (noted by an asterisk in the description of the parameter TelProfile) of the preferred Profile are applied to that call. If the Preference of the Tel and IP Profiles is identical, the Tel Profile parameters are applied.

Note: If the coder lists of both IP and Tel Profiles apply to the same call, only the coders common to both are used. The order of the coders is determined by the preference.

5. Configure the parameters as required. For a description of each parameter, refer to the corresponding "global" parameter.
6. Click **Submit** to apply your changes.

18.4 Configuring IP Profiles

The IP Profile Settings table allows you to define up to nine *IP Profiles*. An IP Profile is a set of special call configuration behaviors relating to signaling (e.g., SIP message terminations such as REFER) and media (e.g., coder used) applied to specific IP calls (inbound and/or outbound). Therefore, IP Profiles provide high-level adaptation when the device interworks between different IP entities (for Tel and IP sides), each of which may require different handling by the device. For example, if a specific IP entity uses the G.711 coder only, you can configure an IP Profile with G.711 for this IP entity.

Many of the parameters in the IP Profile Settings table have a corresponding "global" parameter. If an IP Profile is not associated with specific calls, the settings of the global parameters are applied to these calls.

IP Profiles can be assigned to the following configuration elements:

- IP Groups - see [Configuring IP Groups](#) on page 214
- Outbound IP routing rules (for Gateway / IP-to-IP application) - see [Configuring Outbound IP Routing Table](#) on page 323
- Inbound IP routing rules (for Gateway / IP-to-IP application) - see [Configuring Inbound IP Routing Table](#) on page 332

The device selects the IP Profile as follows:

- If different IP Profiles (not default) are assigned to the same specific calls in all these tables, the device uses the IP Profile that has the highest preference level (as set in the 'Profile Preference' field). If they have the same preference level, the device uses the IP Profile assigned in the IP Group table.
- If different IP Profiles are assigned to these tables and one table is set to the default IP Profile, the device uses the IP Profile that is not the default.



Notes:

- IP Profiles can also be implemented when using a Proxy server (when the AlwaysUseRouteTable parameter is set to 1).
- RxDTMFOption configures the received DTMF negotiation method: [-1] not configured, use the global parameter; [0] don't declare RFC 2833; [1] declare RFC 2833 payload type is SDP.
- You can also configure IP Profiles using the table ini file parameter, IPProfile (see [Configuration Parameters Reference](#) on page 609).

➤ **To configure IP Profiles:**

1. Open the IP Profile Settings page (**Configuration** tab > **VoIP** menu > **Coders and Profiles** submenu > **IP Profile Settings**).

Profile ID	1
Profile Name	
Common Parameters	
RTP IP DiffServ	46
Signaling DiffServ	40
Disconnect on Broken Connection	Yes
Dynamic Jitter Buffer Minimum Delay [msec](*)	10
Dynamic Jitter Buffer Optimization Factor(*)	10
RTP Redundancy Depth(*)	0
Echo Canceler(*)	Enable
Input Gain (-32 to 31 dB)(*)	0
Voice Volume (-32 to 31 dB)(*)	0
Gateway Parameters	
Fax Signaling Method	No Fax
Play Ringback Tone to IP	Don't Play
Enable Early Media	Disable
Copy Destination Number to Redirect Number	Disable
Media Security Behavior	Preferable
CNG Detector Mode	Disable
Modems Transport Type	Enable Bypass
NSE Mode	Disable
Number of Calls Limit	-1
Progress Indicator to IP	Not Configured
Profile Preference	1
Coder Group	Default Coder Group
Remote RTP Base UDP Port	0
First Tx DTMF Option	RFC 2833
Second Tx DTMF Option	
Declare RFC 2833 in SDP	Yes
Add IE In SETUP	
AMD Sensitivity Parameter Suit	0
AMD Sensitivity Level	8
AMD Max Greeting Time	300
AMD Max Post Silence Greeting Time	400
Enable Hold	Enable

2. From the 'Profile ID' drop-down list, select the IP Profile index.
3. In the 'Profile Name' field, enter an arbitrary name that allows you to easily identify the IP Profile.
4. From the 'Profile Preference' drop-down list, select the priority of the IP Profile, where '1' is the lowest priority and '20' is the highest. If both IP and Tel profiles apply to the same call, the coders and other common parameters (noted by an asterisk) of the preferred Profile are applied to that call. If the Preference of the Tel and IP Profiles is identical, the Tel Profile parameters are applied.
Note: If the coder lists of both IP and Tel Profiles apply to the same call, only the coders common to both are used. The order of the coders is determined by the preference.
5. Configure the parameters as required.
6. Click **Submit** to apply your changes.

Table 18-1: IP Profile Parameters Description

Parameter	Description
Web: Profile ID [IpProfile_Index]	Defines a unique index number for the IP Profile.
Web: Profile Name [IpProfile_ProfileName]	(Optional) Defines a descriptive name for the IP Profile.
Common Parameters	
Web: RTP IP DiffServ [IpProfile_IPDiffServ]	For a description, see the global parameter PremiumServiceClassMediaDiffServ.
Web: Signaling DiffServ [IpProfile_SigIPDiffServ]	For a description, see the global parameter PremiumServiceClassControlDiffServ.
Web: Disconnect on Broken Connection [IpProfile_DisconnectOnBrokenConnection]	For a description, see the global parameter DisconnectOnBrokenConnection.
Web: Media IP Version Preference [IpProfile_MediaIPVersionPreference]	For a description, see the global parameter MediaIPVersionPreference.
Web: Dynamic Jitter Buffer Minimum Delay [IpProfile_JitterBufMinDelay]	For a description, see the global parameter DJBufMinDelay.
Web: Dynamic Jitter Buffer Optimization Factor [IpProfile_JitterBufOptFactor]	For a description, see the global parameter DJBufOptFactor.
Web: RTP Redundancy Depth [IpProfile_RTPRedundancyDepth]	For a description, see the global parameter RTPRedundancyDepth.
Web: Echo Canceled [IpProfile_EnableEchoCanceller]	For a description, see the global parameter EnableEchoCanceller.
Web: Input Gain [IpProfile_InputGain]	For a description, see the global parameter InputGain.
Web: Voice Volume [IpProfile_VoiceVolume]	For a description, see the global parameter VoiceVolume.
Web: Symmetric MKI Negotiation [IpProfile_EnableSymmetricMKI]	For a description, see the global parameter EnableSymmetricMKI.
Web: MKI Size [IpProfile_MKISize]	For a description, see the global parameter SRTPTxPacketMKISize.
Gateway Parameters	
Web: Fax Signaling Method [IpProfile_IsFaxUsed]	For a description, see the global parameter IsFaxUsed.
Web: Play Ringback Tone to IP [IpProfile_PlayRBTone2IP]	For a description, see the global parameter PlayRBTone2IP.

Parameter	Description
Web: Enable Early Media [IpProfile_EnableEarlyMedia]	For a description, see the global parameter EnableEarlyMedia.
Web: Copy Destination Number to Redirect Number [IpProfile_CopyDest2RedirectNumber]	For a description, see the global parameter CopyDest2RedirectNumber.
Web: Media Security Behavior [IpProfile_MediaSecurityBehaviour]	For a description, see the global parameter MediaSecurityBehaviour.
Web: CNG Detector Mode [IpProfile_CNGmode]	For a description, see the global parameter CNGDetectorMode.
Web: Modems Transport Type [IpProfile_VxxTransportType]	For a description, see the global parameters V21ModemTransportType, V22ModemTransportType, V23ModemTransportType, V32ModemTransportType, and V34ModemTransportType.
Web: NSE Mode [IpProfile_NSEMode]	For a description, see the global parameter NSEMode.
Web: Number of Calls Limit [IpProfile_CallLimit]	<p>Defines the maximum number of concurrent calls (incoming and outgoing). If the number of concurrent calls reaches this limit, the device rejects any new incoming and outgoing calls belonging to this IP Profile.</p> <p>This parameter can also be set to the following:</p> <ul style="list-style-type: none"> ▪ [-1] = (Default) No limitation on calls. ▪ [0] = Calls are rejected. <p>Note: For IP-to-IP calls, you can configure the device to route calls to an alternative IP Group when this maximum number of concurrent calls is reached. To do so, you need to add an alternative routing rule in the Outbound IP Routing table that reroutes the call to an alternative IP Group. You also need to add a rule to the Reason for Alternative Routing table to initiate an alternative rule for Tel-to-IP calls using cause 805.</p>
Web: Progress Indicator to IP [IpProfile_ProgressIndicator2IP]	For a description, see the global parameter ProgressIndicator2IP.
Web: Profile Preference [IpProfile_IpPreference]	<p>Defines the priority of the IP Profile, where "1" is the lowest and "20" the highest. If both IP and Tel Profiles apply to the same call, the coders and other common parameters of the preferred profile are applied to the call. If the preference of the Tel and IP Profiles is identical, the Tel Profile parameters are applied.</p> <p>Note: If the coder lists of both IP and Tel Profiles apply to the same call, only the coders common to both are used. The order of the coders is determined by the preference.</p>
Web: Coder Group [IpProfile_CodersGroupID]	For a description, see the global parameter CodersGroup.
Web: Remote RTP Base UDP Port [IpProfile_RemoteBaseUDPPort]	For a description, see the global parameter RemoteBaseUDPPort.
Web: First Tx DTMF Option [IpProfile_FirstTxDtmfOption]	For a description, see the global parameter TxDTMFOption.

Parameter	Description
Web: Second Tx DTMF Option [IpProfile_SecondTxDtmfOption]	For a description, see the global parameter TxDTMFOption.
Web: Declare RFC 2833 in SDP [IpProfile_RxDTMFOption]	For a description, see the global parameter RxDTMFOption.
Web: Add IE In SETUP [IpProfile_AddIEInSetup]	For a description, see the global parameter AddIEInSetup.
Web: AMD Sensitivity Level [IpProfile_AMDSensitivityParameterSuit]	For a description, see the global parameter AMDSensitivityLevel.
Web: AMD Sensitivity Level [IpProfile_AMDSensitivityLevel]	For a description, see the global parameter AMDSensitivityLevel.
Web: AMD Max Greeting Time [IpProfile_AMDMaxGreetingTime]	For a description, see the global parameter AMDMaxGreetingTime.
Web: AMD Max Post Silence Greeting Time [IpProfile_AMDMaxPostSilenceGreetingTime]	For a description, see the global parameter AMDMaxPostGreetingSilenceTime.
Web: Enable QSIG Tunneling [IpProfile_EnableQSIGTunneling]	For a description, see the global parameter EnableQSIGTunneling.
Web: Enable Hold [IpProfile_EnableHold]	For a description, see the global parameter EnableHold.
[IpProfile_EnableEarly183]	For a description, see the global parameter EnableEarly183.
[IpProfile_EarlyAnswerTimeout]	For a description, see the global parameter EarlyAnswerTimeout.

Reader's Notes

Part V

Gateway and IP-to-IP Application

19 Introduction

This section describes configuration of the Gateway and IP-to-IP applications. The Gateway application refers to IP-to-Tel (PSTN) call routing and vice versa. The IP-to-IP application refers to call routing of calls received from the IP and forwarded to an IP destination. For a description of the IP-to-IP application, see IP-to-IP Routing Application on page 255.

**Notes:**

- In some areas of the Web interface, the term "GW" and "IP2IP" application refers to the Gateway and IP-to-IP applications, respectively.
- The terms *IP-to-Tel* and *Tel-to-IP* refer to the direction of the call relative to the device. IP-to-Tel refers to calls received from the IP network and destined to the PSTN/PBX (i.e., telephone connected directly or indirectly to the device); Tel-to-IP refers to calls received from telephones connected directly to the device's FXS ports or from the PSTN/PBX, and destined for the IP network.
- FXO (Foreign Exchange Office) is the interface replacing the analog telephone and connects to a Public Switched Telephone Network (PSTN) line from the Central Office (CO) or to a Private Branch Exchange (PBX). The FXO is designed to receive line voltage and ringing current, supplied from the CO or the PBX (just like an analog telephone). An FXO VoIP device interfaces between the CO/PBX line and the Internet.
- FXS (Foreign Exchange Station) is the interface replacing the Exchange (i.e., the CO or the PBX) and connects to analog telephones, dial-up modems, and fax machines. The FXS is designed to supply line voltage and ringing current to these telephone devices. An FXS VoIP device interfaces between the analog telephone devices and the Internet.

Reader's Notes

20 IP-to-IP Routing Application

The device's IP-to-IP application supports IP-to-IP VoIP call routing (or SIP Trunking). The IP-to-IP call routing application enables enterprises to seamlessly connect their IP-based PBX (IP-PBX) to SIP trunks, typically provided by Internet Telephony Service Providers (ITSP). The device enables the enterprise to communicate with the PSTN network (local and overseas) through the ITSP, which interfaces directly with the PSTN. Therefore, the IP-to-IP application enables enterprises to replace the bundles of physical PSTN wires with SIP trunks provided by ITSPs and use VoIP to communicate within and outside the enterprise network using its standard Internet connection. At the same time, the device can also provide an interface with the traditional PSTN network, enabling PSTN fallback in case of IP connection failure with the ITSPs.

The device also supports multiple SIP Trunking. This can be useful in scenarios where if a connection to one ITSP fails, the call can immediately be transferred to another ITSP. In addition, by allowing multiple SIP trunks where each trunk is designated a specific ITSP, the device can route calls to an ITSP based on call destination (e.g., country code).

In addition to providing VoIP communication within the enterprise's LAN, the device enables the enterprise to communicate outside of the corporate LAN using SIP Trunking. This includes remote (roaming) IP-PBX users, for example, employees using their laptops to communicate with one another from anywhere in the world such as at airports.

The IP-to-IP application can be implemented by enterprises in the following example scenarios:

- VoIP between an enterprise's headquarters and remote branch offices
- VoIP between an enterprise and the PSTN through an ITSP

The IP-to-IP call routing capability is feature-rich, allowing interoperability with different ITSPs:

- Easy and smooth integration with multiple ITSP SIP trunks.
- Supports SIP registration and authentication with ITSP servers (on behalf of the enterprise's IP telephony system) even if the enterprise's IP telephony system does not support registration and authentication.
- Supports SIP-over-UDP, SIP-over-TCP, and SIP-over-TLS transport protocols, one of which is generally required by the ITSP.
- Provides alternative routing to different destinations (to another ITSP or the PSTN) when the connection with an ITSP network is down.
- Provides fallback to the legacy PSTN telephone network upon Internet connection failure.
- Provides Transcoding from G.711 to G.729 coder with the ITSP for bandwidth reduction.
- Supports SRTP, providing voice traffic security toward the ITSP.
- IP-to-IP routing can be used in combination with the regular Gateway application. For example, an incoming IP call can be sent to an E1/T1 span or it can be forwarded to an IP destination.

Therefore, the device provides the ideal interface between the enterprise IP-PBX and the ITSP SIP trunk.

The device's IP-to-IP application handles and terminates SIP methods and responses at each leg independently:

- Initiating-dialog INVITE: terminated at one leg and initiated on the other leg, 180\182\183\200\4xx uses the same logic and same limitations, in some cases the result may be a different response code.
- OPTIONS: terminated at each leg independently.
- INFO: only specific INFO's (such as DTMF) are handled; other types are omitted.

- UPDATE: terminated at each leg independently and may cause only changes in the RTP flow - Hold/Retrieve are the only exceptions that traverse the two legs.
- Re-INVITE: terminated at each leg independently and may cause only changes in the RTP flow - Hold/Retrieve are the only exceptions that traverse the two legs.
- PRACK: terminated at each leg independently.
- REFER (within a dialog): terminated at each leg independently.
- 3xx Responses: terminated at each leg independently.
- 401/407 responses to initial INVITE: in case the back-to-back session is associated with an Account, the responses is terminated at the receiving leg; in other cases, the responses are passed transparently.
- REGISTER: handled only in cases associated with a User-type IP Group - Contact, To, From specific parameters are omitted.

20.1 Theory of Operation

The device's IP-to-IP SIP session is performed by implementing Back-to-Back User Agent (B2BUA). The device acts as a user agent for both ends (*legs*) of the SIP call (from call establishment to termination). The session negotiation is performed independently for each call leg, using global parameters such as coders or using IP Profiles associated with each call leg to assign different configuration behaviors for these two IP-to-IP call legs.


If transcoding is required, the RTP streams for IP-to-IP calls traverse the device and two DSP channels are allocated per IP-to-IP session. Therefore, the maximum number of IP-to-IP sessions is 60 (corresponding to a maximum of 120 media channels that can be designated for IP-to-IP call routing is).

If transcoding is not needed, the device supports up to 150 IP-to-IP SIP sessions (without using DSP channels).

The device also supports NAT traversal for SIP clients behind NAT, where the device is defined with a global IP address.

The figure below provides a simplified illustration of the device's handling of IP-to-IP call routing:

Figure 20-1: Basic Schema of the Device's IP-to-IP Call Handling



The basic IP-to-IP call handling process can be summarized as follows:

1. Incoming IP calls are identified as belonging to a specific logical entity in the network referred to as a *Source IP Group*, according to Inbound IP Routing rules.
2. The Source IP Group is sent to a specific IP Group referred to as a *Destination IP Group*; the IP destination address being as configured by the *Proxy Set* associated with the Destination IP Group.
3. Number manipulation can be done on inbound and outbound legs.

The following subsections discuss the main terms associated with the IP-to-IP call routing application.

20.1.1 Proxy Sets

A Proxy Set is a group of Proxy servers (for Proxy load balancing and redundancy) defined by IP address or fully qualified domain name (FQDN). The Proxy Set is assigned to Server-type IP Groups only, representing the address of the IP Group to where the device sends the INVITE message (i.e., the **destination** of the call). Typically, for IP-to-IP call routing, two Proxy Sets are defined for call destination – one for each leg (i.e., one for each IP Group) of the call (i.e., both directions).

20.1.2 IP Groups


An IP Group represents a logical SIP entity in the device's network environment such as an ITSP SIP trunk, Proxy/Registrar server, IP-PBX, or remote IP-PBX users. The address of the IP Group is typically defined by its associated Proxy Set.

The opposite legs of the call are each presented by an IP Group; one being a *Serving* IP Group the other a *Served* IP Group. The Serving IP Group denotes the IP Group that provides service (e.g., ITSP) to the Served IP Group (e.g., IP-PBX). This is the IP Group to where the device sends INVITE messages received from the Served IP Group as well as REGISTER messages for registering on behalf of the Served IP Group.

IP Group can be a *Server* or *User* type. For Server-type IP Groups (e.g., ITSP or IP-PBX), the destination address (defined by the Proxy Set) is known. In contrast, User-type IP Groups represents groups of users whose location is dynamically obtained by the device when REGISTER requests and responses traverse (or are terminated) by the device. Generally, these are remote IP-PBX users (e.g., IP phones and soft phones).


For registrations of User-type IP Groups, the device updates its internal database with the AOR and Contacts of the users (see the figure below) Digest authentication using SIP 401/407 responses, if needed, is done by the Serving IP Group (e.g., IP-PBX). The device forwards these responses directly to the remote SIP users. For a call to a registered remote user, the device searches its dynamic database using the Request URI for an entry that matches a registered AOR or Contact. Once an entry is found, the IP destination is obtained and a SIP request is then sent to the user.

Figure 20-2: IP-to-IP Routing/Registration/Authentication of Remote IP-PBX Users (Example)



The device also supports the IP-to-IP call routing Survivability mode feature (see the figure below) for User-type IP Groups. The device stores in its database REGISTER messages sent by the clients of the User-type IP Group. If communication with the Serving IP Group (e.g., IP-PBX) fails, the User-type IP Group enters into Survivability mode in which the device uses its database for routing calls between the clients of the User-type IP Group. The RTP packets between the clients traverse through the device. When the Serving IP Group is available again, the device returns to normal mode, sending INVITE and REGISTER messages to the Serving IP Group.

Figure 20-3: IP-to-IP Routing for IP-PBX Remote Users in Survivability Mode (Example)



20.1.3 Inbound and Outbound IP Routing Rules


The device's IP-to-IP call routing is performed using the following two routing rule stages:

1. **Inbound IP Routing Mapping Rule:** Identifies the received call as an IP-to-IP call based on various characteristics such as the call's source IP address, and assigns it to an IP Group.
2. **Outbound IP Routing Mapping Rule:** Determines the destination (i.e., IP address) to where the incoming call associated with a specific source IP Group is finally routed. The destination address is typically denoted by another IP Group (destination IP Group) and therefore, the call is sent to the IP address that is defined by the Proxy Set associated with this IP Group. If the destination is a User-type IP Group, the device searches for a match between the request-URI of the received INVITE to an AOR registration record in the device's database. If a match is found, the INVITE is sent to the IP address of the registered contact.

20.1.4 Accounts

Accounts are used by the device to register to a Serving IP Group (e.g., an ITSP) on behalf of a Served IP Group (e.g., IP-PBX). This is necessary for ITSPs that require registration to provide services. Accounts are also used for defining user name and password for digest authentication (with or without registration) if required by the ITSP. Multiple Accounts per Served IP Group can be configured for registration to more than one Serving IP Group (e.g., an IP-PBX that requires registering to multiple ITSP's).

Figure 20-4: Registration with Multiple ITSP's on Behalf of IP-PBX



20.2 IP-to-IP Routing Configuration Example

This section provides step-by-step procedures for configuring IP-to-IP call routing. These procedures are based on the setup example described below. In this example, the device serves as the communication interface between the enterprise's IP-PBX (located on the LAN) and the following network entities:

- ITSP SIP trunks (located on the WAN)
- Remote IP-PBX users (located on the WAN)
- Local PSTN network

Calls from the Enterprise are routed according to destination.


This example assumes the following:

- The device has the public IP address 212.25.125.136 and is connected to the enterprise's firewall/NAT demilitarized zone (DMZ) network, providing the interface between the IP-PBX, and two ITSP's and the local PSTN.
- The enterprise has an IP-PBX located behind a Firewall/NAT:
 - IP-PBX IP address: 10.15.4.211
 - Transport protocol: UDP
 - Voice coder: G.711
 - IP-PBX users: 4-digit length extension number and served by two ITSPs.
 - The enterprise also includes remote IP-PBX users that communicate with the IP-PBX via the device. All dialed calls from the IP-PBX consisting of four digits starting with digit "4" are routed to the remote IP-PBX users.
- Using SIP trunks, the IP-PBX connects (via the device) to two different ITSP's:
 - **ITSP-A:**

- ◆ Implements Proxy servers with fully qualified domain names (FQDN): "Proxy1.ITSP-A" and "Proxy2.ITSP-B", using TLS.
- ◆ Allocates a range of PSTN numbers beginning with +1919, which is assigned to a range of IP-PBX users.
- ◆ Voice coder: G.723.
- **ITSP-B:**
 - ◆ Implements Proxy servers with IP addresses 216.182.224.202 and 216.182.225.202, using TCP.
 - ◆ Allocates a range of PSTN numbers beginning with 0200, which is assigned to a range of IP-PBX users.
 - ◆ Voice coder: G.723.
- Registration and authentication is required by both ITSP's, which is performed by the device on behalf of the IP-PBX. The SIP REGISTER messages use different URI's (host name and contact user) in the From, To, and Contact headers per ITSP as well as username and password authentication.
- Outgoing calls from IP-PBX users are routed according to destination:
 - If the calls are dialed with the prefix "+81", they are routed to ITSP-A (Region A).
 - If the calls are dialed with the prefix "9", they are routed to the local PSTN network.
 - For all other destinations, the calls are routed to ITSP-B.
- The device is also connected to the PSTN through a traditional T1 ISDN trunk for local incoming and outgoing calls. Calls dialed from the enterprise's IP-PBX with prefix '9' are sent to the local PSTN. In addition, in case of Internet interruption and loss of connection with the ITSP trunks, all calls are rerouted to the PSTN.

The figure below provides an illustration of this example scenario:

Figure 20-5: SIP Trunking Setup Scenario Example



The steps for configuring the device according to the scenario above can be summarized as follows:

- Enable the IP-to-IP feature (see 'Step 1: Enable the IP-to-IP Capabilities' on page 261).
- Configure the number of media channels (see 'Step 2: Configure the Number of Media Channels' on page 261).
- Configure a Trunk Group for interfacing with the local PSTN (see 'Step 3: Define a Trunk Group for the Local PSTN' on page 262).
- Configure Proxy Sets (see 'Step 4: Configure the Proxy Sets' on page 262).
- Configure IP Groups (see 'Step 5: Configure the IP Groups' on page 265).
- Configure Registration Accounts (see 'Step 6: Configure the Account Table' on page 266).
- Configure IP Profiles (see 'Step 7: Configure IP Profiles for Voice Coders' on page 267).
- Configure inbound IP routing rules (see 'Step 8: Configure Inbound IP Routing' on page 268).
- Configure outbound IP routing rules (see 'Step 9: Configure Outbound IP Routing' on page 270).
- Configure destination phone number manipulation (see 'Step 10: Configure Destination Phone Number Manipulation' on page 272).

20.2.1 Step 1: Enable the IP-to-IP Capabilities

This step describes how to enable the device's IP-to-IP application.

➤ **To enable IP-to-IP capabilities:**

1. Open the Applications Enabling page (**Configuration** tab > **VoIP** menu > **Applications Enabling** submenu > **Applications Enabling**).
2. From the 'IP to IP Application' drop-down list, select **Enable**.
3. Click **Submit**.
4. Save the setting to flash memory ("burn") with a device reset.



Note: For the IP-to-IP Application feature, the device must also be installed with the appropriate Software License Key.


20.2.2 Step 2: Configure the Number of Media Channels

The number of media channels represents the number of digital signaling processors (DSP) channels that the device allocates to IP-to-IP calls. The remaining DSP channels can be used for PSTN calls. Two IP media channels are used per IP-to-IP call.

➤ **To configure the number of media channels:**

1. Open the IP Media Settings page (**Configuration** tab > **VoIP** menu > **IP Media** > **IP Media Settings**).

Figure 20-6: Defining Required Media Channels



2. In the 'Number of Media Channels' field, enter the required number of media channels (in the example above, "120" to enable up to 60 IP-to-IP calls).
3. Click **Submit**.
4. Save the settings to flash memory ("burn") with a device reset (see 'Saving Configuration' on page 494).

20.2.3 Step 3: Define a Trunk Group for the Local PSTN

For incoming and outgoing local PSTN calls with the IP-PBX, you need to define the Trunk Group ID (#1) for the T1 ISDN trunk connecting the device to the local PSTN. This Trunk Group is also used for alternative routing to the PSTN if connectivity with the ITSP fails.

➤ **To configure the Trunk Group for local PSTN:**

1. Open the Trunk Group Table page (**Configuration** tab > **VoIP** menu > **GW and IP to IP** > **Trunk Group** > **Trunk Group**).
2. Configure Trunk Group ID #1 (as shown in the figure below):
 - From the 'From Trunk' and 'To Trunk' drop-down lists, select 1 to indicate Trunk 1 for this Trunk Group.
 - In the 'Channels' field, enter the Trunk channels or ports assigned to the Trunk Group (e.g. 1-31 for E1 and 1-24 for T1).
 - In the 'Phone Number' field, enter any phone number (logical) for this Trunk (e.g. 1000).
 - In the 'Trunk Group ID' field, enter "1" as the ID for this Trunk Group.

Add Phone Context As Prefix		Disable					
Trunk Group Index		1-12					
Group Index	Module	From Trunk	To Trunk	Channels	Phone Number	Trunk Group ID	Tel Profile ID
1	Module 1 PRI	1	1	1-31	1000	1	
2							

3. Configure the Trunk in the Trunk Settings page (**Configuration** tab > **VoIP** menu > **PSTN** > **Trunk Settings**).

20.2.4 Step 4: Configure the Proxy Sets

The Proxy Sets represent the actual destination (IP address or FQDN) to which the call is routed. These Proxy Sets are later assigned to IP Groups (see 'Step 5: Configure the IP Groups' on page 265).

This step describes how to configure the following Proxy Sets:

- Proxy Set ID #1 with two FQDN's for ITSP-A

- Proxy Set ID #2 with two IP addresses for ITSP-B
 - Proxy Set ID #3 with an IP address for the IP-PBX
- **To configure the Proxy Sets:**
1. Open the Proxy Sets Table page (**Configuration** tab > **VoIP** menu > **Control Network** > **Proxy Sets Table**).
 2. Configure Proxy Set ID #1 for ITSP-A:
 - a. From the 'Proxy Set ID' drop-down list, select **1**.
 - b. In the 'Proxy Address' column, enter the FQDN of ITSP-A SIP trunk Proxy servers (e.g., "Proxy1.ITSP-A" and "Proxy2. ITSP-A").
 - c. From the 'Transport Type' drop-down list corresponding to the Proxy addresses entered above, select **TLS**.
 - d. In the 'Enable Proxy Keep Alive' drop-down list, select **Using Options**, and then in the 'Proxy Load Balancing Method' drop-down list, select **Round Robin**.

Figure 20-7: Proxy Set ID #1 for ITSP-A

The screenshot shows the configuration interface for Proxy Set ID #1. At the top, a dropdown menu is set to '1'. Below it is a table with two columns: 'Proxy Address' and 'Transport Type'. The first two rows contain 'Proxy1.ITSP-A' and 'Proxy2.ITSP-A' respectively, both with 'TLS' selected in the Transport Type dropdown. Below the table, there are several configuration options: 'Enable Proxy Keep Alive' is set to 'Using Options', 'Proxy Keep Alive Time' is '60', 'Proxy Load Balancing Method' is 'Round Robin', 'Is Proxy Hot Swap' is 'No', 'Proxy Redundancy Mode' is '(-1) - Not Configured', and 'SRD Index' is '0'. Callouts 2a through 2d point to these specific fields.

	Proxy Address	Transport Type
1	Proxy1.ITSP-A	TLS
2	Proxy2.ITSP-A	TLS
3		
4		
5		

Enable Proxy Keep Alive	Using Options
Proxy Keep Alive Time	60
Proxy Load Balancing Method	Round Robin
Is Proxy Hot Swap	No
Proxy Redundancy Mode	(-1) - Not Configured
SRD Index	0

3. Configure Proxy Set ID #2 for ITSP-B:
 - a. From the 'Proxy Set ID' drop-down list, select **2**.
 - b. In the 'Proxy Address' column, enter the IP addresses of the ITSP-B SIP trunk (e.g., "216.182.224.202" and "216.182.225.202").
 - c. From the 'Transport Type' drop-down list corresponding to the IP address entered above, select **UDP**.

- d. In the 'Enable Proxy Keep Alive' drop-down list, select "Using Options", and then in the 'Proxy Load Balancing Method' drop-down list, select **Round Robin**.

Figure 20-8: Proxy Set ID #2 for ITSP-B

Proxy Set ID: 2

	Proxy Address	Transport Type
1	216.182.224.202	UDP
2	216.182.225.202	UDP
3		
4		
5		

Enable Proxy Keep Alive	Using Options
Proxy Keep Alive Time	60
Proxy Load Balancing Method	Round Robin
Is Proxy Hot Swap	No
Proxy Redundancy Mode	(-1) - Not Configured
SRD Index	0

4. Configure Proxy Set ID #3 for the IP-PBX:
 - a. From the 'Proxy Set ID' drop-down list, select **3**.
 - b. In the 'Proxy Address' column, enter the IP address of the IP-PBX (e.g., "10.15.4.211").
 - c. From the 'Transport Type' drop-down list corresponding to the IP address entered above, select **UDP**.
 - d. In the 'Enable Proxy Keep Alive' drop-down list, select **Using Options**. This is used in Survivability mode for remote IP-PBX users.

Figure 20-9: Proxy Set ID #3 for the IP-PBX

Proxy Set ID: 3

	Proxy Address	Transport Type
1	10.15.4.211	UDP
2		
3		
4		
5		

Enable Proxy Keep Alive	Using Options
Proxy Keep Alive Time	60
Proxy Load Balancing Method	Disable
Is Proxy Hot Swap	No
Proxy Redundancy Mode	(-1) - Not Configured
SRD Index	0

20.2.5 Step 5: Configure the IP Groups

This step describes how to create the IP Groups for the following entities in the network:

- ITSP-A SIP trunk
- ITSP-B SIP trunk
- IP-PBX server
- IP-PBX remote users

These IP Groups are later used by the device for routing calls.

➤ **To configure the IP Groups:**

1. Open the IP Group Table page (**Configuration** tab > **VoIP** menu > **Control Network** > **IP Group Table**).
2. Define IP Group #1 for ITSP-A:
 - a. From the 'Type' drop-down list, select **Server**.
 - b. In the 'Description' field, type an arbitrary name for the IP Group (e.g., ITSP A).
 - c. From the 'Proxy Set ID' drop-down lists, select **1** (represents the IP addresses, configured in , for communicating with this IP Group).
 - d. In the 'SIP Group Name' field, enter the host name sent in the SIP Request From\To headers for this IP Group, as required by ITSP-A (e.g., RegionA).
 - e. Contact User = name that is sent in the SIP Request's Contact header for this IP Group (e.g., ITSP-A).
3. Define IP Group #2 for ITSP-B:
 - a. From the 'Type' drop-down list, select **Server**.
 - b. In the 'Description' field, type an arbitrary name for the IP Group (e.g., ITSP B).
 - c. From the 'Proxy Set ID' drop-down lists, select **2** (represents the IP addresses, configured in , for communicating with this IP Group).
 - d. In the 'SIP Group Name' field, enter the host name sent in SIP Request From\To headers for this IP Group, as required by ITSP-B (e.g., RegionB).
 - e. Contact User = name that is sent in the SIP Request Contact header for this IP Group (e.g., ITSP-B).
4. Define IP Group #3 for the IP-PBX:
 - a. From the 'Type' drop-down list, select **Server**.
 - b. In the 'Description' field, type an arbitrary name for the IP Group (e.g., IP-PBX).
 - c. From the 'Proxy Set ID' drop-down lists, select **3** (represents the IP address, configured in , for communicating with this IP Group).
 - d. In the 'SIP Group Name' field, enter the host name that is sent in SIP Request From\To headers for this IP Group (e.g., IPPBX).
 - e. Contact User = name that is sent in the SIP Request Contact header for this IP Group (e.g., PBXUSER).
5. Define IP Group #4 for the remote IP-PBX users:
 - a. From the 'Type' drop-down list, select **User**.
 - b. In the 'Description' field, type an arbitrary name for the IP Group (e.g., IP-PBX).
 - c. In the 'SIP Group Name' field, enter the host name that is used internal in the device's database for this IP Group (e.g., RemoteIPPBXusers).
 - d. From the 'Serving IP Group ID' drop-down list, select **3** (i.e. the IP Group for the IP-PBX).



Note: No Serving IP Groups are defined for ITSP-A and ITSP-B. Instead, the Outbound IP Routing table (see 'Step 9: Configure Outbound IP Routing' on page 270) is used to configure outbound IP call routing for calls originating from these ITSP IP Groups.

20.2.6 Step 6: Configure the Account Table

The Account table is used by the device to register to an ITSP on behalf of the IP-PBX. As described previously, the ITSP requires registration and authentication to provide service. For the example, the Served IP Group is the IP-PBX (IP Group ID #3) and the Serving IP Groups are the two ITSPs (IP Groups #1 and #2).

➤ **To configure the Account table:**

1. Open the Account Table page (**Configuration** tab > **VoIP** menu > **SIP Definitions** > **Account Table**).

Figure 20-10: Defining Accounts for Registration

Index	Served Trunk Group	Served IP Group	Serving IP Group	Username	Password
1	-1	3	1	itsp_a	*
2	-1	3	2	itsp_b	*

Host Name	Register	Contact User	Application Type
regiona	Yes	ITSP-A	GW/1P2IP
regionb	Yes	ITSP-B	GW/1P2IP

2. Configure Account ID #1 for IP-PBX authentication and registration with ITSP-A:
 - In the 'Served IP Group' field, enter "3" to indicate that authentication is performed on behalf of IP Group #3 (i.e., the IP-PBX).
 - In the 'Serving IP Group' field, enter "1" to indicate that registration/authentication is with IP Group #1 (i.e., ITSP-A).
 - In the 'Username', enter the SIP username for authentication supplied by ITSP-A (e.g., itsp_a).
 - In the 'Password' field, enter the SIP password for authentication supplied by ITSP-A (e.g., 12345).
 - In the 'Register' field, enter "1" to enable registration with ITSP-A.
3. Configure Account ID #2 for IP-PBX registration) with ITSP-B Registrar server:
 - In the 'Served IP Group' field, enter "3" to indicate that registration is performed on behalf of IP Group #3 (i.e., the IP-PBX).
 - In the 'Serving IP Group' field, enter "2" to indicate that registration is with IP Group #3 (e.g., ITSP-B).
 - In the 'Username', enter the SIP username for the registration/authentication supplied by ITSP-B (e.g., itsp_b).
 - In the 'Password' field, enter the SIP password for registration/authentication supplied by ITSP-B (e.g., 11111).
 - In the 'Register' field, enter "1" to enable registration with ITSP-B.

20.2.7 Step 7: Configure IP Profiles for Voice Coders

Since different voice coders are used by the IP-PBX (G.711) and the ITSPs (G.723), you need to define two IP Profiles:

- Profile ID #1 - configured with G.711 for the IP-PBX
- Profile ID #2 - configured with G.723 for the ITSPs

These profiles are later used in the Inbound IP Routing table and Outbound IP Routing table.

➤ **To configure IP Profiles for voice coders:**

1. Open the Coder Group Settings page (**Configuration** tab > **VoIP** menu > **Coders and Profiles** > **Coders Group Settings**)
2. Configure Coder Group ID #1 for the IP-PBX (as shown in the figure below):
 - a. From the 'Coder Group ID' drop-down list, select **1**.
 - b. From the 'Coder Name' drop-down list, select **G.711A-law**.
 - c. Click **Submit**.

Figure 20-11: Defining Coder Group ID 1

Coder Name	Packetization Time	Rate	Payload Type	Silence Suppression
G.711A-law	20	64	8	Disabled

3. Configure Coder Group ID #2 for the ITSP's (as shown in the figure below):
 - a. From the 'Coder Group ID' drop-down list, select **2**.
 - b. From the 'Coder Name' drop-down list, select **G.723.1**.
 - c. Click **Submit**.

Figure 20-12: Defining Coder Group ID 2

Coder Name	Packetization Time	Rate	Payload Type	Silence Suppression
G.723.1	30	5.3	4	Disabled

4. Open the IP Profile Settings page (**Configuration** tab > **VoIP** menu > **Coders and Profiles** > **IP Profile Settings**).
5. Configure Profile ID #1 for the IP-PBX (as shown below):
 - a. From the 'Profile ID' drop-down list, select **1**.
 - b. From the 'Coder Group' drop-down list, select **Coder Group 1**.

- c. Click **Submit**.

Figure 20-13: Defining IP Profile ID 1

- 6. Configure Profile ID #2 for the ITSP's:
 - a. From the 'Profile ID' drop-down list, select **2**.
 - b. From the 'Coder Group' drop-down list, select **Coder Group 2**.
 - c. Click **Submit**.

20.2.8 Step 8: Configure Inbound IP Routing

This step defines how to configure the device for routing inbound (i.e., received) IP-to-IP calls. The table in which this is configured uses the IP Groups that you defined in 'Step 5: Configure the IP Groups' on page 265.

➤ **To configure inbound IP routing:**

- 1. Open the Inbound IP Routing Table page (**Configuration** tab > **VoIP** menu > **GW and IP to IP** submenu > **Routing** submenu > **IP to Trunk Group Routing**).

Figure 20-14: Defining Inbound IP Routing Rules

	Dest. Host Prefix	Source Host Prefix	Dest. Phone Prefix	Source Phone Prefix	Source IP Address	Trunk Group ID	IP Profile ID	Source IPGroup ID
2	1		9	*	*	1	0	
3	2		*	*	10.15.4.211	-1	1	3
4	3		+1919	*	*	-1	2	1
5	4		0200	*	*	-1	2	2
6	5	pbxremote	*	*	*	-1	0	4
7	6		*	*	10.15.4.211	1	0	-1

- 2. **Index #1:** routes calls with prefix 9 (i.e., local calls) dialed from IP-PBX users to the local PSTN:

- 'Dest Phone Prefix': enter "9" for the dialing prefix for local calls.
 - 'Trunk Group ID': enter "1" to indicate that these calls are routed to the Trunk (belonging to Trunk Group #1) connected between the device and the local PSTN network.
3. **Index #2:** identifies IP calls received from the IP-PBX as IP-to-IP calls and assigns them to the IP Group ID configured for the IP-PBX:
- 'Dest Phone Prefix': enter the asterisk (*) symbol to indicate all destinations.
 - 'Source IP Address': enter the IP address of the IP-PBX (i.e., 10.15.4.211).
 - 'Trunk Group ID': enter "-1" to indicate that these calls are IP-to-IP calls.
 - 'IP Profile ID': enter "1" to assign these calls to Profile ID #1 to use G.711.
 - 'Source IP Group ID': enter "3" to assign these calls to the IP Group pertaining to the IP-PBX.
4. **Index #3:** identifies IP calls received from ITSP-A as IP-to-IP calls and assigns them to the IP Group ID configured for ITSP-A:
- 'Dest Phone Prefix': ITSP-A assigns the Enterprise a range of numbers that start with +1919. Enter this prefix to indicate calls received from this ITSP.
 - 'Trunk Group ID': enter "-1" to indicate that these calls are IP-to-IP calls.
 - 'IP Profile ID': enter "2" to assign these calls to Profile ID #2 to use G.723.
 - 'Source IP Group ID': enter "1" to assign these calls to IP Group pertaining to ITSP-A.
5. **Index #4:** identifies IP calls received from ITSP-B as IP-to-IP calls and assigns them to the IP Group ID configured for ITSP-B:
- 'Dest Phone Prefix': ITSP-B assigns the Enterprise a range of numbers that start with 0200. Enter this prefix to indicate calls coming from this ITSP.
 - 'Trunk Group ID': enter "-1" to indicate that these calls are IP-to-IP calls.
 - 'IP Profile ID': enter "2" to assign these calls to Profile ID #2 to use G.723.
 - 'Source IP Group ID': enter "2" to assign these calls to IP Group pertaining to ITSP-B.
6. **Index #5:** identifies all IP calls received from IP-PBX remote users:
- 'Source Host Prefix': enter "PBXuser". This is the host name that appears in the From header of the Request URI received from remote IP-PBX users.
 - 'Trunk Group ID': enter "-1" to indicate that these calls are IP-to-IP calls.
 - 'Source IP Group ID': enter "4" to assign these calls to the IP Group pertaining to the remote IP-PBX users.
7. **Index #6:** is used for alternative routing. This configuration identifies all IP calls received from the IP-PBX and which can't reach the ITSP's servers (e.g. loss of connection with ITSP's) and routes them to the local PSTN network:
- 'Dest Phone Prefix': enter the asterisk (*) symbol to indicate all destinations.
 - 'Source IP Address': enter the IP address of the IP-PBX (i.e., 10.15.4.211).
 - 'Trunk Group ID': enter "1" to route these calls to the Trunk Group ID configured for the Trunk connected to the device and interfacing with the local PSTN.
 - 'Source IP Group ID': enter "-1" to indicate that these calls are not assigned to any source IP Group.

20.2.9 Step 9: Configure Outbound IP Routing

This step defines how to configure the device for routing outbound (i.e., sent) IP-to-IP calls. In our example scenario, calls from both ITSP's must be routed to the IP-PBX, while outgoing calls from IP-PBX users must be routed according to destination. If the calls are destined to the Japanese market, then they are routed to ITSP-B; for all other destinations, the calls are routed to ITSP-A. This configuration uses the IP Groups defined in 'Step 5: Configure the IP Groups' on page 265 and IP Profiles defined in 'Step 7: Configure IP Profiles for Voice Coders' on page 267.

➤ To configure outbound IP routing rules:

1. Open the Outbound IP Routing Table page (**Configuration** tab > **VoIP** menu > **GW and IP to IP** > **Routing** > **Tel to IP Routing**).
2. Configure **Index #1** to route IP calls received from ITSP-A to the IP-PBX:
 - 'Source IP Group ID': select **1** to indicate received (inbound) calls identified as belonging to the IP Group configured for ITSP-A.
 - 'Dest Phone Prefix' and 'Source Phone Prefix': enter the asterisk (*) symbol to indicate all destinations and callers respectively.
 - 'Dest IP Group ID': select **3** to indicate the destination IP Group to where these calls are sent, i.e., to the IP-PBX.
 - 'IP Profile ID': enter "2" to indicate the IP Profile configured for G.723.
3. Configure **Index #2** to route IP calls received from ITSP-B to the IP-PBX:
 - 'Source IP Group ID': select **2** to indicate received (inbound) calls identified as belonging to the IP Group configured for ITSP-B.
 - 'Dest Phone Prefix' and 'Source Phone Prefix': enter the asterisk (*) symbol to indicate all destinations and callers respectively.
 - 'Dest IP Group ID': select **3** to indicate the destination IP Group to where these calls are sent, i.e., to the IP-PBX.
 - 'IP Profile ID': enter "2" to indicate the IP Profile configured for G.723.
4. Configure **Index #3** to route calls received from the local PSTN network to the IP-PBX:
 - 'Source Trunk Group ID': enter "1" to indicate calls received on the trunk connecting the device to the local PSTN network.
 - 'Dest IP Group ID': select **3** to indicate the destination IP Group to where the calls must be sent, i.e., to the IP-PBX.
5. Configure **Index #4** to route IP calls received from the IP-PBX to ITSP-A:
 - 'Source IP Group ID': select **3** to indicate received (inbound) calls identified as belonging to the IP Group configured for the IP-PBX.
 - 'Dest Phone Prefix': enter "+81" to indicate calls to Japan (i.e., with prefix +81).
 - 'Source Phone Prefix': enter the asterisk (*) symbol to indicate all sources.
 - 'Dest IP Group ID': select **1** to indicate the destination IP Group to where the calls must be sent, i.e., to ITSP-A.
 - 'IP Profile ID': enter "1" to indicate the IP Profile configured for G.711.
6. Configure **Index #5** to route IP calls received from the IP-PBX to ITSP-B:
 - 'Source IP Group ID': select **3** to indicate received (inbound) calls identified as belonging to the IP Group configured for the IP-PBX.
 - 'Dest Phone Prefix' and 'Source Phone Prefix': enter the asterisk (*) symbol to indicate all destinations (besides Japan) and all sources respectively.
 - 'Dest IP Group ID': select **2** to indicate the destination IP Group to where the calls must be sent, i.e., to ITSP-A.

- 'IP Profile ID': enter "1" to indicate the IP Profile configured for G.711.
7. Configure **Index #6** to route dialed calls (four digits starting with digit 4) from IP-PBX to remote IP-PBX users. The device searches its database for the remote users registered number, and then sends an INVITE to the remote user's IP address (listed in the database):
- 'Source IP Group ID': select **3** to indicate received (inbound) calls identified as belonging to the IP Group configured for the IP-PBX.
 - 'Dest Phone Prefix': enter the "4xxx#" to indicate all calls dialed from IP-PBX that include four digits and start with the digit 4.
 - 'Dest IP Group ID': select **4** to indicate the destination IP Group to where the calls must be sent, i.e., to remote IP-PBX users.
 - 'IP Profile ID': enter "1" to indicate the IP Profile configured for G.711.

20.2.10 Step 10: Configure Destination Phone Number Manipulation

This step defines how to manipulate the destination phone number. The IP-PBX users in our example scenario use a 4-digit extension number. The incoming calls from the ITSP's have different prefixes and different lengths. This manipulation leaves only the four digits of the user's destination number coming from the ITSP's.

➤ **To configure destination phone number manipulation rules:**

1. Open the Destination Phone Number Manipulation Table for IP -> Tel calls page (**Configuration** tab > **VoIP** menu > **GW and IP to IP** > **Manipulations** > **Destination Number Tel->IP**).
2. Configure Index #1 to manipulate destination number of IP calls received from ITSP-A. The phone number of calls received with prefix +1919 (i.e., from ITSP-A) are removed except for the last four digits:
 - 'Destination Prefix': enter the prefix "+1919".
 - 'Source Prefix': enter the asterisk (*) symbol to indicate all sources.
 - 'Number of Digits to Leave': enter "4" to leave only the last four digits.
3. Configure Index #2 to manipulate destination number of IP calls received from ITSP-B. The phone number of calls received with prefix 0200 (i.e., from ITSP-B) are removed except for the last four digits:
 - 'Destination Prefix': enter the prefix "0200".
 - 'Source Prefix': enter the asterisk (*) symbol to indicate all sources.
 - 'Number of Digits to Leave': enter "4" to leave only the last four digits.

21 Digital PSTN

This section describes the configuration of the public switched telephone network (PSTN) related parameters.

21.1 Configuring Trunk Settings

The Trunk Settings page allows you to configure the device's trunks. This includes selecting the PSTN protocol and configuring related parameters. This page also provides the following features:

- **Taking a Trunk Out of Service:** Some parameters can be configured when the trunk is in service, while others require you to take the trunk out of service. This is done by clicking the **Stop**  button. Once you have "stopped" a trunk, all current calls are dropped and no new calls can be made on the trunk.
- **Deactivating a Trunk:** You can deactivate a trunk for maintenance. This is done by clicking the **Deactivate**  button. Deactivation temporarily disconnects (logically) the trunk from the PSTN network. Upon trunk deactivation, the device generates an AIS alarm on the trunk to the far-end. As a result, an RAI alarm signal may be received by the device. A subsequent trunk activation, done by clicking the **Activate**  button, reconnects the trunk to the PSTN network and clears the AIS alarm. Trunk deactivation is typically used for maintenance such as checking the trunk's physical integrity.
- **Creating a Loopback Line:** You can create (and remove) remote loopback for DS1 lines. This is done by clicking the **Create Loopback**  button. To remove the loopback, click the **Remove Loopback**  button.


Notes:

- To delete a previously configured trunk, set the 'Protocol Type' parameter to **NONE**.
- For a description of the trunk parameters, see 'PSTN Parameters' on page 747.
- During trunk deactivation, you cannot configure trunks.
- You cannot activate or deactivate a stopped trunk.
- If the trunk can't be stopped because it provides the device's clock (assuming the device is synchronized with the E1/T1 clock), assign a different E1/T1 trunk to provide the device's clock or enable 'TDM Bus PSTN Auto Clock' in the TDM Bus Settings page (see 'TDM and Timing' on page 276).
- If the 'Protocol Type' parameter is set to **NONE** (i.e., no protocol type is selected) and no other trunks have been configured, after selecting a PRI protocol type you must reset the device.
- The displayed parameters depend on the protocol selected.
- All PRI trunks of the device must be of the same line type (i.e., E1 or T1). However, different variants of the same line type can be configured on different trunks, for example, E1 Euro ISDN and E1 CAS (subject to the constraints in the device's Release Notes).
- BRI trunks can operate with E1 or T1 trunks.
- If the protocol type is CAS, you can assign or modify a dial plan (in the 'Dial Plan' field) and perform this without stopping the trunk.



➤ **To configure trunks:**


1. Open the Trunk Settings page (**Configuration** tab > **VoIP** menu > **PSTN** submenu > **Trunk Settings**).



On the top of the page, a bar with Trunk number icons displays the status of each trunk, according to the following color codes:

- **Grey:** Disabled
 - **Green:** Active
 - **Yellow:** RAI alarm (also appears when you deactivate a Trunk by clicking the **Deactivate** button)
 - **Red:** LOS/LOF alarm
 - **Blue:** AIS alarm
 - **Orange:** D-channel alarm (ISDN only)
2. Select the trunk that you want to configure by clicking the desired Trunk number icon. The bar initially displays the first eight trunk number icons (i.e., trunks 1 through 8). To scroll through the trunk number icons (i.e., view the next/last or previous/first group of eight trunks), see the figure below:

Figure 21-1: Trunk Scroll Bar (Used Only as an Example)





Note: If the Trunk scroll bar displays all available trunks, the scroll bar buttons are unavailable.

After you have selected a trunk, the following is displayed:

- The read-only 'Module ID' field displays the module number to which the trunk belongs.
- The read-only 'Trunk ID' field displays the selected trunk number.
- The read-only 'Trunk Configuration State' displays the state of the trunk ('Active' or 'Inactive').
- The displayed parameters pertain to the selected trunk only.

3. Click the **Stop Trunk**  button (located at the bottom of the page) to take the trunk out of service so that you can configure the currently grayed out (unavailable) parameters. (Skip this step if you want to configure parameters that are available when the trunk is active). The stopped trunk is indicated by the following:

- The 'Trunk Configuration State' field displays 'Inactive'.
- The **Stop Trunk** button is replaced by the **Apply Trunk Settings**  button.

When all trunks are stopped, the **Apply to All Trunks**  button also appears.

- All the parameters are available and can be modified.
4. Configure the trunk parameters as required.
 5. Click the **Apply Trunk Settings** button to apply the changes to the selected trunk (or click **Apply to All Trunks** to apply the changes to all trunks); the **Stop Trunk** button replaces **Apply Trunk Settings** and the 'Trunk Configuration State' displays 'Active'.
 6. To save the changes to flash memory, see 'Saving Configuration' on page 494.
 7. To reset the device, see 'Resetting the Device' on page 491.

21.2 TDM and Timing

This section describes the configuration of the TDM and clock timing parameters.

21.2.1 Configuring TDM Bus Settings

The TDM page allows you to configure the device's Time-Division Multiplexing (TDM) bus settings. For a description of these parameters, see 'PSTN Parameters' on page 747.

➤ **To configure the TDM Bus settings:**

1. Open the TDM page (**Configuration** tab > **VoIP** menu > TDM > TDM Bus Settings).

▼ TDM Bus Settings	
⚡ PCM Law Select	MuLaw ▼
TDM Bus Clock Source	Internal ▼
⚡ TDM Bus PSTN Auto FallBack Clock	Disable ▼
⚡ TDM Bus PSTN Auto Clock Reverting	Disable ▼
⚡ Idle PCM Pattern	255
⚡ Idle ABCD Pattern	0x0F ▼
TDM Bus Local Reference	1
⚡ TDM Bus Type	Framers ▼

2. Configure the parameters as required.
3. Click **Submit** to apply your changes.
4. Save the changes to flash memory, see 'Saving Configuration' on page 494.

21.2.2 Clock Settings

In a traditional TDM service network such as PSTN, both ends of the TDM connection must be synchronized. If synchronization is not achieved, voice frames are either dropped (to prevent a buffer overflow condition) or inserted (to prevent an underflow condition). In both cases, connection quality and reliability is affected.

- PSTN line clock (see 'Recovering Clock from PSTN Line' on page 276)
- Internal clock (see 'Configuring Internal Clock as Clock Source' on page 277)



Note: When the device is used in a 'non-span' configuration, the internal device clock must be used (as explained above).

21.2.2.1 Recovering Clock from PSTN Line Interface

This section provides a brief description for configuring synchronization based on recovering clock from the PSTN line (Trunk) interface. For a full description of the clock parameters, see 'PSTN Parameters' on page 747.

➤ **To configure synchronization based on clock from PSTN line:**

1. In the TDM Bus Settings page, do the following:
 - a. Set the 'TDM Bus Clock Source' parameter (TDMBusClockSource) to **Network** to recover the clock from the line interface.
 - b. Select the trunk from which the clock is derived, using the 'TDM Bus Local Reference' parameter (TDMBusLocalReference).



Note: The E1/T1 trunk should recover the clock from the remote side (see below description of the 'Clock Master' parameter). The BRI trunk should be configured as an ISDN user-side.

- c. Enable automatic switchover to the next available "salve" trunk if the device detects that the local-reference trunk is no longer capable of supplying the clock to the system:
 - a. Set the 'TDM Bus PSTN Auto FallBack Clock' parameter (TDMBusPSTNAutoClockEnable) to **Enable**.
 - b. Enable the device to switch back to a previous trunk that returns to service if it has higher switchover priority, using the 'TDM Bus PSTN Auto Clock Reverting' parameter (TDMBusPSTNAutoClockRevertingEnable).
 - c. In the Trunk Settings page, configure the priority level of the trunk for taking over as a local-reference trunk, using the 'Auto Clock Trunk Priority' parameter (AutoClockTrunkPriority). A value of 100 means that it never uses the trunk as local reference.
2. **For E1/T1 trunks only:** Set the PSTN trunk to recover/derive clock from/to the remote side of the PSTN trunk (i.e. clock slave or clock master): In the Trunk Settings page, set the 'Clock Master' parameter (ClockMaster) to one of the following:
 - **Recovered** - to recover clock (i.e. slave)
 - **Generated** - to transmit clock (i.e. master)

21.2.2.2 Configuring Internal Clock as Clock Source

This section describes how to configure the device to use its internal clock source. The internal clock source is a stratum 4E-compliant clock source. When the device has no line interfaces, the device should be configured in this mode.

➤ **To configure internal clock as clock source:**

1. Set the clock source to be from the device's internal oscillator. In the TDM Bus Settings page, set the 'TDM Bus Clock Source' parameter (TDMBusClockSource) to **Internal**.
2. For E1/T1 trunks only, set the line to drive the clock on all trunks: In the Trunk Settings page, set the 'Clock Master' parameter (ClockMaster) to **Generated** (for all trunks).

21.3 Configuring CAS State Machines

The CAS State Machine page allows you to modify various timers and other basic parameters to define the initialization of the CAS state machine without changing the state machine itself (no compilation is required). The change doesn't affect the state machine itself, but rather the configuration.

The CAS table used can be chosen in two ways (using the parameter CasChannelIndex):

- Single CAS table per trunk

- Different CAS table per group of B-channels in a trunk
- **To modify the CAS state machine parameters:**
 1. Open the CAS State Machine page (**Configuration** tab > **VoIP** menu > **PSTN** submenu > **CAS State Machines**).

Figure 21-2: CAS State Machine Page

CAS Table Name	Generate Digit On Time	Generate Inter Digit Time	DTMF Max Detection Time	DTMF Min Detection Time	Max Incoming Address Digits	Max Incoming ANI Digits
E_M_FGDWinkTable.dat	-1	-1	-1	-1	-1	-1
E_M_FGDWinkTable.dat	-1	-1	-1	-1	-1	-1
E_M_FGDWinkTable.dat	-1	-1	-1	-1	-1	-1

2. Ensure that the trunk is inactive. The trunk number displayed in the 'Related Trunks' field must be green. If it is red, indicating that the trunk is active, click the trunk number to open the Trunk Settings page (see 'Configuring Trunk Settings' on page 273), select the required Trunk number icon, and then click **Stop Trunk**.
3. In the CAS State Machine page, modify the required parameters according to the table below.
4. Once you have completed the configuration, activate the trunk if required in the Trunk Settings page, by clicking the trunk number in the 'Related Trunks' field, and in the Trunk Settings page, select the required Trunk number icon, and then click **Apply Trunk Settings**.
5. Click **Submit**, and then reset the device (see 'Resetting the Device' on page 491).

Notes:



- Don't modify the default values unless you fully understand the implications of the changes and know the default values. Every change affects the configuration of the state machine parameters and the call process related to the trunk you are using with this state machine.
- You can modify CAS state machine parameters only if the following conditions are met:
 - 1) Trunks are inactive (stopped), i.e., the 'Related Trunks' field displays the trunk number in green.
 - 2) State machine is not in use or is in reset, or when it is not related to any trunk. If it is related to a trunk, you must delete the trunk or deactivate (*Stop*) the trunk.
- Field values displaying '-1' indicate CAS default values. In other words, CAS state machine values are used.
- The modification of the CAS state machine occurs at the CAS application initialization only for non-default values (-1).
- For more information on the CAS Protocol table, refer to the *CAS Protocol Table Configuration Note*.

CAS State Machine Parameters Description

Parameter	Description
Generate Digit On Time [CasStateMachineGenerateDigitOnTime]	Generates digit on-time (in msec). The value must be a positive value. The default is -1 (use value from CAS state machine).

Parameter	Description
Generate Inter Digit Time [CasStateMachineGenerateInterDigitTime]	Generates digit off-time (in msec). The value must be a positive value. The default is -1 (use value from CAS state machine).
DTMF Max Detection Time [CasStateMachineDTMFMaxOnDetectionTime]	Detects digit maximum on time (according to DSP detection information event) in msec units. The value must be a positive value. The default is -1 (use value from CAS state machine).
DTMF Min Detection Time [CasStateMachineDTMFMinOnDetectionTime]	Detects digit minimum on time (according to DSP detection information event) in msec units. The digit time length must be longer than this value to receive a detection. Any number may be used, but the value must be less than CasStateMachineDTMFMaxOnDetectionTime. The value must be a positive value. The default is -1 (use value from CAS state machine).
MAX Incoming Address Digits [CasStateMachineMaxNumOfIncomingAddressDigits]	Defines the limitation for the maximum address digits that need to be collected. After reaching this number of digits, the collection of address digits is stopped. The value must be an integer. The default is -1 (use value from CAS state machine).
MAX Incoming ANI Digits [CasStateMachineMaxNumOfIncomingANIDigits]	Defines the limitation for the maximum ANI digits that need to be collected. After reaching this number of digits, the collection of ANI digits is stopped. The value must be an integer. The default is -1 (use value from CAS state machine).
Collect ANI [CasStateMachineCollectANI]	In some cases, when the state machine handles the ANI collection (not related to MFCR2), you can control the state machine to collect ANI or discard ANI. <ul style="list-style-type: none"> ▪ [0] No = Don't collect ANI. ▪ [1] Yes = Collect ANI. ▪ [-1] Default = Default value - use value from CAS state machine.
Digit Signaling System [CasStateMachineDigitSignalingSystem]	Defines which Signaling System to use in both directions (detection\generation). <ul style="list-style-type: none"> ▪ [0] DTMF = Uses DTMF signaling. ▪ [1] MF = Uses MF signaling (default). ▪ [-1] Default = Default value - use value from CAS state machine.

21.4 Configuring Digital Gateway Parameters

The Digital Gateway Parameters page allows you to configure miscellaneous digital parameters. For a description of these parameters, see 'Configuration Parameters Reference' on page 609.

➤ **To configure the digital gateway parameters:**

1. Open the Digital Gateway Parameters page (**Configuration** tab > **VoIP** menu > **GW and IP to IP** submenu > **Digital Gateway** submenu > **Digital Gateway Parameters**).

Figure 21-3: Digital Gateway Parameters Page

B-channel Negotiation	Exclusive	▼
Swap Redirect and Called Numbers	No	▼
MFC R2 Category	1	
Disconnect Call on Busy Tone Detection (CAS)	Enable	▼
Disconnect Call on Busy Tone Detection (ISDN)	Disable	▼
⚡ Enable TDM Tunneling	Disable	▼
Send Screening Indicator to IP	Not Configured	▼
Send Screening Indicator to ISDN	Not Configured	▼
Add IE in SETUP		
Trunk Groups to Send IE		
Enable User-to-User IE for Tel to IP	Disable	▼
Enable User-to-User IE for IP to Tel	Disable	▼
Enable ISDN Tunneling Tel to IP	Disable	▼
Enable QSIG Tunneling	Disable	▼
Enable ISDN Tunneling IP to Tel	Disable	▼
ISDN Transfer on Connect	Alert	▼
Remove CLI when Restricted	No	▼
Remove Calling Name	Disable	▼
Tdm Over IP Minimum Calls For Trunk Activation	0	
ISDN Facility Trace	Disable	▼
Use EndPoint Number As Calling Number Tel2IP	Disable	▼
Use EndPoint Number As Calling Number IP2Tel	Disable	▼
Default Cause Mapping From ISDN to SIP	0	
Add Prefix to Redirect Number		
Copy Destination Number to Redirect Number	Don't copy	▼
Enable Calling Party Category	Disable	▼
ISDN SubAddress Format	ASCII	▼
Play Local RBT on ISDN Transfer	Don't play	▼
Send Local Time To ISDN Connect	Disable	▼
User To User Header Format	0	
⚡ Digital Out-Of-Service Behavior	Default	▼
Ignore BRI LOS Alarm	Enable	▼
MLPP		
MLPP Default Namespace	DSN	▼
Default Call Priority	0	
Preemption tone Duration	3	
RTP DSCP for MLPP Routine	-1	
RTP DSCP for MLPP Priority	-1	
RTP DSCP for MLPP Immediate	-1	
RTP DSCP for MLPP Flash	-1	
RTP DSCP for MLPP Flash-Override	-1	
RTP DSCP for MLPP Flash-Override-Override	-1	
MLPP Default Service Domain	000000	
MLPP Normalized Service Domain	000000	

2. Configure the parameters as required.
3. Click **Submit** to apply your changes.
4. To save the changes to flash memory, see 'Saving Configuration' on page 494.

21.5 Tunneling Applications

This section discusses the device's support for VoIP tunneling applications.

21.5.1 TDM Tunneling

The device's TDM Tunneling feature allows you to tunnel groups of digital trunk spans or timeslots (B-channels) over the IP network. TDM Tunneling utilizes the device's internal routing (without Proxy control) capabilities to receive voice and data streams from TDM (E1/T1/J1) spans or individual timeslots, convert them into packets, and then transmit them over the IP network (using point-to-point or point-to-multipoint device distributions). A device opposite it (or several devices when point-to-multipoint distribution is used) converts the IP packets back into TDM traffic. Each timeslot can be targeted to any other timeslot within a trunk in the opposite device.

When TDM Tunneling is enabled (the parameter `EnableTDMoverIP` is set to '1') on the originating device, the originating device automatically initiates SIP calls from all enabled B-channels belonging to the E1/T1/J1 spans that are configured with the protocol type 'Transparent' (for ISDN trunks) or 'Raw CAS' (for CAS trunks). The called number of each call is the internal phone number of the B-channel from where the call originates. The Inbound IP Routing Table is used to define the destination IP address of the terminating device. The terminating device automatically answers these calls if its E1/T1 protocol type is set to 'Transparent' (`ProtocolType = 5`) or 'Raw CAS' (`ProtocolType = 3` for T1 and 9 for E1) and the parameter `ChannelSelectMode` is set to 0 (By Phone Number).



Note: It's possible to configure both devices to also operate in symmetric mode. To do so, set `EnableTDMoverIP` to 1 and configure the Outbound IP Routing Table in both devices. In this mode, each device (after it's reset) initiates calls to the second device. The first call for each B-channel is answered by the second device.

The device continuously monitors the established connections. If for some reason, one or more calls are released, the device automatically re-establishes these 'broken' connections. When a failure in a physical trunk or in the IP network occurs, the device re-establishes the tunneling connections when the network is restored.



Note: It's recommended to use the keep-alive mechanism for each connection, by activating the 'session expires' timeout and using Re-INVITE messages.

The device supports the configuration (`TDMoIPInitiateInviteTime` and `TDMoIPInviteRetryTime` parameters) of the following timers for the TDM-over-IP tunneling application:

- Time between successive INVITEs sent from the same E1/T1 trunk.
- Time between call release and the new INVITE that is sent on the same channel. The call can be released if the device receives a 4xx or 5xx response.

By utilizing the 'Profiles' mechanism (see 'Coders and Profiles' on page 239), you can configure the TDM Tunneling feature to choose different settings based on a timeslot or groups of timeslots. For example, you can use low-bit-rate vocoders to transport voice and 'Transparent' coder to transport data (e.g., for D-channel). You can also use Profiles to assign ToS (for DiffServ) per source - a timeslot carrying data or signaling is assigned a higher priority value than a timeslot carrying voice.

For tunneling of E1/T1 CAS trunks, set the protocol type to 'Raw CAS' (ProtocolType = 3 / 9) and enable RFC 2833 CAS relay mode ('CAS Transport Type' parameter is set to 'CAS RFC2833 Relay').



Note: For TDM over IP, the parameter CallerIDTransportType must be set to '0' (disabled), i.e., transparent.

Below is an example of *ini* files for two devices implementing TDM Tunneling for four E1 spans. Note that in this example both devices are dedicated to TDM tunneling.

Terminating Side:

```

EnableTDMOverIP = 1
;E1_TRANSPARENT_31
ProtocolType_0 = 5
ProtocolType_1 = 5
ProtocolType_2 = 5
ProtocolType_3 = 5
[PREFIX]
PREFIX_DestinationPrefix, PREFIX_DestAddress, PREFIX_SourcePrefix,
PREFIX_ProfileId, PREFIX_MeteringCode, PREFIX_DestPort,
PREFIX_SrcIPGroupID, PREFIX_DestHostPrefix, PREFIX_DestIPGroupID,
PREFIX_SrcHostPrefix, PREFIX_TransportType,
PREFIX_SrcTrunkGroupID, PREFIX_DestSRD, PREFIX_CostGroup,
PREFIX_ForkingGroup;
Prefix 1 = *,10.8.24.12;
[\\PREFIX]

;IP address of the device in the opposite
;location
;Channel selection by Phone number.
ChannelSelectMode = 0
;Profiles can be used do define different coders per B-channels
;such as Transparent
;coder for B-channels (timeslot 16) that carries PRI ;signaling.
[TrunkGroup]
FORMAT TrunkGroup_Index = TrunkGroup_TrunkGroupNum,
TrunkGroup_FirstTrunkId, TrunkGroup_LastTrunkId,
TrunkGroup_FirstBChannel, TrunkGroup_LastBChannel,
TrunkGroup_FirstPhoneNumber, TrunkGroup_ProfileId,
TrunkGroup_Module;
TrunkGroup 1 = 0,0,0,1,31,1000,1;
TrunkGroup 1 = 0,1,1,1,31,2000,1;
TrunkGroup 1 = 0,2,2,1,31,3000,1;
TrunkGroup 1 = 0,3,3,1,31,4000,1;
TrunkGroup 1 = 0,0,0,16,16,7000,2;
TrunkGroup 1 = 0,1,1,16,16,7001,2;
TrunkGroup 1 = 0,2,2,16,16,7002,2;
TrunkGroup 1 = 0,3,3,16,16,7003,2;
[/TrunkGroup]
[ CodersGroup0 ]
FORMAT CodersGroup0_Index = CodersGroup0_Name, CodersGroup0_pTime,
CodersGroup0_rate, CodersGroup0_PayloadType, CodersGroup0_Sce;
CodersGroup0 0 = g7231;
CodersGroup0 1 = Transparent;
[ \\CodersGroup0 ]
[TelProfile]
FORMAT TelProfile_Index = TelProfile_ProfileName,
    
```

```

TelProfile_TelPreference, TelProfile_CodersGroupID,
TelProfile_IsFaxUsed, TelProfile_JitterBufMinDelay,
TelProfile_JitterBufOptFactor, TelProfile_IPDiffServ,
TelProfile_SigIPDiffServ, TelProfile_DtmfVolume,
TelProfile_InputGain, TelProfile_VoiceVolume,
TelProfile_EnableReversePolarity,
TelProfile_EnableCurrentDisconnect,
TelProfile_EnableDigitDelivery, TelProfile_EnableEC,
TelProfile_MWIAAnalog, TelProfile_MWIDisplay,
TelProfile_FlashHookPeriod, TelProfile_EnableEarlyMedia,
TelProfile_ProgressIndicator2IP;
TelProfile 1 = voice,$$,1,$$,,$$,,$$,,$$,,$$,,$$;
TelProfile 2 = data,$$,2,$$,,$$,,$$,,$$,,$$,,$$;
[\\TelProfile]

```

Originating Side:

```

;E1_TRANSPARENT_31
ProtocolType_0 = 5
ProtocolType_1 = 5
ProtocolType_2 = 5
ProtocolType_3 = 5
;Channel selection by Phone number.
ChannelSelectMode = 0
[TrunkGroup]
FORMAT TrunkGroup_Index = TrunkGroup_TrunkGroupNum,
TrunkGroup_FirstTrunkId, TrunkGroup_LastTrunkId,
TrunkGroup_FirstBChannel, TrunkGroup_LastBChannel,
TrunkGroup_FirstPhoneNumber, TrunkGroup_ProfileId,
TrunkGroup_Module;
TrunkGroup 0 = 0,0,0,1,31,1000,1;
TrunkGroup 0 = 0,1,1,1,31,2000,1;
TrunkGroup 0 = 0,2,2,1,31,3000,1;
TrunkGroup 0 = 0,3,1,31,4000,1;
TrunkGroup 0 = 0,0,0,16,16,7000,2;
TrunkGroup 0 = 0,1,1,16,16,7001,2;
TrunkGroup 0 = 0,2,2,16,16,7002,2;
TrunkGroup 0 = 0,3,3,16,16,7003,2;
[\\TrunkGroup]
[ CodersGroup0 ]
FORMAT CodersGroup0_Index = CodersGroup0_Name, CodersGroup0_pTime,
CodersGroup0_rate, CodersGroup0_PayloadType, CodersGroup0_Sce;
CodersGroup0 0 = g7231;
CodersGroup0 1 = Transparent;
[ \\CodersGroup0 ]
[TelProfile]
FORMAT TelProfile_Index = TelProfile_ProfileName,
TelProfile_TelPreference, TelProfile_CodersGroupID,
TelProfile_IsFaxUsed, TelProfile_JitterBufMinDelay,
TelProfile_JitterBufOptFactor, TelProfile_IPDiffServ,
TelProfile_SigIPDiffServ, TelProfile_DtmfVolume,
TelProfile_InputGain, TelProfile_VoiceVolume,
TelProfile_EnableReversePolarity,
TelProfile_EnableCurrentDisconnect,
TelProfile_EnableDigitDelivery, TelProfile_EnableEC,
TelProfile_MWIAAnalog, TelProfile_MWIDisplay,
TelProfile_FlashHookPeriod, TelProfile_EnableEarlyMedia,
TelProfile_ProgressIndicator2IP;
TelProfile_1 = voice,$$,1,$$,,$$,,$$,,$$,,$$,,$$

```

```
TelProfile_2 = data,$$,2,$$,,$$,,$$,,$$,,$$,,$$
[\\TelProfile]
```

21.5.1.1 DSP Pattern Detector

For TDM tunneling applications, you can use the DSP pattern detector feature to initiate the echo canceller at call start. The device can be configured to support detection of a specific one-byte idle data pattern transmitted over digital E1/T1 timeslots. The device can be configured to detect up to four different one-byte data patterns. When the defined idle data pattern is detected, the channel resets its echo canceller.

➤ **To configure DSP pattern detector:**

1. In the IPMedia Settings page (**Configuration** tab > **VoIP** menu > **Media** > **IPMedia Settings**), do the following:
 - a. Set the 'IPMedia Detectors' parameter (EnabledDSPIPMDetectors) to **Enable**.
 - b. Set the 'Enable Pattern Detector' parameter (EnablePatternDetector) to **Enable**.
2. Configure the number (e.g., 5) of consecutive patterns to trigger the pattern detection event, using the ini file parameter, PDThreshold.
3. Configure the patterns that can be detected by the Pattern Detector, using the ini file parameter, PDPattern. For example:

```
PDPattern = 84, 85, 212, 213 ; for idle patterns 54, 55, D4
and D5
```

21.5.2 QSIG Tunneling

The device supports QSIG tunneling over SIP, according to IETF Internet-Draft draft-elwell-sipping-qsig-tunnel-03 ("Tunnelling of QSIG over SIP") and ECMA-355/ISO/IEC 22535. This is applicable to all ISDN variants. QSIG tunneling can be applied to all calls or to specific calls using IP Profiles.

QSIG tunneling sends all QSIG messages as raw data in corresponding SIP messages using a dedicated message body. This is used, for example, to enable two QSIG subscribers connected to the same or different QSIG PBX to communicate with each other over an IP network. Tunneling is supported in both directions (Tel-to-IP and IP-to-Tel).

The term tunneling means that messages are transferred 'as is' to the remote side without being converted (QSIG > SIP > QSIG). The advantage of tunneling over QSIG-to-SIP interworking is that by using interworking, QSIG functionality can only be partially achieved. When tunneling is used, all QSIG capabilities are supported and the tunneling medium (the SIP network) does not need to process these messages.

QSIG messages are transferred in SIP messages in a separate Multipurpose Internet Mail Extensions (MIME) body. Therefore, if a message contains more than one body (e.g., SDP and QSIG), multipart MIME must be used. The Content-Type of the QSIG tunneled message is 'application/QSIG'. The device also adds a Content-Disposition header in the following format:

```
Content-Disposition: signal; handling=required.
```

QSIG tunneling is done as follows:

- **Call setup (originating device):** The QSIG Setup request is encapsulated in the SIP INVITE message without being altered. After the SIP INVITE request is sent, the device does not encapsulate the subsequent QSIG message until a SIP 200 OK response is received. If the originating device receives a 4xx, 5xx, or 6xx response, it disconnects the QSIG call with a 'no route to destination' cause.
- **Call setup (terminating device):** After the terminating device receives a SIP INVITE request with a 'Content-Type: application/QSIG', it sends the encapsulated QSIG Setup message to the Tel side and sends a 200 OK response (no 1xx response is

sent) to IP. The 200 OK response includes an encapsulated QSIG Call Proceeding message (without waiting for a Call Proceeding message from the Tel side). If tunneling is disabled and the incoming INVITE includes a QSIG body, a 415 response is sent.

- **Mid-call communication:** After the SIP connection is established, all QSIG messages are encapsulated in SIP INFO messages.
- **Call tear-down:** The SIP connection is terminated once the QSIG call is complete. The Release Complete message is encapsulated in the SIP BYE message that terminates the session.

➤ **To enable QSIG tunneling:**

1. In the Digital Gateway Parameters page (**Configuration** tab > **VoIP** menu > **GW and IP to IP** > **Digital Gateway** > **Digital Gateway Parameters**), set the 'Enable QSIG Tunneling' parameter (EnableQSIGTunneling) to **Enable** on the originating and terminating devices.
2. Configure the QSIGTunnelingMode parameter for defining the format of encapsulated QSIG message data in the SIP message MIME body (0 for ASCII presentation; 1 for binary encoding).
3. Set the ISDNDuplicateQ931BuffMode parameter to 128 to duplicate all messages.
4. Set the ISDNInCallsBehavior parameter to 4096.
5. Set the ISDNRxOverlap parameter to 0 for tunneling of QSIG overlap-dialed digits (see below for description).

The configuration of the ISDNInCallsBehavior and ISDNRxOverlap parameters allows tunneling of QSIG overlap-dialed digits (Tel to IP). In this configuration, the device **delays** the sending of the QSIG Setup Ack message upon receipt of the QSIG Setup message. Instead, the device sends the Setup Ack message to QSIG only when it receives the SIP INFO message with Setup Ack encapsulated in its MIME body. The PBX sends QSIG Information messages (to complete the Called Party Number) only after it receives the Setup Ack. The device relays these Information messages encapsulated in SIP INFO messages to the remote party.

21.6 ISDN Non-Facility Associated Signaling (NFAS)

In regular T1 ISDN trunks, a single 64 kbps channel carries signaling for the other 23 B-channels of that particular T1 trunk. This channel is called the D-channel and usually resides on timeslot # 24. ISDN Non-Facility Associated Signaling (NFAS) enables the use of a single D-channel to control multiple PRI interfaces.

With NFAS it is possible to define a group of T1 trunks, called an *NFAS group*, in which a single D-channel carries ISDN signaling messages for the entire group. The NFAS group's B-channels are used to carry traffic such as voice or data. The NFAS mechanism also enables definition of a backup D-channel on a different T1 trunk, to be used if the primary D-channel fails.

The device supports up to 12 NFAS groups. Each group can comprise up to 10 T1 trunks and each group must contain different T1 trunks. Each T1 trunk is called an 'NFAS member'. The T1 trunk whose D-channel is used for signaling is called the 'Primary NFAS Trunk'. The T1 trunk whose D-channel is used for backup signaling is called the 'Backup NFAS Trunk'. The primary and backup trunks each carry 23 B-channels while all other NFAS trunks each carry 24 B-channels.

The NFAS group is identified by an NFAS GroupID number (possible values are 1 to 12). To assign a number of T1 trunks to the same NFAS group, use the NFASGroupNumber_x = groupID (where x is the physical trunk ID (0 to the maximum number of trunks) or the Web interface (see 'Configuring Trunk Settings' on page 273).

The parameter 'DchConfig_x = Trunk_type' defines the type of NFAS trunk. Trunk_type is set to 0 for the primary trunk, to 1 for the backup trunk, and to 2 for an ordinary NFAS

trunk. 'x' denotes the physical trunk ID (0 to the maximum number of trunks). You can also use the Web interface (see 'Configuring Trunk Settings' on page 273).

For example, to assign the first four T1 trunks to NFAS group #1, in which trunk #0 is the primary trunk and trunk #1 is the backup trunk, use the following configuration:

```
NFASGroupNumber_0 = 1
NFASGroupNumber_1 = 1
NFASGroupNumber_2 = 1
NFASGroupNumber_3 = 1
DchConfig_0 = 0           ;Primary T1 trunk
DchConfig_1 = 1           ;Backup T1 trunk
DchConfig_2 = 2           ;24 B-channel NFAS trunk
DchConfig_3 = 2           ;24 B-channel NFAS trunk
```

The NFAS parameters are described in 'PSTN Parameters' on page 747.

21.6.1 NFAS Interface ID

Several ISDN switches require an additional configuration parameter per T1 trunk that is called 'Interface Identifier'. In NFAS T1 trunks, the Interface Identifier is sent explicitly in Q.931 Setup / Channel Identification IE for all NFAS trunks, except for the B-channels of the Primary trunk (see note below).

The Interface ID can be defined per member (T1 trunk) of the NFAS group, and must be coordinated with the configuration of the Switch. The default value of the Interface ID is identical to the number of the physical T1 trunk (0 for the first trunk, 1 for the second T1 trunk, and so on, up to the maximum number of trunks).

To define an explicit Interface ID for a T1 trunk (that is different from the default), use the following parameters:

- ISDNIBehavior_x = 512 (x = 0 to the maximum number of trunks identifying the device's physical trunk)
- ISDNNFASInterfaceID_x = ID (x = 0 to 255)



Notes:

- Usually the Interface Identifier is included in the Q.931 Setup/Channel Identification IE only on T1 trunks that doesn't contain the D-channel. Calls initiated on B-channels of the Primary T1 trunk, by default, don't contain the Interface Identifier. Setting the parameter ISDNIBehavior_x to 2048' forces the inclusion of the Channel Identifier parameter also for the Primary trunk.
- The parameter ISDNNFASInterfaceID_x = ID can define the 'Interface ID' for any Primary T1 trunk, even if the T1 trunk is not a part of an NFAS group. However, to include the Interface Identifier in Q.931 Setup/Channel Identification IE configure ISDNIBehavior_x = 2048 in the *ini* file.

21.6.2 Working with DMS-100 Switches

The DMS-100 switch requires the following NFAS Interface ID definitions:

- InterfaceID #0 for the Primary trunk
- InterfaceID #1 for the Backup trunk
- InterfaceID #2 for a 24 B-channel T1 trunk
- InterfaceID #3 for a 24 B-channel T1 trunk, and so on for subsequent T1 trunks

For example, if four T1 trunks on a device are configured as a single NFAS group with Primary and Backup T1 trunks that is used with a DMS-100 switch, the following parameters should be used:

```
NFASGroupNumber_0 = 1
NFASGroupNumber_1 = 1
NFASGroupNumber_2 = 1
NFASGroupNumber_3 = 1
DchConfig_0 = 0      ;Primary T1 trunk
DchConfig_1 = 1      ;Backup T1 trunk
DchConfig_2 = 2      ;B-Channel NFAS trunk
DchConfig_3 = 2      ;B-channel NFAS trunk
```

If there is no NFAS Backup trunk, the following configuration should be used:

```
ISDNNFASInterfaceID_0 = 0
ISDNNFASInterfaceID_1 = 2
ISDNNFASInterfaceID_2 = 3
ISDNNFASInterfaceID_3 = 4
ISDNBehavior = 512    ;This parameter should be added because of
;ISDNNFASInterfaceID configuration above
NFASGroupNumber_0 = 1
NFASGroupNumber_1 = 1
NFASGroupNumber_2 = 1
NFASGroupNumber_3 = 1
DchConfig_0 = 0      ;Primary T1 trunk
DchConfig_1 = 2      ;B-Channel NFAS trunk
DchConfig_2 = 2      ;B-Channel NFAS trunk
DchConfig_3 = 2      ;B-channel NFAS trunk
```

21.6.3 Creating an NFAS-Related Trunk Configuration

The procedures for creating and deleting an NFAS group must be performed in the correct order, as described below.

➤ **To create an NFAS Group:**

1. If there's a backup ('secondary') trunk for this group, it must be configured first.
2. Configure the primary trunk before configuring any NFAS ('slave') trunk.
3. Configure NFAS ('slave') trunks.

➤ **To stop / delete an NFAS Group:**

1. Stop or delete (by setting ProtocolType to 0, i.e., 'None') all NFAS ('slave') trunks.
2. Stop or delete (by setting ProtocolType to 0, i.e., 'None') the backup trunk if a backup trunk exists.
3. Stop or delete (by setting ProtocolType to 0, i.e., 'None') the primary trunk.



Notes:

- All trunks in the group must be configured with the same values for trunk parameters TerminationSide, ProtocolType, FramingMethod, and LineCode.
- After stopping or deleting the backup trunk, delete the group and then reconfigure it.

21.6.4 Performing Manual D-Channel Switchover in NFAS Group

If an NFAS group is configured with two D-channels (Primary and Backup), you can do a manual switchover between these D-channels.

➤ **To manually switchover from active to standby D-channel:**

1. Open the NFAS Group & D-Channel Status page (**Status & Diagnostics** tab > **VoIP Status** menu > **NFAS Group & D-Channel Status**).
2. Select the required NFAS group, and then click the **Switch Activity** button.



Notes:

- The **Switch Activity** button is unavailable (i.e., grayed out) if a switchover cannot be done due to, for example, alarms or unsuitable states.
- This feature is applicable only to T1 ISDN protocols supporting NFAS, and only if the NFAS group is configured with two D-channels.

21.7 ISDN Overlap Dialing

Overlap dialing is a dialing scheme used by several ISDN variants to send and/or receive called number digits one after the other (or several at a time). This is in contrast to en-bloc dialing in which a complete number is sent in one message. ISDN overlap dialing is applicable to PRI and BRI.

The device supports the following ISDN overlap dialing methods:

- Collects ISDN called party number digits and then sends the SIP INVITE to the IP side with the complete destination number (see 'Collecting ISDN Digits and Sending Complete Number in SIP' on page 288)
- Interworks ISDN overlap dialing with SIP, according to RFC 3578 (see 'Interworking ISDN Overlap Dialing with SIP According to RFC 3578' on page 289)

21.7.1 Collecting ISDN Digits and Sending Complete Number in SIP

The device can support an overlap dialing mode whereby the device collects the called party number digits from ISDN Q.931 Information messages or DTMF signals, and then sends a SIP INVITE message to the IP side containing the complete destination number.

ISDN overlap dialing for incoming ISDN calls can be configured for the entire device or per E1/T1 trunk. This is configured using the global, `ISDNRxOverlap` parameter or the `ISDNRxOverlap_x` parameter (where *x* denotes the trunk number), respectively.

By default (see the `ISDNINCallsBehavior` parameter), the device plays a dial tone to the ISDN user side when it receives an empty called number from the ISDN. In this scenario, the device includes the Progress Indicator in the SetupAck ISDN message that it sends to the ISDN side.

The device can also mute in-band DTMF detection until it receives the complete destination number from the ISDN. This is configured using the `MuteDTMFInOverlap` parameter. The Information digits can be sent in-band in the voice stream, or out-of-band using Q.931 Information messages. If Q.931 Information messages are used, the DTMF in-band detector must be disabled. Note that when at least one digit is received in the ISDN Setup message, the device stops playing a dial tone.

The device stops collecting digits (from the ISDN) upon the following scenarios:

- The device receives a Sending Complete IE in the ISDN Setup or Information messages, indicating no more digits.
- The timeout between received digits expires (configured by the `TimeBetweenDigits`

parameter).

- The maximum number of received digits has been reached (configured by the MaxDigits parameter).
- A match is found with the defined digit map (configured by the DigitMapping parameter).

Relevant parameters (described in 'PSTN Parameters' on page 747):

- ISDNRxOverlap_x = 1 (can be configured per trunk)
- TimeBetweenDigits
- MaxDigits
- MuteDTMFInOverlap
- DigitMapping

For configuring ISDN overlap dialing using the Web interface, see 'Configuring Trunk Settings' on page 273.

21.7.2 Interworking ISDN Overlap Dialing with SIP According to RFC 3578

The device supports the interworking of ISDN overlap dialing to SIP and vice versa, according to RFC 3578.

- **Interworking ISDN overlap dialing to SIP (Tel to IP):** The device sends collected digits each time it receives them (initially from the ISDN Setup message and then from subsequent Q.931 Information messages) to the IP side, using subsequent SIP INVITE messages. You can also define the minimum number of overlap digits to collect before sending the first SIP message (INVITE) for routing the call, using the MinOverlapDigitsForRouting parameter.
- **Interworking SIP to ISDN overlap dialing (IP to Tel):** For each received SIP INVITE pertaining to the same dialog session, the device sends an ISDN Setup message (and subsequent Q.931 Information messages) with the collected digits to the Tel side. For all subsequent INVITEs received, the device sends a SIP 484 "Address Incomplete" response to the IP in order to maintain the current dialog session and to receive additional digits from subsequent INVITEs.

Relevant parameters (described in 'PSTN Parameters' on page 747):

- ISDNRxOverlap = 2
- ISDNTxOverlap
- ISDNOutCallsBehavior = 2
- MinOverlapDigitsForRouting
- TimeBetweenDigits
- MaxDigits
- DigitMapping
- MuteDTMFInOverlap

For configuring ISDN overlap dialing using the Web interface, see 'Configuring Trunk Settings' on page 273.

21.8 Redirect Number and Calling Name (Display)

The following tables define the device's redirect number and calling name (Display) support for various ISDN variants according to NT (Network Termination) / TE (Termination Equipment) interface direction:

Calling Name (Display)

NT/TE Interface	DMS-100	NI-2	4/5ESS	Euro ISDN	QSIG
NT-to-TE	Yes	Yes	Yes	Yes	Yes
TE-to-NT	Yes	Yes	Yes	No	Yes

Redirect Number

NT/TE Interface	DMS-100	NI-2	4/5ESS	Euro ISDN	QSIG
NT-to-TE	Yes	Yes	Yes	Yes	Yes
TE-to-NT	Yes	Yes	Yes	Yes*	Yes

* When using ETSI DivertingLegInformation2 in a Facility IE (not Redirecting Number IE).

22 Trunk Group

This section describes the configuration of the device's channels, which includes assigning them to Trunk Groups.

22.1 Configuring Trunk Group Table

The Trunk Group Table page allows you to define up to 120 Trunk Groups. A Trunk Group is a logical group of physical trunks and channels that are assigned a Trunk Group ID. The Trunk Group can include multiple trunks and ranges of channels.

To enable and activate the channels of the device, Trunk Groups need to be defined and with telephone numbers. Channels that are not defined in this table are disabled. The Trunk Groups are later used for routing IP-to-Tel and Tel-to-IP calls.



Notes:

- After you have configured a Trunk Group, you must configure the Inbound IP Routing Table rules (see 'Configuring Inbound IP Routing Table' on page 332) to route incoming IP calls to the Trunk Group. If you do not configure this, calls cannot be established.
- To select the method on how incoming calls are routed to channels within a Trunk Group, see 'Configuring Trunk Group Settings' on page 293.
- The Trunk Group Table can also be configured using the table ini file parameter, TrunkGroup_x to (see 'Number Manipulation Parameters' on page 808).

➤ To configure the Trunk Group Table:

1. Open the Trunk Group Table page (**Configuration** tab > **VoIP** menu > **GW and IP to IP** submenu > **Trunk Group** > **Trunk Group**).

Add Phone Context As Prefix		Disable					
Trunk Group Index		1-12					

Group Index	Module	From Trunk	To Trunk	Channels	Phone Number	Trunk Group ID	Tel Profile ID
1	Module 1 PRI	1	1	1-30	6000	1	1
2	Module 1 PRI	2	2	1-30	7000	2	1
3	Module 2 FXS			1-4	101	3	2
4							

2. Configure the Trunk Group as required. For a description of the parameters, see the table below.
3. Click **Submit** to apply your changes.
4. To save the changes to the flash memory, see 'Saving Configuration' on page 494.
5. To register the Trunk Groups, click the **Register** button. To unregister the Trunk Groups, click **Unregister**. The registration method for each Trunk Group is according to the 'Registration Mode' parameter in the Trunk Group Settings page (see

'Configuring Trunk Group Settings' on page 293).

Trunk Group Table Parameters

Parameter	Description
Module [TrunkGroup_Module]	Defines the module (i.e., FXS, FXO, PRI, or BRI) for which you want to define the Trunk Group.
From Trunk [TrunkGroup_FirstTrunkId]	Defines the starting physical Trunk number in the Trunk Group. The number of listed Trunks depends on the device's hardware configuration. Note: This parameter is applicable only to PRI and BRI modules.
To Trunk [TrunkGroup_LastTrunkId]	Defines the ending physical Trunk number in the Trunk Group. The number of listed Trunks depends on the device's hardware configuration. Note: This parameter is applicable only to PRI and BRI modules.
Channels [TrunkGroup_FirstBChannel] [TrunkGroup_LastBChannel]	Defines the device's channels/ports (analog module) or Trunk B-channels (digital module). To enable channels, enter the channel numbers. You can enter a range of channels by using the syntax <i>n-m</i> , where <i>n</i> represents the lower channel number and <i>m</i> the higher channel number. For example, "1-4" specifies channels 1 through 4. Notes: <ul style="list-style-type: none"> The number of defined channels must not exceed the maximum number of the Trunk's B-channels. To represent all the Trunk's B-channels, enter a single asterisk (*).
Phone Number [TrunkGroup_FirstPhoneNumber]	Defines the telephone number(s) of the channels. The valid value can be up to 50 characters. For a range of channels, enter only the first telephone number. Subsequent channels are assigned the next consecutive telephone number. For example, if you enter 400 for channels 1 to 4, then channel 1 is assigned phone number 400, channel 2 is assigned phone number 401, and so on. These numbers are also used for channel allocation for IP-to-Tel calls if the Trunk Group's 'Channel Select Mode' parameter is set to By Dest Phone Number . Notes: <ul style="list-style-type: none"> If this field includes alphabetical characters and the phone number is defined for a range of channels (e.g., 1-4), then the phone number must end with a number (e.g., 'user1'). This field is optional for BRI/PRI interfaces. The logical numbers defined in this field are used when an incoming PSTN/PBX call doesn't contain the calling number or called number (the latter being determined by the ReplaceEmptyDstWithPortNumber parameter). These numbers are used to replace them.
Trunk Group ID [TrunkGroup_TrunkGroupNum]	Defines the Trunk Group ID for the specified channels. The same Trunk Group ID can be assigned to more than one group of channels. If an IP-to-Tel call is assigned to a Trunk Group, the IP call is routed to the channel(s) pertaining to that Trunk Group ID. The valid value can be 0 to 119.
Tel Profile ID [TrunkGroup_ProfileId]	Assigns a Tel Profile ID to the Trunk Group. Note: For configuring Tel Profiles, see 'Configuring Tel Profiles' on page 243.

22.2 Configuring Trunk Group Settings

The Trunk Group Settings allows you to configure the following per Trunk Group:

- Channel select method by which IP-to-Tel calls are assigned to the Trunk Group's channels.
- Registration method for registering Trunk Groups to selected Serving IP Group IDs.



Notes:

- For configuring Trunk Groups, see Configuring Trunk Group Table on page 291.
- The Trunk Group Settings table can also be configured using the table ini file parameter, TrunkGroupSettings (see 'Number Manipulation Parameters' on page 808).

➤ To configure the Trunk Group Settings table:

1. Open the Trunk Group Settings page (**Configuration** tab > **VoIP** menu > **GW and IP to IP** submenu > **Trunk Group** > **Trunk Group Settings**).

Trunk Group ID	Channel Select Mode	Registration Mode	Serving IP Group ID	Gateway Name	Contact User	MWI Interrogation Type
1						Not Configured
2						Not Configured
3						Not Configured
4						Not Configured
5						Not Configured
6						Not Configured
7						Not Configured
8						Not Configured
9						Not Configured
10						Not Configured

2. From the 'Index' drop-down list, select the range of entries that you want to edit.
3. Configure the Trunk Group as required. For a description of the parameters, see the table below.
4. Click **Submit** to apply your changes.
5. To save the changes to flash memory, see 'Saving Configuration' on page 494.

Trunk Group Settings Parameters Description

Parameter	Description
Trunk Group ID [TrunkGroupSettings_TrunkGroupID]	Defines the Trunk Group ID that you want to configure.
Channel Select Mode [TrunkGroupSettings_ChannelSelectMode]	<p>Defines the method by which IP-to-Tel calls are assigned to the channels of the Trunk Group.</p> <ul style="list-style-type: none"> ▪ [0] By Dest Phone Number = The channel is selected according to the called (destination) number. If the number is not located, the call is released. If the channel is unavailable (e.g., busy), the call is put on call waiting (if call waiting is enabled and no other call is on call waiting); otherwise, the call is released.

Parameter	Description
	<ul style="list-style-type: none"> ▪ [1] Cyclic Ascending = The next available channel in the Trunk Group, in ascending cyclic order is selected. After the device reaches the highest channel number in the Trunk Group, it selects the lowest channel number in the Trunk Group, and then starts ascending again. ▪ [2] Ascending = The lowest available channel in the Trunk Group is selected, and if unavailable, the next higher channel is selected. ▪ [3] Cyclic Descending = The next available channel in descending cyclic order is selected. The next lower channel number in the Trunk Group is always selected. When the device reaches the lowest channel number in the Trunk Group, it selects the highest channel number in the Trunk Group, and then starts descending again. ▪ [4] Descending = The highest available channel in the Trunk Group is selected, and if unavailable, the next lower channel is selected. ▪ [5] Dest Number + Cyclic Ascending = The channel is selected according to the called number. If the called number isn't found, the next available channel in ascending cyclic order is selected. Note: If the called number is located, but the port associated with the number is busy, the call is released. ▪ [6] By Source Phone Number = The channel is selected according to the calling number. ▪ [7] Trunk Cyclic Ascending = The channel from the first channel of the next trunk (adjacent to the trunk from which the previous channel was selected) is selected. This option is applicable only to digital interfaces. ▪ [8] Trunk & Channel Cyclic Ascending = The device implements the Trunk Cyclic Ascending and Cyclic Ascending methods to select the channel. This method selects the next physical trunk in the Trunk Group, and then selects the B-channel of this trunk according to the Cyclic Ascending method (i.e., selects the channel after the last allocated channel). This option is applicable only to digital interfaces. For example, if the Trunk Group includes two physical trunks, 0 and 1: <ul style="list-style-type: none"> ✓ For the first incoming call, the first channel of Trunk 0 is selected. ✓ For the second incoming call, the first channel of Trunk 1 is selected. ✓ For the third incoming call, the second channel of Trunk 0 is selected. ▪ [9] Ring to Hunt Group = The device allocates IP-to-Tel calls to all the FXS ports (channels) in the Hunt Group. When a call is received for the Hunt Group, all telephones connected to the FXS ports belonging to the Hunt Group start ringing. The call is eventually received by whichever telephone first answers the call (after which the other phones stop ringing). This option is applicable only to FXS interfaces. ▪ [10] Select Trunk by ISDN SuppServ Table = The BRI port/module is selected according to the settings in the ISDN Supplementary Services table (see Configuring ISDN BRI Supplementary Services on page 385), allowing the routing of IP-to-Tel calls to specific BRI endpoints. ▪ [11] Dest Number + Ascending = The device allocates a channels

Parameter	Description
	<p>to incoming IP-to-Tel calls as follows:</p> <ol style="list-style-type: none"> a. The device attempts to route the call to the channel that is associated with the destination (called) number. If located, the call is sent to that channel. b. If the number is not located or the channel is unavailable (e.g., busy), the device searches in ascending order for the next available channel in the Trunk Group. If located, the call is sent to that channel. c. If all the channels are unavailable, the call is released. <p>Note: If this parameter is not configured for the Trunk Group, then its channel select method is according to the global parameter, ChannelSelectMode.</p>
<p>Registration Mode [TrunkGroupSettings_RegistrationMode]</p>	<p>Defines the registration method for the Trunk Group:</p> <ul style="list-style-type: none"> ▪ [1] Per Gateway = (Default) Single registration for the entire device. This is applicable only if a default Proxy or Registrar IP is configured and Registration is enabled (i.e., parameter IsRegisterUsed is set to 1). In this mode, the SIP URI user part in the From, To, and Contact headers is set to the value of the global registration parameter, GWRegistrationName or username if GWRegistrationName is not configured. ▪ [0] Per Endpoint = Each channel in the Trunk Group registers individually. The registrations are sent to the 'Serving IP Group ID' if defined in the table, otherwise, it is sent to the default Proxy, and if no default Proxy, then to the Registrar IP. ▪ [4] Don't Register = No registrations are sent by endpoints pertaining to the Trunk Group. For example, if the device is configured globally to register all its endpoints (using the parameter ChannelSelectMode), you can exclude some endpoints from being registered by assigning them to a Trunk Group and configuring the Trunk Group registration mode to 'Don't Register'. ▪ [5] Per Account = Registrations are sent (or not) to an IP Group, according to the settings in the Account table (see 'Configuring Account Table' on page 225). <p>An example is shown below of a REGISTER message for registering endpoint "101" using the registration Per Endpoint mode:</p> <pre>REGISTER sip:SipGroupName SIP/2.0 Via: SIP/2.0/UDP 10.33.37.78;branch=z9hG4bKac862428454 From: <sip:101@GatewayName>;tag=1c862422082 To: <sip:101@GatewayName> Call-ID: 9907977062512000232825@10.33.37.78 CSeq: 3 REGISTER Contact: <sip:101@10.33.37.78>;expires=3600 Expires: 3600 User-Agent: Sip-Gateway/v.6.60A.011.002 Content-Length: 0</pre> <p>The "SipGroupName" in the Request-URI is configured in the IP Group table (see 'Configuring IP Groups' on page 214).</p> <p>Notes:</p> <ul style="list-style-type: none"> ▪ If this parameter is not configured, the registration is performed according to the global registration parameter, ChannelSelectMode. ▪ To enable Trunk Group registration, set the global parameter,

Parameter	Description
	<p>IsRegisterNeeded to 1. This is unnecessary for 'Per Account' registration mode.</p> <ul style="list-style-type: none"> If the device is configured globally to register Per Endpoint and an channel group includes four channels to register Per Gateway, the device registers all channels except the first four channels. The group of these four channels sends a single registration request.
Serving IP Group ID [TrunkGroupSettings_ServingIPGroup]	<p>Assigns an IP Group to where INVITE messages received from this Trunk Group are sent. The actual destination to where these INVITE messages are sent is according to the Proxy Set ID associated with the IP Group. The Request-URI host name in the INVITE and REGISTER messages (except for 'Per Account' registration modes) is set to the value of the 'SIP Group Name' parameter configured in the IP Group table (see 'Configuring IP Groups' on page 214).</p> <p>Notes:</p> <ul style="list-style-type: none"> If this parameter is not configured, the INVITE messages are sent to the default Proxy or according to the Outbound IP Routing Table (see 'Configuring Outbound IP Routing Table' on page 323). If the PreferRouteTable parameter is set to 1 (see 'Configuring Proxy and Registration Parameters' on page 228), the routing rules in the Outbound IP Routing table take precedence over the selected Serving IP Group ID.
Gateway Name [TrunkGroupSettings_GatewayName]	<p>Defines the host name for the SIP From header in INVITE messages and for the From/To headers in REGISTER requests.</p> <p>Note: If this parameter is not configured, the global parameter, SIPGatewayName is used.</p>
Contact User [TrunkGroupSettings_ContactUser]	<p>Defines the user part for the SIP Contact URI in INVITE messages and for the From, To, and Contact headers in REGISTER requests.</p> <p>Notes:</p> <ul style="list-style-type: none"> This parameter is applicable only if the 'Registration Mode' parameter is set to 'Per Account' and registration through the Account table is successful. If registration fails, the user part in the INVITE Contact header is set to the source party number. The 'Contact User' parameter in the Account table overrides this parameter (see 'Configuring Account Table' on page 225).
Trunk Group Name [TrunkGroupSettings_TrunkGroupName]	<p>Defines a name for the Trunk Group. This name represents the Trunk Group in the SIP 'tgrp' parameter of the outgoing INVITE messages (according to RFC 4904). For example:</p> <pre style="background-color: #f0f0f0; padding: 5px;">sip:+16305550100;tgrp=TG-1;trunk-context=+1-630@isp.example.net;user=phone</pre> <p>The valid value can be a string of up to 20 characters. By default, no name is configured.</p> <p>Notes:</p> <ul style="list-style-type: none"> If this parameter is not configured, the Trunk Group decimal number is used in the SIP 'tgrp' parameter. This feature is enabled by any of the following parameters: <ul style="list-style-type: none"> ✓ UseSIPtgrp ✓ UseBroadsoftDTG Currently, this parameter can only be configured using the ini file.

Parameter	Description
MWI Interrogation Type [TrunkGroupSettings_MWIInterrogationType]	<p>Defines MWI QSIG-to-IP interworking for interrogating MWI supplementary services:</p> <ul style="list-style-type: none"> ▪ [255] Not Configured ▪ [0] None = Disables the feature. ▪ [1] Use Activate Only = MWI Interrogation messages are not sent and only "passively" responds to MWI Activate requests from the PBX. ▪ [2] Result Not Used = MWI Interrogation messages are sent, but the result is not used. Instead, the device waits for MWI Activate requests from the PBX. ▪ [3] Use Result = MWI Interrogation messages are sent, its results are used, and the MWI Activate requests are used. MWI Activate requests are interworked to SIP NOTIFY MWI messages. The SIP NOTIFY messages are sent to the IP Group defined by the NotificationIPGroupID parameter. <p>Note: This parameter appears in the table only if the VoiceMailInterface parameter is set to 3 (QSIG). Configuring Voice Mail on page 388.</p>

Reader's Notes

23 Manipulation

This section describes the configuration of various manipulation processes.

23.1 Configuring General Settings

The General Settings page allows you to configure general manipulation parameters. For a description of the parameters appearing on this page, see 'Configuration Parameters Reference' on page 609.

➤ **To configure the general manipulation parameters:**

1. Open the General Settings page (**Configuration** tab > **VoIP** menu > **GW and IP to IP** submenu > **Manipulations** submenu > **General Settings**).

Figure 23-1: General Settings Page

Set TEL-to-IP Redirect Reason	Not Configured	▼
Set IP-to-TEL Redirect Reason	Not Configured	▼
Redirect number SI to TEL	Not Configured	▼

2. Configure the parameters as required.
3. Click **Submit** to apply your changes.

23.2 Configuring Source/Destination Number Manipulation Rules

You can configure rules for manipulating destination and/or source telephone numbers for IP-to-Tel and Tel-to-IP calls. The following number manipulation tables are used for this:

■ **Tel-to-IP calls:**

- Destination Phone Number Manipulation Table for Tel > IP Calls table (up to 120 entries)
- Source Phone Number Manipulation Table for Tel > IP Calls table (up to 120 entries)

■ **IP-to-Tel calls:**

- Destination Phone Number Manipulation Table for IP > Tel Calls table (up to 120 entries)
- Source Phone Number Manipulation Table for IP > Tel Calls table (up to 120 entries)

The number manipulation tables provide two configuration areas:

- Matching characteristics (*Rule*) of incoming call, for example, prefix of destination number.
- Manipulation operation (*Action*), for example, remove user-defined number of digits from the left of the number.

If the incoming call matches the characteristics of a rule, then its manipulation action is applied.

The device searches a matching manipulation rule starting from the first entry (i.e., top of the table). In other words, a rule at the top of the table takes precedence over a rule defined lower down in the table. Therefore, define more specific rules above more generic rules. For example, if you enter 551 in Index 1 and 55 in Index 2, the device applies rule 1 to numbers that start with 551 and applies rule 2 to numbers that start with 550, 552, 553,

and so on until 559. However, if you enter 55 in Index 1 and 551 in Index 2, the device applies rule 1 to all numbers that start with 55, including numbers that start with 551.

You can perform a second "round" (additional) of destination (NumberMapIP2Tel parameter) and source (SourceNumberMapIP2Tel parameter) number manipulations for IP-to-Tel calls on an already manipulated number. The initial and additional number manipulation rules are both configured in these tables. The additional manipulation is performed on the initially manipulated number. Therefore, for complex number manipulation schemes, you only need to configure relatively few manipulation rules in these tables (that would otherwise require many rules). This feature is enabled using the following parameters:

- PerformAdditionalIP2TELSrcManipulation for source number manipulation
- PerformAdditionalIP2TELDestinationManipulation for destination number manipulation

Telephone number manipulation can be useful, for example, for the following:

- Stripping or adding dialing plan digits from or to the number, respectively. For example, a user may need to first dial 9 before dialing the phone number to indicate an external line. This number 9 can then be removed by number manipulation before the call is setup.
- Allowing or blocking Caller ID information according to destination or source prefixes. For more information on Caller ID, see *Configuring Caller Display Information* on page 396.
- For digital modules only: Assigning Numbering Plan Indicator (NPI) and Type of Numbering (TON) to IP-to-Tel calls. The device can use a single global setting for NPI/TON classification or it can use the setting in the manipulation tables on a call-by-call basis.



Notes:

- Number manipulation can occur before or after a routing decision is made. For example, you can route a call to a specific Trunk Group according to its original number, and then you can remove or add a prefix to that number before it is routed. To determine when number manipulation is performed, configure the 'IP to Tel Routing Mode' parameter (RouteModeIP2Tel) described in 'Configuring Inbound IP Routing Table' on page 332, and 'Tel to IP Routing Mode' parameter (RouteModeTel2IP) described in 'Configuring Outbound IP Routing Table' on page 323.
- The device manipulates the number in the following order: 1) strips digits from the left of the number, 2) strips digits from the right of the number, 3) retains the defined number of digits, 4) adds the defined prefix, and then 5) adds the defined suffix.
- The source/destination number manipulation tables can also be configured using the ini file:
 - 1) **Destination Phone Number Manipulation Table for IP > Tel Calls table:** NumberMapIP2Tel (ini)
 - 2) **Destination Phone Number Manipulation Table for Tel > IP Calls table:** NumberMapTel2IP (ini)
 - 3) **Source Phone Number Manipulation Table for IP > Tel Calls table:** SourceNumberMapIP2Tel (ini)
 - 4) **Source Phone Number Manipulation Table for Tel > IP Calls table:** SourceNumberMapTel2IP (ini)

➤ **To configure number manipulation rules:**

1. Open the required Number Manipulation page (**Configuration** tab > **VoIP** menu > **GW and IP to IP** submenu > **Manipulations** submenu > **Dest Number IP->Tel**, **Dest Number Tel->IP**, **Source Number IP->Tel**, or **Source Number Tel->IP**); the relevant Manipulation table page is displayed.
2. Click the **Add** button; the following dialog box appears:

Figure 23-2: Number Manipulation Table - Add Dialog Box

Rule	Action
Index	0
Destination Prefix	*
Source Prefix	*
Source IP Address	*
Source Host Prefix	*
Destination Host Prefix	*

3. Click the **Rule** tab, and then configure the matching characteristics. For a description of the parameters, see the table below.
4. Click the **Action** tab, and then configure the manipulation operation. For a description of the parameters, see the table below.
5. Click **Submit** to apply your changes.
6. To save the changes to flash memory, see 'Saving Configuration' on page 494.

The table below shows configuration examples of Tel-to-IP source phone number manipulation rules, where:

- **Rule 1:** When the destination number has the prefix 03 (e.g., 035000), source number prefix 201 (e.g., 20155), and from source IP Group ID 2, the source number is changed to, for example, 97120155.
- **Rule 2:** When the source number has prefix 1001 (e.g., 1001876), it is changed to 587623.
- **Rule 3:** When the source number has prefix 123451001 (e.g., 1234510012001), it is changed to 20018.
- **Rule 4:** When the source number has prefix from 30 to 40 and a digit (e.g., 3122), it is changed to 2312.
- **Rule 5:** When the destination number has the prefix 6, 7, or 8 (e.g., 85262146), source number prefix 2001, it is changed to 3146.

Parameter	Rule 1	Rule 2	Rule 3	Rule 4	Rule 5
Source IP Group	2	0	-	-	-
Destination Prefix	03		*	*	[6,7,8]
Source Prefix	201	1001	123451001#	[30-40]x	2001
Stripped Digits from Left	-	4	-	-	5
Stripped Digits from Right	-	-	-	1	-
Prefix to Add	971	5	-	2	3
Suffix to Add	-	23	8	-	-
Number of Digits to Leave	-	-	4	-	-
Presentation	Allowed	Restricted	-	-	-

Number Manipulation Parameters Description

Parameter	Description
Matching Characteristics (Rule)	
Web: Destination Prefix EMS: Prefix [DestinationPrefix]	Defines the destination (called) telephone number prefix and/or suffix. You can use special notations for denoting the prefix. For example, [100-199](100,101,105) denotes a number that starts with 100 to 199 and ends with 100, 101 or 105. You can also use the \$ sign to denote calls without a called number. For a description of available notations, see 'Dialing Plan Notation for Routing and Manipulation Tables' on page 607.
Web/EMS: Source Prefix [SourcePrefix]	Defines the source (calling) telephone number prefix and/or suffix. You can use special notations for denoting the prefix. For example, [100-199](100,101,105) denotes a number that starts with 100 to 199 and ends with 100, 101 or 105. You can also use the \$ sign to denote calls without a calling number. For a description of available notations, see 'Dialing Plan Notation for Routing and Manipulation Tables' on page 607.
Web/EMS: Source IP Address [SourceAddress]	Defines the source IP address of the caller. This is obtained from the Contact header in the INVITE message. Notes: <ul style="list-style-type: none"> ▪ This parameter is applicable only to the number manipulation tables for IP-to-Tel calls. ▪ The source IP address can include the 'x' wildcard to represent single digits. For example: 10.8.8.xx represents all IP addresses between 10.8.8.10 to 10.8.8.99. ▪ The source IP address can include the asterisk (*) wildcard to represent any number between 0 and 255. For example, 10.8.8.* represents all IP addresses between 10.8.8.0 and 10.8.8.255.

Parameter	Description
Web: Source Host Prefix [SrcHost]	<p>Defines the URI host name prefix of the incoming SIP INVITE message in the From header.</p> <p>Notes:</p> <ul style="list-style-type: none"> ▪ This parameter is applicable only to the number manipulation tables for IP-to-Tel calls. ▪ The asterisk (*) wildcard can be used to denote any prefix. ▪ If the P-Asserted-Identity header is present in the incoming INVITE message, then the value of this parameter is compared to the P-Asserted-Identity URI host name (instead of the From header).
Web: Destination Host Prefix [DestHost]	<p>Defines the Request-URI host name prefix of the incoming SIP INVITE message.</p> <p>Notes:</p> <ul style="list-style-type: none"> ▪ This parameter is applicable only to the number manipulation tables for IP-to-Tel calls. ▪ The asterisk (*) wildcard can be used to denote any prefix.
Web: Source Trunk Group [SrcTrunkGroupID]	<p>Defines the source Trunk Group ID for Tel-to-IP calls. To denote all Trunk Groups, leave this field empty.</p> <p>Notes:</p> <ul style="list-style-type: none"> ▪ The value -1 indicates that this field is ignored in the rule. ▪ This parameter is applicable only to the number manipulation tables for Tel-to-IP calls. ▪ For IP-to-IP call routing, this parameter is not required (i.e., leave the field empty).
Web: Source IP Group [SrcIPGroupID]	<p>Defines the IP Group from where the IP call originated. Typically, the IP Group of an incoming INVITE is determined or classified using the Inbound IP Routing Table. If not used (i.e., any IP Group), leave the field empty.</p> <p>Notes:</p> <ul style="list-style-type: none"> ▪ The value -1 indicates that this field is ignored. ▪ This parameter is applicable only to the number manipulation tables for Tel-to-IP calls. ▪ If this Source IP Group has a Serving IP Group, then all calls from this Source IP Group are sent to the Serving IP Group. In this scenario, this table is used only if the PreferRouteTable parameter is set to 1.
Web: Destination IP Group [DestIPGroupID]	<p>Defines the IP Group to where the call is sent.</p> <p>Notes:</p> <ul style="list-style-type: none"> ▪ The value -1 indicates that this field is ignored. ▪ This parameter is applicable only to the Destination Phone Number Manipulation Table for Tel -> IP Calls.
Operation (Action)	
Web: Stripped Digits From Left EMS: Number Of Stripped Digits [RemoveFromLeft]	<p>Defines the number of digits to remove from the left of the telephone number prefix. For example, if you enter 3 and the phone number is 5551234, the new phone number is 1234.</p>
Web: Stripped Digits From Right	<p>Defines the number of digits to remove from the right of the telephone number prefix. For example, if you enter 3 and the phone number is</p>

Parameter	Description
EMS: Number Of Stripped Digits [RemoveFromRight]	5551234, the new phone number is 5551.
Web: Prefix to Add EMS: Prefix/Suffix To Add [Prefix2Add]	Defines the number or string that you want added to the front of the telephone number. For example, if you enter 9 and the phone number is 1234, the new number is 91234.
Web: Suffix to Add EMS: Prefix/Suffix To Add [Suffix2Add]	Defines the number or string that you want added to the end of the telephone number. For example, if you enter 00 and the phone number is 1234, the new number is 123400.
Web/EMS: Number of Digits to Leave [LeaveFromRight]	Defines the number of digits that you want to keep from the right of the phone number. For example, if you enter 4 and the phone number is 00165751234, then the new number is 1234.
Web: NPI EMS: Number Plan [NumberPlan]	<p>Defines the Numbering Plan Indicator (NPI).</p> <ul style="list-style-type: none"> ▪ [0] Unknown (default) ▪ [9] Private ▪ [1] E.164 Public ▪ [-1] Not Configured = value received from PSTN/IP is used <p>Notes:</p> <ul style="list-style-type: none"> ▪ This parameter is applicable only to number manipulation tables for IP-to-Tel calls. ▪ NPI can be used in the SIP Remote-Party-ID header by using the EnableRPIHeader and AddTON2RPI parameters. ▪ For more information on available NPI/TON values, see Numbering Plans and Type of Number on page 321.
Web: TON EMS: Number Type [NumberType]	<p>Defines the Type of Number (TON).</p> <ul style="list-style-type: none"> ▪ If you selected 'Unknown' for the NPI, you can select Unknown [0]. ▪ If you selected 'Private' for the NPI, you can select Unknown [0], Level 2 Regional [1], Level 1 Regional [2], PISN Specific [3] or Level 0 Regional (Local) [4]. ▪ If you selected 'E.164 Public' for the NPI, you can select Unknown [0], International [1], National [2], Network Specific [3], Subscriber [4] or Abbreviated [6]. <p>The default is 'Unknown'.</p> <p>Notes:</p> <ul style="list-style-type: none"> ▪ This parameter is applicable only to number manipulation tables for IP-to-Tel calls. ▪ TON can be used in the SIP Remote-Party-ID header by using the EnableRPIHeader and AddTON2RPI parameters. ▪ For more information on available NPI/TON values, see Numbering Plans and Type of Number on page 321.
Web: Presentation EMS: Is Presentation Restricted [IsPresentationRestricted]	<p>Enables caller ID.</p> <ul style="list-style-type: none"> ▪ Not Configured = Privacy is determined according to the Caller ID table (see Configuring Caller Display Information on page 396). ▪ [0] Allowed = Sends Caller ID information when a call is made using these destination/source prefixes. ▪ [1] Restricted = Restricts Caller ID information for these prefixes. <p>Notes:</p> <ul style="list-style-type: none"> ▪ This field is applicable only to number manipulation tables for source phone number manipulation.

Parameter	Description
	<ul style="list-style-type: none"> If this field is set to Restricted and the 'Asserted Identity Mode' (AssertedIdMode) parameter is set to Add P-Asserted-Identity, the From header in the INVITE message includes the following: From: 'anonymous' <sip: anonymous@anonymous.invalid> and 'privacy: id' header.

23.3 Manipulating Number Prefix

The device supports a notation for adding a prefix where part of the prefix is first extracted from a user-defined location in the original destination or source number. This notation is entered in the 'Prefix to Add' field in the Number Manipulation tables (see 'Configuring Source/Destination Number Manipulation' on page 299): $x[n,l]y...$

where,

- x = any number of characters/digits to add at the beginning of the number (i.e. first digits in the prefix).
- $[n,l]$ = defines the location in the original destination or source number where the digits y are added:
 - n = location (number of digits counted from the left of the number) of a specific string in the original destination or source number.
 - l = number of digits that this string includes.
- y = prefix to add at the specified location.

For example, assume that you want to manipulate an incoming IP call with destination number +5492028888888 (area code 202 and phone number 8888888) to the number 0202158888888. To perform such a manipulation, the following configuration is required in the Number Manipulation table:

1. The following notation is used in the 'Prefix to Add' field:

0[5,3]15

where,

- 0 is the number to add at the beginning of the original destination number.
 - [5,3] denotes a string that is located after (and including) the fifth character (i.e., the first '2' in the example) of the original destination number, and its length being three digits (i.e., the area code 202, in the example).
 - 15 is the number to add immediately after the string denoted by [5,3] - in other words, 15 is added after (i.e. to the right of) the digits 202.
2. The first seven digits from the left are removed from the original number, by entering "7" in the 'Stripped Digits From Left' field.

Example of Configured Rule for Manipulating Prefix using Special Notation

Parameter	Rule 1
Destination Prefix	+5492028888888
Source Prefix	*
Source IP Address	*
Stripped Digits from Left	7

Parameter	Rule 1
Prefix to Add	0[5,3]15

In this configuration example, the following manipulation process occurs:

1. The prefix is calculated as 020215.
2. The first seven digits from the left are removed from the original number, thereby changing the number to 8888888.
3. The prefix that was previously calculated is then added.

23.4 SIP Calling Name Manipulations

The Calling Name Manipulations Tel2IP and Calling Name Manipulations IP2Tel tables allow you to configure up to 120 manipulation rules for manipulating the calling name (i.e., caller ID) in SIP messages. This can include modifying or removing the calling name. SIP calling name manipulation is applicable to Tel-to-IP and IP-to-Tel calls.

For example, assume that an incoming SIP INVITE message includes the following header:

```
P-Asserted-Identity: "company:john" sip:6666@78.97.79.104
```

Using the Calling Name Manipulations IP2Tel table, the text "company" can be changed to "worker" in the outgoing INVITE, as shown below:

```
P-Asserted-Identity: "worker:john" sip:996666@10.13.83.10
```

The calling name manipulation tables provide two configuration areas:

- Matching characteristics (*Rule*) of incoming call, for example, prefix of destination number.
- Manipulation operation (*Action*), for example, remove user-defined number of digits from the left of the calling name.

If the incoming call matches the characteristics of a rule, then its manipulation action is applied.



Notes:

- For configuring the Calling Name Manipulation Table for Tel > IP Calls table for retrieving calling name (display name) from an Active Directory using LDAP queries, see 'Querying the AD for Calling Name' on page 201.
- The Calling Name Manipulations Tel2IP table can also be configured using the table *ini* file parameter, CallingNameMapTel2Ip.
- The Calling Name Manipulations IP2Tel table can also be configured using the table *ini* file parameter, CallingNameMapIp2Tel.

- **To configure calling name manipulation rules:**
- 1. Open the required Calling Name Manipulations page (**Configuration** tab > **VoIP** menu > **GW and IP to IP** submenu > **Manipulations** > **Calling Name IP->Tel** or **Calling Name Tel->IP**).
- 2. Click the **Add** button; the following dialog box appears:

Figure 23-3: Calling Name Manipulation IP2Tel - Rule Tab

- 3. Click the **Rule** tab, and then configure the matching characteristics. For a description of the parameters, see the table below.
- 4. Click the **Action** tab, and then configure the manipulation operation. For a description of the parameters, see the table below.
- 5. Click the **Submit** button to save your changes.

Calling Name Manipulation Parameters Description

Parameter	Description
Matching Characteristics (Rule)	
Web: Destination Prefix	Defines the destination (called) telephone number prefix and/or suffix. You can use special notations for denoting the prefix. For example, [100-199](100,101,105) denotes a number that starts with 100 to 199 and ends with 100, 101 or 105. You can also use the \$ sign to denote calls without a called number. For a description of available notations, see 'Dialing Plan Notation for Routing and Manipulation Tables' on page 607.
Web/EMS: Source Prefix	Defines the source (calling) telephone number prefix and/or suffix. You can use special notations for denoting the prefix. For example, [100-199](100,101,105) denotes a number that starts with 100 to 199 and ends with 100, 101 or 105. You can also use the \$ sign to denote calls without a calling number. For a description of available notations, see 'Dialing Plan Notation for Routing and Manipulation Tables' on page 607.
Web: Calling Name Prefix	Defines the caller name (i.e., caller ID) prefix. You can use special notations for denoting the prefix. For example, to denote any prefix, use the asterisk (*) symbol or to denote calls without a calling name, use the \$ sign. For a description of available notations, see 'Dialing Plan Notation for Routing and Manipulation Tables' on page 607.
Web: Source Trunk Group ID	Defines the source Trunk Group ID for Tel-to-IP calls. To denote all Trunk Groups, leave this field empty. Notes:

Parameter	Description
	<ul style="list-style-type: none"> ▪ This parameter is applicable only to the Calling Name Manipulations Tel2IP table. ▪ The value -1 indicates that this field is ignored in the rule. ▪ This parameter is applicable only to Tel-to-IP calls.
Web: Source IP Group ID	Defines the IP Group from where the IP call originated. Notes: <ul style="list-style-type: none"> ▪ This parameter is applicable only to the Calling Name Manipulations Tel2IP table. ▪ The value -1 indicates that this field is ignored in the rule.
Web/EMS: Source IP Address	Defines the source IP address of the caller, obtained from the Contact header in the INVITE message. Notes: <ul style="list-style-type: none"> ▪ This parameter is applicable only to the Calling Name Manipulations IP2Tel table. ▪ The source IP address can include the 'x' wildcard to represent single digits. For example: 10.8.8.xx represents all IP addresses between 10.8.8.10 to 10.8.8.99. ▪ The source IP address can include the asterisk (*) wildcard to represent any number between 0 and 255. For example, 10.8.8.* represents all IP addresses between 10.8.8.0 and 10.8.8.255.
Web: Source Host Prefix	Defines the URI host name prefix of the incoming SIP INVITE message in the From header. Notes: <ul style="list-style-type: none"> ▪ This parameter is applicable only to the Calling Name Manipulations IP2Tel table. ▪ The asterisk (*) wildcard can be used to denote any prefix. ▪ If the P-Asserted-Identity header is present in the incoming INVITE message, then the value of this parameter is compared to the P-Asserted-Identity URI host name (instead of the From header).
Web: Destination Host Prefix	Defines the Request-URI host name prefix of the incoming SIP INVITE message. Notes: <ul style="list-style-type: none"> ▪ This parameter is applicable only to the Calling Name Manipulations IP2Tel table. ▪ The asterisk (*) wildcard can be used to denote any prefix.
Operation (Action)	
Web: Stripped Digits From Left EMS: Number Of Stripped Digits	Defines the number of characters to remove from the left of the calling name. For example, if you enter 3 and the calling name is "company:john", the new calling name is "pany:john".
Web: Stripped Digits From Right EMS: Number Of Stripped Digits	Defines the number of characters to remove from the right of the calling name. For example, if you enter 3 and the calling name is "company:name", the new name is "company:n".
Web/EMS: Number of Digits to Leave	Defines the number of characters that you want to keep from the right of the calling name. For example, if you enter 4 and the calling name is "company:name", the new name is "name".

Parameter	Description
Web: Prefix to Add EMS: Prefix/Suffix To Add	Defines the number or string to add at the front of the calling name. For example, if you enter ITSP and the calling name is "company:name", the new name is ITSPcompany:john".
Web: Suffix to Add EMS: Prefix/Suffix To Add	Defines the number or string to add at the end of the calling name. For example, if you enter 00 and calling name is "company:name", the new name is "company:name00".

23.5 Configuring Redirect Number IP to Tel

You can configure rules for manipulating the redirect number received in the incoming message:

- IP-to-Tel redirect number manipulation: You can manipulate the value of the received SIP Diversion, Resource-Priority, or History-Info headers, which is then added to the Redirecting Number Information Element (IE) in the ISDN Setup message sent to the Tel side. This also includes the reason for the call redirection. This is configured in the Redirect Number IP > Tel table.
- Tel-to-IP redirect number manipulation: You can manipulate the prefix of the redirect number, received from the Tel side, in the outgoing SIP Diversion, Resource-Priority, or History-Info headers sent to the IP side. This is configured in the Redirect Number Tel > IP table.

The redirect number manipulation tables provide two configuration areas:

- Matching characteristics (*Rule*) of incoming call, for example, prefix of redirect number.
- Manipulation operation (*Action*), for example, remove user-defined number of digits from the left of the redirect number.

If the incoming call matches the characteristics of a rule, then its manipulation action is applied.

Notes:

- If the device copies the received destination number to the outgoing SIP redirect number (enabled by the CopyDest2RedirectNumber parameter), then no redirect number Tel-to-IP manipulation is done.
- The manipulation rules are done in the following order: Stripped Digits From Left, Stripped Digits From Right, Number of Digits to Leave, Prefix to Add, and then Suffix to Add.
- The Redirect Prefix parameter is used before it is manipulated.
- The redirect number manipulation tables can also be configured using the ini file:
 - Redirect Number IP to Tel table: RedirectNumberMapIp2Tel (ini)
 - Redirect Number Tel to IP table: RedirectNumberMapTel2Ip (ini)



- **To configure redirect number manipulation rules:**
- 1. Open the required redirect number manipulation table (**Configuration** tab > **VoIP** menu > **GW and IP to IP** submenu > **Manipulations** > **Redirect Number Tel > IP** or **Redirect Number IP > Tel**).
- 2. Click the **Add** button; the following dialog box appears (e.g., **Redirect Number Tel > IP** table):

Figure 23-4: Redirect Number Manipulation (e.g., Tel to IP)

- 3. Click the **Rule** tab, and then configure the matching characteristics. For a description of the parameters, see the table below.
- 4. Click the **Action** tab, and then configure the manipulation operation. For a description of the parameters, see the table below.
- 5. Click **Submit** to apply your settings.

Redirect Number Manipulation Parameters Description

Parameter	Description
Matching Characteristics (Rule)	
Web/EMS: Redirect Prefix [RedirectPrefix]	Defines the redirect telephone number prefix. To denote any number, use the wildcard asterisk (*) symbol.
Web/EMS: Destination Prefix [DestinationPrefix]	Defines the destination (called) telephone number prefix. To denote any number, use the wildcard asterisk (*) symbol. For manipulating the diverting and redirected numbers for call diversion, you can use the strings "DN" and "RN" to denote the destination prefix of these numbers. For more information, see <i>Manipulating Redirected and Diverted Numbers for Call Diversion</i> on page 312.
Web: Source Trunk Group ID [SrcTrunkGroupID]	Defines the Trunk Group from where the Tel call is received. To denote any Trunk Group, leave this field empty. Notes: <ul style="list-style-type: none"> ▪ This parameter is applicable only to the Redirect Number Tel > IP table. ▪ The value -1 indicates that this field is ignored in the rule. ▪ For IP-to-IP call routing, this parameter is not relevant.
Source IP Group ID [SrcIPGroupID]	Defines the IP Group from where the IP call originated. Typically, the IP Group of an incoming INVITE is determined or classified by the Inbound IP Routing Table. If not used (i.e., any IP Group), leave the field empty. Notes: <ul style="list-style-type: none"> ▪ This parameter is applicable only to the Redirect Number Tel > IP

Parameter	Description
	table. <ul style="list-style-type: none"> ▪ This parameter is applicable only to the IP-to-IP application. ▪ The value -1 indicates that it is ignored in the rule.
Web/EMS: Source IP Address [SourceAddress]	Defines the IP address of the caller. This is obtained from the Contact header in the INVITE message. Notes: <ul style="list-style-type: none"> ▪ This parameter is applicable only to the Redirect Number IP > Tel table. ▪ The source IP address can include the following wildcards: <ul style="list-style-type: none"> ✓ "x": represents single digits. For example, 10.8.8.xx denotes all addresses between 10.8.8.10 and 10.8.8.99. ✓ "*": represents any number between 0 and 255. For example, 10.8.8.* denotes all addresses between 10.8.8.0 and 10.8.8.255.
Web: Source Host Prefix [SrcHost]	Defines the URI host name prefix of the incoming SIP INVITE message in the From header. Notes: <ul style="list-style-type: none"> ▪ This parameter is applicable only to the Redirect Number IP > Tel table. ▪ Use the wildcard asterisk (*) symbol to denote any prefix. ▪ If the P-Asserted-Identity header is present in the incoming INVITE message, then the value of this parameter is compared to the P-Asserted-Identity URI host name (instead of to the From header).
Web: Destination Host Prefix [DestHost]	Defines the Request-URI host name prefix of the incoming SIP INVITE message. Notes: <ul style="list-style-type: none"> ▪ This parameter is applicable only to the Redirect Number IP > Tel table. ▪ Use the wildcard asterisk (*) symbol to denote any prefix.
Operation (Action)	
Web: Stripped Digits From Left EMS: Remove From Left [RemoveFromLeft]	Defines the number of digits to remove from the left of the redirect number prefix. For example, if you enter 3 and the redirect number is 5551234, the new number is 1234.
Web: Stripped Digits From Right EMS: Remove From Right [RemoveFromRight]	Defines the number of digits to remove from the right of the redirect number prefix. For example, if you enter 3 and the redirect number is 5551234, the new number is 5551.
Web/EMS: Number of Digits to Leave [LeaveFromRight]	Defines the number of digits that you want to retain from the right of the redirect number.
Web/EMS: Prefix to Add [Prefix2Add]	Defines the number or string that you want added to the front of the redirect number. For example, if you enter 9 and the redirect number is 1234, the new number is 91234.
Web/EMS: Suffix to Add [Suffix2Add]	Defines the number or string that you want added to the end of the redirect number. For example, if you enter 00 and the redirect number is 1234, the new number is 123400.

Parameter	Description
Web: Presentation EMS: Is Presentation Restricted [IsPresentationRestricted]	Enables caller ID. <ul style="list-style-type: none"> ▪ Not Configured = Privacy is determined according to the Caller ID table (see Configuring Caller Display Information on page 396). ▪ [0] Allowed = Sends Caller ID information when a call is made using these destination / source prefixes. ▪ [1] Restricted = Restricts Caller ID information for these prefixes. Notes: <ul style="list-style-type: none"> ▪ If 'Presentation' is set to 'Restricted' and the AssertedIdMode parameter is set to Add P-Asserted-Identity, the From header in the INVITE message includes the following: From: 'anonymous' <sip: anonymous@anonymous.invalid> and 'privacy: id' header.
Web: TON EMS: Number Type [NumberType]	Defines the Type of Number (TON). The default is 'Unknown' [0] . <ul style="list-style-type: none"> ▪ If you select 'Unknown' for the NPI, you can select Unknown [0]. ▪ If you select 'Private' for the NPI, you can select Unknown [0], International [1], National [2], Network Specific [3] or Subscriber [4]. ▪ If you select 'E.164 Public' for the NPI, you can select Unknown [0], International [1], National [2], Network Specific [3], Subscriber [4] or Abbreviated [6]. Notes: <ul style="list-style-type: none"> ▪ This parameter is applicable only to the Redirect Number IP > Tel table. ▪ For more information on available NPI/TON values, see Numbering Plans and Type of Number on page 321.
Web: NPI EMS: Number Plan [NumberPlan]	Defines the Numbering Plan Indicator (NPI). <ul style="list-style-type: none"> ▪ [0] Unknown (default) ▪ [9] Private ▪ [1] E.164 Public ▪ [-1] Not Configured = value received from PSTN/IP is used Notes: <ul style="list-style-type: none"> ▪ This parameter is applicable only to the Redirect Number IP > Tel table. ▪ For more information on available NPI/TON values, see Numbering Plans and Type of Number on page 321.

23.6 Manipulating Redirected and Diverted Numbers for Call Diversion

You can configure manipulation rules to manipulate the Diverted-to and Diverting numbers received in the incoming Call Redirection Facility message for call diversion, which is interworked to outgoing SIP 302 responses. This feature is applicable to the Euro ISDN and QSIG variants, and to IP-to-Tel calls.

The incoming redirection Facility message includes, among other parameters, the Diverted-to number and Diverting number. The Diverted-to number (i.e., new destination) is mapped to the user part in the Contact header of the SIP 302 response. The Diverting number is mapped to the user part in the Diversion header of the SIP 302 response.

These two numbers can be manipulated by entering the following special strings in the 'Destination Prefix' field of the Redirect Number Tel -> IP manipulation table:

- "RN" - used in the rule to manipulate the Redirected number (i.e., originally called number or Diverting number).
- "DN" - used in the rule to manipulate the Diverted-to number (i.e., the new called number or destination). This manipulation is done on the user part in the Contact header of the SIP 302 response.

For example, assume the following required manipulation:

- Manipulate Redirected number 6001 (originally called number) to 6005
- Manipulate Diverted-to number 8002 (the new called number or destination) to 8005

The configuration in the Redirect Number Tel -> IP manipulation table is as follows:

Redirect Number Configuration Example

Parameter	Rule 1	Rule 2
Destination Prefix	RN	DN
Redirect Prefix	6	8
Stripped Digits From Right	1	1
Suffix to Add	5	5
Number of Digits to Leave	5	-

After the above manipulation is done, the device sends the following outgoing SIP 302 response:

```
SIP/2.0 302 Moved Temporarily
Via: SIP/2.0/TLS 10.33.45.68;branch=z9hG4bKac54132643;alias
From: "MP118 1" <sip:8001@10.33.45.68>;tag=1c54119560
To: <sip:6001@10.33.45.69;user=phone>;tag=1c664560944
Call-ID: 541189832710201115142@10.33.45.68
CSeq: 1 INVITE
Contact: <sip:8005@10.33.45.68;user=phone>
Supported: em,timer,replaces,path,early-session,resource-priority
Allow:
REGISTER,OPTIONS,INVITE,ACK,CANCEL,BYE,NOTIFY,PRACK,REFER,INFO,SUBSCRIBE,UPDATE
Diversion: <tel:6005>;reason=unknown;counter=1
Server: Audiocodes-Sip-Gateway-IPmedia 260_UN/v.6.20A.043.001
Reason: SIP ;cause=302 ;text="302 Moved Temporarily"
Content-Length: 0
```

23.7 Mapping NPI/TON to SIP Phone-Context

The Phone-Context table page allows you to map Numbering Plan Indication (NPI) and Type of Number (TON) to the SIP 'phone-context' parameter. The 'phone-context' parameter appears in the standard SIP headers where a phone number is used (i.e., Request-URI, To, From, and Diversion). When a call is received from the ISDN/Tel side, the NPI and TON are compared against the table and the matching 'phone-context' value is used in the outgoing SIP INVITE message. The same mapping occurs when an INVITE with a 'phone-context' parameter is received.

For example, for a Tel-to-IP call with NPI/TON set as E164 National (values 1/2), the device sends the following SIP INVITE URI:

sip:12365432;phone-context= na.e.164.nt.com

This is configured for entry 3 in the figure below. In the opposite direction (IP-to-Tel call), if the incoming INVITE contains this 'phone-context' (e.g. "phone-context= na.e.164.nt.com"), the NPI/TON of the called number in the outgoing Setup message is changed to E164 National.

➤ **To configure NPI/TON to SIP phone-context rules:**

1. Open the Phone Context Table page (**Configuration** tab > **VoIP** menu > **GW and IP to IP** submenu > **Manipulations** > **Phone Context**).

Figure 23-5: Phone Context Table Page

Add Phone Context As Prefix		Enable
Phone Context Index		1-10

	NPI	TON	Phone Context
1	Unknown	Unknown	unknown.com
2	Private	Level 2 Regional	host.com
3	E.164 Public	National	na.e164.host.com
4			

2. Configure the parameters as required. For a description of the parameters, see the table below.
3. Click **Submit** to apply your changes.
4. To save the changes to flash memory, see 'Saving Configuration' on page 494.

Notes:



- You can configure multiple rows with the same NPI/TON or same SIP 'phone-context'. In such a configuration, a Tel-to-IP call uses the first matching rule in the table.
- The Phone Context table can also be configured using the table ini file parameter, PhoneContext (see 'Number Manipulation Parameters' on page 808).

Phone-Context Parameters Description

Parameter	Description
Add Phone Context As Prefix [AddPhoneContextAsPrefix]	Determines whether the received SIP 'phone-context' parameter is added as a prefix to the outgoing ISDN Setup message (for digital interfaces) with called and calling numbers. <ul style="list-style-type: none"> ▪ [0] Disable (default) ▪ [1] Enable
NPI [PhoneContext_Npi]	Defines the Number Plan Indicator (NPI). <ul style="list-style-type: none"> ▪ [0] Unknown (default) ▪ [1] E.164 Public ▪ [9] Private For a detailed list of the available NPI/TON values, see Numbering Plans and Type of Number on page 321.

Parameter	Description
TON [PhoneContext_Ton]	<p>Defines the Type of Number (TON).</p> <ul style="list-style-type: none"> ▪ If you selected Unknown as the NPI, you can select Unknown [0]. ▪ If you selected Private as the NPI, you can select one of the following: <ul style="list-style-type: none"> ✓ [0] Unknown ✓ [1] Level 2 Regional ✓ [2] Level 1 Regional ✓ [3] PSTN Specific ✓ [4] Level 0 Regional (Local) ▪ If you selected E.164 Public as the NPI, you can select one of the following: <ul style="list-style-type: none"> ✓ [0] Unknown ✓ [1] International ✓ [2] National ✓ [3] Network Specific ✓ [4] Subscriber ✓ [6] Abbreviated
Phone Context [PhoneContext_Context]	Defines the SIP 'phone-context' URI parameter.

23.8 Configuring Release Cause Mapping

The Release Cause Mapping table allows you to map up to 12 different ISDN ITU-T Q.850 cause codes, which indicate reasons for ISDN call failure, to SIP response codes, and vice versa. This allows you to override the default release cause mappings between ISDN and SIP, as described in 'Fixed Mapping of ISDN Release Reason to SIP Response' on page 318 and 'Fixed Mapping of SIP Response to ISDN Release Reason' on page 316.



Notes:

- For Tel-to-IP calls, you can also map the less commonly used SIP responses to a single default ISDN Release Cause, using the DefaultCauseMapISDN2IP parameter. This parameter defines a default ISDN Cause that is always used except when the following Release Causes are received: Normal Call Clearing (16), User Busy (17), No User Responding (18) or No Answer from User (19).
- The release cause mapping tables can also be configured using the ini file:
 - 1) Release Cause Mapping from ISDN to SIP table: CauseMapISDN2SIP (ini).
 - 2) Release Cause Mapping from SIP to ISDN table: CauseMapSIP2ISDN (ini).

➤ To configure Release Cause mapping:

1. Open the Release Cause Mapping page (Configuration tab > VoIP menu > GW and IP to IP submenu > Manipulations > Release Cause Mapping).

Figure 23-6: Release Cause Mapping Page

Release Cause Mapping from ISDN to SIP			
	Q.850 Cause		SIP Response
1	<input type="text"/>		<input type="text"/>
2	<input type="text"/>		<input type="text"/>
3	<input type="text"/>		<input type="text"/>
4	<input type="text"/>		<input type="text"/>
5	<input type="text"/>		<input type="text"/>
6	<input type="text"/>		<input type="text"/>
7	<input type="text"/>		<input type="text"/>
8	<input type="text"/>		<input type="text"/>
9	<input type="text"/>		<input type="text"/>
10	<input type="text"/>		<input type="text"/>
11	<input type="text"/>		<input type="text"/>
12	<input type="text"/>		<input type="text"/>

Release Cause Mapping from SIP to ISDN			
	SIP Response		Q.850 Cause
1	<input type="text"/>		<input type="text"/>
2	<input type="text"/>		<input type="text"/>
3	<input type="text"/>		<input type="text"/>

2. In the 'Release Cause Mapping from ISDN to SIP' group, map different Q.850 Release Causes to SIP Responses.
3. In the 'Release Cause Mapping from SIP to ISDN' group, map different SIP Responses to Q.850 Release Causes.
4. Click **Submit** to apply your changes.

23.8.1 Fixed Mapping of SIP Response to ISDN Release Reason

The following table describes the mapping of SIP response to ISDN release reason.

Mapping of SIP Response to ISDN Release Reason

SIP Response	Description	ISDN Release Reason	Description
400*	Bad request	31	Normal, unspecified
401	Unauthorized	21	Call rejected
402	Payment required	21	Call rejected
403	Forbidden	21	Call rejected

SIP Response	Description	ISDN Release Reason	Description
404	Not found	1	Unallocated number
405	Method not allowed	63	Service/option unavailable
406	Not acceptable	79	Service/option not implemented
407	Proxy authentication required	21	Call rejected
408	Request timeout	102	Recovery on timer expiry
409	Conflict	41	Temporary failure
410	Gone	22	Number changed w/o diagnostic
411	Length required	127	Interworking
413	Request entity too long	127	Interworking
414	Request URI too long	127	Interworking
415	Unsupported media type	79	Service/option not implemented
420	Bad extension	127	Interworking
480	Temporarily unavailable	18	No user responding
481*	Call leg/transaction doesn't exist	127	Interworking
482*	Loop detected	127	Interworking
483	Too many hops	127	Interworking
484	Address incomplete	28	Invalid number format
485	Ambiguous	1	Unallocated number
486	Busy here	17	User busy
488	Not acceptable here	31	Normal, unspecified
500	Server internal error	41	Temporary failure
501	Not implemented	38	Network out of order
502	Bad gateway	38	Network out of order
503	Service unavailable	41	Temporary failure
504	Server timeout	102	Recovery on timer expiry
505*	Version not supported	127	Interworking
600	Busy everywhere	17	User busy
603	Decline	21	Call rejected
604	Does not exist anywhere	1	Unallocated number
606*	Not acceptable	38	Network out of order

* Messages and responses were created because the 'ISUP to SIP Mapping' draft does not specify their cause code mapping.

23.8.2 Fixed Mapping of ISDN Release Reason to SIP Response

The following table describes the mapping of ISDN release reason to SIP response.

Mapping of ISDN Release Reason to SIP Response

ISDN Release Reason	Description	SIP Response	Description
1	Unallocated number	404	Not found
2	No route to network	404	Not found
3	No route to destination	404	Not found
6	Channel unacceptable	406*	Not acceptable
7	Call awarded and being delivered in an established channel	500	Server internal error
16	Normal call clearing	-*	BYE
17	User busy	486	Busy here
18	No user responding	408	Request timeout
19	No answer from the user	480	Temporarily unavailable
21	Call rejected	403	Forbidden
22	Number changed w/o diagnostic	410	Gone
26	Non-selected user clearing	404	Not found
27	Destination out of order	502	Bad gateway
28	Address incomplete	484	Address incomplete
29	Facility rejected	501	Not implemented
30	Response to status enquiry	501*	Not implemented
31	Normal unspecified	480	Temporarily unavailable
34	No circuit available	503	Service unavailable
38	Network out of order	503	Service unavailable
41	Temporary failure	503	Service unavailable
42	Switching equipment congestion	503	Service unavailable
43	Access information discarded	502*	Bad gateway
44	Requested channel not available	503*	Service unavailable
47	Resource unavailable	503	Service unavailable
49	QoS unavailable	503*	Service unavailable
50	Facility not subscribed	503*	Service unavailable
55	Incoming calls barred within CUG	403	Forbidden
57	Bearer capability not authorized	403	Forbidden
58	Bearer capability not presently available	503	Service unavailable
63	Service/option not available	503*	Service unavailable
65	Bearer capability not implemented	501	Not implemented

ISDN Release Reason	Description	SIP Response	Description
66	Channel type not implemented	480*	Temporarily unavailable
69	Requested facility not implemented	503*	Service unavailable
70	Only restricted digital information bearer capability is available	503*	Service unavailable
79	Service or option not implemented	501	Not implemented
81	Invalid call reference value	502*	Bad gateway
82	Identified channel does not exist	502*	Bad gateway
83	Suspended call exists, but this call identity does not	503*	Service unavailable
84	Call identity in use	503*	Service unavailable
85	No call suspended	503*	Service unavailable
86	Call having the requested call identity has been cleared	408*	Request timeout
87	User not member of CUG	503	Service unavailable
88	Incompatible destination	503	Service unavailable
91	Invalid transit network selection	502*	Bad gateway
95	Invalid message	503	Service unavailable
96	Mandatory information element is missing	409*	Conflict
97	Message type non-existent or not implemented	480*	Temporarily not available
98	Message not compatible with call state or message type non-existent or not implemented	409*	Conflict
99	Information element non-existent or not implemented	480*	Not found
100	Invalid information elements contents	501*	Not implemented
101	Message not compatible with call state	503*	Service unavailable
102	Recovery of timer expiry	408	Request timeout
111	Protocol error	500	Server internal error
127	Interworking unspecified	500	Server internal error

* Messages and responses were created because the 'ISUP to SIP Mapping' draft doesn't specify their cause code mapping.

23.8.3 Reason Header

The device supports the SIP Reason header according to RFC 3326. The Reason header conveys information describing the disconnection cause of a call:

- **Sending Reason header:** If a call is disconnected from the Tel side (ISDN), the Reason header is set to the received Q.850 cause in the appropriate message (BYE/CANCEL/final failure response) and sent to the SIP side. If the call is disconnected because of a SIP reason, the Reason header is set to the appropriate SIP response.
- **Receiving Reason header:** If a call is disconnected from the IP side and the SIP message includes the Reason header, it is sent to the Tel side according to the following logic:
 - If the Reason header includes a Q.850 cause, it is sent as is.
 - If the Reason header includes a SIP response:
 - ◆ If the message is a final response, the response status code is translated to Q.850 format and passed to ISDN.
 - ◆ If the message isn't a final response, it is translated to a Q.850 cause.
 - When the Reason header is received twice (i.e., SIP Reason and Q.850), the Q.850 takes precedence over the SIP reason and is sent to the Tel side.

23.8.4 Mapping PSTN Release Cause to SIP Response

The device's FXO interface interoperates between the SIP network and the PSTN/PBX. This interoperability includes the mapping of PSTN/PBX Call Progress tones to SIP 4xx or 5xx responses for IP-to-Tel calls. The converse is also true - for Tel-to-IP calls, the SIP 4xx or 5xx responses are mapped to tones played to the PSTN/PBX.

When establishing an IP-to-Tel call, the following rules are applied:

- If the remote party (PSTN/PBX) is busy and the FXO device detects a busy tone, it sends a SIP 486 Busy response to IP. If it detects a reorder tone, it sends a SIP 404 Not Found (no route to destination) to IP. In both cases the call is released. Note that if the 'Disconnect Call on Busy Tone Detection' parameter is set to **Disable**, the FXO device ignores the detection of busy and reorder tones and does not release the call.
- For all other FXS/FXO release types such as:
 - no free channels in the Trunk Group,
 - an appropriate call routing rule to a Trunk Group doesn't exist, or
 - the phone number isn't found

then the device sends a SIP response to the IP according to the 'Default Release Cause' parameter. This parameter defines Q.931 release causes. Its default is **3**, which is mapped to the SIP 404 response. By changing its value to **34**, the SIP 503 response is sent. Other causes can be used as well.

23.9 Numbering Plans and Type of Number

The IP-to-Tel destination or source number manipulation tables allow you to classify numbers by their Numbering Plan Indication (NPI) and Type of Number (TON). The device supports all NPI/TON classifications used in the ETSI ISDN variant, as shown in the table below:

NPI/TON Values for ETSI ISDN Variant

NPI	TON	Description
Unknown [0]	Unknown [0]	A valid classification, but one that has no information about the numbering plan.
E.164 Public [1]	Unknown [0]	A public number in E.164 format, but no information on what kind of E.164 number.
	International [1]	A public number in complete international E.164 format, e.g., 16135551234.
	National [2]	A public number in complete national E.164 format, e.g., 6135551234.
	Network Specific [3]	The type of number "network specific number" is used to indicate administration / service number specific to the serving network, e.g., used to access an operator.
	Subscriber [4]	A public number in complete E.164 format representing a local subscriber, e.g., 5551234.
	Abbreviated [6]	The support of this code is network dependent. The number provided in this information element presents a shorthand representation of the complete number in the specified numbering plan as supported by the network.
Private [9]	Unknown [0]	A private number, but with no further information about the numbering plan.
	Level 2 Regional [1]	
	Level 1 Regional [2]	A private number with a location, e.g., 3932200.
	PISN Specific [3]	
	Level 0 Regional (local) [4]	A private local extension number, e.g., 2200.

For NI-2 and DMS-100 ISDN variants, the valid combinations of TON and NPI for calling and called numbers include (Plan/Type):

- 0/0 - Unknown/Unknown
- 1/1 - International number in ISDN/Telephony numbering plan
- 1/2 - National number in ISDN/Telephony numbering plan
- 1/4 - Subscriber (local) number in ISDN/Telephony numbering plan
- 9/4 - Subscriber (local) number in Private numbering plan

Reader's Notes

24 Routing

This section describes the configuration of call routing rules.

24.1 Configuring General Routing Parameters

The Routing General Parameters page allows you to configure general routing parameters. For a description of these parameters, see 'Configuration Parameters Reference' on page 609.

➤ **To configure general routing parameters:**

1. Open the Routing General Parameters page (**Configuration** tab > **VoIP** menu > **GW and IP to IP** submenu > **Routing** submenu > **General Parameters**).

General Parameters	
Add Hunt Group ID as Prefix	No
Add Trunk ID as Prefix	No
Replace Empty Destination with B-channel Phone Number	No
Add NPI and TON to Called Number	No
Add NPI and TON to Calling Number	No
IP to Tel Remove Routing Table Prefix	No
Source IP Address Input	SIP Contact Header
Enable Alt Routing Tel to IP	Disable
Alt Routing Tel to IP Mode	Both
Alt Routing Tel to IP Connectivity Method	ICMP Ping
Alt Routing Tel to IP Keep Alive Time	60
Alternative Routing Tone Duration [ms]	0
Source Manipulation Mode	FROM & PAI (after manipulation)
Max Allowed Packet Loss for Alt Routing [%]	20
Max Allowed Delay for Alt Routing [msec]	250

2. Configure the parameters as required.
3. Click **Submit** to apply your changes.

24.2 Configuring Outbound IP Routing Table

The Outbound IP Routing Table page allows you to configure up to 180 Tel-to-IP or outbound IP call routing rules. The device uses these rules to route calls from the Tel or IP to a user-defined IP destination.


The Outbound IP Routing Table table provides two configuration areas:

- **Matching Characteristics:** Characteristics of the incoming call. If the call characteristics match a table entry, the routing rule is used to route the call to the specified destination. One or more characteristics can be defined for the rule:
 - Source IP Group (to which the call belongs)
 - Source and destination Request-URI host name prefix
 - Source Trunk Group (from where the call is received)
 - Source (calling) and destination (called) telephone number prefix and suffix
 - Source and destination Request-URI host name prefix

- **Destination:** If the call matches the configured characteristics, the device routes the call to an IP destination. If no characteristics match is found in the table, the call is rejected. The destination can be any of the following:
 - IP address in dotted-decimal notation.
 - Fully Qualified Domain Name (FQDN).
 - E.164 Telephone Number Mapping (ENUM service - NREnum.net or e164.arp).
 - Lightweight Directory Access Protocol (LDAP). For a description, see 'Routing Based on LDAP Active Directory Queries' on page 193.
 - IP Group, where the call is routed to the IP address configured for the Proxy Set or SRD associated with the IP Group (configured in 'Configuring IP Groups' on page 214). If the device is configured with multiple SRDs, you can also indicate (in the table's 'Dest. SRD' field) the destination SRD for routing to one of the following destination types - IP address, FQDN, ENUM, or LDAP. If the SRD is not specified, then the default SRD (0) is used. In scenarios where routing is to an IP Group, the destination SRD is obtained from the SRD associated with the IP Group (in the IP Group table). The specified destination SRD determines the:
 - ◆ Destination SIP interface (SIP port and control IP interface) - important when using multiple SIP control VLANs
 - ◆ Media Realm (port and IP interface for media / RTP voice)
 - ◆ Other SRD-related interfaces and features on which the call is routed

Since each call must have a destination IP Group (even in cases where the destination type is not to an IP Group), in cases when the IP Group is not specified, the SRD's default IP Group is used, which is the first configured IP Group that belongs to the SRD.

Figure 24-1: Locating SRD





Notes: When using a proxy server, you do not need to configure this table, unless you require one of the following:

- Fallback (alternative) routing if communication is lost with the proxy server.
- IP security, whereby the device routes only received calls whose source IP addresses are defined in this table. IP security is enabled using the SecureCallsFromIP parameter.
- Filter Calls to IP feature: the device checks this table before a call is routed to the proxy server. However, if the number is not allowed, i.e., the number does not exist in the table or a Call Restriction (see below) routing rule is applied, the call is released.
- Obtain different SIP URI host names (per called number).
- Assign IP Profiles to calls.
- For this table to take precedence over a proxy for routing calls, you need to set the parameter PreferRouteTable to 1. The device checks the 'Destination IP Address' field in this table for a match with the outgoing call; a proxy is used only if a match is not found.

In addition to basic outbound IP routing, this table supports the following features:

- **Least Cost Routing (LCR):** If the LCR feature is enabled, the device searches the routing table for matching routing rules and then selects the one with the lowest call cost. The call cost of the routing rule is done by assigning it a Cost Group. For configuring Cost Groups, see 'Least Cost Routing' on page 202. If two routing rules have identical costs, then the rule appearing higher up in the table (i.e., first-matched rule) is used. If a selected route is unavailable, the device uses the next least-cost routing rule. However, even if a matched rule is not assigned a Cost Group, the device can select it as the preferred route over other matched routing rules with Cost Groups, according to the settings of the LCR parameter, LCRDefaultCost (see 'Enabling LCR and Configuring Default LCR' on page 204).
- **Call Forking:** If the Tel-to-IP Call Forking feature is enabled, the device can send a Tel call to multiple IP destinations. An incoming Tel call with multiple matched routing rules (e.g., all with the same source prefix numbers) can be sent (forked) to multiple IP destinations if the rules are defined with a Forking Group in the table. The call is established with the first IP destination that answers the call.
- **Call Restriction:** Rejects calls whose matching routing rule is configured with the destination IP address of 0.0.0.0.
- **Always Use Routing Table:** Even if a proxy server is used, the SIP Request-URI host name in the outgoing INVITE message is obtained from this table. Using this feature, you can assign a different SIP URI host name for different called and/or calling numbers. This feature is enabled using the AlwaysUseRouteTable parameter.
- **IP Profiles:** IP Profiles can be assigned to destination addresses (also when a proxy is used).
- **Alternative Routing (when a proxy isn't used):** An alternative IP destination can be configured for a specific call. To associate an alternative IP address to a called telephone number prefix, assign it with an additional entry with a different IP address, or use an FQDN that resolves into two IP addresses. For more information on alternative routing, see 'Alternative Routing for Tel-to-IP Calls' on page 336.



Notes:

- Outbound IP routing can be performed before or after number manipulation. This is configured using the RouteModeTel2IP parameter, as described below.
- The Outbound IP Routing Table can also be configured using the table ini file parameter, Prefix.

➤ **To configure Tel-to-IP or outbound IP routing rules:**

1. Open the Outbound IP Routing Table page (**Configuration** tab > **VoIP** menu > **GW and IP to IP** submenu > **Routing > Tel to IP Routing**).

Figure 24-2: Outbound IP Routing Page

	Src. IP Group ID	Src. Host Prefix	Dest Host Prefix	Src. Trunk Group ID	Dest. Phone Prefix	Source Phone Prefix	->	Dest. IP Address
1	-1							
2	-1							
3	-1							
4	-1							
5	-1							

2. From the 'Routing Index' drop-down list, select the range of entries that you want to add.
3. Configure the routing rule as required. For a description of the parameters, see the table below.
4. Click **Submit** to apply your changes.
5. To save the changes to flash memory, see 'Saving Configuration' on page 494.

The table below shows configuration examples of Tel-to-IP or outbound IP routing rules, where:

- **Rule 1 and 2 (Least Cost Routing rule):** For both rules, the called (destination) phone number prefix is 10, the caller's (source) phone number prefix is 100, and the call is assigned IP Profile ID 1. However, Rule 1 is assigned a cheaper Cost Group than Rule 2, and therefore, the call is sent to the destination IP address (10.33.45.63) associated with Rule 1.
- **Rule 3 (IP Group destination rule):** For all callers (*), if the called phone number prefix is 20, the call is sent to IP Group 1 (whose destination is the IP address configured for its associated Proxy Set ID).
- **Rule 4 (domain name destination rule):** If the called phone number prefix is 5, 7, 8, or 9 and the caller belongs to Trunk Group ID 1, the call is sent to domain.com.
- **Rule 5 (block rule):** For all callers (*), if the called phone number prefix is 00, the call is rejected (discarded).

- **Rule 6, 7, and 8 (Forking Group rule):** For all callers (*), if the called phone number prefix is 100, the call is sent to Rule 7 and 9 (belonging to Forking Group "1"). If their destinations are unavailable and alternative routing is enabled, the call is sent to Rule 8 (Forking Group "2").
- **Rule 9 (IP-to-IP rule):** If an incoming IP call from Source IP Group 2 with domain.com as source host prefix in its SIP Request-URI, the IP call is sent to IP address 10.33.45.65.

Example of Tel-to-IP Source Phone Number Manipulation Rules

Parameter	Rule 1	Rule 2	Rule 3	Rule 4	Rule 5	Rule 6	Rule 7	Rule 8	Rule 9
Src. IP Group ID	-	-	-	-	-	-	-	-	2
Src. Trunk Group ID	*	0	1	-	-	-	-	-	-
Src. Host Prefix	-	-	-	-	-	-	-	-	domain.com
Src. Trunk Group ID	-	-	*	1	-	*	*	*	-
Dest. Phone Prefix	10	10	20	[5,7-9]	00	100	100	100	*
Source Phone Prefix	100	100	*	*	*	*	*	*	*
Dest. IP Address	10.33.45.63	10.33.45.50	-	domain.com	0.0.0.0	10.33.45.68	10.33.45.67	domain.com	10.33.45.65
Dest IP Group ID	-	-	1	-	-	-	-	-	-
IP Profile ID	1	1	-	-	-	-	-	-	-
Cost Group ID	Week end	Weekend_B	-	-	-	-	-	-	-
Forking Group			-	-	-	1	2	1	-

Tel-to-IP / Outbound IP Routing Table Parameters

Parameter	Description
Matching Call Characteristics	
Web/EMS: Tel to IP Routing Mode [RouteModeTel2IP]	<p>Determines whether to route received calls to an IP destination before or after manipulation of the destination number.</p> <ul style="list-style-type: none"> ■ [0] Route calls before manipulation = Calls are routed before the number manipulation rules are applied (default). ■ [1] Route calls after manipulation = Calls are routed after the number manipulation rules are applied.

Parameter	Description
	<p>Notes:</p> <ul style="list-style-type: none"> ▪ This parameter is not applicable if outbound proxy routing is used. ▪ For number manipulation, see 'Configuring Source/Destination Number Manipulation' on page 299.
Web: Src. IP Group ID EMS: Source IP Group ID [PREFIX_SrcIPGroupID]	<p>Defines the IP Group from where the incoming IP call is received. Typically, the IP Group of an incoming INVITE is determined according to the Inbound IP Routing Table.</p> <p>Notes:</p> <ul style="list-style-type: none"> ▪ This parameter is applicable only to the IP-to-IP routing application. ▪ To denote all IP Groups, leave this field empty. ▪ If this IP Group has a Serving IP Group, then all calls from this IP Group are sent to the Serving IP Group. In such a scenario, this routing table is used only if the parameter PreferRouteTable is set to 1.
Web: Src. Host Prefix EMS: Source Host Prefix [PREFIX_SrcHostPrefix]	<p>Defines the prefix of the SIP Request-URI host name in the From header of the incoming SIP INVITE message.</p> <p>Notes:</p> <ul style="list-style-type: none"> ▪ To denote any prefix, use the asterisk (*) symbol. ▪ This parameter is applicable only to the IP-to-IP routing application.
Web: Dest. Host Prefix EMS: Destination Host Prefix [PREFIX_DestHostPrefix]	<p>Defines the SIP Request-URI host name prefix of the incoming SIP INVITE message.</p> <p>Notes:</p> <ul style="list-style-type: none"> ▪ To denote any prefix, use the asterisk (*) symbol. ▪ This parameter is applicable only for IP-to-IP routing application.
Web: Src. Trunk Group ID EMS: Source Trunk Group ID [PREFIX_SrcTrunkGroupID]	<p>Defines the Trunk Group from where the call is received.</p> <p>Notes:</p> <ul style="list-style-type: none"> ▪ To denote any Trunk Group, use the asterisk (*) symbol. ▪ This parameter is applicable only to the Gateway application.
Web: Dest. Phone Prefix EMS: Destination Phone Prefix [PREFIX_DestinationPrefix]	<p>Defines the prefix and/or suffix of the called (destination) telephone number. The suffix is enclosed in parenthesis after the suffix value. You can use special notations for denoting the prefix. For example, [100-199](100,101,105) denotes a number that starts with 100 to 199 and ends with 100, 101 or 105. To denote any prefix, use the asterisk (*) symbol or to denote calls without a called number, use the \$ sign. For a description of available notations, see 'Dialing Plan Notation for Routing and Manipulation Tables' on page 607.</p> <p>The number can include up to 50 digits.</p> <p>Notes:</p> <ul style="list-style-type: none"> ▪ For LDAP-based routing, enter the LDAP query keyword as the prefix number to denote the IP domain: <ul style="list-style-type: none"> ✓ "PRIVATE" = Private number ✓ "OCS" = Lync / OCS client number ✓ "PBX" = PBX / IP PBX number ✓ "MOBILE" = Mobile number ✓ "LDAP_ERR" = LDAP query failure <p>For more information, see Routing Based on LDAP Active Directory</p>

Parameter	Description
	<p>Queries on page 193.</p> <ul style="list-style-type: none"> If you want to configure re-routing of ISDN Tel-to-IP calls to fax destinations, you need to enter the value string "FAX" (case-sensitive) as the destination phone prefix. For more information regarding this feature, see the FaxReroutingMode parameter.
<p>Web/EMS: Source Phone Prefix [PREFIX_SourcePrefix]</p>	<p>Defines the prefix and/or suffix of the calling (source) telephone number. You can use special notations for denoting the prefix. For example, [100-199](100,101,105) denotes a number that starts with 100 to 199 and ends with 100, 101 or 105. To denote any prefix, use the asterisk (*) symbol or to denote calls without a calling number, use the \$ sign. For a description of available notations, see 'Dialing Plan Notation for Routing and Manipulation Tables' on page 607.</p> <p>The number can include up to 50 digits.</p>
Operation (IP Destination)	
<p>Web: Dest. IP Address EMS: Address [PREFIX_DestAddress]</p>	<p>Defines the IP address (in dotted-decimal notation or FQDN) to where the call is sent. If an FQDN is used (e.g., domain.com), DNS resolution is done according to the DNSQueryType parameter.</p> <p>For ENUM-based routing, enter the string value "ENUM". The device sends an ENUM query containing the destination phone number to an external DNS server, configured in the Multiple Interface table. The ENUM reply includes a SIP URI which is used as the Request-URI in the subsequent outgoing INVITE and for routing (if a proxy is not used). To configure the type of ENUM service (e.g., e164.arpa), use the EnumService parameter.</p> <p>For LDAP-based routing, enter the string value "LDAP" for denoting the IP address of the LDAP server. For more information, see Routing Based on LDAP Active Directory Queries on page 193.</p> <p>Notes:</p> <ul style="list-style-type: none"> This field and any value assigned to it is ignored if you have configured a destination IP Group for this routing rule (in the 'Dest IP Group ID' field). To reject calls, enter the IP address 0.0.0.0. For example, if you want to prohibit international calls, then in the 'Dest Phone Prefix' field, enter 00 and in the 'Dest IP Address' field, enter 0.0.0.0. For routing calls between phones connected to the device (i.e., local routing), enter the device's IP address. When the device's IP address is unknown (e.g., when DHCP is used), enter IP address 127.0.0.1. When using domain names, enter the DNS server's IP address or alternatively, configure these names in the Internal DNS table (see 'Configuring the Internal DNS Table' on page 125). The IP address can include the following wildcards: <ul style="list-style-type: none"> ✓ "x": represents single digits. For example, 10.8.8.xx denotes all addresses between 10.8.8.10 and 10.8.8.99. ✓ "*": represents any number between 0 and 255. For example, 10.8.8.* denotes all addresses between 10.8.8.0 and 10.8.8.255.
<p>Web: Port EMS: Destination Port [PREFIX_DestPort]</p>	<p>Defines the destination port to where you want to route the call.</p>
<p>Web/EMS: Transport</p>	<p>Defines the transport layer type for sending the IP call:</p>

Parameter	Description
Type [PREFIX_TransportType]	<ul style="list-style-type: none"> ▪ [-1] Not Configured ▪ [0] UDP ▪ [1] TCP ▪ [2] TLS <p>Note: When set to Not Configured (-1), the transport type defined by the SIPTransportType parameter is used.</p>
Web: Dest IP Group ID EMS: Destination IP Group ID [PREFIX_DestIPGroupID]	<p>Defines the IP Group to where you want to route the call. The SIP INVITE message is sent to the IP address defined for the Proxy Set ID associated with the IP Group.</p> <p>Notes:</p> <ul style="list-style-type: none"> ▪ If you select an IP Group, you do not need to configure a destination IP address. However, if both parameters are configured in this table, the INVITE message is sent only to the IP Group (and not the defined IP address). ▪ If the destination is a User-type IP Group, the device searches for a match between the Request-URI (of the received INVITE) to an AOR registration record in the device's database. The INVITE is then sent to the IP address of the registered contact. ▪ If the parameter AlwaysUseRouteTable is set to 1 (see 'Configuring IP Groups' on page 214), then the Request-URI host name in the INVITE message is set to the value defined for the parameter 'Dest. IP Address' (above); otherwise, if no IP address is defined, it is set to the value of the parameter 'SIP Group Name' (defined in the IP Group table). ▪ This parameter is used as the 'Serving IP Group' in the Account table for acquiring authentication user/password for this call (see 'Configuring Account Table' on page 225). ▪ For defining Proxy Set ID's, see 'Configuring Proxy Sets Table' on page 219.
Dest SRD [PREFIX_DestSRD]	<p>Defines the SRD to where you want to route the call. The actual destination is defined by the Proxy Set associated with the SRD. This allows you to route the call to a specific SIP Media Realm and SIP Interface.</p> <p>To configure SRD's, see Configuring SRD Table on page 211.</p>
IP Profile ID [PREFIX_ProfileID]	<p>Assigns an IP Profile ID to this IP destination call. This allows you to assign numerous configuration attributes (e.g., voice codes) per routing rule. To configure IP Profiles, see 'Configuring IP Profiles' on page 245.</p>
Status	<p>Displays the connectivity status of the routing rule's IP destination. If there is connectivity with the destination, this field displays "OK" and the device uses this routing rule if required.</p> <p>The routing rule is not used if any of the following is displayed:</p> <ul style="list-style-type: none"> ▪ "n/a" = The destination IP Group is unavailable ▪ "No Connectivity" = No connection with the destination (no response to the ping or SIP OPTIONS). ▪ "QoS Low" = Poor Quality of Service (QoS) of the destination. ▪ "DNS Error" = No DNS resolution. This status is applicable only when a domain name is used (instead of an IP address). ▪ "Unavailable" = The destination is unreachable due to networking issues.
Web/EMS: Charge Code [PREFIX_MeteringCode]	<p>Assigns a Charge Code to the routing rule. To configure Charge Codes, see Configuring Charge Codes Table on page 391.</p>

Parameter	Description
	Note: This parameter is applicable only to FXS interfaces.
Cost Group ID [PREFIX_CostGroup]	Assigns a Cost Group with the routing rule for determining the cost of the call. To configure Cost Groups, see 'Configuring Cost Groups' on page 206.
Forking Group [PREFIX_ForkingGroup]	<p>Defines a forking group ID for the routing rule. This enables forking of incoming Tel calls to two or more IP destinations. The device sends simultaneous INVITE messages and handles multiple SIP dialogs until one of the calls is answered. When a call is answered, the other calls are dropped.</p> <p>If all matched routing rules belong to the same Forking Group number, the device sends an INVITE to all the destinations belonging to this group and according to the following logic:</p> <ul style="list-style-type: none"> ▪ If matched routing rules belong to different Forking Groups, the device sends the call to the Forking Group of the first matched routing rule. If the call cannot be established with any of the destinations associated with this Forking Group and alternative routing is enabled, the device forks the call to the Forking Group of the next matched routing rules as long as the Forking Group is defined with a higher number than the previous Forking Group. For example: <ul style="list-style-type: none"> ▪ Table index entries 1 and 2 are defined with Forking Group "1", and index entries 3 and 4 with Forking Group "2": The device first sends the call according to index entries 1 and 2, and if unavailable and alternative routing is enabled, sends the call according to index entries 3 and 4. ▪ Table index entry 1 is defined with Forking Group "2", and index entries 2, 3, and 4 with Forking Group "1": The device sends the call according to index entry 1 only and ignores the other index entries even if the destination is unavailable and alternative routing is enabled. This is because the subsequent index entries are defined with a Forking Group number that is lower than that of index entry 1. ▪ Table index entry 1 is defined with Forking Group "1", index entry 2 with Forking Group "2", and index entries 3 and 4 with Forking Group "1": The device first sends the call according to index entries 1, 3, and 4 (all belonging to Forking Group "1"), and if the destination is unavailable and alternative routing is enabled, the device sends the call according to index entry 2. ▪ Table index entry 1 is defined with Forking Group "1", index entry 2 with Forking Group "3", index entry 3 with Forking Group "2", and index entry 4 with Forking Group "1": The device first sends the call according to index entries 1 and 4 (all belonging to Forking Group "1"), and if the destination is unavailable and alternative routing is enabled, the device sends the call according to index entry 2 (Forking Group "3"). Even if index entry 2 is unavailable and alternative routing is enabled, the device ignores index entry 3 because it belongs to a Forking Group that is lower than index entry 2. <p>Notes:</p> <ul style="list-style-type: none"> ▪ To enable Tel-to-IP call forking, set the 'Tel2IP Call Forking Mode' (<i>Tel2IPCallForkingMode</i>) parameter to Enable. ▪ You can implement Forking Groups when the destination is an LDAP server or a domain name using DNS. In such scenarios, the INVITE is sent to all the queried LDAP or resolved IP addresses

Parameter	Description
	respectively. You can also use LDAP routing rules with standard routing rules for Forking Groups. <ul style="list-style-type: none"> ▪ When the UseDifferentRTPportAfterHold parameter is enabled, every forked call is sent with a different RTP port. Thus, ensure that the device has available RTP ports for these forked calls.

24.3 Configuring Inbound IP Routing Table

The Inbound IP Routing Table page allows you to configure up to 24 inbound call routing rules:

- For IP-to-IP routing: The table is used to identify an incoming call as an IP-to-IP call and subsequently, to assign the call to an IP Group, referred to as a source IP Group. These IP-to-IP calls can later be routed to an outbound destination IP Group (see [Configuring Outbound IP Routing Table](#) on page 323).
- For IP-to-Tel routing: This table is used to route incoming IP calls to Trunk Groups. The specific channel pertaining to the Trunk Group to which the call is routed is determined according to the Trunk Group's channel selection mode. The channel selection mode can be defined per Trunk Group (see ['Configuring Trunk Group Settings'](#) on page 293) or for all Trunk Groups using the global parameter ChannelSelectMode.

The Inbound IP Routing Table provides two configuration areas:

- Matching characteristics of incoming IP call, for example, prefix of destination number.
- Operation (destination), for example, sends to a specific Trunk Group.

If the incoming call matches the characteristics of a rule, then the call is sent to the destination configured for that rule.

The device also supports alternative routing if the Trunk Group is unavailable:

- If a call release reason is received for a specific IP-to-Tel call and this reason is configured for alternative IP-to-Tel routing, then the device re-routes the call to an alternative Trunk Group. The alternative route is configured in this table as an additional row (below the main routing rule) with the same call characteristics, but with a destination to a different Trunk Group. For more information on IP-to-Tel alternative routing, see ['Alternative Routing to Trunk upon Q.931 Call Release Cause Code'](#) on page 340.
- The device can re-route (i.e., call redirection) IP-to-Tel calls to an alternative IP destination using SIP 3xx responses. For more information, see ['Alternative Routing to IP Destinations upon Busy Trunk'](#) on page 341.

The device automatically re-routes an IP-to-Tel call to a different physical FXO port or physical trunk if the initially destined FXO port or physical trunk within the same Trunk Group is detected as out of service (e.g., physically disconnected). When the physical FXO port or physical trunk is disconnected, the device sends the SNMP trap, GWAPP_TRAP_BUSYOUT_LINK notifying of the out-of-service state for the specific FXO line or trunk number. When the FXO port or physical trunk is physically reconnected, this trap is sent notifying of the back-to-service state.



Note: You can also configure the Inbound IP Routing Table using the table ini file parameter, PSTNPrefix (see ['Number Manipulation Parameters'](#) on page 808).

➤ **To configure IP-to-Tel or inbound IP routing rules:**

1. Open the Inbound IP Routing Table page (**Configuration** tab > **VoIP** menu > **GW and IP to IP** submenu > **Routing** > **IP to Trunk Group Routing**).

Figure 24-3: Inbound IP Routing Table

Routing Index		1-12					
IP To Tel Routing Mode		Route calls before manipulation					
Dest. Host Prefix	Source Host Prefix	Dest. Phone Prefix	Source Phone Prefix	Source IP Address	Trunk Group ID	IP Profile ID	Source IPGroup ID
1		1x	*		1	2	-1
2		[501-502]	101		2	1	
3	domain.com	*	*		3		
4		*	*	10.13.64.5	-1		4

The previous figure displays the following configured routing rules:

- **Rule 1:** If the incoming IP call destination phone prefix is between 10 and 19, the call is assigned settings configured for IP Profile ID 2 and routed to Trunk Group ID 1.
 - **Rule 2:** If the incoming IP call destination phone prefix is between 501 and 502 and source phone prefix is 101, the call is assigned settings configured for IP Profile ID 1 and routed to Trunk Group ID 2.
 - **Rule 3:** If the incoming IP call has a From URI host prefix as domain.com, the call is routed to Trunk Group ID 3.
 - **Rule 4:** If the incoming IP call has IP address 10.13.64.5 in the INVITE's Contact header, the call is identified as an IP-to-IP call and assigned to Source IP Group 4. This call is routed according to the outbound IP routing rules for this Source IP Group configured in the Outbound IP Routing Table.
2. Configure the routing rule, as required. For a description of the parameters, see the table below.
 3. Click **Submit** to apply your changes.

IP-to-Tel or Inbound IP Routing Table Description

Parameter	Description
IP to Tel Routing Mode [RouteModeIP2Tel]	Determines whether to route the incoming IP call before or after manipulation of destination number, configured in 'Configuring Source/Destination Number Manipulation' on page 299. <ul style="list-style-type: none"> ▪ [0] Route calls before manipulation = (Default) Incoming IP calls are routed before number manipulation. ▪ [1] Route calls after manipulation = Incoming IP calls are routed after number manipulation.
Matching Characteristics	
Web: Dest. Host Prefix [DestPrefix]	Defines the Request-URI host name prefix of the incoming SIP INVITE message. If this routing rule is not required, leave the field empty. Note: The asterisk (*) wildcard can be used to depict any prefix.

Parameter	Description
Web: Source Host Prefix [SrcHostPrefix]	Defines the From URI host name prefix of the incoming SIP INVITE message. If this routing rule is not required, leave the field empty. Notes: <ul style="list-style-type: none"> ▪ The asterisk (*) wildcard can be used to depict any prefix. ▪ If the P-Asserted-Identity header is present in the incoming INVITE message, then the value of this parameter is compared to the P-Asserted-Identity URI host name (and not the From header).
Web: Dest. Phone Prefix [DestHostPrefix]	Defines the prefix or suffix of the called (destined) telephone number. You can use special notations for denoting the prefix. For example, [100-199](100,101,105) denotes a number that starts with 100 to 199 and ends with 100, 101 or 105. To denote any prefix, use the asterisk (*) symbol or to denote calls without a called number, use the \$ sign. For a description of available notations, see 'Dialing Plan Notation for Routing and Manipulation Tables' on page 607. The prefix can include up to 49 digits.
Web: Source Phone Prefix [SourcePrefix]	Defines the prefix or suffix of the calling (source) telephone number. You can use special notations for denoting the prefix. For example, [100-199](100,101,105) denotes a number that starts with 100 to 199 and ends with 100, 101 or 105. To denote any prefix, use the asterisk (*) symbol or to denote calls without a calling number, use the \$ sign. For a description of available notations, see 'Dialing Plan Notation for Routing and Manipulation Tables' on page 607. The prefix can include up to 49 digits.
Web: Source IP Address [SourceAddress]	Defines the source IP address of the incoming IP call that can be used for routing decisions. The IP address can be configured in dotted-decimal notation (e.g., 10.8.8.5) or as an FQDN. If the address is an FQDN, DNS resolution is done according to the DNSQueryType parameter. Notes: <ul style="list-style-type: none"> ▪ The source IP address is obtained from the Contact header in the INVITE message. ▪ You can configure from where the source IP address is obtained, using the SourceIPAddressInput parameter. ▪ The source IP address can include the following wildcards: <ul style="list-style-type: none"> ✓ "x": denotes single digits. For example, 10.8.8.xx represents all the addresses between 10.8.8.10 and 10.8.8.99. ✓ "*": denotes any number between 0 and 255. For example, 10.8.8.* represents all addresses between 10.8.8.0 and 10.8.8.255.
Source SRD ID [SrcSRDID]	Defines the SRD from which the incoming packet is received. Notes: <ul style="list-style-type: none"> ▪ When the incoming INVITE matches the SRD in the routing rule, if the 'Source IP Group ID' parameter (see below) is defined and it is associated with a different SRD, the incoming SIP call is rejected. If the 'Source IP Group ID' parameter is not defined, the SRD's default IP Group is used. If there is no valid source IP Group, the call is rejected. ▪ Currently, this parameter can only be configured using the ini file.
Operation (Destination)	

Parameter	Description
Web: Trunk Group ID [TrunkGroupID]	For IP-to-Tel calls: Defines the Trunk Group to where the incoming SIP call is sent. For IP-to-IP calls: Identifies the call as an IP-to-IP call if this parameter is set to -1.
Web: Trunk ID [TrunkID]	Defines the Trunk to where the incoming SIP call is sent. Notes: <ul style="list-style-type: none"> ▪ If both 'Trunk Group ID' and 'Trunk ID' parameters are configured in the table, the routing is done according to the 'Trunk Group ID' parameter. ▪ The method for selecting the trunk's channel to which the IP call is sent is configured by the global parameter, ChannelSelectMode. ▪ Currently, this field can only be configured using the ini file.
Web: IP Profile ID [ProfileID]	Assigns an IP Profile (configured in 'Configuring IP Profiles' on page 245) to the call.
Web: Source IP Group ID [SrcIPGroupID]	For IP-to-Tel calls: Defines the IP Group associated with the incoming IP call. This is the IP Group that sent the INVITE message. This IP Group can later be used as the 'Serving IP Group' in the Account table for obtaining authentication user name/password for this call (see 'Configuring Account Table' on page 225). For IP-to-IP calls: Assigns the IP Group to the incoming IP call. This IP Group can later be used for outbound IP routing and as the 'Serving IP Group' in the Account table for obtaining authentication user name/password for this call (see Configuring Account Table on page 225).

24.4 IP Destinations Connectivity Feature

The device can be configured to check the integrity of the connectivity to IP destinations of Tel-to-IP routing rules in the Outbound IP Routing table. The IP Connectivity feature can be used for the Alternative Routing feature, whereby the device attempts to re-route calls from unavailable Tel-to-IP routing destinations to available ones (see 'Alternative Routing Based on IP Connectivity' on page 336).

The device supports the following methods for checking the connectivity of IP destinations:

- **Network Connectivity:** The device checks the network connectivity of the IP destination using one of the following methods configured by the 'Alt Routing Tel to IP Connectivity Method' parameter:
 - Ping: The device periodically (every seven seconds) pings the IP destination.
 - **SIP OPTIONS:** The device sends "keep-alive" SIP OPTIONS messages to the IP destination. If the device receives a SIP 200 OK in response, it considers the destination as available. If the destination does not respond to the OPTIONS message, then it is considered unavailable. You can configure the time interval for sending these OPTIONS messages, using the 'Alt Routing Tel to IP Keep Alive Time' parameter.

These parameters are configured in the Routing General Parameters page (**Configuration** tab > **VoIP** menu > **GW and IP to IP** > **Routing** > **General Parameters**), as shown below:

Figure 24-4: IP Connectivity Method in Routing General Parameters Page

Alt Routing Tel to IP Connectivity Method	SIP OPTIONS
Alt Routing Tel to IP Keep Alive Time	60

- **Quality of Service (QoS):** You can enable the device to check the QoS of IP destinations. The device measures the QoS according to RTCP statistics of previously established calls with the IP destination. The RTCP includes packet delay (in milliseconds) and packet loss (in percentage). If these measured statistics exceed a user-defined threshold, the destination is considered unavailable. Note that if call statistics is not received within two minutes, the QoS data is reset. These thresholds are configured using the following parameters:
 - 'Max Allowed Packet Loss for Alt Routing' (IPConnQoSMaxAllowedPL): defines the threshold value for packet loss after which the IP destination is considered unavailable.
 - 'Max Allowed Delay for Alt Routing' (IPConnQoSMaxAllowedDelay): defines the threshold value for packet delay after which the IP destination is considered unavailable

These parameters are configured in the Routing General Parameters page, as shown below:

Figure 24-5: IP QoS Thresholds in Routing General Parameters Page

Max Allowed Packet Loss for Alt Routing [%]	20
Max Allowed Delay for Alt Routing [msec]	250

- **DNS Resolution:** When a host name (FQDN) is used (instead of an IP address) for the IP destination, it is resolved into an IP address by a DNS server. The device checks network connectivity and QoS of the resolved IP address. If the DNS host name is unresolved, the device considers the connectivity of the IP destination as unavailable.

You can view the connectivity status of IP destinations in the following Web interface pages:

- **Outbound IP Routing Table:** The connectivity status of the IP destination per routing rule is displayed in the 'Status' column. For more information, see 'Configuring Outbound IP Routing Table' on page 323.
- **IP Connectivity:** This page displays a more informative connectivity status of the IP destinations used in Tel-to-IP routing rules in the Outbound IP Routing table. For viewing this page, see 'Viewing IP Connectivity' on page 558.

24.5 Alternative Routing for Tel-to-IP Calls

The device supports various alternative Tel-to-IP call routing methods, as described in this section.

24.5.1 Alternative Routing Based on IP Connectivity

You can configure the device to do alternative Tel-to-IP call routing based on IP connectivity. When the connectivity state of an IP destination is unavailable, the device attempts to re-route the Tel-to-IP call to an alternative IP destination. It does this by searching for the next call matching rule (e.g., phone number prefix) in the Outbound IP Routing table.

**Notes:**

- Alternative routing based on IP connectivity is applicable only when a proxy server is not used.
- As the device searches the Outbound IP Routing table for a matching rule starting from the top, you must configure the main routing rule above the alternative routing rules.
- You can configure up to two alternative routing rules.
- For configuring Tel-to-IP routing rules in the Outbound IP Routing table, see 'Configuring Outbound IP Routing Table' on page 323.

The device searches for an alternative IP destination when any of the following connectivity states are detected with the IP destination of the initial Tel-to-IP routing rule:

- No response received from a ping or from SIP OPTIONS messages. This depends on the chosen method for checking IP connectivity.
- Poor QoS according to the configured thresholds for packet loss and delay.
- Unresolved DNS, if the configured IP destination is a domain name (or FQDN). If the domain name is resolved into two IP addresses, the timeout for INVITE re-transmissions can be configured using the HotSwapRtx parameter. For example, if you set this parameter to 3, the device attempts up to three times to route the call to the first IP address and if unsuccessful, it attempts up to three times to re-route it to the second resolved IP address.

The connectivity status of the IP destination is displayed in the 'Status' column of the Outbound IP Routing table per routing rule. If it displays a status other than "ok", then the device considers the IP destination as unavailable and attempts to re-route the call to an alternative destination. For more information on the IP connectivity methods and on viewing IP connectivity status, see 'IP Destinations Connectivity Feature' on page 335.

The table below shows an example of alternative routing where the device uses an available alternative routing rule in the Outbound IP Routing table to re-route the initial Tel-to-IP call.

Alternative Routing based on IP Connectivity Example

	Destination Phone Prefix	IP Destination	IP Connectivity Status	Rule Used?
Main Route	40	10.33.45.68	"No Connectivity"	No
Alternative Route #1	40	10.33.45.70	"QoS Low"	No
Alternative Route #2	40	10.33.45.72	"ok"	Yes

The steps for configuring alternative Tel-to-IP routing based on IP connectivity are summarized below.

➤ **To configure alternative Tel-to-IP routing based on IP connectivity:**

1. In the Outbound IP Routing table, add alternative Tel-to-IP routing rules for specific calls.
2. In the Routing General Parameters page (**Configuration** tab > **VoIP** menu > **GW and IP to IP** > **Routing** > **General Parameters**), do the following:
 - a. Enable alternative routing based on IP connectivity, by setting the 'Enable Alt Routing Tel to IP AltRouting' (Tel2IPEnable) parameter to **Enable**.

- b. Configure the IP connectivity reason for triggering alternative routing, by setting the 'Alt Routing Tel to IP Mode' parameter (AltRoutingTel2IPMode) to one of the following:
 - ◆ Ping or SIP OPTIONS failure
 - ◆ Poor QoS
 - ◆ Ping or SIP OPTIONS failure, poor QoS, or unresolved DNS
- c. The device plays a tone to the Tel endpoint (for analog interfaces) whenever an alternative route is used. This tone is played for a user-defined time configured by the 'Alternative Routing Tone Duration' parameter.

24.5.2 Alternative Routing Based on SIP Responses

You can configure the device to do alternative routing based on the received SIP response. If the SIP response code reflects an error (i.e., 4xx, 5xx, or 6xx) and you have configured this specific response code as a trigger for alternative routing, then the device attempts to re-route the call to an alternative destination.

You can configure up to five SIP response codes for triggering alternative routing. This is done in the Reasons for Alternative Routing table, explained in this section.

Typically, the device performs alternative routing when there is no response at all to an INVITE message after a user-defined number of INVITE re-transmissions, configured using the SIPMaxRtx parameter. In such a scenario, the device issues itself the SIP response code 408 "Request Timeout". If this release code is defined in the Reasons for Alternative Routing table, then alternative routing is done.



Note: The device also plays a tone to the endpoint whenever an alternative route is used. This tone is played for a user-defined time, configured by the AltRoutingToneDuration parameter.

Depending on configuration, the alternative routing is done using one of the following configuration entities:

- **Outbound IP Routing Rules:** You can configure up to two alternative routing rules in the table. If the initial, main routing rule destination is unavailable, the device searches the table (starting from the top) for the next call matching rule (e.g., destination phone number), and if available attempts to re-route the call to the IP destination configured for this alternative routing rule. The table below shows an example of alternative routing where the device uses the first available alternative routing rule to re-route the initial, unsuccessful Tel-to-IP call destination.

Alternative Routing based on SIP Response Code Example

	Destination Phone Prefix	IP Destination	SIP Response	Rule Used?
Main Route	40	10.33.45.68	408 Request Timeout	No
Alternative Route #1	40	10.33.45.70	486 Busy Here	No
Alternative Route #2	40	10.33.45.72	200 OK	Yes

- **Proxy Sets:** Proxy Sets are used for Server-type IP Groups (e.g., an IP PBX) and define the actual IP destination (IP address or FQDN) of the server. As you can define up to five IP destinations per Proxy Set, the device supports proxy redundancy, which works together with the alternative routing feature. If the destination of a routing rule in

the Outbound IP Routing table is an IP Group, the device routes the call to the IP destination configured for the Proxy Set associated with the IP Group. If the first IP destination of the Proxy Set is unavailable, the device attempts to re-route the call to the next proxy destination, and so on until an available IP destination is located. To enable the Proxy Redundancy feature, set the IsProxyHotSwap parameter to 1 (per Proxy Set) and set the EnableProxyKeepAlive to 1.

When the Proxy Redundancy feature is enabled, the device continually monitors the connection with the proxies by using keep-alive messages (SIP OPTIONS). The device sends these messages every user-defined interval (ProxyKeepAliveTime parameter). Any response from the proxy, either success (200 OK) or failure (4xx response) is considered as if the proxy is communicating. If there is no response from the first (primary) proxy after a user-defined number of re-transmissions (re-INVITEs) configured using the HotSwapRtx parameter, the device attempts to communicate (using the same INVITE) with the next configured (redundant) proxy in the list, and so on until an available redundant proxy is located. The device's behavior can then be one of the following, depending on the ProxyRedundancyMode parameter setting:

- The device continues operating with the redundant proxy (now active) until the next failure occurs, after which it switches to the next redundant proxy. This is referred to as *Parking* mode.
- The device always attempts to operate with the primary proxy. In other words, it switches back to the primary proxy whenever it's available again. This is referred to as *Homing* mode.

If none of the proxy servers respond, the device goes over the list again.

The steps for configuring alternative Tel-to-IP routing based on SIP response codes are summarized below.

➤ **To configure alternative Tel-to-IP routing based on SIP response codes:**

1. Enable alternative routing based on SIP responses, by setting the 'Redundant Routing Mode' parameter to one of the following:
 - **Routing Table** for using the Outbound IP Routing table for alternative routing.
 - **Proxy** for using the Proxy Set redundancy feature for alternative routing.
2. If you are using the Outbound IP Routing table, configure alternative routing rules with identical call matching characteristics, but with different IP destinations. If you are using the Proxy Set, configure redundant proxies.
3. Define SIP response codes (call failure reasons) that invoke alternative Tel-to-IP routing:
 - a. Open the Reasons for Alternative Routing page (**Configuration** tab > **VoIP** menu > **GW and IP to IP** submenu > **Routing** submenu > **Alternative Routing Reasons**).

Figure 24-6: Tel to IP Reasons - Reasons for Alternative Routing Page

Tel to IP Reasons	
Reason 1	▼
Reason 2	▼
Reason 3	▼
Reason 4	▼
Reason 5	▼

- b. Under the 'Tel to IP Reasons' group, select up to five different SIP response codes (call failure reasons) that invoke alternative Tel-to-IP routing.
- c. Click **Submit**.

24.5.3 PSTN Fallback

The PSTN Fallback feature enables the device to re-route a Tel-to-IP call to the legacy PSTN using one of its trunks if the IP destination is unavailable. For example, if poor voice quality is detected over the IP network, the device attempts to re-route the call to the PSTN.

The steps for configuring alternative Tel-to-IP routing to the legacy PSTN are summarized below.

➤ **To configure alternative Tel-to-IP routing to the legacy PSTN:**

1. Configure an alternative routing rule in the Outbound IP Routing table with the same call matching characteristics (e.g., phone number destination), but where the destination is the IP address of the device itself.
2. Configure an IP-to-Tel routing rule in the Inbound IP Routing table to route calls received from the device (i.e., its IP address) to a specific Trunk Group connected to the PSTN. This configuration is necessary as the re-routed call is now considered an IP-to-Tel call. For configuring IP-to-Tel routing rules, see 'Configuring the Inbound IP Routing Table' on page 332.



Note: The PSTN Fallback feature is applicable only to digital interfaces (e.g., E1 / T1 trunks).

24.6 Alternative Routing for IP-to-Tel Calls

The device supports alternative IP-to-Tel call routing, as described in this section.

24.6.1 Alternative Routing to Trunk upon Q.931 Call Release Cause Code

You can configure the device to do alternative IP-to-Tel call routing based on the received ISDN Q.931 cause code. If an IP-to-Tel call is rejected or disconnected on the Tel side as a result of a specific ISDN Q.931 release cause code that is listed in the Reasons for Alternative Routing table, the device searches for an alternative IP-to-Tel routing rule in the Inbound IP Routing table and sends it to the alternative Trunk Group. For example, you can enable alternative IP-to-Tel routing for scenarios where the initial Tel destination is busy and a Q.931 Cause Code No. 17 is received (or for other call releases that issue the default Cause Code No. 3).

You can also configure a default release cause code that the device issues itself upon the following scenarios:

- The device initiates a call release whose cause is unknown.
- No free channels (i.e., busy) in the Trunk Group.
- No appropriate routing rule located in the Inbound IP Routing table to the Trunk Group.
- Phone number is not found in the Inbound IP Routing table.

By default, it is set to Cause Code No. 3 (No Route to Destination). This default cause code can be changed using the 'Default Release Cause' parameter located in the Advanced Parameters page (**Configuration** tab > **VoIP** menu > **SIP Definitions** > **Advanced Parameters**). To enable alternative routing based on Q.931 cause code, you need to define this cause code in the Reasons for Alternative Routing table.

- **To configure alternative Trunk Group routing based on Q.931 cause codes:**
1. In the Proxy & Registration page, set the 'Redundant Routing Mode' parameter to **Routing Table** so that the device uses the Inbound IP Routing table for alternative routing.
 2. In the Inbound IP Routing table, configure alternative routing rules with the same call matching characteristics, but with different Trunk Group destinations.
 3. Configure up to five Q.931 cause codes that invoke alternative IP-to-Tel routing:
 - a. Open the Reasons for Alternative Routing page (**Configuration** tab > **VoIP** menu > **GW and IP to IP** > **Routing** > **Alternative Routing Reasons**).

Figure 24-7: IP to Tel Reasons - Reasons for Alternative Routing Page

IP to Tel Reasons	
Reason 1	3
Reason 2	17
Reason 3	
Reason 4	
Reason 5	

- b. Under the 'IP to Tel Reasons' group, select the desired Q.931 cause codes.
- c. Click **Submit** to apply your changes.

Notes:

- You can configure up to two alternative routing rules in the Inbound IP Routing table.
- If a Trunk is disconnected or not synchronized, the device issues itself the internal Cause Code No. 27. This cause code is mapped (by default) to SIP 502.
- The default release cause is described in the Q.931 notation and is translated to corresponding SIP 40x or 50x values (e.g., Cause Code No. 3 to SIP 404, and Cause Code No. 34 to SIP 503).
- For analog interfaces: For information on mapping PSTN release causes to SIP responses, see PSTN Release Cause to SIP Response Mapping on page 320.
- For mapping SIP-to-Q.931 and Q.931-to-SIP release causes, see Configuring Release Cause Mapping on page 315.
- For configuring IP-to-Tel routing rules in the Inbound IP Routing table, see 'Configuring Inbound IP Routing Table' on page 332.
- The Reasons for Alternative Routing IP to Tel table can also be configured using the table ini file parameter, AltRouteCauseIP2Tel.



24.6.2 Alternative Routing to an IP Destination upon a Busy Trunk

You can configure the device to forward (i.e., call redirection) IP-to-Tel calls to an alternative IP destination using SIP 3xx responses. This can be done upon the following scenarios:

- For digital interfaces: Trunk Group has no free channels (i.e., “busy”).
- For analog interfaces: Unavailable FXS / FXO Trunk Group. This feature can be used, for example, to forward the call to another FXS / FXO device.

This feature is configured per Trunk Group and is configured in the Forward on Busy Trunk Destination table, as described in this section.

The alternative destination can be defined as a host name or as a SIP Request-URI user name and host part (i.e., user@host). For example, the below configuration forwards IP-to-Tel calls to destination user “112” at host IP address 10.13.4.12, port 5060, using transport protocol TCP, if Trunk Group ID 2 is unavailable:

```
ForwardOnBusyTrunkDest 1 = 2, 112@10.13.4.12:5060;transport=tcp;
```

When configured with user@host, the original destination number is replaced by the user part.

The device forwards calls using this table only if no alternative IP-to-Tel routing rule has been configured in the Inbound IP Routing table or alternative routing fails and one of the following reasons in the SIP Diversion header of 3xx messages exists:

- For digital interfaces: "out-of-service" - all trunks are unavailable/disconnected
- "unavailable":
 - For digital interfaces: All trunks are busy or unavailable
 - For analog interfaces: All FXS / FXO lines pertaining to a Trunk Group are busy or unavailable



Note: You can also configure the Forward on Busy Trunk Destination table using the table ini file parameter, ForwardOnBusyTrunkDest.

➤ **To configure Forward on Busy Trunk Destination rules:**

1. Open the Forward on Busy Trunk Destination page (**Configuration** tab > **VoIP** menu > **GW and IP to IP** > **Routing** > **Forward on Busy Trunk**).

Figure 24-8: Forward on Busy Trunk Destination Page

Index	Trunk Group ID	Forward Destination
0	1	10.13.5.67

The figure above displays a configuration that forwards IP-to-Tel calls destined for Trunk Group ID 1 to destination IP address 10.13.5.67 if the conditions mentioned earlier exist.

2. Configure the table as required, and then click **Submit** to apply your changes.
3. Save the changes to the device's flash memory with a device reset (see 'Saving Configuration' on page 494).

Forward on Busy Trunk Destination Description Parameters

Parameter	Description
Trunk Group ID [ForwardOnBusyTrunkDest_TrunkGroupID]	Defines the Trunk Group ID to which the IP call is destined to.
Forward Destination [ForwardOnBusyTrunkDest_ForwardDestination]	Defines the alternative IP destination for the call used if the Trunk Group is busy or unavailable. The valid value can be an IP address in dotted-decimal notation, an FQDN, or a SIP Request-URI user name and host part (i.e., user@host). The following syntax can also be used: host:port;transport=xxx (i.e., IP address, port and transport type). Note: When configured with a user@host, the original destination number is replaced by the user part.

25 Configuring DTMF and Dialing

The DTMF & Dialing page is used to configure parameters associated with dual-tone multi-frequency (DTMF) and dialing. For a description of the parameters appearing on this page, see 'Configuration Parameters Reference' on page 609.

➤ **To configure the DTMF and dialing parameters:**

1. Open the DTMF & Dialing page (**Configuration** tab > **VoIP** menu > **GW and IP to IP** submenu > **DTMF & Supplementary** submenu > **DTMF & Dialing**).

Max Digits In Phone Num	<input type="text" value="30"/>
Inter Digit Timeout [sec]	<input type="text" value="4"/>
Declare RFC 2833 in SDP	<input type="text" value="Yes"/>
1st Tx DTMF Option	<input type="text" value="RFC 2833"/>
2nd Tx DTMF Option	<input type="text"/>
RFC 2833 Payload Type	<input type="text" value="96"/>
Hook-Flash Option	<input type="text" value="Not Supported"/>
Digit Mapping Rules	<input type="text"/>
Dial Plan Index	<input type="text" value="-1"/>
Dial Tone Duration [sec]	<input type="text" value="16"/>
Hotline Dial Tone Duration [sec]	<input type="text" value="16"/>
Enable Special Digits	<input type="text" value="Disable"/>
Dial Plan Index	<input type="text" value="-1"/>
Min Routing Overlap Digits	<input type="text" value="1"/>
ISDN Overlap IP to Tel Dialing	<input type="text" value="Disable"/>
Default Destination Number	<input type="text" value="1000"/>
Special Digit Representation	<input type="text" value="Special"/>

2. Configure the parameters as required.
3. Click **Submit** to apply your changes.
4. To save the changes to flash memory, see 'Saving Configuration' on page 494.

25.1 Dialing Plan Features

This section describes various dialing plan features supported by the device.

25.1.1 Digit Mapping

Digit map pattern rules are used for Tel-to-IP ISDN overlap dialing (by setting the ISDNRxOverlap parameter to 1) to reduce the dialing period (for digital interface). For more information on digit maps for ISDN overlapping, see ISDN Overlap Dialing on page 288. The device collects digits until a match is found in the user-defined digit pattern (e.g., for closed numbering schemes). The device stops collecting digits and starts sending the digits (collected number) when any one of the following scenarios occur:

- Maximum number of digits is received. You can define (using the MaxDigits parameter) the maximum number of collected destination number digits that can be received (i.e., dialed) from the Tel side by the device. When the number of collected digits reaches the maximum (or a digit map pattern is matched), the device uses these digits for the called destination number.
- Inter-digit timeout expires (e.g., for open numbering schemes). This is defined using the TimeBetweenDigits parameter. This is the time that the device waits between each received digit. When this inter-digit timeout expires, the device uses the collected digits to dial the called destination number.
- The phone's pound (#) key is pressed.
- Digit string (i.e., dialed number) matches one of the patterns defined in the digit map.

Digit map (pattern) rules are defined using the DigitMapping parameter. The digit map pattern can contain up to 52 options (rules), each separated by a vertical bar ("|"). The maximum length of the entire digit pattern is 152 characters. The available notations are described in the table below:

Digit Map Pattern Notations

Notation	Description
[n-m]	Range of numbers (not letters).
.	(single dot) Repeat digits until next notation (e.g., T).
x	Any single digit.
T	Dial timeout (configured by the TimeBetweenDigits parameter).
S	Short timer (configured by the TimeBetweenDigits parameter; default is two seconds) that can be used when a specific rule is defined after a more general rule. For example, if the digit map is 99 998, then the digit collection is terminated after the first two 9 digits are received. Therefore, the second rule of 998 can never be matched. But when the digit map is 99s 998, then after dialing the first two 9 digits, the device waits another two seconds within which the caller can enter the digit 8.

Below is an example of a digit map pattern containing eight rules:

```
DigitMapping = 11xS|00[1-7]xxx|8xxxxxxxx|#xxxxxxx|*xx|91xxxxxxxxxxxx|9011x|xx.T
```

In the example, the rule "00[1-7]xxx" denotes dialed numbers that begin with 00, and then any digit from 1 through 7, followed by three digits (of any number). Once the device receives these digits, it does not wait for additional digits, but starts sending the collected digits (dialed number) immediately.

**Notes:**

- If you want the device to accept/dial any number, ensure that the digit map contains the rule "xx.T"; otherwise, dialed numbers not defined in the digit map are rejected.
- If you are using an external Dial Plan file for dialing plans (see 'Dialing Plans for Digit Collection' on page 508), the device first attempts to locate a matching digit pattern in the Dial Plan file, and if not found, then attempts to locate a matching digit pattern in the Digit Map (configured by the DigitMapping parameter).
- It may be useful to configure both Dial Plan file and Digit Maps. For example, the Digit Map can be used for complex digit patterns (which are not supported by the Dial Plan) and the Dial Plan can be used for long lists of relatively simple digit patterns. In addition, as timeout between digits is not supported by the Dial Plan, the Digit Map can be used to define digit patterns (MaxDigits parameter) that are shorter than those defined in the Dial Plan, or left at default. For example, "xx.T" Digit Map instructs the device to use the Dial Plan and if no matching digit pattern, it waits for two more digits and then after a timeout (TimeBetweenDigits parameter), it sends the collected digits. Therefore, this ensures that calls are not rejected as a result of their digit pattern not been completed in the Dial Plan.

25.1.2 External Dial Plan File

The device can be loaded with a Dial Plan file with user-defined dialing plans. For more information, see 'Dial Plan File' on page 508.

Reader's Notes

26 Configuring Supplementary Services

This section describes SIP supplementary services that can enhance your telephone service.



Notes:

- All call participants must support the specific supplementary service that is used.
- When working with certain application servers (such as BroadSoft's BroadWorks) in client server mode (the application server controls all supplementary services and keypad features by itself), the device's supplementary services must be disabled.

The Supplementary Services page is used to configure many of the discussed supplementary services parameters. For a description of the parameters appearing on this page, see 'Configuration Parameters Reference' on page 609.

➤ To configure supplementary services parameters:

1. Open the Supplementary Services page (**Configuration** tab > **VoIP** menu > **GW and IP to IP** submenu > **DTMF & Supplementary** submenu > **Supplementary Services**).

Enable Hold	Enable	▼
Enable Hold to ISDN	Disable	▼
Hold Format	0.0.0.0	▼
Held Timeout	-1	
Call Hold Reminder Ring Timeout	30	
Enable Transfer	Enable	▼
Transfer Prefix		
Enable Call Forward	Enable	▼
Enable Call Waiting	Enable	▼
Number of Call Waiting Indications	2	
Time Between Call Waiting Indications	10	
Time Before Waiting Indications	0	
Waiting Beep Duration	300	
Enable Caller ID	Disable	▼
Caller ID Type	Standard Bellcore	▼
Hook-Flash Code		
Flash Keys Sequence Style	0	
Flash Keys Sequence Timeout	2000	
Max 3 Way Conference on Board Calls	2	
Non Allocatable Ports	0	
Enable NRT Subscription	Disable	▼
AS Subscribe IPGroupID	-1	
NRT Subscribe Retry Time	120	
Call Forward Ring Tone ID	1	

MWI Parameters		
Enable MWI	Disable	▼
MWI Analog Lamp	Disable	▼
MWI Display	Disable	▼
Subscribe to MWI	No	▼
MWI Server Transport Type	Not Configured	▼
MWI Server IP Address		
MWI Subscribe Expiration Time	7200	
MWI Subscribe Retry Time	120	
Stutter Tone Duration	2000	

Conference		
Enable 3-Way Conference	Disable	▼
Establish Conference Code	!	
Conference ID	conf	
Three Way Conference Mode	AutoCodes Media Server	▼

MLPP		
Call Priority Mode	Disable	▼
MLPP Diffserv	50	
Precedence Ringing Type	-1	

BRI to SIP Supplementary Services Codes		
Call Forward Unconditional		
Call Forward Unconditional Deactivation		
Call Forward on Busy		
Call Forward on Busy Deactivation		
Call Forward on No Reply		
Call Forward on No Reply Deactivation		

Transfer		
Blind		

2. Configure the parameters as required.
3. Click **Submit** to apply your changes, or click the **Subscribe to MWI** or **Unsubscribe to MWI** buttons to save your changes and to subscribe / unsubscribe to the MWI server.
4. To save the changes to flash memory, see 'Saving Configuration' on page 494.

26.1 Call Hold and Retrieve

Initiating Call Hold and Retrieve:

- Active calls can be put on-hold by pressing the phone's hook-flash button.
- The party that initiates the hold is called the *holding* party; the other party is called the *held* party.
- After a successful Hold, the holding party hears a dial tone (HELD_TONE defined in the device's Call Progress Tones file).
- Call retrieve can be performed only by the holding party while the call is held and active.
- The holding party performs the retrieve by pressing the telephone's hook-flash button.
- After a successful retrieve, the voice is connected again.
- Hold is performed by sending a Re-INVITE message with IP address 0.0.0.0 or a=sendonly in the SDP according to the parameter HoldFormat.
- The hold and retrieve functionalities are implemented by re-INVITE messages. The IP address 0.0.0.0 as the connection IP address or the string 'a=inactive' in the received re-INVITE SDP cause the device to enter Hold state and to play the held tone (configured in the device) to the PBX/PSTN. If the string 'a=sendonly' is received in the SDP message, the device stops sending RTP packets, but continues to listen to the incoming RTP packets. Usually, the remote party plays, in this scenario, Music on Hold (MOH) and the device forwards the MOH to the held party.


Receiving Hold/Retrieve:

- When an active call receives a re-INVITE message with either the IP address 0.0.0.0 or the 'inactive' string in SDP, the device stops sending RTP and plays a local held tone.
- When an active call receives a re-INVITE message with the 'sendonly' string in SDP, the device stops sending RTP and listens to the remote party. In this mode, it is expected that on-hold music (or any other hold tone) is played (over IP) by the remote party.

You can also configure the device to keep a call on-hold for a user-defined time after which the call is disconnected, using the HeldTimeout parameter.

The device also supports "double call hold" for FXS interfaces where the called party, which has been placed on-hold by the calling party, can then place the calling party on hold as well and make a call to another destination. The flowchart below provides an example of this type of call hold:

Figure 26-1: Double Hold SIP Call Flow



The flowchart above describes the following "double" call-hold scenario:

1. A calls B and establishes a voice path.
2. A places B on hold; A hears a dial tone and B hears a held tone.
3. A calls C and establishes a voice path.
4. B places A on hold; B hears a dial tone.
5. B calls D and establishes a voice path.
6. A ends call with C; A hears a held tone.
7. B ends call with D.
8. B retrieves call with A.



Notes:

- If a party that is placed on hold (e.g., B in the above example) is called by another party (e.g., D), then the on-hold party receives a call waiting tone instead of the held tone.
- While in a Double Hold state, placing the phone on-hook disconnects both calls (i.e. call transfer is not performed).
- You can enable the device to handle incoming re-INVITE messages with "a=sendonly" in the SDP, in the same way as if "a=inactive" is received in the SDP. This is configured using the SIPHoldBehavior parameter. When enabled, the device plays a held tone to the Tel phone and responds with a 200 OK containing "a=recvonly" in the SDP.

26.2 Call Pickup

The device supports the Call Pick-Up feature, whereby the FXS user can answer someone else's telephone call by pressing a user-defined sequence of phone keys. When the user dials the user-defined digits (e.g., #77), the incoming call from the other phone is forwarded to the FXS user's phone. This feature is configured using the parameter KeyCallPickup.



Note: The Call Pick-Up feature is supported only for FXS endpoints pertaining to the same Trunk Group ID.

26.3 BRI Suspend and Resume

The device supports call suspend and resume services initiated by ISDN BRI phones connected to the device. During an ongoing call, the BRI phone user can suspend the call by typically pressing the phone's "P" button or a sequence of keys (depending on the phone), and then on-hooking the handset. To resume the call, the phone user typically presses the same keys or button again and then off-hooks the phone. During the suspended state, the device plays a howler tone to the remote party. This service is also supported when instead of pressing the call park button(s), the phone cable is disconnected (suspending the call) and then reconnected again (resuming the call).

If the phone user does not resume the call within a user-defined interval (configured using the HeldTimeout parameter), the device releases the call.



Note: Only one call can be suspended per trunk. If another suspend request is received from a BRI phone while there is already a suspended call (even if done by another BRI phone connected to the same trunk), the device rejects this suspend request.

26.4 Consultation Feature

The device's Consultation feature allows you to place one number on hold and make a second call to another party.

- After holding a call (by pressing hook-flash), the holding party hears a dial tone and can then initiate a new call, which is called a Consultation call.
- While hearing a dial tone, or when dialing to the new destination (before dialing is complete), the user can retrieve the held call by pressing hook-flash.
- The held call can't be retrieved while ringback tone is heard.
- After the Consultation call is connected, the user can toggle between the held and active call by pressing the hook-flash key.



Note: The Consultation feature is applicable only to FXS interfaces.

26.5 Call Transfer

This section describes the device's support for call transfer types.

26.5.1 Consultation Call Transfer

The device supports Consultation Call Transfer using the SIP REFER message and Replaces header. The common method to perform a consultation transfer is described in the following example, which assumes three call parties:

- Party A = transferring
 - Party B = transferred
 - Party C = transferred to
1. A Calls B.
 2. B answers.
 3. A presses the hook-flash button and places B on-hold (party B hears a hold tone).
 4. A dials C.
 5. After A completes dialing C, A can perform the transfer by on-hooking the A phone.
 6. After the transfer is complete, B and C parties are engaged in a call.

The transfer can be initiated at any of the following stages of the call between A and C:

- Just after completing dialing C phone number - transfer from setup
- While hearing ringback – transfer from alert
- While speaking to C - transfer from active



Note: For FXS interfaces, the device can also handle call transfers using SIP INVITE and re-INVITE messages, instead of REFER messages. This is useful when communicating with SIP UAs that do not support the receipt of REFER messages. This feature is applicable to FXS interfaces. To enable this support, use the EnableCallTransferUsingReinvites parameter.

The device also supports attended (consultation) call transfer for BRI phones (user side) connected to the device and using the Euro ISDN protocol. BRI call transfer is according to ETSI TS 183 036, Section G.2 (Explicit Communication Transfer – ECT). Call transfer is enabled using the EnableTransfer and EnableHoldtoISDN parameters.

The Explicit Call Transfer (ECT, according to ETS-300-367, 368, 369) supplementary service is supported for BRI and PRI trunks. This service provides the served user who has two calls to ask the network to connect these two calls together and release its connection to both parties. The two calls can be incoming or outgoing calls. This service is similar to NI2 Two B-Channel Transfer (TBCT) Supplementary Service. The main difference is that in ECT one of the calls must be in HELD state. The ECT standard defines two methods - Implicit and Explicit. In implicit method, the two calls must be on the same trunk. BRI uses the implicit mechanism, and PRI the explicit mechanism.

26.5.2 Consultation Transfer for QSIG Path Replacement

The device can interwork consultation call transfer requests for ISDN QSIG-to-IP calls. When the device receives a request for a consultation call transfer from the PBX, the device sends a SIP REFER message with a Replaces header to the SIP UA to transfer it to another SIP UA. Once the two SIP UA parties are successfully connected, the device requests the PBX to disconnect the ISDN call, thereby freeing resources on the PBX.

For example, assume legacy PBX user "A" has two established calls connected through the device – one with remote SIP UA "B" and the other with SIP UA "C". In this scenario, user "A" initiates a consultation call transfer to connect "B" with "C". The device receives the consultation call transfer request from the PBX and then connects "B" with "C", by sending "B" a REFER message with a Replaces header (i.e., replace caller "A" with "C"). Upon receipt of a SIP NOTIFY 200 message in response to the REFER, the device sends a Q.931 Disconnect messages to the PBX, notifying the PBX that it can disconnect the ISDN calls (of user "A").

This feature is enabled by the QSIGPathReplacementMode parameter.

26.5.3 Blind Call Transfer

Blind call transfer is done (using SIP REFER messages) after a call is established between call parties A and B, and party A decides to immediately transfer the call to C without first speaking to C. The result of the transfer is a call between B and C (similar to consultation transfer, but skipping the consultation stage).

You can also use the ManipulateIP2PSTNReferTo parameter to manipulate the destination number according to the number received in the SIP Refer-To header. This is applicable to all types of blind transfers to the PSTN (e.g., TBCT, ECT, RLT, QSIG, FXO, and CAS). During blind transfer, the device initiates a new call to the PSTN and the destination number of this call can be manipulated if this parameter is enabled. The following is an example of such a blind transfer:

1. IP phone "A" calls PSTN phone "B", and the call is established.
2. "A" performs a blind transfer to PSTN phone "C". It does this as follows:
 - a. "A" sends a SIP REFER message (with the phone number of "C" in the Refer-To header) to the device.
 - b. The device sends a Q.931 Setup message to "C". This feature enables manipulating the called party number in this outgoing Setup message.

The manipulation is done as follows:

1. If you configure a value for the `xferPrefix` parameter, then this value (string) is added as a prefix to the number in the Refer-To header.
2. This called party number is then manipulated using the IP-to-Tel Destination Phone Number Manipulation table.
3. The source number of the transferred call is taken from the original call, according to its initial direction:
 - Tel-to-IP call: source number of the original call.
 - IP-to-Tel call: destination number of the original call.
 - If the `UseReferredByForCallingNumber` parameter is set to 1, the source number is taken from the SIP Referred-By header if included in the received SIP REFER message.

This source number can also be used as the value for the 'Source Prefix' field in the IP-to-Tel Destination Phone Number Manipulation table. The local IP address is used as the value for the 'Source IP Address' field.



Note: Manipulation using the `ManipulateIP2PSTNReferTo` parameter does not affect IP-to-Trunk Group routing rules.

26.6 Call Forward

For digital interfaces: The device supports Call Deflection (ETS-300-207-1) for Euro ISDN and QSIG (ETSI TS 102 393) for Network and User sides, which provides IP-ISDN interworking of call forwarding (call diversion) when the device receives a SIP 302 response.

Call forward performed by the SIP side: Upon receipt of a Facility message with Call Rerouting IE from the PSTN, the device initiates a SIP transfer process by sending a SIP 302 (including the Call Rerouting destination number) to the IP in response to the remote SIP entity's INVITE message. The device then responds with a Disconnect message to the PSTN side.

Call forward performed by the PSTN side: When the device sends the INVITE message to the remote SIP entity and receives a SIP 302 response, the device sends a Facility message with the same IE mentioned above to the PSTN, and waits for the PSTN side to disconnect the call. This is configured using the `CallReroutingMode`.

For analog interfaces: The following methods of call forwarding are supported:

- Immediate: incoming call is forwarded immediately and unconditionally.
- Busy: incoming call is forwarded if the endpoint is busy.
- No Reply: incoming call is forwarded if it isn't answered for a specified time.
- On Busy or No Reply: incoming call is forwarded if the port is busy or when calls are not answered after a specified time.
- Do Not Disturb: immediately reject incoming calls. Upon receiving a call for a Do Not Disturb, the 603 Decline SIP response code is sent.

Three forms of forwarding parties are available:

- Served party: party configured to forward the call (FXS device).
- Originating party: party that initiates the first call (FXS or FXO device).
- Diverted party: new destination of the forwarded call (FXS or FXO device).

The served party (FXS interface) can be configured through the Web interface (see Configuring Call Forward on page 397) or ini file to activate one of the call forward modes. These modes are configurable per endpoint.




Notes:

- When call forward is initiated, the device sends a SIP 302 response with a contact that contains the phone number from the forward table and its corresponding IP address from the routing table (or when a proxy is used, the proxy's IP address).
- For receiving call forward, the device handles SIP 3xx responses for redirecting calls with a new contact.

26.6.1 Call Forward Reminder Ring

The device supports the Call Forward Reminder Ring feature for FXS interfaces, whereby the device's FXS endpoint emits a short ring burst, only in **onhook** state, when a third-party Application Server (e.g., softswitch) forwards an incoming call to another destination. This is important in that it notifies (audibly) the FXS endpoint user that a call forwarding service is currently being performed.

Figure 26-2: Call Forward Reminder with Application Server



The device generates a Call Forward Reminder ring burst to the FXS endpoint each time it receives a SIP NOTIFY message with a “reminder ring” xml body. The NOTIFY request is sent from the Application Server to the device each time the Application Server forwards an incoming call. The service is cancelled when an UNSUBSCRIBE request is sent from the device, or when the Subscription time expires.

The reminder-ring tone can be defined by using the parameter CallForwardRingToneID, which points to a ring tone defined in the Call Progress Tone file.

The following parameters are used to configure this feature:

- EnableNRTSubscription
- ASSubscribeIPGroupID
- NRTSubscribeRetryTime
- CallForwardRingToneID

26.6.2 Call Forward Reminder (Off-Hook) Special Dial Tone

The device plays a special dial tone (stutter dial tone - Tone Type #15) to a specific FXS endpoint when the phone is off-hooked and when a third-party Application server (AS), e.g., a softswitch is used to forward calls intended for the endpoint, to another destination.

This is useful in that it reminds the FXS user of this service. This feature does not involve device subscription (SIP SUBSCRIBE) to the AS.

Activation/deactivation of the service is notified by the server. An unsolicited SIP NOTIFY request is sent from the AS to the device when the Call Forward service is activated or deactivated. Depending on this NOTIFY request, the device plays either the standard dial tone or the special dial tone for Call Forward.

For playing the special dial tone, the received SIP NOTIFY message must contain the following headers:

- **From and To:** contain the same information, indicating the specific endpoint
- **Event:** ua-profile
- **Content-Type:** "application/simservs+xml"
- Message body is the XML body and contains the "dial-tone-pattern" set to "special-condition-tone" (<ss:dial-tone-pattern>special-condition-tone</ss:dial-tone-pattern>), which is the special tone indication.

To cancel the special dial tone and playing the regular dial tone, the received SIP NOTIFY message must contain the following headers:

- **From and To:** contain the same information, indicating the specific endpoint
- **Event:** ua-profile
- **Content-Type:** "application/simservs+xml"
- Message body is the XML body containing the "dial-tone-pattern" set to "standard-condition-tone" (<ss:dial-tone-pattern>standard-condition-tone</ss:dial-tone-pattern>), which is the regular dial tone indication.

Therefore, the special dial tone is valid until another SIP NOTIFY is received that instructs otherwise (as described above).



Note: if the MWI service is active, the MWI dial tone overrides this special Call Forward dial tone.

26.6.3 Call Forward Reminder Dial Tone (Off-Hook) upon Spanish SIP Alert-Info

The device plays a special dial tone to FXS phones in off-hook state that are activated with the call forwarding service. The special dial tone is used as a result of the device receiving a SIP NOTIFY message from a third-party softswitch providing the call forwarding service with the following SIP Alert-Info header:

```
Alert-Info: <http://127.0.0.1/Tono-Espec-Invitacion>;lpi-
aviso=Desvio-Inmediato
```

This special tone is a stutter dial tone (Tone Type = 15), as defined in the CPT file.

The FXS phone user, connected to the device, activates the call forwarding service by dialing a special number (e.g., *21*xxxx) and as a result, the device sends a regular SIP INVITE message to the softswitch. The softswitch later notifies of the activation of the forwarding service by sending an unsolicited NOTIFY message with the Alert-Info header, as mentioned above.

When the call forwarding service is de-activated, for example, by dialing #21# and sending an INVITE with this number, the softswitch sends another SIP NOTIFY message with the following Alert-Info header:

```
Alert-Info: <http://127.0.0.1/ Tono-Normal-Invitacion>; Aviso =
Desvió-Inmediato
```

From this point on, the device plays a normal dial tone to the FXS phone when it goes off-hook.

26.6.4 BRI Call Forwarding

The device supports call forwarding (CF) services initiated by ISDN Basic BRI phones connected to it. Upon receipt of an ISDN Facility message for call forward from the BRI phone, the device sends a SIP INVITE to the softswitch with a user-defined code in the SIP To header, representing the reason for the call forward.

The codes for the call forward can be defined using the following parameters:

- SuppServCodeCFU - Call Forward Unconditional
- SuppServCodeCFUDeact - Call Forward Unconditional Deactivation
- SuppServCodeCFB - Call Forward on Busy
- SuppServCodeCFBDeact - Call Forward on Busy Deactivation
- SuppServCodeCFNR - Call Forward on No Reply
- SuppServCodeCFNRDeact - Call Forward on No Reply Deactivation



Note: These codes must be defined according to the settings of the softswitch (i.e., the softswitch must recognize them).

Below is an example of an INVITE message sent by the device indicating an unconditional call forward (“*72”) to extension number 100. This code is defined using the SuppServCodeCFU parameter.

```
INVITE sip:*72100@10.33.8.53;user=phone SIP/2.0
Via: SIP/2.0/UDP 10.33.2.5:5060;branch=z9hG4bKWDSUKUHWFEQSVUUVJGM
From: <sip:400@10.33.2.5;user=phone>;tag=DUOROSXSOYJLNBFRQTG
To: <sip:*72100@10.33.8.53;user=phone>
Call-ID: GMNOVQRRXUUCYCQSFQHS@10.33.2.5
CSeq: 1 INVITE
Contact: <sip:400@10.33.2.5:5060>
Supported: em,100rel,timer,replaces
Allow:
REGISTER,OPTIONS,INVITE,ACK,CANCEL,BYE,NOTIFY,PRACK,REFER,INFO,SUBSCRIBE
User-Agent: Sip Message Generator V1.0.0.5
User-to-User: 31323334;pd=4
Content-Type: application/sdp
Content-Length: 155
```

26.7 Call Waiting

The Call Waiting feature enables FXS devices to accept an additional (second) call on busy endpoints. If an incoming IP call is designated to a busy port, the called party hears a call waiting tone (several configurable short beeps) and (for Bellcore and ETSI Caller IDs) can view the Caller ID string of the incoming call. The calling party hears a call waiting ringback tone. The called party can accept the new call using hook-flash, and can toggle between the two calls.

➤ To enable call waiting:

1. Set the parameter EnableCallWaiting to 1.
2. Set the parameter EnableHold to 1.

3. Define the Call Waiting indication and call waiting ringback tones in the Call Progress Tones file. You can define up to four call waiting indication tones (refer to the FirstCallWaitingToneID parameter).
4. To configure the call waiting indication tone cadence, modify the following parameters: NumberOfWaitingIndications, WaitingBeepDuration and TimeBetweenWaitingIndications.
5. To configure a delay interval before a Call Waiting Indication is played to the currently busy port, use the parameter TimeBeforeWaitingIndication. This enables the caller to hang up before disturbing the called party with Call Waiting Indications. Applicable only to FXS modules.

Both the calling and called sides are supported by FXS interfaces; FXO interfaces support only the calling side.

To indicate Call Waiting, the device sends a 182 Call Queued response. The device identifies Call Waiting when a 182 Call Queued response is received.



Note: The Call Waiting feature is applicable only to FXS/FXO interfaces.

26.8 Message Waiting Indication

The device supports Message Waiting Indication (MWI) according to IETF RFC 3842, including SUBSCRIBE to an MWI server.

For analog interfaces: The FXS device can accept an MWI NOTIFY message that indicates waiting messages or that the MWI is cleared. Users are informed of these messages by a stutter dial tone. The stutter and confirmation tones are defined in the CPT file. If the MWI display is configured, the number of waiting messages is also displayed. If the MWI lamp is configured, the phone's lamp (on a phone that is equipped with an MWI lamp) is lit. The device can subscribe to the MWI server per port (usually used on FXS) or per device (used on FXO).



Notes:

- For more information on IP voice mail configuration, refer to the *IP Voice Mail CPE Configuration Guide*.
- For creating a CPT file using AudioCodes CPTWizard utility, refer to CPTWizard Utility User's Guide.

To configure MWI, use the following parameters:

- EnableMWI
- MWIServerIP, or MWISubscribeIPGroupID and ProxySet
- MWIAnalogLamp
- MWIDisplay
- StutterToneDuration
- EnableMWISubscription
- MWIExpirationTime
- SubscribeRetryTime
- SubscriptionMode
- CallerIDType (determines the standard for detection of MWI signals)

- ETSIVMWITypeOneStandard
- BellcoreVMWITypeOneStandard
- VoiceMailInterface
- EnableVMURI

The device supports the following MWI features for its digital PSTN interfaces:

- For BRI interfaces: This feature provides support for MWI on BRI phones connected to the device and using the Euro ISDN BRI variant. When this feature is activated and a voice mail message is recorded to the mail box of a BRI extension, the softswitch sends a notification to the device. In turn, the device notifies the BRI extension and a red light flashes on the BRI extension's phone. Once the voice message is retrieved, the MWI light on the BRI extension turns off. This feature is configured by setting the VoiceMailInterface parameter to 8 ("ETSI") and enabled by the EnableMWI parameter.
- Euro-ISDN MWI: The device supports Euro-ISDN MWI for IP-to-Tel calls. The device interworks SIP MWI NOTIFY messages to Euro-ISDN Facility information element (IE) MWI messages. This is supported by setting the VoiceMailInterface parameter to 8.
- QSIG MWI: The device also supports the interworking of QSIG MWI to IP (in addition to interworking of SIP MWI NOTIFY to QSIG Facility MWI messages). This provides interworking between an ISDN PBX with voicemail capabilities and a softswitch, which requires information on the number of messages waiting for a specific user. This support is configured using the TrunkGroupSettings_MWIInterrogationType parameter (in the Trunk Group Settings table), which determines the device's handling of MWI Interrogation messages. The process for sending the MWI status upon request from a softswitch is as follows:
 1. The softswitch sends a SIP SUBSCRIBE message to the device.
 2. The device responds by sending an empty SIP NOTIFY to the softswitch, and then sending an ISDN Setup message with Facility IE containing an MWI Interrogation request to the PBX.
 3. The PBX responds by sending to the device an ISDN Connect message containing Facility IE with an MWI Interrogation result, which includes the number of voice messages waiting for the specific user.
 4. The device sends another SIP NOTIFY to the softswitch, containing this MWI information.
 5. The SIP NOTIFY messages are sent to the IP Group defined by the NotificationIPGroupID parameter.

In addition, when a change in the status occurs (e.g., a new voice message is waiting or the user has retrieved a message from the voice mail), the PBX initiates an ISDN Setup message with Facility IE containing an MWI Activate request, which includes the new number of voice messages waiting for the user. The device forwards this information to the softswitch by sending a SIP NOTIFY.

Depending on the PBX support, the MWIInterrogationType parameter can be configured to handle these MWI Interrogation messages in different ways. For example, some PBXs support only the MWI Activate request (and not MWI Interrogation request). Some support both these requests. Therefore, the device can be configured to disable this feature, or enable it with one of the following support:

- Responds to MWI Activate requests from the PBX by sending SIP NOTIFY MWI messages (i.e., does not send MWI Interrogation messages).
- Send MWI Interrogation message, but don't use its result. Instead, wait for MWI Activate requests from the PBX.
- Send MWI Interrogation message, use its result, and use the MWI Activate requests.

26.9 Caller ID

This section describes the device's Caller ID support.



Note: The Caller ID feature is applicable only to FXS/FXO interfaces.

26.9.1 Caller ID Detection / Generation on the Tel Side

By default, generation and detection of Caller ID to the Tel side is disabled. To enable Caller ID, set the parameter `EnableCallerID` to 1. When the Caller ID service is enabled:

- For FXS: the Caller ID signal is sent to the device's port
- For FXO: the Caller ID signal is detected

The configuration for Caller ID is described below:

- Use the parameter `CallerIDType` to define the Caller ID standard. Note that the Caller ID standard that is used on the PBX or phone must match the standard defined in the device.
- Select the Bellcore caller ID sub standard using the parameter `BellcoreCallerIDTypeOneSubStandard`
- Select the ETSI FSK caller ID sub standard using the parameter `ETSICallerIDTypeOneSubStandard`
- Enable or disable (per port) the caller ID generation (for FXS) and detection (for FXO) using the 'Generate / Detect Caller ID to Tel' table (`EnableCallerID`). If a port isn't configured, its caller ID generation / detection are determined according to the global parameter `EnableCallerID`.
- `EnableCallerIDTypeTwo`: disables / enables the generation of Caller ID type 2 when the phone is off-hooked (used for call waiting).
- `RingsBeforeCallerID`: sets the number of rings before the device starts detection of caller ID (FXO only). By default, the device detects the caller ID signal between the first and second rings.
- `AnalogCallerIDTimingMode`: determines the time period when a caller ID signal is generated (FXS only). By default, the caller ID is generated between the first two rings.
- `PolarityReversalType`: some Caller ID signals use reversal polarity and/or wink signals. In these scenarios, it is recommended to set `PolarityReversalType` to 1 (Hard) (FXS only).
- The Caller ID interworking can be changed using the parameters `UseSourceNumberAsDisplayName` and `UseDisplayNameAsSourceNumber`.

26.9.2 Debugging a Caller ID Detection on FXO

The procedure below describes debugging caller ID detection in FXO interfaces.

➤ **To debug a Caller ID detection on an FXO interface:**

1. Verify that the parameter `EnableCallerID` is set to 1.
2. Verify that the caller ID standard (and substandard) of the device matches the standard of the PBX (using the parameters `CallerIDType`,

BellcoreCallerIDTypeOneSubStandard, and ETSICallerIDTypeOneSubStandard).

3. Define the number of rings before the device starts the detection of caller ID (using the parameter RingsBeforeCallerID).
4. Verify that the correct FXO coefficient type is selected (using the parameter CountryCoefficients), as the device is unable to recognize caller ID signals that are distorted.
5. Connect a phone to the analog line of the PBX (instead of to the device's FXO interface) and verify that it displays the caller ID.

If the above does not solve the problem, you need to record the caller ID signal (and send it to AudioCodes), as described below.

➤ **To record the caller ID signal using the debug recording mechanism:**

1. Access the FAE page (by appending "FAE" to the device's IP address in the Web browser's URL, for example, http://10.13.4.13/FAE).
2. Press the **Cmd Shell** link.
3. Enter the following commands:

```
dr
ait <IP address of PC to collect the debug traces sent from
the device>
AddChannelIdTrace ALL-WITH-PCM <port number, which starts from
0>
Start
```

4. Make a call to the FXO.
5. To stop the DR recording, at the CLI prompt, type **STOP**.

26.9.3 Caller ID on the IP Side

Caller ID is provided by the SIP From header containing the caller's name and "number", for example:

```
From: "John" <SIP:101@10.33.2.2>; tag=35dfsgasd45dg
```

If Caller ID is restricted (received from Tel or configured in the device), the From header is set to:

```
From: "anonymous" <anonymous@anonymous.invalid>; tag=35dfsgasd45dg
```

The P-Asserted (or P-Preferred) headers are used to present the originating party's caller ID even when the caller ID is restricted. These headers are used together with the Privacy header.

- If Caller ID is restricted:
 - The From header is set to "anonymous" <anonymous@anonymous.invalid>
 - The 'Privacy: id' header is included
 - The P-Asserted-Identity (or P-Preferred-Identity) header shows the caller ID
- If Caller ID is allowed:
 - The From header shows the caller ID
 - The 'Privacy: none' header is included
 - The P-Asserted-Identity (or P-Preferred-Identity) header shows the caller ID

The caller ID (and presentation) can also be displayed in the Calling Remote-Party-ID header.

The 'Caller Display Information' table (CallerDisplayInfo) is used for the following:

- **FXS interfaces** - to define the caller ID (per port) that is sent to IP.
- **FXO interfaces** - to define the caller ID (per port) that is sent to IP if caller ID isn't detected on the Tel side, or when EnableCallerID = 0.

- **FXS and FXO interfaces** - to determine the presentation of the caller ID (allowed or restricted).
- **To maintain backward compatibility** - when the strings 'Private' or 'Anonymous' are set in the Caller ID/Name field, the caller ID is restricted and the value in the Presentation field is ignored.

The value of the 'Presentation' field that is defined in the 'Caller Display Information' table can be overridden by configuring the 'Presentation' parameter in the 'Tel to IP Source Number Manipulation' table. Therefore, this table can be used to set the presentation for specific calls according to Source / Destination prefixes.

The caller ID can be restricted/allowed (per port) using keypad features KeyCLIR and KeyCLIRDeact (FXS only).

AssertedIdMode defines the header that is used (in the generated INVITE request) to deliver the caller ID (P-Asserted-Identity or P-Preferred-Identity). Use the parameter UseTelURIForAssertedID to determine the format of the URI in these headers (sip: or tel:).

The parameter EnableRPIheader enables Remote-Party-ID (RPI) headers for calling and called numbers for Tel-to-IP calls.

26.10 Three-Way Conferencing

The device supports three-way conference calls. These conference calls can also occur simultaneously. The device supports the following conference modes (configured by the parameter 3WayConferenceMode):

- **Conferencing managed by an external, AudioCodes Conference (media) server:** The Conference-initiating INVITE sent by the device uses the ConferenceID concatenated with a unique identifier as the Request-URI. This same Request-URI is set as the Refer-To header value in the REFER messages that are sent to the two remote parties. For this mode, the 3WayConferenceMode parameter is set to 0 (default.)
- **Conferencing managed by an external, third-party Conference (media) server:** The Conference-initiating INVITE sent by the device uses only the ConferenceID as the Request-URI. The Conference server sets the Contact header of the 200 OK response to the actual unique identifier (Conference URI) to be used by the participants. This Conference URI is included (by the device) in the Refer-To header value in the REFER messages sent by the device to the remote parties. The remote parties join the conference by sending INVITE messages to the Conference server using this conference URI. For this mode, the 3WayConferenceMode parameter is set to 1.
- **Local, on-board conferencing:** The conference is established on the device without the need for an external Conference server. This feature includes local mixing and transcoding of the 3-Way Call legs on the device, and even allowing multi-codec conference calls. The number of simultaneous, on-board conferences can be limited using the parameter MaxInBoardConferenceCalls. The device sets up the call conference using its IP media channels. These channels are obtained from the IP media module (i.e., MPM module). Note that the MPM module(s) must be installed to support three-way conferencing. The device supports up to five simultaneous, on-board, three-way conference calls. For this mode, the 3WayConferenceMode parameter is set to 2.

For n-way conferencing, the device can house up to three MPM modules. DSP resource allocation is as follows:

- MPM module in Slot #6 enables the conferencing feature and provides 20 channels, thereby supporting up to 6 three-way conferences.
- MPM module in Slot #4 provides 40 channels.
- MPM module in Slot #5 provides 40 channels.

Therefore, when the MPM modules are installed in chassis slots #4, #5, and #6, the device supports up to 100 DSP resources, thereby supporting up to 100 conference participants, which is 33 three-way conferences.



Notes:

- If the device is installed with all three MPM modules, no other telephony interface module can be installed in the device.
- Three-way conferencing using an external conference server is supported only by FXS interfaces.
- The on-board, three-way conference mode is not supported by Mediant 600.
- Instead of using the flash-hook button to establish a three-way conference call, you can dial a user-defined hook-flash code (e.g., "*1"), configured by the HookFlashCode parameter.
- Three-way conferencing is applicable only to FXS and BRI interfaces. Three-way conferencing support for the BRI phones connected to the device complies with ETS 300 185.

The following example demonstrates three-way conferencing using the device's local, on-board conferencing feature. In this example, telephone "A" connected to the device establishes a three-way conference call with two remote IP phones, "B" and "C":

1. A establishes a regular call with B.
2. A places B on hold, by pressing the telephone's flash-hook button.
3. A hears a dial tone and then makes a call to C.
4. C answers the call.
5. A establishes a three-way conference call with B and C, by pressing the flash-hook button and digit 3.

To configure this local, on-board three-way conferencing:

1. Open the Supplementary Services page.
2. Set 'Enable 3-Way Conference' to **Enable** (Enable3WayConference = 1).
3. Set 'Three Way Conference Mode' to **On Board** (3WayConferenceMode = 2).
4. Set 'Flash Keys Sequence Style' to **Sequence 1** or **Sequence 2** (FlashKeysSequenceStyle = 1 or 2).

26.11 Emergency E911 Phone Number Services


This section describes the device's support for emergency phone number services. The device supports the North American emergency telephone number system known as Enhanced 911 (E911), according to the TR-TSY-000350 and Bellcore's GR-350-Jun2003 standards. The E911 emergency system automatically associates a physical address with the calling party's telephone number, and routes the call to the most appropriate (closest) Public Safety Answering Point (PSAP), allowing the PSAP to quickly dispatch emergency response (e.g., police) to the caller's location.

Typically, the dialed emergency number is routed to the appropriate PSAP by the telephone company's switch, known as a 911 Selective Router (or E911 tandem switch). If the PSAP receives calls from the telephone company on old-style digital trunks, they are specially formatted Multi-Frequency (MF) trunks that pass only the calling party's number (known as Automatic Number Identification - ANI). Once the PSAP receives the call, it searches for the physical address that is associated with the calling party's telephone number (in the Automatic Location Identification database - ALI).

26.11.1 FXS Device Emulating PSAP using DID Loop-Start Lines

The device's FXS interface can be configured to emulate PSAP (using DID loop start lines), according to the Telcordia GR-350-CORE specification.

Figure 26-3: FXS Device Emulating PSAP using DID Loop-Start Lines



The call flow of an E911 call to the PSAP is as follows:

1. The E911 tandem switch seizes the line.
2. The FXS device detects the line seize, and then generates a wink signal (nominal 250 msec). The wink can be delayed by configuring the parameter `DelayBeforeDIDWink` to 200 (for 200 msec or a higher value).
3. The switch detects the wink and then sends the MF Spill digits with ANI and (optional) Pseudo-ANI (P ANI).
4. The FXS device collects the MF digits, and then sends a SIP INVITE message to the PSAP with all collected MF digits in the SIP From header as one string.
5. The FXS device generates a mid-call wink signal (two subsequent polarity reversals) toward the E911 tandem switch upon either detection of an RFC 2833 "hookflash" telephony event, or if a SIP INFO message with a "hooflash" body is received from the PSAP (see the example below). The duration of this "flashhook" wink signal is configured using the parameter `FlashHookPeriod` (usually 500 msec). Usually the wink signal is followed by DTMF digits sent by PSAP to perform call transfer. Another way to perform the call transfer is to use SIP REFER messages, as described below.
6. The FXS device supports call transfer initiated by the PSAP. If it receives a SIP REFER message with the Refer-To URI host part containing an IP address that is equal to the device's IP address, the FXS device generates a 500-msec wink signal (double polarity reversals), and then (after a user-defined interval configured by the parameter `WaitForDialTime`), plays DTMF digits according to the transfer number received in the SIP Refer-To header URI userpart.
7. When the call is answered by the PSAP operator, the PSAP sends a SIP 200 OK to the FXS device, and the FXS device then generates a polarity reversal signal to the E911 switch.

8. After the call is disconnected by the PSAP, the PSAP sends a SIP BYE to the FXS device, and the FXS device reverses the polarity of the line toward the tandem switch.

The following parameters need to be configured:

- EnableDIDWink = 1
- EnableReversalPolarity = 1
- PolarityReversalType = 1
- FlashHookPeriod = 500 (for 500 msec "hookflash" mid-call Wink)
- WinkTime = 250 (for 250 msec signalling Wink generated by the FXS device after it detects the line seizure)
- EnableTransfer = 1 (for call transfer)
- LineTransferMode = 1 (for call transfer)
- WaitforDialTime = 1000 (for call transfer)
- SwapTEI2IPCcalled&CallingNumbers = 1
- DTMFDetectorEnable = 0
- MFR1DetectorEnable = 1
- DelayBeforeDIDWink = 200 (for 200 msec) - can be configured in the range from 0 (default) to 1000.



Note: Modification of the WinkTime and FlashHookPeriod parameters require a device reset.

The outgoing SIP INVITE message contains the following headers:

```
INVITE sip:Line@DomainName
From: <sip:*81977820#@sipgw>;tag=1c143
To: <sip:Line@DomainName>
```

Where:

- *Line* = as configured in the Endpoint Phone Number Table
- *SipGtw* = configured by the SIPGatewayName parameter
- *From* header/user part = calling party number as received from the MF spill

The ANI and the pseudo-ANI numbers are sent to the PSAP either in the From and/or P-AssertedID SIP header.

Typically, the MF spills are sent from the E911 tandem switch to the PSAP, as shown in the table below:

Dialed MF Digits Sent to PSAP

Digits of Calling Number	Dialed MF Digits
8 digits "nnnnnnnn" (ANI)	"KPnnnnnnnnST"
12 digits "nnnnnnnnnnnn" (ANI)	"KPnnnnnnnnnnnnSTP"
12 digits ANI and 10 digits PANI	"KPnnnnnnnnnnnnSTKPmmmmmmmmmmST"
two digits "nn"	"KPnnSTP"

The MF KP, ST, and STP digits are mapped as follows:

- * for KP
- # for ST

- B for STP

For example, if ANI and PANI are received, the SIP INVITE contains the following From header:

```
From: <sip:*nnnnnnnnnnn#*mmmmmmmmmm#@10.2.3.4>;tag=1c14
```



Note: It is possible to remove the * and # characters, using the device's number manipulation rules.

If the device receives the SIP INFO message below, it then generates a "hookflash" mid-call Wink signal:

```
INFO sip:4505656002@192.168.13.40:5060 SIP/2.0
Via: SIP/2.0/UDP 192.168.13.2:5060
From: portlvegal <sip:06@192.168.13.2:5060>
To: <sip:4505656002@192.168.13.40:5060>;tag=132878796-1040067870294
Call-ID: 0010-0016-D69A7DA8-1@192.168.13.2
CSeq:2 INFO
Content-Type: application/broadsoft
Content-Length: 17
event flashhook
```

26.11.2 FXO Device Interworking SIP E911 Calls from Service Provider's IP Network to PSAP DID Lines

The device's FXO interface can interwork SIP emergency E911 calls from the Service Provider's IP network to the analog PSAP DID lines. The standards that define this interface include TR-TSY-000350 or Bellcore's GR-350-Jun2003. This protocol defines signaling between the E911 tandem switch (E911 Selective Router) and the PSAP, using analog loop-start lines. The FXO device can be implemented instead of an E911 switch, by connecting directly to the PSAP DID loop-start lines.

Figure 26-4: FXO Device Interfacing between E911 Switch and PSAP



When an IP phone subscriber dials 911, the device receives the SIP INVITE message and makes a call to the PSAP as follows:

1. The FXO device seizes the line.
2. PSAP sends a Wink signal (250 msec) to the device.
3. Upon receipt of the Wink signal, the device dials MF digits after a user-defined time (WaitForDialTime) containing the caller's ID (ANI) obtained from the SIP headers From or P-Asserted-Identity.
4. When the PSAP operator answers the call, the PSAP sends a polarity reversal to the device, and the device then sends a SIP 200 OK to the IP side.
5. After the PSAP operator disconnects the call, the PSAP reverses the polarity of the line, causing the device to send a SIP BYE to the IP side.
6. If, during active call state, the device receives a Wink signal (typically of 500 msec) from the PSAP, the device generates a SIP INFO message that includes a "hookflash" body, or sends RFC 2833 hookflash Telephony event (according to the HookFlashOption parameter).
7. Following the "hookflash" Wink signal, the PSAP sends DTMF digits. These digits are detected by the device and forwarded to the IP, using RFC 2833 telephony events (or inband, depending on the device's configuration). Typically, this Wink signal followed by the DTMF digits initiates a call transfer.

For supporting the E911 service, used the following configuration parameter settings:

- Enable911PSAP = 1 (also forces the EnableDIDWink and EnableReversalPolarity)
- HookFlashOption = 1 (generates the SIP INFO hookflash message) or 4 for RFC 2833 telephony event
- WinkTime = 700 (defines detection window of 50 to 750 msec for detection of both winks - 250 msec wink sent by the PSAP for starting the device's dialing; 500 msec wink during the call)
- IsTwoStageDial = 0

- EnableHold = 0
- EnableTransfer = 0
 - Use RFC 2833 DTMF relay:
 - ◆ RxDTMFOption = 3
 - ◆ TxDTMFOption = 4
 - ◆ RFC2833PayloadType = 101
- TimeToSampleAnalogLineVoltage = 100
- WaitForDialTime = 1000 (default is 1 sec)
- SetDefaultLinePolarityState = 0 (you need to verify that the RJ-11 two-wire cable is connected without crossing, Tip to Tip, Ring to Ring. Typically, the Tip line is positive compared to the Ring line.)



Note: If the two-wire cable is crossed, the SetDefaultLinePolarityState parameter must be set to 1.

The device expects to receive the ANI number in the From and/or P-Asserted-Identity SIP header. If the pseudo-ANI number exists, it should be sent as the display name in these headers.

Dialed Number by Device Depending on Calling Number

Digits of Calling Number (ANI)	Digits of Displayed Number	Number Dialed MF Digits
8 "nnnnnnnn"	-	MF dialed "KPnnnnnnnnST"
12 "nnnnnnnnnnnn"	None	"KPnnnnnnnnnnnnSTP"
12 "nnnnnnnnnnnn"	10 "mmmmmmmmmm" (pANI)	"KPnnnnnnnnnnnnSTKPmmmmmmmmmmS T"
2 "nn"	None	"KPnnSTP"
1 "n"	-	MF dialed "KPnST" For example: "From: <sip:8>@xyz.com>" generates device MF spill of KP 8 ST

Table notes:

- For all other cases, a SIP 484 response is sent.
- KP is for .
- ST is for #.
- STP is for B.

The MF duration of all digits, except for the KP digit is 60 msec. The MF duration of the KP digit is 120 msec. The gap duration is 60 msec between any two MF digits.


Notes:

- Manipulation rules can be configured for the calling (ANI) and called number (but not on the "display" string), for example, to strip 00 from the ANI "00INXXXXXX".
- The called number, received as userpart of the Request URI ("301" in the example below), can be used to route incoming SIP calls to FXO specific ports, using the TrunkGroup and PSTNPrefix parameters.
- When the PSAP party off-hooks and then immediately on-hooks (i.e., the device detects wink), the device releases the call sending SIP response "403 Forbidden" and the release reason 21 (i.e., call rejected) "Reason: Q.850 ;cause=21" is sent. Using the cause mapping parameter, it is possible to change the 403 to any other SIP reason, for example, to 603.
- Sometimes a wink signal sent immediately after the FXO device seizes the line is not detected. To overcome this problem, configure the parameter TimeToSampleAnalogLineVoltage to 100 (instead of 1000 msec, which is the default value). The wink is then detected only after this timeout + 50 msec (minimum 150 msec).

Below are two examples for a) INVITE messages and b) INFO messages generated by hook-flash.

- **Example A:** INVITE message with ANI = 333333444444 and pseudo-ANI = 0123456789:

```

INVITE sip:301@10.33.37.79;user=phone SIP/2.0
Via: SIP/2.0/UDP 10.33.37.78;branch=z9hG4bKac771627168
Max-Forwards: 70
From: "0123456789"
<sip:333333444444@audiocodes.com>;tag=1c771623824
To: <sip:301@10.33.37.79;user=phone>
Call-ID: 77162335841200014153@10.33.37.78
CSeq: 1 INVITE
Contact: <sip:101@10.33.37.78>
Supported: em,100rel,timer,replaces,path
Allow:
REGISTER,OPTIONS,INVITE,ACK,CANCEL,BYE,NOTIFY,PRACK,REFER,INFO
,SUBSCRIBE,UPDATE
User-Agent: Audiocodes-Sip-Gateway-FXO/v.6.00A.020.077
Privacy: none
P-Asserted-Identity: "0123456789"
<sip:333333444444@audiocodes.com>
Content-Type: application/sdp
Content-Length: 253
v=0
o=AudiocodesGW 771609035 771608915 IN IP4 10.33.37.78
s=Phone-Call
c=IN IP4 10.33.37.78
t=0 0
m=audio 4000 RTP/AVP 8 0 101
a=rtpmap:8 pcma/8000
a=rtpmap:0 pcmu/8000
a=rtpmap:101 telephone-event/8000
a=fmtp:101 0-15
a=ptime:20
a=sendrecv
    
```

- **Example B:** The detection of a Wink signal generates the following SIP INFO message:

```

INFO sip:4505656002@192.168.13.40:5060 SIP/2.0
Via: SIP/2.0/UDP 192.168.13.2:5060
From: portlvegal <sip:06@192.168.13.2:5060>
To: <sip:4505656002@192.168.13.40:5060>;tag=132878796-1040067870294
Call-ID: 0010-0016-D69A7DA8-1@192.168.13.2
CSeq:2 INFO
Content-Type: application/broadsoft
Content-Length: 17
event flashhook

```

26.11.3 Pre-empting Existing Calls for E911 IP-to-Tel Calls

If the device receives an E911 call from the IP network destined to the Tel, and there are unavailable channels (e.g., all busy), the device terminates one of the calls (arbitrary) and then sends the E911 call to that channel. The preemption is done only on a channel pertaining to the same Trunk Group for which the E911 call was initially destined and if the channel select mode (configured by the ChannelSelectMode parameter) is set to a value other than "By Dest Number" (0).

The preemption is done only if the incoming IP-to-Tel call is identified as an emergency call. The device identifies emergency calls by one of the following:

- The destination number of the IP call matches one of the numbers defined by the EmergencyNumbers parameter. For E911, you must defined this parameter with the value "911".
- The Priority header of the incoming SIP INVITE message contains the "emergency" value.

Emergency pre-emption of calls can be enabled for all calls, using the global parameter CallPriorityMode, or for specific calls using the Tel Profile parameter CallPriorityMode.

Notes:

- For Trunk Groups configured with call preemption, all must be configured to MLPP [1] or all configured to Emergency [2]. In other words, you cannot set some trunks to [1] and some to [2].
- The global parameter must be set to the same value as that of the Tel Profile parameter; otherwise, the Tel Profile parameter is not applied.
- If you configure call preemption using the global parameter and a new Tel Profile is subsequently added, the TelProfile_CallPriorityMode parameter automatically acquires the same setting as well.
- This feature is applicable to FXO, CAS and ISDN interfaces.
- For FXO interfaces, the preemption is done only on existing IP-to-Tel calls. In other words, if all the current FXO channels are busy with calls that were answered by the FXO device (i.e., Tel-to-IP calls), new incoming emergency IP-to-Tel calls are rejected.



26.11.4 Enhanced 9-1-1 Support for Lync Server 2010

The Enhanced 9-1-1 (E9-1-1) service is becoming the mandatory emergency service required in many countries around the world. The E9-1-1 service, based on its predecessor 911, enables emergency operators to pinpoint the location (granular location) of callers who dial the 9-1-1 emergency telephone number.

Today, most enterprises implement an IP-based infrastructure providing a VoIP network with fixed and nomadic users, allowing connectivity anywhere with any device. This,

together with an often deployed multi-line telephone system (MLTS) poses a challenge for E9-1-1 due to the difficulty in accurately locating the E9-1-1 caller.


This section describes the E9-1-1 solution provided by Microsoft Lync Server 2010 (hereafter referred to as *Lync Server 2010*), and the deployed AudioCodes ELIN Gateway which provides the ISDN (or CAMA) connectivity to the PSTN-based E9-1-1 emergency providers. This section also describes the configuration of AudioCodes ELIN Gateway for interoperating between the Lync Server 2010 environment and the E9-1-1 emergency provider.

26.11.4.1 About E9-1-1 Services

E9-1-1 is a national emergency service for many countries, enabling E9-1-1 operators to automatically identify the geographical location and phone number of a 911 caller. In E9-1-1, the 911 caller is routed to the nearest E9-1-1 operator, termed *public safety answering point* (PSAP) based on the location of the caller. Automatic identification of the caller's location and phone number reduces the time spent on requesting this information from the 911 caller. Therefore, the E9-1-1 service enables the PSAP to quickly dispatch the relevant emergency services (for example, fire department or police) to the caller's location. Even if the call prematurely disconnects, the operator has sufficient information to call back the 911 caller.

The figure below illustrates the routing of an E9-1-1 call to the PSAP:

Figure 26-5: Call Flow of E9-1-1 to PSTN-Based Emergency Services Provider



1. The VoIP user dials 9-1-1.
2. The call is eventually sent to the PSTN through a PSTN Gateway.
3. The PSTN identifies the call is an emergency call and sends it to an E9-1-1 Selective Router in the Emergency Services provider's network.
4. The E9-1-1 Selective Router determines the geographical location of the caller by requesting this information from an Automatic Location Identification (ALI) database based on the phone number or Automatic Number Identifier (ANI) of the 911 caller. Exact location information is also supplied by the Master Street Address Guide (MSAG) database, which is a companion database to the ALI database. Phone companies and public safety agencies collaborate beforehand to create master maps that match phone numbers, addresses and cross streets to their corresponding PSAP. This MSAG is the official record of valid streets (with exact spelling), street number

ranges, and other address elements with which the service providers are required to update their ALI databases.

5. The E9-1-1 Selective Router sends the call to the appropriate PSAP based on the retrieved location information from the ALI.
6. The PSAP operator dispatches the relevant emergency services to the E9-1-1 caller.

26.11.4.2 Microsoft Lync Server 2010 and E9-1-1


Microsoft Lync Server 2010 enables Enterprise voice users to access its unified communications platform from virtually anywhere and through many different devices. This, together with a deployed MLTS, poses a challenge for E9-1-1 due to the difficulty in accurately locating the E9-1-1 caller. However, Lync Server 2010 offers an innovative solution to solving Enterprises E9-1-1 location problems.

26.11.4.2.1 Gathering Location Information of Lync 2010 Clients for 911 Calls

When a Microsoft® Lync™ 2010 client (hereafter referred to as *Lync 2010 client*) is enabled for E9-1-1, the location data that is stored on the client is sent during an emergency call. This stored location information is acquired automatically from the Microsoft Location Information Server (LIS). The LIS stores the location of each network element in the enterprise. Immediately after the Lync 2010 client registration process or when the operating system detects a network connection change, each Lync 2010 client submits a request to the LIS for a location. If the LIS is able to resolve a location address for the client request, it returns the address in a location response. Each client then caches this information. When the Lync 2010 client dials 9-1-1, this location information is then included as part of the emergency call and used by the Emergency Services provider to route the call to the correct PSAP.

The gathering of location information in the Lync Server 2010 network is illustrated in the figure below:

Figure 26-6: Microsoft Lync Server 2010 Client Acquiring Location Information



1. The Administrator provisions the LIS database with the location of each network element in the Enterprise. The location is a civic address, which can include contextual in-building and company information. In other words, it associates a specific network entity (for example, a WAP) with a physical location in the Enterprise (for example, Floor 2, Wing A, and the Enterprise's street address). For more information on populating the LIS database, see 'Adding ELINs to the Location

Information Server' on page 373.

2. The Administrator validates addresses with the Emergency Services provider's MSAG –a companion database to the ALI database. This ensures that the civic address is valid as an official address (e.g., correct address spelling).
3. The Lync 2010 client initiates a location request to the LIS under the following circumstances:
 - Immediately after startup and registering the user with Lync Server 2010
 - Approximately every four hours after initial registration
 - Whenever a network connection change is detected (such as roaming to a new WAP)

The Lync 2010 client includes in its location request the following known network connectivity information:

- Always included:
 - ◆ IPv4 subnet
 - ◆ Media Access Control (MAC) address
- Depends on network connectivity:
 - ◆ Wireless access point (WAP) Basic Service Set Identifier (BSSID)
 - ◆ Link Layer Discovery Protocol-Media Endpoint Discovery (LLDP-MED) chassis ID and port ID

For a Lync 2010 client that moves inside the corporate network such as a soft phone on a laptop that connects wirelessly to the corporate network, Lync Server 2010 can determine which subnet the phone belongs to or which WAP / SSID is currently serving the soft-client.

4. The LIS queries the published locations for a location and if a match is found, returns the location information to the client. The matching order is as follows:
 - WAP BSSID
 - LLDP switch / port
 - LLDP switch
 - Subnet
 - MAC address

This logic ensures that for any client that is connected by a wireless connection, a match is first attempted based on the hardware address of its connected access point. The logic is for the match to be based on the most detailed location. The subnet generally provides the least detail. If no match is found in the LIS for WAP BSSID, LLDP switch / port, LLDP switch, or subnet, the LIS proxies the MAC address to an integrated Simple Network Management Protocol (SNMP) scanning application. Using SNMP may benefit some organizations for the following reasons:

- LLDP is not supported by Lync Server 2010 so this provides a mechanism for soft phones to acquire detailed location information.
- Installed Layer-2 switches may not support LLDP.

If there is no match and the LIS cannot determine the location, the user may be prompted to manually enter the location. For example, the client may be located in an undefined subnet, at home, in a coffee shop or anywhere else outside the network. When a user manually provides a location, the location is mapped based on the MAC address of the default gateway of the client's network and stored on the client. When the client returns to any previously stored location, the client is automatically set to that location. A user can also manually select any location stored in the local users table and manage existing entries.

26.11.4.2.2 Adding ELINs to the Location Information Server

As mentioned in the previous section, the Administrator needs to populate the Location Information Server (LIS) database with a network wire map, which maps the Enterprise's network elements to civic addresses. Once done, it can automatically locate clients within a network. You can add addresses individually to the LIS or in a batch using a comma-separated value (CSV) file containing the column formats listed in the table below.

Columns in the LIS Database

Network Element	Columns
Wireless access point	<BSSID>,<Description>,<Location>,< CompanyName >,<HouseNumber>,<HouseNumberSuffix>,<PreDirectional>,...<StreetName>,<StreetSuffix>,<PostDirectional>,<City>,<State>,<PostalCode>,<Country>
Subnet	<Subnet>,<Description>,<Location>,<CompanyName>,<HouseNumber>,<HouseNumberSuffix>,<PreDirectional>,...<StreetName>,<StreetSuffix>,<PostDirectional>,<City>,<State>,<PostalCode>,<Country>
Port	<ChassisID>,<PortIDSubType>,<PortID>,<Description>,<Location>,<CompanyName>,<HouseNumber>,<HouseNumberSuffix>,...<PreDirectional>,<StreetName>,<StreetSuffix>,<PostDirectional>,<City>,<State>,<PostalCode>,<Country>
Switch	<ChassisID>,<Description>,<Location>,<CompanyName>,<HouseNumber>,<HouseNumberSuffix>,<PreDirectional>,...<StreetName>,<StreetSuffix>,<PostDirectional>,<City>,<State>,<PostalCode>,<Country>

For the ELIN number to be included in the SIP INVITE (XML-based PIDF-LO message) sent by the Mediation Server to the ELIN Gateway, the Administrator must add the ELIN number to the <CompanyName> column (shown in the table above in **bold** typeface). As the ELIN Gateway supports up to five ELINs per PIDF-LO, the <CompanyName> column can be populated with up to this number of ELINs, each separated by a semicolon. The digits of each ELIN can be separated by hyphens (xxx-xxx-xxx) or they can be adjacent (xxxxxxxxx).

When the ELIN Gateway receives the SIP INVITE, it extracts the ELINs from the NAM field in the PIDF-LO (e.g., <ca:NAM>1111-222-333; 1234567890 </ca:NAM>), which corresponds to the <CompanyName> column of the LIS.

If you do not populate the location database, and the Lync Server 2010 location policy, Location Required is set to **Yes** or **Disclaimer**, the user will be prompted to enter a location manually.

26.11.4.2.3 Passing Location Information to the PSTN Emergency Provider

When a Lync 2010 client, enabled for E9-1-1 emergency services, dials 9-1-1, the location data and callback information stored on the client is sent with the call through the Mediation Server to a PSTN-based Emergency Services provider. The Emergency Services provider then routes the call to the nearest and most appropriate PSAP based on the location information contained within the call.


Lync Server 2010 passes the location information of the Lync 2010 client in an IETF-standard format - Presence Information Data Format - Location Object (PIDF-LO)—in a SIP INVITE message. However, this content cannot be sent on the PSTN network using ISDN PRI due to protocol limitations. To overcome this, Enterprises using PSTN Gateways can divide their office space into Emergency Response Locations (ERLs) and assign a dedicated Emergency Location Identification Number (ELIN) to each ERL (or zone). When Lync Server 2010 sends a SIP INVITE message with the PIDF-LO to the PSTN Gateway, it

can parse the content and translate the calling number to an appropriate ELIN. The PSTN Gateway then sends the call to the PSTN with the ELIN number as the calling number. This ELIN number is sent to the Emergency Services provider, which sends it on to the appropriate PSAP according to the ELIN address match in the ALI database lookup.

The ERL defines a specific location at a street address, for example, the floor number of the building at that address. The geographical size of an ERL is according to local or national regulations (for example, less than 7000 square feet per ERL). Typically, you would have an ERL for each floor of the building. The ELIN is used as the phone number for 911 callers within this ERL.

The figure below illustrates the use of ERLs and ELINs, with an E9-1-1 call from floor 2 at the branch office:

Figure 26-7: Implementing ERLs and ELINs for E9-1-1 in Lync Server 2010



The table below shows an example of designating ERLs to physical areas (floors) in a building and associating each ERL with a unique ELIN.

Designating ERLs and Assigning to ELINs

ERL Number	Physical Area	IP Address	ELIN
1	Floor 1	10.13.124.xxx	503 972-4410
2	Floor 2	10.15.xxx.xxx	503 972-4411
3	Floor 3	10.18.xxx.xxx	503 972-4412


In the table above, a unique IP subnet is associated per ERL. This is useful if you implement different subnets between floors. Therefore, IP phones, for example, on a specific floor are in the same subnet and therefore, use the same ELIN when dialing 9-1-1.

26.11.4.3 AudioCodes ELIN Gateway for Lync Server 2010 E9-1-1 Calls to PSTN

The Microsoft Mediation Server sends the location information of the E9-1-1 caller in the XML-based PIDF-LO body contained in the SIP INVITE message. However, this content cannot be sent on the PSTN network using ISDN PRI due to protocol limitations. To solve this issue, Lync Server 2010 requires a PSTN Gateway (*ELIN Gateway*) to send the E9-1-1 call to the PSTN. When Lync Server 2010 sends the PIDF-LO to the PSTN Gateway, it parses the content and translates the calling number to an appropriate ELIN. This ensures that the call is routed to an appropriate PSAP, based on ELIN-address match lookup in the Emergency Services provider's ALI database.

The figure below illustrates an AudioCodes ELIN Gateway deployed in the Lync Server 2010 environment for handling E9-1-1 calls between the Enterprise and the PSTN.

Figure 26-8: AudioCodes ELIN Gateway for E9-1-1 in Lync Server 2010 Environment



26.11.4.3.1 Detecting and Handling E9-1-1 Calls

The ELIN Gateway identifies E9-1-1 calls and translates their incoming E9-1-1 calling numbers into ELIN numbers, sent toward the PSAP. The ELIN Gateway handles the received E9-1-1 calls as follows:

1. The ELIN Gateway identifies E9-1-1 calls if the incoming SIP INVITE message contains a PIDF-LO XML message body. This is indicated in the SIP *Content-Type* header, as shown below:

```
Content-Type: application/pidf+xml
```

2. The ELIN Gateway extracts the ELIN number(s) from the "NAM" field in the XML message. The "NAM" field corresponds to the <CompanyName> column in the Location Information Server (LIS). The ELIN Gateway supports up to five ELIN numbers per XML message. The ELINs are separated by a semicolon. The digits of the ELIN number can be separated by hyphens (xxx-xxx-xxx) or they can be adjacent (xxxxxxxx), as shown below:

```
<ca:NAM>1111-222-333; 1234567890 </ca:NAM>
```

3. The ELIN Gateway saves the *From* header value of the SIP INVITE message in its ELIN database table (**Call From** column). The ELIN table is used for PSAP callback,

as discussed later in 'PSAP Callback to Lync 2010 Clients for Dropped E9-1-1 Calls' on page 378. The ELIN table also stores the following information:

- **ELIN:** ELIN number
- **Time:** Time at which the original E9-1-1 call was terminated with the PSAP
- **Count:** Number of E9-1-1 calls currently using this ELIN

An example of the ELIN database table is shown below:

ELIN	Time	Count	Index	Call From
4257275678	22:11:52	0	2	4258359333
4257275999	22:11:57	0	3	4258359444
4257275615	22:12:03	0	0	4258359555
4257275616	22:11:45	0	1	4258359777

The ELIN table stores this information for a user-defined period (see 'Configuring the E9-1-1 Callback Timeout' on page 379), starting from when the E9-1-1 call, established with the PSAP, terminates. After this time expires, the table entry with its ELIN is disregarded and no longer used (for PSAP callback). Therefore, table entries of only the most recently terminated E9-1-1 callers are considered in the ELIN table.

The maximum entries in the ELIN table depend on the AudioCodes ELIN Gateway deployed in the Lync Server 2010 environment:

- **Mediant 1000 Series and Mediant 2000:** 100 entries
- **Mediant 3000:** 300 entries

4. The ELIN Gateway uses the ELIN number as the E9-1-1 calling number and sends it in the ISDN Setup message (as an ANI / Calling Party Number) to the PSTN.

An example of a SIP INVITE message received from an E9-1-1 caller is shown below. The SIP *Content-Type* header indicating the PIDF-LO, and the NAM field listing the ELINs are shown in **bold** typeface.

```
INVITE sip:911;phone-context=Redmond@192.168.1.12;user=phone
SIP/2.0
From:
"voip_911_user1" <sip:voip_911_user1@contoso.com>;epid=1D19090AED;t
ag=d04d65d924
To: <sip:911;phone-context=Redmond@192.168.1.12;user=phone>
CSeq: 8 INVITE
Call-ID: e6828be1-1cdd-4fb0-bdda-cda7faf46df4
VIA: SIP/2.0/TLS 192.168.0.244:57918;branch=z9hG4bK528b7ad7
CONTACT:
<sip:voip_911_user1@contoso.com;opaque=user:epid:R4bCDaUj51a06PUbk
raS0QAA;gruu>;text;audio;video;image
PRIORITY: emergency
CONTENT-TYPE: multipart/mixed; boundary= -----
=_NextPart_000_4A6D_01CAB3D6.7519F890
geolocation: <cid:voip_911_user1@contoso.com>;inserted-
by="sip:voip_911_user1@contoso .com"
Message-Body:
-----=_NextPart_000_4A6D_01CAB3D6.7519F890
Content-Type: application/sdp ; charset=utf-8
v=0
o=- 0 0 IN IP4 Client
s=session
```

```

c=IN IP4 Client
t=0 0
m=audio 30684 RTP/AVP 114 111 112 115 116 4 3 8 0 106 97
c=IN IP4 172.29.105.23
a=rtcp:60423
a=label:Audio
a=rtpmap:3 GSM/8000/1
a=rtpmap:101 telephone-event/8000
a=fmtp:101 0-16
a=rtpmap:0 PCMU/8000
a=rtpmap:8 PCMA/8000
a=ptime:20

-----=_NextPart_000_4A6D_01CAB3D6.7519F890
Content-Type: application/pidf+xml
Content-ID: <voip_911_user1@contoso.com>
<?xml version="1.0" encoding="utf-8"?>
<presence xmlns="urn:ietf:params:xml:ns:pidf"
xmlns:gp="urn:ietf:params:xml:ns:pidf:geopriv10"
xmlns:bp="urn:ietf:params:xml:ns:pidf:geopriv10:basicPolicy"
xmlns:ca="urn:ietf:params:xml:ns:pidf:geopriv10:civicAddr"
xmlns:ms="urn:schema:Rtc.LIS.msftE911PidfExtn.2008"
entity="sip:voip_911_user1@contoso.com"><tuple
id="0"><status><gp:geopriv><gp:location-
info><ca:civicAddress><ca:country>US</ca:country><ca:A1>WA</ca:A1>
<ca:A3>Redmond</ca:A3><ca:RD>163rd</ca:RD><ca:STS>Ave</ca:STS><ca:
POD>NE</ca:POD><ca:HNO>3910</ca:HNO><ca:LOC>40/4451</ca:LOC>
<ca:NAM>1111-222-333; 1234567890 </ca:NAM>
<ca:PC>98052</ca:PC></ca:civicAddress></gp:location-
info><gp:usage-rules><bp:retransmission-
allowed>true</bp:retransmission-allowed></gp:usage-
rules></gp:geopriv><ms:msftE911PidfExtn><ms:ConferenceUri>sip:+142
55550199@contoso.com/user=phone</ms:ConferenceUri><ms:ConferenceMo
de>twoway</ms:ConferenceMode><LocationPolicyTagID
xmlns="urn:schema:Rtc.Lis.LocationPolicyTagID.2008">user-
tagid</LocationPolicyTagID
></ms:msftE911PidfExtn></status><timestamp>1991-09-
22T13:37:31.03</timestamp></tuple></presence>
-----=_NextPart_000_4A6D_01CAB3D6.7519F890--

```

26.11.4.3.2 Pre-empting Existing Calls for E9-1-1 Calls

If the ELIN Gateway receives an E9-1-1 call from the IP network and there are unavailable channels (for example, all busy), the ELIN Gateway immediately terminates one of the non-E9-1-1 calls (arbitrary) and accepts the E9-1-1 call on the freed channel.

The preemption is done only on a channel pertaining to the same Trunk Group for which the E9-1-1 call was initially destined. For example, if an E9-1-1 call is destined for Trunk Group #2 and all the channels belonging to this group are busy, the ELIN Gateway terminates one of the calls in this group to free a channel for accepting the E9-1-1 call.

This feature is initiated only if the received SIP INVITE message contains a *Priority* header set to "emergency", as shown below:

```
PRIORITY: emergency
```

26.11.4.3.3 PSAP Callback to Lync 2010 Clients for Dropped E9-1-1 Calls

As the E9-1-1 service automatically provides all the contact information of the E9-1-1 caller to the PSAP, the PSAP operator can call back the E9-1-1 caller. This is especially useful in cases where the caller disconnects prematurely. However, as the Enterprise sends ELINs to the PSAP for E9-1-1 calls, a callback can only reach the original E9-1-1 caller using the ELIN Gateway to translate the ELIN number back into the E9-1-1 caller's extension number.

In the ELIN table of the ELIN Gateway, the temporarily stored *From* header value of the SIP INVITE message originally received from the E9-1-1 caller is used for PSAP callback. When the PSAP makes a callback to the E9-1-1 caller, the ELIN Gateway translates the called number (i.e., ELIN) received from the PSAP to the corresponding E9-1-1 caller's extension number as matched in the ELIN table.

The handling of PSAP callbacks by the ELIN Gateway is as follows:

1. When the ELIN Gateway receives any call from the PSTN, it searches the ELIN table for an ELIN that corresponds to the received Called Party Number in the incoming PSTN call.
2. If a match is found in the ELIN table, it routes the call to the Mediation Sever by sending a SIP INVITE, where the values of the *To* and *Request-URI* are taken from the value of the original *From* header that is stored in the ELIN table (in the **Call From** column).
3. The ELIN Gateway updates the Time in the ELIN table. (The Count is not affected).

The PSAP callback can be done only within a user-defined timeout (see 'Configuring the E9-1-1 Callback Timeout' on page 379) started from after the original E9-1-1 call established with the PSAP is terminated. After this time expires, the table entry with its ELIN is disregarded and no longer used (for PSAP callback). Therefore, table entries of only the most recently terminated

E9-1-1 callers are considered in the ELIN table. If the PSAP callback is done after this timeout expires, the ELIN Gateway is unable to route the call to the E9-1-1 caller and instead, either sends it as a regular call or most likely, rejects it if there are no matching routing rules. However, if another E9-1-1 caller has subsequently been processed with the same ELIN number, then the PSAP callback is routed to this new E9-1-1 caller.

In scenarios where the same ELIN number is being used by multiple E9-1-1 callers, upon receipt of a PSAP callback, the ELIN Gateway sends the call to the most recent E9-1-1 caller. For example, if the ELIN number "4257275678" is being used by three E9-1-1 callers, as shown in the table below, then when a PSAP callback is received, the ELIN Gateway sends it to the E9-1-1 caller with phone number "4258359555".

Choosing Caller of ELIN

ELIN	Time	Call From
4257275678	11:00	4258359333
4257275678	11:01	4258359444
4257275678	11:03	4258359555

26.11.4.3.4 Selecting ELIN for Multiple Calls within Same ERL

The ELIN Gateway supports the receipt of up to five ELIN numbers in the XML message of each incoming SIP INVITE message. As discussed in the preceding sections, the ELIN Gateway sends the ELIN number as the E9-1-1 calling number to the PSTN-based emergency provider. If the XML message contains more than one ELIN number, the ELIN Gateway chooses the ELIN according to the following logic:

- If the first ELIN in the list is not being used by other active calls, it chooses this ELIN.

- If the first ELIN in the list is being used by another active call, the ELIN Gateway skips to the next ELIN in the list, and so on until it finds an ELIN that is not being used and sends this ELIN.
- If all the ELINs in the list are in use by active calls, the ELIN Gateway selects the ELIN number as follows:
 1. The ELIN with the lowest count (i.e., lowest number of active calls currently using this ELIN).
 2. If the count between ELINs is identical, the ELIN Gateway selects the ELIN with the greatest amount of time passed since the original E9-1-1 call using this ELIN was terminated with the PSAP. For example, if E9-1-1 caller using ELIN 4257275678 was terminated at **11:01** and E9-1-1 caller using ELIN 4257275670 was terminated at **11:03**, then the ELIN Gateway selects ELIN 4257275678.

In this scenario, multiple E9-1-1 calls will be sent with the same ELIN.

26.11.4.3.5 Location Based Emergency Routing

The device supports location-based emergency routing (E-911) in Lync Server 2010. This ensures that E-911 calls from remote branches are routed to emergency providers that are relevant to the geographical area in which the remote branch callers are physically located. To support this, the device enables routing and SIP header / number manipulation of such emergency calls based on the geographical location of the caller. The device manipulates the received destination number (i.e., 911) from the remote branch callers, into a destination number of an emergency provider that is relevant to the geographical area in which the remote branch office is located.

26.11.4.4 Configuring AudioCodes ELIN Gateway

This section describes E9-1-1 configuration of the AudioCodes ELIN Gateway deployed in the Lync Server 2010 environment.

26.11.4.4.1 Enabling the E9-1-1 Feature

By default, the E9-1-1 feature in the ELIN Gateway for Lync Server 2010 is disabled. To enable it, the following *ini* file parameter setting must be done:

```
E911Gateway = 1
```

26.11.4.4.2 Configuring the E9-1-1 Callback Timeout

The PSAP can use the ELIN to call back the E9-1-1 caller within a user-defined time interval (in minutes) from when the initial call established with the PSAP has been terminated. By default, an ELIN can be used for PSAP callback within 30 minutes after the call is terminated. You can change this interval, by using the following *ini* file parameter:

```
E911CallbackTimeout = <time value> ; where <time value > can be any value from 0 through 60
```

26.11.4.4.3 Configuring the SIP Release Cause Code for Failed E9-1-1 Calls

When a Lync 2010 client makes an emergency call, the call is routed through the Microsoft Mediation Server to the ELIN Gateway, which sends it on to the PSTN. In some scenarios, the call may not be established due to either the PSTN (for example, the destination is busy or not found) or ELIN Gateway (for example, lack of resources or an internal error). In such a scenario, the Mediation Server requires that the ELIN Gateway "reject" the call with the SIP release cause code 503 "Service Unavailable" instead of the designated release call. Such a release cause code enables the Mediation Server to issue a failover to another

entity (for example, another ELIN Gateway), instead of retrying the call or returning the release call to the user.

To support this requirement, the ELIN Gateway can be configured to send the 503 "Service Unavailable" release cause code instead of SIP 4xx if an emergency call cannot be established. To enable this support, the following *ini* file parameter setting must be done:



Note: This can also be configured using the *ini* file parameter, EmergencySpecialReleaseCause.

➤ **To enable SIP response 503 upon failed E911:**

1. Open the Advanced Parameters page (**Configuration** tab > **VoIP** menu > **SIP Definitions** > **Advanced Parameters**).
2. From the 'Emergency Special Release Cause' drop-down list, select **Enable**.

26.11.4.4.4 Configuring Location-Based Emergency Routing

The device identifies callers by their ELIN numbers contained in the PIDF-LO XML body of the received SIP INVITE message. To configure the manipulation rule for location-based emergency routing, the ELIN number is used as the source prefix in the Destination Phone Number Manipulation Table for Tel -> IP Calls table. To identify this source prefix as an E-911 ELIN number, the "ELIN" string is added in front of the source prefix number, for example, "ELIN1234567890". For example, assume an E-9-1-1 call is received for destination 911@company.com and the ELIN number is 1234567890; to create the new destination as 15509115000@company.com, the destination number is manipulated using the manipulation table by adding prefix 1550 and suffix 5000.

➤ **To configure location-based emergency routing:**

1. Enable location-based emergency routing, by loading an ini file to the device with the following parameter setting:

```
E911Gateway = 2
```

2. In the Destination Phone Number Manipulation Table for Tel -> IP Calls table (**Configuration** tab > **VoIP** menu > **GW and IP to IP** submenu > **Manipulations** > **Dest Number Tel->IP**), configure the following fields:
 - Under the **Rule** tab:
 - ◆ 'Source Prefix': ELIN<ELIN source number>
 - Under the **Action** tab:
 - ◆ Configure the manipulation action as required

26.11.4.4.5 Viewing the ELIN Table

You can view the ELIN table of the ELIN Gateway. The method depends on the type of device:

- Using the following CLI command:

```
# show voip gw e911
ELIN      Time    Count Index Call From
-----
4257275678  22:11:52  0    2    4258359333
4257275999  22:11:57  0    3    4258359444
4257275615  22:12:03  0    0    4258359555
4257275616  22:11:45  0    1    4258359777
```

```
----- Current Time: 22:12:40
```

- Using Syslog, by invoking the following Web command shell:

```
SIP / GateWay / E911Dump
```

26.12 Multilevel Precedence and Preemption

The device supports Multilevel Precedence and Preemption (MLPP) service. MLPP is a call priority scheme, which does the following:

- Assigns a precedence level (priority level) to specific phone calls or messages.
- Allows higher priority calls (*precedence call*) and messages to preempt lower priority calls and messages (i.e., terminates existing lower priority calls) that are recognized within a user-defined domain (*MLPP domain ID*). The domain specifies the collection of devices and resources that are associated with an MLPP subscriber. When an MLPP subscriber that belongs to a particular domain places a precedence call to another MLPP subscriber that belongs to the same domain, MLPP service can preempt the existing call that the called MLPP subscriber is on for a higher-precedence call. MLPP service availability does not apply across different domains.

MLPP is typically used in the military where, for example, high-ranking personnel can preempt active calls during network stress scenarios such as a national emergency or degraded network situations.

MLPP can be enabled for all calls, using the global parameter, `CallPriorityMode`, or for specific calls using the Tel Profile parameter, `CallPriorityMode`.

Notes:

- For Trunk Groups configured with call preemption, all must be configured to MLPP [1] or all configured to Emergency [2]. In other words, you cannot set some trunks to [1] and some to [2].
- The global parameter must be set to the same value as that of the Tel Profile parameter; otherwise, the Tel Profile parameter is not applied.
- If you configure call preemption using the global parameter and a new Tel Profile is subsequently added, the `TelProfile_CallPriorityMode` parameter automatically acquires the same setting as well.



The Resource Priority value in the Resource-Priority SIP header can be any one of those listed in the table below. A default MLPP call Precedence Level (configured by the `SIPDefaultCallPriority` parameter) is used if the incoming SIP INVITE or PRI Setup message contains an invalid priority or Precedence Level value respectively. For each MLPP call priority level, the Multiple Differentiated Services Code Points (DSCP) can be set to a value from 0 to 63.

MLPP Call Priority Levels (Precedence) and DSCP Configuration Parameters

MLPP Precedence Level	Precedence Level in Resource-Priority SIP Header	DSCP Configuration Parameter
0 (lowest)	routine	MLPPRoutineRTPDSCP
2	priority	MLPPPRIORITYRTPDSCP
4	immediate	MLPPImmediateRTPDSCP
6	flash	MLPPFlashRTPDSCP
8	flash-override	MLPPFlashOverRTPDSCP

MLPP Precedence Level	Precedence Level in Resource-Priority SIP Header	DSCP Configuration Parameter
9 (highest)	flash-override-override	MLPPFlashOverOverRTPDSCP

The device automatically interworks the network identity digits (NI) in the ISDN Q.931 Precedence Information Element (IE) to the network domain subfield of the INVITE's Resource-Priority header, and vice versa. The SIP Resource-Priority header contains two fields, namespace and priority. The namespace is subdivided into two subfields, network-domain and precedence-domain. Below is an example of a Resource-Priority header whose network-domain subfield is "uc", r-priority field is "priority" (2), and precedence-domain subfield is "000000":

Resource-Priority: uc-000000.2

The MLPP Q.931 Setup message contains the Precedence IE. The NI digits are presented by four nibbles found in octets 5 and 6. The device checks the NI digits according to the translation table of the Department of Defense (DoD) Unified Capabilities (UC) Requirements (UCR 2008, Changes 3) document, as shown below:

NI Digits in ISDN Precedence

Level IE	Network Domain in SIP Resource-Priority Header
0000	uc
0001	cuc
0002	dod
0003	nato

Notes:

- If the received ISDN message contains NI digits that are not listed in the translation table, the device sets the network-domain to "uc" in the outgoing SIP message.
- If the received SIP message contains a network-domain value that is not listed in the translation table, the device sets the NI digits to "0000" in the outgoing ISDN message.
- If the received ISDN message does not contain a Precedence IE, you can configure the namespace value - dsn (default), dod, drsn, uc, or cuc - in the SIP Resource-Priority header of the outgoing INVITE message. This is done using the MLPPDefaultNamespace parameter. You can also configure up to 32 user-defined namespaces, using the table ini file parameter, ResourcePriorityNetworkDomains. Once defined, you need to set the MLPPDefaultNamespace parameter value to the desired table row index.



By default, the device maps the received Resource-Priority field of the SIP Resource-Priority header to the outgoing ISDN PRI Precedence Level (priority level) field as follows:

- If the network-domain field in the Resource-Priority header is "uc", then the device sets the Precedence Level field in the ISDN PRI Precedence Level IE according to Table 5.3.2.12-4 (Mapping of RPH r-priority Field to PRI Precedence Level Value):

Mapping of SIP Resource-Priority Header to PRI Precedence Level for MLPP

MLPP Precedence Level	PRI Precedence Level	SIP Resource-Priority Header Field
Routine	4	0
Priority	3	2
Immediate	2	4
Flash	1	6
Flash Override	0	8

- If the network-domain field in the Resource-Priority header is any value other than "uc", then the device sets the Precedence Level field to "0 1 0 0" (i.e., "routine").

This can be modified using the EnableIp2TelInterworkingtable field of the ini file parameter, ResourcePriorityNetworkDomains.



Notes:

- If required, you can exclude the "resource-priority" tag from the SIP Require header in INVITE messages for Tel-to-IP calls when MLPP priority call handling is used. This is configured using the RPRRequired parameter.
- For a complete list of the MLPP parameters, see 'MLPP and Emergency Call Parameters' on page 736.

26.12.1 MLPP Preemption Events in SIP Reason Header

The device sends the SIP Reason header (as defined in RFC 4411) to indicate the reason and type of a preemption event. The device sends a SIP BYE or CANCEL request, or SIP 480, 486, 488 response (as appropriate) with a Reason header whose Reason-params can include one of the following preemption cause classes:

- Reason: preemption ;cause=1 ;text="UA Preemption"
- Reason: preemption ;cause=2 ;text="Reserved Resources Preempted"
- Reason: preemption ;cause=3 ;text="Generic Preemption"
- Reason: preemption ;cause=4 ;text="Non-IP Preemption"

This Reason cause code indicates that the session preemption has occurred in a non-IP portion of the infrastructure. The device sends this code in the following scenarios:

- The device performs a network preemption of a busy call (when a high priority call is received), the device sends a SIP BYE or CANCEL request with this Reason cause code.
- The device performs a preemption of a B-channel for a Tel-to-IP outbound call request from the softswitch for which it has not received an answer response (e.g., Connect), and the following sequence of events occurs:
 - a. The device sends a Q.931 DISCONNECT over the ISDN MLPP PRI to the partner switch to preempt the remote end instrument.
 - b. The device sends a 488 (Not Acceptable Here) response with this Reason cause code.
- Reason: preemption; cause=5; text="Network Preemption"

This Reason cause code indicates preempted events in the network. Within the Defense Switched Network (DSN) network, the following SIP request messages and response codes for specific call scenarios have been identified for signaling this preemption cause:

- SIP:BYE - If an active call is being preempted by another call
- CANCEL - If an outgoing call is being preempted by another call
- 480 (Temporarily Unavailable), 486 (User Busy), 488 (Not Acceptable Here) - Due to incoming calls being preempted by another call.

The device receives SIP requests with preemption reason cause=5 in the following cases:

- The softswitch performs a network preemption of an active call - the following sequence of events occurs:
 - a. The softswitch sends the device a SIP BYE request with this Reason cause code.
 - b. The device initiates the release procedures for the B-channel associated with the call request and maps the preemption cause to PRI Cause = #8 'Preemption'. This value indicates that the call is being preempted. For PRI, it also indicates that the B-channel is not reserved for reuse.
 - c. The device sends a SIP 200 OK in response to the received BYE, before the SIP end instrument can proceed with the higher precedence call.
- The softswitch performs a network preemption of an outbound call request for the device that has not received a SIP 2xx response - the following sequence of events occur:
 - a. The softswitch sends the device a SIP 488 (Not Acceptable Here) response code with this Reason cause code. The device initiates the release procedures for the B-channel associated with the call request and maps the preemption cause to PRI Cause = #8 'Preemption'.
 - b. The device deactivates any user signaling (e.g., ringback tone) and when the call is terminated, it sends a SIP ACK message to the softswitch.

26.12.2 Precedence Ring Tone

You can assign a ring tone that is defined in the CPT file to be played when a precedence call is received from the IP side. This is configured by the `PrecedenceRingingType` parameter. You can configure the duration for which the device plays a preemption tone to the Tel and IP sides if a call is preempted, using the `PreemptionToneDuration` parameter.

Emergency Telecommunications Services (ETS) calls (e.g., E911) can be configured with a higher priority than any MLPP call (default), using the `E911MLPPBehavior` parameter.

26.13 Denial of Collect Calls

You can configure the device to reject (disconnect) incoming Tel-to-IP collect calls and to signal this denial to the PSTN. This capability is required, for example, in the Brazilian telecommunication system to deny collect calls. When this feature is enabled upon rejecting the incoming call, the device sends a sequence of signals to the PSTN. This consists of an off-hook, an on-hook after one second, and then an off-hook after two seconds. In other words, this is in effect, a double-answer sequence.

This feature can be enabled for all calls, using the EnableFXODoubleAnswer "global" parameter, or it can be enabled for specific calls, by enabling this feature in a Tel Profile.



Notes:

- This feature is applicable only to FXO interfaces.
- If automatic dialing is also configured for an FXO port enabled with Denial of Collect Calls, the FXO line does not answer the incoming call (ringing) until a SIP 200 OK is received from the remote destination. When a 200 OK is received, a double answer is sent from the FXO line.
- Ensure that the PSTN side is configured to identify this double-answer signal.

26.14 Configuring ISDN Supplementary Services

The ISDN Supp Services Table page allows you to configure supplementary services for Integrated Services Digital Network (ISDN) Basic Rate Interface (BRI) phones connected to the device. This feature enables the device to route IP-to-Tel calls (including voice and fax) to specific BRI ports (channels).

This table allows you to define BRI phone extension numbers per BRI port pertaining to a specific BRI module. Therefore, this offers support for point-to-multipoint configuration of several phone numbers per BRI channel. Up to eight phone numbers can be defined per BRI trunk. For each BRI endpoint, the following optional configurations can also be defined:

- User ID and password - for registering the BRI endpoint to a third-party softswitch for authentication and/or billing. For viewing BRI registration status, see 'Viewing Endpoint Registration Status' on page 556.
- Caller ID name - for displaying the BRI endpoint's caller ID to a dialed destination, if enabled (i.e., "Presentation" is not restricted)
- Caller ID presentation or restriction
- Enable/disable sending caller ID to BRI endpoints



Notes:

- To use this table for routing of IP-to-Tel calls to specific BRI channels, the Channel Select Mode in the Trunk Group Settings must be set to 'Select Trunk by ISDN Supplementary Services Table' (see 'Configuring Trunk Group Settings' on page 293).
- The ISDN Supp Services table can also be configure using the table ini file parameter, ISDNSuppServ.
- To allow the end-user to hear a dial tone when picking up the BRI phone, it is recommended to set the Progress Indicator in the Setup Ack bit (0x10000=65536). Therefore, the recommended value is 0x10000 + 0 x1000 = 65536 + 4096 = 69632 (i.e., set the ISDNInCallsBehavior parameter to 69632).

➤ To configure BRI supplementary services:

1. Open the ISDN Supp Services Table page (**Configuration** tab > **VoIP** menu > **GW and IP to IP** > **Digital Gateway** > **ISDN Supp Services**).

Figure 26-9: ISDN Supp Services Table Page

Index	Phone Number	Module	Port	User ID
1 <input type="radio"/>	4112	1	3	mike
2 <input type="radio"/>		0	0	



User Password	Caller ID	Presentation Restricted	Caller ID Enabled
*	mike	Allowed	Enabled
*		Not Configured	Not Configured

2. Configure the parameters as described in the table below.
3. Click **Submit** to apply your changes.
4. To save the changes to flash memory, see 'Saving Configuration' on page 494.
5. To register the BRI endpoints, click the **Register** button. To unregister the BRI endpoints, click **Unregister**. The registration method for each BRI endpoint is according to the setting of the 'Registration Mode' parameter in the Trunk Group Settings page.

ISDN Supp Services Table Parameters

Parameter	Description
Phone Number [ISDNSuppServ_PhoneNumber]	Defines the telephone extension number for the BRI endpoint.
Module [ISDNSuppServ_Module]	Defines the BRI module number to which the BRI extension pertains.
Port [ISDNSuppServ_Port]	Defines the port number on the BRI module to which the BRI extension is connected.
User ID [ISDNSuppServ_UserId]	Defines the User ID for registering the BRI endpoint to a third-party softswitch for authentication and/or billing.
User Password [ISDNSuppServ_UserPassword]	Defines the user password for registering the BRI endpoint to a third-party softswitch for authentication and/or billing. Note: For security, the password is displayed as an asterisk (*).
Caller ID Number [ISDNSuppServ_CallerID]	Defines the caller ID name of the BRI extension (sent to the IP side). The valid value is a string of up to 18 characters.
Presentation Restricted [ISDNSuppServ_IsPresentationRestricted]	Determines whether the BRI extension sends its Caller ID information to the IP when a call is made. <ul style="list-style-type: none"> ▪ [0] Allowed = The device sends the string defined in the 'Caller ID' field when this BRI extension makes a Tel-to-IP call. ▪ [1] Restricted = The string defined in the 'Caller ID' field is not sent.

Parameter	Description
Caller ID Enabled [ISDNSuppServ_IsCallerID Enabled]	Enables the receipt of Caller ID. <ul style="list-style-type: none"> [0] Disabled = The device does not send Caller ID information to the BRI extension. [1] Enabled = The device sends Caller ID information to the BRI extension

26.15 Advice of Charge Services for Euro ISDN

Advice of charge (AOC) is a pre-billing function that tasks the rating engine with calculating the cost of using a service and relaying that information back to the customer thus, allowing users to obtain charging information for all calls during the call (AOC-D) or at the end of the call (AOC-E), or both.

The AOC-D and AOC-E messages are part of the Facility Information Element (IE) message:

- AOC-D message—ISDN Advice of Charge information sent during a call. The message is sent periodically to subscribers of AOC during-call services.
- AOC-E message—ISDN Advice of Charge information sent at the end of a call.

The device supports the sending of AoC messages for Tel-to-IP calls, providing billing applications with the number of charged units. This feature can typically be implemented in the hotel industry, where external calls made by guests can be billed accurately. In such a setup, the device is connected on one side to a PBX through an E1 line (Euro ISDN), and on the other side to a SIP trunk provided by an ITSP. When a call is made by a guest, the device first sends an AOC-D Facility message to the PBX indicating the connection charge unit, and then sends subsequent AOC-D messages every user-defined interval to indicate the charge unit during the call. When the call ends, the device sends an AoC-E Facility message to the PBX indicating the total number of charged units.

To configure AoC:

1. Ensure that the PSTN protocol for the E1 trunk line is Euro ISDN and set to network side.
2. Ensure that the date and time of the device is correct. For accuracy, it is recommended to use an NTP server to obtain the date and time.
3. Enable the AoC service, using the EnableAOC parameter.
4. Configure charge codes in the Charge Code table (ChargeCode) - see Configuring Charge Codes on page 391. Note that in the Charge Code table, the table fields are as follows:
 - 'End Time' - time at which this charge code ends
 - 'Pulse Interval' - time between every sent AOC-D Facility message
 - 'Pulses On Answer' - number of charging units in first generated AOC-D Facility message
5. Assign the charge code index to the desired routing rule in the Outbound IP Routing table (see 'Configuring Outbound IP Routing Table' on page 323).

26.16 Configuring Voice Mail

The Voice Mail Settings page allows you to configure the voice mail parameters. For a description of these parameters, see 'Configuration Parameters Reference' on page 609.



Notes:

- The Voice Mail Settings page is available only for FXO and CAS interfaces.
- For more information on configuring voice mail, refer to the *CPE Configuration Guide for Voice Mail User's Manual*.

➤ **To configure the Voice Mail parameters:**

1. Open the Voice Mail Settings page (**Configuration** tab > **VoIP** menu > **GW and IP to IP** > **Advanced Applications** > **Voice Mail Settings**).

Line Transfer Mode	None	▼
Voice Mail Interface	NONE	▼
▼ Digit Patterns		
Forward on Busy Digit Pattern (Internal)	<input type="text"/>	
Forward on No Answer Digit Pattern (Internal)	<input type="text"/>	
Forward on Do Not Disturb Digit Pattern (Internal)	<input type="text"/>	
Forward on No Reason Digit Pattern (Internal)	<input type="text"/>	
Forward on Busy Digit Pattern (External)	<input type="text"/>	
Forward on No Answer Digit Pattern (External)	<input type="text"/>	
Forward on Do Not Disturb Digit Pattern (External)	<input type="text"/>	
Forward on No Reason Digit Pattern (External)	<input type="text"/>	
Internal Call Digit Pattern	<input type="text"/>	
External Call Digit Pattern	<input type="text"/>	
Disconnect Call Digit Pattern	<input type="text"/>	
Digit To Ignore Digit Pattern	<input type="text"/>	
▼ Message Waiting Indication (MWI)		
MWI Off Digit Pattern	<input type="text"/>	
MWI On Digit Pattern	<input type="text"/>	
MWI Suffix Pattern	<input type="text"/>	
MWI Source Number	<input type="text"/>	
▼ SMDI		
⚡ Enable SMDI	Disable	▼
SMDI Timeout [msec]	2000	

2. Configure the parameters as required.
3. Click **Submit** to apply your changes.
4. To save the changes to flash memory, see 'Saving Configuration' on page 494.

27 Analog Gateway

This section describes configuration of analog settings.



Note: The Analog Gateway submenu appears only if the device is installed with an FXS or FXO module.

27.1 Configuring Keypad Features

The Keypad Features page enables you to activate and deactivate the following features directly from the connected telephone's keypad:

- Call Forward
- Caller ID Restriction
- Hotline for automatic dialing
- Call Transfer
- Call Waiting
- Rejection of Anonymous Calls



Notes:

- The Keypad Features page is available only for FXS interfaces.
- The method used by the device to collect dialed numbers is identical to the method used during a regular call (i.e., max digits, interdigit timeout, digit map, etc.).
- The activation of each feature remains in effect until it is deactivated (i.e., not deactivated after a call).
- For a description of the keypad parameters, see 'Telephone Keypad Sequence Parameters' on page 793.

- **To configure the keypad features**
- 1. Open the Keypad Features page (**Configuration** tab > **VoIP** menu > **GW and IP to IP** > **Analog Gateway** > **Keypad Features**).

Figure 27-1: Keypad Features Page

▼ Forward	
Unconditional	<input type="text"/>
No Answer	<input type="text"/>
On Busy	<input type="text"/>
On Busy or No Answer	<input type="text"/>
Do Not Disturb	<input type="text"/>
Deactivate	<input type="text"/>
▼ Caller ID Restriction	
Activate	<input type="text"/>
Deactivate	<input type="text"/>
▼ Hotline	
Activate	<input type="text"/>
Deactivate	<input type="text"/>
▼ Transfer	
Blind	<input type="text"/>
▼ Call Waiting	
Activate	<input type="text"/>
Deactivate	<input type="text"/>
▼ Reject Anonymous Call	
Activate	<input type="text"/>
Deactivate	<input type="text"/>

- 2. Configure the keypad features as required.
- 3. Click **Submit** to apply your changes.

27.2 Configuring Metering Tones

The FXS interfaces can generate 12/16 KHz metering pulses toward the Tel side (e.g., for connection to a pay phone or private meter). Tariff pulse rate is determined according to the device's Charge Codes table. This capability enables users to define different tariffs according to the source/destination numbers and the time-of-day. The tariff rate includes the time interval between the generated pulses and the number of pulses generated on answer.

**Notes:**

- The Metering Tones page is available only for FXS interfaces.
- Charge Code rules can be assigned to routing rules in the Outbound IP Routing Table (see 'Configuring Outbound IP Routing Table' on page 323). When a new call is established, the Outbound IP Routing Table is searched for the destination IP address. Once a route is located, the Charge Code (configured for that route) is used to associate the route with an entry in the Charge Codes table.

➤ **To configure Metering tones:**

1. Open the Metering Tones page (**Configuration** tab > **VoIP** menu > **GW and IP to IP** > **Analog Gateway** > **Metering Tones**).

Figure 27-2: Metering Tones Page

Generate Metering Tones	Disable	▼
⚡ Metering Tone Type	16 KHz	▼
Charge Codes Table		

2. Configure the Metering tones parameters as required. For a description of the parameters appearing on this page, see 'Configuration Parameters Reference' on page 609.
3. Click **Submit** to apply your changes.
4. To save the changes to the flash memory, see 'Saving Configuration' on page 494.

If you set the 'Generate Metering Tones' parameter to **Internal Table**, access the Charge Codes Table page by clicking the **Charge Codes Table**  button. For more information on configuring the Charge Codes table, see 'Configuring Charge Codes' on page 391.

27.3 Configuring Charge Codes

The Charge Codes table is used to configure the metering tones (and their time interval) that the FXS interfaces generate to the Tel side. To associate a charge code to an outgoing Tel-to-IP call, use the Outbound IP Routing Table.

You can configure up to 25 different charge codes, where each table row represents a charge code. Each charge code can include up to four different time periods in a day (24 hours). The device selects the time period by comparing the device's current time to the end time of each time period of the selected Charge Code. The device generates the Number of Pulses on Answer once the call is connected and from that point on, it generates a pulse each Pulse Interval. If a call starts at a certain time period and crosses to the next, the information of the next time period is used.

**Notes:**

- The Charge Codes Table page is available only for FXS interfaces.
- The Charge Codes table can also be used to configure Advice of Charge (AoC) services for Euro ISDN trunks (see Advice of Charge Services for Euro ISDN on page 387).
- The Charge Codes table can also be configured using the table ini file parameter, ChargeCode.

- **To configure the Charge Codes:**
 1. Open the Charge Codes Table page (**Configuration** tab > **VoIP** menu > **GW and IP to IP** submenu > **Analog Gateway** submenu > **Charge Codes**). Alternatively, you can access this page from the Metering Tones page (see 'Configuring Metering Tones' on page 390).

Figure 27-3: Charge Codes Table Page

Table Index												
0-4												
Index	Time Period 1			Time Period 2			Time Period 3			Time Period 4		
	End Time	Pulse Interval	Pulses On Answer	End Time	Pulse Interval	Pulses On Answer	End Time	Pulse Interval	Pulses On Answer	End Time	Pulse Interval	Pulses On Answer
0	07	30	1	14	20	2	20	15	1	00	60	1
1	05	60	1	14	20	1	00	60	1			
2	00	60	1									
3												
4												

2. Configured the charge codes, as required. For a description of the parameters, see the table below.
3. Click **Submit** to apply your changes.
4. To save the changes to the flash memory, see 'Saving Configuration' on page 494.

Charge Codes Table Parameter Description

Parameter	Description
End Time [ChargeCode_EndTime<1-4>]	Defines the end of the time period in a 24 hour format, <i>hh</i> . For example, "04" denotes 4 A.M. Notes: <ul style="list-style-type: none"> ▪ The first time period always starts at midnight (00). ▪ It is mandatory that the last time period of each rule end at midnight (00). This prevents undefined time frames in a day.
Pulse Interval [ChargeCode_PulseInterval<1-4>]	Defines the time interval between pulses (in tenths of a second).
Pulses On Answer [ChargeCode_PulsesOnAnswer<1-4>]	Defines the number of pulses sent on answer.

27.4 Configuring FXO Settings

The FXO Settings page allows you to configure the device's specific FXO parameters. For a description of these parameters, see 'Configuration Parameters Reference' on page 609.



Note: The FXO Settings page is available only for FXO interfaces.

➤ **To configure the FXO parameters:**

1. Open the FXO Settings page (**Configuration** tab > **VoIP** menu > **GW and IP to IP** > **Analog Gateway** > **FXO Settings**).

Figure 27-4: FXO Settings Page

Dialing Mode	Two Stages	▼
Waiting for Dial Tone	No	▼
Time to Wait before Dialing [msec]	1000	
Ring Detection Timeout [sec]	8	
Reorder Tone Duration [sec]	255	
Answer Supervision	No	▼
Rings before Detecting Caller ID	1	▼
Send Metering Message to IP	No	▼
Disconnect Call on Busy Tone Detection (CAS)	Enable	▼
Disconnect On Dial Tone	Disable	▼
Guard Time Between Calls	1	
FXO Double Answer	Disable	▼
FXO AutoDial Play BusyTone	Disable	▼

2. Configure the parameters as required.
3. Click **Submit** to apply your changes.
4. To save the changes to flash memory, see 'Saving Configuration' on page 494.

27.5 Configuring Authentication

The Authentication page defines a user name and password for authenticating each device port. Authentication is typically used for FXS interfaces, but can also be used for FXO interfaces.



Notes:

- For configuring whether authentication is done per port or for the entire device, use the parameter AuthenticationMode.
- If authentication is configured for the entire device, the configuration in this table is ignored.
- If the user name or password is not configured in this table, the port's phone number (configured in the Trunk Group Table) and global password (configured by the global parameter, Password) are used instead for authentication of the port.
- After you click **Submit**, the password is displayed as an asterisk (*).
- The Authentication table can also be configured using the table ini file parameter, Authentication (see 'Configuration Parameters Reference' on page 609).

- **To configure authentication credentials per port:**
 1. Set the parameter 'Registration Mode' (AuthenticationMode) to **Per Endpoint**. This can be configured in any of the following pages:
 - Proxy & Registration page (see 'Configuring Proxy and Registration Parameters' on page 228).
 - Trunk Group Settings page (see 'Configuring Trunk Group Settings' on page 293), where registration method is configured per Trunk Group.
 2. Open the Authentication page (**Configuration** tab > **VoIP** menu > **GW and IP to IP** > **Analog Gateway** > **Authentication**).

Figure 27-5: Authentication Page

Gateway Port	User Name	Password
Module 1 Port 1 FXS	<input type="text" value="user1"/>	<input type="password" value="*****"/>
Module 1 Port 2 FXS	<input type="text" value="user2"/>	<input type="password" value="*****"/>
Module 2 Port 1 FXO	<input type="text"/>	<input type="password"/>
Module 2 Port 2 FXO	<input type="text"/>	<input type="password"/>
Module 2 Port 3 FXO	<input type="text"/>	<input type="password"/>
Module 2 Port 4 FXO	<input type="text"/>	<input type="password"/>

3. Configure port authentication credentials as required. For a description of the parameters, see the table below.
4. Click **Submit** to apply your changes.

Authentication Table Parameter Description

Parameter	Description
[Authentication_Port]	Defines the port to authenticate. Note: This parameter is not relevant to the Web interface.
[Authentication_Module]	Defines the module number on which the port is located. Note: This parameter is not relevant to the Web interface.
User Name [Authentication_UserId]	Defines the user name used for authenticating the port.
Password [Authentication_UserPassword]	Defines the password used for authenticating the port.

27.6 Configuring Automatic Dialing

The Automatic Dialing page allows you to define a telephone number that is automatically dialed when an FXS or FXO port goes off-hook. The dialing can be done immediately upon off-hook, or after a user-defined interval after off-hook referred to as *Hotline* dialing.



Note: The Automatic Dialing can also be configured using the table ini file parameter, TargetOfChannel.

➤ **To configure automatic dialing per port:**

1. Open the Automatic Dialing page (**Configuration** tab > **VoIP** menu > **GW and IP to IP** submenu > **Analog Gateway** > **Automatic Dialing**).

Gateway Port	Destination Phone Number	Auto Dial Status	Hotline Dial Tone Duration [sec]
Module 3 Port 1 FXS	911	Hotline ▾	15
Module 3 Port 2 FXS	200	Enable ▾	0
Module 3 Port 3 FXS		Enable ▾	0
Module 3 Port 4 FXS		Enable ▾	0

The first table entry in the figure above enables Hotline automatic dialing for an FXS port, whereby if the port is off-hooked for over 15 seconds, the device automatically dials 911.

2. Configure automatic dialing per port, as required. See the table below for parameter descriptions.
3. Click **Submit** to apply your changes.
4. To save the changes to flash memory, see 'Saving Configuration' on page 494.

Automatic Dialing Table Parameter Description

Parameter	Description
Gateway Port [TargetOfChannel_Module] [TargetOfChannel_Port]	Lists the FXS or FXO port (per module) for which you want to configure automatic dialing.
Destination Phone Number [TargetOfChannel_Destination]	Defines the destination telephone number to automatically dial.
Auto Dial Status [TargetOfChannel_Type]	<p>Enables automatic dialing.</p> <ul style="list-style-type: none"> ▪ [0] Disable = Automatic dialing for the specific port is disabled. ▪ [1] Enable = (Default) Automatic dialing is enabled and the phone number configured in the 'Destination Phone Number' field is automatically dialed if the following occurs: <ul style="list-style-type: none"> ✓ FXS interfaces: The phone is off-hooked ✓ FXO interfaces: A ring signal (from a PBX/PSTN switch) is detected on the FXO line. The device initiates a call to the destination without seizing the FXO line. The line is seized only after the SIP call is answered. ▪ [2] Hotline = Automatic dialing is done after an interval configured by the 'Hotline Dial Tone Duration' parameter: <ul style="list-style-type: none"> ✓ FXS interfaces: When the phone is off-hooked and no digit is dialed within a user-defined time, the configured destination number is automatically dialed. ✓ FXO interfaces: If a ring signal is detected, the device seizes the FXO line, plays a dial tone, and then waits for DTMF digits. If no digits are detected within a user-defined time, the configured destination number is automatically dialed by sending a SIP INVITE message with this number.

Parameter	Description
Hotline Dial Tone Duration [TargetOfChannel_HotLineToneDuration]	Defines the duration (in seconds) after which the destination phone number is automatically dialed. This is applicable only if the port has been configured for Hotline (i.e., 'Auto Dial Status' is set to Hotline). The valid value is 0 to 60. The default is 16. Note: You can configure this Hotline interval for all ports, using the global parameter, HotLineToneDuration.

27.7 Configuring Caller Display Information

The Caller Display Information table allows you to define a caller identification string (Caller ID) for FXS and FXO ports and enable the device to send the Caller ID to the IP when a call is made. The called party can use this information for caller identification.

The device sends the configured caller ID in the outgoing INVITE message's From header. For information on Caller ID restriction according to destination/source prefixes, see 'Configuring Source/Destination Number Manipulation' on page 299.



Notes:

- If an FXS port receives 'Private' or 'Anonymous' strings in the SIP From header, the calling name or number is not sent to the Caller ID display.
- If Caller ID is detected on an FXO line (EnableCallerID = 1), it is used instead of the Caller ID configured in this table.
- If you set the 'Caller ID/Name' parameter to the strings "Private" or "Anonymous", Caller ID is restricted and the settings of the 'Presentation' parameter is ignored.
- The Caller Display Information table can also be configured using the table ini file parameter, CallerDisplayInfo.

➤ **To configure Caller Display:**

1. Open the Caller Display Information page (**Configuration** tab > **VoIP** menu > **GW and IP to IP** > **Analog Gateway** > **Caller Display Information**).

Gateway Port	Caller ID/Name	Presentation
Module 1 Port 1 FXS	Private	Restricted ▼
Module 1 Port 2 FXS	Susan C.	Restricted ▼
Module 2 Port 1 FXO	Lee P.	Allowed ▼
Module 2 Port 2 FXO	Ronaldo	Allowed ▼
Module 2 Port 3 FXO		Allowed ▼
Module 2 Port 4 FXO		Allowed ▼

2. Configure the table as required. For a description of the parameters, see the table below.
3. Click **Submit** to apply your changes.

Caller Display Parameter Description

Parameter	Description
Gateway Port [CallerDisplayInfo_Port] [CallerDisplayInfo_Module]	Displays the port per module.
Caller ID/Name [CallerDisplayInfo_DisplayString]	Defines the Caller ID string. The valid value is a string of up to 18 characters.
Presentation [CallerDisplayInfo_IsCidRestricted]	<p>Enables the sending of the caller ID string.</p> <ul style="list-style-type: none"> ▪ [0] Allowed = The caller ID string is sent when a Tel-to-IP call is made. ▪ [1] Restricted = The caller ID string is not sent. <p>Notes:</p> <ul style="list-style-type: none"> ▪ This parameter is overridden by the 'Presentation' parameter in the Source Number Manipulation table (see 'Configuring Source/Destination Number Manipulation' on page 299). ▪ If this parameter is set to Restricted, the Caller ID is sent to the remote side using only the SIP P-Asserted-Identity and P-Preferred-Identity headers (AssertedIdMode).

27.8 Configuring Call Forward

The Call Forwarding table allows you to configure call forwarding per port for IP-to-Tel calls. This redirects the call (using SIP 302 response) initially destined to a specific device Tel port, to a different device port or to an IP destination.



Notes:

- To enable call forwarding, set the 'Enable Call Forward' parameter to **Enable**. This is done in the Supplementary Services page (**Configuration** tab > **VoIP** menu > **GW and IP to IP** > **DTMF and Supplementary** > **Supplementary Services**).
- The Call Forward table can also be configured using the table ini file parameter, FwdInfo.

➤ **To configure Call Forward per port:**

1. Open the Call Forward Table page (**Configuration** tab > **VoIP** menu > **GW and IP to IP** > **Analog Gateway** > **Call Forward**).

Gateway Port	Forward Type	Forward to Phone Number	Time for No Reply Forward
Module 1 Port 1 FXS	On busy	201	30
Module 1 Port 2 FXS	Unconditional	202@10.2.1.1	30
Module 2 Port 1 FXO	No Answer	203	30
Module 2 Port 2 FXO	Deactivate		30
Module 2 Port 3 FXO	Deactivate		30
Module 2 Port 4 FXO	Deactivate		30

2. Configure the table as required. For descriptions of the parameters, see the table below.
3. Click **Submit** to apply your changes.

Call Forward Table Parameter Description

Parameter	Description
Forward Type [FwdInfo_Type]	Defines the condition upon which the call is forwarded. <ul style="list-style-type: none"> ▪ [0] Deactivate = (Default) Don't forward incoming calls. ▪ [1] On Busy = Forward incoming calls when the port is busy. ▪ [2] Unconditional = Always forward incoming calls. ▪ [3] No Answer = Forward incoming calls that are not answered within the time specified in the 'Time for No Reply Forward' field. ▪ [4] On Busy or No Answer = Forward incoming calls when the port is busy or when calls are not answered within the time specified in the 'Time for No Reply Forward' field. ▪ [5] Do Not Disturb = Immediately reject incoming calls.
Forward to Phone Number [FwdInfo_Destination]	Defines the telephone number or URI (<number>@<IP address>) to where the call is forwarded. Note: If this parameter is configured with only a telephone number and a Proxy isn't used, this forwarded-to phone number must be specified in the Outbound IP Routing Table (see 'Configuring Outbound IP Routing Table' on page 323).
Time for No Reply Forward [FwdInfo_NoReplyTime]	If you have set the 'Forward Type' for this port to No Answer , then configure the number of seconds the device waits before forwarding the call to the specified phone number.

27.9 Configuring Caller ID Permissions

The Caller ID Permissions table allows you to enable per port, Caller ID generation for FXS interfaces and Caller ID detection for FXO interfaces.



Notes:

- If Caller ID permissions is not configured for a port in this table, its Caller ID generation / detection is determined according to the global parameter, 'Enable Call ID' in the Supplementary Services page (**Configuration** tab > **VoIP** menu > **GW and IP to IP** > **DTMF and Supplementary** > **Supplementary Services**).
- The Caller ID Permissions table can also be configured using the table ini file parameter, EnableCallerID.

➤ To configure Caller ID permissions per port:

1. Open the Caller ID Permissions page (**Configuration** tab > **VoIP** menu > **GW and IP to IP** > **Analog Gateway** > **Caller ID Permissions**).

Gateway Port	Caller ID
Module 1 Port 1 FXS	Enable <input type="button" value="v"/>
Module 1 Port 2 FXS	Disable <input type="button" value="v"/>
Module 2 Port 1 FXO	<input type="button" value="v"/>
Module 2 Port 2 FXO	<input type="button" value="v"/>
Module 2 Port 3 FXO	<input type="button" value="v"/>
Module 2 Port 4 FXO	<input type="button" value="v"/>

2. Configure the table as required. For a description of the parameter, see the table below.
3. Click **Submit** to apply your changes.

Caller ID Permissions Table Parameter Description

Parameter	Description
Caller ID [EnableCallerId_IsEnabled]	Enables Caller ID generation (FXS) or detection (FXO) per port. <ul style="list-style-type: none"> ▪ [0] Disable ▪ [1] Enable

27.10 Configuring Call Waiting

The Call Waiting table allows you to enable or disable call waiting per FXS port.



Notes:

- This page is applicable only to FXS interfaces.
- You can enable or disable call waiting for all the device's ports using the global parameter, 'Enable Call Waiting' in the Supplementary Services page (**Configuration** tab > **VoIP** menu > **GW and IP to IP** > **DTMF and Supplementary** > **Supplementary Services**).
- The CPT file installed on the device must include a 'call waiting Ringback' tone (caller side) and a 'call waiting' tone (called side, FXS interfaces only).
- The EnableHold parameter must be enabled on both the calling and the called sides.
- For additional call waiting configuration, see the following parameters: FirstCallWaitingToneID (in the CPT file), TimeBeforeWaitingIndication, WaitingBeepDuration, TimeBetweenWaitingIndications, and NumberOfWaitingIndications.
- The Call Waiting table can also be configured using the table ini file parameter, CallWaitingPerPort.

➤ **To enable call waiting per port:**

1. Open the Call Waiting page (**Configuration** tab > **VoIP** menu > **GW and IP to IP** > **Analog Gateway** > **Call Waiting**).

Gateway Port	Call Waiting Configuration
Module 1 Port 1 FXS	Enable ▼
Module 1 Port 2 FXS	Enable ▼
Module 2 Port 1 FXO	▼
Module 2 Port 2 FXO	▼
Module 2 Port 3 FXO	▼
Module 2 Port 4 FXO	▼

2. Configure the table as required. For a description of the parameter, see the table below.
3. Click **Submit** to apply your changes.

Call Waiting Table Parameter Description

Parameter	Description
Call Waiting Configuration [CallWaitingPerPort_IsEnabled]	<p>Enables call waiting for the port.</p> <ul style="list-style-type: none"> ▪ [0] Disable ▪ [1] Enable = Enables call waiting for the port. When the device receives a call on a busy port, it responds with a SIP 182 response (not with a 486 busy). The device plays a call waiting indication signal. When the device detects a hook-flash from the FXS port, the device switches to the waiting call. The device that initiated the waiting call plays a call waiting ringback tone to the calling party after a 182 response is received.

27.11 Rejecting Anonymous Calls

You can configure the device to reject anonymous calls received from the IP and destined for a specific FXS port. This can be configured using the ini file parameter, `RejectAnonymousCallPerPort`. If configured, when an FXS interface receives an anonymous call, the device rejects the call and responds with a SIP 433 (Anonymity Disallowed) response. For a description of the parameter see 'Caller ID Parameters' on page 721.

27.12 Configuring FXS Distinctive Ringing and Call Waiting Tones per Source/Destination Number

You can configure a distinctive ringing tone and call waiting tone per calling (source) and/or called (destination) number (or prefix) for IP-to-Tel calls. This feature can be configured per FXS endpoint or for a range of FXS endpoints. Therefore, different tones can be played per FXS endpoint depending on the source and/or destination number of the received call. You can also configure multiple entries with different source and/or destination prefixes and tones for the same FXS port.

Typically, the played ring and/or call waiting tone is indicated in the SIP Alert-info header field of the received INVITE message. If this header is not present in the received INVITE, then this feature is used and the tone played is according to the settings in this table.



Notes:

- This page is applicable only to FXS interfaces.
- The Tone Index table can also be configured using the table ini file parameter, `ToneIndex`.

➤ To configure distinctive ringing and call waiting per FXS port:

1. Open the Tone Index Table page (**Configuration** tab > **VoIP** menu > **GW and IP to IP** > **Analog Gateway** > **Tone Index**).
2. Click the **Add** button; the following dialog box appears:

Figure 27-6: Tone Index Table Page

Index	0
FXS Port First	1
FXS Port Last	4
Source Prefix	2
Destination Prefix	
Priority Index	1

The figure above shows a configuration example for using distinctive ringing and call waiting tones of Index #9 ('Priority Index' 1) in the CPT file for FXS endpoints 1 to 4 when a call is received from a source number with prefix 2.

3. Configure the table as required. For a description of the parameters, see the table below.
4. Click **Submit** to apply your changes.

Tone index Table Parameter Description

Parameter	Description
Index	Defines the table index entry. Up to 50 entries can be defined.
FXS Port First [ToneIndex_FXSPort_First]	Defines the first port in the FXS port range.
FXS Port Last [ToneIndex_FXSPort_Last]	Defines the last port in the FXS port range.
Source Prefix [ToneIndex_SourcePrefix]	Defines the prefix of the calling number.
Destination Prefix [ToneIndex_DestinationPrefix]	Defines the prefix of the called number.
Priority Index [ToneIndex_PriorityIndex]	Defines the index of the distinctive ringing and call waiting tones. The call waiting tone index equals to the Priority Index plus the value of the FirstCallWaitingToneID parameter. For example, if you want to use the call waiting tone in the CPT file at Index #9, you need to enter "1" as the Priority Index value and set the FirstCallWaitingToneID parameter to "8". The summation of these values is 9, i.e., index #9. The default is 0.

27.13 FXS/FXO Coefficient Types

The FXS Coefficient and FXO Coefficient types used by the device can be one of the following:

- US line type of 600 ohm AC impedance and 40 V RMS ringing voltage for REN = 2
- European standard (TBR21)

These Coefficient types are used to increase return loss and trans-hybrid loss performance for two telephony line type interfaces (US or European). This adaptation is performed by modifying the telephony interface characteristics. This means, for example, that changing impedance matching or hybrid balance doesn't require hardware modifications, so that a single device is able to meet requirements for different markets. The digital design of the filters and gain stages also ensures high reliability, no drifts (over temperature or time) and simple variations between different line types.

The FXS Coefficient types provide best termination and transmission quality adaptation for two FXS line type interfaces. This parameter affects the following AC and DC interface parameters:

- DC (battery) feed characteristics
- AC impedance matching
- Transmit gain
- Receive gain
- Hybrid balance
- Frequency response in transmit and receive direction

- Hook thresholds
- Ringing generation and detection parameters
- **To select the FXO and FXS Coefficient types:**
- 1. Open the Analog Settings page (**Configuration** tab > **VoIP** menu > **Media** > **Analog Settings**). This page includes the Coefficient type parameters, as shown below:

Figure 27-7: FXS/FXO Coefficient Parameters in Analog Settings Page

⚡ FXS Coefficient Type	USA
⚡ FXO Coefficient Type	USA

2. From the 'FXS Coefficient Type' drop-down list (FXSCountryCoefficients), select the required FXS Coefficient type.
3. From the 'FXO Coefficient Type' drop-down list (CountryCoefficients), select the required FXO Coefficient type.
4. Click **Submit**.
5. Save your settings to the flash memory ("burn") with a device reset.

27.14 FXO Operating Modes

This section provides a description of the device's FXO operating modes:

- For IP-to-Tel calls (see 'FXO Operations for IP-to-Tel Calls' on page 403)
- For Tel-to-IP calls (see 'FXO Operations for Tel-to-IP Calls' on page 406)
- Call termination on FXO devices (see 'Call Termination on FXO Devices' on page 408)


27.14.1 FXO Operations for IP-to-Tel Calls

The FXO device provides the following operating modes for IP-to-Tel calls:

- One-stage dialing (see 'One-Stage Dialing' on page 403)
 - Waiting for dial tone (see 'Two-Stage Dialing' on page 405)
 - Time to wait before dialing
 - Answer supervision
- Two-stage dialing (see 'Two-Stage Dialing' on page 405)
- Dialing time: DID wink (see 'DID Wink' on page 405)

27.14.1.1 One-Stage Dialing

One-stage dialing is when the FXO device receives an IP-to-Tel call, off-hooks the PBX line connected to the telephone, and then immediately dials the destination telephone number. In other words, the IP caller doesn't dial the PSTN number upon hearing a dial tone.



One-stage dialing incorporates the following FXO functionality:

- **Waiting for Dial Tone:** Enables the device to dial the digits to the Tel side only after detecting a dial tone from the PBX line. The *ini* file parameter `IsWaitForDialTone` is used to configure this operation.
- **Time to Wait Before Dialing:** Defines the time (in msec) between seizing the FXO line and starting to dial the digits. The *ini* file parameter `WaitForDialTime` is used to configure this operation.




Note: The *ini* file parameter `IsWaitForDialTone` must be disabled for this mode.

- **Answer Supervision:** The Answer Supervision feature enables the FXO device to determine when a call is connected, by using one of the following methods:
 - **Polarity Reversal:** the device sends a 200 OK in response to an INVITE only when it detects a polarity reversal.
 - **Voice Detection:** the device sends a 200 OK in response to an INVITE only when it detects the start of speech (fax or modem answer tone) from the Tel side. Note that the IPM detectors must be enabled.

27.14.1.2 Two-Stage Dialing

Two-stage dialing is when the IP caller is required to dial twice. The caller initially dials to the FXO device and only after receiving a dial tone from the PBX (via the FXO device), dials the destination telephone number.

Figure 27-8: Call Flow for Two-Stage Dialing



Two-stage dialing implements the Dialing Time feature. Dialing Time allows you to define the time that each digit can be separately dialed. By default, the overall dialing time per digit is 200 msec. The longer the telephone number, the greater the dialing time.

The relevant parameters for configuring Dialing Time include the following:

- **DTMFDigitLength** (100 msec): time for generating DTMF tones to the PSTN (PBX) side
- **DTMFInterDigitInterval** (100 msec): time between generated DTMF digits to PSTN (PBX) side

27.14.1.3 DID Wink

The device's FXO ports support Direct Inward Dialing (DID). DID is a service offered by telephone companies that enables callers to dial directly to an extension on a PBX without the assistance of an operator or automated call attendant. This service makes use of DID trunks, which forward only the last three to five digits of a phone number to the PBX. If, for example, a company has a PBX with extensions 555-1000 to 555-1999, and a caller dials 555-1234, the local central office (CO) would forward, for example, only 234 to the PBX. The PBX would then ring extension 234.

DID wink enables the originating end to seize the line by going off-hook. It waits for acknowledgement from the other end before sending digits. This serves as an integrity check that identifies a malfunctioning trunk and allows the network to send a re-order tone to the calling party.

The "start dial" signal is a wink from the PBX to the FXO device. The FXO then sends the last four to five DTMF digits of the called number. The PBX uses these digits to complete the routing directly to an internal station (telephone or equivalent).

- DID Wink can be used for connection to EIA/TIA-464B DID Loop Start lines
- Both FXO (detection) and FXS (generation) are supported

27.14.2 FXO Operations for Tel-to-IP Calls


The FXO device provides the following FXO operating modes for Tel-to-IP calls:

- Automatic Dialing (see 'Automatic Dialing' on page 406)
- Collecting Digits Mode (see 'Collecting Digits Mode' on page 407)
- FXO Supplementary Services (see 'FXO Supplementary Services' on page 407)
 - Hold/Transfer Toward the Tel side
 - Hold/Transfer Toward the IP side
 - Blind Transfer to the Tel side

27.14.2.1 Automatic Dialing

Automatic dialing is defined using the Web interface's Automatic Dialing (TargetOfChannel ini file parameter) page, described in see 'Configuring Automatic Dialing' on page 394.


The SIP call flow diagram below illustrates Automatic Dialing.



27.14.2.2 Collecting Digits Mode

When automatic dialing is not defined, the device collects the digits. The SIP call flow diagram below illustrates the Collecting Digits Mode.

Figure 27-9: Call Flow for Collecting Digits Mode



27.14.2.3 FXO Supplementary Services

The FXO supplementary services include the following:

- Hold / Transfer toward the Tel side:** The *ini* file parameter `LineTransferMode` must be set to 0 (default). If the FXO receives a hook-flash from the IP side (using out-of-band or RFC 2833), the device sends the hook-flash to the Tel side by performing one of the following:

- Performing a hook flash (i.e., on-hook and off-hook)
- Sending a hook-flash code (defined by the *ini* file parameter `HookFlashCode`)

The PBX may generate a dial tone that is sent to the IP, and the IP side may dial digits of a new destination.

- Blind Transfer to the Tel side:** A blind transfer is one in which the transferring phone connects the caller to a destination line before ringback begins. The *ini* file parameter `LineTransferMode` must be set to 1.

The blind transfer call process is as follows:

- FXO receives a REFER request from the IP side
- FXO sends a hook-flash to the PBX, dials the digits (that are received in the Refer-To header), and then drops the line (on-hook). Note that the time between flash to dial is according to the `WaitForDialTime` parameter.
- PBX performs the transfer internally

- Hold / Transfer toward the IP side:** The FXO device doesn't initiate hold / transfer as a response to input from the Tel side. If the FXO receives a REFER request (with or without replaces), it generates a new INVITE according to the Refer-To header.

27.14.3 Call Termination on FXO Devices

This section describes the device's call termination capabilities for its FXO interfaces:

- Calls terminated by a PBX (see 'Call Termination by PBX' on page 408)
- Calls terminated before call establishment (see 'Call Termination before Call Establishment' on page 409)
- Ring detection timeout (see 'Ring Detection Timeout' on page 409)

27.14.3.1 Calls Termination by PBX

The FXO device supports various methods for identifying when a call has been terminated by the PBX.

The PBX doesn't disconnect calls, but instead signals to the device that the call has been disconnected using one of the following methods:

- **Detection of polarity reversal/current disconnect:** The call is immediately disconnected after polarity reversal or current disconnect is detected on the Tel side (assuming the PBX/CO generates this signal). This is the recommended method.

Relevant parameters: EnableReversalPolarity, EnableCurrentDisconnect, CurrentDisconnectDuration, CurrentDisconnectDefaultThreshold, and TimeToSampleAnalogLineVoltage.

- **Detection of Reorder, Busy, Dial, and Special Information Tone (SIT) tones:** The call is immediately disconnected after a Reorder, Busy, Dial, or SIT tone is detected on the Tel side (assuming the PBX / CO generates this tone). This method requires the correct tone frequencies and cadence to be defined in the Call Progress Tones file. If these frequencies are unknown, define them in the CPT file. The tone produced by the PBX / CO must be recorded and its frequencies analyzed. Adding a reorder tone to the CPT file can be done using AudioCodes CPTWizard utility (refer to the *CPTWizard Utility User's Guide*). This method is slightly less reliable than the previous one. You can use the CPTWizard to analyze Call Progress Tones generated by any PBX or telephone network.

Relevant parameters: DisconnectOnBusyTone and DisconnectOnDialTone.

- **Detection of silence:** The call is disconnected after silence is detected on both call directions for a specific (configurable) amount of time. The call isn't disconnected immediately; therefore, this method should only be used as a backup option.

Relevant parameters: EnableSilenceDisconnect and FarEndDisconnectSilencePeriod.

- **Special DTMF code:** A digit pattern that when received from the Tel side, indicates to the device to disconnect the call.

Relevant *ini* file parameter: TelDisconnectCode.

- **Interruption of RTP stream:** Relevant parameters: BrokenConnectionEventTimeout and DisconnectOnBrokenConnection.



Note: This method operates correctly only if silence suppression is not used.

- **Protocol-based termination of the call from the IP side**



Note: The implemented disconnect method must be supported by the CO or PBX.

27.14.3.2 Call Termination before Call Establishment

The device supports the following call termination methods before a call is established:

- **Call termination upon receipt of SIP error response (in Automatic Dialing mode):** By default, when the FXO device operates in Automatic Dialing mode, there is no method to inform the PBX if a Tel-to-IP call has failed (SIP error response - 4xx, 5xx or 6xx - is received). The reason is that the FXO device does not seize the line until a SIP 200 OK response is received. Use the `FXOAutoDialPlayBusyTone` parameter to allow the device to play a busy / reorder tone to the PSTN line if a SIP error response is received. The FXO device seizes the line (off-hook) for the duration defined by the `TimeForReorderTone` parameter. After playing the tone, the line is released (on-hook).
- **Call termination after caller (PBX) on-hooks phone (Ring Detection Timeout feature):** This method operates in one of the following manners:
 - **Automatic Dialing is enabled:** if the remote IP party doesn't answer the call and the ringing signal (from the PBX) stops for a user-defined time (configured by the parameter `FXOBetweenRingTime`), the FXO device releases the IP call.
 - **No automatic dialing and Caller ID is enabled:** the device seizes the line after detection of the second ring signal (allowing detection of caller ID sent between the first and the second rings). If the second ring signal is not received within this timeout, the device doesn't initiate a call to IP.

27.14.3.3 Ring Detection Timeout

The operation of Ring Detection Timeout depends on the following:

- **Automatic dialing is disabled and Caller ID is enabled:** if the second ring signal is not received for a user-defined time (using the parameter `FXOBetweenRingTime`), the FXO device doesn't initiate a call to the IP.
- **Automatic dialing is enabled:** if the remote party doesn't answer the call and the ringing signal stops for a user-defined time (using the parameter `FXOBetweenRingTime`), the FXO device releases the IP call.

Ring Detection Timeout supports full ring cycle of ring on and ring off (from ring start to ring start).

27.15 Remote PBX Extension between FXO and FXS Devices

Remote PBX extension offers a company the capability of extending the "power" of its local PBX by allowing remote phones (remote offices) to connect to the company's PBX over the IP network (instead of via PSTN). This is as if the remote office is located in the head office (where the PBX is installed). PBX extensions are connected through FXO ports to the IP network, instead of being connected to individual telephone stations. At the remote office, FXS units connect analog phones to the same IP network. To produce full transparency, each FXO port is mapped to an FXS port (i.e., one-to-one mapping). This allows individual extensions to be extended to remote locations. To call a remote office worker, a PBX user or a PSTN caller simply dials the PBX extension that is mapped to the remote FXS port.


This section provides an example on how to implement a remote telephone extension through the IP network, using FXO and FXS interfaces. In this configuration, the FXO device routes calls received from the PBX to the 'Remote PBX Extension' connected to the FXS device. The routing is transparent as if the telephone connected to the FXS device is directly connected to the PBX.

The following is required:

- FXO interfaces with ports connected directly to the PBX lines (shown in the figure

below)

- FXS interfaces for the 'remote PBX extension'
- Analog phones (POTS)
- PBX (one or more PBX loop start lines)
- LAN network



27.15.1 Dialing from Remote Extension (Phone at FXS)

The procedure below describes how to dial from the 'remote PBX extension' (i.e., phone connected to the FXS interface).

- **To make a call from the FXS interface:**
 1. Off-hook the phone and wait for the dial tone from the PBX. This is as if the phone is connected directly to the PBX. The FXS and FXO interfaces establish a voice path connection from the phone to the PBX immediately after the phone is off-hooked.
 2. Dial the destination number (e.g., phone number 201). The DTMF digits are sent over IP directly to the PBX. All the audible tones are generated from the PBX (such as ringback, busy, or fast busy tones). One-to-one mapping occurs between the FXS ports and PBX lines.
 3. The call disconnects when the phone connected to the FXS goes on-hook.

27.15.2 Dialing from PBX Line or PSTN

The procedure below describes how to dial from a PBX line (i.e., from a telephone directly connected to the PBX) or from the PSTN to the 'remote PBX extension' (i.e., telephone connected to the FXS interface).

- **To dial from a telephone directly connected to the PBX or from the PSTN:**
 - Dial the PBX subscriber number (e.g., phone number 101) in the same way as if the user's phone was connected directly to the PBX. As soon as the PBX rings the FXO device, the ring signal is 'sent' to the phone connected to the FXS device. Once the

phone connected to the FXS device is off-hooked, the FXO device seizes the PBX line and the voice path is established between the phone and PBX.

There is one-to-one mapping between PBX lines and FXS device ports. Each PBX line is routed to the same phone (connected to the FXS device). The call disconnects when the phone connected to the FXS device is on-hooked.

27.15.3 Message Waiting Indication for Remote Extensions

The device supports the relaying of Message Waiting Indications (MWI) for remote extensions (and voice mail applications). Instead of subscribing to an MWI server to receive notifications of pending messages, the FXO device receives subscriptions from the remote FXS device and notifies the appropriate extension when messages (and the number of messages) are pending.

The FXO device detects an MWI message from the Tel (PBX) side using any one of the following methods:

- 100 VDC (sent by the PBX to activate the phone's lamp)
- Stutter dial tone from the PBX
- MWI display signal (according to the parameter CallerIDType)

Upon detection of an MWI message, the FXO device sends a SIP NOTIFY message to the IP side. When receiving this NOTIFY message, the remote FXS device generates an MWI signal toward its Tel side.



27.15.4 Call Waiting for Remote Extensions

When the FXO device detects a Call Waiting indication (FSK data of the Caller Id - CallerIDType2) from the PBX, it sends a proprietary INFO message, which includes the caller identification to the FXS device. Once the FXS device receives this INFO message, it plays a call waiting tone and sends the caller ID to the relevant port for display. The remote extension connected to the FXS device can toggle between calls using the Hook Flash button.



27.15.5 FXS Gateway Configuration

The procedure below describes how to configure the FXS interface (at the 'remote PBX extension').

➤ **To configure the FXS interface:**

1. In the Trunk Group Table page (see Configuring Trunk Group Table on page 291, assign the phone numbers 100 to 104 to the device's endpoints.

Figure 27-10: Assigning Phone Numbers to FXS Endpoints

Group Index	Module	From Trunk	To Trunk	Channels	Phone Number	Trunk Group ID
1	Module 3 FXS	1	1	1-4	100	0

2. In the Automatic Dialing page (see 'Configuring Automatic Dialing' on page 394), enter the phone numbers of the FXO device in the 'Destination Phone Number' fields. When a phone connected to Port #1 off-hooks, the FXS device automatically dials the number '200'.

Figure 27-11: Automatic Dialing for FXS Ports

Gateway Port	Destination Phone Number	Auto Dial Status
Module 3 Port 1 FXS	200	Enable
Module 3 Port 2 FXS	201	Enable
Module 3 Port 3 FXS	202	Enable
Module 3 Port 4 FXS	203	Enable

3. In the Outbound IP Routing Table page (see 'Configuring Outbound IP Routing Table' on page 323), enter 20 for the destination phone prefix, and 10.1.10.2 for the IP address of the FXO device.

Figure 27-12: FXS Tel-to-IP Routing Configuration

	Src. Trunk Group ID	Dest. Phone Prefix	Source Phone Prefix	Dest. IP Address
1		20	*	10.1.10.2



Note: For the transfer to function in remote PBX extensions, Hold must be disabled at the FXS device (i.e., Enable Hold = 0) and hook-flash must be transferred from the FXS to the FXO (HookFlashOption = 4).

27.15.6 FXO Gateway Configuration

The procedure below describes how to configure the FXO interface (to which the PBX is directly connected).

➤ **To configure the FXO interface:**

1. In the Trunk Group Table page (see Configuring Trunk Group Table on page 291, assign the phone numbers 200 to 204 to the device's FXO endpoints.

Figure 27-13: Assigning Phone Numbers to FXO Ports

Group Index	Module	From Trunk	To Trunk	Channels	Phone Number
1	Module 3 FXO ▾	▾	▾	1-4	200

2. In the Automatic Dialing page, enter the phone numbers of the FXS device in the 'Destination Phone Number' fields. When a ringing signal is detected at Port #1, the FXO device automatically dials the number '100'.

Figure 27-14: FXO Automatic Dialing Configuration

Gateway Port	Destination Phone Number	Auto Dial Status
Module 3 Port 1 FXO	100	Enable ▾
Module 3 Port 2 FXO	101	Enable ▾
Module 3 Port 3 FXO	102	Enable ▾
Module 3 Port 4 FXO	103	Enable ▾

3. In the Outbound IP Routing Table page, enter 10 in the 'Destination Phone Prefix' field, and the IP address of the FXS device (10.1.10.3) in the field 'IP Address'.

Figure 27-15: FXO Tel-to-IP Routing Configuration

	Dest. Phone Prefix	Source Phone Prefix	- >	Dest. IP Address
1	10	*		10.1.10.3

4. In the FXO Settings page (see 'Configuring FXO Parameters' on page 392), set the parameter 'Dialing Mode' to **Two Stages** (IsTwoStageDial = 1).

Reader's Notes

Part VI

Stand-Alone Survivability Application

28 Overview

The device's Stand-Alone Survivability (SAS) feature ensures telephony communication continuity (survivability) for enterprises using hosted IP services (such as IP Centrex) or IP-PBX in cases of failure of these entities. In case of failure of the IP Centrex, IP-PBX servers (or even WAN connection and access Internet modem), the enterprise typically loses its internal telephony service at any branch, between its offices, and with the external environment. Typically, these failures also lead to the inability to make emergency calls (e.g., 911 in North America). Despite these possible points of failure, the device's SAS feature ensures that the enterprise's telephony services (e.g., SIP IP phones or soft phones) are maintained, by routing calls to the PSTN (i.e., providing PSTN fallback).



Notes:

- The SAS application is available only if the device is installed with the SAS Software License Key.
- Throughout this section, the term *user agent* (UA) refers to the enterprise's LAN phone user (i.e., SIP telephony entities such as IP phones).
- Throughout this section, the term *proxy* or *proxy server* refers to the enterprise's centralized IP Centrex or IP-PBX.
- Throughout this section, the term SAS refers to the SAS application running on the device.

28.1 SAS Operating Modes

The device's SAS application can be implemented in one of the following main modes:

- **Outbound Proxy:** In this mode, SAS receives SIP REGISTER requests from the enterprise's UAs and forwards these requests to the external proxy (i.e., outbound proxy). When a connection with the external proxy fails, SAS enters SAS emergency state and serves as a proxy, by handling internal call routing for the enterprise's UAs - routing calls between UAs and if setup, routing calls between UAs and the PSTN. For more information, see 'SAS Outbound Mode' on page 418.
- **Redundant Proxy:** In this mode, the enterprise's UAs register with the external proxy and establish calls directly through the external proxy, without traversing SAS (or the device per se'). Only when connection with the proxy fails, do the UAs register with SAS, serving now as the UAs redundant proxy. SAS then handles the calls between UAs, and between the UAs and the PSTN (if setup). This mode is operational only during SAS in emergency state. This mode can be implemented, for example, for proxies that accept only SIP messages that are sent directly from the UAs. For more information, see 'SAS Redundant Mode' on page 419.



Note: It is recommended to implement the SAS outbound mode.

28.1.1 SAS Outbound Mode


This section describes the SAS outbound mode, which includes the following states:

- Normal state (see 'Normal State' on page 418)
- Emergency state (see 'Emergency State' on page 418)

28.1.1.1 Normal State

In normal state, SAS receives REGISTER requests from the enterprise's UAs and forwards them to the external proxy (i.e., outbound proxy). Once the proxy replies with a SIP 200 OK, the device records the Contact and address of record (AOR) of the UAs in its internal SAS registration database. Therefore, in this mode, SAS maintains a database of all the registered UAs in the network. SAS also continuously maintains a keep-alive mechanism toward the external proxy, using SIP OPTIONS messages. The figure below illustrates the operation of SAS outbound mode in normal state:

Figure 28-1: SAS Outbound Mode in Normal State (Example)



28.1.1.2 Emergency State

When a connection with the external proxy fails (detected by the device's keep-alive messages), the device enters SAS emergency state. The device serves as a proxy for the UAs, by handling internal call routing of the UAs (within the LAN enterprise).




Note: SAS can also enter Emergency state if no response is received from the proxy for sent OPTIONS, INVITE, or REGISTER messages. To configure this, set the SASEnteringEmergencyMode parameter to 1.

When the device receives calls, it searches its SAS registration database to locate the destination address (according to AOR or Contact). If the destination address is not found, SAS forwards the call to the default gateway. Typically, the default gateway is defined as the device itself (on which SAS is running), and if the device has PSTN interfaces, the enterprise preserves its capability for outgoing calls (from UAs to the PSTN network).

The routing logic of SAS in emergency state is described in detail in 'SAS Routing in Emergency State' on page 423.

The figure below illustrates the operation of SAS outbound mode in emergency state:

Figure 28-2: SAS Outbound Mode in Emergency State (Example)



When emergency state is active, SAS continuously attempts to communicate with the external proxy, using keep-alive SIP OPTIONS. Once connection to the proxy returns, the device exits SAS emergency state and returns to SAS normal state, as explained in 'Exiting Emergency and Returning to Normal State' on page 420.

28.1.2 SAS Redundant Mode

In SAS redundant mode, the enterprise's UAs register with the external proxy and establish calls directly through it, without traversing SAS (or the device per se). Only when connection with the proxy fails, do the UAs register with SAS, serving now as the UAs redundant proxy. SAS then handles the calls between UAs, and between the UAs and the PSTN (if setup).

This mode is operational only during SAS in emergency state.




Note: In this SAS deployment, the UAs (e.g., IP phones) must support configuration for primary and secondary proxy servers (i.e., proxy redundancy), as well as homing. Homing allows the UAs to switch back to the primary server from the secondary proxy once the connection to the primary server returns (UAs check this using keep-alive messages to the primary server). If homing is not supported by the UAs, you can configure SAS to ignore messages received from UAs in normal state (the 'SAS Survivability Mode' parameter must be set to 'Always Emergency' / 2) and thereby, "force" the UAs to switch back to their primary proxy.

28.1.2.1 Normal State

In normal state, the UAs register and operate directly with the external proxy.


Figure 28-3: SAS Redundant Mode in Normal State (Example)



28.1.2.2 Emergency State

If the UAs detect that their primary (external) proxy does not respond, they immediately register to SAS and start routing calls to it.

Figure 28-4: SAS Redundant Mode in Emergency State (Example)



28.1.2.3 Exiting Emergency and Returning to Normal State

Once the connection with the primary proxy is re-established, the following occurs:

- **UAs:** Switch back to operate with the primary proxy.
- **SAS:** Ignores REGISTER requests from the UAs, forcing the UAs to switch back to the primary proxy.

Note: This is applicable only if the 'SAS Survivability Mode' parameter is set to 'Always Emergency' (2).


28.2 SAS Routing

This section provides flowcharts describing the routing logic for SAS in normal and emergency states.

28.2.1 SAS Routing in Normal State


The flowchart below displays the routing logic for SAS in normal state for INVITE messages received from UAs:

Figure 28-5: Flowchart of INVITE from UA's in SAS Normal State



The flowchart below displays the routing logic for SAS in normal state for INVITE messages received from the external proxy:


Figure 28-6: Flowchart of INVITE from Primary Proxy in SAS Normal State



28.2.2 SAS Routing in Emergency State

The flowchart below shows the routing logic for SAS in emergency state:

Figure 28-7: Flowchart for SAS Emergency State



Reader's Notes

29 SAS Configuration

SAS supports various configuration possibilities, depending on how the device is deployed in the network and the network architecture requirements. This section provides step-by-step procedures on configuring the SAS application, using the device's Web interface.

The SAS configuration includes the following:

- General SAS configuration that is common to all SAS deployment types (see 'General SAS Configuration' on page 425)
- SAS outbound mode (see 'Configuring SAS Outbound Mode' on page 428)
- SAS redundant mode (see 'Configuring SAS Redundant Mode' on page 429)
- Gateway and SAS applications deployed together (see 'Configuring Gateway Application with SAS' on page 429)
- Optional, advanced SAS features (see 'Advanced SAS Configuration' on page 433)

29.1 General SAS Configuration

This section describes the general configuration required for the SAS application. This configuration is applicable to all SAS modes.

29.1.1 Enabling the SAS Application

Before you can configure SAS, you need to enable the SAS application on the device. Once enabled, the **SAS** menu and related pages appear in the device's Web interface.



Note: The SAS application is available only if the device is installed with the SAS Software License Key. If your device is not installed with the SAS feature, contact your AudioCodes representative.

➤ **To enable the SAS application:**

1. Open the Applications Enabling page (**Configuration** tab > **VoIP** menu > **Applications Enabling** > **Applications Enabling**).
2. From the 'SAS Application' drop-down list, select **Enable**.



3. Click **Submit**.
4. Save the changes to the flash memory with a device reset.

29.1.2 Configuring Common SAS Parameters

The procedure below describes how to configure SAS settings that are common to all SAS modes. This includes various SAS parameters as well as configuring the Proxy Set for the SAS proxy (if required). The SAS Proxy Set ID defines the address of the UAs' external proxy.

➤ **To configure common SAS settings:**

1. Open the SAS Configuration page (**Configuration** tab > **VoIP** menu > **SAS** > **Stand Alone Survivability**).
2. Define the port used for sending and receiving SAS messages. This can be any of the following port types:
 - UDP port - defined in the 'SAS Local SIP UDP Port' field
 - TCP port - defined in the 'SAS Local SIP TCP Port' field
 - TLS port - defined in the 'SAS Local SIP TLS Port' field



Note: This SAS port must be different than the device's local gateway port (i.e., that defined for the 'SIP UDP/TCP/TLS Local Port' parameter in the SIP General Parameters page - **Configuration** tab > **VoIP** menu > **SIP Definitions** > **General Parameters**).

3. In the 'SAS Default Gateway IP' field, define the IP address and port (in the format *x.x.x.x:port*) of the device (i.e., Gateway application). Note that the port of the device is defined by the parameter 'SIP UDP Local Port' (refer to the note in Step 2 above).
4. In the 'SAS Registration Time' field, define the value for the SIP Expires header, which is sent in the 200 OK response to an incoming REGISTER message when SAS is in emergency state.
5. From the 'SAS Binding Mode' drop-down list, select the database binding mode:
 - **0-URI:** If the incoming AOR in the REGISTER request uses a 'tel:' URI or 'user=phone', the binding is done according to the Request-URI user part only. Otherwise, the binding is done according to the entire Request-URI (i.e., user and host parts - user@host).
 - **1-User Part Only:** Binding is done according to the user part only.

You must select **1-User Part Only** in cases where the UA sends REGISTER messages as SIP URI, but the INVITE messages sent to this UA include a Tel URI. For example, when the AOR of an incoming REGISTER is sip:3200@domain.com, SAS adds the entire SIP URI (e.g., sip:3200@domain.com) to its database (when the parameter is set to '0-URI'). However, if a subsequent Request-URI of an INVITE message for this UA arrives with sip:3200@10.1.2.3 user=phone, SAS searches its database for "3200", which it does not find. Alternatively, when this parameter is set to '1-User Part Only', then upon receiving a REGISTER message with sip:3200@domain.com, SAS adds only the user part (i.e., "3200") to its database. Therefore, if a Request-URI of an INVITE message for this UA arrives with sip:3200@10.1.2.3 user=phone, SAS can successfully locate the UA in its database.

Figure 29-1: Configuring Common Settings

SAS Local SIP UDP Port	5080
SAS Default Gateway IP	
SAS Registration Time	20
SAS Local SIP TCP Port	5080
SAS Local SIP TLS Port	5081
SAS Proxy Set	2
SAS Emergency Numbers	
SAS Binding Mode	1-User Part Only
SAS Survivability Mode	Standard
Enable ENUM	Disable
Enable Record-Route	Disable
SAS Block Unregistered Users	Un-Block
Redundant SAS Proxy Set	-1
SAS Inbound Manipulation Mode	None

6. In the 'SAS Proxy Set' field, enter the Proxy Set used for SAS. The SAS Proxy Set must be defined only for the following SAS modes:

- **Outbound mode:** In SAS normal state, SAS forwards REGISTER and INVITE messages received from the UAs to the proxy servers defined in this Proxy Set.
- **Redundant mode and only if UAs don't support homing:** SAS sends keep-alive messages to this proxy and if it detects that the proxy connection has resumed, it ignores the REGISTER messages received from the UAs, forcing them to send their messages directly to the proxy.

If you define a SAS Proxy Set ID, you must configure the Proxy Set as described in Step 8 below.

7. Click **Submit** to apply your settings.
8. If you defined a SAS Proxy Set ID in Step 6 above, then you must configure the SAS Proxy Set ID:
- Open the Proxy Sets Table page (**Configuration** tab > **VoIP** menu > **Control Networks** > **Proxy Set Table**).
 - From the 'Proxy Set ID' drop-down list, select the required Proxy Set ID.



Notes:

- The selected Proxy Set ID number must be the same as that specified in the 'SAS Proxy Set' field in the 'SAS Configuration page (see Step 6).
- Do not use Proxy Set ID 0.

- In the 'Proxy Address' field, enter the IP address of the external proxy server.

- b. From the 'Enable Proxy Keep Alive' drop-down list, select **Using Options**. This instructs the device to send SIP OPTIONS messages to the proxy for the keep-alive mechanism.

Figure 29-2: Defining SAS Proxy Server

Proxy Set ID: 2

	Proxy Address	Transport Type
1	10.15.4.52	TLS
2		
3		
4		
5		

Enable Proxy Keep Alive: Using Options

Proxy Keep Alive Time: 60

Proxy Load Balancing Method: Disable

Is Proxy Hot Swap: No

Proxy Redundancy Mode: Not Configured

SRD Index: 0

Classification Input: IP only

- c. Click **Submit** to apply your settings.

29.2 Configuring SAS Outbound Mode

This section describes how to configure the SAS outbound mode. These settings are in addition to the ones described in 'Configuring Common SAS Parameters' on page 426.



Note: The VoIP CPEs (such as IP phones or residential gateways) need to be defined so that their proxy and registrar destination addresses and ports are the same as that configured for the device's SAS IP address and SAS local SIP port. In some cases, on the UAs, it is also required to define SAS as their outbound proxy, meaning that messages sent by the UAs include the host part of the external proxy, but are sent (on Layer 3/4) to the IP address / UDP port of SAS.

- **To configure SAS outbound mode:**
 1. Open the SAS Configuration page (**Configuration** tab > **VoIP** menu > **SAS** > **Stand Alone Survivability**).
 2. From the 'SAS Survivability Mode' drop-down list, select **Standard**.
 3. Click **Submit**.

29.3 Configuring SAS Redundant Mode

This section describes how to configure the SAS redundant mode. These settings are in addition to the ones described in 'Configuring Common SAS Parameters' on page 426.



Note: The VoIP CPEs (such as IP phones or residential gateways) need to be defined so that their primary proxy is the external proxy, and their redundant proxy destination addresses and port is the same as that configured for the device's SAS IP address and SAS SIP port.

➤ **To configure SAS redundant mode:**

1. Open the SAS Configuration page (**Configuration** tab > **VoIP** menu > **SAS** > **Stand Alone Survivability**).
2. From the 'SAS Survivability Mode' drop-down list, select one of the following, depending on whether the UAs support homing (i.e., they always attempt to operate with the primary proxy, and if using the redundant proxy, they switch back to the primary proxy whenever it's available):
 - **UAs support homing:** Select **Always Emergency**. This is because SAS does not need to communicate with the primary proxy of the UAs; SAS serves only as the redundant proxy of the UAs. When the UAs detect that their primary proxy is available, they automatically resume communication with it instead of with SAS.
 - **UAs do not support homing:** Select **Ignore REGISTER**. SAS uses the keep-alive mechanism to detect availability of the primary proxy (defined by the SAS Proxy Set). If the connection with the primary proxy resumes, SAS ignores the messages received from the UAs, forcing them to send their messages directly to the primary proxy.
3. Click **Submit**.

29.4 Configuring Gateway Application with SAS

If you want to run both the Gateway and SAS applications on the device, the configuration described in this section is required. The configuration steps depend on whether the Gateway application is operating with SAS in outbound mode or SAS in redundant mode.



Note: The Gateway application must use the same SAS operation mode as the SIP UAs. For example, if the UAs use the SAS application as a redundant proxy (i.e., SAS redundancy mode), then the Gateway application must do the same.


29.4.1 Gateway with SAS Outbound Mode

The procedure below describes how to configure the Gateway application with SAS outbound mode.

➤ **To configure Gateway application with SAS outbound mode:**


1. Define the proxy server address for the Gateway application:
 - a. Open the Proxy & Registration page (**Configuration** tab > **VoIP** menu > **SIP Definitions** submenu > **Proxy & Registration**).
 - b. From the 'Use Default Proxy' drop-down list, select **Yes**.

Figure 29-3: Enabling Proxy Server for Gateway Application



- c. Click **Submit**.
- d. Open the Proxy Sets Table page (**Configuration** tab > **VoIP** menu > **Control Network** submenu > **Proxy Sets** Table).
- e. From the 'Proxy Set ID' drop-down list, select **0**.
- f. In the first 'Proxy Address' field, enter the IP address and port of the device (in the format `x.x.x.x:port`). This is the port as defined in the 'SAS Local UDP/TCP/TLS Port' field (see 'Configuring Common SAS Parameters' on page 426).

Figure 29-4: Defining Proxy Server for Gateway Application



- g. Click **Submit**.

2. Disable use of user=phone in SIP URL:
 - a. Open the SIP General Parameters page (**Configuration** tab > **VoIP** menu > **SIP Definitions** submenu > **General Parameters**).
 - b. From the 'Use user=phone in SIP URL' drop-down list, select **No**. This instructs the Gateway application not to use *user=phone* in the SIP URL and therefore, REGISTER and INVITE messages use SIP URI. (By default, REGISTER messages are sent with *sip uri* and INVITE messages with *tel uri*.)

Figure 29-5: Disabling user=phone in SIP URL

SIP General	
NAT IP Address	0.0.0.0
PRACK Mode	Supported
Channel Select Mode	Cyclic Ascending
Enable Early Media	Disable
183 Message Behavior	Progress
Session-Expires Time	0
Minimum Session-Expires	90
Session Expires Method	Re-INVITE
Asserted Identity Mode	Disabled
Fax Signaling Method	No Fax
Detect Fax on Answer Tone	Initiate T.38 on Preamble
SIP Transport Type	UDP
SIP UDP Local Port	5060
SIP TCP Local Port	5060
SIP TLS Local Port	5061
Enable SIPs	Disable
Enable TCP Connection Reuse	Enable
TCP Timeout	0
SIP Destination Port	5060
Use user=phone in SIP URL	No

- c. Click **Submit**.

29.4.2 Gateway with SAS Redundant Mode

The procedure below describes how to configure the Gateway application with SAS redundant mode.

➤ To configure Gateway application with SAS redundant mode:

1. Define the proxy servers for the Gateway application:
 - a. Open the Proxy & Registration page (**Configuration** tab > **VoIP** menu > **SIP Definitions** submenu > **Proxy & Registration**).
 - b. From the 'Use Default Proxy' drop-down list, select **Yes**.

Figure 29-6: Enabling Proxy Server for Gateway Application

Use Default Proxy	Yes
Proxy Set Table	
Proxy Name	<input type="text"/>

- c. Click **Submit**.
- d. Open the Proxy Sets Table page (**Configuration** tab > **VoIP** menu > **Control Network** submenu > **Proxy Sets Table**).
- e. From the 'Proxy Set ID' drop-down list, select **0**.
- f. In the first 'Proxy Address' field, enter the IP address of the external proxy server.

- g. In the second 'Proxy Address' field, enter the IP address and port of the device (in the format *x.x.x.x:port*). This is the same port as defined in the 'SAS Local UDP/TCP/TLS Port' field (see 'Configuring Common SAS Parameters' on page 426).
- h. From the 'Proxy Redundancy Mode' drop-down list, select **Homing**.

Figure 29-7: Defining Proxy Servers for Gateway Application

Proxy Set ID: 0

	Proxy Address	Transport Type
1	202.10.13.1:5080	UDP
2	10.13.4.1	UDP
3		
4		
5		

Enable Proxy Keep Alive	Using Options
Proxy Keep Alive Time	60
Proxy Load Balancing Method	Disable
Is Proxy Hot Swap	No
Proxy Redundancy Mode	Homing
SRD Index	0
Classification Input	IP only

- i. Click **Submit**.
2. Disable the use of *user=phone* in the SIP URL:
 - a. Open the SIP General Parameters page (**Configuration** tab > **VoIP** menu > **SIP Definitions** submenu > **General Parameters**).
 - b. From the 'Use user=phone in SIP URL' drop-down list, select **No**. This instructs the Gateway application not to use *user=phone* in SIP URL and therefore, REGISTER and INVITE messages use SIP URI. (By default, REGISTER messages are sent with *sip uri* and INVITE messages with *tel uri*.)
 - c. Click **Submit**.

29.5 Advanced SAS Configuration

This section describes the configuration of advanced SAS features that can optionally be implemented in your SAS deployment.

29.5.1 Manipulating URI user part of Incoming REGISTER

There are scenarios in which the UAs register to the proxy server with their full phone number (for example, "976653434"), but can receive two types of INVITE messages (calls):

- INVITEs whose destination is the UAs' full number (when the call arrives from outside the enterprise)
- INVITEs whose destination is the last four digits of the UAs' phone number ("3434" in our example) when it is an internal call within the enterprise

Therefore, it is important that the device registers the UAs in the SAS registered database with their extension numbers (for example, "3434") in addition to their full numbers. To do this, you can define a manipulation rule to manipulate the SIP Request-URI user part of the AOR (in the To header) in incoming REGISTER requests. Once manipulated, it is saved in this manipulated format in the SAS registered users database in addition to the original (un-manipulated) AOR.

For example: Assume the following incoming REGISTER message is received and that you want to register in the SAS database the UA's full number as well as the last four digits from the right of the SIP URI user part:

```
REGISTER sip:10.33.38.2 SIP/2.0
Via: SIP/2.0/UDP 10.33.4.226:5050;branch=z9hG4bKac10827
Max-Forwards: 70
From: <sip: 976653434@10.33.4.226>;tag=1c30219
To: <sip: 976653434@10.33.4.226>
Call-ID: 16844@10.33.4.226
CSeq: 1 REGISTER
Contact: <sip: 976653434@10.10.10.10:5050>;expires=180
Allow:
REGISTER, OPTIONS, INVITE, ACK, CANCEL, BYE, NOTIFY, PRACK, REFER, INFO, SUB
SCRIBE, UPDATE
Expires: 180
User-Agent: Audiocodes-Sip-Gateway-/v.
Content-Length: 0
```

After manipulation, SAS registers the user in its database as follows:

- **AOR:** 976653434@10.33.4.226
- **Associated AOR:** 3434@10.33.4.226 (after manipulation, in which only the four digits from the right of the URI user part are retained)
- **Contact:** 976653434@10.10.10.10

The procedure below describes how to configure the above manipulation example.

- **To manipulate incoming Request-URI user part of REGISTER message:**

 1. Open the SAS Configuration page (**Configuration** tab > **VoIP** menu > **SAS** > **Stand Alone Survivability**).
 2. Under the **SAS Registration Manipulation** group, in the 'Leave From Right' field, enter the number of digits (e.g., "4") to leave from the right side of the user part. This field defines the number of digits to retain from the right side of the user part; all other digits in the user part are removed.

Figure 29-8: Manipulating User Part in Incoming REGISTER

SAS Local SIP UDP Port	5080
SAS Default Gateway IP	10.0.0.2:5080
SAS Registration Time	20
SAS Local SIP TCP Port	5080
SAS Local SIP TLS Port	5081
SAS Proxy Set	0
SAS Emergency Numbers	
SAS Binding Mode	0-URI
SAS Survivability Mode	Always Emergency
Enable ENUM	Disable
Enable Record-Route	Disable
SAS Block Unregistered Users	Un-Block
Redundant SAS Proxy Set	-1
SAS Inbound Manipulation Mode	None

SAS Registration Manipulation

Remove From Right	Leave From Right
0	4

←

3. Click **Submit**.



Note: You can also configure SAS registration manipulation using the table ini file parameter, SASRegistrationManipulation.

29.5.2 Manipulating Destination Number of Incoming INVITE

You can define a manipulation rule to manipulate the destination number in the Request-URI of incoming INVITE messages when SAS is in emergency state. This is required, for example, if the call is destined to a registered user but the destination number in the received INVITE is not the number assigned to the registered user in the SAS registration database. To overcome this and successfully route the call, you can define manipulation rules to change the INVITE's destination number so that it matches that of the registered user in the database. This is done using the IP to IP Inbound Manipulation table.

For example, in SAS emergency state, assume an incoming INVITE has a destination number "7001234" which is destined to a user registered in the SAS database as "552155551234". In this scenario, the received destination number needs to be manipulated to the number "552155551234". The outgoing INVITE sent by the device then also contains this number in the Request-URI user part.

In normal state, the numbers are not manipulated. In this state, SAS searches the number 552155551234 in its database and if found, it sends the INVITE containing this number to the UA.

➤ **To manipulate the destination number in SAS emergency state:**

1. Open the SAS Configuration page (**Configuration** tab > **VoIP** menu > **SAS** > **Stand Alone Survivability**).
2. From the 'SAS Inbound Manipulation Mode' (*SASInboundManipulationMode*) drop-down list, select **Emergency Only**.
3. Click **Submit**; the **SAS Inbound Manipulation Mode Table**  button appears on the page.
4. Click this button to open the IP to IP Inbound Manipulation page.
5. Add your SAS manipulation rule as required. See the table below for descriptions of the parameters.
6. Click **Submit** to save your changes.



Notes:

- The following fields in the IP to IP Inbound Manipulation table are not applicable to SAS and must be left at their default values:
 - 'Additional Manipulation' - default is **0**
 - 'Manipulation Purpose' - default is **Normal**
 - 'Source IP Group' - default is **-1**
- The IP to IP Inbound Manipulation table can also be configured using the table ini file parameter, IPInboundManipulation.

SAS IP to IP Inbound Manipulation Parameters

Parameter	Description
Matching Characteristics (Rule)	
Additional Manipulation [IPInboundManipulation_IsAdditionalManipulation]	<p>Determines whether additional SIP URI user part manipulation is done for the table entry rule listed directly above it.</p> <ul style="list-style-type: none"> ▪ [0] No = (Default) Regular manipulation rule (not done in addition to the rule above it). ▪ [1] Yes = If the above row entry rule matched the call, consider this row entry as a match as well and perform the manipulation specified by this rule. <p>Note: Additional manipulation can only be done on a different SIP URI, source or destination, to the rule configured in the row above as configured by the 'Manipulated URI' parameter (see below).</p>
Manipulation Purpose [IPInboundManipulation_ManipulationPurpose]	<p>Defines the purpose of the manipulation:</p> <ul style="list-style-type: none"> ▪ [0] Normal = (Default) Inbound manipulations affect the routing input and source and/or destination number. ▪ [1] Routing input only = Inbound manipulations affect the routing input only, retaining the original source and destination number.
Source IP Group ID [IPInboundManipulation_SrcIpGroup]	<p>Defines the IP Group from where the incoming INVITE is received. For any IP Group, enter the value "-1".</p>
Source Username Prefix [IPInboundManipulation_SrcUsernamePrefix]	<p>Defines the prefix of the source SIP URI user name (usually in the From header). For any prefix, enter the asterisk "*" symbol (default).</p> <p>Note: The prefix can be a single digit or a range of digits. For available notations, see 'Dialing Plan Notation for Routing and Manipulation' on</p>

Parameter	Description
	page 607.
Source Host [IPInboundManipulation_SrcHost]	Defines the source SIP URI host name - full name (usually in the From header). For any host name, enter the asterisk "*" symbol (default).
Destination Username Prefix [IPInboundManipulation_DestUsernamePrefix]	Defines the prefix of the destination SIP URI user name (usually in the Request-URI). For any prefix, enter the asterisk "*" symbol (default). Note: The prefix can be a single digit or a range of digits. For available notations, see 'Dialing Plan Notation for Routing and Manipulation' on page 607.
Destination Host [IPInboundManipulation_DestHost]	Defines the destination SIP URI host name - full name (usually in the Request URI). For any host name, enter the asterisk "*" symbol (default).
Request Type [IPInboundManipulation_RequestType]	Defines the SIP request type to which the manipulation rule is applied. <ul style="list-style-type: none"> ▪ [0] All = (Default) All SIP messages. ▪ [1] INVITE = All SIP messages except REGISTER and SUBSCRIBE. ▪ [2] REGISTER = Only REGISTER messages. ▪ [3] SUBSCRIBE = Only SUBSCRIBE messages. ▪ [4] INVITE and REGISTER = All SIP messages except SUBSCRIBE. ▪ [5] INVITE and SUBSCRIBE = All SIP messages except REGISTER.
Manipulated URI [IPInboundManipulation_ManipulatedURI]	Determines whether the source or destination SIP URI user part is manipulated. <ul style="list-style-type: none"> ▪ [0] Source = (Default) Manipulation is done on the source SIP URI user part. ▪ [1] Destination = Manipulation is done on the destination SIP URI user part.
Operation Rule (Action)	
Remove From Left [IPInboundManipulation_RemoveFromLeft]	Defines the number of digits to remove from the left of the user name prefix. For example, if you enter 3 and the user name is "john", the new user name is "n".
Remove From Right [IPInboundManipulation_RemoveFromRight]	Defines the number of digits to remove from the right of the user name prefix. For example, if you enter 3 and the user name is "john", the new user name is "j". Note: If both 'Remove From Right' and 'Leave From Right' parameters are configured, the 'Remove From Right' setting is applied first.
Leave From Right [IPInboundManipulation_LeaveFromRight]	Defines the number of characters that you want retained from the right of the user name. Note: If both 'Remove From Right' and 'Leave From Right' parameters are configured, the 'Remove From Right' setting is applied first.
Prefix to Add [IPInboundManipulation_Prefix2Add]	Defines the number or string that you want added to the front of the user name. For example, if you enter 'user' and the user name is "john", the new user name is "userjohn".
Suffix to Add [IPInboundManipulation_Suffix2Add]	Defines the number or string that you want added to the end of the user name. For example, if you enter '01' and the user name is "john", the new user name is "john01".

29.5.3 SAS Routing Based on IP-to-IP Routing Table

SAS routing that is based on SAS Routing table rules is applicable for the following SAS states:

- Normal, if the 'SAS Survivability Mode' parameter is set to **Use Routing Table only in Normal mode**.
- Emergency, if the 'SAS Survivability Mode' parameter is **not** set to **Use Routing Table only in Normal mode**.

The SAS routing rule destination can be an IP Group, IP address, Request-URI, or ENUM query.

The IP-to-IP Routing Table page allows you to configure up to 120 SAS routing rules (for Normal and Emergency modes). The device routes the SAS call (received SIP INVITE message) once a rule in this table is matched. If the characteristics of an incoming call do not match the first rule, the call characteristics is then compared to the settings of the second rule, and so on until a matching rule is located. If no rule is matched, the call is rejected.

When SAS receives a SIP INVITE request from a proxy server, the following routing logic is performed:

- a. Sends the request according to rules configured in the IP-to-IP Routing table.
- b. If no matching routing rule exists, the device sends the request according to its SAS registration database.
- c. If no routing rule is located in the database, the device sends the request according to the Request-URI header.




Note: The IP-to-IP Routing table can also be configured using the table *ini* file parameter, IP2IPRouting (see 'Configuration Parameters Reference' on page 609).

➤ **To configure the IP-to-IP Routing table for SAS:**

1. In the SAS Configuration page, click the **SAS Routing Table**  button; the IP-to-IP Routing Table page appears.
2. Click **Add**; the Add Record dialog box appears:

Figure 29-9: Add Record Dialog Box of SAS IP2IP Routing Page



Index	<input type="text"/>
Source IP Group ID	<input type="text" value="-1"/>
Source Username Prefix	<input type="text" value="*"/>
Source Host	<input type="text" value="*"/>
Destination Username Prefix	<input type="text" value="*"/>
Destination Host	<input type="text" value="*"/>
Request Type	All <input type="button" value="v"/>
Message Condition	None <input type="button" value="v"/>
Destination Type	IP Group <input type="button" value="v"/>
Destination IP Group ID	<input type="text" value="-1"/>
Destination SRD ID	None <input type="button" value="v"/>
Destination Address	<input type="text"/>
Destination Port	<input type="text" value="0"/>
Destination Transport Type	<input type="button" value="v"/>
Alternative Route Options	Route Row <input type="button" value="v"/>
Cost Group	None <input type="button" value="v"/>
<input type="button" value="Submit"/> <input type="button" value="Cancel"/>	

3. Configure the rule according to the table below.
4. Click **Submit** to apply your changes.
5. To save the changes to flash memory, see 'Saving Configuration' on page 494.



Note: The following parameters are not applicable to SAS and must be ignored:

- 'Source IP Group ID'
- 'Destination IP Group ID'
- 'Destination SRD ID'
- 'Alternative Route Options'

SAS IP-to-IP Routing Table Parameters

Parameter	Description
Matching Characteristics	
Source Username Prefix [IP2IPRouting_SrcUserNamePrefix]	Defines the prefix of the user part of the incoming SIP dialog's source URI (usually the From URI). You can use special notations for denoting the prefix. For example, to denote any prefix, use the asterisk (*) symbol; to denote calls without a user part in the URI, use the \$ sign. For available notations, see 'Dialing Plan Notation for Routing and Manipulation' on page 607. The default is * (i.e., any prefix).

Parameter	Description
Source Host [IP2IPRouting_SrcHost]	Defines the host part of the incoming SIP dialog's source URI (usually the From URI). If this rule is not required, leave the field empty. To denote any host name, use the asterisk (*) symbol (default).
Destination Username Prefix [IP2IPRouting_DestUsernamePrefix]	Defines the prefix of the incoming SIP dialog's destination URI (usually the Request URI) user part. You can use special notations for denoting the prefix. For example, to denote any prefix, use the asterisk (*) symbol; to denote calls without a user part in the URI, use the \$ sign. For available notations, see 'Dialing Plan Notation for Routing and Manipulation' on page 607. The default is * (i.e., any prefix).
Destination Host [IP2IPRouting_DestHost]	Defines the host part of the incoming SIP dialog's destination URI (usually the Request-URI). If this rule is not required, leave the field empty. The asterisk (*) symbol (default) can be used to denote any destination host.
Message Condition [IP2IPRouting_MessageCondition]	Selects a Message Condition rule. To configure Message Condition rules, see Configuring Condition Rules.
ReRoute IP Group ID [IP2IPRouting_ReRouteIPGroupID]	Defines the IP Group that initiated (sent) the SIP redirect response (e.g., 3xx) or REFER message. This field is typically used for re-routing requests (e.g., INVITEs) when interworking is required for SIP 3xx redirect responses or REFER messages (for more information, see Interworking SIP 3xx Redirect Responses and Interworking SIP REFER Messages, respectively). This parameter functions together with the 'Call Trigger' field (see below). The default is -1 (i.e., not configured).
Call Trigger [IP2IPRouting_Trigger]	Defines the reason (i.e, trigger) for re-routing the SIP request: <ul style="list-style-type: none"> ▪ [0] Any = (Default) This routing rule is used for all scenarios (re-routes and non-re-routes). ▪ [1] 3xx = Re-routes the request if it was triggered as a result of a SIP 3xx response. ▪ [2] REFER = Re-routes the INVITE if it was triggered as a result of a REFER request. ▪ [3] 3xx or REFER = Applies to options [1] and [2]. ▪ [4] Initial only = This routing rule is used for regular requests that the device forwards to the destination. This rule is not used for re-routing of requests triggered by the receipt of REFER or 3xx.
Operation Routing Rule	
Destination Type [IP2IPRouting_DestinationType]	Determines the destination type to which the outgoing SIP dialog is sent. <ul style="list-style-type: none"> ▪ [0] IP Group = (Default) The SIP dialog is sent to the IP Group's Proxy Set (SERVER-type IP Group) or registered contact from the database (if USER-type IP Group). ▪ [1] Dest Address = The SIP dialog is sent to the address configured in the following fields: 'Destination SRD ID', 'Destination Address', 'Destination Port', and 'Destination Transport Type'. ▪ [2] Request URI = The SIP dialog is sent to the address indicated in the incoming Request-URI. If the fields 'Destination Port' and 'Destination Transport Type' are configured, the incoming Request-URI parameters are overridden and these fields take precedence.

Parameter	Description
	<ul style="list-style-type: none"> ▪ [3] ENUM = An ENUM query is sent to include the destination address. If the fields 'Destination Port' and 'Destination Transport Type' are configured, the incoming Request-URI parameters are overridden and these fields take precedence. ▪ [4] Hunt Group = Used for call center survivability. For more information, see Call Survivability for Call Centers. ▪ [5] Dial Plan = The IP destination is determined by a Dial Plan index of the loaded Dial Plan file. The syntax of the Dial Plan index in the Dial Plan file is as follows: <destination / called prefix number>,0,<IP destination> <p>Note that the second parameter "0" is ignored. An example of a configured Dial Plan (# 6) in the Dial Plan file is shown below:</p> <pre style="background-color: #f0f0f0; padding: 5px;"> [PLAN6] 200,0,10.33.8.52 ; called prefix 200 is routed to destination 10.33.8.52 201,0,10.33.8.52 300,0,itsp.com ; called prefix 300 is routed to destination itsp.com </pre> <p>Once the Dial Plan is defined, you need to assign it (0 to 7) to the routing rule as the destination in the 'Destination Address' parameter, where "0" denotes [PLAN1], "1" denotes [PLAN2], and so on.</p> <ul style="list-style-type: none"> ▪ [7] LDAP = LDAP-based routing.
Destination IP Group ID [IP2IPRouting_DestIPGroupID]	<p>Defines the IP Group ID to where you want to route the call. The SIP dialog messages are sent to the IP address defined for the Proxy Set associated with this IP Group. If you select an IP Group, it is unnecessary to configure a destination IP address (in the 'Destination Address' field). However, if both parameters are configured, then the IP Group takes precedence.</p> <p>If the destination IP Group is of USER type, the device searches for a match between the Request-URI (of the received SIP dialog) to an AOR registration record in the device's database. The SIP dialog is then sent to the IP address of the registered contact.</p> <p>The default is -1.</p> <p>Notes:</p> <ul style="list-style-type: none"> ▪ This parameter is only relevant if the parameter 'Destination Type' is set to 'IP Group'. However, regardless of the settings of the parameter 'Destination Type', the IP Group is still used - only for determining the IP Profile or outgoing SRD. If neither IP Group nor SRD are defined in this table, the destination SRD is determined according to the source SRD associated with the Source IP Group (configured in the IP Group table, see 'Configuring IP Groups' on page 214). If this table does not define an IP Group but only an SRD, then the first IP Group associated with this SRD (in the IP Group table) is used. ▪ If the selected destination IP Group ID is type SERVER, the request is routed according to the IP Group addresses. ▪ If the selected destination IP Group ID is type USER, the request is routed according to the IP Group specific database (i.e., only to registered users of the selected database). ▪ If the selected destination IP Group ID is ANY USER ([-2]), the request is routed according to the general database (i.e., any matching registered user).
Destination Address [IP2IPRouting_DestAdd]	Defines the destination IP address (or domain name, e.g., domain.com) to where the call is sent.

Parameter	Description
ress]	<p>Notes:</p> <ul style="list-style-type: none"> This parameter is applicable only if the parameter 'Destination Type' is set to 'Dest Address' [1]. When using domain names, enter a DNS server IP address or alternatively, define these names in the 'Internal DNS Table' (see 'Configuring the Internal SRV Table' on page 127).
Destination Port [IP2IPRouting_DestPort]	Defines the destination port to where the call is sent.
Destination Transport Type [IP2IPRouting_DestTransportType]	<p>Defines the transport layer type for sending the call:</p> <ul style="list-style-type: none"> [-1] Not Configured (default) [0] UDP [1] TCP [2] TLS <p>Note: When this parameter is set to -1, the transport type is determined by the parameter SIPTransportType.</p>
Cost Group [IP2IPRouting_CostGroup]	<p>Assigns a Cost Group to the routing rule for determining the cost of the call. To configure Cost Groups, see 'Configuring Cost Groups' on page 206.</p> <p>By default, no Cost Group is assigned to the rule.</p>

29.5.4 Blocking Calls from Unregistered SAS Users

To prevent malicious calls, for example, service theft, it is recommended to configure the feature for blocking SIP INVITE messages received from SAS users that are not registered in the SAS database. This applies to SAS in normal and emergency states.

➤ To block calls from unregistered SAS users:

1. Open the SAS Configuration page (**Configuration** tab > **VoIP** menu > **SAS Stand Alone Survivability**).
2. From the 'SAS Block Unregistered Users' drop-down list, select **Block**.
3. Click **Submit** to apply your changes.

29.5.5 Configuring SAS Emergency Calls

You can configure SAS to route emergency calls (such as 911 in North America) directly to the PSTN through its FXO interface or E1/T1 trunk. Thus, even during a communication failure with the external proxy, enterprise UAs can still make emergency calls.

You can define up to four emergency numbers, where each number can include up to four digits. When SAS receives a SIP INVITE (from a UA) that includes one of the user-defined emergency numbers in the SIP user part, it forwards the INVITE directly to the default gateway (see 'SAS Routing in Emergency State' on page 423). The default gateway is defined in the 'SAS Default Gateway IP' field, and this is the device itself. The device then sends the call directly to the PSTN.

This feature is applicable to SAS in normal and emergency states.

➤ **To configure SAS emergency numbers:**

1. Open the SAS Configuration page (**Configuration** tab > **VoIP** menu > **SAS** > **Stand Alone Survivability**).
2. In the 'SAS Default Gateway IP' field, define the IP address and port (in the format *x.x.x.x:port*) of the device (Gateway application).



Note: The port of the device is defined in the 'SIP UDP/TCP/TLS Local Port' field in the SIP General Parameters page (**Configuration** tab > **VoIP** menu > **SIP Definitions** > **General Parameters**).

3. In the 'SAS Emergency Numbers' field, enter an emergency number in each field box.

Figure 29-10: Configuring SAS Emergency Numbers

SAS Local SIP UDP Port	5080
SAS Default Gateway IP	10.13.4.12
SAS Registration Time	20
SAS Local SIP TCP Port	5080
SAS Local SIP TLS Port	5081
SAS Proxy Set	0
SAS Emergency Numbers	911
SAS Binding Mode	1-User Part Only
SAS Survivability Mode	Always Emergency
Enable ENUM	Disable
Enable Record-Route	Disable
SAS Block Unregistered Users	Block
Redundant SAS Proxy Set	-1
SAS Inbound Manipulation Mode	None

4. Click **Submit** to apply your changes.

29.5.6 Adding SIP Record-Route Header to SIP INVITE

You can configure SAS to add the SIP Record-Route header to SIP requests (e.g. INVITE) received from enterprise UAs. SAS then sends the request with this header to the proxy. The Record-Route header includes the IP address of the SAS application. This ensures that future requests in the SIP dialog session from the proxy to the UAs are routed through the SAS application. If not configured, future request within the dialog from the proxy are sent directly to the UAs (and do not traverse SAS). When this feature is enabled, the SIP Record-Route header includes the URI "lr" parameter, indicating loose routing, as shown in the following example:

```
Record-Route: <sip:server10.biloxi.com;lr>
```



Note: This feature is applicable only to the SAS Outbound mode.

➤ **To enable the Record-Route header:**

1. Open the SAS Configuration page (**Configuration** tab > **VoIP** menu > **SAS** > **Stand Alone Survivability**).
2. From the 'Enable Record-Route' drop-down list, select **Enable**.
3. Click **Submit** to apply your changes.

29.5.7 Re-using TCP Connections

You can enable the SAS application to re-use the same TCP connection for sessions (multiple SIP requests / responses) with the same SIP UA. The benefits of this feature include less CPU and memory usage because fewer TCP connections are open and reduced network congestion. For example, assume User A sends a REGISTER message to SAS with transport=TCP, and User B sends an INVITE message to A using SAS. In this scenario, the SAS application forwards the INVITE request using the same TCP connection that User A initially opened with the REGISTER message.

➤ To re-use TCP connection sessions in SAS

1. Open the SAS Configuration page (**Configuration** tab > **VoIP** menu > **SAS** > **Stand Alone Survivability**).
2. From the 'SAS Connection Reuse' drop-down list, select **Enable**.
3. Click **Submit** to apply your changes.

29.5.8 Replacing Contact Header for SIP Messages

You can configure SAS to change the SIP Contact header so that it points to the SAS host. This ensures that in the message, the top-most SIP Via header and the Contact header point to the same host.



Notes:

- This feature is applicable only to the SAS Outbound mode.
- The device may become overloaded if this feature is enabled, as all incoming SIP dialog requests traverse the SAS application.

Currently, this feature can be configured only by the *ini* file parameter, `SASEnableContactReplace`:

- **[0]** (Default): Disable - when relaying requests, SAS adds a new Via header (with the IP address of the SAS application) as the top-most Via header and retains the original Contact header. Thus, the top-most Via header and the Contact header point to different hosts.
- **[1]**: Enable - SAS changes the Contact header so that it points to the SAS host and therefore, the top-most Via header and the Contact header point to the same host.

29.6 Viewing Registered SAS Users

You can view all the users that are registered in the SAS registration database. This is displayed in the 'SAS/SBC Registered Users' page, as described in 'Viewing Registered Users' on page 555.



Note: You can increase the maximum number of registered SAS users, by implementing the SAS Cascading feature, as described in 'SAS Cascading' on page 445.

30 SAS Cascading

The SAS Cascading feature allows you to increase the number of SAS users above the maximum supported by the SAS gateway. This is achieved by deploying multiple SAS gateways in the network. For example, if the SAS gateway supports up to 600 users, but your enterprise has 1,500 users, you can deploy three SAS gateways to accommodate all users: the first SAS gateway can service 600 registered users, the second SAS gateway the next 600 registered users, and the third SAS gateway the rest (i.e., 300 registered users).

In SAS Cascading, the SAS gateway first attempts to locate the called user in its SAS registration database. Only if the user is not located, does the SAS gateway send it on to the next SAS gateway according to the SAS Cascading configuration.

There are two methods for configuring SAS Cascading. This depends on whether the users can be identified according to their phone extension numbers:

- **SAS Routing Table:** If users can be identified with unique phone extension numbers, then the SAS Routing table is used to configure SAS Cascading. This SAS Cascading method routes calls directly to the SAS Gateway (defined by IP address) to which the called SAS user is registered.


The following is an example of a SAS Cascading deployment of users with unique phone extension numbers:

- users registered to the first SAS gateway start with extension number "40"
- users registered to the second SAS gateway start with extension number "20"
- users registered to the third SAS gateway start with extension number "30"

The SAS Routing table rules for SAS Cascading are created using the destination (called) extension number prefix (e.g., "30") and the destination IP address of the SAS gateway to which the called user is registered. Such SAS routing rules must be configured at each SAS gateway to allow routing between the SAS users. The routing logic for SAS Cascading is similar to SAS routing in Emergency state (see the flowchart in 'SAS Routing in Emergency State' on page 423). For a description on the SAS Routing table, see 'SAS Routing Based on IP-to-IP Routing Table' on page 437.

The figure below illustrates an example of a SAS Cascading call flow configured using the SAS Routing table. In this example, a call is routed from SAS Gateway (A) user to a user on SAS Gateway (B).

Figure 30-1: SAS Cascading Using SAS Routing Table - Example




- SAS Redundancy mode:** If users cannot be distinguished (i.e., associated to a specific SAS gateway), then the SAS Redundancy feature is used to configure SAS Cascading. This mode routes the call in a loop fashion, from one SAS gateway to the next, until the user is located. Each SAS gateway serves as the redundant SAS gateway (“redundant SAS proxy server”) for the previous SAS gateway (in a one-way direction). For example, if a user calls a user that is not registered on the same SAS gateway, the call is routed to the second SAS gateway, and if not located, it is sent to the third SAS gateway. If the called user is not located on the third (or last) SAS gateway, it is then routed back to the initial SAS gateway, which then routes the call to the default gateway (i.e., to the PSTN).

Each SAS gateway adds its IP address to the SIP via header in the INVITE message before sending it to the next (“redundant”) SAS gateway. If the SAS gateway receives an INVITE and its IP address appears in the SIP via header, it sends it to the default gateway (and not to the next SAS gateway), as defined by the SASDefaultGatewayIP parameter. Therefore, this mode of operation prevents looping between SAS gateways when a user is not located on any of the SAS gateways.

The figure below illustrates an example of a SAS Cascading call flow when configured using the SAS Redundancy feature. In this example, a call is initiated from a SAS Gateway (A) user to a user that is not located on any SAS gateway. The call is subsequently routed to the PSTN.

Figure 30-2: SAS Cascading Using SAS Redundancy Mode - Example



Part VII

IP Media Capabilities

31 Overview

This section provides information on the device's media server capabilities:



Note: This section is applicable only to Mediant 1000.

The device conference, transcoding, announcement and media server applications can be used separately, each on a different platform, or all on the same device. The SIP URI name in the INVITE message is used to identify the resource (media server, conference or announcement) to which the SIP session is addressed.

The number of DSP channels that are allocated for IP conferences, transcoding and IP announcements is determined by the parameter MediaChannels. Other DSP channels can be used for PSTN media server.

The device's SIP implementation is based on the decomposition model described in the following IETF Internet-Drafts:

- "A Multi-party Application Framework for SIP" (draft-ietf-sipping-cc-framework-06)
- "Models for Multi Party Conferencing in SIP" (draft-ietf-sipping-conferencing-framework-05)
- "A Framework for Conferencing with the Session Initiation Protocol (SIP)" (RFC 4353)
- "Basic Network Media Services with SIP" (RFC 4240)
- "Media Server Control Markup Language (MSCML) and Protocol" (draft-vandyke-mscml-06)



Note: To use the device's advanced Announcement capabilities, it's essential that the *ini* file parameter AMSProfile be set to 1.

Some of the IP media functionalities are configured in the IP Media settings page.



Note: This page is applicable only to Mediant 1000. This page appears only if your device is installed with the relevant Software License Key (see 'Loading Software License Key' on page 522).

- **To access the IP Media Settings page:**
- Open the IP Media Settings page (**Configuration** tab > **VoIP** menu > **IP Media** submenu > **IP Media Settings**).

Figure 31-1: IP Media Settings Page

▼	
⚡ Number of Media Channels	<input type="text" value="0"/>
⚡ Voice Streaming	<input type="text" value="Disable"/> ▼
NetAnn Announcement ID	<input type="text" value="annc"/>
MSCML ID	<input type="text" value="ivr"/>
Transcoding ID	<input type="text" value="trans"/>
▼ Conference	
Conference ID	<input type="text" value="conf"/>
Beep on Conference	<input type="text" value="Enable"/> ▼
Enable Conference DTMF Clamping	<input type="text" value="Enable"/> ▼
Enable Conference DTMF Reporting	<input type="text" value="Disable"/> ▼

32 Transcoding using Third-Party Call Control

The device supports transcoding using a third-party call control Application server. This support is provided by the following:

- Using RFC 4117 (see 'Using RFC 4117' on page 451)
- Using RFC 4240 - NetAnn Conferencing (see Using RFC 4240 - NetAnn 2-Party Conferencing on page 451)



Note: Transcoding can also be implemented using the IP-to-IP application.

32.1 Using RFC 4117

The device supports RFC 4117 - Transcoding Services Invocation in the Session Initiation Protocol (SIP) Using Third Party Call Control (3pcc) - providing transcoding services (i.e., acting as a transcoding server). This is used in scenarios where two SIP User Agents (UA) would like to establish a session, but do not have a common coder or media type. When such incompatibilities are found, the UAs need to invoke transcoding services to successfully establish the session. Note that transcoding can also be performed using NetAnn, according to RFC 4240.

To enable the RFC 4117 feature, the parameter EnableRFC4117Transcoding must be set to 1 (and the device must be reset).

The 3pcc call flow is as follows: The device receives from one of the UAs, a single INVITE with an SDP containing two media lines. Each media represents the capabilities of each of the two UAs. The device needs to find a match for both of the media, and opens two channels with two different media ports to the different UAs. The device performs transcoding between the two voice calls.

In the example below, an Application Server sends a special INVITE that consists of two media lines to perform transcoding between G.711 and G.729:

```
m=audio 20000 RTP/AVP 0
c=IN IP4 A.example.com
m=audio 40000 RTP/AVP 18
c=IN IP4 B.example.com
```

32.2 Using RFC 4240 - NetAnn 2-Party Conferencing

Transcoding bridges (or translates) between two remote *network* locations, each of which uses a different coder and/or a different DTMF and fax transport types. The device supports IP-to-IP transcoding. It creates a transcoding call that is similar to a dial-in, two-party conference call. The SIP URI in the INVITE message is used as a transcoding service identifier. The transcoding identifier is configured by the 'Transcoding ID' parameter (TranscodingID), located in the IP Media Settings page (**Configuration** tab > **VoIP** menu > **IP Media** > **IP Media Settings**).

It is assumed that the device is controlled by a third-party, Application server (or any SIP user agent) that instructs the device to start an IP transcoding call by sending two SIP INVITE messages with SIP URI that includes the transcoding identifier name.

For example:

```
Invite sip:trans123@audiocodes.com SIP/2.0
```


The left part of the SIP URI includes the transcoding ID ('the default string is 'trans') and is terminated by a unique number (123). The device immediately sends a 200 OK message in response to each INVITE.

Each of the transcoding SIP call participants can use a different VoIP coder and a different DTMF transport type, negotiated with the device using common SIP negotiation.


Sending a BYE request to the device by any of the participants, terminates the SIP session and removes it from the Transcoding session. The second BYE from the second participant ends the transcoding session and releases its resources.

The device uses two media (DSP) channels for each call, thereby reducing the number of available transcoding sessions to half of the defined value for MediaChannels. To limit the number of resources for transcoding, use the 'Number of Media Channels' parameter (MediaChannels), located in the IP Media Settings page (**Configuration** tab > **VoIP** menu > **IP Media** > **IP Media Settings**). For example, if 'Number of Media Channels' is set to "40", only 20 transcoding sessions are available.

The figure below illustrates an example of a direct connection to a device:



The figure below illustrates an example of implementing an Application server:



33 Conference Server

The device supports dial-in, multi-party conferencing. In conference applications, the device functions as a centralized conference bridge. In ad-hoc or prearranged conferences, users 'invite' the conference bridge. The conference bridge mixes the media and sends it to all participants.

The device supports the following interfaces for conferencing:

- Simple, according to NetAnn (see 'Simple Conferencing (NetAnn)' on page 453)
- Advanced, according to MSCML (see 'Advanced Conferencing (MSCML)' on page 455)




Note: The conference application is a special order option.

33.1 Simple Conferencing (NetAnn)

33.1.1 SIP Call Flow

A SIP call flow for simple conferencing is shown below:



33.1.2 Creating a Conference

The device creates a conference call when the first user joins the conference. To create a conference, the Application Server sends a regular SIP INVITE message to the device. The User Part of that Request-URI includes both the Conference Service Identifier (indicating that the requested Media Service is a Conference) and a Unique Conference Identifier (identifying a specific instance of a conference).

```
INVITE sip: conf100@audiocodes.com SIP/2.0
```

By default, a request to create a conference reserves three resources on the device. It is possible to reserve a larger number of resources in advance by adding the number of required participants to the User Part of the Request-URI. For example, '6conf100' reserves six resources for the duration of the conference. If the device can allocate the requested number of resources, it responds with a 200 OK.

The Conference Service Identifier can be configured using the 'Conference ID' parameter (ConferenceID), located in the IP Media Settings page (**Configuration** tab > **VoIP** menu > **IP Media** > **IP Media Settings**). By default, it is set to 'conf'.

33.1.3 Joining a Conference

To join an existing conference, the Application Server sends a SIP INVITE message with the same Request-URI as the one that created the conference. Each conference participant can use a different coder negotiated with the device using usual SIP negotiation.

If more than the initially requested number of participants try to join the conference (i.e., four resources were reserved and a fifth INVITE is received) and the device has an available resource, the request is granted.

If an INVITE to join an existing conference is received with a request to reserve a larger number of participants than initially requested, it is granted if the device has available resources. A request for a smaller number of participants is not granted as this may create a situation where existing legs would need to be disconnected.

The maximal number of participants in a single conference is 60. The maximal number of participants that actually participate in the mix at a given time is three (the loudest legs).

The Application Server can place a participant on Hold/Un-hold by sending the appropriate SIP Re-INVITE on that participant dialog.

33.1.4 Terminating a Conference

The device never disconnects an existing conference leg. If a BYE is received on an existing leg, it is disconnected, but the resource is still saved if the same leg (or a different one) wants to re-join the conference. This logic occurs only for the initial number of reserved legs.

For example:

1. INVITE reserves three legs.
2. A, B, and C join the conference.
3. A disconnects.
4. A joins (guaranteed).
5. D joins.
6. A disconnects.
7. A joins (not guaranteed).

Sending a BYE request to the device terminates the participant's SIP session and removes it from the conference. The final BYE from the last participant ends the conference and releases all conference resources.

33.1.5 PSTN Participants

Adding PSTN participants is done by performing a loopback from the IP side (the device's IP address is configured in the Outbound IP Routing Table). If the destination phone number in the incoming call from the PSTN is equal to the Conference Service Identifier and Unique Conference Identifier, the participant joins the conference.

A PSTN participant uses two DSP channels (caused by the IP loopback).

33.2 Advanced Conferencing (MSCML)

33.2.1 Creating a Conference


The device creates a conference call when the first INVITE is received from the Application Server (same as NetAnn). The Unique Conference Identifier is used to join participants to the same conference. This first INVITE must include a <configure_conference> MSCML request body. If this body is not included, a simple conference is established. This first leg is the Control Leg, which is different from a regular Participant Leg. The Control Leg is used to perform operations for the whole conference.

The MSCML response to the first INVITE is sent in the 200 OK SIP response. If no error occurs, the response is:

```
<response request="configure_conference" code="200" text="OK"/>
```

The <configure_conference> can include the following attributes:

- **Id:** identification number of the MSCML request. This is used to correlate between MSCML requests and responses.
- **Reservedtalkers:** defines the maximum number of talker legs. As the device does not support "listener only" legs, this actually sets the maximum number of participants in the conference. The device reserves this number of participants for the entire duration of the conference. If a participant leg decides to leave the conference by issuing a BYE, the resource is not freed, thereby allowing that same leg (or a new one) to join at any stage.
- **Reserveconfmedia:** determines if Media Services such as Play or Record can be applied to the conference. If set to Yes, the device reserves the necessary amount of resources to play an announcement to the whole conference or record the whole conference. The Application Server can change the value of reserveconfmedia during an existing conference. By default, reserveconfmedia is set to Yes.



33.2.2 Joining a Conference

To join an existing conference, the Application Server sends a SIP INVITE message with the same Request-URI as the one that created the conference. The INVITE message may include a <configure_leg> MSCML request body. If not included, defaults are used for that leg attributes.

The <configure_leg> can include the following attributes:

- **Id:** identification number of the MSCML request. This is used to correlate between MSCML requests and responses.
- **Type:** Talker / Listener. If set to Listener, the incoming RTP from that leg does not participate in the conference mix. The default is Talker.
- **Mixmode:**
 - Full: RTP from this leg participates in the mix (default).
 - Mute: RTP from this leg is not participating in the mix.
 - Private: RTP from this leg can only hear participants within a conference team (<teammate>) to which it belongs (see below).

The <configure_team> element enables clients to create personalized mixes for scenarios where the standard mixmode settings do not provide sufficient control. The <configure_team> element is a child of <configure_leg>. The <configure_team> element, containing one or more <teammate> elements, specifies those participants that should be present in this participant's personalized mix. The <configure_team> element supports several commands: set, add, remove, and query.

The participants are identified in the <teammate> elements by their IDs that are assigned in their <configure_leg> element. The team configuration is implicitly symmetric, i.e. if participant A defines participant B as its team member, implicitly participant B defines participant A as its team member.

A "coaching" example:

MSCML Conferencing with Personalized Mixes

Participant	ID	Team Members	Mixmode	Hears
Supervisor	"supervisor"	Agent	Private	Customer and Agent
Agent	"agent"	Supervisor	Full	Customer and Supervisor
Customer	"customer"		Full	Agent

This scenario is established as follows:

1. Conference is created on the control leg with <configure_conference>.

2. Coach leg joins and issues:

```
<configure_leg id="supervisor" mixmode="private"/>
```

3. Agent leg joins and issues:

```
<configure_leg id="agent">
  <configure_team action="set">
    <teammate id="supervisor"/>
  </configure_team>
</configure_leg>
```

4. Customer joins and issues:

```
<configure_leg id="customer"/>
```


33.2.3 Modifying a Conference

To modify an existing conference, INFO messages are used. Each INFO message carries an MSCML request. The MSCML response is included in an INFO message back from the device to the Application Server. It is possible to modify an entire conference (by issuing requests on the Control Leg) or only a certain participant (by issuing requests on that specific leg).

To modify the entire conference, a <configure_conference> MSCML request body is sent in an INFO message on the Control Leg SIP dialog. Using this request, the Application Server can modify the following attributes:

- **Reservedtalkers:** If the Application Server sets a number that is lower than the initial number requested in the INVITE, then the request is not granted. If the number is higher than the initial number, the device sends a success response in the response INFO.
- **Reserveconfmedia:** If the necessary resources for applying Media Services on the entire conference were reserved in advance, then by setting reserveconfmedia to Yes, it is reserved. If set to No, the device can free the resource.


To modify a certain Participant Leg, a <configure_leg> MSCML request body is sent in an INFO message on that leg SIP dialog. Using this request, the Application Server can modify any of the attributes defined for the <configure_leg> request.



33.2.4 Applying Media Services on a Conference

The Application Server can issue a Media Service request (<play>, <playcollect>, or <playrecord>) on either the Control Leg or a specific Participant Leg. For a Participant Leg, all three requests are applicable. For the Control Leg, the <playcollect> is not applicable as there is no way to collect digits from the whole conference.

When issuing a Media Service on the Control Leg, it affects all Participant Legs in the conference, e.g., play an announcement. When issuing a Media Service on a Participant Leg, it affects the specific leg only.



33.2.5 Active Speaker Notification

After an advanced conference is established, the Application Server can subscribe to the device to receive notifications of the current set of active speakers in a conference at any given moment. This feature is referred to as *Active Speaker Notification (ASN)* and is designed according to the MSCML standard. Notifications provide information on the number of active participants and their details.

The notifications are sent unsolicited at specific intervals requested by the application and only when a change in the number of active conference speakers occurs. If a change in the speakers list occurs, the server issues an INVITE to the specific SIP UA, and then transfers the call to the UA.


Event notifications are sent in SIP INFO messages, as shown in the example below of XML Response Generated for ASN:

```
<?xml version="1.0" encoding="utf-8"?>
<MediaServerControl version="1.0">
<notification>
<conference uniqueID="3331" numtalkers="1">
<activetalkers>
<talker callID="9814266171512000193619@10.8.27.118"/>
</activetalkers>
</conference>
</notification>
</MediaServerControl>
```

33.2.6 Terminating a Conference


To remove a leg from a conference, the Application Server issues a SIP BYE request on the selected dialog representing the conference leg. The Application Server can terminate all legs in a conference by issuing a SIP BYE request on the Control Leg. If one or more participants are still in the conference when the device receives a SIP BYE request on the

Control Leg, the device issues SIP BYE requests on all of the remaining conference legs to ensure a clean up of the legs.



33.3 Conference Call Flow Example

The call flow, shown in the following figure, describes SIP messages exchanged between the device (10.8.58.4) and three conference participants (10.8.29.1, 10.8.58.6 and 10.8.58.8).



1. SIP MESSAGE 1: 10.8.29.1:5060 -> 10.8.58.4:5060

```

INVITE sip:conf100@10.8.58.4;user=phone SIP/2.0
Via: SIP/2.0/UDP 10.8.29.1;branch=z9hG4bKacRHmJhMj
Max-Forwards: 70
From: <sip:100@10.8.8.10>;tag=1c352329022
To: <sip:conf100@10.8.58.4;user=phone>
Call-ID: 1792526528qlax@10.8.29.1
CSeq: 1 INVITE
Contact: <sip:100@10.8.29.1>
Supported: em,100rel,timer,replaces,path
Allow:REGISTER,OPTIONS,INVITE,ACK,CANCEL,BYE,NOTIFY,PRACK,REFER,INFO,SUBSCRIBE,UPDATE
User-Agent: Audiocodes-Sip-Gateway-Mediant
1000/v.5.40A.010.006
Content-Type: application/sdp
Content-Length: 216

v=0
o=AudiocodesGW 663410 588654 IN IP4 10.8.29.1
s=Phone-Call
c=IN IP4 10.8.29.1
t=0 0
m=audio 6000 RTP/AVP 8 96
a=rtpmap:8 pcma/8000
a=rtpmap:96 telephone-event/8000
a=fmtp:96 0-15
a=ptime:20
a=sendrecv
    
```

2. SIP MESSAGE 2: 10.8.58.4:5060() -> 10.8.29.1:5060()

```

SIP/2.0 100 Trying
Via: SIP/2.0/UDP 10.8.29.1;branch=z9hG4bKacRHmJhMj
From: <sip:100@10.8.8.10>;tag=1c352329022
To: <sip:conf100@10.8.58.4;user=phone>;tag=1c222574568
Call-ID: 1792526528qlax@10.8.29.1
CSeq: 1 INVITE
Supported: em,timer,replaces,path
Allow:REGISTER,OPTIONS,INVITE,ACK,CANCEL,BYE,NOTIFY,PRACK,REFER,INFO,SUBSCRIBE,UPDATE
Server: Audiocodes-Sip-Gateway-Mediant 1000/v.5.40A.010.006
Content-Length: 0
    
```

3. SIP MESSAGE 3: 10.8.58.4:5060 -> 10.8.29.1:5060

```

SIP/2.0 200 OK
Via: SIP/2.0/UDP 10.8.29.1;branch=z9hG4bKacRHmJhMj
From: <sip:100@10.8.8.10>;tag=1c352329022
To: <sip:conf100@10.8.58.4;user=phone>;tag=1c222574568
Call-ID: 1792526528qlax@10.8.29.1
CSeq: 1 INVITE
Contact: <sip:10.8.58.4>
Supported: em,timer,replaces,path
Allow:REGISTER,OPTIONS,INVITE,ACK,CANCEL,BYE,NOTIFY,PRACK,REFER,INFO,SUBSCRIBE,UPDATE
Server: Audiocodes-Sip-Gateway-Mediant 1000/v.5.40A.010.006
Content-Type: application/sdp
Content-Length: 216

v=0
o=AudiocodesGW 820775 130089 IN IP4 10.8.58.4
s=Phone-Call
c=IN IP4 10.8.58.4
t=0 0
    
```

```
m=audio 7160 RTP/AVP 8 96
a=rtpmap:8 pcma/8000
a=rtpmap:96 telephone-event/8000
a=fmtp:96 0-15
aptime:20
a=sendrecv
```

4. SIP MESSAGE 4: 10.8.29.1:5060 -> 10.8.58.4:5060

```
ACK sip:10.8.58.4 SIP/2.0
Via: SIP/2.0/UDP 10.8.29.1;branch=z9hG4bKacbUrWtRo
Max-Forwards: 70
From: <sip:100@10.8.8.10>;tag=1c352329022
To: <sip:conf100@10.8.58.4;user=phone>;tag=1c222574568
Call-ID: 1792526528qlax@10.8.29.1
CSeq: 1 ACK
Contact: <sip:100@10.8.29.1>
Supported: em,timer,replaces,path
Allow:REGISTER,OPTIONS,INVITE,ACK,CANCEL,BYE,NOTIFY,PRACK,REFER,INFO,SUBSCRIBE,UPDATE
User-Agent: Audiocodes-Sip-Gateway-Mediant
1000/v.5.40A.010.006
Content-Length: 0
```

5. SIP MESSAGE 5: 10.8.58.6:5060 -> 10.8.58.4:5060

```
INVITE sip:conf100@10.8.58.4;user=phone SIP/2.0
Via: SIP/2.0/UDP 10.8.58.6;branch=z9hG4bKacfowEuut
Max-Forwards: 70
From: <sip:600@10.8.8.10>;tag=1c201038291
To: <sip:conf100@10.8.58.4;user=phone>
Call-ID: 1008914574iygW@10.8.58.6
CSeq: 1 INVITE
Contact: <sip:600@10.8.58.6>
Supported: em,timer,replaces,path
Allow:REGISTER,OPTIONS,INVITE,ACK,CANCEL,BYE,NOTIFY,PRACK,REFER,INFO,SUBSCRIBE,UPDATE
User-Agent: Audiocodes-Sip-Gateway-Mediant
1000/v.4.60A.005.009
Content-Type: application/sdp
Content-Length: 313
v=0
o=AudiocodesGW 702680 202680 IN IP4 10.8.58.6
s=Phone-Call
c=IN IP4 10.8.58.6
t=0 0
m=audio 6000 RTP/AVP 4 8 0 110 96
a=rtpmap:4 g723/8000
a=fmtp:4 annexa=no
a=rtpmap:8 pcma/8000
a=rtpmap:0 pcmu/8000
a=rtpmap:110 AMR/8000/1
a=rtpmap:96 telephone-event/8000
a=fmtp:96 0-15
aptime:30
a=sendrecv
```

6. SIP MESSAGE 6: 10.8.58.4:5060 -> 10.8.58.6:5060

```
SIP/2.0 100 Trying
Via: SIP/2.0/UDP 10.8.58.6;branch=z9hG4bKacfowEuut
From: <sip:600@10.8.8.10>;tag=1c201038291
To: <sip:conf100@10.8.58.4;user=phone>;tag=1c1673415884
```

```

Call-ID: 1008914574iYgW@10.8.58.6
CSeq: 1 INVITE
Supported: em,timer,replaces,path
Allow:REGISTER,OPTIONS,INVITE,ACK,CANCEL,BYE,NOTIFY,PRACK,REFER,INFO,SUBSCRIBE,UPDATE
Server: Audiocodes-Sip-Gateway-Mediant 1000/v.5.40A.010.006
Content-Length: 0
    
```

7. SIP MESSAGE 7: 10.8.58.4:5060 -> 10.8.58.6:5060

```

SIP/2.0 200 OK
Via: SIP/2.0/UDP 10.8.58.6;branch=z9hG4bKacfowEuut
From: <sip:600@10.8.8.10>;tag=1c201038291
To: <sip:conf100@10.8.58.4;user=phone>;tag=1c1673415884
Call-ID: 1008914574iYgW@10.8.58.6
CSeq: 1 INVITE Contact: <sip:conf100@10.8.58.4>
Supported: em,timer,replaces,path
Allow:REGISTER,OPTIONS,INVITE,ACK,CANCEL,BYE,NOTIFY,PRACK,REFER,INFO,SUBSCRIBE,UPDATE
Server: Audiocodes-Sip-Gateway-Mediant 1000/v.5.40A.010.006
Content-Type: application/sdp
Content-Length: 236

v=0 o=AudiocodesGW 886442 597756 IN IP4 10.8.58.4
s=Phone-Call
c=IN IP4 10.8.58.4
t=0 0
m=audio 7150 RTP/AVP 4 96
a=rtpmap:4 g723/8000
a=fmtp:4 annexa=no
a=rtpmap:96 telephone-event/8000
a=fmtp:96 0-15
a=ptime:30
a=sendrecv
    
```

8. SIP MESSAGE 8: 10.8.58.6:5060 -> 10.8.58.4:5060

```

ACK sip:conf100@10.8.58.4 SIP/2.0
Via: SIP/2.0/UDP 10.8.58.6;branch=z9hG4bKacRRRZPXN
Max-Forwards: 70
From: <sip:600@10.8.8.10>;tag=1c201038291
To: <sip:conf100@10.8.58.4;user=phone>;tag=1c1673415884
Call-ID: 1008914574iYgW@10.8.58.6
CSeq: 1 ACK
Contact: <sip:600@10.8.58.6>
Supported: em,timer,replaces,path
Allow:REGISTER,OPTIONS,INVITE,ACK,CANCEL,BYE,NOTIFY,PRACK,REFER,INFO,SUBSCRIBE,UPDATE
User-Agent: Audiocodes-Sip-Gateway-Mediant
1000/v.4.60A.005.009
Content-Length: 0
    
```

9. SIP MESSAGE 9: 10.8.58.8:5060 -> 10.8.58.4:5060

```

INVITE sip:conf100@10.8.58.4;user=phone SIP/2.0
Via: SIP/2.0/UDP 10.8.58.8;branch=z9hG4bKaczJpxnnv
Max-Forwards: 70
From: <sip:800@10.8.58.8>;tag=1c2419012378
To: <sip:conf100@10.8.58.4;user=phone>
Call-ID: 150852731NDDC@10.8.58.8
CSeq: 1 INVITE
Contact: <sip:800@10.8.58.8>
Supported: em,timer,replaces,path
Allow:REGISTER,OPTIONS,INVITE,ACK,CANCEL,BYE,NOTIFY,PRACK,REFER,INFO,SUBSCRIBE,UPDATE
    
```

```
User-Agent: Audiocodes-Sip-Gateway-Mediant
1000/v.4.60A.005.009
Content-Type: application/sdp Content-Length: 236
v=0
o=AudiocodesGW 558246 666026 IN IP4 10.8.58.8
s=Phone-Call
c=IN IP4 10.8.58.8
t=0 0 m=audio 6000 RTP/AVP 4 96
a=rtpmap:4 g723/8000
a=fmtp:4 annexa=no
a=rtpmap:96 telephone-event/8000
a=fmtp:96 0-15
a=ptime:30
a=sendrecv
```

10. SIP MESSAGE 10: 10.8.58.4:5060 -> 10.8.58.8:5060

```
SIP/2.0 100 Trying
Via: SIP/2.0/UDP 10.8.58.8;branch=z9hG4bKaczJpxnnv
From: <sip:800@10.8.58.8>;tag=1c2419012378
To: <sip:conf100@10.8.58.4;user=phone>;tag=1c3203015250
Call-ID: 150852731NDDC@10.8.58.8
CSeq: 1 INVITE
Supported: em,timer,replaces,path
Allow:REGISTER,OPTIONS,INVITE,ACK,CANCEL,BYE,NOTIFY,PRACK,REFER,INFO,SUBSCRIBE,UPDATE
Server: Audiocodes-Sip-Gateway-Mediant 1000/v.5.40A.010.006
Content-Length: 0
```

11. SIP MESSAGE 11: 10.8.58.4:5060 -> 10.8.58.8:5060

```
SIP/2.0 200 OK
Via: SIP/2.0/UDP 10.8.58.8;branch=z9hG4bKaczJpxnnv
From: <sip:800@10.8.58.8>;tag=1c2419012378
To: <sip:conf100@10.8.58.4;user=phone>;tag=1c3203015250
Call-ID: 150852731NDDC@10.8.58.8
CSeq: 1 INVITE
Contact: <sip:conf100@10.8.58.4>
Supported: em,timer,replaces,path
Allow:REGISTER,OPTIONS,INVITE,ACK,CANCEL,BYE,NOTIFY,PRACK,REFER,INFO,SUBSCRIBE,UPDATE
Server: Audiocodes-Sip-Gateway-Mediant 1000/v.5.40A.010.006
Content-Type: application/sdp
Content-Length: 236
v=0
o=AudiocodesGW 385533 708665 IN IP4 10.8.58.4
s=Phone-Call
c=IN IP4 10.8.58.4
t=0 0
m=audio 7140 RTP/AVP 4 96
a=rtpmap:4 g723/8000
a=fmtp:4 annexa=no
a=rtpmap:96 telephone-event/8000
a=fmtp:96 0-15
a=ptime:30
a=sendrecv
```

12. SIP MESSAGE 12: 10.8.58.8:5060 -> 10.8.58.4:5060

```
ACK sip:conf100@10.8.58.4 SIP/2.0
Via: SIP/2.0/UDP 10.8.58.8;branch=z9hG4bKacisqqyow
Max-Forwards: 70
From: <sip:800@10.8.58.8>;tag=1c2419012378
```

```
To: <sip:conf100@10.8.58.4;user=phone>;tag=1c3203015250
Call-ID: 150852731NDDC@10.8.58.8
CSeq: 1 ACK
Contact: <sip:800@10.8.58.8>
Supported: em,timer,replaces,path
Allow:REGISTER,OPTIONS,INVITE,ACK,CANCEL,BYE,NOTIFY,PRACK,REFER,INFO,SUBSCRIBE,UPDATE
User-Agent: Audiocodes-Sip-Gateway-Mediant
1000/v.5.40A.010.006
Content-Length: 0
```

13. SIP MESSAGE 13: 10.8.58.8:5060 -> 10.8.58.4:5060

```
BYE sip:conf100@10.8.58.4 SIP/2.0
Via: SIP/2.0/UDP 10.8.58.8;branch=z9hG4bKackSIyGww
Max-Forwards: 70
From: <sip:800@10.8.58.8>;tag=1c2419012378
To: <sip:conf100@10.8.58.4;user=phone>;tag=1c3203015250
Call-ID: 150852731NDDC@10.8.58.8
CSeq: 2 BYE
Contact: <sip:800@10.8.58.8>
Supported: em,timer,replaces,path
Allow:REGISTER,OPTIONS,INVITE,ACK,CANCEL,BYE,NOTIFY,PRACK,REFER,INFO,SUBSCRIBE,UPDATE
User-Agent: Audiocodes-Sip-Gateway-Mediant
1000/v.5.40A.010.006
Content-Length: 0
```

14. SIP MESSAGE 14: 10.8.58.4:5060 -> 10.8.58.8:5060

```
SIP/2.0 200 OK
Via: SIP/2.0/UDP 10.8.58.8;branch=z9hG4bKackSIyGww
From: <sip:800@10.8.58.8>;tag=1c2419012378
To: <sip:conf100@10.8.58.4;user=phone>;tag=1c3203015250
Call-ID: 150852731NDDC@10.8.58.8
CSeq: 2 BYE
Contact: <sip:conf100@10.8.58.4>
Supported: em,timer,replaces,path
Allow:REGISTER,OPTIONS,INVITE,ACK,CANCEL,BYE,NOTIFY,PRACK,REFER,INFO,SUBSCRIBE,UPDATE
Server: Audiocodes-Sip-Gateway-Mediant 1000/v.5.40A.010.006
Content-Length: 0
```

15. SIP MESSAGE 15: 10.8.58.6:5060 -> 10.8.58.4:5060

```
BYE sip:conf100@10.8.58.4 SIP/2.0
Via: SIP/2.0/UDP 10.8.58.6;branch=z9hG4bKacQypxnvl
Max-Forwards: 70
From: <sip:600@10.8.8.10>;tag=1c201038291
To: <sip:conf100@10.8.58.4;user=phone>;tag=1c1673415884
Call-ID: 1008914574iYgW@10.8.58.6
CSeq: 2 BYE
Contact: <sip:600@10.8.58.6>
Supported: em,timer,replaces,path
Allow:REGISTER,OPTIONS,INVITE,ACK,CANCEL,BYE,NOTIFY,PRACK,REFER,INFO,SUBSCRIBE,UPDATE
User-Agent: Audiocodes-Sip-Gateway-Mediant
1000/v.5.40A.010.006
Content-Length: 0
```

16. SIP MESSAGE 16: 10.8.58.4:5060 -> 10.8.58.6:5060

```
SIP/2.0 200 OK
Via: SIP/2.0/UDP 10.8.58.6;branch=z9hG4bKacQypxnvl
From: <sip:600@10.8.8.10>;tag=1c201038291
To: <sip:conf100@10.8.58.4;user=phone>;tag=1c1673415884
```

```
Call-ID: 1008914574iYgW@10.8.58.6
CSeq: 2 BYE
Contact: <sip:conf100@10.8.58.4>
Supported: em,timer,replaces,path
Allow:REGISTER,OPTIONS,INVITE,ACK,CANCEL,BYE,NOTIFY,PRACK,REFER,INFO,SUBSCRIBE,UPDATE
Server: Audiocodes-Sip-Gateway-Mediant 1000/v.5.40A.010.006
Content-Length: 0
```

Reader's Notes

34 Announcement Server

The device supports playing and recording of announcements (local Voice Prompts or HTTP streaming) and playing of Call Progress Tones over the IP network. Three different methods are available for playing and recording announcements:

- NetAnn for playing a single announcement (see 'NetAnn Interface' on page 467)
- MSCML for playing single or multiple announcements and collecting digits (see 'MSCML Interface' on page 469)

34.1 NetAnn Interface

The device supports playing announcements using NetAnn format (according to RFC 4240).

34.1.1 Playing a Local Voice Prompt

To play a single local Voice Prompt, the Application Server (or any SIP user agent) sends a regular SIP INVITE message with SIP URI that includes the NetAnn Announcement Identifier name. For example:

```
INVITE sip:annc@audiocodes.com; play=file:///12 SIP/2.0
```

The left part of the SIP URI includes the string 'annc'. In the example above, the device starts playing announcement number 12 from the internal Voice Prompts file. The following Voice Prompts file formats are supported:

- file:///
- file:///
- http://<localhost>

The NetAnn Announcement Identifier string is configured by the 'NetAnn Announcement ID' parameter (NetAnnAnnCID), located in the IP Media Settings page (**Configuration** tab > **VoIP** menu > **IP Media** > **IP Media Settings**).

Sending a BYE request terminates the SIP session and stops the playing of the announcement. If the played Voice Prompt reaches its end, the device initiates a BYE message to notify the Application Server that the session has ended.

34.1.2 Playing using HTTP/NFS Streaming

To play a single announcement via HTTP or NFS streaming, the Application Server (or any SIP user agent) sends a regular SIP INVITE message with SIP URI that includes the NetAnn Announcement Identifier name. For example:

```
INVITE sip:annc@ac.com;  
play=http://server.net/gem/Hello.wav SIP/2.0
```

The left part of the SIP URI includes the string 'annc' terminated by the IP address of the HTTP server, and the name and path of the file to be played. In the example above, the device starts playing the 'Hello.wav' file that resides in the folder 'server.net/gem'. The NetAnn Announcement Identifier string is configured by the 'NetAnn Announcement ID' parameter (NetAnnAnnCID), located in the IP Media Settings page (**Configuration** tab > **VoIP** menu > **IP Media** > **IP Media Settings**).

Sending a BYE request terminates the SIP session and stops the playing of the announcement. If the played announcement reaches its end, the device initiates a BYE message to notify the Application Server that the session is ended.

**Notes:**

- A 200 OK message is sent only after the HTTP connection is successfully established and the requested file is found. If the file isn't found, a 404 Not Found response is sent.
- To use NFS, the requested file system should be first mounted by using the NFS Servers table, see 'Configuring the NFS Settings' on page 128.

34.1.3 Supported Attributes

When playing announcements, the following attributes are available:

- **Repeat:** defines the number of times the announcement is repeated. The default is 1. The valid range is 1 to 1000, or -1 (i.e., repeats the message forever).
- **Delay:** defines the delay (in msec) between announcement repetitions. The default is 0. The valid range is 1 to 3,600,000.
- **Duration:** defines the total duration (in msec) the announcement(s) are played. The default is 0 (i.e., no limitation). The valid range is 1 to 3,600,000.

For example:

```
INVITE sip:annc@ac.com;  
play=http://server.net/gem/Hello.wav; repeat=5;delay=10000 SIP/2.0
```

34.2 MSCML Interface


Media Server Control Markup Language (MSCML), according to IETF RFC 5022 is a protocol used in conjunction with SIP to provide advanced announcements handling. MSCML is implemented by adding an XML body to existing SIP INFO messages. Only a single message body (containing a single request or response) is allowed per message.

The device supports all the Interactive Voice Response (IVR) requirements for playing announcements, collecting digits, and recording (Play, PlayCollect, and PlayRecord).



Note: MSCML is only supported on devices operating with 128-MByte RAM size.

The following figure illustrates standard MSCML application architecture:



The architecture comprises the following components:

- **Device:** Operating independently, the device controls and allocates its processing resources to match each application's requirements. Its primary role is to handle requests from the Application server for playing announcements and collecting digits.
- **Application Server:** An application platform that controls the call signaling. It interfaces with the device using MSCML. It instructs the media server to play announcements, collect digits and record voice streams.
- **Remote Storage:** An HTTP server that contains less-frequently used voice prompts for playback and to which voice stream recording is performed.
- **IP Phones / MediaPack:** Client applications.

34.2.1 Operation

The Application server communicates with the device using MSCML Requests (sent by the Application server), as shown in the example below:

```
<?xml version="1.0" encoding="utf-8"?>
  <MediaServerControl version="1.0">
    <request>
      ... request body ...
    </request>
  </MediaServerControl>
```

The device uses MSCML Responses (i.e., sent by the device) to reply to the Application server, as shown in the example below:

```
<?xml version="1.0" encoding="utf-8"?>
  <MediaServerControl version="1.0">
    <response>
      ... response body ...
    </response>
  </MediaServerControl>
```

To start an MSCML IVR call, the Application server (or any SIP user agent) sends a regular SIP INVITE message with a SIP URI that includes the MSCML Identifier name. For example:

```
INVITE sip:ivr@audiocodes.com SIP/2.0
```

The left part of the SIP URI includes the MSCML Identifier string 'ivr', which is configured by the 'MSCML ID' parameter (MSCMLID), located in the IP Media Settings page (**Configuration** tab > **VoIP** menu > **IP Media** > **IP Media Settings**).

After a call is established, SIP INFO messages are used to carry MSCML requests and responses. An INFO message that carries an MSCML body is identified by its content-type header that is set to 'application/mediaservercontrol+xml'.

Note that IVR requests are not queued. Therefore, if a request is received while another is in progress, the device stops the first operation and executes the new request. The device generates a response message for the first request and returns any data collected up to that point. If an application is required to stop a request in progress, it issues a <Stop> request. This request also causes the device to generate a response message.

The device supports basic IVR functions of playing announcements, collecting DTMF digits, and voice stream recording. These services are implemented using the following Request and Response messages:

- <Play> for playing announcements
- <PlayCollect> for playing announcements and collecting digits
- <PlayRecord> for playing announcements and recording voice
- <Stop> for stopping the playing of an announcement

The device sends a Response to each Request that is issued by the Application server.

The <Play>, <PlayCollect>, and <PlayRecord> messages are composed of two sections: Attributes and a Prompt block (the request can contain several different Prompt blocks). The Attributes section includes several request-specific parameters. The Prompt block section itself is also composed of two sections:

- **Prompt-specific Parameter (optional):** *baseurl* - defines a URL address that functions as a prefix to all audio segment URLs in the Prompt block.
- **Physical Audio Segments:** These are physical audio files that are located either locally or on an external HTTP server. If the file is located locally, the reference to it is by using one of the following syntaxes:

'file://x', 'file:///x', 'file:///x' or 'http://localhost/x'

Where x denotes the file's URL in for HTTP streaming.

34.2.2 Playing Announcements

A <Play> request is used to play an announcement to the caller. Each <Play> request contains a single Prompt block and the following request-specific parameters:

- *id*: an optional random number used to synchronize request and response.
- *prompturl*: a specific audio file URL that is used in addition to the references in the Prompt block. This audio file is the first to be played.

An example of an MSCML <Play> Request that includes local and streaming audio files is shown below:

```
<?xml version="1.0" encoding="utf-8"?>
<MediaServerControl version="1.0">
  <request>
    <play id="123">
      <prompt>
        <audio url="http://localhost/1"/>
        <audio url="http://10.3.0.2/aa.wav"/>
        <audiourl="nfs://10.3.0.3/prov_data/bb.wav"/>
      </prompt>
    </play>
  </request>
</MediaServerControl>
```

34.2.3 Playing Announcements and Collecting Digits

The <PlayCollect> request is used to play an announcement to the caller and to then collect entered DTMF digits. The play part of the <PlayCollect> request is identical to the <Play> request. The collect part includes an expected digit map. The collected digits are continuously compared to the digit map. Once a match is found, the collected digits are sent in a <PlayCollect> response. The digit map should be in MGCP format (the type value must be set to 'mgcpdigitmap'). For example:

```
<regex type="mgcpdigitmap" value="([0-1]xxx)">
</regex>
```

Each <PlayCollect> request contains the following request-specific parameters in addition to the Prompt block (all parameters are optional):

- *id*: an optional random number used to synchronize request and response.
- *prompturl*: a specific audio file URL that is used in addition to the references in the prompt block. This audio file is the first to be played.
- *barge*: if set to 'NO', DTMF digits received during announcement playback are ignored. If set to 'YES', DTMF digits received during announcement playback stop the playback and start the digit collection phase.
- *firstdigittimer*: defines the amount of time (in milliseconds) the user does not enter any digits, after which a response is sent indicating timeout.
- *interdigittimer*: defines the amount of time (in milliseconds) the user does not enter any digits after the first DTMF digit is received, after which a response is sent indicating timeout.
- *extradigittimer*: used to enable the following:
 - Detection of command keys (ReturnKey and EscapeKey).

- Not report the shortest match. MGCP Digitmap searches for the shortest possible match. This means that if a digitmap of (123 | 1234) is defined, once the user enters 123, a match is found and a response is sent. If ExtraDigitTimer is defined, the match can also be 1234 because the device waits for the next digits. To use ExtraDigitTimer, it must be defined in the request and you must add a "T" to the Digitmap (for example, 'xxT'). The ExtraDigitTimer is only used when a match is found. Before a match is found, the timer used is the InterDigitTimer. Therefore, if the ExtraDigitTimer expires, a "match" response reason is reported -- never a "timeout".
- *maxdigits*: defines the maximum number of collected DTMF digits after which the device sends a response.
- *cleardigits*: defines whether or not the device clears the digit buffer between subsequent requests.
- *returnkey*: defines a specific digit (including '*' and '#') which (when detected during a collection) stops the collection and initiates a response (that includes all digits collected up to that point) to be sent.
- *escapekey*: defines a specific digit (including '*' and '#') which (when detected during a collection) stops the collection and initiates a response (with no collected digits) to be sent.

An example is shown below of an MSCML <PlayCollect> Request that includes a sequence with variables and an MGCP digit map:

```
<?xml version="1.0" encoding="utf-8"?>
<MediaServerControl version="1.0">
  <request>
    <playcollect id="6379" barge="NO" returnkey="#">
      <prompt>
        <audio url="http://localhost/1">
      </prompt>
      <regex type="mgcpdigitmap" value="([0-
1]xxx)">
    </regex>
  </playcollect>
</request>
</MediaServerControl>
```

An example is shown below of an MSCML <PlayCollect> Response:

```
<?xml version="1.0" encoding="utf-8"?>
<MediaServerControl version="1.0">
  <response request="playcollect" id="6478" code="200"
text="OK" digits="4563">
</response>
</MediaServerControl>
```

34.2.4 Playing Announcements and Recording Voice

The <PlayRecord> request is used to play an announcement to the caller and to then record the voice stream associated with that caller. The play part of the <PlayRecord> request is identical to the <Play> request. The record part includes a URL to which the voice stream is recorded. This URL refers to an HTTP server.

Each <PlayRecord> request contains the following request-specific parameters in addition to the Prompt block (all parameters except 'recurl' are optional):

- *id*: an optional random number used to synchronize request and response.
- *prompturl*: a specific audio file URL that is used in addition to the references in the prompt block. This audio file is the first to be played.
- *barge*: if set to 'NO', DTMF digits received during announcement playback are ignored. If set to 'YES', DTMF digits received during announcement playback stop the

playback and start the recording phase.

- *cleardigits*: defines whether or not the device clears the digit buffer between subsequent requests.
- *escapekey*: defines a specific digit (including "*" and "#") which (when detected during any phase) stops the request and initiates a response.
- *recurl*: the URL on the external storage server to which the RTP stream is sent for recording. This is a mandatory parameter.
- *mode*: defines if the recording 'overwrites' the existing file or 'appends' to it.
- *initsilence*: defines how long to wait for initial speech input before terminating the recording. This parameter may take an integer value in milliseconds.
- *endsilence*: defines how long the device waits after speech has ended to stop the recording. This parameter may take an integer value in milliseconds.
- *duration*: the total time in milliseconds for the entire recording. Once this time expires, recording stops and a response is generated.
- *recstopmask*: defines a digit pattern to which the device compares digits detected during the recording phase. If a match is found, recording stops and a response is sent.

An example is shown below of an MSCML <PlayRecord> Request:

```
<?xml version="1.0" encoding="utf-8"?>
<MediaServerControl version="1.0">
  <request>
    <playrecord id="75899" barge="NO"
Recurl=nfs://10.11.12.13/save/recordings/11.wav>
    <prompt>
      <audio url="nfs://100.101.102.103/45">
    </prompt>
    </playrecord>
  </request>
</MediaServerControl>
```

An example is shown below of an MSCML <PlayRecord> Response:

```
<?xml version="1.0" encoding="utf-8"?>
<MediaServerControl version="1.0">
  <response request="playrecord" id="75899" code="200"
text="OK" reclength="15005">
  </response>
</MediaServerControl>
```

34.2.5 Stopping the Playing of an Announcement

The Application server issues a <stop> request when it requires that the device stops a request in progress and not initiate another operation. The only (optional) request-specific parameter is id.

The device refers to a SIP re-INVITE message with hold media (c=0.0.0.0) as an implicit <Stop> request. The device immediately terminates the request in progress and sends a response.

An example is shown below of an MSCML <Stop> Request:

```
<?xml version="1.0" encoding="utf-8"?>
<MediaServerControl version="1.0">
  <request>
    <stop id="123">
    </stop>
  </request>
</MediaServerControl>
```

34.2.6 Relevant Parameters

The following parameters (described in IP Media Parameters) are used to configure the MSCML:

- AmsProfile = 1 (default and mandatory setting)
- AASPackagesProfile = 3 (default and mandatory setting)
- VoiceStreamUploadMethod = 1 (mandatory)
- EnableVoiceStreaming = 1 (mandatory)
- MSCMLID (default="ivr")
- When using AutoUpdate:
 - VPFileURL
 - AutoUpdateFrequency / AutoUpdatePredefinedTime

34.2.7 Signal Events Notifications

The device supports Signal Events Notifications as defined in RFC 4722/5022 - MSCML. MSCML defines event notifications that are scoped to a specific SIP dialog or call leg. These events allow a client to be notified of various call progress signals. Subscriptions for call leg events are performed by sending an MSCML <configure_leg> request on the desired SIP dialog. Call leg events may be used with the MSCML conferencing or IVR services. Using the Signal Notifications, the device can report the following events:

Reportable Events

Type	Subtype
AMD	<ul style="list-style-type: none"> ▪ voice ▪ automata ▪ silence ▪ unknown
CPT	<ul style="list-style-type: none"> ▪ SIT-NC ▪ SIT-IC ▪ SIT-VC ▪ SIT-RO ▪ busy ▪ reorder
FAX	<ul style="list-style-type: none"> ▪ CED ▪ CNG ▪ modem

Below is an example:

```
<?xml version="1.0"?>
<MediaServerControl version="1.0">
  <request>
    <configure_leg>
      <subscribe>
        <events>
          <signal type="amd" report="yes"/>
        </events>
      </subscribe>
    </configure_leg>
  </request>
</MediaServerControl>
```

```
<?xml version="1.0"?>
<MediaServerControl version="1.0">
  <notification>
    <signal type="amd" subtype="voice"/>
  </notification>
</MediaServerControl>
```

34.3 Voice Streaming

The voice streaming layer provides you with the ability to play and record different types of files while using an NFS or HTTP server.

34.3.1 Voice Streaming Features

The following subsections summarize the Voice Streaming features supported on HTTP and NFS servers, unless stated otherwise.

34.3.1.1 Basic Streaming Play

You may play a .wav, .au or .raw file from a remote server using G.711 coders.

34.3.1.2 Supported File Formats

The voice streaming layer provides support for .wav, .au, and .raw file formats. The maximum supported header size of the file is 150 bytes.

In .wav format, only mono mode and supported/known coders are supported. The maximum number of the non-data, non-fmt chunks can be up to 5.

34.3.1.3 Play from Offset

You may play a .wav, .au or .raw file from a given offset within the file. Offset can be both positive and negative relative to the file's length. A negative offset relates to an offset from the end of the file.

34.3.1.4 Remote File Systems

You may configure up to 16 remote file systems to operate with the system through NFS mounting.

34.3.1.5 Using Proprietary Scripts

You may use cgi or servlet scripts released with the version for recording to a remote HTTP server using the POST or PUT method.

34.3.1.6 Dynamic HTTP URLs

Voice streaming supports dynamic HTTP URLs. The following terminology is used:

- **Static audio content:** Traditional audio file URLs containing references to specific files (.wav, .au or .raw). For example: `http://10.50.0.2/qa/GOSSIP_ENG.wav`
- **Dynamic audio content:** URLs referencing to cgi scripts or servlets. For example: `http://10.50.0.2/cgi/getaudio.cgi?filename=DEFAULT_GREETING.raw&offset=0`

In the case of dynamic URLs, the device performs the GET command with the supplied URL and as a result, the servlet or cgi script on the Web server is invoked. The Web server responds by sending a GET response containing the audio.

The URL format can be as follows (RFC 1738 URLs, section 3.3):

```
http://<host>[:<port>]/<path>?<searchpart>
```

where,

- `[:<port>]` is optional.

- **<path>** is a path to a server-side script.
- **<searchpart>** is of the form: key=value[&key=value]*



Note: At least one key=value pair is required.

Another example of a dynamic URL is shown below:

```
http://MyServer:8080/prompts/servlet?action=play&language=eng&file=welcome.raw&format=1
```

(See also RFC 2396 URI: Generic Syntax.)

The servlet or cgi script can respond by sending a complete audio file or a portion of an audio file. The device skips any .wav or .au file header that it encounters at the beginning of the response. The device does not attempt to use any information in the header. For example, the device does not use the coder from the header. Note however, that the coder may be supplied through Web or *ini* file parameters.

34.3.1.7 Play LBR Audio File

You may play a file using low bit rate coders for .wav and .raw files.



Note: This feature is relevant for both NFS and HTTP.

34.3.1.8 Basic Record

You may record a .wav, .au or .raw files to a remote server using G.711 coders.



Note: This feature is relevant for both NFS and HTTP.

34.3.1.9 Remove DTMF Digits at End of Recording

You may configure a recording to remove the DTMF received at the end, indicating an end of a recording.



Note: This feature is relevant for both NFS and HTTP.

34.3.1.10 Record Files Using LBR

You may record a file using low bit rate coders for .wav and .raw files.



Notes: This feature is relevant for both NFS and HTTP.

34.3.1.11 Modifying Streaming Levels Timers

Several parameters enable the user to control streaming level timers for NFS and HTTP and also the number of data retransmission when using NFS as the application layer protocol:

- **General command timeout – ServerRespondTimeout:** Defines the maximal time a command or respond may be delayed. This relates both to HTTP commands (GET, PUT, POST, HEAD etc.) and to NFS commands (create, lookup, read, write etc.).
- **Recording packet overruns timer – StreamingRecordingOverRunTimeout:** An overrun condition is one in which the device sends data to the server but does not receive responds from the server acknowledging that it received the data. Overruns relate to recording data to a remote server and result with “holes” in the recording. The streaming level aborts sessions containing consecutive overruns as derived from this timer. You may set the timer to longer periods than the default value, thereby enabling the device to be more "tolerant" to overrun conditions.
- **Playing packet underruns – StreamingPlayingUnderRunTimeout:** An underrun condition is one in which the device does not supply the DSPs with sufficient data, thus "starving" the DSPs. Underruns relate to playing data from a server to the device where, due to environmental conditions (usually network problems), the data is not passed quickly enough. This condition results with broken data passed to the user. The streaming level aborts sessions containing consecutive underruns as derived from this timer. You may set the timer to longer periods than the default value, thereby enabling the device to be more "tolerant" to underrun conditions.
- **NFS command retransmission – NFSClientMaxRetransmission:** Defines the number of times an NFS command is retransmitted when the server side does not respond. By default, the value is set to 0 and not used - instead, the number of retransmissions is derived from the server response timeout parameter and the current Recovery Time Objective (RTO) of the system.

These parameters may be configured using the *ini* file, Web interface, or SNMP.

34.3.2 Using File Coders with Different Channel Coders

The tables in the following subsections describe the support for different combinations of file coders (used for recording or playing a file) and channel coders (used when opening a voice channel).

The following abbreviations are used in the subsequent tables:

- **LBR:** Low Bit Rate Coder
- **PCMU:** G.711 μ -law coder
- **PCMA:** G.711 A-law coder
- **WB:** Linear PCM 16KHZ Wide Band Coder



Note: When recording with an LBR type coder, it is assumed that the same coder is used both as the file coder and the channel coder. Combinations of different LBR coders are currently not supported.

34.3.2.1 Playing a File

The table below lists the device's support of channel coders and file coders for playing a file.

Coder Combinations - Playing a File

File Coder	File Type											
	.wav				.au				.raw			
	Channel Coder				Channel Coder				Channel Coder			
	PCMA	PCMU	LBR	WB	PCMA	PCMU	LBR	WB	PCMA	PCMU	LBR	WB
PCMA	Yes	Yes	Yes	Yes	Yes	Yes	Yes	No	Yes	Yes	Yes	Yes
PCMU	Yes	Yes	Yes	Yes	Yes	Yes	Yes	No	Yes	Yes	Yes	Yes
LBR	No	No	Yes	No	No	No	No	No	No	No	Yes	Yes

34.3.2.2 Recording a File

The table below lists the device's support of channel coders and file coders for recording a file.

Coder Combinations - Recording a File

File Coder	File Type											
	WAV				AU				RAW			
	Channel Coder				Channel Coder				Channel Coder			
	PCMA	PCMU	LBR	WB	PCMA	PCMU	LBR	WB	PCMA	PCMU	LBR	WB
PCMA	Yes	Yes	Yes	No	Yes	Yes	Yes	No	Yes	Yes	Yes	No
PCMU	Yes	Yes	Yes	No	Yes	Yes	Yes	No	Yes	Yes	Yes	No
LBR	No	No	Yes	No	No	No	No	No	No	No	No	No

34.3.3 Maximum Concurrent Playing and Recording

For details on maximum concurrent playing and recording, refer to the *Release Notes*.

34.3.4 LBR Coders Support

The following table describes the different low bit rate (LBR) coders and their support for .wav, .au, and .raw files.



Note: Coder support depends on the specific DSP template version installed on the device.

LBR Coders and File Extension Support

Coder	.wav file	.raw file	.au file
G.726 (Rate 16)	Yes	Yes	No
G.726 (Rate 24)	Yes	Yes	No
G.726 (Rate 32)	Yes	Yes	No
G.726 (Rate 40)	Yes	Yes	No
G.723.1 (Rate 5.3)	Yes	Yes	No
G.723.1 (Rate 6.3)	Yes	Yes	No
G.729	Yes	Yes	No
GSM FR	Yes	Yes	No
MS GSM	Yes	Yes	No
GSM EFR	Yes	Yes	No
AMR (Rate 4.75)	No	Yes	No
AMR (Rate 5.15)	No	Yes	No
AMR (Rate 5.9)	No	Yes	No
AMR (Rate 6.7)	No	Yes	No
AMR (Rate 7.4)	No	Yes	No
AMR (Rate 7.95)	No	Yes	No
AMR (Rate 10.2)	No	Yes	No
AMR (Rate 12.2)	No	Yes	No
QCELP (Rate 8)	No	Yes	No
QCELP (Rate 13)	No	Yes	No

34.3.5 HTTP Recording Configuration

The HTTP record method (PUT or POST) is configured using the following offline *ini* parameter:

```
// 0=post (default), 1=put
VoiceStreamUploadMethod = 1
```

The default is shown below:

```
VoiceStreamUploadPostUri =
"/audioupload/servlet/AcAudioUploadServlet"
```



Note: The PUT method disregards this string.

34.3.6 NFS Configuration Using the ini File

An example of an NFS configuration is shown below. In this example, NFS server 192.168.20.26 shares two file systems - one rooted at /PROV_data, and the other rooted at /opt/uas. NFSv3 is used for both remote file systems. The defaults for UID(0) and GID(1) are used.

```
[NFSServers]
FORMAT NFSServers_Index = NFSServers_HostOrIP,
NFSServers_RootPath, NFSServers_NfsVersion;
NFSServers 0 = 192.168.20.26, /PROV_data, 3;
NFSServers 1 = 192.168.20.26, /opt/uas, 3;
[\NFSServers]
```



Notes:

- The combination of Host/IP and Root Path should be unique for each row in the table. For example, there should be only one row in the table with a Host/IP of 192.168.1.1 and Root Path of /audio.
- To avoid terminating calls in progress, a row must not be deleted or modified while the system is accessing files on the remote NFS file system.
- An NFS file server can share multiple file systems. There must be a separate row in this table for each remote file system shared by the NFS file server that needs to be accessed by this system.
- For further details, see 'Configuring the NFS Settings' on page 128.

34.3.7 Supported HTTP Servers

The following is a list of HTTP servers that are known to be compatible with AudioCodes voice streaming under Linux™:

- **Apache:** cgi scripts are used for recording and supporting dynamic URLs.
- **Jetty:** servlets scripts are used for recording and supporting dynamic URLs.
- **Apache tomcat:** using servlets.

34.3.7.1 Tuning the Apache Server

It is recommended to perform the following modifications in the http.conf file located in the apache conf/ directory:

- Define PUT script location: Assuming the put.cgi file is included in this package, add the following line for defining the PUT script (script must be placed in the cgi-bin/ directory):

```
Script PUT /cgi-bin/put.cgi
```

- Create the directory /the-apache-dir/perl (for example, /var/www/perl) and copy the

CGI script to this directory. In the script, change the first line from `c:/perl/bin/perl` to your perl executable file (this step is required only if `mod_perl` is not included in your Apache installation).

- Keep-alive parameters: the following parameters must be set for correct operation with multiple POST requests:

```
KeepAlive On
MaxKeepAliveRequests 0 (unlimited amount)
```

- Using mode perl, fix the `mod_perl` to the following:

```
<IfModule mod_perl.c>
<Location /cgi-bin>
  SetHandler perl-script
  PerlResponseHandler ModPerl::Registry
  Options +ExecCGI
  PerlOptions +ParseHeaders
  Order allow,deny
  Allow from all
</Location>
</IfModule>
```

- Apache MPM worker: it is recommended to use the Multi-Processing Module implementing a hybrid multi-threaded multi-process Web server. The following configuration is recommended:

```
<IfModule worker.c>
ThreadLimit      64
StartServers     2
ServerLimit     20000
MaxClients      16384
MinSpareThreads 100
MaxSpareThreads 250
ThreadsPerChild 64
MaxRequestsPerChild 16384
</IfModule>
```

34.3.8 Supporting NFS Servers

The table below lists the NFS servers that are known to be compatible with AudioCodes Voice Streaming functionality.

Compatible NFS Servers

Operating System	Server	Versions
Solaris™ 5.8 and 5.9	nfsd	2, 3
Fedora™ Linux™ 2.6.5-1.358	nfsd	2, 3
Mandrake™ Linux™ v2.4.22	nfsd	2, 3
Windows™ 2000	Services For Unix™ (SFU)	2, 3
Windows™ 2000	winnfsd	2 (See Note)
SCO UnixWare™ 7.1.1	nfsd	2, 3
Windows™ 2000	Cygwin nfsd	2 (See Note)



Note: Cygwin and winnfsd support only NFSv2.

34.3.8.1 Solaris-Based NFS Servers

If you are using a Solaris™-based NFS server, then the following `nfsd` configuration modification is recommended, especially if you are planning to support voice recording:

- Edit the file `/etc/default/nfs` and set the value of `NFSD_SERVERS` to $N*2$, where N is the maximum number of record and play sessions that you expect to have in progress at any one time.

The `NFSD_SERVERS` parameter controls the number of worker threads that the NFS daemon uses to satisfy requests. When a request arrives, a check is made for an idle worker thread. If an idle worker thread is available, then the request is passed to it. If an idle worker thread is unavailable, then a new one is created and the request is passed to it. If the limit in worker threads is reached, the request is queued until one of the existing worker threads is available. Queuing of NFS requests from a real-time application such as the media server should be avoided. Therefore, the `NFSD_SERVERS` parameter should be used to ensure there is an adequate number of worker threads.

The default value for `NFSD_SERVERS` is 1. Typically, the `/etc/default/nfs` file contains `NFSD_SERVERS` set to 16.

To determine how many worker threads are running on the NFS server, invoke the following command:

```
pstack `pgrep nfsd` | grep nfssys | wc -l
```

An idle NFS daemon process displays 1 `nfsd` thread.

- Directories are shared by placing an entry in the `/etc/dfs/dfstab` file. See the `share(1M)` and `share_nfs(1M)` main pages for information on the format of entries in the `dfstab` file. Note that read-write (`rw`) is the default behavior. If you are planning to record to the file system, ensure that the directory is shared as `rw`. Also ensure that the recording directory has 777 (`rwrxrwx`) permissions.

Below is an example `/etc/dfs/dfstab` file. Note that `/audio1` is shared as read-only, and `/audio2` is shared as read-write.

```
> cat /etc/dfs/dfstab
share -F nfs -o ro /audio1
share -F nfs /audio2
```

- Ensure that the `/etc/nfssec.conf` file is configured so that "sys" is the default security mode. You should see the following:

```
> cat /etc/nfssec.conf
none      0      -      -      -      # AUTH_NONE
sys       1      -      -      -      # AUTH_SYS
dh        3      -      -      -      # AUTH_DH
default   1      -      -      -      # default is AUTH_SYS
```

- If the systems administrator wishes to use a default other than `AUTH_SYS` in the `nfssec.conf` file, then you should add "sec=sys" to each line in the `dfstab` file that is to be shared with an AudioCodes system. For example:

```
> cat /etc/dfs/dfstab
share -F nfs -o sec=sys,ro /audio1
share -F nfs -o sec=sys /audio2
```

- To restart the `nfs` daemon on Solaris, invoke the following two commands:

```
> /etc/init.d/nfs.server stop
> /etc/init.d/nfs.server start
```

- To view a log of directories which were shared on the previous restart of the nfs daemon, type the sharetab file. For example:

```
> cat /etc/dfs/sharetab
/audio1      -      nfs      ro
/audio2      -      nfs      rw
```

Other useful Solaris™ commands include the following:

- dfmounts: displays shared directories, including a list of clients that have these resources mounted.
- dfshares: displays a list of shared directories.

34.3.8.2 Linux-Based NFS Servers

The AudioCodes device uses local UDP ports that are outside of the range of 0..IPPORT_RESERVED(1024). Therefore, when configuring a remote file system to be accessed by an AudioCodes device, use the insecure option in the /etc/exports file. The insecure option allows the nfs daemon to accept mount requests from ports outside of this range.

Without the insecure option, the following nfs daemon log is received:

```
rpc.mountd: refused mount request from <ip> for <dir> illegal port
28000
```

Without the insecure option, the following Syslog is received:

```
NFS mount failed, reason=permission denied IP=<ip> path=<dir>
state=waitForMountReply numRetries=0
```

For more information, see the exports(5) main page on your Linux server.

An example /etc/exports entry is shown below:

```
/nfsshare *(rw,insecure,no_root_squash,no_all_squash,sync)
```

34.3.9 Common Troubleshooting

Always inspect the Syslog for any problem you may encounter; in many cases, the cause appears there.


Troubleshooting

Problem	Probable Cause	Corrective Action
General Voice Streaming Problems		
Attempts to perform voice streaming operations results in each Syslog containing the string: 'VS_STACK_NOT_ACTIVE'.	Voice streaming is not enabled.	Enable voice streaming by loading an <i>ini</i> file containing this entry: EnableVoiceStreaming = 1
HTTP Voice Streaming Problems		

Problem	Probable Cause	Corrective Action
<p>The last half-second of an announcement is not played, or a record operation terminates abnormally and the Syslog displays the following: 'VSReceiveFromNetwork: VS_CONNECTION_WITH_SERVER_LOST'. (The problem has been experienced with Apache version 2.0.50 on Solaris 9.)</p>	<p>The Web server is closing the virtual circuit at unexpected times.</p>	<p>Increase the Apache KeepAliveTimeout config parameter. Try to increase it to 30 seconds or longer than the longest announcement or expected record session.</p>
NFS Voice Streaming Problems		
<p>Announcement is terminated prematurely and the Syslog displays the following: 'NFS request aborted ... networkError'.</p>	<p>The AudioCodes media server has lost communication with the NFS server. A network problem or some problem with the NFS server exists.</p>	<p>Fix the network problem or NFS server problem. Ensure that the NFS server is not over-loaded.</p>
<p>Unable to play announcements from an NFS server and each Syslog displays the following: 'Unable to create new request, file system not mounted' 'NFS mount error ...'</p>	<p>Either there is a problem with the NFS server, the network, or configuration of the media server or NFS server.</p>	<p>Fix the network problem or NFS server problem. Check the configuration on both the media server and the NFS server.</p>
<p>Record is terminated prematurely and the Syslog displays the following: 'VeData: no free buffers, req=16' 'Unable to play announNFS request aborted, reqid=16 cid=16 error=noRecordBufferError reqtype=vsHostRecord state=recTransfer'.</p>	<p>This occurs when the media server is receiving audio faster than it can save it to the remote NFS server. Either there is a problem with the NFS server, the network, or configuration of the media server or NFS server.</p>	<p>Fix the network problem or NFS server problem. Check the configuration on both the media server and the NFS server.</p>
<p>Remote file system is not being mounted and the Syslog displays the following: 'NFS mount failed, reason=permission denied IP=<ip> path=<dir> state=waitForMountReply numRetries=0;'</p>	<p>The NFS server is not configured to accept requests on ports outside of the range 0...1024.</p>	<p>On a Linux NFS server, use the insecure option in the /etc/exports file (see Linux-Based NFS Servers on page 484).</p>
<p>All recording sessions are aborted at the same time with these Syslogs: 'NFS request aborted, reqid=209 cid=-1 error=writeReplyError reqtype=writeFile state=writeWait [File:NfsStateMachine.cpp ...]' 'NFS request aborted, reqid=186 cid=-1 error=writeReplyError reqtype=writeFile state=writeWait [File:NfsStateMachine.cpp ...]'</p>	<p>The file system on the NFS server is full.</p>	<p>Remove unwanted files on the file system.</p>

34.4 Announcement Call Flow Example

The call flow, shown in the following figure, describes SIP messages exchanged between the device (10.33.24.1) and a SIP client (10.33.2.40) requesting to play local announcement #1 (10.8.25.17) using AudioCodes proprietary method.



1. SIP MESSAGE 1: 10.33.2.40:5060 -> 10.33.24.1:5060

```

INVITE
sip:annc@10.33.24.1;play=http://10.3.0.2/hello.wav;repeat=2
SIP/2.0
Via: SIP/2.0/UDP 10.33.2.40;branch=z9hG4bKactXhKPQT
Max-Forwards: 70
From: <sip:103@10.33.2.40>;tag=1c2917829348
To: <sip:annc@10.33.24.1>
Call-ID: 1414622340oZZq@10.33.2.40
CSeq: 1 INVITE
Contact: <sip:103@10.33.2.40>
Supported: em,100rel,timer,replaces,path
Allow:REGISTER,OPTIONS,INVITE,ACK,CANCEL,BYE,NOTIFY,PRACK,REFER,INFO,SUBSCRIBE,UPDATE
User-Agent: Audiocodes-Sip-Gateway-4.0 GA/v.4.0 GA
Content-Type: application/sdp
Content-Length: 215
v=0
o=AudiocodesGW 377662 728960 IN IP4 10.33.41.52
s=Phone-Call
c=IN IP4 10.33.41.52
t=0 0
m=audio 4030 RTP/AVP 4 0 8
a=rtpmap:4 g723/8000
a=rtpmap:0 pcmu/8000
a=rtpmap:8 pcma/8000
a=ptime:30
a=sendrecv
    
```

2. SIP MESSAGE 2: 10.33.24.1:5060 -> 10.33.2.40:5060

```

SIP/2.0 100 Trying
Via: SIP/2.0/UDP 10.33.2.40;branch=z9hG4bKactXhKPQT
From: <sip:103@10.33.2.40>;tag=1c2917829348
To: <sip:annc@10.33.24.1>;tag=1c1528117157
Call-ID: 1414622340oZZq@10.33.2.40
CSeq: 1 INVITE
    
```

```
Supported: em,timer,replaces,path
Allow:REGISTER,OPTIONS,INVITE,ACK,CANCEL,BYE,NOTIFY,PRACK,REFER,INFO,SUBSCRIBE,UPDATE
Server: Audiocodes-Sip-Gateway-Mediant 1000/v.5.40.010.006D
Content-Length: 0
```

3. SIP MESSAGE 3: 10.33.24.1:5060 -> 10.33.2.40:5060

```
SIP/2.0 200 OK
Via: SIP/2.0/UDP 10.33.2.40;branch=z9hG4bKactXhKPQT
From: <sip:103@10.33.2.40>;tag=1c2917829348
To: <sip:annc@10.33.24.1>;tag=1c1528117157
Call-ID: 1414622340oZZq@10.33.2.40
CSeq: 1 INVITE Contact: <sip:10.33.24.1>
Supported: em,timer,replaces,path
Allow:REGISTER,OPTIONS,INVITE,ACK,CANCEL,BYE,NOTIFY,PRACK,REFER,INFO,SUBSCRIBE,UPDATE
Server: Audiocodes-Sip-Gateway-Mediant 1000/v.5.40.010.006D
Content-Type: application/sdp
Content-Length: 165
v=0
o=AudiocodesGW 355320 153319 IN IP4 10.33.24.1
s=Phone-Call
c=IN IP4 10.33.24.1
t=0 0
m=audio 7170 RTP/AVP 0
a=rtpmap:0 pcmu/8000
a=ptime:20
a=sendrecv
```

4. SIP MESSAGE 4: 10.33.2.40:5060 -> 10.33.24.1:5060

```
ACK sip:10.33.24.1 SIP/2.0
Via: SIP/2.0/UDP 10.33.2.40;branch=z9hG4bKacnNUEeKP
Max-Forwards: 70
From: <sip:103@10.33.2.40>;tag=1c2917829348
To: <sip:annc@10.33.24.1>;tag=1c1528117157
Call-ID: 1414622340oZZq@10.33.2.40
CSeq: 1 ACK
Contact: <sip:103@10.33.2.40>
Supported: em,timer,replaces,path
Allow:REGISTER,OPTIONS,INVITE,ACK,CANCEL,BYE,NOTIFY,PRACK,REFER,INFO,SUBSCRIBE,UPDATE
User-Agent: Audiocodes-Sip-Gateway-4.0 GA/v.4.0 GA
Content-Length: 0
```

5. SIP MESSAGE 5: 10.33.24.1:5060 -> 10.33.2.40:5060

```
BYE sip:103@10.33.2.40 SIP/2.0
Via: SIP/2.0/UDP 10.33.24.1;branch=z9hG4bKacFhtFbFR
Max-Forwards: 70
From: <sip:annc@10.33.24.1>;tag=1c1528117157
To: <sip:103@10.33.2.40>;tag=1c2917829348
Call-ID: 1414622340oZZq@10.33.2.40
CSeq: 1 BYE
Contact: <sip:10.33.24.1>
Supported: em,timer,replaces,path
Allow:REGISTER,OPTIONS,INVITE,ACK,CANCEL,BYE,NOTIFY,PRACK,REFER,INFO,SUBSCRIBE,UPDATE
User-Agent: Audiocodes-Sip-Gateway-Mediant
1000/v.5.40.010.006D
Content-Length: 0
```

6. SIP MESSAGE 6: 10.33.2.40:5060 -> 10.33.24.1:5060

```
SIP/2.0 200 OK
Via: SIP/2.0/UDP 10.33.24.1;branch=z9hG4bKacFhtFbFR
From: <sip:annc@10.33.24.1>;tag=1c1528117157
To: <sip:103@10.33.2.40>;tag=1c2917829348
Call-ID: 1414622340oZZq@10.33.2.40
CSeq: 1 BYE
Contact: <sip:103@10.33.2.40>
Supported: em,timer,replaces,path
Allow:REGISTER,OPTIONS,INVITE,ACK,CANCEL,BYE,NOTIFY,PRACK,REFER,INFO,SUBSCRIBE,UPDATE
Server: Audiocodes-Sip-Gateway-4.0 GA/v.4.0 GA
Content-Length: 0
```

Part VIII

Maintenance

35 Basic Maintenance

The Maintenance Actions page allows you to perform the following:

- Reset the device - see 'Resetting the Device' on page 491
- Lock and unlock the device - see 'Locking and Unlocking the Device' on page 493
- Save configuration to the device's flash memory - see 'Saving Configuration' on page 494

➤ **To access the Maintenance Actions page, do one of the following:**

- On the toolbar, click the **Device Actions** button, and then from the drop-down menu, choose **Reset**.
- On the Navigation bar, click the **Maintenance** tab, and then in the Navigation tree, select the **Maintenance** menu and choose **Maintenance Actions**.

Figure 35-1: Maintenance Actions Page

▼ Reset Configuration	
Reset Board	<input type="button" value="Reset"/>
Burn To FLASH	Yes <input type="button" value="v"/>
Graceful Option	No <input type="button" value="v"/>
▼ LOCK / UNLOCK	
Lock	<input type="button" value="LOCK"/>
Graceful Option	No <input type="button" value="v"/>
Current Admin State	UNLOCKED
▼ Save Configuration	
Burn To FLASH	<input type="button" value="BURN"/>

35.1 Resetting the Device

The Maintenance Actions page allows you to remotely reset the device. In addition, before resetting the device, you can choose the following options:

- Save the device's current configuration to the device's flash memory (non-volatile).
- Perform a graceful shutdown, whereby device reset starts only after a user-defined time (i.e., timeout) or after no more active traffic exists (the earliest thereof).




Notes:

- Throughout the Web interface, parameters displayed with a lightning ⚡ symbol are not applied on-the-fly and require that you reset the device for them to take effect.
- When you modify parameters that require a device reset, once you click the **Submit** button in the relevant page, the toolbar displays "Reset" (see 'Toolbar Description' on page 42) to indicate that a device reset is required.
- After you reset the device, the Web GUI is displayed in Basic view (see 'Displaying Navigation Tree in Basic and Full View' on page 43).

- **To reset the device:**
1. Open the Maintenance Actions page (see 'Basic Maintenance' on page 491).
 2. Under the 'Reset Configuration' group, from the 'Burn To FLASH' drop-down list, select one of the following options:
 - **Yes:** The device's current configuration is saved (*burned*) to the flash memory prior to reset (default).
 - **No:** Resets the device without saving the current configuration to flash (discards all unsaved modifications).
 3. Under the 'Reset Configuration' group, from the 'Graceful Option' drop-down list, select one of the following options:
 - **Yes:** Reset starts only after the user-defined time in the 'Shutdown Timeout' field (see Step 4) expires or after no more active traffic exists (the earliest thereof). In addition, no new traffic is accepted.
 - **No:** Reset starts regardless of traffic, and any existing traffic is terminated at once.
 4. In the 'Shutdown Timeout' field (relevant only if the 'Graceful Option' in the previous step is set to **Yes**), enter the time after which the device resets. Note that if no traffic exists and the time has not yet expired, the device resets.
 5. Click the **Reset** button; a confirmation message box appears, requesting you to confirm.

Figure 35-2: Reset Confirmation Message Box



6. Click **OK** to confirm device reset; if the parameter 'Graceful Option' is set to **Yes** (in Step 3), the reset is delayed and a screen displaying the number of remaining calls and time is displayed. When the device begins to reset, a message appears notifying you of this.

35.2 Remotely Resetting Device using SIP NOTIFY

The device can be remotely reset upon the receipt of a SIP NOTIFY that includes an Event header set to 'check-sync;reboot=true', as shown in the example below:

```
NOTIFY sip:<user>@<dsthost> SIP/2.0
To: sip:<user>@<dsthost>
From: sip:sipsak@<srchost>
CSeq: 10 NOTIFY
Call-ID: 1234@<srchost>
Event: check-sync;reboot=true
```

- **To enable remote reset upon receipt of SIP NOTIFY:**
1. Open the Advanced Parameters page (**Configuration** tab > **VoIP** menu > **SIP Definitions** > **Advanced Parameters**).
 2. Under the Misc Parameters group, set the 'SIP Remote Rest' parameter to **Enable**.
 3. Click **Submit**.




Note: This SIP Event header value is proprietary to AudioCodes.

35.3 Locking and Unlocking the Device

The Lock and Unlock option allows you to lock the device so that it doesn't accept any new calls and maintains only the current calls. This is useful when, for example, you are uploading new software files to the device and you don't want any traffic to interfere with the process.

- **To lock the device:**
1. Open the Maintenance Actions page (see 'Basic Maintenance' on page 491).
 2. Under the 'LOCK / UNLOCK' group, from the 'Graceful Option' drop-down list, select one of the following options:
 - **Yes:** The device is 'locked' only after the user-defined time in the 'Lock Timeout' field (see Step 3) expires or no more active traffic exists (the earliest thereof). In addition, no new traffic is accepted.
 - **No:** The device is 'locked' regardless of traffic. Any existing traffic is terminated immediately.
- Note:** These options are only available if the current status of the device is in the Unlock state.
3. In the 'Lock Timeout' field (relevant only if the parameter 'Graceful Option' in the previous step is set to **Yes**), enter the time (in seconds) after which the device locks. Note that if no traffic exists and the time has not yet expired, the device locks.
 4. Click the **LOCK** button; a confirmation message box appears requesting you to confirm device Lock.

Figure 35-3: Device Lock Confirmation Message Box



5. Click **OK** to confirm device Lock; if 'Graceful Option' is set to **Yes**, the lock is delayed and a screen displaying the number of remaining calls and time is displayed.

Otherwise, the lock process begins immediately. The Current Admin State' field displays the current state - "LOCKED" or "UNLOCKED".

➤ **To unlock the device:**

1. Open the Maintenance Actions page (see 'Maintenance Actions' on page 491).
2. Under the 'LOCK / UNLOCK' group, click the **UNLOCK** button. Unlock starts immediately and the device accepts new incoming calls.



Note: The Home page's General Information pane displays whether the device is locked or unlocked (see 'Viewing the Home Page' on page 61).

35.4 Saving Configuration

The Maintenance Actions page allows you to save (*burn*) the current parameter configuration (including loaded auxiliary files) to the device's *non-volatile* memory (i.e., flash). The parameter modifications that you make throughout the Web interface's pages are temporarily saved (to the *volatile* memory - RAM) when you click the **Submit** button on these pages. Parameter settings that are saved only to the device's RAM revert to their previous settings after a hardware/software reset (or power failure). Therefore, to ensure that your configuration changes are retained, you must save them to the device's flash memory using the burn option described below.

➤ **To save the changes to the non-volatile flash memory :**

1. Open the Maintenance Actions page (see 'Basic Maintenance' on page 491).
2. Under the 'Save Configuration' group, click the **BURN** button; a confirmation message appears when the configuration successfully saves.



Notes:

- Saving configuration to the *non-volatile* memory may disrupt current traffic on the device. To avoid this, disable all new traffic before saving, by performing a graceful lock (see 'Locking and Unlocking the Device' on page 493).
- Throughout the Web interface, parameters displayed with the lightning ⚡ symbol are not applied on-the-fly and require that you reset the device for them to take effect (see 'Resetting the Device' on page 491).
- The Home page's General Information pane displays whether the device is currently "burning" the configuration (see 'Viewing the Home Page' on page 61).

36 Replacing Modules

To replace the device's modules, you must use the Web interface in combination with physical removal and insertion of the modules. In other words, when you replace a module, you first need to 'software-remove' it, then extract it physically from the chassis and insert a new module, and then 'software-insert' it using the Web interface. The software removal and insertion is performed in the Home page.



Warnings:

- A module must be replaced with the same type of module and in the same module slot number. For example, a module with two digital spans in Slot 1 must be replaced with a module with two digital spans in Slot 1.
- When only one module is available, removal of the module causes the device to reset.
- Before inserting a module into a previously empty slot, you must power down the device.




Note: This section is applicable only to Mediant 1000.

➤ To replace a module:


1. Remove the module by performing the following:
 - a. In the Home page, click the title of the module that you want to replace; the **Remove Module** button appears:

Figure 36-1: Remove Module Button



- b. Click the **Remove Module** button; a message box appears requesting you to confirm module removal:

Figure 36-2: Module Removal Confirmation Message Box




- c. Click **OK** to confirm removal; after a few seconds, the module is software-removed, the module status icon turns to grey, and the name of the module is suffixed with the word 'Reserved':



- d. Physically remove the module (refer to the *Installation Manual*).
2. Insert the replaced module, by performing the following:
 - a. Physically insert the replaced module (refer to the *Installation Manual*) into the same slot in which the previous module resided.
 - b. In the Home page, click the title of the module ("**<module type> Reserved**") that you want to replace; the **Insert Module** button appears:

Figure 36-3: Insert Module Button



- c. Click the **Insert Module** button; a message appears informing you that this may take a few seconds. When the message disappears, the module is inserted, which is indicated by the disappearance of the word 'Reserved' from the module's name.

37 Resetting Channels

37.1 Resetting an Analog Channel

You can inactivate (*reset*) an FXO or FXS analog channel. This is sometimes useful, for example, when the device (FXO) is connected to a PBX and the communication between the two can't be disconnected (e.g., when using reverse polarity). This is done in the Web interface's Home page.

➤ **To reset an analog channel:**

1. Open the Home page.
2. Click the required **FXS** or **FXO** port icon; a shortcut menu appears.
3. From the shortcut menu, choose **Reset Channel**; the channel is changed to inactive and the port icon is displayed in gray.

37.2 Restarting a B-Channel

You can restart a specific B-channel belonging to an ISDN or CAS trunk, using the SNMP MIB variable, `acTrunkISDNCommonRestartBChannel` or the EMS management tool (refer to the EMS User's Manual). This may be useful, for example, for troubleshooting specific voice channels.



Notes:

- If a voice call is currently in progress on the B-channel, it is disconnected when the B-channel is restarted.
- B-channel restart can only be done if the D-channel of the trunk to which it belongs is synchronized (Layer 2).
- B-channel restart does not affect the B-channel's configuration.

Reader's Notes

38 Software Upgrade

The **Software Update** menu allows you to do the following:

- Load Auxiliary files (see 'Loading Auxiliary Files' on page 499)
- Load a Software License Key (see 'Loading Software License Key' on page 522)
- Upgrade the device using Software Upgrade Wizard (see 'Software Upgrade Wizard' on page 522)
- Load/save Configuration file (see 'Backing Up and Loading Configuration File' on page 526)

38.1 Loading Auxiliary Files

Various Auxiliary files can be installed on the device. These Auxiliary files provide the device with additional configuration settings. The table below lists the different types of Auxiliary files:

Auxiliary Files

File	Description
INI	Configures the device. The Web interface enables practically full device provisioning. However, some features may only be configured by ini file or you may wish to configure your device using the ini file. For more information on using the ini file to configure the device, see 'INI File-Based Management' on page 93.
CAS	CAS auxiliary files containing the CAS Protocol definitions for CAS-terminated trunks (for various types of CAS signaling). You can use the supplied files or construct your own files. Up to eight different CAS files can be installed on the device. For more information, see CAS Files on page 507.
Voice Prompts	Voice announcement file containing a set of Voice Prompts (VP) that are played by the device during operation. For more information, see Voice Prompts File on page 507. Note: This file is applicable only to Mediant 1000.
Call Progress Tones	Region-specific, telephone exchange-dependent file that contains the Call Progress Tones (CPT) levels and frequencies for the device. The default CPT file is U.S.A. For more information, see 'Call Progress Tones File' on page 502.
Prerecorded Tones	The Prerecorded Tones (PRT) file enhances the device's capabilities of playing a wide range of telephone exchange tones that cannot be defined in the CPT file. For more information, see Prerecorded Tones File on page 506.
Dial Plan	Provides dialing plans, for example, to know when to stop collecting dialed digits and start forwarding them or for obtaining the destination IP address for outbound IP routing. For more information, see 'Dial Plan File' on page 508.
VXML	Voice Extensible Markup Language (VXML) script file.

File	Description
User Info	The User Information file maps PBX extensions to IP numbers. This file can be used to represent PBX extensions as IP phones in the global 'IP world'. For more information, see 'User Information File' on page 514.
AMD Sensitivity	Answer Machine Detector (AMD) Sensitivity file containing the AMD Sensitivity suites. For more information, see AMD Sensitivity File on page 516.

The Auxiliary files can be loaded to the device using one of the following methods:

- Web interface.
- TFTP: This is done by specifying the name of the Auxiliary file in an *ini* file (see Auxiliary and Configuration Files Parameters) and then loading the *ini* file to the device. The Auxiliary files listed in the *ini* file are then automatically loaded through TFTP during device startup. If the *ini* file does not contain a specific auxiliary file type, the device uses the last auxiliary file of that type that was stored on its non-volatile memory.




Notes:

- You can schedule automatic loading of updated auxiliary files using HTTP/HTTPS, FTP, or NFS. For more information on automatic updates, see 'Automatic Update' on page 527.
-
- When loading an *ini* file using this Web page, parameters that are excluded from the loaded *ini* file retain their current settings (*incremental*).
- Saving an auxiliary file to flash memory may disrupt traffic on the device. To avoid this, disable all traffic on the device by performing a graceful lock as described in 'Locking and Unlocking the Device' on page 493.
- For deleting auxiliary files, see 'Viewing Device Information' on page 541.

The procedure below describes how to load Auxiliary files using the Web interface.

➤ **To load auxiliary files to the device using the Web interface:**

1. Open the Load Auxiliary Files page (**Maintenance** tab > **Software Update** menu > **Load Auxiliary Files**).



The screenshot displays a web interface for loading auxiliary files. It features several rows, each with a file type label, an empty text input field, a 'Browse...' button, and a 'Load File' button. The file types listed are: INI file (incremental), CAS file, Voice Prompts file, Call Progress Tones file (marked with a lightning bolt icon), Prerecorded Tones file, Dial Plan file, User Info file, and AMD Sensitivity file.



Note: The appearance of certain file load fields depends on the installed Software License Key.

2. Click the **Browse** button corresponding to the file type that you want to load, navigate to the folder in which the file is located, and then click **Open**; the name and path of the file appear in the field next to the **Browse** button.
3. Click the **Load File** button corresponding to the file you want to load.
4. Repeat steps 2 through 3 for each file you want to load.

5. Save the loaded auxiliary files to flash memory, see 'Saving Configuration' on page 494 and reset the device (if you have loaded a Call Progress Tones file), see 'Resetting the Device' on page 491.

You can also load auxiliary files using an ini file that is loaded to the device with BootP. Each auxiliary file has a specific ini file parameter that specifies the name of the auxiliary file that you want to load to the device with the ini file. For a description of these ini file parameters, see Auxiliary and Configuration Files Parameters.

➤ **To load auxiliary files using an ini file:**

1. In the ini file, define the auxiliary files to be loaded to the device. You can also define in the ini file whether the loaded files must be stored in the non-volatile memory so that the TFTP process is not required every time the device boots up.
2. Save the auxiliary files and the ini file in the same directory on your local PC.
3. Invoke a BootP/TFTP session; the ini and associated auxiliary files are loaded to the device.

38.1.1 Call Progress Tones File

The Call Progress Tones (CPT) and Distinctive Ringing (applicable to analog interfaces) auxiliary file is comprised of two sections:

- The first section contains the definitions of the Call Progress Tones (levels and frequencies) that are detected/generated by the device.
- The second section contains the characteristics of the Distinctive Ringing signals that are generated by the device (see Distinctive Ringing on page 504).

You can use one of the supplied auxiliary files (.dat file format) or create your own file. To create your own file, it's recommended to modify the supplied *usa_tone.ini* file (in any standard text editor) to suit your specific requirements and then convert the modified *ini* file into binary format, using AudioCodes DConvert utility. For a description on converting a CPT *ini* file into a binary *dat* file, refer to the *DConvert Utility User's Guide*.



Note: Only the *dat* file format can be loaded to the device.

You can create up to 32 different Call Progress Tones, each with frequency and format attributes. The frequency attribute can be single or dual-frequency (in the range of 300 to 1980 Hz) or an Amplitude Modulated (AM). Up to 64 different frequencies are supported. Only eight AM tones, in the range of 1 to 128 kHz, can be configured (the detection range is limited to 1 to 50 kHz). Note that when a tone is composed of a single frequency, the second frequency field must be set to zero.

The format attribute can be one of the following:

- **Continuous:** A steady non-interrupted sound (e.g., a dial tone). Only the 'First Signal On time' should be specified. All other on and off periods must be set to zero. In this case, the parameter specifies the detection period. For example, if it equals 300, the tone is detected after 3 seconds (300 x 10 msec). The minimum detection time is 100 msec.
- **Cadence:** A repeating sequence of on and off sounds. Up to four different sets of on/off periods can be specified.
- **Burst:** A single sound followed by silence. Only the 'First Signal On time' and 'First Signal Off time' should be specified. All other on and off periods must be set to zero. The burst tone is detected after the off time is completed.

You can specify several tones of the same type. These additional tones are used only for tone detection. Generation of a specific tone conforms to the first definition of the specific

tone. For example, you can define an additional dial tone by appending the second dial tone's definition lines to the first tone definition in the *ini* file. The device reports dial tone detection if either of the two tones is detected.

The Call Progress Tones section of the *ini* file comprises the following segments:

- **[NUMBER OF CALL PROGRESS TONES]:** Contains the following key: 'Number of Call Progress Tones' defining the number of Call Progress Tones that are defined in the file.
- **[CALL PROGRESS TONE #X]:** containing the Xth tone definition, starting from 0 and not exceeding the number of Call Progress Tones less 1 defined in the first section (e.g., if 10 tones, then it is 0 to 9), using the following keys:
 - **Tone Type:** Call Progress Tone types:
 - ◆ **[1]** Dial Tone
 - ◆ **[2]** Ringback Tone
 - ◆ **[3]** Busy Tone
 - ◆ **[4]** Congestion Tone
 - ◆ **[6]** Warning Tone
 - ◆ **[7]** Reorder Tone
 - ◆ **[8]** Confirmation Tone
 - ◆ **[9]** Call Waiting Tone - heard by the called party
 - ◆ **[15]** Stutter Dial Tone
 - ◆ **[16]** Off Hook Warning Tone
 - ◆ **[17]** Call Waiting Ringback Tone - heard by the calling party
 - ◆ **[18]** Comfort Tone
 - ◆ **[23]** Hold Tone
 - ◆ **[46]** Beep Tone
 - **Tone Modulation Type:** Amplitude Modulated (1) or regular (0)
 - **Tone Form:** The tone's format can be one of the following:
 - ◆ Continuous (1)
 - ◆ Cadence (2)
 - ◆ Burst (3)
 - **Low Freq [Hz]:** Frequency (in Hz) of the lower tone component in case of dual frequency tone, or the frequency of the tone in case of single tone. This is not relevant to AM tones.
 - **High Freq [Hz]:** Frequency (in Hz) of the higher tone component in case of dual frequency tone, or zero (0) in case of single tone (not relevant to AM tones).
 - **Low Freq Level [-dBm]:** Generation level 0 dBm to -31 dBm in dBm (not relevant to AM tones).
 - **High Freq Level:** Generation level of 0 to -31 dBm. The value should be set to 32 in the case of a single tone (not relevant to AM tones).
 - **First Signal On Time [10 msec]:** 'Signal On' period (in 10 msec units) for the first cadence on-off cycle. For continuous tones, this parameter defines the detection period. For burst tones, it defines the tone's duration.
 - **First Signal Off Time [10 msec]:** 'Signal Off' period (in 10 msec units) for the first cadence on-off cycle (for cadence tones). For burst tones, this parameter defines the off time required after the burst tone ends and the tone detection is reported. For continuous tones, this parameter is ignored.
 - **Second Signal On Time [10 msec]:** 'Signal On' period (in 10 msec units) for the second cadence on-off cycle. Can be omitted if there isn't a second cadence.
 - **Second Signal Off Time [10 msec]:** 'Signal Off' period (in 10 msec units) for the second cadence on-off cycle. Can be omitted if there isn't a second cadence.

- **Third Signal On Time [10 msec]:** 'Signal On' period (in 10 msec units) for the third cadence on-off cycle. Can be omitted if there isn't a third cadence.
- **Third Signal Off Time [10 msec]:** 'Signal Off' period (in 10 msec units) for the third cadence on-off cycle. Can be omitted if there isn't a third cadence.
- **Fourth Signal On Time [10 msec]:** 'Signal On' period (in 10 msec units) for the fourth cadence on-off cycle. Can be omitted if there isn't a fourth cadence.
- **Fourth Signal Off Time [10 msec]:** 'Signal Off' period (in 10 msec units) for the fourth cadence on-off cycle. Can be omitted if there isn't a fourth cadence.
- **Carrier Freq [Hz]:** Frequency of the carrier signal for AM tones.
- **Modulation Freq [Hz]:** Frequency of the modulated signal for AM tones (valid range from 1 to 128 Hz).
- **Signal Level [-dBm]:** Level of the tone for AM tones.
- **AM Factor [steps of 0.02]:** Amplitude modulation factor (valid range from 1 to 50). Recommended values from 10 to 25.


Notes:

- When the same frequency is used for a continuous tone and a cadence tone, the 'Signal On Time' parameter of the continuous tone must have a value that is greater than the 'Signal On Time' parameter of the cadence tone. Otherwise, the continuous tone is detected instead of the cadence tone.
- The tones frequency must differ by at least 40 Hz between defined tones.

For example, to configure the dial tone to 440 Hz only, enter the following text:

```
[NUMBER OF CALL PROGRESS TONES]
Number of Call Progress Tones=1
#Dial Tone
[CALL PROGRESS TONE #0]
Tone Type=1
Tone Form =1 (continuous)
Low Freq [Hz]=440
High Freq [Hz]=0
Low Freq Level [-dBm]=10 (-10 dBm)
High Freq Level [-dBm]=32 (use 32 only if a single tone is
required)
First Signal On Time [10msec]=300; the dial tone is detected after
3 sec
First Signal Off Time [10msec]=0
Second Signal On Time [10msec]=0
Second Signal Off Time [10msec]=0
```

38.1.1.1 Distinctive Ringing

Distinctive Ringing is applicable only to FXS interfaces. Using the Distinctive Ringing section of the Call Progress Tones auxiliary file, you can create up to 16 Distinctive Ringing patterns. Each ringing pattern configures the ringing tone frequency and up to four ringing cadences. The same ringing frequency is used for all the ringing pattern cadences. The ringing frequency can be configured in the range of 10 to 200 Hz with a 5 Hz resolution.

Each of the ringing pattern cadences is specified by the following parameters:

- **Burst Ring On Time:** Configures the cadence to be a burst cadence in the entire ringing pattern. The burst relates to On time and the Off time of the same cadence. It must appear between 'First/Second/Third/Fourth' string and the 'Ring On/Off Time'

This cadence rings once during the ringing pattern. Otherwise, the cadence is interpreted as cyclic: it repeats for every ringing cycle.

- **Ring On Time:** Specifies the duration of the ringing signal.
- **Ring Off Time:** Specifies the silence period of the cadence.

The Distinctive Ringing section of the *ini* file format contains the following strings:

- **[NUMBER OF DISTINCTIVE RINGING PATTERNS]:** Contains the following key:
 - 'Number of Distinctive Ringing Patterns' defining the number of Distinctive Ringing signals that are defined in the file.
- **[Ringing Pattern #X]:** Contains the Xth ringing pattern definition (starting from 0 and not exceeding the number of Distinctive Ringing patterns defined in the first section minus 1) using the following keys:
 - **Ring Type:** Must be equal to the Ringing Pattern number.
 - **Freq [Hz]:** Frequency in hertz of the ringing tone.
 - **First (Burst) Ring On Time [10 msec]:** 'Ring On' period (in 10 msec units) for the first cadence on-off cycle.
 - **First (Burst) Ring Off Time [10 msec]:** 'Ring Off' period (in 10 msec units) for the first cadence on-off cycle.
 - **Second (Burst) Ring On Time [10 msec]:** 'Ring On' period (in 10 msec units) for the second cadence on-off cycle.
 - **Second (Burst) Ring Off Time [10 msec]:** 'Ring Off' period (in 10 msec units) for the second cadence on-off cycle.
 - **Third (Burst) Ring On Time [10 msec]:** 'Ring On' period (in 10 msec units) for the third cadence on-off cycle.
 - **Third (Burst) Ring Off Time [10 msec]:** 'Ring Off' period (in 10 msec units) for the third cadence on-off cycle.
 - **Fourth (Burst) Ring On Time [10 msec]:** 'Ring Off' period (in 10 msec units) for the fourth cadence on-off cycle.
 - **Fourth (Burst) Ring Off Time [10 msec]:** 'Ring Off' period (in 10 msec units) for the fourth cadence on-off cycle.



Note: In SIP, the Distinctive Ringing pattern is selected according to the Alert-Info header in the INVITE message. For example:
Alert-Info:<Bellcore-dr2>, or Alert-Info:<http://.../Bellcore-dr2>
'dr2' defines ringing pattern #2. If the Alert-Info header is missing, the default ringing tone (0) is played.

An example of a **ringing burst** definition is shown below:

```
#Three ringing bursts followed by repeated ringing of 1 sec on and
3 sec off.
[NUMBER OF DISTINCTIVE RINGING PATTERNS]
Number of Ringing Patterns=1
[Ringing Pattern #0]
Ring Type=0
Freq [Hz]=25
First Burst Ring On Time [10msec]=30
First Burst Ring Off Time [10msec]=30
Second Burst Ring On Time [10msec]=30
Second Burst Ring Off Time [10msec]=30
Third Burst Ring On Time [10msec]=30
Third Burst Ring Off Time [10msec]=30
```

```
Fourth Ring On Time [10msec]=100
Fourth Ring Off Time [10msec]=300
```

An example of **various ringing signals** definition is shown below:

```
[NUMBER OF DISTINCTIVE RINGING PATTERNS]
Number of Ringing Patterns=3
#Regular North American Ringing Pattern
[Ringing Pattern #0]
Ring Type=0
Freq [Hz]=20
First Ring On Time [10msec]=200
First Ring Off Time [10msec]=400
#GR-506-CORE Ringing Pattern 1
[Ringing Pattern #1]
Ring Type=1
Freq [Hz]=20
First Ring On Time [10msec]=200
First Ring Off Time [10msec]=400
#GR-506-CORE Ringing Pattern 2
[Ringing Pattern #2]
Ring Type=2
Freq [Hz]=20
First Ring On Time [10msec]=80
First Ring Off Time [10msec]=40
Second Ring On Time [10msec]=80
Second Ring Off Time [10msec]=400
```

38.1.2 Prerecorded Tones File

The CPT file mechanism has several limitations such as a limited number of predefined tones and a limited number of frequency integrations in one tone. To overcome these limitations and provide tone generation capability that is more flexible, the Prerecorded Tones (PRT) file can be used. If a specific prerecorded tone exists in the PRT file, it takes precedence over the same tone that exists in the CPT file and is played instead of it.



Note: The PRT are used only for generation of tones. Detection of tones is performed according to the CPT file.

The PRT is a *.dat* file containing a set of prerecorded tones that can be played by the device. Up to 40 tones (totaling approximately 10 minutes) can be stored in a single PRT file on the device's flash memory. The prerecorded tones are prepared offline using standard recording utilities (such as CoolEdit™) and combined into a single file, using AudioCodes DConvert utility (refer to *DConvert Utility User's Guide* for more information).

The raw data files must be recorded with the following characteristics:

- **Coders:** G.711 A-law or G.711 μ -law
- **Rate:** 8 kHz
- **Resolution:** 8-bit
- **Channels:** mono

Once created, the PRT file can then be loaded to the device using AudioCodes' AcBootP utility or the Web interface (see 'Loading Auxiliary Files' on page 499).

The prerecorded tones are played repeatedly. This allows you to record only part of the tone and then play the tone for the full duration. For example, if a tone has a cadence of 2 seconds on and 4 seconds off, the recorded file should contain only these 6 seconds. The

PRT module repeatedly plays this cadence for the configured duration. Similarly, a continuous tone can be played by repeating only part of it.

38.1.3 Voice Prompts File

The Voice Prompts (VP) file contains a set of voice prompts (or announcements) that can be played by the device during operation. The voice announcements are prepared offline using standard recording utilities and then combined into a single file using the DConvert utility. The VP file can then be loaded to the device using the Web interface.

The VP file is a collection of raw voice recordings and/or *wav* files. These recordings can be prepared using standard utilities such as CoolEdit and Goldwave™.

The raw data files must be recorded with the following characteristics:

- **Coders:** Linear G.711 A-law or G.711 μ -law
- **Rate:** 8000 kHz
- **Resolution:** 8-bit
- **Channels:** mono

When the list of recorded files is converted to a single *voiceprompts.dat* file, every Voice Prompt is tagged with an ID number, starting with '1'. This ID is later used by the device to play the correct announcement. Up to 1,000 Voice Prompts can be defined. If the size of the combined VP file is less than 1 MB, it can be permanently stored on flash memory. Larger files (up to 10 MB) are stored in RAM, and should be loaded again (using the AcBootP utility) after the device is reset.

The device can be provided with a professionally recorded English (U.S.) VP file.



Note: Voice Prompts are applicable only to Mediant 1000.

- **To generate and load the VP file:**
 1. Prepare one or more voice files using standard utilities.
 2. Use the DConvert utility to generate the *voiceprompts.dat* file from the pre-recorded voice messages. For more information, refer to *DConvert Utility User's Guide*.
 3. Load the *voiceprompts.dat* file to the device using TFTP (see 'Automatic Update' on page 527) or the Web interface (see 'Loading Auxiliary Files' on page 499).

38.1.4 CAS Files

The CAS auxiliary files contain the CAS Protocol definitions that are used for CAS-terminated trunks. You can use the supplied files or construct your own files. Up to eight files can be loaded to the device. Different files can be assigned to different trunks (CAS_{TableIndex_x}) and different CAS tables can be assigned to different B-channels (CAS_{ChannelIndex}).

The CAS files can be loaded to the device using the Web interface or *ini* file (see 'Loading Auxiliary Files' on page 499).



Note: All CAS files loaded together must belong to the same Trunk Type (i.e., either E1 or T1).

38.1.5 Dial Plan File

The Dial Plan file can be used for various digit mapping features, as described in this section.

38.1.5.1 Creating a Dial Plan File

Creating a Dial Plan file is similar between all Dial Plan features. The main difference is the syntax used in the Dial Plan file and the method for selecting the Dial Plan index to use for the specific feature.

The Dial Plan file is a text-based file that can contain up to eight Dial Plans (Dial Plan indices) and up to 8,000 rules (lines). The general syntax rules for the Dial Plan file are as follows (syntax specific to the feature is described in the respective section):

- Each Dial Plan index must begin with a Dial Plan name enclosed in square brackets "[...]" on a new line.
- Each line under the Dial Plan index defines a rule.
- Empty lines are ignored.
- Lines beginning with a semicolon ";" are ignored. The semicolon can be used for comments.

➤ To create a Dial Plan file:

1. Create a new file using a text-based editor (such as Notepad) and configure your Dial Plans, as required.
2. Save the file with the *ini* file extension name (e.g., mydialplanfile.ini).
3. Convert the *ini* file to a *dat* binary file, using AudioCodes DConvert utility. For more information, refer to *DConvert Utility User's Guide*.
4. Install the converted file on the device, as described in 'Loading Auxiliary Files' on page 499.
5. Select the Dial Plan index that you want to use. This depends on the feature and is described in the respective section.

38.1.5.2 Dialing Plans for Digit Collection

The device enables you to configure multiple dialing plans in an external Dial Plan file, which can be installed on the device. If a Dial Plan file is implemented, the device first attempts to locate a matching digit pattern in a specified Dial Plan index listed in the file and if not found, attempts to locate a matching digit pattern in the Digit Map. The Digit Map is configured by the 'Digit Mapping Rules' parameter, located in the DTMF & Dialing page (**Configuration** tab > **VoIP** menu > **GW and IP to IP** > **DTMF and Supplementary** > **DTMF & Dialing**).

The Dial Plan is used for the following:

- ISDN Overlap Dialing, FXS, and FXO collecting digit mode (Tel-to-IP calls): The file allows the device to know when digit collection ends, after which it starts sending all the collected (or dialed) digits in the outgoing INVITE message. This also provides enhanced digit mapping.
- CAS E1 MF-CR2 (Tel-to-IP calls): Useful for E1 MF-CR2 variants that do not support I-15 terminating digits (e.g., in Brazil and Mexico). The Dial Plan file allows the device to detect end-of-dialing in such cases. The CasTrunkDialPlanName_x ini file parameter determines which dial plan (in the Dial Plan file) to use for a specific trunk.

**Notes:**

- To use the Dial Plan file, you must also use a special CAS .dat file that supports this feature. For more information, contact your AudioCodes sales representative.
- For E1 CAS MFC-R2 variants, which don't support terminating digit for the called party number, usually 1-15, the Dial Plan file and the DigitMapping parameter are ignored. Instead, you can define a Dial Plan template per trunk using the parameter CasTrunkDialPlanName_x.

The Dial Plan file can contain up to eight Dial Plans (Dial Plan indices), with a total of up to 8,000 dialing rules (lines) of distinct prefixes (e.g. area codes, international telephone number patterns) for the PSTN to which the device is connected.

The Dial Plan file is created in a textual *ini* file with the following syntax:

```
<called number prefix>,<total digits to wait before sending>
```

- Each new Dial Plan index begins with a Dial Plan name enclosed in square brackets "[...]" on a new line.
- Each line under the Dial Plan index defines a dialing prefix and the number of digits expected to follow that prefix. The prefix is separated by a comma "," from the number of additional digits.
- The prefix can include numerical ranges in the format [x-y], as well as multiple numerical ranges [n-m][x-y] (no comma between them).
- The prefix can include the asterisk "*" and number "#" signs.
- The number of additional digits can include a numerical range in the format x-y.
- Empty lines are ignored.
- Lines beginning with a semicolon ";" are ignored. The semicolon can be used for comments.

Below shows an example of a Dial Plan file (in *ini*-file format), containing two dial plans:

```
; Example of dial-plan configuration.
; This file contains two dial plans:
[ PLAN1 ]
; Destination cellular area codes 052, 054, and 050 with 8 digits.
052,8
054,8
050,8
; Defines International prefixes 00, 012, 014.
; The number following these prefixes may
; be 7 to 14 digits in length.
00,7-14
012,7-14
014,7-14
; Defines emergency number 911. No additional digits are expected.
911,0
[ PLAN2 ]
; Defines area codes 02, 03, 04.
; In these area codes, phone numbers have 7 digits.
0[2-4],7
; Operator services starting with a star: *41, *42, *43.
; No additional digits are expected.
*4[1-3],0
```

The procedure below provides a summary on how to create a Dial Plan file and select the required Dial Plan index.

➤ **To create a Dial Plan file:**

1. Create a new file using a text-based editor (such as Notepad) and configure your Dial Plans, as required.
2. Save the file with the *ini* file extension name (e.g., mydialplans.ini).
3. Convert the *ini* file to a *dat* binary file, using AudioCodes DConvert utility. For more information, refer to *DConvert Utility User's Guide*.
4. Install the converted file on the device, as described in 'Loading Auxiliary Files' on page 499.
5. The required Dial Plan is selected using the 'Dial Plan Index' parameter. This parameter can be set to **0** through **7**, where **0** denotes PLAN1, **1** denotes PLAN2, and so on.

Notes:

- The Dial Plan file must not contain overlapping prefixes. Attempting to process an overlapping configuration by the DConvert utility results in an error message specifying the problematic line.
- The Dial Plan index can be selected globally for all calls (as described in the previous procedure), or per specific calls using Tel Profiles.
- It may be useful to configure both Dial Plan file and Digit Maps. For example, the Digit Map can be used for complex digit patterns (which are not supported by the Dial Plan) and the Dial Plan can be used for long lists of relatively simple digit patterns. In addition, as timeout between digits is not supported by the Dial Plan, the Digit Map can be used to configure digit patterns that are shorter than those defined in the Dial Plan or left at default (MaxDigits parameter). For example, the "xx.T" digit map instructs the device to use the Dial Plan and if no matching digit pattern is found, it waits for two more digits and then after a timeout (TimeBetweenDigits parameter), it sends the collected digits. Therefore, this ensures that calls are not rejected as a result of their digit pattern not been completed in the Dial Plan.
- By default, if no matching digit pattern is found in both the Dial Plan and Digit Map, the device rejects the call. However, if you set the DisableStrictDialPlan parameter to 1, the device attempts to complete the call using the MaxDigits and TimeBetweenDigits parameters. In such a setup, it collects the number of digits configured by the MaxDigits parameters. If more digits are received, it ignores the settings of this parameter and collects the digits until the inter-digit timeout configured by the TimeBetweenDigits parameter is exceeded.



38.1.5.3 Dial Plan Prefix Tags for IP-to-Tel Routing

The device supports the use of string labels (or "tags") in the external Dial Plan file for tagging incoming IP-to-Tel calls. The special "tag" is added as a prefix to the called party number, and then the Inbound IP Routing Table uses this "tag" instead of the original prefix. Manipulation is then performed after routing in the Manipulation table, which strips the "tag" characters before sending the call to the endpoint.

This feature resolves the limitation of entries in the Inbound IP Routing Table (IP-to-Tel call routing) for scenarios in which many different routing rules are required. For example, a city may have many different area codes, some for local calls and others for long distance calls (e.g. 425-202-xxxx for local calls, but 425-200-xxxx for long distance calls).

For using tags, the Dial Plan file is defined as follows:

- Number of dial plan (text)
- Dial string prefix (ranges can be defined in brackets)

- User-defined routing tag (text)



Note: Dial Plan Prefix Tags are not applicable to FXS and FXO interfaces.

The example configuration below assumes a scenario where multiple prefixes exist for local and long distance calls:

➤ **To use Dial Plan file routing tags:**

1. Load an *ini* file to the device that selects Dial Plan index (e.g., 1) for routing tags, as shown below:

```
IP2TelTaggingDestDialPlanIndex = 0
```

2. Define the external Dial Plan file with two routing tags (as shown below):

- "LOCL" - for local calls
- "LONG" - for long distance calls

```
[ PLAN1 ]
42520[3-5],0,LOCL
425207,0,LOCL
42529,0,LOCL
425200,0,LONG
425100,0,LONG
```

For example, if an incoming IP call to destination prefix 425203 is received, the device adds the prefix tag "LOCL" as specified in the Dial Plan file, resulting in the number "LOCL425203".

3. Assign the different tag prefixes to different Trunk Groups in the Inbound IP Routing Table (**Configuration** tab > **VoIP** menu > **GW and IP to IP** > **Routing** > **IP to Trunk Group Routing**):

- The Dest. Phone Prefix' field is set to the value "LOCL" and this rule is assigned to a local Trunk Group (e.g. Trunk Group ID 1).
- The Dest. Phone Prefix' field is set to the value "LONG" and this rule is assigned to a long distance Trunk Group (e.g. Trunk Group ID 2).

Figure 38-1: Configuring Dial Plan File Label for IP-to-Tel Routing

Routing Index: 1-12 IP To Tel Routing Mode: Route calls before manipulation						
	Dest. Host Prefix	Source Host Prefix	Dest. Phone Prefix	Source Phone Prefix	Source IP Address	Hunt Group ID
1			LOCL			1
2			LONG			2

The above routing rules are configured to be performed before manipulation (described in the step below).

4. Configure manipulation in the Destination Phone Number Manipulation Table for IP to Tel Calls table (**Configuration** tab > **VoIP** menu > **GW and IP to IP** submenu > **Manipulations** submenu > **Dest Number IP->Tel**) for removing the first four characters of the called party number "tag" (in our example, "LOCL" and "LONG"):

- The Destination Prefix' field is set to the value "LOCL" and the 'Stripped Digits From Left' field is set to '4'.

- The 'Destination Prefix' field is set to the value "LONG" and the 'Stripped Digits From Left' field is set to '4'.

Figure 38-2: Configuring Manipulation for Removing Label

Index	Destination Prefix	Source Prefix	Source IP Address	Stripped Digits From Left
1	LOCL	*	*	4
2	LONG	*	*	4

38.1.5.4 Obtaining IP Destination from Dial Plan File

You can use a Dial Plan index listed in a loaded Dial Plan file for determining the IP destination of Tel-to-IP /IP-to-IP calls. This enables the mapping of called numbers to IP addresses (in dotted-decimal notation) or FQDNs (up to 15 characters).

➤ **To configure routing to an IP destination based on Dial Plan:**

1. Create the Dial Plan file. The syntax of the Dial Plan index for this feature is as follows:

```
<destination / called prefix number>,0,<IP destination>
```

Note that the second parameter "0" is not used and ignored.

An example of a configured Dial Plan (# 6) in the Dial Plan file is shown below:

```
[ PLAN6 ]
200,0,10.33.8.52 ; called prefix 200 is routed to
10.33.8.52
201,0,10.33.8.52
300,0,itsp.com ; called prefix 300 is routed to itsp.com
```

2. Convert the file to a loadable file and then load it to the device.
 3. Assign the Dial Plan index to the required routing rule:
 - Tel-to-IP or IP-to-IP Calls: In the Outbound IP Routing table, do the following:
 - ◆ In the 'Destination Address' field, enter the required Dial Plan index using the following syntax:
DialPlan<index>
- Where "DialPlan0" denotes [PLAN1] in the Dial Plan file, "DialPlan1" denotes [PLAN2], and so on.



Note: The "DialPlan" string is case-sensitive.

38.1.5.5 Modifying ISDN-to-IP Calling Party Number

The device can use the Dial Plan file to change the Calling Party Number value (source number) of the incoming ISDN call when sending to IP. For this feature, the Dial Plan file supports the following syntax:

<ISDN Calling Party Number>,0,<new calling number>

- The first number contains the calling party number (or its prefix) received in the ISDN call SETUP message. The source number can also be a range, using the syntax [x-y] in the Dial Plan file. This number is used as the display name in the From header of the outgoing INVITE.

- The second number must always be set to "0".
- The third number is a string of up to 12 characters containing the mapped number that is used as the URI user part in the From and Contact headers of the outgoing INVITE.

The Dial Plan index used in the Dial Plan file for this feature is defined by the `Tel2IPSourceNumberMappingDialPlanIndex` parameter.

An example of such a configuration in the Dial Plan file is shown below:

```
[ PLAN1 ]
; specific received number changed to 04343434181.
0567811181,0,04343434181
; number range that changes to 04343434181.
056788118[2-4],0,04343434181
```

If we take the first Dial Plan rule in the example above (i.e., "0567811181,0,04343434181"), the received Calling Number Party of 0567811181 is changed to 04343434181 and sent to the IP with a SIP INVITE as follows:

```
Via: SIP/2.0/UDP 211.192.160.214:5060;branch=z9hG4bK3157667347
From: <sip:04343434181@kt.co.kr:5060>;tag=de0004b1
To: sip:01066557573@kt.co.kr:5060
Call-ID: 585e60ec@211.192.160.214
CSeq: 1 INVITE
Contact:<sip:04343434181@211.192.160.214:5060;transport=udp>
```

The initial Dial Plan text file must be converted to *.dat file format using the DConvert utility. This is done by clicking the DConvert's **Process Dial Plan File** button. For more information, refer to *DConvert Utility User's Guide*.

You can load this *.dat file to the device using the Web interface (see 'Loading Auxiliary Files' on page 499), AcBootP utility, or using the Auto-update mechanism from an external HTTP server.



Notes:

- Tel-to-IP routing is performed on the original source number if the parameter 'Tel to IP Routing Mode' is set to 'Route calls before manipulation'.
- Tel-to-IP routing is performed on the modified source number as defined in the Dial Plan file, if the parameter 'Tel To IP Routing Mode' is set to 'Route calls after manipulation'.
- Source number Tel-to-IP manipulation is performed on the modified source number as defined in the Dial Plan file.

38.1.6 User Information File

This section describes the various uses of the User Info file.

You can load the User Info file using any of the following methods:

- Web interface (see 'Loading Auxiliary Files' on page 499)
- *ini* file - using the `UserInfoFileName` parameter, e.g., `UserInfoFileName = 'UserInformationFile.txt'` (see 'Auxiliary and Configuration File Name Parameters' on page 834)
- Automatic update mechanism - using the `UserInfoFileURL` parameter, e.g., `UserInfoFileUrl = 'http://192.168.0.250/Audiocodes/ UserInformationFile.txt'` (see 'Automatic Update Mechanism' on page 527)

38.1.6.1 User Information File for PBX Extensions and "Global" Numbers

The User Info file contains a User Info table that can be used for the following Gateway-related:

- **Mapping (Manipulating) PBX Extension Numbers with Global Phone Numbers:** maps PBX extension number, connected to the device, with any "global" phone number (alphanumerical) for the IP side. In this context, the "global" phone number serves as a routing identifier for calls in the "IP world" and the PBX extension uses this mapping to emulate the behavior of an IP phone. This feature is especially useful in scenarios where unique or non-consecutive number translation per PBX is needed. This number manipulation feature supports the following call directions:
 - IP-to-Tel Calls: Maps the called "global" number (in the Request-URI user part) to the PBX extension number. For example, if the device receives an IP call destined for "global" number 638002, it changes this called number to the PBX extension number 402, and then sends the call to the PBX extension on the Tel side.



Note: If you have configured regular IP-to-Tel manipulation rules (see 'Configuring Source/Destination Number Manipulation' on page 299), the device applies these rules before applying the mapping rules of the User Info table.

- Tel-to-IP Calls: Maps the calling (source) PBX extension to the "global" number. For example, if the device receives a Tel call from PBX extension 402, it changes this calling number to 638002, and then sends call to the IP side with this calling number. In addition to the "global" phone number, the display name (caller ID) configured for the PBX user in the User Info table is used in the SIP From header.



Note: If you have configured regular Tel-to-IP manipulation rules (see 'Configuring Source/Destination Number Manipulation' on page 299), the device applies these rules before applying the mapping rules of the User Info table.

- IP-to-IP Calls: Maps SIP From (calling number) and To (called number) of IP PBX extension numbers with "global" numbers. For example, if the device receives a call from IP PBX extension number 402 (calling / SIP From) that is destined to IP PBX extension number 403 (called / SIP To), the device changes both these numbers into their "global" numbers 638002 and 638003, respectively.
- **Registering Users:** The device can register each PBX user configured in the User Info table. For each user, the device sends a SIP REGISTER to an external IP-based Registrar server, using the "global" number in the From/To headers. If authentication is

necessary for registration, the device sends the user's username and password, configured in the User Info table, in the SIP MD5 Authorization header.



Notes:

- To enable the User Info table, see 'Enabling the User Info Table' on page 516.
- To modify the Use Info table, you need to load a new User Info table containing your modifications.
- To enable user registration, set the following parameters on the Proxy & Registration page (**Configuration** tab > **VoIP** menu > **SIP Definitions** > **Proxy & Registration**) as shown:
 - ✓ 'Enable Registration' parameter set to **Enable** (IsRegisterNeeded is set to 1).
 - ✓ 'Registration Mode' parameter set to **Per Endpoint** (AuthenticationMode is set to 0).
- For FXS ports, when the device needs to send a new SIP request with the Authorization header (e.g., after receiving a SIP 401 response), it uses the username and password configured in the Authentication table (see 'Configuring Authentication per Port' on page 393). To use the username and password configured in the User Info file, set the 'Password' parameter to any value other than its default value.

The User Info file is a text-based file that you can create using any text-based program such as Notepad. To add mapping rules to this file, use the following syntax:

```
[ GW ]
FORMAT
PBXExtensionNum,GlobalPhoneNum,DisplayName,UserName,Password
```

Where:

- *PBXExtensionNum* is the PBX extension number (up to 10 characters)
- *GlobalPhoneNum* is the "global" phone number (up to 20 characters) for the IP side
- *DisplayName* is the Caller ID (string of up to 30 characters) of the PBX extension
- *UserName* is the username (string of up to 40 characters) for registering the user when authentication is necessary
- *Password* is the password (string of up to 20 characters) for registering the user when authentication is necessary

Each line in the file represents a mapping rule of a single PBX extension user.

You can add up to 1,000 mapping rules. The maximum size of the User Info file is 10,800 bytes for analog interfaces and 108,000 bytes for digital interfaces.



Note: Make sure that the last line in the User Info file ends with a carriage return (i.e., by pressing the <Enter> key).

An example of a configured User Info file is shown below:

```
[ GW ]
FORMAT
PBXExtensionNum,GlobalPhoneNum,DisplayName,UserName,Password
401 , 638001 , Mike , miked , 1234
402 , 638002 , Lee , leep , 4321
403 , 638003 , Sue , suer , 8790
404 , 638004 , John , johnd , 7694
```

```

405 , 638005 , Pam , pame, 3928
406 , 638006 , Steve , steveg, 1119
407 , 638007 , Fred , frede, 8142
408 , 638008 , Maggie , maggiea , 9807
    
```

38.1.6.2 Enabling the User Info Table

The procedure below describes how to load a User Info file to the device and enable the use of the User Info table:

➤ **To enable the User Info table:**

1. Open the Advanced Parameters page (**Configuration** tab > **VoIP** menu > **SIP Definitions** > **Advanced Parameters**).
2. Set the 'Enable User-Information Usage' parameter to **Enable**.

38.1.7 AMD Sensitivity File

The AMD Sensitivity file allows you to configure the device with different AMD Sensitivity suites. You can load the device with up to four AMD Sensitivity suites. Each suite can be configured to a different language, country or region, thereby fine tuning the detection algorithm of the DSP according to requirements.

The structure of the file can be viewed in the example below. Each file consists of at least one parameter suite with its suite ID. Each parameter suite consists of up to 16 sensitivity levels, where each level possessing 3 coefficients A, B and C. When loading a new parameter suite, the existing parameter suite with the same ID is overwritten.

The file is created in .xml format and installed on the device as a binary file (with a .dat extension). The XML to binary file format is processed by AudioCodes DConvert utility. For more information, refer to *DConvert Utility User's Guide*.

The file can be installed on the device in the following ways:

- TFTP at initialization time, by setting the *ini* file parameter `AMDSensitivityFileName` with the .dat file name, and adding the file to the TFTP directory.
- Auxiliary files Web page (see 'Loading Auxiliary Files' on page 499).
- Using the AutoUpdate mechanism (see 'Automatic Update' on page 527). In this case the `AMDSensitivityFileUrl` parameter must be set using SNMP or *ini* file.

The following example shows an xml file with two parameter suites:

- Parameter Suite 0 with six sensitivity levels
- Parameter Suite 2 with three sensitivity levels

```

<AMDSENSITIVITY>
<PARAMETERSUIT>
  <PARAMETERSUITID>0</PARAMETERSUITID>
  <!-- First language/country -->
  <NUMBEROFLEVELS>8</NUMBEROFLEVELS>
    <AMDSENSITIVITYLEVEL>
      <!-- Level 0 -->
      <AMDCOEFFICIENTA>15729</AMDCOEFFICIENTA>
      <AMDCOEFFICIENTB>58163</AMDCOEFFICIENTB>
      <AMDCOEFFICIENTC>32742</AMDCOEFFICIENTC>
    </AMDSENSITIVITYLEVEL>
    <AMDSENSITIVITYLEVEL>
      <!-- Level 1 -->
      <AMDCOEFFICIENTA>19923</AMDCOEFFICIENTA>
      <AMDCOEFFICIENTB>50790</AMDCOEFFICIENTB>
    
```

```

        <AMDCOEFFICIENTC>30720</AMDCOEFFICIENTC>
    </AMDSENSITIVITYLEVEL>
<AMDSENSITIVITYLEVEL>
<!-- Level 2 -->
        <AMDCOEFFICIENTA>10486</AMDCOEFFICIENTA>
        <AMDCOEFFICIENTB>57344</AMDCOEFFICIENTB>
        <AMDCOEFFICIENTC>25600</AMDCOEFFICIENTC>
    </AMDSENSITIVITYLEVEL>
<AMDSENSITIVITYLEVEL>
<!-- Level 3 -->
        <AMDCOEFFICIENTA>8389</AMDCOEFFICIENTA>
        <AMDCOEFFICIENTB>62259</AMDCOEFFICIENTB>
        <AMDCOEFFICIENTC>23040</AMDCOEFFICIENTC>
    </AMDSENSITIVITYLEVEL>
<AMDSENSITIVITYLEVEL>
<!-- Level 4 -->
        <AMDCOEFFICIENTA>10486</AMDCOEFFICIENTA>
        <AMDCOEFFICIENTB>50790</AMDCOEFFICIENTB>
        <AMDCOEFFICIENTC>28160</AMDCOEFFICIENTC>
    </AMDSENSITIVITYLEVEL>
<AMDSENSITIVITYLEVEL>
<!-- Level 5 -->
        <AMDCOEFFICIENTA>6291</AMDCOEFFICIENTA>
        <AMDCOEFFICIENTB>58982</AMDCOEFFICIENTB>
        <AMDCOEFFICIENTC>23040</AMDCOEFFICIENTC>
    </AMDSENSITIVITYLEVEL>
<AMDSENSITIVITYLEVEL>
<!-- Level 6 -->
        <AMDCOEFFICIENTA>7864</AMDCOEFFICIENTA>
        <AMDCOEFFICIENTB>58982</AMDCOEFFICIENTB>
        <AMDCOEFFICIENTC>12800</AMDCOEFFICIENTC>
    </AMDSENSITIVITYLEVEL>
<AMDSENSITIVITYLEVEL>
<!-- Level 7 -->
        <AMDCOEFFICIENTA>7340</AMDCOEFFICIENTA>
        <AMDCOEFFICIENTB>64717</AMDCOEFFICIENTB>
        <AMDCOEFFICIENTC>3840</AMDCOEFFICIENTC>
    </AMDSENSITIVITYLEVEL>
</PARAMETERSUIT>
<PARAMETERSUIT>
    <PARAMETERSUITID>2</PARAMETERSUITID>
    <!-- Second language/country -->
    <NUMBEROFLEVELS>3</NUMBEROFLEVELS>
    <AMDSENSITIVITYLEVEL>
    <!-- Level 0 -->
        <AMDCOEFFICIENTA>15729</AMDCOEFFICIENTA>
        <AMDCOEFFICIENTB>58163</AMDCOEFFICIENTB>
        <AMDCOEFFICIENTC>32742</AMDCOEFFICIENTC>
    </AMDSENSITIVITYLEVEL>
    <AMDSENSITIVITYLEVEL>
    <!-- Level 1 -->
        <AMDCOEFFICIENTA>5243</AMDCOEFFICIENTA>
        <AMDCOEFFICIENTB>9830</AMDCOEFFICIENTB>
        <AMDCOEFFICIENTC>24320</AMDCOEFFICIENTC>
    </AMDSENSITIVITYLEVEL>
    <AMDSENSITIVITYLEVEL>
    <!-- Level 2 -->
        <AMDCOEFFICIENTA>13107</AMDCOEFFICIENTA>

```

```
<AMDCOEFFICIENTB>61440</AMDCOEFFICIENTB>  
<AMDCOEFFICIENTC>26880</AMDCOEFFICIENTC>  
</AMDSENSITIVITYLEVEL>  
</PARAMETERSUIT>  
</AMDSENSITIVITY>
```

39 Software License Key

The device is shipped with a pre-installed Software License Key, which determines the device's supported features, capabilities, and available resources. You can upgrade or change your device's supported features by purchasing and installing a new Software License Key to match your requirements.



Note: The availability of certain Web pages depends on the installed Software License Key.

39.1 Obtaining the Software License Key File

Before you can install a new Software License Key, you need to obtain a Software License Key file for your device with the required features from your AudioCodes representative. The Software License Key is an encrypted key in string format that is associated with the device's serial number ("S/N") and supplied in a text-based file.

If you need a Software License Key for more than one device, the Software License Key file can include multiple Software License Keys (see figure below). In such cases, each Software License Key in the file is associated with a unique serial number identifying the specific device. When loading such a Software License Key file, the device installs only the Software License Key that is associated with its serial number.

Figure 3: Software License Key File with Multiple S/N Lines

```
sample.ini - Notepad
[LicenseKeys]
.Board Type 29
SN241182 =
okRTr5topwYMBIzd4NN2a3Qhm4Njfi daagUyehso94APbBF85hF4by0cmQZf2B8bMcze7JQ9kMSa5h641R1aOkeEb9AddF894Zx
SN242519 = tmxTr5to0mlMblZdoPd2a3Qh9zJlfi dafilyehsogOQPbBF8pj4by0c9pdx2B8eOoze7JQgywSa5h6o391aOkeTlIAAddF8c6Fx
SN226403 = tmxTr5to0lsMblZdoOB2a3Qh9yJlfi dafilyehsogN4PbBF8piZ4by0c9pdx2B8eOoze7JQgywSa5h6o2x1aOkeTlIAAddF8c6Fx
SN226417 = r6xTr5to25sMblZdfB2a3Qh5OJlfi da92yehsox4PbBF8eOZ4by0c52df2B88yoze7JQlNgSa5h6fyx1aOkeXZlIAAddF8amFx
.Board Type 24
SN241182 =
okRTr5topwYMBIzd4NN2a3wkm4Njfi daagUyehso94APbBF85hF4by0cmQZf2B8bMcze7JQ9kMSa5h641R1aOkeEb9AddF8938s
SN242519 = tmxTr5to0mlMblZdoPd2a3wk9zJlfi dafilyehsogOQPbBF8pj4by0c9pdx2B8eOoze7JQgywSa5h6o391aOkeTlIAAddF8c1ss
SN226403 = tmxTr5to0lsMblZdoOB2a3wk9yJlfi dafilyehsogN4PbBF8piZ4by0c9pdx2B8eOoze7JQgywSa5h6o2x1aOkeTlIAAddF8c1ss
SN226417 = r6xTr5to25sMblZdfB2a3wk5OJlfi da92yehsox4PbBF8eOZ4by0c52df2B88yoze7JQlNgSa5h6fyx1aOkeXZlIAAddF8ahss
```

- **To obtain a Software License Key:**
 1. Make a note MAC address and/or serial number of the device, which uniquely identifies the device:
 - a. Open the Device Information page (**Status & Diagnostics** tab > **System Status** menu > **Device Information**).
 - b. The MAC address is displayed in the "MAC Address" field and the serial number in the "Serial Number" field.
 2. If you need a Software License Key for more than one device, repeat Step 1 for each device.
 3. Request the required Software License Key from your AudioCodes representative and provide them with the MAC address and/or serial number of the device(s).
 4. When you receive the new Software License Key file, check the file as follows:
 - a. Open the file with any text-based program such as Notepad.
 - b. Verify that the first line displays "[LicenseKeys]".
 - c. Verify that the file contains one or more lines in the following format:

"S/N<serial number> = <long Software License Key string>".
 For example: "S/N370604 = jCx6r5tovCIKaBBbhPtT53Yj..."

- d. Verify that the "S/N" value reflects the serial number of your device. If you have multiple Software License Keys, ensure that each "S/N" value corresponds to a device.



Warning: Do not modify the contents of the Software License Key file.

5. Install the Software License Key on the device as described in 'Installing the Software License Key' on page 520.

39.2 Installing the Software License Key

Once you have received your Software License Key file from your AudioCodes representative, you can install it on the device using one of the following management tools:

- Web interface - see 'Installing Software License Key using Web Interface' on page 520
- AudioCodes AcBootP utility - see Installing Software License Key using AcBootP on page 522
- AudioCodes EMS - refer to the EMS User's Manual or EMS Product Description



Note: When you install a new Software License Key, it is loaded to the device's non-volatile flash memory and overwrites the previously installed Software License Key.

39.2.1 Installing Software License Key using Web Interface

The procedure below describes how to install the Software License Key using the Web interface.

- **To install the Software License Key using the Web interface:**
 1. Open the Software Upgrade Key Status page (**Maintenance** tab > **Software Update** menu > **Software Upgrade Key**).

2. As a precaution, backup the Software License Key currently installed on the device. If the new Software License Key does not comply with your requirements, you can re-load this backup to restore the device's original capabilities.
 - a. In the 'Current Key' field, select the entire text string and copy it to any standard text file (e.g., Notepad).
 - b. Save the text file with any file name and file extension (e.g., key.txt) to a folder on your computer.
3. Depending on whether you are loading a Software License Key file with a single Software License Key (i.e., one "S/N") or with multiple Software License Keys (i.e., more than one "S/N"), do one of the following:
 - **Loading a File with a Single Software License Key:**
 - a. Open the Software License Key file using a text-based program such as Notepad.
 - b. Copy-and-paste the string from the file to the 'Add a Software Upgrade Key' field.
 - c. Click the **Add Key** button.
 - **Loading a File with Multiple Software License Keys:**
 - a. In the 'Load Upgrade Key file ...' field, click the **Browse** button and navigate to the folder in which the Software License Key file is located on your computer.
 - b. Click **Load File**; the new key is installed on the device.

If the Software License Key is valid, it is burned to the device's flash memory and displayed in the 'Current Key' field.
4. Verify that the Software License Key was successfully installed, by doing one of the following:
 - In the Software Upgrade Key Status page, check that the listed features and capabilities activated by the installed Software License Key match those that were ordered.
 - Access the Syslog server and ensure that the following message appears in the Syslog server:
"S/N___ Key Was Updated. The Board Needs to be Reloaded with ini file\n"
5. Reset the device; the new capabilities and resources enabled by the Software License Key are active.



Note: If the Syslog server indicates that the Software License Key was unsuccessfully loaded (i.e., the "SN_" line is blank), do the following preliminary troubleshooting procedures:

1. Open the Software License Key file and check that the "S/N" line appears. If it does not appear, contact AudioCodes.
2. Verify that you have loaded the correct file. Open the file and ensure that the first line displays "[LicenseKeys]".
3. Verify that the content of the file has not been altered.

39.2.2 Loading via BootP/TFTP

The procedure below describes how to install a Software License Key using AudioCodes AcBootP utility.



Notes:

- When loading the Software License Key file, a *cmp* file must also be loaded during this BootP process.
- For more information on using the AcBootP utility, refer to the document *AcBootP Utility User's Guide*.

➤ **To install a Software License Key using the AcBootP utility:**

1. Change the file extension name of the Software License Key file from *.txt* to *.ini*.
2. Place the Software License Key file in the same folder in which the device's *cmp* file is located.
3. Start the AcBootP utility.
4. Click the **Client Configuration** tab, and then from the 'INI File' drop-down list, select the Software License Key file.
5. From the 'BootP File' drop-down list, select the device's *cmp* file.
6. Configure the initial BootP/TFTP parameters as required, and then click **Apply**.
7. Reset the device; the *cmp* and Software License Key files are loaded to the device.

39.3 Software Upgrade Wizard

The Software Upgrade Wizard allows you to upgrade the device's firmware. The firmware file has the *.cmp* file extension name. The wizard also enables you to load an *ini* file and/or auxiliary files (typically loaded using the Load Auxiliary File page described in 'Loading Auxiliary Files' on page 499). However, it is mandatory when using the wizard to first load a *.cmp* file to the device. You can then choose to also load an *ini* file and/or auxiliary files, but this cannot be done without first loading a *.cmp* file. For the *ini* and each auxiliary file type, you can choose to load a new file or not load a file but use the existing file (i.e., maintain existing configuration) running on the device.




Warning: The Software Upgrade Wizard requires the device to be reset at the end of the process, which may disrupt traffic. To avoid this, disable all traffic on the device before initiating the wizard by performing a graceful lock (see 'Basic Maintenance' on page 491).

**Notes:**

- You can get the latest software files from AudioCodes Web site at <http://www.audiocodes.com/downloads>.
- Before upgrading the device, it is recommended that you save a copy of the device's configuration settings (i.e., *ini* file) to your computer. If an upgrade failure occurs, you can then restore your configuration settings by uploading the backup file to the device. For saving and restoring configuration, see 'Backing Up and Loading Configuration File' on page 526.
- If you wish to also load an *ini* or auxiliary file, it is mandatory to first load a *.cmp* file.
- When you activate the wizard, the rest of the Web interface is unavailable. After the files are successfully loaded, access to the full Web interface is restored.
- If you upgraded your *.cmp* and the "SW version mismatch" message appears in the Syslog or Web interface, then your Software License Key does not support the new *.cmp* file version. If this occurs, contact AudioCodes support for assistance.
- If you use the wizard to load an *ini* file, parameters excluded from the *ini* file are assigned default values (according to the *.cmp* file running on the device) thereby, overriding values previously defined for these parameters.
- You can schedule automatic loading of these files using HTTP/HTTPS, FTP, or NFS (see 'Automatic Update' on page 527).

➤ To load files using the Software Upgrade Wizard:

1. Stop all traffic on the device using the Graceful Lock feature (refer to the warning bulletin above).
2. Open the Software Upgrade wizard, by performing one of the following:
 - Select the **Maintenance** tab, click the **Software Update** menu, and then click **Software Upgrade Wizard**.
 - On the toolbar, click **Device Actions**, and then choose **Software Upgrade Wizard**.

Figure 39-4: Start Software Upgrade Wizard Screen

- Click the **Start Software Upgrade** button; the wizard starts, requesting you to browse to a .cmp file for uploading.



Note: At this stage, you can quit the Software Update Wizard, by clicking **Cancel** , without requiring a device reset. However, once you start uploading a cmp file, the process must be completed with a device reset. If you choose to quit the process in any of the subsequent pages, the device resets.

- Click the **Browse** button, navigate to the .cmp file, and then click **Load File**; a progress bar appears displaying the status of the loading process. When the .cmp file is successfully loaded to the device, a message appears notifying you of this.
- If you want to load **only** a .cmp file, then click the **Reset**  button to reset the device with the newly loaded .cmp file, utilizing the existing configuration (*ini*) and auxiliary files. To load additional files, skip to the next Step.



Note: Device reset may take a few minutes depending on cmp file version (this may even take up to 10 minutes).


- Click the **Next**  button; the wizard page for loading an *ini* file appears. You can now perform one of the following:
 - Load a new *ini* file: Click **Browse**, navigate to the *ini* file, and then click **Send File**; the *ini* file is loaded to the device and you're notified as to a successful loading.
 - Retain the existing configuration (*ini* file): Do not select an *ini* file, and ensure that the 'Use existing configuration' check box is selected (default).
 - Return the device's configuration settings to factory defaults: Do not select an *ini* file, and clear the 'Use existing configuration' check box.
- Click the **Next**  button to progress to the relevant wizard pages for loading the desired auxiliary files. To return to the previous wizard page, click the **Back**  button. As you navigate between wizard pages, the relevant file type corresponding to the Wizard page is highlighted in the left pane.
- When you have completed loading all the desired files, click the **Next**  button until the last wizard page appears ("FINISH" is highlighted in the left pane).
- Click the **Reset**  button to complete the upgrade process; the device 'burns' the newly loaded files to flash memory and then resets the device.



Note: Device reset may take a few minutes (depending on .cmp file version, this may even take up to 30 minutes).

After the device resets, the End of Process wizard page appears displaying the new .cmp and auxiliary files loaded to the device.

Figure 39-5: Software Upgrade Process Completed Successfully



10. Click **End Process** to close the wizard; the Web Login dialog box appears.
11. Enter your login user name and password, and then click **OK**; a message box appears informing you of the new .cmp file.
12. Click **OK**; the Web interface becomes active, reflecting the upgraded device.

39.4 Backing Up and Loading Configuration File

You can save a copy/backup of the device's current configuration settings as an *ini* file to a folder on your computer, using the Configuration File page. The saved *ini* file includes only parameters that were modified and parameters with other than default values. The Configuration File page also allows you to load an *ini* file to the device. If the device has "lost" its configuration, you can restore the device's configuration by loading the previously saved *ini* file or by simply loading a newly created *ini* file.



Note: When loading an *ini* file using this Web page, parameters not included in the *ini* file are reset to default settings.

➤ To save the *ini* file:

1. Open the Configuration File page by doing one of the following:
 - From the Navigation tree, click the **Maintenance** tab, click the **Software Update** menu, and then click **Configuration File**.
 - On the toolbar, click **Device Actions**, and then from the drop-down menu, choose **Load Configuration File** or **Save Configuration File**.



2. To save the *ini* file to a folder on your computer, do the following:
 - a. Click the **Save INI File** button; the File Download dialog box appears.
 - b. Click the **Save** button, navigate to the folder where you want to save the *ini* file, and then click **Save**.
3. To load the *ini* file to the device, do the following:
 - a. Click the **Browse** button, navigate to the folder where the *ini* file is located, select the file, and then click **Open**; the name and path of the file appear in the field beside the **Browse** button.
 - b. Click the **Load INI File** button, and then at the prompt, click **OK**; the device uploads the *ini* file and then resets (from the *cmp* version stored on the flash memory). Once complete, the Web Login screen appears, requesting you to enter your user name and password.

40 Automatic Update

Automatic provisioning is useful for large-scale deployment of devices. In some cases, the devices are shipped to the end customer directly from the manufacturer. In other cases, they may pass through a staging warehouse. Configuration may occur at the staging warehouse or at the end-customer premises.

The devices may be pre-configured during the manufacturing process (commonly known as *private labeling*). Typically, a two-stage configuration process is implemented such that initial configuration includes only basic configuration, while the final configuration is done when the device is deployed in a live network.

Automatic provisioning can be used to update the following files:

- Software file (*cmp*)
- Auxiliary files (e.g., Call Progress Tones)
- Configuration file (*ini*)

The Automatic Update mechanism is applied per file, using specific parameters that define the URLs to the servers where the files are located, and the file names (see Automatic Update Parameters on page 836). These files can be stored on any standard Web, FTP, or NFS server and can be loaded periodically to the device using HTTP, HTTPS, FTP, or NFS. This mechanism can be used even for devices that are installed behind NAT and firewalls.

The Automatic Update mechanism can be triggered by the following:

- Upon device startup.
- At a user-defined time of day (e.g., 18:00), configured by the *ini* file parameter `AutoUpdatePredefinedTime`.
- Periodically (e.g., every 60 minutes), configured by the *ini* file parameter `AutoUpdateFrequency`.
- Upon startup but before the device is operational, if the Secure Startup feature is enabled (see 'Loading Files Securely (Disabling TFTP)' on page 534).
- Upon receipt of a special SIP Notify message (see 'Remotely Triggering Auto Update using SIP NOTIFY' on page 535)

When implementing Automatic Updates using HTTP/S, the device determines whether the file on the provisioning server is an updated one as follows:

- **Configuration file:** The device checks the timestamp according to the HTTP server response. Cyclical Redundancy Check (CRC) is only checked if the `AUPDCheckIfIniChanged` parameter is enabled. The device downloads the configuration file only if it was modified since the last successful configuration update.
- **Software file (*cmp*):** The device first downloads the file and then checks if its version number is different from the software version file currently stored on the device's flash memory.
- **Auxiliary files (e.g., CPT):** These files are updated only once. To update the auxiliary file again, you must modify the settings of the related parameter that configures its URL.


40.1 BootP Request and DHCP Discovery upon Device Initialization

After the device powers up or is physically reset, it broadcasts a BootP request to the network. If it receives a reply from a BootP server, it changes its network parameters (IP address, subnet mask and default gateway address) to the values provided. If there is no reply from a BootP server and if DHCP is enabled (`DHCPEnable = 1`), the device initiates a standard DHCP procedure to configure its network parameters.

After changing the network parameters, the device attempts to load the device's firmware file (cmp) and various configuration files from the TFTP server's IP address received from the BootP/DHCP server. If a TFTP server's IP address isn't received, the device attempts to load the cmp file and / or configuration files from a preconfigured TFTP server. Thus, the device can obtain its network parameters from BootP or DHCP servers, and its software and configuration files from a different TFTP server (preconfigured in the ini configuration file).

If BootP/DHCP servers are not found or when the device is reset using the Web interface or SNMP, it retains its network parameters and attempts to load the cmp file and / or configuration files from a preconfigured TFTP server. If a preconfigured TFTP server doesn't exist, the device operates using the existing software and configuration files on its flash memory.

Figure 40-1: BootP Request and DHCP Discovery upon Startup



Note: By default, the duration between BootP/DHCP requests sent by the device is one second (configured by the BootPDelay ini file parameter). By default, the number of requests is three (configured by the BootPRetries ini file parameter).

40.2 Obtaining IP Address Automatically using DHCP

You can configure the device to obtain an IP address from a DHCP server during bootup.

➤ **To enable DHCP for obtaining an IP address:**

1. Open the Application Settings page (**Configuration** tab > **System** menu > **Application Settings**).

Figure 40-2: Enabling DHCP - Application Settings Page



The screenshot shows a web interface for 'DHCP Settings'. There is a label 'Enable DHCP' followed by a dropdown menu currently showing 'Enable'. To the right of the dropdown is a blue circular icon with a pencil, representing a 'Submit' or 'Save' button.

2. From the 'Enable DHCP' drop-down list, select **Enable**.
3. Click **Submit**.



Note: When using DHCP to acquire an IP address, the Multiple Interface table, VLANs and other advanced configuration options are disabled.

40.3 Configuring Automatic Update

The procedure below describes how to configure the Automatic Update feature. It describes a scenario where the devices download a "master" configuration file with common settings from an HTTP server. This "master" file applies common configuration and instructs each device to download a specific configuration file based on the device's MAC address from an HTTP server.



Warning: Do not use the Web interface to configure the device when the Automatic Update feature is implemented. If you do and save (burn) the new settings to the device's flash memory, the IniFileURL parameter is automatically set to 0 and Automatic Updates is consequently disabled. To enable Automatic Updates again, you would need to re-load the ini file (using the Web interface or BootP) with the correct IniFileURL settings. As a safeguard to an unintended burn-to-flash when resetting the device, if the device is configured for Automatic Updates, the 'Burn To FLASH' field under the Reset Configuration group in the Web interface's Maintenance Actions page is automatically set to **No** by default.



Note: For a description of all the Automatic Update *ini* file parameters, see Automatic Update Parameters on page 836.

➤ **To configure the Automatic Update feature (ini file example):**

1. Setup a Web server (e.g., <http://www.corp.com>) and place all the required configuration files on this server.
2. For each device, preconfigure the following parameter (DHCP / DNS are assumed):

```
IniFileURL = 'http://www.corp.com/master_configuration.ini'
```

3. Create a file named *master_configuration.ini* with the following text:

```
# Common configuration for all devices
# -----
CptFileURL = 'http://www.corp.com/call_progress.dat'
# Check for updates every 60 minutes
AutoUpdateFrequency = 60
# Additional configuration per device
# -----
# Each device loads a file named based on its MAC address
# (e.g., config_00908F033512.ini)
IniFileURL = 'http://www.corp.com/config_<MAC>.ini'
# Reset the device after configuration is updated.
# The device resets after all files are processed.
ResetNow = 1
```

You can modify the *master_configuration.ini* file (or any of the *config_<MAC>.ini* files) at any time. The device queries for the latest version every 60 minutes and applies the new settings immediately.

4. For additional security, use HTTPS or FTPS. The device supports HTTPS (RFC 2818) and FTPS using the AUTH TLS method <draft-murray-auth-ftp-ssl-16>.
5. The configuration URL can also be provided using the analog-based Voice Configuration Menu.
6. To download configuration files from an NFS server, the NFS file system parameters should be defined in the *ini* file. The following is an example of an *ini* file for downloading files from NFS servers using NFS version 2:

```
# Define NFS servers for Automatic Update
[ NFSServers ]
FORMAT NFSServers_Index = NFSServers_HostOrIP,
NFSServers_RootPath, NFSServers_NfsVersion;
NFSServers 1 = 10.31.2.10, /usr/share, 2 ;
NFSServers 2 = 192.168.100.7, /d/shared, 2 ;
[ \NFSServers ]
CptFileUrl =
'file://10.31.2.10/usr/share/public/usa_tones.dat'
VpFileUrl =
'file://192.168.100.7/d/shared/gateways/voiceprompt.dat'
```

The following *ini* file example can be used to activate the Automatic Update mechanism.

```
# DNS is required for specifying domain names in URLs
[ InterfaceTable ]
FORMAT InterfaceTable_Index = InterfaceTable_ApplicationTypes,
InterfaceTable_InterfaceMode, InterfaceTable_IPAddress,
InterfaceTable_PrefixLength, InterfaceTable_Gateway,
InterfaceTable_VlanID, InterfaceTable_InterfaceName,
InterfaceTable_PrimaryDNSServerIPAddress ,
InterfaceTable_SecondaryDNSServerIPAddress,
InterfaceTable_UnderlyingInterface;
InterfaceTable 0 = 6, 10, 10.13.4.12, 16, 10.13.0.1, 1, Mng,
10.1.1.11, 0.0.0.0, ;
[ \InterfaceTable ]
# Load an extra configuration ini file using HTTP
IniFileURL = 'http://webserver.corp.com/Gateway/inifile.ini'
# Load Call Progress Tones file using HTTPS
CptFileUrl = 'https://10.31.2.17/usa_tones.dat'
# Load Voice Prompts file using FTPS with user 'root' and password
'wheel'
VPFileUrl = 'ftps://root:wheel@ftpsserver.corp.com/vp.dat'
```

```
# Update every day at 03:00 AM
AutoUpdatePredefinedTime = '03:00'
# Note: The cmp file isn't updated since it's disabled by default
(AutoUpdateCmpFile).
```

**Notes:**

- The Automatic Update mechanism assumes that the external Web server conforms to the HTTP standard. If the Web server ignores the If-Modified-Since header, or doesn't provide the current date and time during the HTTP 200 OK response, the device may reset itself repeatedly. To overcome this problem, modify the update frequency, using the AutoUpdateFrequency parameter.
- To load a different configuration file (ini file) per device, add the string "<MAC>" to the URL (e.g., IniFileURL = 'http://www.corp.com/config_<MAC>.ini'). This mnemonic is replaced with the device's hardware MAC address, resulting in an ini file name request that contains the device's MAC address (e.g., config_00908F033512.ini).
- To prevent the device from accidentally upgrading its software, by default the Automatic Update feature does not apply a downloaded *cmp* file even if its URL was configured (using the CmpFileURL parameter). To enable this, set the AutoUpdateCmpFile parameter to 1.
- To enable the device to automatically reset after an ini file has been loaded, set the ResetNow parameter to 1. This is important if the downloaded configuration file includes parameters that require a device reset for its settings to be applied.
- By default, parameters that are not included in the downloaded configuration file are set to default. To retain the current settings of these parameters, set the SetDefaultOnINIFileProcess parameter to 0.

40.4 Automatic Configuration Methods

This section describes available methods that can be used for automatic device configuration.

40.4.1 Local Configuration Server with BootP/TFTP

Local configuration server with BootP/TFTP provides an easy and efficient method for automatic configuration, where configuration occurs at a staging warehouse, as described below:

1. Install AudioCodes AcBootP/TFTP utility program on a computer located in a staging warehouse.
2. Prepare a standard configuration *ini* file and place it in the TFTP directory.
3. Enter the MAC address of each device in the AcBootP utility.
4. For each device added in the BootP utility, select the *cmp* and *ini* file in the 'BootP File' field.
5. Connect each device to the network and then power up the device.
6. The BootP reply contains the *cmp* and *ini* file names entered in the 'BootP File' field. Each device retrieves these files using BootP and stores them in its flash memory. If auxiliary files are required (e.g., call progress tones), they may also be specified in the *ini* file and downloaded from the same TFTP server.

7. When the devices' LEDs turn green indicating that the files were successfully loaded, disconnect the devices and ship to the customer.


Notes:

- Typically, IP addressing at the customer site is done by DHCP.
- For more information on the AcBootP utility, refer to the *AcBootP Utility User's Guide*.

40.4.2 DHCP-based Configuration Server

This method is similar to the setup described in 'Local Configuration Server with BootP/TFTP' on page 531, except that DHCP is used instead of BootP. The DHCP server can be configured to automatically provide each device with a temporary IP address so that individual MAC addresses are not required. Configuration occurs at a staging warehouse for this method.

Below is an example configuration file for Linux DHCP server (dhcpd.conf). The devices are allocated temporary IP addresses in the range 10.31.4.53 to 10.31.4.75. TFTP is assumed to be on the same computer as the DHCP server (alternatively, the "next-server" directive may be used).

```
ddns-update-style ad-hoc;
default-lease-time 60;
max-lease-time 60;
class "gateways" {
    match if(substring(hardware, 1, 3) = 00:90:8f);
}
subnet 10.31.0.0 netmask 255.255.0.0 {
    pool {
        allow members of "audiocodes";
        range 10.31.4.53 10.31.4.75;
        filename "SIP_F6.60A.217.003.cmp -fb;device.ini";
        option routers                10.31.0.1;
        option subnet-mask             255.255.0.0;
    }
}
```

40.4.3 Configuration using DHCP Option 67

This method is suitable for deployments where DHCP server configuration is possible at the customer site. Most DHCP servers support the configuration of individual DHCP option values for different devices on the network. The DHCP configuration should be modified so that the device receives a URL to the configuration file in Option 67, along with IP addressing and DNS server information. The DHCP response is processed by the device upon startup and the device automatically downloads the configuration file from the HTTP server specified in the DHCP response. This method does not require additional servers at the customer premises and is NAT-safe.

Below is an example of a Linux DHCP configuration file (dhcpd.conf) showing the required format of Option 67:

```
ddns-update-style ad-hoc;
default-lease-time 3600;
max-lease-time 3600;
class "audiocodes" {
    match if(substring(hardware, 1, 3) = 00:90:8f);
}
subnet 10.31.0.0 netmask 255.255.0.0 {
```

```
pool {
    allow members of "audiocodes";
    range 10.31.4.53 10.31.4.75;
    option routers                10.31.0.1;
    option subnet-mask            255.255.0.0;
    option domain-name-servers    10.1.0.11;
    option bootfile-name
"INI=http://www.corp.com/master.ini";
    option dhcp-parameter-request-list 1,3,6,51,67;
}
```

40.4.4 TFTP Configuration using DHCP Option 66

This method is suitable when the customer's network contains a provisioning TFTP server for all network equipment, without being able to distinguish between AudioCodes and non-AudioCodes devices.

Upon startup, the device searches for Option 66 in the DHCP response from the DHCP server. If Option 66 contains a valid IP address, the device attempts to download through TFTP a file with a name that contains the device's MAC address (e.g., 00908f0130aa.ini). This method requires a provisioning server at the customer premises.

This method loads the configuration file to the device as a one-time action. The download is only repeated if the device is manually restored to factory defaults (by pressing the hardware reset button while the Ethernet cable is not connected) and DHCP is enabled (see note below).



Notes:

- For TFTP configuration using DHCP Option 66, enable DHCP on your device: `DHCPEnable = 1` and `DHCPRequestTFTPParams = 1`.
- Access to the core network using TFTP is not NAT-safe.

40.4.5 HTTP-based Automatic Updates

An HTTP/S server can be placed in the customer's network where configuration and software updates are available for download. This does not require additional servers at the customer premises and is NAT-safe.

For example, assume the core network HTTPS server is `https://www.corp.com`. A master configuration *ini* file should be placed on the server, e.g., `https://www.corp.com/gateways/master.ini`. This file could point to additional *ini* files, auxiliary files (e.g., call progress tones), and software files (cmp), all on the same HTTP server or different HTTP servers in the network.

The main advantage of this method is that the HTTP configuration can be checked periodically when the device is deployed at the customer site. HTTP(S) is not sensitive to NAT devices, enabling configuration whenever needed without on-site intervention.

For additional security, the URL may contain a different port, and username and password.

The devices should only be pre-configured with the URL of the initial *ini* file, using one of the following methods:

- Methods described in 'DHCP-based Configuration Server' on page 532 or above, via TFTP at a staging warehouse. The configuration URL is configured using the `IniFileURL` parameter.
- Private labeling.
- Using DHCP Option 67 (see 'Configuration using DHCP Option 67' on page 532).

- Manually on-site, using the RS-232 port or Web interface.

When the device is deployed at the customer site, local DHCP server provides the devices with IP addressing and DNS server information. From the URL provided in the DHCP response, the device can then contact the HTTP server at the core network and automatically download its configuration. The URL can be a simple file name or contain the device's MAC or IP address, e.g.:

- `http://corp.com/config-<MAC>.ini` - which becomes, for example, `http://corp.com/config-00908f030012.ini`
- `http://corp.com/<IP>/config.ini` - which becomes, for example, `http://corp.com/192.168.0.7/config.ini`

40.4.6 Configuration using FTP or NFS

Some networks block access to HTTP(S). The Automatic Update feature provides limited support for FTP/FTPS connectivity. Periodic polling for updates is not possible since these protocols don't support conditional fetching, i.e., updating files only if it is changed on the server.

The only difference between this method and those described in 'HTTP-based Automatic Updates' on page 533 and 'Configuration using DHCP Option 67' on page 532 is that the protocol in the URL is "ftp" (instead of "http").



Notes:

- Unlike FTP, NFS is not NAT-safe.
- NFS v2/v3 is also supported.

40.4.7 Configuration using AudioCodes EMS

AudioCodes EMS server functions as a core-network provisioning server. The device's SNMP Manager should be configured with the IP address of the EMS server, using one of the methods detailed in the previous sections. As soon as a registered device contacts the EMS server through SNMP, the EMS server handles all required configuration automatically, upgrading software as needed. This alternative method doesn't require additional servers at the customer premises, and is NAT-safe.

40.5 Loading Files Securely (Disabling TFTP)

The TFTP protocol is not considered secure and some network operators block it using a firewall. It is possible to disable TFTP completely, using the *ini* file parameter `EnableSecureStartup` (set to 1). This way, secure protocols such as HTTPS may be used to fetch the device configuration.

➤ To download the ini file to the device using HTTPS instead of TFTP:

1. Prepare the device's configuration file on an HTTPS server and obtain a URL to the file (e.g., `https://192.168.100.53/gateways.ini`).
2. Enable DHCP, if necessary.
3. Enable SSH and connect to it.
4. In the CLI, use the *ini* file parameters `IniFileURL` (for defining the URL of the configuration file) and `EnableSecureStartup` (for disabling TFTP), and then restart the device with the new configuration:

```
/conf/scp IniFileURL https://192.168.100.53/gateways.ini
/conf/scp EnableSecureStartup 1
/conf/sar bootp
```



Note: Once Secure Startup has been enabled, it can only be disabled by setting EnableSecureStartup to 0 using the CLI. Loading a new *ini* file using BootP/TFTP is not possible until EnableSecureStartup is disabled.

40.6 Remotely Triggering Auto Update using SIP NOTIFY

The device can be remotely triggered to start the Automatic Update process upon receipt of a SIP NOTIFY that includes an Event header set to 'check-sync;reboot=false', as shown in the example below:

```
NOTIFY sip:<user>@<dsthost> SIP/2.0
To: sip:<user>@<dsthost>
From: sip:sipsak@<srchost>
CSeq: 10 NOTIFY
Call-ID: 1234@<srchost>
Event: check-sync;reboot=false
```

For this feature to function, Automatic Update must be enabled on the device. In other words, it must have a loaded ini file with the Automatic Update settings.

➤ **To enable remote trigger of Auto Update upon receipt of SIP NOTIFY:**

1. Open the Advanced Parameters page (**Configuration** tab > **VoIP** menu > **SIP Definitions** > **Advanced Parameters**).
2. Under the **Misc Parameters** group, set the 'SIP Remote Reset' parameter to **Enable**.
3. Click **Submit**.



Note: This SIP Event header value is proprietary to AudioCodes.

Reader's Notes

41 Restoring Factory Defaults

You can restore the device's configuration to factory defaults using one of the following methods:

- CLI (see 'Restoring Defaults using CLI' on page 537)
- Hardware reset pinhole button (see Restoring Defaults using Hardware Reset Button on page 537)
- Loading an empty *ini* file (see 'Restoring Defaults using an ini File' on page 538)

41.1 Restoring Defaults using CLI

The device can be restored to factory defaults using CLI, as described in the procedure below.

➤ **To restore factory defaults using CLI:**

1. Access the CLI:
 - a. Connect the RS-232 serial port of the device to the communication port on your computer. For serial cabling, refer to the *Hardware Installation Manual*.
 - b. Establish serial communication with the device using a serial communication program (such as HyperTerminal™) with the following communication port settings:
 - ◆ **Baud Rate:** 115,200 bps
 - ◆ **Data Bits:** 8
 - ◆ **Parity:** None
 - ◆ **Stop Bits:** 1
 - ◆ **Flow Control:** None
2. At the CLI prompt, type the following command to access the configuration mode, and then press Enter:

```
# conf
```
3. At the prompt, type the following command to reset the device to default settings, and then press Enter:

```
# RestoreFactorySettings
```

41.2 Restoring Defaults using Hardware Reset Button

The device's hardware reset pinhole button can be used to reset the device to default settings.

➤ **To restore default settings using the hardware reset pinhole button:**

- With a paper clip or any other similar pointed object, press and hold down the reset pinhole button, located on the CPU module for at least 12 seconds (but no more than 25 seconds).

41.3 Restoring Defaults using an ini File

You can restore the device to factory default settings by loading an empty *ini* file to the device. This is done using the Web interface's Configuration File page (see 'Backing Up and Loading Configuration File' on page 526). If the *ini* file does include content (e.g., parameters), ensure that they are on lines beginning with comment signs (i.e., semicolons ";") so that the device ignores them.



Note: The only settings that are not restored to default are the management (OAMP) IP address and the Web interface's login user name and password.

Part IX

Status, Performance Monitoring and Reporting

42 System Status

This section describes how to view various system statuses.

42.1 Viewing Device Information

The Device Information page displays various hardware and software information of the device. This page also lists any Auxiliary files that have been installed on the device and allows you to remove them.

➤ **To access the Device Information page:**

- Open the Device Information page (**Status & Diagnostics** tab > **System Status** menu > **Device Information**).

▼ General Settings	
MAC Address:	00908f222e30
Serial Number:	2240048
Board Type:	Mediant 1000
Device Up Time:	0d:0h:31m:15s:20th
Device Administrative State:	Unlocked
Device Operational State:	Enabled
Flash Size [bytes]:	64
RAM Size [bytes]:	268435456
CPU Speed [MHz]:	500
▼ Versions	
Version ID:	6.40A.010.012
DSP Type:	2
DSP Software Version:	60007
DSP Software Name:	624AE3
Flash Version:	520
▼ Loaded Files	
Call Progress Tones File Name:	usa_tones_13.dat <input type="button" value="Delete"/>
Loaded Coder Table :	Default CODERTABLE

➤ **To delete a loaded file:**

- Click the **Delete** button corresponding to the file that you want to delete. Deleting a file takes effect only after device reset (see 'Resetting the Device' on page 491).

42.2 Viewing Ethernet Port Information

The Ethernet Port Information page displays read-only information on the Ethernet port connections.



Note: The Ethernet Port Information page can also be accessed from the Home page (see 'Viewing the Home Page' on page 61).

➤ **To view Ethernet port information:**

- Open the Ethernet Port Information page (**Status & Diagnostics** tab > **System Status** menu > **Ethernet Port Information**).

Ethernet Information	
Active Port	1
Port 1 Duplex Mode	Half Duplex
Port 1 Speed	100 Mbps
Port 2 Duplex Mode	Not Available
Port 2 Speed	Not Available

Ethernet Port Information Parameters

Parameter	Description
Active Port	Displays the active Ethernet port (1 or 2).
Port Duplex Mode	Displays whether the port is in half or duplex mode.
Port Speed	Displays the speed (in Mbps) of the Ethernet port.

43 Carrier-Grade Alarms

This section describes how to view the following types of alarms:

- Active alarms - see 'Viewing Active Alarms' on page 543
- Alarm history - see 'Viewing Alarm History' on page 543

43.1 Viewing Active Alarms

The Active Alarms page displays a list of currently active alarms. You can also access this page from the Home page (see 'Viewing the Home Page' on page 61).

➤ **To view the list of active alarms:**

- Open the Active Alarms page (**Status & Diagnostics** tab > **System Status** menu > **Carrier-Grade Alarms** > **Active Alarms**).

Sequential number	Severity	Source	Description	Date
1	Major	Board#1/WanLink#1	WAN link alarm. FE interface 1 is down.	25.8.2011 , 16:28:47
2	Minor	Board#1/EthernetLink#2	Ethernet link alarm. LAN port number 2 is down.	25.8.2011 , 16:28:47
3	Minor	Board#1/EthernetLink#3	Ethernet link alarm. LAN port number 3 is down.	25.8.2011 , 16:28:47

For each alarm, the following information is provided:

- **Severity:** severity level of the alarm:
 - Critical (red)
 - Major (orange)
 - Minor (yellow)
- **Source:** unit from which the alarm was raised
- **Description:** brief explanation of the alarm
- **Date:** date and time that the alarm was generated

You can view the next 20 alarms (if exist), by clicking the **Go to page** button.

43.2 Viewing Alarm History

The Alarms History page displays a list of alarms that have been raised and traps that have been cleared.

➤ **To view the list of history alarms:**

- Open the Alarms History page (**Status & Diagnostics** tab > **System Status** menu > **Carrier-Grade Alarms** > **Alarms History**).

Sequential number	Severity	Source	Description	Date
1	Major	Board#1	Controller failure alarm Proxy Set 0: Proxy lost, looking for another proxy	6.1.2010 , 14:1:26
2	cleared	Board#1	Alarm cleared: Controller failure alarm Proxy Set 0: Proxy lost, looking for another proxy	6.1.2010 , 14:1:26
3	Major	Board#1	Controller failure alarm Proxy Set ID 0	6.1.2010 , 14:1:26
4	Major	Board#1/WanLink#1	WAN link alarm. FE interface 1 is down.	6.1.2010 , 14:1:29
5	Minor	Board#1/EthernetLink#2	Ethernet link alarm. LAN port number 2 is down.	6.1.2010 , 14:1:29
6	Major	Board#1	NTP server alarm. No connection to NTP server.	6.1.2010 , 14:11:14

For each alarm, the following information is provided:

- **Severity:** severity level of the alarm:
 - Critical (red)
 - Major (orange)
 - Minor (yellow)

- Cleared (green)
- **Source:** unit from which the alarm was raised
- **Description:** brief explanation of the alarm
- **Date:** date and time that the alarm was generated

You can view the next 20 alarms (if exist), by clicking the **Go to page** button.

➤ **To delete all the alarms in the table:**

1. Click the **Delete History Table** button; a confirmation message box appears.
2. Click **OK** to confirm.

44 Performance Monitoring

This section describes how to view performance monitoring.

44.1 Viewing MOS per Media Realm

The MOS Per Media Realm page displays statistics on Media Realms (configured in 'Configuring Media Realms' on page 183). This page provides two graphs:

- Upper graph: displays the Mean Opinion Score (MOS) quality in RTCP data per selected Media Realm.
- Lower graph: displays the bandwidth of transmitted media (in Kbps) in RTCP data per Media Realm.

➤ **To view the MOS per Media Realm graph:**

1. Open the MOS Per Media Realm page (**Status & Diagnostics** tab > **Performance Monitoring** menu > **MOS Per Media Realm**).

Figure 44-1: MOS Per Media Realm Graph



2. From the 'Media Realm' drop-down list, select the Media Realm for which you want to view.

Use the **Zoom In**  button to increase the displayed time resolution or the **Zoom Out**  button to decrease it. Instead of using these zoom buttons, you can use the slide ruler. As you increase the resolution, more data is displayed on the graph. The minimum resolution is about 30 seconds; the maximum resolution is about an hour.

To pause the graph, click the **Pause** button; click **Play** to resume.

44.2 Viewing Trunk Utilization

The Trunk Utilization page provides an X-Y graph that displays the number of active channels per trunk over time. The x-axis indicates the time; the y-axis indicates the number of active trunk channels.




Note: If you navigate to a different page, the data displayed in the graph and all its settings are cleared.

➤ **To view the number of active trunk channels**

1. Open the Trunk Utilization page (**Status & Diagnostics** tab > **Performance Monitoring** menu > **Trunk Utilization**).

Figure 44-2: Trunk Utilization Page



2. From the 'Trunk' drop-down list, select the trunk for which you want to view active channels.

For more graph functionality, see the following table:

Additional Graph Functionality for Trunk Utilization

Button	Description
Add button	<p>Displays additional trunks in the graph. Up to five trunks can be displayed simultaneously in the graph. To view another trunk, click this button and then from the new 'Trunk' drop-down list, select the required trunk.</p> <p>Each trunk is displayed in a different color, according to the legend shown in the top-left corner of the graph.</p>
Remove button	Removes the selected trunk display from the graph.
Disable check box	<p>Hides or shows an already selected trunk. Select this check box to temporarily hide the trunk display; clear this check box to show the trunk. This is useful if you do not want to remove the trunk entirely (using the Remove button).</p>
Get Most Active button	Displays only the trunk with the most active channels (i.e., trunk with the most calls).
Pause button	Pauses the display in the graph.
Play button	Resumes the display in the graph.
Zoom slide ruler and buttons	<p>Increases or reduces the trunk utilization display resolution concerning time. The Zoom In  button increases the time resolution; the Zoom Out  button decreases it. Instead of using the buttons, you can use the slide ruler. As you increase the resolution, more data is displayed on the graph. The minimum resolution is about 30 seconds; the maximum resolution is about an hour.</p>

Reader's Notes

45 VoIP Status

This section describes how to view VoIP status and statistics.

45.1 Viewing Trunks & Channels Status

The Trunks & Channels Status page displays the status of the device's trunks and corresponding channels. It also enables you to view trunk configuration and channel information.

➤ **To view the status of the device's trunks and channels:**

1. Open the Home page.
2. On the graphical display of the device, click the required trunk, and then from the shortcut menu, choose Port Settings; the Trunks & Channels Status page appears.

Figure 45-1: Trunks and Channels Status Screen

Trunks		Channels																														
Status	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31
 Trunk 1																																



Note: The number of displayed trunks and channels depends on configuration.

The status of the trunks is depicted by color-coded icons, as described in the table below:

Description of Color-Coded Icons for Trunk Status

Icon	Color	Trunk
		Label
	Gray	Disabled
	Green	Active - OK
	Yellow	RAI Alarm
	Red	LOS / LOF Alarm
	Blue	AIS Alarm
	Light Orange	D-Channel Alarm
	Dark Orange	NFAS Alarm
	Purple	Lower Layer Down (DS3 physical layer is disabled)

The status of the channels is depicted by color-coded icons, as described in the table below:

Description of Color-Coded Icons for Channel Status

Icon	Color	Label	Description
	Light blue	Inactive	Channel is configured, but currently has no calls
	Green	Active	Call in progress (RTP traffic) and no alarms
	Purple	SS7	Channel is configured for SS7 Note: Currently, SS7 is not supported.
	Gray	Non Voice	Channel is not configured
	Blue	ISDN Signaling	Channel is configured as a D-channel
	Yellow	CAS Blocked	-
	Dark Orange	Maintenance	B-channel has been intentionally taken out of service due to maintenance
	Red	Out Of Service	B-channel is out of service

- To view detailed information on a specific trunk's channel, click the required channel icon; the Basic Channel Information page appears, displaying information under the **Basic** tab (displayed in green):

Figure 45-2: Basic Channel Information Page

 SIP  Basic  RTP/RTCP  Voice Settings	
Channel Identifier:	55
Status:	Inactive
Call ID:	0
Endpoint ID:	Not Available
Call Duration [sec]:	0
Call Type:	Voice
Call Destination:	10.13.4.12
Coder:	Transparent

To view additional channel information, click the required tab (**SIP**, **RTP/RTCP**, and **Voice Settings**).

- To view the settings of a specific trunk, click the required trunk icon, and then from the shortcut menu, choose **Port Settings**; the Trunk Settings page opens, displaying the trunk's settings. If needed, you can modify the settings (see 'Configuring Trunk Settings' on page 273).

45.2 Viewing Analog Port Information

The Home page allows you to view detailed information on selected FXS and FXO analog ports such as RTP/RTCP and voice settings.

➤ **To view information on an analog port:**

1. Open the Home page.
2. On the graphical display of the device, click the required analog port; a shortcut menu appears.
3. From the shortcut menu, choose **Port Settings**; the Basic Channel Information page appears with the **Basic** tab selected (displayed in green):

Figure 45-3: Basic Channel Information Page

◆ SIP ◆ Basic ◆ RTP/RTCP ◆ Voice Settings	
Channel Identifier:	55
Status:	Inactive
Call ID:	0
Endpoint ID:	Not Available
Call Duration [sec]:	0
Call Type:	Voice
Call Destination:	10.13.4.12
Coder:	Transparent

4. To view additional channel information, click the required tab - **SIP**, **RTP/RTCP**, and **Voice Settings**.

45.3 Viewing NFAS Groups and D-Channel Status

The NFAS Group & D-Channel Status page displays the status of the device's D-channels and NFAS groups. The status of a D-channel and NFAS group can be "In Service" or "Out of Service". This page also indicates whether the D-channel is a primary or backup D-channel.

This page also enables you to manually switchover between active and standby D-channels belonging to the same NFAS group. This is done using the **Switch Activity** button. For more information, see 'Performing Manual D-Channel Switchover in NFAS Group' on page 288.



Note: This page is applicable only to T1 ISDN protocols supporting NFAS, and only if the NFAS group is configured with two D-channels.

- To view the status of the D-channels and NFAS groups:
 - Open the NFAS Group & D-Channel Status page (**Status & Diagnostics** tab > **VoIP Status** menu > **NFAS Group & D-Channel Status**).

Figure 45-4: NFAS Group & D-Channel Status Page



45.4 Viewing Active IP Interfaces

The IP Interface Status page displays the device's active IP interfaces that are listed in the Multiple Interface Table page (see 'Configuring IP Network Interfaces' on page 110).

- To view the active IP network interfaces:
 - Open the IP Interface Status page (**Status & Diagnostics** tab > **VoIP Status** menu > **IP Interface Status**).

Index	Application Type	Address Type	Interface Mode	IP Address	Prefix Length	Gateway	VLAN ID	Interface Name
NA	O+M+C	IPv4	IPv4 Manual	10.13.4.13	16	10.13.0.1	0	O+M+C

VLAN Mode	Disabled
Native VLAN ID	1

45.5 Viewing Performance Statistics

The Basic Statistics page provides read-only, device performance statistics. This page is refreshed every 60 seconds. The duration that the currently displayed statistics has been collected is displayed above the statistics table.

- **To view performance statistics:**
 - Open the Basic Statistics page (**Status & Diagnostics** tab > **VoIP Status** menu > **Performance Statistics**).

Figure 45-5: Basic Statistics Page

(Statistics for 759525 seconds)	
Active TDM channels	0
Active DSP resources	0
Active analog channels	0
Active G.711 channels	0
Average voice delay (ms)	5
Average voice jitter (ms)	11
Total RTP packets TX	4250
Total RTP packets RX	4241
Total call attempts	6

The duration that the displayed statistics were collected is displayed in seconds above the table. To reset the performance statistics to zero, click the **Reset Statistics** button.

45.6 Viewing Call Counters

The IP to Tel Calls Count page and Tel to IP Calls Count page provide you with statistical information on incoming (IP-to-Tel) and outgoing (Tel-to-IP) calls. The statistical information is updated according to the release reason that is received after a call is terminated (during the same time as the end-of-call Call Detail Record or CDR message is sent). The release reason can be viewed in the 'Termination Reason' field in the CDR message.

You can reset the statistical data displayed on the page (i.e., refresh the display), by clicking the **Reset Counters** button located below the table.

- **To view IP-to-Tel and Tel-to-IP call counters:**
 - Open the Call Counters page that you want to view (**Status & Diagnostics** tab > **VoIP Status** menu > **IP to Tel Calls Count** or **Tel to IP Calls Count**); the figure below shows the IP to Tel Calls Count page.

Figure 45-6: Calls Count Page

Number of Attempted Calls	19
Number of Established Calls	14
Percentage of Successful Calls(ASR)	73.684211
Number of Calls Terminated due to a Busy Line	2
Number of Calls Terminated due to No Answer	0
Number of Calls Terminated due to Forward	0
Number of Failed Calls due to No Route	0
Number of Failed Calls due to No Matched Capabilities	0
Number of Failed Calls due to No Resources	0
Number of Failed Calls due to Other Failures	0
Average Call Duration(ACD)[sec]	25
Attempted Fax Calls Counter	0
Successful Fax Calls Counter	0

The fields in this page are described in the following table:

Call Counters Description

Counter	Description
Number of Attempted Calls	Indicates the number of attempted calls. It is composed of established and failed calls. The number of established calls is represented by the 'Number of Established Calls' counter. The number of failed calls is represented by the failed-call counters. Only one of the established / failed call counters is incremented every time.
Number of Established Calls	Indicates the number of established calls. It is incremented as a result of one of the following release reasons if the duration of the call is greater than zero: <ul style="list-style-type: none"> ▪ GWAPP_REASON_NOT_RELEVANT (0) ▪ GWAPP_NORMAL_CALL_CLEAR (16) ▪ GWAPP_NORMAL_UNSPECIFIED (31) And the internal reasons: <ul style="list-style-type: none"> ▪ RELEASE_BECAUSE_UNKNOWN_REASON ▪ RELEASE_BECAUSE_REMOTE_CANCEL_CALL ▪ RELEASE_BECAUSE_MANUAL_DISC ▪ RELEASE_BECAUSE_SILENCE_DISC ▪ RELEASE_BECAUSE_DISCONNECT_CODE Note: When the duration of the call is zero, the release reason GWAPP_NORMAL_CALL_CLEAR increments the 'Number of Failed Calls due to No Answer' counter. The rest of the release reasons increment the 'Number of Failed Calls due to Other Failures' counter.
Percentage of Successful Calls (ASR)	The percentage of established calls from attempted calls.
Number of Calls Terminated due to a Busy Line	Indicates the number of calls that failed as a result of a busy line. It is incremented as a result of the following release reason: GWAPP_USER_BUSY (17)
Number of Calls Terminated due to No Answer	Indicates the number of calls that weren't answered. It's incremented as a result of one of the following release reasons: <ul style="list-style-type: none"> ▪ GWAPP_NO_USER_RESPONDING (18) ▪ GWAPP_NO_ANSWER_FROM_USER_ALERTED (19) ▪ GWAPP_NORMAL_CALL_CLEAR (16) (when the call duration is zero)
Number of Calls Terminated due to Forward	Indicates the number of calls that were terminated due to a call forward. The counter is incremented as a result of the following release reason: RELEASE_BECAUSE_FORWARD
Number of Failed Calls due to No Route	Indicates the number of calls whose destinations weren't found. It is incremented as a result of one of the following release reasons: <ul style="list-style-type: none"> ▪ GWAPP_UNASSIGNED_NUMBER (1) ▪ GWAPP_NO_ROUTE_TO_DESTINATION (3)
Number of Failed Calls due to No Matched Capabilities	Indicates the number of calls that failed due to mismatched device capabilities. It is incremented as a result of an internal identification of capability mismatch. This mismatch is reflected to CDR via the value of the parameter DefaultReleaseReason (default is GWAPP_NO_ROUTE_TO_DESTINATION (3)) or by the GWAPP_SERVICE_NOT_IMPLEMENTED_UNSPECIFIED (79) reason.

Counter	Description
Number of Failed Calls due to No Resources	Indicates the number of calls that failed due to unavailable resources or a device lock. The counter is incremented as a result of one of the following release reasons: <ul style="list-style-type: none"> ▪ GWAPP_RESOURCE_UNAVAILABLE_UNSPECIFIED ▪ RELEASE_BECAUSE_GW_LOCKED
Number of Failed Calls due to Other Failures	This counter is incremented as a result of calls that failed due to reasons not covered by the other counters.
Average Call Duration (ACD) [sec]	The average call duration (ACD) in seconds of established calls. The ACD value is refreshed every 15 minutes and therefore, this value reflects the average duration of all established calls made within a 15 minute period.
Attempted Fax Calls Counter	Indicates the number of attempted fax calls.
Successful Fax Calls Counter	Indicates the number of successful fax calls.

45.7 Viewing Registered Users

The SAS/SBC Registered Users page displays a list of registered SAS users recorded in the device's database.

➤ **To view registered SAS users:**

- Open the Registration Status page (**Status & Diagnostics** tab > **VoIP Status** menu > **Registered Users**).

Figure 45-7: SAS/SBC Registered Users Page

Address Of Record	Contact
1000@10.8.5.71	<sip:1000@10.8.5.71:5060>;expires=180; Active status: 1
1001@10.8.5.71	<sip:1001@10.8.5.71:5060>;expires=180; Active status: 1
1100@10.8.5.71	<sip:1100@10.8.5.71:5060>;expires=180; Active status: 1
1101@10.8.5.71	<sip:1101@10.8.5.71:5060>;expires=180; Active status: 1
2000@10.8.5.72	<sip:2000@10.8.5.72:5060>;expires=180; Active status: 1

SAS/SBC Registered Users Parameters

Column Name	Description
Address of Record	An address-of-record (AOR) is a SIP or SIPS URI that points to a domain with a location service that can map the URI to another URI (Contact) where the user might be available.
Contact	SIP URI that can be used to contact that specific instance of the User Agent for subsequent requests.

45.8 Viewing Registration Status

The Registration Status page displays whether the device as a whole, its endpoints (FXS / FXO / BRI), and SIP Accounts are registered to a SIP Registrar/Proxy server.

➤ **To view the registration status:**

- Open the Registration Status page (**Status & Diagnostics** tab > **VoIP Status** menu > **Registration Status**).

Registered Per Gateway		NO	
▼ Ports Registration Status			
Gateway Port		Status	
Module	3 Port 1 FXS	NOT REGISTERED	
Module	3 Port 2 FXS	NOT REGISTERED	
Module	3 Port 3 FXS	NOT REGISTERED	
Module	3 Port 4 FXS	NOT REGISTERED	
▼ Accounts Registration Status			
Index	Group Type	Group Name	Status
▼ BRI Phone Numbers Status			
Phone Number		Module / Port	Status

- **Registered Per Gateway:**
 - "YES" = Registration is per device
 - "NO" = Registration is not per device
- **Ports Registration Status:**
 - "REGISTERED" = channel is registered
 - "NOT REGISTERED" = channel not registered
- **Accounts Registration Status:** registration status based on the Accounts table (configured in 'Configuring Account Table' on page 225):
 - **Group Type:** type of served group - Trunk Group or IP Group
 - **Group Name:** name of the served group, if applicable
 - **Status:** indicates whether or not the group is registered ("Registered" or "Unregistered")
- **BRI Phone Number Status:**
 - **Phone Number:** phone number of BRI endpoint
 - **Module/Port:** module/port number of BRI endpoint
 - **Status:** indicates whether or not the BRI endpoint is registered ("Registered" or "Unregistered")



Note: The registration mode (i.e., per device, endpoint, account. or no registration) is configured in the Trunk Group Settings table (see 'Configuring Trunk Group Settings' on page 293) or using the TrunkGroupSettings *ini* file parameter.

45.9 Viewing Call Routing Status

The Call Routing Status page provides you with information on the current routing method used by the device. This information includes the IP address and FQDN (if used) of the Proxy server with which the device currently operates.

➤ **To view call routing status:**

- Open the Call Routing Status page (**Status & Diagnostics** tab > **VoIP Status** menu > **Call Routing Status**).

Figure 45-8: Call Routing Status Page

Call-Routing Method		Routing Table	
▼ Active Proxy Sets Status			
ID	IP Address	State	
0	Not Used (--)	--	
1	10.8.230.64 (10.8.230.64)	OK	
2	10.9.244.80 (10.9.244.80)	OK	
3	10.10.244.80 (10.10.244.80)	OK	
4	10.11.244.80 (10.11.244.80)	OK	
5	10.12.244.80 (10.12.244.80)	OK	
6	Not Used (--)	--	
7	Not Used (--)	--	
8	Not Used (--)	--	
9	10.8.244.81 (10.8.244.81)	OK	
10	Not Used (--)	--	
11	Not Used (--)	--	
12	Not Used (--)	--	

Call Routing Status Parameters

Parameter	Description
Call-Routing Method	<ul style="list-style-type: none"> ▪ Proxy/GK = Proxy server is used to route calls. ▪ Routing Table = The Outbound IP Routing Table is used to route calls.
IP Address	<ul style="list-style-type: none"> ▪ Not Used = Proxy server isn't defined. ▪ IP address and FQDN (if exists) of the Proxy server with which the device currently operates.
State	<ul style="list-style-type: none"> ▪ N/A = Proxy server isn't defined. ▪ OK = Communication with the Proxy server is in order. ▪ Fail = No response from any of the defined Proxies.

45.10 Viewing IP Connectivity

The IP Connectivity page displays on-line, read-only network diagnostic connectivity information on all destination IP addresses configured in the Outbound IP Routing Table page (see 'Configuring Outbound IP Routing Table' on page 323).



Note: The information in columns 'Quality Status' and 'Quality Info' (per IP address) is reset if two minutes elapse without a call to that destination.

➤ **To view IP connectivity information:**

1. In the Routing General Parameters page, set the 'Enable Alt Routing Tel to IP' parameter (AltRoutingTel2IPMode) to **Enable** or **Status Only** (see 'Configuring General Routing Parameters' on page 323).
2. Open the IP Connectivity page (**Status & Diagnostics** tab > **VoIP Status** menu > **IP Connectivity**).

Figure 45-9: IP Connectivity Page

	IP Address	Host Name	Connectivity Method	Connectivity Status	Quality Status	Quality Info	DNS Status
1	Unused	---	Ping	---	---	---	---
2	Unused	---	Ping	---	---	---	---
3	Unused	---	Ping	---	---	---	---
4	Unused	---	Ping	---	---	---	---
5	Unused	---	Ping	---	---	---	---
6	Unused	---	Ping	---	---	---	---
7	Unused	---	Ping	---	---	---	---
8	Unused	---	Ping	---	---	---	---
9	Unused	---	Ping	---	---	---	---
10	Unused	---	Ping	---	---	---	---
11	Unused	---	Ping	---	---	---	---
12	Unused	---	Ping	---	---	---	---

IP Connectivity Parameters

Column Name	Description
IP Address	The IP address can be one of the following: <ul style="list-style-type: none"> ▪ IP address defined as the destination IP address in the Outbound IP Routing Table. ▪ IP address resolved from the host name defined as the destination IP address in the Outbound IP Routing Table.
Host Name	Host name (or IP address) as defined in the Outbound IP Routing Table.
Connectivity Method	The method according to which the destination IP address is queried periodically (ICMP ping or SIP OPTIONS request).
Connectivity Status	The status of the IP address' connectivity according to the method in the 'Connectivity Method' field. <ul style="list-style-type: none"> ▪ OK = Remote side responds to periodic connectivity queries. ▪ Lost = Remote side didn't respond for a short period.

Column Name	Description
	<ul style="list-style-type: none"> ▪ Fail = Remote side doesn't respond. ▪ Init = Connectivity queries not started (e.g., IP address not resolved). ▪ Disable = The connectivity option is disabled, i.e., parameter 'Alt Routing Tel to IP Mode' (AltRoutingTel2IPMode <i>ini</i>) is set to 'None' or 'QoS'.
Quality Status	<p>Determines the QoS (according to packet loss and delay) of the IP address.</p> <ul style="list-style-type: none"> ▪ Unknown = Recent quality information isn't available. ▪ OK ▪ Poor <p>Notes:</p> <ul style="list-style-type: none"> ▪ This parameter is applicable only if the parameter 'Alt Routing Tel to IP Mode' is set to 'QoS' or 'Both' (AltRoutingTel2IPMode = 2 or 3). ▪ This parameter is reset if no QoS information is received for 2 minutes.
Quality Info.	<p>Displays QoS information: delay and packet loss, calculated according to previous calls.</p> <p>Notes:</p> <ul style="list-style-type: none"> ▪ This parameter is applicable only if the parameter 'Alt Routing Tel to IP Mode' is set to 'QoS' or 'Both' (AltRoutingTel2IPMode = 2 or 3). ▪ This parameter is reset if no QoS information is received for 2 minutes.
DNS Status	<p>DNS status can be one of the following:</p> <ul style="list-style-type: none"> ▪ DNS Disable ▪ DNS Resolved ▪ DNS Unresolved

Reader's Notes

46 Reporting Information to External Party

This section describes features for reporting various information to an external party.

46.1 RTP Control Protocol Extended Reports (RTCP XR)

RTP Control Protocol Extended Reports (RTCP XR) is a VoIP management control that defines a set of metrics containing information for assessing VoIP call quality and for diagnosing problems. RTCP XR (RFC 3611) extends the RTCP reports defined in RFC 3550 by providing additional VoIP metrics. RTCP XR information publishing is implemented in the device according to <draft-johnston-sipping-rtcp-summary-07>. This draft defines how a SIP User Agent (UA) publishes the detailed information to a defined collector. RTCP XR measures VoIP call quality such as packet loss, delay, signal / noise / echo levels, estimated R-factor, and mean opinion score (MOS). RTCP XR measures these parameters using metrics as listed in the table below.



Note: RTCP XR is a customer ordered feature and thus, must be included in the Software License Key installed on the device.

RTCP XR messages containing key call-quality-related metrics are exchanged periodically (user-defined) between the device and the SIP UA. This allows an analyzer to monitor these metrics midstream, or a device to retrieve them using SNMP. The device can send RTCP XR reports to an Event State Compositor (ESC) server using PUBLISH messages. These reports can be sent at the end of each call and according to a user-defined interval between consecutive reports.

RTCP XR Published VoIP Metrics

Group	Metric Name
General	Start Timestamp
	Stop Timestamp
	Call-ID
	Local Address (IP, Port & SSRC)
	Remote Address (IP, Port & SSRC)
Session Description	Payload Type
	Payload Description
	Sample Rate
	Frame Duration
	Frame Octets
	Frames per Packets
	Packet Loss Concealment
	Silence Suppression State
Jitter Buffer	Jitter Buffer Adaptive
	Jitter Buffer Rate

Group	Metric Name
	Jitter Buffer Nominal
	Jitter Buffer Max
	Jitter Buffer Abs Max
Packet Loss	Network Packet Loss Rate
	Jitter Buffer Discard Rate
Burst Gap Loss	Burst Loss Density
	Burst Duration
	Gap Loss Density
	Gap Duration
	Minimum Gap Threshold
Delay	Round Trip Delay
	End System Delay
	One Way Delay
	Interarrival Jitter
	Min Absolute Jitter
	Signal
	Signal Level
	Noise Level
	Residual Echo Return Noise
Quality Estimates	Listening Quality R
	RLQ Est. Algorithm
	Conversational Quality R
	RCQ Est. Algorithm
	External R In
	Ext. R In Est. Algorithm
	External R Out
	Ext. R Out Est. Algorithm
	MOS-LQ
	MOS-LQ Est. Algorithm
	MOS-CQ
	MOS-CQ Est. Algorithm
	QoE Est. Algorithm

➤ **To configure RTCP XR:**

1. Open the RTP/RTCP Settings page (**Configuration** tab > **VoIP** menu > **Media** > **RTP/RTCP Settings**). The RTCP XR parameters are listed under the 'RTCP XR Settings' group, as shown below:

Figure 46-1: RTCP XR Parameters in RTP/RTCP Settings Page

RTCP XR Settings	
Burst Threshold	-1
Delay Threshold	-1
R-Value Delay Threshold	-1
Enable RTCP XR	CE_VQMON_DISABLE
Minimum Gap Size	16
RTCP XR Report Mode	Disable
RTCP XR Packet Interval	0
Disable RTCP XR Interval Randomization	Disable
RTCP XR Collection Server	
RTCP XR Collection Server Transport Type	Not Configured

2. Configure the RTCP XR parameters, as required:
 - 'Enable RTCP XR' (*VQMonEnable*) - enables voice quality monitoring and RTCP XR.
 - 'Minimum Gap Size' (*VQMonGMin*) - defines the voice quality monitoring - minimum gap size (number of frames).
 - 'Burst Threshold' (*VQMonBurstHR*) - defines the voice quality monitoring - excessive burst alert threshold.
 - 'Delay Threshold' (*VQMonDelayTHR*) - defines the voice quality monitoring - excessive delay alert threshold.
 - 'R-Value Delay Threshold' (*VQMonEOCRValTHR*) - defines the voice quality monitoring - end of call low quality alert threshold.
 - 'RTCP XR Report Mode' (*RTCPXRReportMode*) - determines whether RTCP XR reports are sent to the ESC and defines the interval in which they are sent.
 - 'RTCP XR Packet Interval' (*RTCPInterval*) - defines the time interval between adjacent RTCP reports.
 - 'Disable RTCP XR Interval Randomization' (*DisableRTCPRandomize*) - determines whether RTCP report intervals are randomized or whether each report interval accords exactly to the parameter RTCPInterval.
 - 'RTCP XR Collection Server' (*RTCPXREscIP*) - defines the IP address of the Event State Compositor (ESC).
 - 'RTCP XR Collection Server Transport Type' (*RTCPXRESCTransportType*) - determines the transport layer for outgoing SIP dialogs initiated by the device to the RTCP XR Collection Server.
3. Click **Submit**.
4. Reset the device for the settings to take effect.

46.2 Generating Call Detail Records

The Call Detail Record (CDR) contains vital statistic information on calls made from the device. The device can be configured to generate and report CDRs for various stages of the call, including SIP messages and/or media. You can configure when CDRs for a call are generated, for example, only at the end of the call or only at the start and end of the call. Once generated, the device sends the CDRs to a user-defined Syslog server.

The CDR Syslog message complies with RFC 3161 and is identified by Facility 17 (local1) and Severity 6 (Informational).

For CDR in RADIUS format, see 'RADIUS Accounting CDR Attributes' on page 571.

46.2.1 Configuring CDR Reporting

The procedure below describes how to configure CDR reporting.

➤ **To configure CDR reporting:**

1. Enable the Syslog feature for sending log messages generated by the device to a collecting log message server. For more information, see 'Configuring Syslog' on page 583.
2. Open the Advanced Parameters page (**Configuration** tab > **VoIP** menu > **SIP Definitions** > **Advanced Parameters**). The CDR parameters appear under the 'CDR and Debug' group, as shown below:

Figure 46-2: CDR Parameters in Advanced Parameters Page

CDR and Debug	
CDR Server IP Address	10.8.6.55
CDR Report Level	Start & End & Connect Call
Media CDR Report Level	End Media

3. Configure the parameters as required. For a description of the parameters, see 'Syslog, CDR and Debug Parameters' on page 630.
4. Click **Submit**.



Note: If the CDR server IP address is not configured, the CDRs are sent to the Syslog server, configured in 'Configuring Syslog' on page 583.

46.2.2 CDR Field Description

This section describes the CDR fields that are generated by the device.

46.2.2.1 CDR Fields for Gateway/IP-to-IP Application

The CDR fields for the Gateway / IP-to-IP application are listed in the table below.

CDR Fields for Gateway/IP-to-IP Application

Field Name	Description
GWReportType	Report type: <ul style="list-style-type: none"> ▪ CALL_START ▪ CALL_CONNECT ▪ CALL_END
Cid	Port number
SessionId	SIP session identifier
Trunk	Physical trunk number Note: This field is applicable only to the Gateway application.
BChan	Selected B-channel Note: This field is applicable only to the Gateway application.
ConId	SIP conference ID Note: This field is applicable only to the Gateway application.
TG	Trunk Group ID Note: This field is applicable only to the Gateway application.
EPTyp	Endpoint type: <ul style="list-style-type: none"> ▪ FXO ▪ FXS ▪ EANDM ▪ ISDN ▪ CAS ▪ DAA ▪ IPMEDIA ▪ NETANN ▪ STREAMING ▪ TRANSPARENT ▪ MSCML ▪ VXML ▪ IP2IP
Orig	Call originator: <ul style="list-style-type: none"> ▪ LCL (Tel side) ▪ RMT (IP side)
Sourcelp	Source IP address
Destlp	Destination IP address

Field Name	Description
TON	Source phone number type Note: This field is applicable only to the Gateway application.
NPI	Source phone number plan Note: This field is applicable only to the Gateway application.
SrcPhoneNum	Source phone number
SrcNumBeforeMap	Source number before manipulation
TON	Destination phone number type Note: This field is applicable only to the Gateway application.
NPI	Destination phone number plan Note: This field is applicable only to the Gateway application.
DstPhoneNum	Destination phone number
DstNumBeforeMap	Destination number before manipulation
Durat	Call duration
Coder	Selected coder
Intrv	Packet interval
Rtplp	RTP IP address
Port	Remote RTP port
TrmSd	Initiator of call release (IP, Tel, or Unknown)
TrmReason	SIP call termination reason (see 'Release Reasons in CDR' on page 568)
Fax	Fax transaction during call
InPackets	Number of incoming packets
OutPackets	Number of outgoing packets
PackLoss	Local packet loss
RemotePackLoss	Number of outgoing lost packets
SIPCallId	Unique SIP call ID
SetupTime	Call setup time
ConnectTime	Call connect time
ReleaseTime	Call release time
RTPdelay	RTP delay
RTPjitter	RTP jitter
RTPssrc	Local RTP SSRC
RemoteRTPssrc	Remote RTP SSRC
RedirectReason	Redirect reason
TON	Redirection phone number type Note: This field is applicable only to the Gateway application.
NPI	Redirection phone number plan Note: This field is applicable only to the Gateway application.

Field Name	Description
RedirectPhonNum	Redirection phone number
MeteringPulses	Number of generated metering pulses Note: This field is applicable only to the Gateway application.
SrcHost	Source host name
SrcHostBeforeMap	Source host name before manipulation
DstHost	Destination host name
DstHostBeforeMap	Destination host name before manipulation
IPG	IP Group description
LocalRtPlp	Remote RTP IP address
LocalRtpPort	Local RTP port
Amount	0-999999 Data is stored per call and sent in the syslog as follows: <ul style="list-style-type: none"> ▪ currency-type: amount multiplier for currency charge (euro or usd) ▪ recorded-units: for unit charge (1-999999)
Mult	0,001-1000 (in steps of 10) (See explanation above.)
TrmReasonCategory	Termination reason category: <ul style="list-style-type: none"> ▪ Calls with duration 0 (i.e., not connected): <ul style="list-style-type: none"> ✓ NO_ANSWER - GWAPP_NORMAL_CALL_CLEAR, GWAPP_NO_USER_RESPONDING, GWAPP_NO_ANSWER_FROM_USER_ALERTED ✓ BUSY - GWAPP_USER_BUSY ✓ NO_RESOURCES - GWAPP_RESOUUCE_UNAVAILABLE_UNSPECIFIED, RELEASE_BECAUSE_NO_CONFERENCE_RESOURCES_LEFT, RESOURCE_BECAUSE_NO_TRANSCODING_RESOURCES_LEFT, RELEASE_BECAUSE_GW_LOCKED ✓ NO_MATCH - RELEASE_BECAUSE_UNMATCHED_CAPABILITIES ✓ FORWARDED - RELEASE_BECAUSE_FORWARD ✓ GENERAL_FAILED - any other reason ▪ Calls with duration: <ul style="list-style-type: none"> ✓ NORMAL_CALL_CLEAR - GWAPP_NORMAL_CALL_CLEAR ✓ ABNORMALLY_TERMINATED - Anything else ▪ N/A - Reasons not belonging to above categories
RedirectNumBeforeMap	Redirect number before manipulation
SrdId	SRD ID name
SIPInterfaceId	SIP interface ID
ProxySetId	Proxy Set ID
IpProfileId	IP Profile ID name
MediaRealmId	Media Realm name

Field Name	Description
SigTransportType	SIP signaling transport type (UDP, TCP, or TLS)
TxRTPIPDiffServ	Media IP DiffServ
TxSigIPDiffServ	Signaling IP DiffServ
LocalRFactor	Local R-factor
RemoteRFactor	Remote R-factor
LocalMosCQ	Local MOS for conversation quality
RemoteMosCQ	Remote MOS for conversation quality
SigSourcePort	SIP source port
SigDestPort	SIP destination port
MediaType	Media type - audio, video, or text
AMD	Information relating to the Automatic Machine Detection (AMD) feature: <ul style="list-style-type: none"> ▪ V - voice ▪ A - answer machine ▪ S - silence ▪ U - unknown
%	Information relating to AMD that shows the success that the answering type (probability) was correctly detected
SIPTrmReason	SIP call termination reason (BYE, CANCEL, or SIP error codes, e.g., 404)
SipTermDesc	Description of SIP termination reason: <ul style="list-style-type: none"> ▪ SIP Reason header, if exists, for example: SIP ;cause=200 ;text="Call completed elsewhere". ▪ If no SIP Reason header exists, the description is taken from the reason text, if exists, of the SIP response code, for example: "417 Unknown Resource-Priority". ▪ If no reason text exists in the SIP response code, the description is taken from an internal SIP response mapping mechanism. For example, if the device receives a SIP response "422", it sends in the CDR "422 Session Interval Too Small method" as the description.
PstnTermReason	Q.850 protocol termination reason (0-127).
LatchedRtplp	Remote IP address of the incoming RTP stream that the device "latched" on to as a result of the RTP latching mechanism for NAT traversal.
LatchedRtpPort	Remote RTP port of the incoming RTP stream that the device "latched" on to as a result of the RTP latching mechanism for NAT traversal.

46.2.2.2 Release Reasons in CDR

The possible reasons for call termination for the Gateway / IP-to-IP application which is represented in the CDR field **TrmReason** are listed below:

- "REASON N/A"
- "RELEASE_BECAUSE_NORMAL_CALL_DROP"
- "RELEASE_BECAUSE_DESTINATION_UNREACHABLE"
- "RELEASE_BECAUSE_DESTINATION_BUSY"
- "RELEASE_BECAUSE_NOANSWER"

- "RELEASE_BECAUSE_UNKNOWN_REASON"
- "RELEASE_BECAUSE_REMOTE_CANCEL_CALL"
- "RELEASE_BECAUSE_UNMATCHED_CAPABILITIES"
- "RELEASE_BECAUSE_UNMATCHED_CREDENTIALS"
- "RELEASE_BECAUSE_UNABLE_TO_HANDLE_REMOTE_REQUEST"
- "RELEASE_BECAUSE_NO_CONFERECE_RESOURCES_LEFT"
- "RELEASE_BECAUSE_CONFERENCE_FULL"
- "RELEASE_BECAUSE_VOICE_PROMPT_PLAY_ENDED"
- "RELEASE_BECAUSE_VOICE_PROMPT_NOT_FOUND"
- "RELEASE_BECAUSE_TRUNK_DISCONNECTED"
- "RELEASE_BECAUSE_RSRC_PROBLEM"
- "RELEASE_BECAUSE_MANUAL_DISC"
- "RELEASE_BECAUSE_SILENCE_DISC"
- "RELEASE_BECAUSE_RTP_CONN_BROKEN"
- "RELEASE_BECAUSE_DISCONNECT_CODE"
- "RELEASE_BECAUSE_GW_LOCKED"
- "RELEASE_BECAUSE_NORTEL_XFER_SUCCESS"
- "RELEASE_BECAUSE_FAIL"
- "RELEASE_BECAUSE_FORWARD"
- "RELEASE_BECAUSE_ANONYMOUS_SOURCE"
- "RELEASE_BECAUSE_IP_PROFILE_CALL_LIMIT"
- "GWAPP_UNASSIGNED_NUMBER"
- "GWAPP_NO_ROUTE_TO_TRANSIT_NET"
- "GWAPP_NO_ROUTE_TO_DESTINATION"
- "GWAPP_CHANNEL_UNACCEPTABLE"
- "GWAPP_CALL_AWARDED_AND "
- "GWAPP_PREEMPTION"
- "PREEMPTION_CIRCUIT_RESERVED_FOR_REUSE"
- "GWAPP_NORMAL_CALL_CLEAR"
- "GWAPP_USER_BUSY"
- "GWAPP_NO_USER_RESPONDING"
- "GWAPP_NO_ANSWER_FROM_USER_ALERTED"
- "MFCR2_ACCEPT_CALL"
- "GWAPP_CALL_REJECTED"
- "GWAPP_NUMBER_CHANGED"
- "GWAPP_NON_SELECTED_USER_CLEARING"
- "GWAPP_INVALID_NUMBER_FORMAT"
- "GWAPP_FACILITY_REJECT"
- "GWAPP_RESPONSE_TO_STATUS_ENQUIRY"
- "GWAPP_NORMAL_UNSPECIFIED"
- "GWAPP_CIRCUIT_CONGESTION"
- "GWAPP_USER_CONGESTION"
- "GWAPP_NO_CIRCUIT_AVAILABLE"
- "GWAPP_NETWORK_OUT_OF_ORDER"

- "GWAPP_NETWORK_TEMPORARY_FAILURE"
- "GWAPP_NETWORK_CONGESTION"
- "GWAPP_ACCESS_INFORMATION_DISCARDED"
- "GWAPP_REQUESTED_CIRCUIT_NOT_AVAILABLE"
- "GWAPP_RESOURCE_UNAVAILABLE_UNSPECIFIED"
- "GWAPP_PERM_FR_MODE_CONN_OUT_OF_S"
- "GWAPP_PERM_FR_MODE_CONN_OPERATIONAL"
- "GWAPP_PRECEDENCE_CALL_BLOCKED"
 - "RELEASE_BECAUSE_PREEMPTION_ANALOG_CIRCUIT_RESERVED_FOR_REUSE"
 - "RELEASE_BECAUSE_PRECEDENCE_CALL_BLOCKED"
- "GWAPP_QUALITY_OF_SERVICE_UNAVAILABLE"
- "GWAPP_REQUESTED_FAC_NOT_SUBSCRIBED"
- "GWAPP_BC_NOT_AUTHORIZED"
- "GWAPP_BC_NOT_PRESENTLY_AVAILABLE"
- "GWAPP_SERVICE_NOT_AVAILABLE"
- "GWAPP_CUG_OUT_CALLS_BARRED"
- "GWAPP_CUG_INC_CALLS_BARRED"
- "GWAPP_ACCES_INFO_SUBS_CLASS_INCONS"
- "GWAPP_BC_NOT_IMPLEMENTED"
- "GWAPP_CHANNEL_TYPE_NOT_IMPLEMENTED"
- "GWAPP_REQUESTED_FAC_NOT_IMPLEMENTED"
- "GWAPP_ONLY_RESTRICTED_INFO_BEARER"
- "GWAPP_SERVICE_NOT_IMPLEMENTED_UNSPECIFIED"
- "GWAPP_INVALID_CALL_REF"
- "GWAPP_IDENTIFIED_CHANNEL_NOT_EXIST"
- "GWAPP_SUSPENDED_CALL_BUT_CALL_ID_NOT_EXIST"
- "GWAPP_CALL_ID_IN_USE"
- "GWAPP_NO_CALL_SUSPENDED"
- "GWAPP_CALL_HAVING_CALL_ID_CLEARED"
- "GWAPP_INCOMPATIBLE_DESTINATION"
- "GWAPP_INVALID_TRANSIT_NETWORK_SELECTION"
- "GWAPP_INVALID_MESSAGE_UNSPECIFIED"
- "GWAPP_NOT_CUG_MEMBER"
- "GWAPP_CUG_NON_EXISTENT"
- "GWAPP_MANDATORY_IE_MISSING"
- "GWAPP_MESSAGE_TYPE_NON_EXISTENT"
- "GWAPP_MESSAGE_STATE_INCONSISTENCY"
- "GWAPP_NON_EXISTENT_IE"
- "GWAPP_INVALID_IE_CONTENT"
- "GWAPP_MESSAGE_NOT_COMPATIBLE"
- "GWAPP_RECOVERY_ON_TIMER_EXPIRY"
- "GWAPP_PROTOCOL_ERROR_UNSPECIFIED"
- "GWAPP_INTERWORKING_UNSPECIFIED"

- "GWAPP_UNKNOWN_ERROR"
- "RELEASE_BECAUSE_HELD_TIMEOUT"

46.3 Configuring RADIUS Accounting

The the RADIUS Parameters page allows you to enable RADIUS accounting of SIP calls by a RADIUS accounting server. The device can send the accounting messages to the RADIUS server upon call release, call connection and release, or call setup and release.



Notes:

- For RADIUS accounting settings to take effect, you must save the settings to flash memory with a device reset.
- For a description of the RADIUS accounting parameters, see 'RADIUS Parameters' on page 646.

➤ **To configure RADIUS accounting:**

1. Open the RADIUS Parameters page (**Configuration** tab > **VoIP** menu > **SIP Definitions** submenu > **RADIUS Parameters Settings**).

Figure 46-3: RADIUS Accounting Parameters Page

⚡ Enable RADIUS Access Control	Enable
Accounting Server IP Address	0.0.0.0
Accounting Port	1646
RADIUS Accounting Type	At Call Release
AAA Indications	None

2. Configure the parameters as required.
3. Click **Submit**.

The table below describes the RADIUS Accounting CDR attributes included in the communication packets transmitted between the device and a RADIUS server.

Supported RADIUS Accounting CDR Attributes

Attribute Number	Attribute Name	Vendor Specific Attribute (VSA) No.	Purpose	Value Format	Example	AAA
Request Attributes						
1	user-name	-	Account number or calling party number or blank	String up to 15 digits long	5421385747	Start Acc Stop Acc
4	nas-ip-address	-	IP address of the requesting device	Numeric	192.168.14.43	Start Acc Stop Acc
6	service-type	-	Type of service requested	Numeric	1: login	Start Acc Stop Acc

Attribute Number	Attribute Name	Vendor Specific Attribute (VSA) No.	Purpose	Value Format	Example	AAA
26	h323-incoming-conf-id	1	SIP call identifier	Up to 32 octets	-	Start Acc Stop Acc
26	h323-remote-address	23	IP address of the remote gateway	Numeric	-	Stop Acc
26	h323-conf-id	24	H.323/SIP call identifier	Up to 32 octets	-	Start Acc Stop Acc
26	h323-setup-time	25	Setup time in NTP format 1	String	-	Start Acc Stop Acc
26	h323-call-origin	26	The call's originator: Answering (IP) or Originator (PSTN)	String	Answer, Originate etc	Start Acc Stop Acc
26	h323-call-type	27	Protocol type or family used on this leg of the call	String	VoIP	Start Acc Stop Acc
26	h323-connect-time	28	Connect time in NTP format	String	-	Stop Acc
26	h323-disconnect-time	29	Disconnect time in NTP format	String	-	Stop Acc
26	H323-Disconnect-Cause	30	Q.931 disconnect cause code	Numeric	-	Stop Acc
26	h323-gw-id	33	Name of the gateway	String	SIPIDString	Start Acc Stop Acc
26	sip-call-id	34	SIP Call ID	String	abcde@ac.com	Start Acc Stop Acc
26	call-terminator	35	The call's terminator: PSTN-terminated call (Yes); IP-terminated call (No).	String	Yes, No	Stop Acc
30	called-station-id	-	Destination phone number	String	8004567145	Start Acc
31	calling-station-id	-	Calling Party Number (ANI)	String	5135672127	Start Acc Stop Acc
40	acct-status-type	-	Account Request Type (start or stop) Note: 'start' isn't supported on the Calling Card application.	Numeric	1: start, 2: stop	Start Acc Stop Acc
41	acct-delay-time	-	No. of seconds tried in sending a particular record	Numeric	5	Start Acc Stop Acc

Attribute Number	Attribute Name	Vendor Specific Attribute (VSA) No.	Purpose	Value Format	Example	AAA
42	acct-input-octets	-	Number of octets received for that call duration	Numeric	-	Stop Acc
43	acct-output-octets	-	Number of octets sent for that call duration	Numeric	-	Stop Acc
44	acct-session-id	-	A unique accounting identifier - match start & stop	String	34832	Start Acc Stop Acc
46	acct-session-time	-	For how many seconds the user received the service	Numeric	-	Stop Acc
47	acct-input-packets	-	Number of packets received during the call	Numeric	-	Stop Acc
48	acct-opoutput-packets	-	Number of packets sent during the call	Numeric	-	Stop Acc
61	nas-port-type	-	Physical port type of device on which the call is active	String	0: Asynchrono us	Start Acc Stop Acc
Response Attributes						
26	h323-return-code	103	The reason for failing authentication (0 = ok, other number failed)	Numeric	0 Request accepted	Stop Acc
44	acct-session-id	-	A unique accounting identifier – match start & stop	String	-	Stop Acc

Below is an example of RADIUS Accounting, where the non-standard parameters are preceded with brackets:

```
Accounting-Request (361)
user-name = 111
acct-session-id = 1
nas-ip-address = 212.179.22.213
nas-port-type = 0
acct-status-type = 2
acct-input-octets = 4841
acct-output-octets = 8800
acct-session-time = 1
acct-input-packets = 122
acct-output-packets = 220
called-station-id = 201
calling-station-id = 202
// Accounting non-standard parameters:
(4923 33) h323-gw-id =
(4923 23) h323-remote-address = 212.179.22.214
(4923 1) h323-ivr-out = h323-incoming-conf-id:02102944 600a1899
```

```

3fd61009 0e2f3cc5
(4923 30) h323-disconnect-cause = 22 (0x16)
(4923 27) h323-call-type = VOIP
(4923 26) h323-call-origin = Originate
(4923 24) h323-conf-id = 02102944 600a1899 3fd61009 0e2f3cc5
    
```

46.4 Event Notification using X-Detect Header

The device supports the sending of notifications to a remote party notifying the occurrence (or detection) of certain events on the media stream. Event detection and notifications is performed using the SIP X-Detect message header and only when establishing a SIP dialog.

For supporting some events, certain device configurations need to be performed. The table below lists the supported event types (and subtypes) and the corresponding device configurations, if required:

Supported X-Detect Event Types

Events Type	Subtype	Required Configuration
AMD	voice automatic silence unknown beep	EnableDSPIPMDetectors = 1 AMDDTimeout = 2000 (msec) For AMD beep detection, AMDBeepDetectionMode = 1 or 2
CPT	SIT-NC SIT-IC SIT-VC SIT-RO Busy Reorder Ringtone beep	SITDetectorEnable = 1 UserDefinedToneDetectorEnable = 1 Notes: <ul style="list-style-type: none"> ▪ Ensure that the CPT file is configured with the required tone type. ▪ On beep detection, a SIP INFO message is sent with type AMD/CPT and subtype beep. ▪ The beep detection must be started using regular X-detect extension, with AMD or CPT request.
FAX	CED	(IsFaxUsed ≠ 0) or (IsFaxUsed = 0, and FaxTransportMode ≠ 0)
	modem	VxxModemTransportType = 3
PTT	voice-start voice-end	EnableDSPIPMDetectors = 1

The device can detect and report the following Special Information Tones (SIT) types from the PSTN:

- SIT-NC (No Circuit found)
- SIT-IC (Operator Intercept)
- SIT-VC (Vacant Circuit - non-registered number)
- SIT-RO (Reorder - System Busy)

There are additional three SIT tones that are detected as one of the above SIT tones:

- The NC* SIT tone is detected as NC
- The RO* SIT tone is detected as RO
- The IO* SIT tone is detected as VC

The device can map these SIT tones to a Q.850 cause and then map them to SIP 5xx/4xx responses, using the parameters SITQ850Cause, SITQ850CauseForNC, SITQ850CauseForIC, SITQ850CauseForVC, and SITQ850CauseForRO.

Special Information Tones (SITs) Reported by the device

Special Information Tones (SITs) Name	Description	First Tone Frequency Duration		Second Tone Frequency Duration		Third Tone Frequency Duration	
		(Hz)	(ms)	(Hz)	(ms)	(Hz)	(ms)
NC1	No circuit found	985.2	380	1428.5	380	1776.7	380
IC	Operator intercept	913.8	274	1370.6	274	1776.7	380
VC	Vacant circuit (non registered number)	985.2	380	1370.6	274	1776.7	380
RO1	Reorder (system busy)	913.8	274	1428.5	380	1776.7	380
NC*	-	913.8	380	1370.6	380	1776.7	380
RO*	-	985.2	274	1370.6	380	1776.7	380
IO*	-	913.8	380	1428.5	274	1776.7	380

For example:

```
INFO sip:5001@10.33.2.36 SIP/2.0
Via: SIP/2.0/UDP 10.33.45.65;branch=z9hG4bKac2042168670
Max-Forwards: 70
From: <sip:5000@10.33.45.65;user=phone>;tag=1c1915542705
To: <sip:5001@10.33.2.36;user=phone>;tag=WQJNIDDPCOKAPIDSCOTG
Call-ID: AIFHPETLLMVVFWPDXUHD@10.33.2.36
CSeq: 1 INFO
Contact: <sip:2206@10.33.45.65>
Supported: em,timer,replaces,path,resource-priority
Content-Type: application/x-detect
Content-Length: 28
Type= CPT
SubType= SIT-IC
```

The X-Detect event notification process is as follows:

1. For IP-to-Tel or Tel-to-IP calls, the device receives a SIP request message (using the X-Detect header) that the remote party wishes to detect events on the media stream. For incoming (IP-to-Tel) calls, the request must be indicated in the initial INVITE and responded to either in the 183 response (for early dialogs) or in the 200 OK response (for confirmed dialogs).
2. Once the device receives such a request, it sends a SIP response message (using the X-Detect header) to the remote party, listing all supported events that can be detected. The absence of the X-Detect header indicates that no detections are available.
3. Each time the device detects a supported event, the event is notified to the remote party by sending an INFO message with the following message body:
 - Content-Type: application/X-DETECT
 - Type = [AMD | CPT | FAX | PTT...]
 - Subtype = xxx (according to the defined subtypes of each type)

Below is an example of SIP messages using the X-Detect header:

```
INVITE sip:101@10.33.2.53;user=phone SIP/2.0
Via: SIP/2.0/UDP 10.33.2.53;branch=z9hG4bKac5906
```

```

Max-Forwards: 70
From: "anonymous" <sip:anonymous@anonymous.invalid>;tag=1c25298
To: <sip:101@10.33.2.53;user=phone>
Call-ID: 11923@10.33.2.53
CSeq: 1 INVITE
Contact: <sip:100@10.33.2.53>
X- Detect: Request=CPT,FAX
SIP/2.0 200 OK
Via: SIP/2.0/UDP 10.33.2.53;branch=z9hG4bKac5906
From: "anonymous" <sip:anonymous@anonymous.invalid>;tag=1c25298
To: <sip:101@10.33.2.53;user=phone>;tag=1c19282
Call-ID: 11923@10.33.2.53
CSeq: 1 INVITE
Contact: <sip:101@10.33.2.53>
X- Detect: Response=CPT,FAX
INFO sip:101@10.33.2.53;user=phone SIP/2.0
Via: SIP/2.0/UDP 10.33.2.53;branch=z9hG4bKac5906
Max-Forwards: 70
From: "anonymous" <sip:anonymous@anonymous.invalid>;tag=1c25298
To: <sip:101@10.33.2.53;user=phone>
Call-ID: 11923@10.33.2.53
CSeq: 1 INVITE
Contact: <sip:100@10.33.2.53>
X- Detect: Response=CPT,FAX
Content-Type: Application/X-Detect
Content-Length: xxx
Type = CPT
Subtype = SIT
    
```

46.5 Querying Device Channel Resources using SIP OPTIONS

The device reports its maximum and available channel resources in SIP 200 OK responses upon receipt of SIP OPTIONS messages. The device sends this information in the SIP X-Resources header with the following parameters:

- **telchs:** Specifies the total telephone channels and the number of free (available) telephone channels.
- **mediachs:** Specifies the total and the free number of channels associated with media services (e.g., announcements and conferencing). This is applicable only to Mediant 1000.

Below is an example of the X-Resources:

```
X-Resources: telchs= 12/4;mediachs=0/0
```

In the example above, "telchs" specifies the number of available channels and the number of occupied channels (4 channels are occupied and 12 channels are available).

Part X

Diagnostics

47 Syslog and Debug Recordings

Syslog is an event notification protocol that enables a device to send event notification messages across IP networks to event message collectors, also known as Syslog servers. The device contains an embedded Syslog client, which sends error reports / events that it generates to a remote Syslog server using the IP / UDP protocol. This information is a collection of error, warning, and system messages that records every internal operation of the device.

For receiving Syslog messages generated by the device, you can use any of the following Syslog servers:

- **Device's embedded Syslog server:** The device provides an embedded Syslog server, which is accessed through the Web interface. This provides limited Syslog server functionality.
- **Wireshark:** Third-party network protocol analyzer (<http://www.wireshark.org>).
- **Third-party, Syslog server:** Any third-party Syslog server program that enables filtering of messages according to parameters such as priority, IP sender address, time, and date.

47.1 Syslog Message Format

The Syslog message is sent from the device to a Syslog server as an ASCII (American Standard Code for Information Interchange) message. Syslog uses UDP as its underlying transport layer mechanism. By default, UDP port 514 is assigned to Syslog, but this can be changed (see 'Configuring Syslog' on page 583).

Below is an example of a Syslog message:

```
13:10:57.811 : 10.13.4.12 : NOTICE : [S=235][SID:1034099026] (
lgr_flow)(63          ) UdpTransportObject#0- Adding socket event
for address 10.33.2.42:5060 [Time: 04-19-2012@18:29:39]
```

Syslog Message Format Description

Message Item	Description
Message Types	<p>Syslog generates the following types of messages:</p> <ul style="list-style-type: none"> ■ ERROR: Indicates that a problem has been identified that requires immediate handling. ■ WARNING: Indicates an error that might occur if measures are not taken to prevent it. ■ NOTICE: Indicates that an unusual event has occurred. ■ INFO: Indicates an operational message. ■ DEBUG: Messages used for debugging. <p>Notes:</p> <ul style="list-style-type: none"> ■ The INFO and DEBUG messages are required only for advanced debugging. Therefore, by default, they are not sent by the device. ■ When viewing Syslog messages in the Web interface, these message types are color coded.
Message Sequence Number [S=<number>]	<p>Syslog messages are sequentially numbered in the format [S=<number>], for example, "[S=643]".</p> <p>A skip in the number sequence of messages indicates a loss of message packets. For example, in the below Syslog message generation, messages 238 through 300 were not received. In other words, three Syslog messages were lost</p>

Message Item	Description
	(the sequential numbers are indicated below in bold font): <pre> 18:38:14. 52 : 10.33.45.72 : NOTICE: [S=235][SID:1034099026] (lgr_psbrdex)(619) recv <-- DIGIT(0) Ch:0 OnTime:0 InterTime:100 Direction:0 System:1 [File: Line:-1] 18:38:14. 83 : 10.33.45.72 : NOTICE: [S=236][SID:1034099026] (lgr_flow)(620) #0:DIGIT_EV [File: Line:-1] 18:38:14. 83 : 10.33.45.72 : NOTICE: [S=237][SID:1034099026] (lgr_flow)(621) #0:DIGIT_EV [File: Line:-1] 18:38:14.958 : 10.33.45.72 : NOTICE: [S=301][SID:1034099026] (lgr_flow)(625) #0:DIGIT_EV [File: Line:-1] </pre>
Log Number (lgr)(number)	Ignore this number; it has been replaced by the Message Sequence Number (described previously).
Session ID	Automatically assigned (random), unique session identifier (session-id / SID) number per call in the CDR of sent Syslog messages and debug recording packets. This enables you to filter the information (such as SIP, Syslog, and media) according to the SID. <ul style="list-style-type: none"> Gateway/IP-to-IP application: A call session is considered either as a Tel-to-IP leg or an IP-to-Tel leg, where each leg is assigned a unique SID. The benefit of this unique numbering is that it enables you to filter the information (such as SIP, Syslog, and media) according to a specific SID. <p>Note: Forked legs and alternative legs share the same SID.</p>
Message Body	Describes the message.
Timestamp	When the Network Time Protocol (NTP) is enabled, a timestamp string [hour :minutes:seconds] is added to all Syslog messages.

47.1.1 Event Representation in Syslog Messages

The Syslog message events that the device sends are represented by unique abbreviations. An example of an abbreviated event in a Syslog message indicating packet loss (PL) is shown below:

```
Apr  4 12:00:12 172.30.1.14 PL:5 [Code:3a002] [CID:3294] [Time:
20:17:00]
```

The table below lists these unique event abbreviations:

Syslog Error Name Descriptions

Error Abbreviation	Error Name Description
AA	Invalid Accumulated Packets Counter
AC	Invalid Channel ID
AL	Invalid Header Length

Error Abbreviation	Error Name Description
AO	Invalid Codec Type
AP	Unknown Aggregation Payload Type
AR	Invalid Routing Flag Received
AT	Simple Aggregation Packets Lost
CC	Command Checksum Error
CE	Invalid Cell Coder Code
CS	Command Sequence Error
ES	8 sec Timeout Before Disconnect
HO	Host Received Overrun
IA	Invalid AMR Payload
IC	Invalid CID Error
IG	Invalid G723 Code
IP	Invalid payload length
IR	Invalid RTCP Packet
IS	Invalid SID Length
LC	Transmitter Received Illegal Command
LF	Lost Fax Frames In High Speed Mode
LM	Lost Modem Frames In High Speed Mode
MI	Misalignment Error
MR	Modem Relay Is Not Supported
OR	DSP JB Overrun
PH	Packet Header Error
PL	RTP Packet Loss
RB	Counts the number of BFI Frames Received From The Host
RD	No Available Release Descriptor
RO	RTP Reorder
RP	Unknown RTP Payload Type
RS	RTP SSRC Error
UF	Unrecognized Fax Relay Command
AA	Invalid Accumulated Packets Counter
AC	Invalid Channel ID
AL	Invalid Header Length
AO	Invalid Codec Type
AP	Unknown Aggregation Payload Type
AR	Invalid Routing Flag Received

47.1.2 Identifying AudioCodes Syslog Messages using Facility Levels

The device's Syslog messages can easily be identified and distinguished from Syslog messages from other equipment, by setting its Facility level. The Facility levels of the device's Syslog messages are numerically coded with decimal values. Facility level may use any of the "local use" facilities (0 through 7), according to RFC 3164. Implementing Facility levels is useful, for example, if you collect the device's as well as other equipments' Syslog messages on the same server. Therefore, in addition to filtering Syslog messages according to IP address, the messages can be filtered according to Facility level.

The Facility level is configured using the SyslogFacility ini file parameter, which provides the following options:

Syslog Facility Levels

Numerical Value	Facility Level
16 (default)	local use 0 (local0)
17	local use 1 (local1)
18	local use 2 (local2)
19	local use 3 (local3)
20	local use 4 (local4)
21	local use 5 (local5)
22	local use 6 (local6)
23	local use 7 (local7)

Syslog messages begin with a less-than (" $<$ ") character, followed by a number, which is followed by a greater-than (" $>$ ") character. This is optionally followed by a single ASCII space. The number is known as the *Priority* and represents both the Facility level and the Severity level. A Syslog message with Facility level 16 is shown below:

```
Facility: LOCAL0 - reserved for local use (16)
```

47.1.3 Syslog Fields for Automatic Machine Detection

The Syslog message can include information relating to the Automatic Machine Detection (AMD) feature. AMD is used to detect whether a human voice, a fax machine, silence, or beeps have answered the call on the remote side. This feature is applicable only to the Gateway application.

- AMDSignal – this field can acquire one of the following values:
 - voice
 - answer machine
 - silence
 - unknown
- AMDDecisionProbability – probability success that correctly detects answering type

Below is an example of such a Syslog message with AMD information:

```
CallMachine:EVENT_DETECTED_EV - AMDSignal = <type - V/A/S/U>,
AMDDecisionProbability = <percentage> %
```

If there is no AMD detection, the AMDSignal field is shown empty (i.e. AMDSignal =).

47.1.4 SNMP Alarms in Syslog Messages

SNMP alerts are sent to the Syslog server using the following formats:

- **Raised Alarms:** RAISE-ALARM: <Alarm Name>; Textual Description: <Textual Description>; Severity <Alarm Severity>; Source <Alarm Source>; Unique ID: <Alarm Unique ID >.

If additional information exists in the alarm, then these are also added: Additional Info1:/ Additional Info2:/ Additional Info3

The Messages' Severity is as follows:

Syslog Message Severity

ITU Perceived Severity (SNMP Alarm's Severity)	AudioCodes' Syslog Severity
Critical	RecoverableMsg
Major	RecoverableMsg
Minor	RecoverableMsg
Warning	Notice
Indeterminate	Notice
Cleared	Notice

- **Cleared Alarms:** CLEAR-ALARM: <Alarm Name>; Textual Description: <Textual Description>; Severity <Alarm Severity>; Source <Alarm Source>; Unique ID: <Alarm Unique ID >; If exists Additional Info1:/ Additional Info2:/ Additional Info3:

47.2 Configuring Syslog Settings

The procedure below describes how to configure Syslog. This includes defining the Syslog server address as well as selecting the activities on the device (for example, a parameter value change) that you want reported to the server.



Notes:

- For configuring CDR reporting, see 'Configuring CDR Reporting' on page 564.
- For viewing Syslog messages in the Web interface, see 'Viewing Syslog Messages' on page 588.
- For a detailed description on the Syslog parameters, see 'Syslog, CDR and Debug Parameters' on page 630.

➤ **To configure Syslog :**

1. Open the Syslog Settings page (**Configuration** tab > **System** menu > **Syslog Settings**).

Figure 47-1: Syslog Settings Page

▼ Syslog Settings	
Enable Syslog	Enable ▼
Syslog Server IP Address	10.8.2.4
Syslog Server Port	514
Debug Level	5 ▼
▼ Activity Types to Report via 'Activity Log' Messages	
Parameters Value Change	<input type="checkbox"/>
Auxiliary Files Loading	<input type="checkbox"/>
Device Reset	<input type="checkbox"/>
Flash Memory Burning	<input type="checkbox"/>
Device Software Update	<input type="checkbox"/>
Access to Restricted Domains	<input type="checkbox"/>
Non-Authorized Access	<input type="checkbox"/>
Sensitive Parameters Value Change	<input type="checkbox"/>
Login and Logout	<input type="checkbox"/>

2. Enable the Syslog feature by setting the 'Enable Syslog' to **Enable**.
3. Define the Syslog server using the 'Syslog Server IP Address' and 'Syslog Server Port' parameters.
4. Configure the debug level using the 'Debug Level' parameter.
5. Under the 'Activity Types to Report ...' group, select the activities to report.
6. Click **Submit** to apply your changes.

47.3 Configuring Debug Recording

The device enables you to activate debug recording and send debug recording packets to a defined capturing server. When the debug recording is activated, the device duplicates all messages that are sent and/or received by it and then sends them to an external IP address. The debug recording can be done for different types of traffic for example, RTP/RTCP, T.38, ISDN, CAS, and SIP.

Debug recording is used for advanced debugging when you need to analyze internal messages and signals. Debug recording is also useful for recording network traffic in environments where hub or port mirroring is unavailable and for recording internal traffic between two endpoints on the same device.



Note: Debug recording is collected only on the device's OAMP interface.

➤ **To configure and activate debug recording:**

1. Open the Logging Settings page (**Configuration** tab > **System** menu > **Logging** > **Logging Settings**).

Figure 47-2: Logging Settings Page

Debug Recording	
Debug Recording Destination IP	10.13.4.22
Debug Recording Destination Port	925
Debug Recording Status	Start

2. Configure the debug capturing server using the 'Debug Recording Destination IP' and 'Debug Recording Destination Port' parameters.
3. From the 'Debug Recording Status' drop-down list, select **Start** to start the debug recording or **Stop** to end the recording.
4. Click **Submit** to apply your changes.

47.4 Filtering Syslog Messages and Debug Recordings

The device can filter Syslog messages and debug recording (DR) packets, sent by the device to a Syslog server and packet capturing application (such as Wireshark) respectively. This can be useful to reduce CPU consumption and minimize negative impact on VoIP performance.

You can configure up to 30 filtering rules, each based on a selected filtering criteria (e.g., an IP Group). Each filtering criteria can be configured with a range. For example, you can filter Syslog messages for IP Groups 1 through 4. For each filter criteria, you can enable or disable Syslog messages and debug recording.

Debug recording can also be filtered using various filtering criteria such as SIP signaling or signaling and media.

➤ **To configure logging filtering rules:**

1. Open the Logging Filters Table page (**Configuration** tab > **System** menu > **Logging** > **Logging Filters Table**).
2. Click the **Add** button; the Add Record dialog box appears:

Figure 47-3: Logging Filters Table - Add Record Dialog Box

Add Record	
Index	1
Type	Any Filter
Value	
Syslog	Enable
Capture Type	Signaling + Media
<input type="button" value="Submit"/> <input type="button" value="Cancel"/>	

3. Configure the logging filter, as required. See the table below for a description of the parameters.
4. Click **Submit** to save your changes.


Notes:

- To configure the Syslog debug level, use the 'Debug Level' parameter (see 'Configuring Syslog' on page 583).
- The Logging Filters table can also be configured using the table ini file parameter, LoggingFilters.

Logging Filters Table Parameters Description

Parameter	Description
Filter Type CLI: filter-type [LoggingFilters_Type]	Defines the filter criteria. <ul style="list-style-type: none"> ▪ [1] Any (default) ▪ [2] Trunk ID = Filters according to a specified Trunk ID (applicable only to the Gateway application). ▪ [3] Trunk Group ID = Filters according to a specified Trunk Group ID (Applicable only to the Gateway/IP-to-IP application). ▪ [4] Trunk & B-channel = Filters according to a specified Trunk and B-channel (applicable only to the Gateway/IP-to-IP application). ▪ [5] FXS or FXO = Filters according to a specified FXS or FXO port. ▪ [6] Tel-to-IP = Filters according to a specified Tel-to-IP routing rule listed in the Outbound IP Routing table (applicable only to the Gateway/IP-to-IP application). ▪ [7] IP-to-Tel = Filters according to a specified IP-to-Tel routing rule listed in the Inbound IP Routing table (applicable only to the Gateway/IP-to-IP application). ▪ [8] IP Group = Filters according to a specified IP Group ID listed in the IP Group table. ▪ [9] SRD = Filters according to a specified SRD ID listed in the SRD table. ▪ [12] User = Filters according to a specified user defined by username or user@host. ▪ [13] IP Trace = Filters according to a specified IP network trace wireshark-like expression. For a detailed description on configuring IP traces, see 'Filtering IP Network Traces' on page 587.
Value CLI: value [LoggingFilters_Value]	Defines the value of the selected filtering type in the 'Filter Type' parameter. The value can be the following: <ul style="list-style-type: none"> ▪ A single value ▪ A range, using a hyphen "-" between the two values, e.g., "1-3" ▪ Multiple, non-contiguous values, using commas "," between each value, e.g., "1,3,9" ▪ Trunks and FXO/FXS pertaining to a module, using the syntax module number/port or port, for example: <ul style="list-style-type: none"> ▪ "1/2", means module 1, port 2 ▪ "1/[2-4]", means module 1, ports 2 through 4 ▪ Any to indicate all ▪ For IP trace expressions, see e 'Filtering IP Network Traces' on page 587
Syslog [LoggingFilters_Syslog]	Enables Syslog messages for the defined logging filter: <ul style="list-style-type: none"> ▪ [0] Disable (default) ▪ [1] Enable

Parameter	Description
Capture Type [LoggingFilters_CaptureType]	Enables debug recordings for the defined logging filter and defines what to record: <ul style="list-style-type: none"> ▪ [0] None (default) ▪ [1] Signaling = Information related to signaling such as SIP signaling messages, Syslog, and CDR. ▪ [2] Signaling & Media = Signaling and media (RTP/RTCP/T.38). ▪ [3] Signaling & Media & PCM = Signaling, media, and PCM (voice signals from and to TDM). ▪ [4] PSTN trace = ISDN and CAS traces - applicable only for Trunk-related filters.

47.4.1 Filtering IP Network Traces

You can filter Syslog and debug recording messages for IP network traces, by setting the 'Filter Type' parameter to **IP Trace** in the Logging Filters table. IP traces are used to record any IP stream that is not associated with media (RTP/RTCP), according to destination and/or source IP address, or port and Layer-4 protocol (UDP, TCP or any other IP type as defined by <http://www.iana.com>).

When the **IP Trace** option is selected, only the 'Value' parameter is applicable; the 'Syslog' and 'Capture Type' parameters are not relevant. The 'Value' parameter configures the Wireshark-like filtering expressions for your IP trace. The following Wireshark-like expressions are supported:

Supported Wireshark-like Expressions for 'Value' Parameter

Expression	Description
ip.src, ip.dst	Source and destination IP address
ip.addr	IP address - up to two IP addresses can be entered
ip.proto	IP protocol type (PDU) entered as an enumeration value (e.g., 1 is ICMP, 6 is TCP, 17 is UDP)
udp, tcp, icmp, sip, ldap, http, https	Single expressions for protocol type
udp.port, tcp.port	Transport layer
udp.srcport, tcp.srcport	Transport layer for source port
udp.dstport, tcp.dstport	Transport layer for destination port
and, &&, ==, <, >	Between expressions

Below are examples of configured expressions for the 'Value' parameter:

- udp && ip.addr==10.8.6.55
- ip.src==10.8.6.55 && udp.port>=5000 and udp.port<6000
- ip.dst==10.8.0.1/16
- ip.addr==10.8.6.40

For conditions requiring the "or" / "|" expression, add multiple table rows. For example, the Wireshark condition "(ip.src == 1.1.1.1 or ip.src == 2.2.2.2) and ip.dst == 3.3.3.3" can be configured using the following two table row entries:

1. ip.src == 1.1.1.1 and ip.dst == 3.3.3.3
2. ip.src == 2.2.2.2 and ip.dst == 3.3.3.3



Note: If the 'Value' field is left empty, the device will record all IP traffic types.

47.5 Viewing Syslog Messages

You can use the following tools to view the Syslog messages sent by the device:

- Web interface's Message Log page (see below).
- Any third-party Syslog server (e.g., Wireshark).

The procedure below describes how to view Syslog messages in the Web interface.



Notes:

- It's not recommended to keep a Message Log session open for a prolonged period. This may cause the device to overload. For prolonged (and detailed) debugging, use an external Syslog server.
- You can select the Syslog messages in this page, and copy and paste them into a text editor such as Notepad. This text file (*txt*) can then be sent to AudioCodes Technical Support for diagnosis and troubleshooting.

➤ **To activate the Web interface's Message Log:**

1. Enable Syslog (see 'Configuring Syslog' on page 583).
2. Open the Message Log page (**Status & Diagnostics** tab > **System Status** menu > **Message Log**); the Message Log page is displayed and the log is activated.

Figure 47-4: Message Log Page

```

Log is Activated

11d:14h:43m:9s ( lgr_psbrdex) (2662 ) recv <-- ON_HOOK Ch:1
11d:14h:43m:9s ( lgr_flow) (2663 ) #1:ON_HOOK_EV
11d:14h:43m:9s ( lgr_flow) (2664 ) | #1:ON_HOOK_EV
11d:14h:43m:9s ( lgr_psbrdif) (2665 ) #1:cpDigitMapHndlr_Stop - Stopped (0)
11d:14h:43m:9s ( lgr_psbrdif) (2666 ) #1:CloseChannel: ChannelNum=1
11d:14h:43m:9s ( lgr_psbrdif) (2667 ) Open channel: IsVoiceOn: 1, IsT38On: 1, IsVbdOn: 0, I
11d:14h:43m:9s ( lgr_psbrdif) (2668 ) #1:OpenChannel:on Trunk -1 BChannel:1 CID=1 with Voice
11d:14h:43m:9s ( lgr_psbrdif) (2669 ) #1:OpenChannel VoiceVolume= 0, DTMFVolume = -11, Input
11d:14h:43m:9s ( lgr_psbrdif) (2670 ) OpenChannel, CoderType = 15, Interval = 4, M = 1
11d:14h:43m:9s ( lgr_psbrdif) (2671 ) #1:FAXtransportType = 1
11d:14h:43m:9s ( lgr_psbrdif) (2672 ) #1:ConfigFaxModemChannelParams NSEMode=0, CNGDetMode=
11d:14h:43m:9s ( lgr_psbrdif) (2673 ) Detectors: Amd:0, Ans:0 En:0 IBScmd:0xal
11d:14h:43m:9s ( lgr_psbrdif) (2674 ) #1:PSOSBoardInterface::StopPlayTone- Called
11d:14h:43m:9s ( lgr_psbrdex) (2675 ) recv <-- OFF_HOOK Ch:1
11d:14h:43m:9s ( lgr_flow) (2676 ) #1:OFF_HOOK_EV
11d:14h:43m:9s ( lgr_flow) (2677 ) | #1:OFF_HOOK_EV
11d:14h:43m:9s ( lgr_psbrdif) (2678 ) UpdateChannelParams, Channel 1
11d:14h:43m:9s ( lgr_psbrdif) (2679 ) #1:ConfigFaxModemChannelParams NSEMode=0, CNGDetMode=
11d:14h:43m:9s ( lgr_psbrdif) (2680 ) ActivateDigitMap for channel : 1, MaxDialStringLength
    
```

The displayed logged messages are color-coded as follows:

- Yellow - fatal error message
- Blue - recoverable error message (i.e., non-fatal error)
- Black - notice message

➤ **To stop and clear the Message Log:**

- Close the Message Log page by accessing any another page in the Web interface.

47.6 Collecting Debug Recording Messages

To collect debug recording packets, the open source program Wireshark is used. AudioCodes proprietary plug-in files for Wireshark, which are shipped in your software kit, are also required.

Notes:



- The default debug recording port is 925. You can change the port in Wireshark (**Edit menu > Preferences > Protocols > AC DR**).
- The plug-ins are per major software release and are applicable to Wireshark Ver. 1.6.2.
- The plug-ins are backward compatible.
- From Wireshark Ver. 99.08, the tpcnp.dat file must be located in the folder, ...WireShark\tpncp.

➤ **To install Wireshark and the plug-ins for debug recording:**

1. Install Wireshark on your computer. The Wireshark program can be downloaded from <http://www.wireshark.org>.
2. Copy the supplied AudioCodes plug-in files to the directory in which you installed Wireshark, as follows:

Copy this file	To this folder
...\dtds\cdr.dtd	Wireshark\dtds\
...\plugins\1.6.2*.dll	Wireshark\plugins\1.6.2
...\tpncp\tpncp.dat	Wireshark\tpncp

3. Start Wireshark.
4. In the Filter field, type "acdr" (see the figure below) to view the debug recording messages. Note that the source IP address of the messages is always the OAMP IP address of the device.

The device adds the header "AUDIOCODES DEBUG RECORDING" to each debug recording message, as shown below:

The screenshot shows the Wireshark interface. The filter field contains 'acdr'. The packet list pane shows several packets with source IP 10.33.1.5 and destination IP 10.33.2.30. The packet details pane shows a 'Proprietary Header' section with the following content:

```

AUDIOCODES: DEBUG RECORDING
Version: 0x05
Time Stamp: b500edd9(3036.736985 sec)
Sequence Number: 358
Source ID: -1
Dest ID: -1
Extra Data: 0x00
Trace Point: System (6)
Media Type: System Info (5)
Header Extension Len: 0
Session ID: 1131483963
Syslog message: LOCALO.NOTICE: ( sip_stack)(482 ) SIPCall(#246) changes state from Cancelling to Idle [File: Lin
1000 0... = Facility: LOCALO - reserved for local use (16)
... .101 = Level: NOTICE = normal but significant condition (5)
Message: ( sip_stack)(482 ) SIPCall(#246) changes state from Cancelling to Idle [File: Line:-1]
    
```

For ISDN trace messages, the additional header, "NetBricks Trace" is added below the "AUDIOCODES DEBUG RECORDING" header, as shown in the example below:

```
AUDIOCODES DEBUG RECORDING
NetBricks Trace
System time: 3559
  Direction: Message received from internal server queue (73)
From (Entity origination ID): DL_D (DL LAPD Q.921) (100)
  To (Entity destination ID): PH_D (D channel physical) (68)
  Primitive code: 67
  NAI (Network Access ID): 0 -> number of trunk
  SAPI: 1
  Connection ID: 0
  Congestion flag: 0
  Allocated message: 2
  Allocated buffer: 3
  Allocated timer cell: 141
  IT Message stack counter: 120
  IT Buffer stack counter: 120
  Message congestion counter: 0
  Buffer congestion counter: 0
  IT Stack message congestion counter: 0
  IT Stack buffer congestion counter: 0
  Pointer to message: 689
  Pointer to buffer: 0
  Data size: 33
  Link Access Procedure, Channel D (LAPD)
  Q.931
    Protocol discriminator: Q.931
    Call reference value length: 2
    Call reference flag: Message sent from originating side
    Call reference value: 0300 - > can be used as a filter to
identify entire ISDN call
    Message type: SETUP (0x05)
    Bearer capability
    Channel identification
    Calling party number: '201'
    Called party number: '102'
    Sending complete
```

For CAS trace messages, the additional header "CAS Trace" is added below the "AUDIOCODES DEBUG RECORDING" header, as shown in the example below:

```
AUDIOCODES DEBUG RECORDING
CAS Trace
Timer: 1145504439
From: DSP (0)
Current State: 7
Event: EV_DIAL_ENDED (15)
Next State: -1
Function Use: Unknown (-1)
  Parameter 1: -1
  Parameter 2: -1
  Parameter 3: -1
Trunk Number: 3
BChannel Number: 23
Call Handle: 0
```

48 Self-Testing

The device features the following self-testing modes to identify faulty hardware components:

- **Detailed Test (Configurable):** This test verifies the correct functioning of the different hardware components on the device. This test is done when the device is taken out of service (i.e., not in regular service for processing calls). The test is performed on startup when initialization of the device completes.

To enable this test, set the ini file parameter, EnableDiagnostics to 1 or 2, and then reset the device. Upon completion of the test and if the test fails, the device sends information on the test results of each hardware component to the Syslog server.

The following hardware components are tested:

- RAM - when EnableDiagnostics = 1 or 2
- Flash memory - when EnableDiagnostics = 1 or 2
- DSPs - when EnableDiagnostics = 1 or 2
- Physical Ethernet ports - when EnableDiagnostics = 1 or 2
- Analog interfaces - when EnableDiagnostics = 1 or 2



Notes:

- To return the device to regular operation and service, disable the test by setting the ini file parameter, EnableDiagnostics to 0, and then reset the device.
- While the test is enabled, ignore errors sent to the Syslog server.

- **Startup Test (automatic):** This hardware test has minor impact in real-time. While this test is executed, the regular operation of the device is disabled. If an error is detected, an error message is sent to the Syslog.

Reader's Notes

49 Analog Line Testing

The device can test the telephone lines connected to its FXS and FXO ports, using the SNMP `acAnalogFxsLineTestTable` table and `acAnalogFxoLineTestTable` table respectively. These tests provide various line measurements. In addition to these tests (detailed below), a keep-alive test is also done every 100 msec on each of the analog ports to detect communication problems with the analog equipment and overheating of the FXS ports.

- FXS line tests:
 - Hardware revision number
 - Temperature (above or below limit, only if a thermometer is installed)
 - Hook state
 - Coefficients checksum
 - Message waiting indication status
 - Ring state
 - Reversal polarity state
- FXO line tests:
 - Line Current (mA)
 - Line Voltage (V)
 - Hook (0 = on-hook; 1 = off-hook)
 - Ring (0 - Off; 1 - On)
 - Line Connected (0 = Disconnected; 1 = Connected)
 - Polarity state (0 = Normal; 1 = Reversed, 2 = N/A)
 - Line polarity (0 = Positive; 1 = Negative)
 - Message Waiting Indication (0 = Off; 1 = On)



Note: Use the Analog Line testing mechanism only for monitoring and never when there are calls in progress.

Reader's Notes

50 Testing SIP Signaling Calls

A simulated endpoint can be configured on the device to test SIP signaling of calls between it and a remote destination. This feature is useful in that it can remotely verify SIP message flow without involving the remote end side in the debug process. The SIP test call simulates the SIP signaling process - call setup, SIP 1xx responses, and through to completing the SIP transaction with a 200 OK.

The test call sends Syslog messages to a Syslog server, showing the SIP message flow, DTMF signals, termination reasons, as well as voice quality statistics.

50.1 Configuring Test Call Endpoints

The Test Call table enables you to test the SIP signaling (setup and registration) of calls and media (DTMF signals) between a simulated phone on the device and a remote endpoint. These tests involve both incoming and outgoing calls, where the test endpoint can be configured as the caller or called party. Test calls can be dialed automatically at a user-defined interval and/or manually when required. The simulated phone and remote endpoints are defined as SIP URIs (user@host) and the remote destination can be defined as an IP Group, IP address, or according to an Outbound IP Routing rule. You can also enable automatic registration of the endpoint.

When a SIP test call is initiated, the device generates a SIP INVITE towards the remote endpoint (e.g., a SIP proxy server or softswitch). It simulates the SIP call setup process, managing SIP 1xx responses and completing the SIP transaction with a 200 OK.



Notes:

- By default, you can configure up to five test calls. This maximum can be increased by installing the relevant Software License Key. For more information, contact your AudioCodes sales representative.
- The Test Call Endpoint table can also be configured using the table ini file parameter Test_Call (see 'SIP Test Call Parameters' on page 629).

➤ To configure test calls:

1. Open the Test Call Table page (**Configuration** tab > **System** menu > **Test Call** > **Test Call Table**).
2. Click the **Add** button; the following dialog box appears:

Figure 50-1: General Tab of Test Call Table

General	Authentication	Test Settings
Index	<input type="text" value="0"/>	
Endpoint URI	<input type="text"/>	
Called URI	<input type="text"/>	
Route By	GW Tel2IP ▼	
IP Group ID	<input type="text" value="-1"/>	
Destination Address	<input type="text"/>	
Destination Transport Type	▼	
SRD	<input type="text" value="0"/>	
Application Type	GW & IP2IP ▼	
		<input type="button" value="Submit"/> <input type="button" value="Cancel"/>

3. Configure the test endpoint parameters as desired. See the table below for a description of these parameters.
4. Click **Submit** to apply your settings.

Test Call Table Parameters

Parameter	Description
General Tab	
Endpoint URI [Test_Call_EndpointURI]	<p>Defines the endpoint's URI. This can be defined as a user or user@host. The device identifies this endpoint only by the URI's user part. The URI's host part is used in the SIP From header in REGISTER requests.</p> <p>The valid value is a string of up to 150 characters. By default, this parameter is not configured.</p>
Called URI [Test_Call_CalledURI]	<p>Defines the destination (called) URI (user@host).</p> <p>The valid value is a string of up to 150 characters. By default, this parameter is not configured.</p>
Route By [Test_Call_Destination]	<p>Defines the type of routing method. This applies to incoming and outgoing calls.</p> <ul style="list-style-type: none"> ▪ [0] GW Tel2IP = (Default) Calls are matched by (or routed to) an SRD and Application type (defined in the SRD and Application Type parameters below). ▪ [1] IP Group = Calls are matched by (or routed to) an IP Group ID. ▪ [2] Dest Address = Calls are matched by (or routed to) an SRD and application type. <p>Notes:</p> <ul style="list-style-type: none"> ▪ For REGISTER messages, the option [0] cannot be used as the routing method. ▪ For REGISTER messages, if option [1] is used, only Server-type IP Groups can be used.
IP Group ID [Test_Call_IPGroupID]	<p>Defines the IP Group ID to which the test call is sent or from which it is received.</p> <p>Notes:</p> <ul style="list-style-type: none"> ▪ This parameter is applicable only if option [1] is configured for the 'Route By' parameter. ▪ This IP Group is used for incoming and outgoing calls.
Destination Address [Test_Call_DestinationAddress]	<p>Defines the destination host. This can be defined as an IP address[:port] or DNS name[:port].</p> <p>Note: This parameter is applicable only if the 'Route By' parameter is set to [2] (Dest Address).</p>
Destination Transport Type [Test_Call_DestinationTransportType]	<p>Defines the transport type for outgoing calls.</p> <ul style="list-style-type: none"> ▪ [-1] Not configured (default) ▪ [0] UDP ▪ [1] TCP ▪ [2] TLS <p>Note: This parameter is applicable only if the 'Route By' parameter is set to [2] (Dest Address).</p>

Parameter	Description
SRD [Test_Call_SRD]	Defines the SRD for the endpoint. The default is SRD 0. Note: This parameter is applicable only if the 'Route By' parameter is set any option except [1] (IP Group).
Application Type [Test_Call_ApplicationType]	Defines the application type for the endpoint. This, in effect, associates the IP Group and SRD to a specific SIP interface. <ul style="list-style-type: none"> [0] GW & IP2IP (default)
Authentication Tab	
Note: These parameters are applicable only if the test endpoint is set to Caller (see the 'Call Party' parameter).	
Auto Register [Test_Call_AutoRegister]	Enables automatic registration of the endpoint. The endpoint can register to the device itself or to the 'Destination Address' or 'IP Group ID' parameter settings (see above). <ul style="list-style-type: none"> [0] False (default) [1] True
User Name [Test_Call_UserName]	Defines the authentication username. By default, no username is defined.
Password [Test_Call_Password]	Defines the authentication password. By default, no password is defined.
Test Settings Tab	
Call Party [Test_Call_CallParty]	Defines whether the test endpoint is the initiator or receiving side of the test call. <ul style="list-style-type: none"> [0] Caller (default) [1] Called
Maximum Channels for Session [Test_Call_MaxChannels]	Defines the maximum number of concurrent channels for the test session. For example, if you have configured an endpoint "101" and you set this parameter to "3", the device automatically creates three simulated endpoints - "101", "102" and "103" (i.e., consecutive endpoint URIs are assigned). The default is 1.
Call Duration [Test_Call_CallDuration]	Defines the call duration (in seconds). The valid value is -1 to 100000. The default is 20. A value of 0 means infinite. A value of -1 means that the parameter value is automatically calculated according to the values of the 'Calls per Second' and 'Maximum Channels for Session' parameters. Note: This parameter is applicable only if 'Call Party' is set to Caller .
Calls per Second [Test_Call_CallsPerSecond]	Defines the number of calls per second. Note: This parameter is applicable only if 'Call Party' is set to Caller .

Parameter	Description
Test Mode [Test_Call_TestMode]	<p>Defines the test session mode.</p> <ul style="list-style-type: none"> ▪ [0] Once = (Default) The test runs until the lowest value between the following is reached: <ul style="list-style-type: none"> ✓ Maximum channels is reached for the test session, configured by 'Maximum Channels for Session'. ✓ Call duration ('Call Duration') multiplied by calls per second ('Calls per Second'). ✓ Test duration expires, configured by 'Test Duration'. ▪ [1] Continuous = The test runs until the configured test duration is reached. If it reaches the maximum channels configured for the test session (in the 'Maximum Channels for Session'), it waits until the configured call duration of a currently established tested call expires before making the next test call. In this way, the test session stays within the configured maximum channels. <p>Note: This parameter is applicable only if 'Call Party' is set to Caller.</p>
Test Duration [Test_Call_TestDuration]	<p>Defines the test duration (in minutes). The valid value is 0 to 100000. The default is 0 (i.e., unlimited).</p> <p>Note: This parameter is applicable only if 'Call Party' is set to Caller.</p>
Play [Test_Call_Play]	<p>Enables playing a user-defined DTMF signal to the answered side of the call.</p> <ul style="list-style-type: none"> ▪ [0] Disable (default) ▪ [1] DTMF <p>To configure the played DTMF signal, see 'Configuring DTMF Tones for Test Calls' on page 600.</p> <p>Notes:</p> <ul style="list-style-type: none"> ▪ To configure the DTMF signaling type (e.g., out-of-band or in-band) use the 'DTMF Transport Type' parameter (see 'Configuring DTMF Transport Types' on page 171). ▪ This parameter is applicable only if 'Call Party' is set to Caller.
Schedule Interval [Test_Call_ScheduleInterval]	<p>Defines the interval (in minutes) between automatic outgoing test calls. The valid value range is 0 to 100000. The default is 0 (i.e., scheduling is disabled).</p> <p>Note: This parameter is applicable only if 'Call Party' is set to Caller.</p>

50.1.1 Starting, Stopping and Restarting Test Calls

The procedure below describes how to start, stop, and restart test calls.

➤ **To start, stop, and restart a test call:**

1. In the Test Call table, select the required test call entry; the **Actions** button appears above the table.
2. From the **Actions** drop-down list, choose the required command:
 - **Dial:** starts the test call (this action is applicable only if the test call party is the caller).
 - **Drop Call:** stops the test call.
 - **Restart:** ends all established calls and then starts the test call session again.

The status of the test call is displayed in the 'Test Status' field of the Test Call table:

- "Idle": test call is not active.
- "Scheduled": test call is planned to run (according to 'Schedule Interval' parameter settings)
- "Running": test call has been started (i.e., the **Dial** command was clicked)
- "Receiving": test call has been automatically activated by calls received for the test call endpoint from the remote endpoint (when all these calls end, the status returns to "Idle")
- "Terminating": test call is in the process of terminating the currently established calls (this occurs if the **Drop Call** command is clicked to stop the test)
- "Done": test call has been successfully completed (or was prematurely stopped by clicking the **Drop Call** command)

A more detailed description of this field is displayed below the table when you click the **Show/Hide** button (see 'Viewing Test Call Statistics' on page 599).

50.1.2 Viewing Test Call Statistics

In addition to viewing a brief status description of the test call in the 'Test Status' field (as described in 'Starting, Stopping and Restarting Test Calls' on page 598), you can also view a more detailed status description which includes test call statistics.

➤ To view statistics of a test call:

1. Open the Test Call Table page (**Configuration** tab > **System** menu > **Test Call** > **Test Call Table**).
2. Select the test call table entry whose call statistics you want to view.
3. Click the **Show/Hide** button; the call statistics are displayed in the **Test Statistics** pane located below the table, as shown in the figure below:

Figure 50-2: Viewing Test Call Statistics

The screenshot shows the 'Test Call Table' interface. At the top, there are buttons for 'Add +', 'Edit', 'Delete -', and 'Action'. A 'Show/Hide' button is located in the top right corner. Below these buttons is a table with the following columns: Index, Endpoint URI, Called URI, Route By, IP Group ID, Destination Address, SRD, Application Type, Call Party, and Test Status. The table contains one row with the following data: Index: 0, Endpoint URI: 101, Called URI: 102, Route By: GW Tel2IP, IP Group ID: -1, Destination Address: 10.13.4.12, SRD: 0, Application Type: GW & IP2IP, Call Party: Caller, Test Status: Running. Below the table, there is a 'Test Call Table #0' section with detailed parameters for the selected test call. An arrow points to the 'Test Statistics' section, which displays the following information:

Test Statistics	
Elapsed Time [HH:MM:SS]: 00:00:11	Active Calls: 2
Call Attempts: 4	Total Established Calls: 2
Total Failed Attempts: 2	Remote Disconnections Count: 0
Test Status: Running	Average CPS:
Detailed Status: Running (Calls: 2, ASR: 50%)	

The 'Test Statistics' pane displays the following test session information:

- **Elapsed Time:** Duration of the test call since it was started (or restarted).
- **Active Calls:** The number of currently active test calls.
- **Call Attempts:** The number of calls that were attempted.
- **Total Established Calls:** The total number of calls that were successfully established.
- **Total Failed Attempts:** The total number of calls that failed to be established.

- **Remote Disconnections Count:** Number of calls that were disconnected by the remote side.
- **Average CPS:** The average calls per second.
- **Test Status:** Displays the status (brief description) as displayed in the 'Test Status' field (see 'Starting, Stopping and Restarting Test Calls' on page 598).
- **Detailed Status:** Displays a detailed description of the test call status:
 - "Idle": The test call is currently not active.
 - "Scheduled - Established Calls: <established calls>, ASR: <%>": The test call is planned to run (according to 'Schedule Interval' parameter settings) and also shows the following summary of completed test calls:
 - ◆ Total number of test calls that were established.
 - ◆ Number of successfully answered calls out of the total number of calls attempted (ASR).
 - "Running (Calls: <number of active calls>, ASR: <%>)": The test call has been started (i.e., the **Dial** command was clicked) and shows the following:
 - ◆ Number of currently active test calls.
 - ◆ Number of successfully answered calls out of the total number of calls attempted (Answer Seizure Ratio or ASR).
 - "Receiving (<number of active calls>)": The test call has been automatically activated by calls received for this configured test call endpoint from the configured remote endpoint. When all these calls terminate, the status returns to "Idle".
 - "Terminating (<number of active calls>)": The **Drop Call** command has been clicked to stop the test call and the test call is in the process of terminating the currently active test calls.
 - "Done - Established Calls: <established calls>, ASR: <%>": The test call has been successfully completed (or was prematurely stopped by clicking the **Drop Call** command) and shows the following:
 - ◆ Total number of test calls that were established.
 - ◆ Number of successfully answered calls out of the total number of calls attempted (ASR).



Note: On the receiving side, when the first call is accepted in "Idle" state, statistics are reset.

50.2 Configuring DTMF Tones for Test Calls

By default, no DTMF signal is played to an answered test call (incoming or outgoing). However, you can enable this per configured test call in the Test Call table (see 'Configuring Test Call Endpoints' on page 595). If enabled, the default DTMF signal that is played is "3212333". You can change this as described below.



Notes:

- The DTMF signaling type (e.g., out-of-band or in-band) can be configured using the 'DTMF Transport Type' parameter. For more information, see 'Configuring DTMF Transport Types' on page 171.
- To generate DTMF tones, the device's DSP resources are required.

➤ **To configure the played DTMF signal to answered test call:**

1. Open the Test Call Settings page (**Configuration** tab > **System** menu > **Test Call** > **Test Call Settings**).


Test Call DTMF String	3212333
-----------------------	---------

2. In the 'Test Call DTMF String' field, enter the DTMF string (up to 15 digits).
3. Click **Submit**.

50.3 Configuring Basic Test Call

The Basic Test Call feature tests incoming Gateway / IP-to-IP calls from a remote SIP endpoint to a simulated test endpoint on the device. The only required configuration is to assign a prefix number (*test call ID*) to the simulated endpoint. All incoming calls with this called (destination) prefix number is identified as a test call and sent to the simulated endpoint. The figure below displays a basic test call example.

Figure 50-3: Incoming Test Call Example



➤ **To configure basic call testing:**

1. Open the Test Call Settings page (**Configuration** tab > **System** menu > **Test Call** > **Test Call Settings**).

Figure 50-4: Test Call Settings Page

Test Call ID	<input type="text"/>
SBC Test ID	<input type="text"/>

2. In the 'Test Call ID' field, enter a prefix for the simulated endpoint.
3. Click **Submit** to apply your settings.



Notes:


- The Basic Test Call feature tests incoming calls only and is initiated only upon receipt of incoming calls with the configured prefix.
- For a full description of this parameter, see 'SIP Test Call Parameters' on page 629.
- This call test is done on all SIP interfaces.

50.4 Test Call Configuration Examples

Below are a few examples of test call configurations.

- **Single Test Call Scenario:** This example describes the configuration of a simple test call between a simulated test endpoint on the device and a remote endpoint.

Figure 50-5: Single Test Call Example




- Test Call table configuration:
 - ◆ Endpoint URI: "101"
 - ◆ Called URI: "201"
 - ◆ Route By: Dest Address
 - ◆ Destination Address: "10.30.40.01"
 - ◆ Call Party: Caller
 - ◆ Test Mode: Once (default)

Alternatively, if you want to route the test call using the Outbound IP Routing table for the Gateway / IP-to-IP application, configure the following:

- Test Call table configuration:
 - ◆ Endpoint URI: 101@10.0.0.1
 - ◆ Route By: GW Tel2IP
 - ◆ Called URI: [201@10.30.40.1](#)
 - ◆ Call Party: Caller
- Outbound IP Routing table configuration:
 - ◆ Dest. Phone Prefix: 201 (i.e., the Called URI user-part)
 - ◆ Source Phone Prefix: 101 (i.e., the Endpoint URI user-part)
 - ◆ Dest. IP Address: 10.30.40.1

- Batch Test Call Scenario:** This example describes the configuration of a batch test call setup for scheduled and continuous call testing of multiple endpoints. The test call is done between two AudioCodes devices - Device A and Device B - with simulated test endpoints. This eliminates the need for phone users, who would otherwise need to answer and end calls many times for batch testing. The calls are initiated from Device A, where Device B serves as the remote answering endpoint.


Figure 50-6: Batch Test Call Example



- Test Call table configuration at Device A:
 - ◆ Endpoint URI: "101"
 - ◆ Called URI: "201"
 - ◆ Route By: Dest Address
 - ◆ Destination Address: "10.13.4.12"
 - ◆ Call Party: Caller
 - ◆ Maximum Channels for Session: "3" (this setting configures three endpoints - "101", "102" and "103")
 - ◆ Call Duration: "5" (seconds)
 - ◆ Calls per Sec: "1"
 - ◆ Test Mode: Continuous
 - ◆ Test Duration: "3" (minutes)
 - ◆ Schedule Interval: "180" (minutes)
- Test Call table configuration at Device B:
 - ◆ Endpoint URI: "201"
 - ◆ Call Party: Caller
 - ◆ Maximum Channels for Session: "3" (this setting configures three endpoints - "201", "202" and "203")

- **Registration Test Call Scenario:** This example describes the configuration for testing the registration and authentication (i.e., username and password) process of a simulated test endpoint on the device with an external proxy/registrar server. This is useful, for example, for verifying that endpoints located in the LAN can register with an external proxy and subsequently, communicate with one another.

Figure 50-7: Test Call Registration Example



This example assumes that you have configured your device for communication between LAN phone users such as IP Groups to represent the device (10.13.4.12) and the proxy server, and IP-to-IP routing rules to route calls between these IP Groups.

- Test Call table configuration:
 - ◆ Endpoint URI: "101"
 - ◆ Called URI: "itsp"
 - ◆ Route By: Dest Address
 - ◆ Destination Address: "10.13.4.12" (this is the IP address of the device itself)
 - ◆ Auto Register: Enable
 - ◆ User Name: "testuser"
 - ◆ Password: "12345"
 - ◆ Call Party: Caller

Part XI

Appendix

51 Dialing Plan Notation for Routing and Manipulation

The device supports flexible dialing plan notations for denoting the prefix and/or suffix source and/or destination numbers and SIP URI user names in the routing and manipulation tables.

Dialing Plan Notations for Prefixes and Suffixes

Notation	Description
x (letter "x")	Denotes any single digit.
# (pound symbol)	<ul style="list-style-type: none"> When used at the end of a prefix, it denotes the end of a number. For example, 54324xx# represents a 7-digit number that starts with the digits 54324. When used anywhere in the suffix, it is part of the number. For example, (3#45) can represent the number string, 123#45.
* (asterisk symbol)	<ul style="list-style-type: none"> When used in the prefix, it denotes any number. When used in the suffix, it is part of the number. For example, (3*45) can represent the number string, 123*45.
\$ (dollar sign)	<p>Denotes an empty prefix for incoming IP calls that do not have a user part in the Request-URI, or for incoming Tel calls that do not have a called or calling number. This is used for the following matching criteria:</p> <ul style="list-style-type: none"> Source and Destination Phone Prefix Source and Destination Username Source and Destination Calling Name Prefix

Range of Digits

Notes:

- Dial plans denoting a prefix that is a range must be enclosed in square brackets, e.g., **[4-8]** or **23xx[456]**.
- Dial plans denoting a prefix that is not a range is not enclosed, e.g., **12345#**.
- Dial plans denoting a suffix must be enclosed in parenthesis, e.g., **(4)** and **(4-8)**.
- Dial plans denoting a suffix that include multiple ranges, the range must be enclosed in square brackets, e.g., **(23xx[4,5,6])**.
- An example for entering a combined prefix and suffix dial plan - assume you want to match a rule whose destination phone prefix is 4 to 8, and suffix is 234, 235, or 236. The entered value would be the following: **[4-8](23[4,5,6])**.

[n-m] or (n-m)

Represents a range of numbers, for example:

- To depict numbers from 5551200 to 5551300:
 - ✓ Prefix: **[5551200-5551300]#**
 - ✓ Suffix: **(5551200-5551300)**
- To depict numbers from 123100 to 123200:
 - ✓ Prefix: **123[100-200]**
 - ✓ Suffix: **(123[100-200])**
- To depict prefix and suffix numbers together:
 - ✓ 03(100): for any number that starts with 03 and ends with 100.
 - ✓ [100-199](100,101,105): for a number that starts with 100 to 199 and ends with 100, 101 or 105.
 - ✓ 03(abc): for any number that starts with 03 and ends with abc.
 - ✓ 03(5xx): for any number that starts with 03 and ends with 5xx.
 - ✓ 03(400,401,405): for any number that starts with 03 and ends with 400 or 401 or 405.

Notation	Description
	<p>Notes:</p> <ul style="list-style-type: none"> ▪ The value n must be less than the value m. ▪ Only numerical ranges are supported (not alphabetical letters). ▪ For suffix ranges, the starting (n) and ending (m) numbers in the range must have the same number of digits. For example, (23-34) is correct, but (3-12) is not.
<p>[n,m,...] or (n,m,...)</p>	<p>Represents multiple numbers. For example, to depict a one-digit number starting with 2, 3, 4, 5, or 6:</p> <ul style="list-style-type: none"> ▪ Prefix: [2,3,4,5,6]# ▪ Suffix: (2,3,4,5,6) ▪ Prefix with Suffix: [2,3,4,5,6](8,7,6) - prefix is denoted in square brackets; suffix in parenthesis <p>For prefix only, the notations $d[n,m]e$ and $d[n-m]e$ can also be used:</p> <ul style="list-style-type: none"> ▪ To depict a five-digit number that starts with 11, 22, or 33: [11,22,33]xxx# ▪ To depict a six-digit number that starts with 111 or 222: [111,222]xxx# <p>Note: Up to three digits can be used to denote each number.</p>
<p>[n1-m1,n2-m2,a,b,c,n3-m3] or (n1-m1,n2-m2,a,b,c,n3-m3)</p>	<p>Represents a mixed notation of single numbers and multiple ranges. For example, to depict numbers 123 to 130, 455, 766, and 780 to 790:</p> <ul style="list-style-type: none"> ▪ Prefix: [123-130,455,766,780-790] ▪ Suffix: (123-130,455,766,780-790) <p>Note: The ranges and the single numbers used in the dial plan must have the same number of digits. For example, each number range and single number in the dialing plan example above consists of three digits.</p>



Note: When configuring phone numbers or prefixes in the Web interface, enter them only as digits without any other characters. For example, if you wish to enter the phone number 555-1212, it must be entered as 5551212 without the hyphen (-). If the hyphen is entered, the entry is invalid.

52 Configuration Parameters Reference

The device's configuration parameters, default values, and their descriptions are documented in this section.



Note: Parameters and values enclosed in square brackets [...] represent the *ini* file parameters and their enumeration values.

52.1 Networking Parameters

This subsection describes the device's networking parameters.

52.1.1 Ethernet Parameters

The Ethernet parameters are described in the table below.

Ethernet Parameters

Parameter	Description
EMS: Physical Configuration [EthernetPhyConfiguration]	<p>Defines the Ethernet connection mode type.</p> <ul style="list-style-type: none"> ▪ [0] = 10Base-T half-duplex ▪ [1] = 10Base-T full-duplex ▪ [2] = 100Base-TX half-duplex ▪ [3] = 100Base-TX full-duplex ▪ [4] = (Default) Auto-negotiate <p>Note: For this parameter to take effect, a device reset is required.</p>
[MIIRedundancyEnable]	<p>Enables the Ethernet Interface Redundancy feature. When enabled, the device performs a switchover to the second (redundant) Ethernet port upon sensing a link failure in the primary Ethernet port. When disabled, the device operates with a single port (i.e. no redundancy support).</p> <ul style="list-style-type: none"> ▪ [0] = Disable ▪ [1] = (Default) Enable <p>For more information on Ethernet interface redundancy, see Ethernet Interface Redundancy on page 109.</p> <p>Note: For this parameter to take effect, a device reset is required.</p>

52.1.2 Multiple VoIP Network Interfaces and VLAN Parameters

The IP network interfaces and VLAN parameters are described in the table below.

IP Network Interfaces and VLAN Parameters

Parameter	Description
Multiple Interface Table	
Web: Multiple Interface Table EMS: IP Interface Settings [InterfaceTable]	This table parameter configures the Multiple Interface table. The format of this parameter is as follows: [InterfaceTable] FORMAT InterfaceTable_Index = InterfaceTable_ApplicationTypes, InterfaceTable_InterfaceMode, InterfaceTable_IPAddress, InterfaceTable_PrefixLength, InterfaceTable_Gateway, InterfaceTable_VlanID, InterfaceTable_InterfaceName, InterfaceTable_PrimaryDNSServerIPAddress, InterfaceTable_SecondaryDNSServerIPAddress, InterfaceTable_UnderlyingInterface; [InterfaceTable] For example: InterfaceTable 0 = 0, 0, 192.168.85.14, 16, 0.0.0.0, 1, Management; InterfaceTable 1 = 2, 0, 200.200.85.14, 24, 0.0.0.0, 200, Control; InterfaceTable 2 = 1, 0, 211.211.85.14, 24, 211.211.85.1, 211, Media; The above example, configures three network interfaces (OAMP, Control, and Media). Notes: <ul style="list-style-type: none"> For this parameter to take effect, a device reset is required. For a description of this parameter, see 'Configuring IP Network Interfaces' on page 110.
Single IP Network Parameters	
Web: IP Address EMS: Local IP Address [LocalOAMIPAddress]	Defines the device's source IP address of the operations, administration, maintenance, and provisioning (OAMP) interface when operating in a single interface scenario without a Multiple Interface table. The default is 0.0.0.0. Note: For this parameter to take effect, a device reset is required.
Web: Subnet Mask EMS: OAM Subnet Mask [LocalOAMSubnetMask]	Defines the device's subnet mask of the OAMP interface when operating in a single interface scenario without a Multiple Interface table. The default subnet mask is 0.0.0.0. Note: For this parameter to take effect, a device reset is required.
Web: Default Gateway Address EMS: Local Def GW [LocalOAMDefaultGW]	Defines the Default Gateway of the OAMP interface when operating in a single interface scenario without a Multiple Interface table.
VLAN Parameters	
Web/EMS: VLAN Mode [VLANMode]	Enables VLANs tagging (IEEE 802.1Q). <ul style="list-style-type: none"> [0] Disable (default) [1] Enable Notes:

Parameter	Description
	<ul style="list-style-type: none"> For this parameter to take effect, a device reset is required. To operate with multiple network interfaces, VLANs must be enabled. VLANs are available only when booting the device from flash. When booting using BootP/DHCP protocols, VLANs are disabled to allow easier maintenance access. In this scenario, multiple network interface capabilities are unavailable.
Web/EMS: Native VLAN ID [VLANNativeVLANID]	<p>Defines the Native VLAN ID. This is the VLAN ID to which untagged incoming traffic is assigned. Outgoing packets sent to this VLAN are sent only with a priority tag (VLAN ID = 0).</p> <p>When the Native VLAN ID is equal to one of the VLAN IDs listed in the Multiple Interface table (and VLANs are enabled), untagged incoming traffic is considered as incoming traffic for that interface. Outgoing traffic sent from this interface is sent with the priority tag (tagged with VLAN ID = 0).</p> <p>When the Native VLAN ID is different to any value in the 'VLAN ID' column in the table, untagged incoming traffic is discarded and all outgoing traffic is tagged.</p> <p>The default Native VLAN ID is 1.</p> <p>Note: If this parameter is not configured (i.e., default is 1) and one of the interfaces has a VLAN ID set to 1, this interface is still considered the 'Native' VLAN. If you do not wish to have a 'Native' VLAN ID and want to use VLAN ID 1, set this parameter to a value other than any VLAN ID in the table.</p>
[EnableNTPasOAM]	<p>Defines the application type for Network Time Protocol (NTP) services.</p> <ul style="list-style-type: none"> [1] = OAMP (default) [0] = Control <p>Note: For this parameter to take effect, a device reset is required.</p>
[VLANSendNonTaggedOnNative]	<p>Determines whether to send non-tagged packets on the native VLAN.</p> <ul style="list-style-type: none"> [0] = (Default) Sends priority tag packets. [1] = Sends regular packets (with no VLAN tag). <p>Note: For this parameter to take effect, a device reset is required.</p>

52.1.3 Routing Parameters

The IP network routing parameters are described in the table below.

IP Network Routing Parameters

Parameter	Description
Web: Disable ICMP Redirects [DisableICMPRedirects]	<p>Determines whether the device accepts or ignores ICMP Redirect messages.</p> <ul style="list-style-type: none"> [0] Disable = (Default) ICMP Redirect messages are handled by the device. [1] Enable = ICMP Redirect messages are ignored.
Static IP Routing Table	

Parameter	Description
Web/EMS: IP Routing Table [StaticRouteTable]	<p>Defines up to 30 static IP routing rules for the device. These rules can be associated with IP interfaces defined in the Multiple Interface table (InterfaceTable parameter). The routing decision for sending the outgoing IP packet is based on the source subnet/VLAN. If not associated with an IP interface, the static IP rule is based on destination IP address.</p> <p>When the destination of an outgoing IP packet does not match one of the subnets defined in the Multiple Interface table, the device searches this table for an entry that matches the requested destination host/network. If such an entry is found, the device sends the packet to the indicated router (i.e., next hop). If no explicit entry is found, the packet is sent to the default gateway according to the source interface of the packet (if defined).</p> <p>The format of this parameter is as follows: [StaticRouteTable] FORMAT StaticRouteTable_Index = StaticRouteTable_InterfaceName, StaticRouteTable_Destination, StaticRouteTable_PrefixLength, StaticRouteTable_Gateway, StaticRouteTable_Description; [\StaticRouteTable]</p> <p>Note: For a description of this parameter, see 'Configuring Static IP Routing' on page 119.</p>

52.1.4 Quality of Service Parameters

The Quality of Service (QoS) parameters are described in the table below.

QoS Parameters

Parameter	Description
Layer-2 Class Of Service (CoS) Parameters (VLAN Tag Priority Field)	
Web: Network Priority EMS: Network Service Class Priority [VLANNetworkServiceClassPriority]	Defines the VLAN priority (IEEE 802.1p) for Network Class of Service (CoS) content. The valid range is 0 to 7. The default is 7.
Web: Media Premium EMS: Premium Service Class Media Priority Priority [VLANPremiumServiceClassMediaPriority]	Defines the VLAN priority (IEEE 802.1p) for the Premium CoS content and media traffic. The valid range is 0 to 7. The default is 6.
Web: Control Premium Priority EMS: Premium Service Class Control Priority [VLANPremiumServiceClassControlPriority]	Defines the VLAN priority (IEEE 802.1p) for the Premium CoS content and control traffic. The valid range is 0 to 7. The default is 6.
Web: Gold Priority EMS: Gold Service Class Priority [VlanGoldServiceClassP]	Defines the VLAN priority (IEEE 802.1p) for the Gold CoS content. The valid range is 0 to 7. The default is 4.

Parameter	Description
riority]	
Web: Bronze Priority EMS: Bronze Service Class Priority [VLANBronzeServiceClassPriority]	Defines the VLAN priority (IEEE 802.1p) for the Bronze CoS content. The valid range is 0 to 7. The default is 2.
Layer-3 Class of Service (TOS/DiffServ) Parameters	
Web: Network QoS EMS: Network Service Class Diff Serv [NetworkServiceClassDiffServ]	Defines the Differentiated Services (DiffServ) value for Network CoS content. The valid range is 0 to 63. The default is 48. Note: For this parameter to take effect, a device reset is required.
Web: Media Premium QoS EMS: Premium Service Class Media Diff Serv [PremiumServiceClassMediaDiffServ]	Defines the DiffServ value for Premium Media CoS content (only if IPDiffServ is not set in the selected IP Profile). The valid range is 0 to 63. The default is 46. Note: The value for the Premium Control DiffServ is determined by the following (according to priority): <ul style="list-style-type: none"> IPDiffServ value in the selected IP Profile (IPProfile parameter). PremiumServiceClassMediaDiffServ.
Web: Control Premium QoS EMS: Premium Service Class Control Diff Serv [PremiumServiceClassControlDiffServ]	Defines the DiffServ value for Premium Control CoS content (Call Control applications) - only if ControlIPDiffServ is not set in the selected IP Profile. The valid range is 0 to 63. The default is 40. Notes: <ul style="list-style-type: none"> The value for the Premium Control DiffServ is determined by the following (according to priority): <ul style="list-style-type: none"> ✓ SigIPDiffServ value in the selected IP Profile (IPProfile parameter). ✓ PremiumServiceClassControlDiffServ.
Web: Gold QoS EMS: Gold Service Class Diff Serv [GoldServiceClassDiffServ]	Defines the DiffServ value for the Gold CoS content (Streaming applications). The valid range is 0 to 63. The default is 26.
Web: Bronze QoS EMS: Bronze Service Class Diff Serv [BronzeServiceClassDiffServ]	Defines the DiffServ value for the Bronze CoS content (OAMP applications). The valid range is 0 to 63. The default is 10.

52.1.5 NAT and STUN Parameters

The Network Address Translation (NAT) and Simple Traversal of UDP through NAT (STUN) parameters are described in the table below.

NAT and STUN Parameters

Parameter	Description
STUN Parameters	
Web: Enable STUN EMS: STUN Enable [EnableSTUN]	Enables Simple Traversal of UDP through NATs (STUN). <ul style="list-style-type: none"> ▪ [0] Disable (default) ▪ [1] Enable When enabled, the device functions as a STUN client and communicates with a STUN server located in the public Internet. STUN is used to discover whether the device is located behind a NAT and the type of NAT. It is also used to determine the IP addresses and port numbers that the NAT assigns to outgoing signaling messages (using SIP) and media streams (using RTP, RTCP and T.38). STUN works with many existing NAT types and does not require any special behavior from them. <p>Notes:</p> <ul style="list-style-type: none"> ▪ For this parameter to take effect, a device reset is required. ▪ For defining the STUN server domain name, use the parameter STUNServerDomainName. ▪ For more information on STUN, see Configuring STUN on page 131.
Web: STUN Server Primary IP EMS: Primary Server IP [STUNServerPrimaryIP]	Defines the IP address of the primary STUN server. The valid range is the legal IP addresses. The default is 0.0.0.0. Note: For this parameter to take effect, a device reset is required.
Web: STUN Server Secondary IP EMS: Secondary Server IP [STUNServerSecondaryIP]	Defines the IP address of the secondary STUN server. The valid range is the legal IP addresses. The default is 0.0.0.0. Note: For this parameter to take effect, a device reset is required.
[STUNServerDomainName]	Defines the domain name for the Simple Traversal of User Datagram Protocol (STUN) server's address (used for retrieving all STUN servers with an SRV query). The STUN client can perform the required SRV query to resolve this domain name to an IP address and port, sort the server list, and use the servers according to the sorted list. <p>Notes:</p> <ul style="list-style-type: none"> ▪ For this parameter to take effect, a device reset is required. ▪ Use either the STUNServerPrimaryIP or the STUNServerDomainName parameter, with priority to the first one.
NAT Parameters	
Web/EMS: NAT Traversal [DisableNAT]	Enables the NAT mechanism. For more information, see 'First Incoming Packet Mechanism' on page 135. <ul style="list-style-type: none"> ▪ [0] Enable ▪ [1] Disable (default)
Web: NAT IP Address EMS: Static NAT IP	Defines the global (public) IP address of the device to enable static NAT between the device and the Internet.

Parameter	Description
Address [StaticNatIP]	Note: For this parameter to take effect, a device reset is required.
EMS: Binding Life Time [NATBindingDefaultTimeout]	Defines the default NAT binding lifetime in seconds. STUN refreshes the binding information after this time expires. The valid range is 0 to 2,592,000. The default is 30. Note: For this parameter to take effect, a device reset is required.
[EnableIPAddrTranslation]	Enables IP address translation for RTP, RTCP, and T.38 packets. <ul style="list-style-type: none"> ▪ [0] = Disable IP address translation. ▪ [1] = (Default) Enable IP address translation. ▪ [2] = Enable IP address translation for RTP Multiplexing (ThroughPacket™). ▪ [3] = Enable IP address translation for all protocols (RTP, RTCP, T.38 and RTP Multiplexing). When enabled, the device compares the source IP address of the first incoming packet to the remote IP address stated in the opening of the channel. If the two IP addresses don't match, the NAT mechanism is activated. Consequently, the remote IP address of the outgoing stream is replaced by the source IP address of the first incoming packet. Notes: <ul style="list-style-type: none"> ▪ The NAT mechanism must be enabled for this parameter to take effect (i.e., the parameter DisableNAT is set to 0). ▪ For information on RTP Multiplexing, see RTP Multiplexing (ThroughPacket) on page 173.
[EnableUDPPortTranslation]	Enables UDP port translation. <ul style="list-style-type: none"> ▪ [0] = (Default) Disables UDP port translation. ▪ [1] = Enables UDP port translation. The device compares the source UDP port of the first incoming packet to the remote UDP port stated in the opening of the channel. If the two UDP ports don't match, the NAT mechanism is activated. Consequently, the remote UDP port of the outgoing stream is replaced by the source UDP port of the first incoming packet. Notes: <ul style="list-style-type: none"> ▪ For this parameter to take effect, a device reset is required. ▪ The NAT mechanism and the IP address translation must be enabled for this parameter to take effect (i.e., set the parameter DisableNAT to 0 and the parameter EnableIPAddrTranslation to 1).

52.1.6 NFS Parameters

The Network File Systems (NFS) configuration parameters are described in the table below.

NFS Parameters

Parameter	Description
[NFSBasePort]	Defines the start of the range of numbers used for local UDP ports used by the NFS client. The maximum number of local ports is maximum channels plus maximum NFS servers. The valid range is 0 to 65535. The default is 47000.

Parameter	Description
NFS Table	
Web: NFS Table EMS: NFS Settings [NFSServers]	This table parameter defines up to 16 NFS file systems so that the device can access a remote server's shared files and directories for loading cmp, ini, and auxiliary files (using the Automatic Update mechanism). The format of this table ini file parameter is as follows: [NFSServers] FORMAT NFSServers_Index = NFSServers_HostOrIP, NFSServers_RootPath, NFSServers_NfsVersion, NFSServers_AuthType, NFSServers_UID, NFSServers_GID, NFSServers_VlanType; [NFSServers] For example: NFSServers 1 = 101.1.13, /audio1, 3, 1, 0, 1, 1; Note: For a detailed description of this table, see 'Configuring NFS Settings' on page 128.

52.1.7 DNS Parameters

The Domain name System (DNS) parameters are described in the table below.

DNS Parameters

Parameter	Description
Internal DNS Table	
Web: Internal DNS Table EMS: DNS Information [DNS2IP]	This table parameter defines the internal DNS table for resolving host names into IP addresses. Up to four different IP addresses (in dotted-decimal notation) can be assigned to a host name. The format of this parameter is as follows: [Dns2Ip] FORMAT Dns2Ip_Index = Dns2Ip_DomainName, Dns2Ip_FirstIpAddress, Dns2Ip_SecondIpAddress, Dns2Ip_ThirdIpAddress, Dns2Ip_FourthIpAddress; [Dns2Ip] For example: Dns2Ip 0 = DnsName, 1.1.1.1, 2.2.2.2, 3.3.3.3, 4.4.4.4; Note: For a detailed description of this table parameter, see 'Configuring the Internal DNS Table' on page 125.
Internal SRV Table	
Web: Internal SRV Table EMS: DNS Information [SRV2IP]	This table parameter defines the internal SRV table for resolving host names into DNS A-Records. Three different A-Records can be assigned to a host name. Each A-Record contains the host name, priority, weight, and port. The format of this parameter is as follows: [SRV2IP] FORMAT SRV2IP_Index = SRV2IP_InternalDomain, SRV2IP_TransportType, SRV2IP_Dns1, SRV2IP_Priority1, SRV2IP_Weight1, SRV2IP_Port1, SRV2IP_Dns2, SRV2IP_Priority2, SRV2IP_Weight2, SRV2IP_Port2, SRV2IP_Dns3, SRV2IP_Priority3, SRV2IP_Weight3, SRV2IP_Port3; [SRV2IP]

Parameter	Description
	<p>For example: SRV2IP 0 = SrvDomain,0,Dnsname1,1,1,500,Dnsname2,2,2,501,\$\$,0,0,0;</p> <p>Note: For a detailed description of this table parameter, see 'Configuring the Internal SRV Table' on page 127.</p>

52.1.8 DHCP Parameters

The Dynamic Host Control Protocol (DHCP) parameters are described in the table below.

DHCP Parameters

Parameter	Description
Web: Enable DHCP EMS: DHCP Enable [DHCPEnable]	<p>Enables Dynamic Host Control Protocol (DHCP) functionality.</p> <ul style="list-style-type: none"> ▪ [0] Disable (default) ▪ [1] Enable <p>After the device powers up, it attempts to communicate with a BootP server. If a BootP server does not respond and DHCP is enabled, then the device attempts to obtain its IP address and other networking parameters from the DHCP server.</p> <p>Notes:</p> <ul style="list-style-type: none"> ▪ For this parameter to take effect, a device reset is required. ▪ After you enable the DHCP server, do the following: <ol style="list-style-type: none"> a. Enable DHCP and save the configuration. b. Perform a cold reset using the device's hardware reset button (soft reset using the Web interface doesn't trigger the BootP/DHCP procedure and this parameter reverts to 'Disable'). ▪ Throughout the DHCP procedure, the BootP/TFTP application must be deactivated; otherwise the device receives a response from the BootP server instead of from the DHCP server. ▪ This parameter is a special 'Hidden' parameter. Once defined and saved in flash memory, its assigned value doesn't revert to its default even if the parameter doesn't appear in the <i>ini</i> file.
EMS: DHCP Speed Factor [DHCPspeedFactor]	<p>Defines the DHCP renewal speed.</p> <ul style="list-style-type: none"> ▪ [0] = Disable ▪ [1] = (Default) Normal ▪ [2] to [10] = Fast <p>When set to 0, the DHCP lease renewal is disabled. Otherwise, the renewal time is divided by this factor. Some DHCP-enabled routers perform better when set to 4.</p> <p>Note: For this parameter to take effect, a device reset is required.</p>

52.1.9 NTP and Daylight Saving Time Parameters

The Network Time Protocol (NTP) and daylight saving time parameters are described in the table below.

NTP and Daylight Saving Time Parameters

Parameter	Description
NTP Parameters	
Note: For more information on Network Time Protocol (NTP), see 'Simple Network Time Protocol Support' on page 105.	
Web: NTP Server DN/IP EMS: Server IP Address [NTPServerIP]	<p>Defines the IP address (in dotted-decimal notation or as an FQDN) of the NTP server. The advantage of using an FQDN is that multiple IP addresses can be resolved from the DNS server, providing NTP server redundancy.</p> <p>The default IP address is 0.0.0.0 (i.e., internal NTP client is disabled).</p>
Web: NTP Secondary Server IP [NTPSecondaryServerIP]	<p>Defines a second NTP server's address as an FQDN or an IP address (in dotted-decimal notation). This NTP is used for redundancy; if the primary NTP server fails, then this NTP server is used.</p> <p>The default IP address is 0.0.0.0.</p>
Web: NTP UTC Offset EMS: UTC Offset [NTPServerUTCOffset]	<p>Defines the Universal Time Coordinate (UTC) offset (in seconds) from the NTP server.</p> <p>The default offset is 0. The offset range is -43200 to 43200.</p>
Web: NTP Update Interval EMS: Update Interval [NTPUpdateInterval]	<p>Defines the time interval (in seconds) that the NTP client requests for a time update.</p> <p>The default interval is 86400 (i.e., 24 hours). The range is 0 to 214783647.</p> <p>Note: It is not recommend to set this parameter to beyond one month (i.e., 2592000 seconds).</p>
Daylight Saving Time Parameters	
Web: Day Light Saving Time EMS: Mode [DayLightSavingTimeEnable]	<p>Enables daylight saving time.</p> <ul style="list-style-type: none"> ▪ [0] Disable (default) ▪ [1] Enable
Web: Start Time or Day of Month Start EMS: Start [DayLightSavingTimeStart]	<p>Defines the date and time when daylight saving begins. This value can be configured using any of the following formats:</p> <ul style="list-style-type: none"> ▪ Day of year - <i>mm:dd:hh:mm</i>, where: <ul style="list-style-type: none"> ✓ <i>mm</i> denotes month ✓ <i>dd</i> denotes date of the month ✓ <i>hh</i> denotes hour ✓ <i>mm</i> denotes minutes <p>For example, "05:01:08:00" denotes daylight saving starting from May 1 at 8 A.M.</p> ▪ Day of month - <i>mm:day/wk:hh:mm</i>, where: <ul style="list-style-type: none"> ✓ <i>mm</i> denotes month (e.g., 04) ✓ <i>day</i> denotes day of week (e.g., FRI) ✓ <i>wk</i> denotes week of the month (e.g., 03) ✓ <i>hh</i> denotes hour (e.g., 23) ✓ <i>mm</i> denotes minutes (e.g., 10) <p>For example, "04:FRI/03:23:00" denotes Friday, the third week of</p>

Parameter	Description
	April, at 11 P.M. The week field can be 1-5, where 5 denotes the last occurrence of the specified day in the specified month. For example, "04:FRI/05:23:00" denotes the last Friday of April, at 11 P.M.
Web: End Time or Day of Month End EMS: End [DayLightSavingTimeEnd]	Defines the date and time when daylight saving ends. For a description of the format of this value, see the DayLightSavingTimeStart parameter.
Web/EMS: Offset [DayLightSavingTimeOffset]	Defines the daylight saving time offset (in minutes). The valid range is 0 to 120. The default is 60.

52.2 Management Parameters

This subsection describes the device's Web and Telnet parameters.

52.2.1 General Parameters

The general management parameters are described in the table below.

General Management Parameters

Parameter	Description
Web: Web and Telnet Access List Table EMS: Web Access Addresses [WebAccessList_x]	This table configures up to ten IP addresses that are permitted to access the device's Web interface and Telnet interfaces. Access from an undefined IP address is denied. When no IP addresses are defined in this table, this security feature is inactive (i.e., the device can be accessed from any IP address). The default is 0.0.0.0 (i.e., the device can be accessed from any IP address). For example: WebAccessList_0 = 10.13.2.66 WebAccessList_1 = 10.13.77.7 For a description of this parameter, see 'Configuring Web and Telnet Access List' on page 73.

52.2.2 Web Parameters

The Web parameters are described in the table below.

Web Parameters

Parameter	Description
Web: Password Change Interval [WebUserPassChangeInterval]	Defines the duration (in minutes) of the validity of Web login passwords. When this duration expires, the password of the Web user must be changed. The valid value is 0 to 100000, where 0 means that the password is always valid. The default is 1140.

Parameter	Description
	<p>Note: This parameter is applicable only when using the Web Users table, where the default value of the 'Password Age' parameter in the Web Users table inherits this parameter's value.</p>
Web: User inactivity timer [UserInactivityTimer]	<p>Defines the duration (in days) for which a user has not logged in to the Web interface, after which the status of the user becomes inactive and can no longer access the Web interface. These users can only log in to the Web interface if their status is changed (to New or Valid) by a System Administrator or Master user.</p> <p>The valid value is 0 to 10000, where 0 means inactive. The default is 90.</p> <p>Note: This parameter is applicable only when using the Web Users table.</p>
Web: Session Timeout [WebSessionTimeout]	<p>Defines the duration (in minutes) of Web inactivity of a logged-in user, after which the user is automatically logged off the Web interface.</p> <p>The valid value is 0-100000, where 0 means no timeout. The default is 15.</p> <p>Note: This parameter can apply to all users, or per user when set in the Web Users table.</p>
Web: Deny Access On Fail Count [DenyAccessOnFailCount]	<p>Defines the maximum number of failed login attempts, after which the requesting IP address is blocked.</p> <p>The valid value range is 0 to 10. The values 0 and 1 mean immediate block. The default is 3.</p>
Web: Deny Authentication Timer EMS: WEB Deny Authentication Timer [DenyAuthenticationTimer]	<p>Defines the duration (in seconds) for which login to the Web interface is denied from a specific IP address (for all users) when the number of failed login attempts has exceeded the maximum. This maximum is defined by the DenyAccessOnFailCount parameter. Only after this time expires can users attempt to login from this same IP address.</p> <p>The valid value is 0 to 100000, where 0 means that login is not denied regardless of number of failed login attempts. The default is 60.</p>
Web: Display Login Information [DisplayLoginInformation]	<p>Enables display of user's login information on each successful login attempt.</p> <ul style="list-style-type: none"> ▪ [0] = Disable (default) ▪ [1] = Enable
[EnableMgmtTwoFactorAuthentication]	<p>Enables Web login authentication using a third-party, smart card.</p> <ul style="list-style-type: none"> ▪ [0] = Disable (default) ▪ [1] = Enable <p>When enabled, the device retrieves the Web user's login username from the smart card, which is automatically displayed (read-only) in the Web Login screen; the user is then required to provide only the login password.</p> <p>Typically, a TLS connection is established between the smart card and the device's Web interface, and a RADIUS server is implemented to authenticate the password with the username. Thus, this feature implements a two-factor authentication - what the user has (the physical card) and what the user knows (i.e., the login password).</p>
EMS: HTTPS Port [HTTPport]	<p>Defines the LAN HTTP port for Web management (default is 80). To enable Web management from the LAN, configure the desired port.</p> <p>Note: For this parameter to take effect, a device reset is required.</p>
EMS: Disable WEB	<p>Determines whether the entire Web interface is read-only.</p>

Parameter	Description
Config [DisableWebConfig]	<ul style="list-style-type: none"> ▪ [0] = (Default) Enables modifications of parameters. ▪ [1] = Web interface is read-only. <p>When in read-only mode, parameters can't be modified. In addition, the following pages can't be accessed: 'Web User Accounts', 'Certificates', 'Regional Settings', 'Maintenance Actions' and all file-loading pages ('Load Auxiliary Files', 'Software Upgrade Wizard', and 'Configuration File').</p> <p>Notes:</p> <ul style="list-style-type: none"> ▪ For this parameter to take effect, a device reset is required. ▪ To return to read/write after you have applied read-only using this parameter (set to 1), you need to reboot your device with an ini file that doesn't include this parameter, using the AcBootP utility.
[ResetWebPassword]	<p>Resets the username and password of the primary ("Admin") and secondary ("User") accounts to their default settings ("Admin" and "Admin" respectively), and deletes all other users that may have been configured.</p> <ul style="list-style-type: none"> ▪ [0] = (Default) Password and username retain their values. ▪ [1] = Password and username are reset. <p>Notes:</p> <ul style="list-style-type: none"> ▪ For this parameter to take effect, a device reset is required. ▪ You cannot reset the username and password through the Web interface (by loading an ini file or on the AdminPage). To reset the username and password: <ul style="list-style-type: none"> ✓ BootP: Set this parameter in an ini file and load it to the device through BootP (for more information, refer to the AcBootP Utility User's Guide). ✓ SNMP: <ol style="list-style-type: none"> 1) Set acSysGenericINILine to WEBPasswordControlViaSNMP = 1, and reset the device with a flash burn (set acSysActionSetResetControl to 1 and acSysActionSetReset to 1). 2) Change the username and password in the acSysWEBAccessEntry table. Use the following format: Username acSysWEBAccessUserName: old/pass/new Password acSysWEBAccessUserCode: username/old/new
[ScenarioFileName]	<p>Defines the file name of the Scenario file to be loaded to the device. The file name must have the .dat extension and can be up to 47 characters. For loading a Scenario using the Web interface, see Loading a Scenario to the Device on page 57.</p>

Parameter	Description
[WelcomeMessage]	<p>Enables and defines a Welcome message that appears on the Web Login page for logging in to the Web interface.</p> <p>The format of this parameter is as follows:</p> <p>[WelcomeMessage] FORMAT WelcomeMessage_Index = WelcomeMessage_Text [WelcomeMessage]</p> <p>For Example:</p> <p>FORMAT WelcomeMessage_Index = WelcomeMessage_Text WelcomeMessage 1 = "*****" ; WelcomeMessage 2 = "***** This is a Welcome message ****" ; WelcomeMessage 3 = "*****" ;</p> <p>Notes:</p> <ul style="list-style-type: none"> ▪ Each index row represents a line of text in the Welcome message box. Up to 20 lines (or rows) of text can be defined. ▪ The configured text message must be enclosed in double quotation marks (i.e., "..."). ▪ If this parameter is not configured, no Welcome message is displayed.

52.2.3 Telnet Parameters

The Telnet parameters are described in the table below.

Telnet Parameters

Parameter	Description
Web: Embedded Telnet Server EMS: Server Enable [TelnetServerEnable]	Enables the device's embedded Telnet server. Telnet is disabled by default for security. <ul style="list-style-type: none"> ▪ [0] Disable (default) ▪ [1] Enable Unsecured ▪ [2] Enable Secured (SSL) Note: Only the primary Web User Account (which has Security Administration access level) can access the device using Telnet (see 'Configuring Web User Accounts' on page 64).
Web: Telnet Server TCP Port EMS: Server Port [TelnetServerPort]	Defines the port number for the embedded Telnet server. The valid range is all valid port numbers. The default port is 23.
Web: Telnet Server Idle Timeout EMS: Server Idle Disconnect [TelnetServerIdleDisconnect]	Defines the timeout (in minutes) for disconnection of an idle Telnet session. When set to zero, idle sessions are not disconnected. The valid range is any value. The default is 0. Note: For this parameter to take effect, a device reset is required.

52.2.4 SNMP Parameters

The SNMP parameters are described in the table below.

SNMP Parameters

Parameter	Description
Web: Enable SNMP [DisableSNMP]	Enables SNMP. <ul style="list-style-type: none"> ▪ [0] Enable = (Default) SNMP is enabled. ▪ [1] Disable = SNMP is disabled and no traps are sent.
[SNMPPort]	Defines the device's local (LAN) UDP port used for SNMP Get/Set commands. The range is 100 to 3999. The default port is 161. Note: For this parameter to take effect, a device reset is required.
[ChassisPhysicalAlias]	Defines the 'alias' name object for the physical entity as specified by a network manager, and provides a non-volatile 'handle' for the physical entity. The valid range is a string of up to 255 characters.
[ChassisPhysicalAssetID]	Defines the user-assigned asset tracking identifier object for the device's chassis as specified by an EMS, and provides non-volatile storage of this information. The valid range is a string of up to 255 characters.

Parameter	Description
[ifAlias]	Defines the textual name of the interface. The value is equal to the ifAlias SNMP MIB object. The valid range is a string of up to 64 characters.
EMS: Keep Alive Trap Port [KeepAliveTrapPort]	Defines the port to which keep-alive traps are sent. The valid range is 0 - 65534. The default is port 162.
[SendKeepAliveTrap]	Enables keep-alive traps and sends them every 9/10 of the time as defined by the NATBindingDefaultTimeout parameter. <ul style="list-style-type: none"> ▪ [0] = Disable ▪ [1] = Enable Note: For this parameter to take effect, a device reset is required.
[SNMPSysOid]	Defines the base product system OID. The default is eSNMP_AC_PRODUCT_BASE_OID_D. Note: For this parameter to take effect, a device reset is required.
[SNMPTrapEnterpriseOid]	Defines the Trap Enterprise OID. The default is eSNMP_AC_ENTERPRISE_OID. The inner shift of the trap in the AcTrap subtree is added to the end of the OID in this parameter. Note: For this parameter to take effect, a device reset is required.
[acUserInputAlarmDescription]	Defines the description of the input alarm.
[acUserInputAlarmSeverity]	Defines the severity of the input alarm.
[AlarmHistoryTableMaxSize]	Defines the maximum number of rows in the Alarm History table. This parameter can be controlled by the Config Global Entry Limit MIB (located in the Notification Log MIB). The valid range is 50 to 1000. The default is 500. Note: For this parameter to take effect, a device reset is required.
[SNMPEngineIDString]	Defines the SNMP engine ID for SNMPv2/SNMPv3 agents. This is used for authenticating a user attempting to access the SNMP agent on the device. The ID can be a string of up to 36 characters. The default is 00:00:00:00:00:00:00:00:00:00:00:00 (12 Hex octets characters). The provided key must be set with 12 Hex values delimited by a colon (":") in the format xx:xx:...:xx. For example, 00:11:22:33:44:55:66:77:88:99:aa:bb Notes: <ul style="list-style-type: none"> ▪ For this parameter to take effect, a device reset is required. ▪ Before setting this parameter, all SNMPv3 users must be deleted; otherwise, the parameter setting is ignored. ▪ If the supplied key does not pass validation of the 12 Hex values input or it is set with the default value, the engine ID is generated according to RFC 3411.
Web: SNMP Trap Destination Parameters EMS: Network > SNMP Managers Table Note: Up to five SNMP trap managers can be defined.	
SNMP Manager [SNMPManagerIsUsed_x]	Determines the validity of the parameters (IP address and port number) of the corresponding SNMP Manager used to receive

Parameter	Description
	SNMP traps. <ul style="list-style-type: none"> ▪ [0] (Check box cleared) = Disabled (default) ▪ [1] (Check box selected) = Enabled
Web: IP Address EMS: Address [SNMPManagerTableIP_x]	Defines the IP address of the remote host used as an SNMP Manager. The device sends SNMP traps to this IP address. Enter the IP address in dotted-decimal notation, e.g., 108.10.1.255.
Web: Trap Port EMS: Port [SNMPManagerTrapPort_x]	Defines the port number of the remote SNMP Manager. The device sends SNMP traps to this port. The valid SNMP trap port range is 100 to 4000. The default port is 162.
Web: Trap Enable [SNMPManagerTrapSendingEnable_x]	Enables the sending of traps to the corresponding SNMP manager. <ul style="list-style-type: none"> ▪ [0] Disable = Sending is disabled. ▪ [1] Enable = (Default) Sending is enabled.
Web: Trap User [SNMPManagerTrapUser_x]	Defines the SNMPv3 USM user or SNMPv2 user to associate with the trap destination. This determines the trap format, authentication level, and encryption level. By default, it is associated with the SNMPv2 user (SNMP trap community string). The valid value is a string.
Web: Trap Manager Host Name [SNMPTrapManagerHostName]	Defines an FQDN of the remote host used as an SNMP manager. The resolved IP address replaces the last entry in the Trap Manager table (defined by the SNMPManagerTableIP parameter) and the last trap manager entry of snmpTargetAddrTable in the snmpTargetMIB. For example: 'mngr.corp.mycompany.com'. The valid range is a string of up to 99 characters.
SNMP Community String Parameters	
Community String [SNMPReadOnlyCommunityString_x]	Defines up to five read-only SNMP community strings (up to 19 characters each). The default string is 'public'.
Community String [SNMPReadWriteCommunityString_x]	Defines up to five read/write SNMP community strings (up to 19 characters each). The default string is 'private'.
Trap Community String [SNMPTrapCommunityString]	Defines the Community string used in traps (up to 19 characters). The default string is 'trapuser'.
SNMP Trusted Managers Table	
Web: SNMP Trusted Managers [SNMPTrustedMgr_x]	Defines up to five IP addresses of remote trusted SNMP managers from which the SNMP agent accepts and processes SNMP Get and Set requests. Notes: <ul style="list-style-type: none"> ▪ By default, the SNMP agent accepts SNMP Get and Set requests from any IP address, as long as the correct community string is used in the request. Security can be enhanced by using Trusted Managers, which is an IP address from which the SNMP agent accepts and processes SNMP requests. ▪ If no values are assigned to these parameters any manager

Parameter	Description
	can access the device. <ul style="list-style-type: none"> Trusted managers can work with all community strings.
SNMP V3 Users Table	
Web/EMS: SNMP V3 Users [SNMPUsers]	This <i>parameter</i> table defines SNMP v3 users. The format of this parameter is as follows: [SNMPUsers] FORMAT SNMPUsers_Index = SNMPUsers_Username, SNMPUsers_AuthProtocol, SNMPUsers_PrivProtocol, SNMPUsers_AuthKey, SNMPUsers_PrivKey, SNMPUsers_Group; [SNMPUsers] For example: SNMPUsers 1 = v3admin1, 1, 0, myauthkey, -, 1; The example above configures user 'v3admin1' with security level authNoPriv(2), authentication protocol MD5, authentication text password 'myauthkey', and ReadWriteGroup2. Note: For a description of this table, see 'Configuring SNMP V3 Users' on page 88.

52.2.5 Serial Parameters

The RS-232 serial parameters are described in the table below.

Serial Parameters

Parameter	Description
[DisableRS232]	Enables the device's RS-232 (serial) port. <ul style="list-style-type: none"> [0] = (Default) Enabled [1] = Disabled The RS-232 serial port can be used to change the networking parameters and view error/notification messages. For how to establish a serial communication with the device, refer to the <i>Installation Manual</i> . Note: For this parameter to take effect, a device reset is required.
EMS: Baud Rate [SerialBaudRate]	Defines the RS-232 baud rate. The valid values include the following: 1200, 2400, 9600, 14400, 19200, 38400, 57600, or 115200 (default). Note: For this parameter to take effect, a device reset is required.
EMS: Data [SerialData]	Defines the RS-232 data bit. <ul style="list-style-type: none"> [7] = 7-bit [8] = (Default) 8-bit Note: For this parameter to take effect, a device reset is required.
EMS: Parity [SerialParity]	Defines the RS-232 polarity. <ul style="list-style-type: none"> [0] = (Default) None [1] = Odd [2] = Even Note: For this parameter to take effect, a device reset is required.
EMS: Stop	Defines the RS-232 stop bit.

Parameter	Description
[SerialStop]	<ul style="list-style-type: none"> ▪ [1] = (Default) 1-bit (default) ▪ [2] = 2-bit <p>Note: For this parameter to take effect, a device reset is required.</p>
EMS: Flow Control [SerialFlowControl]	<p>Defines the RS-232 flow control.</p> <ul style="list-style-type: none"> ▪ [0] = (Default) None ▪ [1] = Hardware <p>Note: For this parameter to take effect, a device reset is required.</p>

52.3 Debugging and Diagnostics Parameters

This subsection describes the device's debugging and diagnostic parameters.

52.3.1 General Parameters

The general debugging and diagnostic parameters are described in the table below.

General Debugging and Diagnostic Parameters

Parameter	Description
EMS: Enable Diagnostics [EnableDiagnostics]	<p>Determines the method for verifying correct functioning of the different hardware components on the device. On completion of the check and if the test fails, the device sends information on the test results of each hardware component to the Syslog server.</p> <ul style="list-style-type: none"> ▪ [0] = (Default) Rapid and Enhanced self-test mode. ▪ [1] = Detailed self-test mode (full test of DSPs, PCM, Switch, LAN, PHY and Flash). ▪ [2] = A quicker version of the Detailed self-test mode (full test of DSPs, PCM, Switch, LAN, PHY, but partial test of Flash). <p>Note: For this parameter to take effect, a device reset is required.</p>
Web: Enable LAN Watchdog [EnableLanWatchDog]	<p>Enables the LAN watchdog feature.</p> <ul style="list-style-type: none"> ▪ [0] Disable (default) ▪ [1] Enable <p>When LAN watchdog is enabled, the device's overall communication integrity is checked periodically. If no communication is detected for about three minutes, the device performs a self test:</p> <ul style="list-style-type: none"> ▪ If the self-test succeeds, the problem is a logical link down (i.e., Ethernet cable disconnected on the switch side) and the Busy Out mechanism is activated if enabled (i.e., the parameter EnableBusyOut is set to 1). ▪ If the self-test fails, the device restarts to overcome internal fatal communication error. <p>Notes:</p> <ul style="list-style-type: none"> ▪ For this parameter to take effect, a device reset is required. ▪ Enable LAN watchdog is relevant only if the Ethernet connection is full duplex.
[LifeLineType]	<p>Defines the condition(s) upon which the Lifeline analog (FXS) feature is activated. The Lifeline feature can be activated upon a power outage,</p>

Parameter	Description
	<p>physical disconnection of the LAN cable, or network failure (i.e., loss of IP connectivity). Upon any of these conditions, the Lifeline feature provides PSTN connectivity and thus call continuity for the FXS phone users.</p> <p>If the device is in Lifeline mode and the scenario that caused it to enter Lifeline (e.g., power outage) no longer exists (e.g., power returns), the device exits Lifeline and operates as normal.</p> <ul style="list-style-type: none"> ▪ [0] = (Default) Lifeline is activated upon power outage. ▪ [1] = Lifeline is activated upon power outage or when the link is down (i.e., physically disconnected). ▪ [2] = Lifeline is activated upon a power outage, when the link is down (physically disconnected), network failure (logical link disconnection), or when the Trunk Group is in Busy Out state (see the EnableBusyOut parameter). <p>The Lifeline (FXS) phone is connected to FXS Port 1 of each FXS module. FXS Port 1 connects to the POTS (Lifeline) phone as well as to the PSTN / PBX, using a splitter cable.</p> <p>Notes:</p> <ul style="list-style-type: none"> ▪ For this parameter to take effect, a device reset is required. ▪ This parameter is applicable only to FXS interfaces. ▪ To enable Lifeline upon a network failure, the LAN watch dog must be activated (i.e., set the parameter EnableLANWatchDog to 1). ▪ A Lifeline phone connection can be setup for each FXS module (using Port 1) housed in the chassis. ▪ For information on Lifeline cabling, refer to the Installation Manual.
Web: Delay After Reset [sec] [GWAppDelayTime]	<p>Defines the time interval (in seconds) that the device's operation is delayed after a reset.</p> <p>The valid range is 0 to 45. The default is 7 seconds.</p> <p>Note: This feature helps overcome connection problems caused by some LAN routers or IP configuration parameters' modifications by a DHCP server.</p>
[Mediant1000DualPowerSupplySupported]	<p>Determines whether the device sends raised alarms (to the SNMP client and/or Web interface) concerned with the Power Supply modules.</p> <ul style="list-style-type: none"> ▪ [1] = (Default) No alarms are sent. ▪ [2] = The device sends alarms if one of the Power Supply modules is removed from the chassis. These alarms are reflected in the SNMP and Web interface. <p>Notes:</p> <ul style="list-style-type: none"> ▪ For this parameter to take effect, a device reset is required. ▪ If this parameter is set to 2, for this feature to be functional, both Main and Redundant Power Supply modules must be present in the chassis.
[GroundKeyDetection]	<p>Enables analog ground-key detection for the device. The device's FXS and FXO modules implement ground-start signaling. When disabled, the device uses loop-start signaling.</p> <ul style="list-style-type: none"> ▪ [0] = Disable (default) ▪ [1] = Enable (enables ground start) <p>Notes:</p> <ul style="list-style-type: none"> ▪ For this parameter to take effect, a device reset is required. ▪ For ground-start signaling, ensure that the FXO G module is

Parameter	Description
	<p>installed (and not the regular FXO module) in the device's chassis.</p> <ul style="list-style-type: none"> For FXO ground-start signaling, ensure that the parameter EnableCurrentDisconnect is set to 1 and the parameter FXOBetweenRingTime is set to 300. FXS ground-start interface does not generate a ringing voltage. The FXS interface initiates the signaling by grounding of the TIP lead.
[EnableAutoRAITransmitBER]	<p>Enables the device to send a remote alarm indication (RAI) when the bit error rate (BER) is greater than 0.001.</p> <ul style="list-style-type: none"> [0] Disable (default) [1] Enable
Web: Ignore BRI LOS Alarm CLI: ignore-bri-los-alarm [IgnoreBRILOSAAlarm]	<p>Enables the device to ignore LOS alarms received from the BRI user-side trunk and attempts to make a call (relevant for IP-to-Tel calls).</p> <ul style="list-style-type: none"> [0] Disable [1] Enable (default)

52.3.2 SIP Test Call Parameters

The SIP Signaling Test Call parameters are described in the table below.

SIP Test Call Parameters

Parameter	Description
Web: Test Call DTMF String [TestCallDtmfString]	<p>Defines the DTMF tone that is played for answered test calls (incoming and outgoing).</p> <p>The DTMF string can be up to 15 strings. The default is "3212333". An empty string means that no DTMF is played.</p>
Web: Test Call ID [TestCallID]	<p>Defines the test call prefix number (<i>ID</i>) of the simulated phone on the device. Incoming calls received with this called prefix number are identified as test calls.</p> <p>This can be any string of up to 15 characters. By default, no number is defined.</p> <p>Note: This parameter is only for testing incoming calls destined to this prefix number.</p>
Test Call Table	
Web: Test Call Table [Test_Call]	<p>Defines the local and remote endpoints to be tested.</p> <p>[Test_Call]</p> <p>FORMAT Test_Call_Index = Test_Call_EndpointURI, Test_Call_CalledURI, Test_Call_RouteBy, Test_Call_IPGroupID, Test_Call_DestAddress, Test_Call_DestTransportType, Test_Call_SRD, Test_Call_ApplicationType, Test_Call_AutoRegister, Test_Call_UserName, Test_Call_Password, Test_Call_CallParty, Test_Call_MaxChannels, Test_Call_CallDuration, Test_Call_CallsPerSecond, Test_Call_TestMode, Test_Call_TestDuration, Test_Call_Play, Test_Call_ScheduleInterval;</p> <p>[Test_Call]</p> <p>Note: For a description of this table, see 'Configuring Test Calls' on page 595.</p>

52.3.3 Syslog, CDR and Debug Parameters

The Syslog, CDR and debug parameters are described in the table below.

Syslog, CDR and Debug Parameters

Parameter	Description
Web: Enable Syslog EMS: Syslog enable [EnableSyslog]	Determines whether the device sends logs and error messages (e.g., CDRs) generated by the device to a Syslog server. <ul style="list-style-type: none"> ▪ [0] Disable (default) ▪ [1] Enable Notes: <ul style="list-style-type: none"> ▪ If you enable Syslog, you must enter an IP address of the Syslog server (using the SyslogServerIP parameter). ▪ Syslog messages may increase the network traffic. ▪ To configure Syslog SIP message logging levels, use the GwDebugLevel parameter. ▪ By default, logs are also sent to the RS-232 serial port. For how to establish serial communication with the device, refer to the Installation Manual.
Web/EMS: Syslog Server IP Address [SyslogServerIP]	Defines the IP address (in dotted-decimal notation) of the computer on which the Syslog server is running. The Syslog server is an application designed to collect the logs and error messages generated by the device. The default IP address is 0.0.0.0.
Web: Syslog Server Port EMS: Syslog Server Port Number [SyslogServerPort]	Defines the UDP port of the Syslog server. The valid range is 0 to 65,535. The default port is 514.
[MaxBundleSyslogLength]	Defines the maximum size (in bytes) threshold of logged Syslog messages bundled into a single UDP packet, after which they are sent to a Syslog server. The valid value range is 0 to 1220 (where 0 indicates that no bundling occurs). The default is 1220. Note: This parameter is applicable only if the GwDebugLevel parameter is set to 7.
Web: CDR Server IP Address EMS: IP Address of CDR Server [CDRSyslogServerIP]	Defines the destination IP address to where CDR logs are sent. The default is a null string, which causes CDR messages to be sent with all Syslog messages to the Syslog server. Notes: <ul style="list-style-type: none"> ▪ The CDR messages are sent to UDP port 514 (default Syslog port). ▪ This mechanism is active only when Syslog is enabled (i.e., the parameter EnableSyslog is set to 1).
Web/EMS: CDR Report Level [CDRReportLevel]	Enables media- and signaling-related CDRs to be sent to a Syslog server and determines the call stage at which they are sent. <ul style="list-style-type: none"> ▪ [0] None = (Default) CDRs are not used. ▪ [1] End Call = CDR is sent to the Syslog server at the end of each call. ▪ [2] Start & End Call = CDR report is sent to Syslog at the start and end of each call. ▪ [3] Connect & End Call = CDR report is sent to Syslog at

Parameter	Description
	<p>connection and at the end of each call.</p> <ul style="list-style-type: none"> ▪ [4] Start & End & Connect Call = CDR report is sent to Syslog at the start, at connection, and at the end of each call. <p>Notes:</p> <ul style="list-style-type: none"> ▪ The CDR Syslog message complies with RFC 3161 and is identified by: Facility = 17 (local1) and Severity = 6 (Informational). ▪ This mechanism is active only when Syslog is enabled (i.e., the parameter EnableSyslog is set to 1).
<p>Web/EMS: Debug Level [GwDebugLevel]</p>	<p>Defines the Syslog debug logging level.</p> <ul style="list-style-type: none"> ▪ [0] 0 = (Default) Debug is disabled. ▪ [1] 1 = Flow debugging is enabled. ▪ [5] 5 = Flow, device interface, stack interface, session manager, and device interface expanded debugging are enabled. ▪ [7] 7 = This option is recommended when the device is running under "heavy" traffic. In this mode: <ul style="list-style-type: none"> ✓ The Syslog debug level automatically changes between level 5, level 1, and level 0, depending on the device's CPU consumption so that VoIP traffic isn't affected. ✓ Syslog messages are bundled into a single UDP packet, after which they are sent to a Syslog server (bundling size is determined by the MaxBundleSyslogLength parameter). Bundling reduces the number of UDP Syslog packets, thereby improving CPU utilization. <p>Note that when this option is used, in order to read Syslog messages with Wireshark, a special plug-in (i.e., acsyslog.dll) must be used. Once the plug-in is installed, the Syslog messages are decoded as "AC SYSLOG" and are displayed using the 'acsyslog' filter instead of the regular 'syslog' filter.</p> <p>Notes:</p> <ul style="list-style-type: none"> ▪ This parameter is typically set to 5 if debug traces are required. However, in cases of heavy traffic, option 7 is recommended. ▪ Options 2, 3, 4, and 6 are not recommended.
<p>Web: Syslog Facility Number EMS: SyslogFacility [SyslogFacility]</p>	<p>Defines the Facility level (0 through 7) of the device's Syslog messages, according to RFC 3164. This allows you to identify Syslog messages generated by the device. This is useful, for example, if you collect the device's and other equipments' Syslog messages, at one single server. The device's Syslog messages can easily be identified and distinguished from other Syslog messages by its Facility level. Therefore, in addition to filtering Syslog messages according to IP address, the messages can be filtered according to Facility level.</p> <ul style="list-style-type: none"> ▪ [16] = (Default) local use 0 (local0) ▪ [17] = local use 1 (local1) ▪ [18] = local use 2 (local2) ▪ [19] = local use 3 (local3) ▪ [20] = local use 4 (local4) ▪ [21] = local use 5 (local5) ▪ [22] = local use 6 (local6) ▪ [23] = local use 7 (local7)
<p>Web: Activity Types to Report via Activity Log Messages</p>	<p>Defines the Activity Log mechanism of the device, which sends log messages to a Syslog server for reporting certain types of Web</p>

Parameter	Description
[ActivityListToLog]	operations according to the below user-defined filters. <ul style="list-style-type: none"> ▪ [pvc] Parameters Value Change = Changes made on-the-fly to parameters. Note that the <i>ini</i> file parameter, EnableParametersMonitoring can also be used to set this option, using values [0] (disable) or [1] (enable). ▪ [afll] Auxiliary Files Loading = Loading of auxiliary files. ▪ [dr] Device Reset = Reset of device via the 'Maintenance Actions page. Note: For this option to take effect, a device reset is required. ▪ [fb] Flash Memory Burning = Burning of files or parameters to flash (in 'Maintenance Actions page). ▪ [swu] Device Software Update = cmp file loading via the Software Upgrade Wizard. ▪ [ard] Access to Restricted Domains = Access to restricted domains, which include the following Web pages: <ul style="list-style-type: none"> ✓ (1) ini parameters (AdminPage) ✓ (2) General Security Settings ✓ (3) Configuration File ✓ (4) IP Security Proposal / IP Security Associations Tables ✓ (5) Software Upgrade Key Status ✓ (6) Firewall Settings ✓ (7) Web & Telnet Access List ✓ (8) WEB User Accounts ▪ [naa] Non-Authorized Access = Attempt to access the Web interface with a false or empty user name or password. ▪ [spc] Sensitive Parameters Value Change = Changes made to sensitive parameters: <ul style="list-style-type: none"> ✓ (1) IP Address ✓ (2) Subnet Mask ✓ (3) Default Gateway IP Address ✓ (4) ActivityListToLog ▪ [ll] Login and Logout = Every login and logout attempt. For example: ActivityListToLog = 'pvc', 'afll', 'dr', 'fb', 'swu', 'ard', 'naa', 'spc' Note: For the <i>ini</i> file, values must be enclosed in single quotation marks.
[FacilityTrace]	Enables ISDN traces of Facility Information Elements (IE) for ISDN call diagnostics. This allows you to trace all the parameters contained in the Facility IE and view them in the Syslog. <ul style="list-style-type: none"> ▪ [0] Disable (default) ▪ [1] Enable Note: For this feature to be functional, the GWDebugLevel parameter must be enabled (i.e., set to at least level 1).
Web: Debug Recording Destination IP [DebugRecordingDestIP]	Defines the IP address of the server for capturing debug recording.
Web: Debug Recording Destination Port [DebugRecordingDestPort]	Defines the UDP port of the server for capturing debug recording. The default is 925.

Parameter	Description
Debug Recording Status [DebugRecordingStatus]	Activates or de-activates debug recording. <ul style="list-style-type: none"> [0] Stop (default) [1] Start
Logging Filters Table	
Web: Logging Filters Table [LoggingFilters]	This table parameter defines logging filtering rules for Syslog messages and debug recordings. The format of this parameter is as follows: [LoggingFilters] FORMAT LoggingFilters_Index = LoggingFilters_Type, LoggingFilters_Value, LoggingFilters_Syslog, LoggingFilters_CaptureType; [\LoggingFilters] Note: For a detailed description of this table, see 'Filtering Syslog Messages and Debug Recordings' on page 585.

52.3.4 Resource Allocation Indication Parameters

The Resource Allocation Indication (RAI) parameters are described in the table below.

RAI Parameters

Parameter	Description
[EnableRAI]	Enables RAI alarm generation if the device's busy endpoints exceed a user-defined threshold. <ul style="list-style-type: none"> [0] = (Default) Disable RAI (Resource Available Indication) service. [1] = RAI service enabled and an SNMP 'acBoardCallResourcesAlarm' Alarm Trap is sent.
[RAIHighThreshold]	Defines the high threshold percentage of total calls that are active (busy endpoints). When the percentage of the device's busy endpoints exceeds this high threshold, the device sends the SNMP acBoardCallResourcesAlarm alarm trap with a 'major' alarm status. The range is 0 to 100. The default is 90. Note: The percentage of busy endpoints is calculated by dividing the number of busy endpoints by the total number of "enabled" endpoints (trunks are physically connected and synchronized with no alarms and endpoints are defined in the Trunk Group Table).
[RAILowThreshold]	Defines the low threshold percentage of total calls that are active (busy endpoints). When the percentage of the device's busy endpoints falls below this low threshold, the device sends an SNMP acBoardCallResourcesAlarm alarm trap with a 'cleared' alarm status. The range is 0 to 100%. The default is 90%.
[RAILoopTime]	Defines the time interval (in seconds) that the device periodically checks call resource availability. The valid range is 1 to 200. The default is 10.

52.3.5 BootP Parameters

The BootP parameters are described in the table below. The BootP parameters are special 'hidden' parameters. Once defined and saved in the device's flash memory, they are used even if they don't appear in the *ini* file.

BootP Parameters

Parameter	Description		
[BootPRetries]	<p>Note: For this parameter to take effect, a device reset is required. This parameter is used to:</p> <table border="1"> <tr> <td> Defines the number of BootP requests that the device sends during start-up. The device stops sending BootP requests when either BootP reply is received or number of retries is reached. <ul style="list-style-type: none"> ▪ [1] = 1 BootP retry, 1 sec. ▪ [2] = 2 BootP retries, 3 sec. ▪ [3] = (Default) 3 BootP retries, 6 sec. ▪ [4] = 10 BootP retries, 30 sec. ▪ [5] = 20 BootP retries, 60 sec. ▪ [6] = 40 BootP retries, 120 sec. ▪ [7] = 100 BootP retries, 300 sec. ▪ [15] = BootP retries indefinitely. </td> <td> Defines the number of DHCP packets that the device sends. If after all packets are sent there's still no reply, the device loads from flash. <ul style="list-style-type: none"> ▪ [1] = 4 DHCP packets ▪ [2] = 5 DHCP packets ▪ [3] = (Default) 6 DHCP packets ▪ [4] = 7 DHCP packets ▪ [5] = 8 DHCP packets ▪ [6] = 9 DHCP packets ▪ [7] = 10 DHCP packets ▪ [15] = 18 DHCP packets </td> </tr> </table>	Defines the number of BootP requests that the device sends during start-up. The device stops sending BootP requests when either BootP reply is received or number of retries is reached. <ul style="list-style-type: none"> ▪ [1] = 1 BootP retry, 1 sec. ▪ [2] = 2 BootP retries, 3 sec. ▪ [3] = (Default) 3 BootP retries, 6 sec. ▪ [4] = 10 BootP retries, 30 sec. ▪ [5] = 20 BootP retries, 60 sec. ▪ [6] = 40 BootP retries, 120 sec. ▪ [7] = 100 BootP retries, 300 sec. ▪ [15] = BootP retries indefinitely. 	Defines the number of DHCP packets that the device sends. If after all packets are sent there's still no reply, the device loads from flash. <ul style="list-style-type: none"> ▪ [1] = 4 DHCP packets ▪ [2] = 5 DHCP packets ▪ [3] = (Default) 6 DHCP packets ▪ [4] = 7 DHCP packets ▪ [5] = 8 DHCP packets ▪ [6] = 9 DHCP packets ▪ [7] = 10 DHCP packets ▪ [15] = 18 DHCP packets
Defines the number of BootP requests that the device sends during start-up. The device stops sending BootP requests when either BootP reply is received or number of retries is reached. <ul style="list-style-type: none"> ▪ [1] = 1 BootP retry, 1 sec. ▪ [2] = 2 BootP retries, 3 sec. ▪ [3] = (Default) 3 BootP retries, 6 sec. ▪ [4] = 10 BootP retries, 30 sec. ▪ [5] = 20 BootP retries, 60 sec. ▪ [6] = 40 BootP retries, 120 sec. ▪ [7] = 100 BootP retries, 300 sec. ▪ [15] = BootP retries indefinitely. 	Defines the number of DHCP packets that the device sends. If after all packets are sent there's still no reply, the device loads from flash. <ul style="list-style-type: none"> ▪ [1] = 4 DHCP packets ▪ [2] = 5 DHCP packets ▪ [3] = (Default) 6 DHCP packets ▪ [4] = 7 DHCP packets ▪ [5] = 8 DHCP packets ▪ [6] = 9 DHCP packets ▪ [7] = 10 DHCP packets ▪ [15] = 18 DHCP packets 		
[BootPSelectiveEnable]	<p>Enables the Selective BootP mechanism.</p> <ul style="list-style-type: none"> ▪ [1] = Enabled ▪ [0] = Disabled (default) <p>The Selective BootP mechanism (available from Boot version 1.92) enables the device's integral BootP client to filter unsolicited BootP/DHCP replies (accepts only BootP replies that contain the text 'AUDC' in the vendor specific information field). This option is useful in environments where enterprise BootP/DHCP servers provide undesired responses to the device's BootP requests.</p> <p>Notes:</p> <ul style="list-style-type: none"> ▪ For this parameter to take effect, a device reset is required. ▪ When working with DHCP (i.e., the parameter DHCPEnable is set to 1), the selective BootP feature must be disabled. 		
[BootPDelay]	<p>Defines the interval between the device's startup and the first BootP/DHCP request that is issued by the device.</p> <ul style="list-style-type: none"> ▪ [1] = (Default) 1 second ▪ [2] = 3 second ▪ [3] = 6 second ▪ [4] = 30 second ▪ [5] = 60 second <p>Note: For this parameter to take effect, a device reset is required.</p>		
[ExtBootPReqEnable]	<p>Determines whether the device uses the Vendor Specific Information field in the BootP request to provide device-related initial startup information.</p>		

Parameter	Description
	<ul style="list-style-type: none"> ▪ [0] = (Default) Disabled. ▪ [1] = Enables extended information to be sent in BootP requests. The device uses the Vendor Specific Information field in the BootP request to provide device-related initial startup information such as device type, current IP address, software version. For a full list of the Vendor Specific Information fields, refer to the <i>AcBootP Utility User's Guide</i>. The AcBootP utility displays this information in the 'Client Info' column. <p>Notes:</p> <ul style="list-style-type: none"> ▪ For this parameter to take effect, a device reset is required. ▪ This option is not available on DHCP servers.

52.4 Security Parameters

This subsection describes the device's security parameters.

52.4.1 General Parameters

The general security parameters are described in the table below.

General Security Parameters

Parameter	Description
Web: Voice Menu Password [VoiceMenuPassword]	<p>Defines the password for accessing the device's FXS Voice menu used for configuring and monitoring the device.</p> <p>The default is 12345.</p> <p>Notes:</p> <ul style="list-style-type: none"> ▪ To activate the menu, connect a POTS telephone to an FXS port and dial *** (three stars) followed by the password. ▪ To disable the Voice menu, do any of the following: <ul style="list-style-type: none"> ✓ Set the VoiceMenuPassword parameter to 'disable'. ✓ Change the Web login password for the Admin user from its default value (i.e., 'Admin') to any other value, and then reset the device. ▪ This parameter is applicable only to FXS interfaces. ▪ For more information on the Voice menu, see FXS Voice Menu Guidance on page 31.
[EnableSecureStartup]	<p>Enables the Secure Startup mode. In this mode, downloading the ini file to the device is restricted to a URL provided in initial configuration (see the parameter IniFileURL) or using DHCP.</p> <ul style="list-style-type: none"> ▪ [0] Disable (default). ▪ [1] Enable = disables TFTP and allows secure protocols such as HTTPS to fetch the device configuration. <p>Note: For this parameter to take effect, a device reset is required.</p>
Firewall Table	

Parameter	Description
Web/EMS: Internal Firewall Parameters [AccessList]	<p>This table parameter defines the device's access list (firewall), which defines network traffic filtering rules.</p> <p>The format of this parameter is as follows: [AccessList] FORMAT AccessList_Index = AccessList_Source_IP, AccessList_Source_Port, AccessList_PrefixLen, AccessList_Source_Port, AccessList_Start_Port, AccessList_End_Port, AccessList_Protocol, AccessList_Use_Specific_Interface, AccessList_Interface_ID, AccessList_Packet_Size, AccessList_Byte_Rate, AccessList_Byte_Burst, AccessList_Allow_Type; [AccessList]</p> <p>For example: AccessList 10 = mgmt.customer.com, , , 32, 0, 80, tcp, 1, OAMP, 0, 0, 0, allow; AccessList 22 = 10.4.0.0, , , 16, 4000, 9000, any, 0, , 0, 0, 0, block;</p> <p>In the example above, Rule #10 allows traffic from the host 'mgmt.customer.com' destined to TCP ports 0 to 80 on interface OAMP (OAMP). Rule #22 blocks traffic from the subnet 10.4.xxx.yyy destined to ports 4000 to 9000.</p> <p>Note: For a description of this table, see 'Configuring Firewall Settings' on page 137.</p>

52.4.2 HTTPS Parameters

The Secure Hypertext Transport Protocol (HTTPS) parameters are described in the table below.

HTTPS Parameters

Parameter	Description
Web: Secured Web Connection (HTTPS) EMS: HTTPS Only [HTTPSOnly]	<p>Determines the protocol used to access the Web interface.</p> <ul style="list-style-type: none"> ▪ [0] HTTP and HTTPS (default). ▪ [1] HTTPs Only = Unencrypted HTTP packets are blocked. <p>Note: For this parameter to take effect, a device reset is required.</p>
EMS: HTTPS Port [HTTPSPort]	<p>Defines the local Secured HTTPS port of the device. This parameter allows secure remote device Web management from the LAN. To enable secure Web management from the LAN, configure the desired port.</p> <p>The valid range is 1 to 65535 (other restrictions may apply within this range). The default port is 443.</p> <p>Note: For this parameter to take effect, a device reset is required.</p>
Web/EMS: HTTPS Cipher String [HTTSPCipherString]	<p>Defines the Cipher string for HTTPS (in OpenSSL cipher list format). For the valid range values, refer to URL http://www.openssl.org/docs/apps/ciphers.html.</p> <p>The default is 'RC4:EXP' (Export encryption algorithms). For example, use 'ALL' for all ciphers suites (e.g., for ARIA encryption for TLS). The only ciphers available are RC4 and DES, and the cipher bit strength is limited to 56 bits.</p> <p>Notes:</p> <ul style="list-style-type: none"> ▪ For this parameter to take effect, a device reset is required. ▪ If the "Strong Encryption" Software License Key is enabled, the default of this parameter is changed to 'RC4:EXP', enabling RC-

Parameter	Description
	<p>128bit encryption.</p> <ul style="list-style-type: none"> The value 'ALL' can be configured only if the "Strong Encryption" Software License Key is enabled.
<p>Web: HTTP Authentication Mode EMS: Web Authentication Mode [WebAuthMode]</p>	<p>Determines the authentication mode used for the Web interface.</p> <ul style="list-style-type: none"> [0] Basic Mode = (Default) Basic authentication (clear text) is used. [1] Web Based Authentication = Digest authentication (MD5) is used. <p>Note: If you enable RADIUS login (i.e., the WebRADIUSLogin parameter is set to 1), you must set the WebAuthMode parameter to Basic Mode [0].</p>
<p>Web: Requires Client Certificates for HTTPS connection [HTTPSRequireClientCertificate]</p>	<p>Determines whether client certificates are required for HTTPS connection.</p> <ul style="list-style-type: none"> [0] Disable = (Default) Client certificates are not required. [1] Enable = Client certificates are required. The client certificate must be preloaded to the device and its matching private key must be installed on the managing PC. Time and date must be correctly set on the device for the client certificate to be verified. <p>Notes:</p> <ul style="list-style-type: none"> For this parameter to take effect, a device reset is required. For a description on implementing client certificates, see 'Client Certificates' on page 102.
[HTTPSRootFileName]	<p>Defines the name of the HTTPS trusted root certificate file to be loaded using TFTP. The file must be in base64-encoded PEM (Privacy Enhanced Mail) format.</p> <p>The valid range is a 47-character string.</p> <p>Note: This parameter is applicable only when the device is loaded using BootP/TFTP.</p>
[HTTPSPkeyFileName]	<p>Defines the name of a private key file (in unencrypted PEM format) to be loaded from the TFTP server.</p>
[HTTPSCertFileName]	<p>Defines the name of the HTTPS server certificate file to be loaded using TFTP. The file must be in base64-encoded PEM format.</p> <p>The valid range is a 47-character string.</p> <p>Note: This parameter is only applicable when the device is loaded using BootP/TFTP.</p>

52.4.3 SRTP Parameters

The Secure Real-Time Transport Protocol (SRTP) parameters are described in the table below.

SRTP Parameters

Parameter	Description
<p>Web: Media Security EMS: Enable Media Security [EnableMediaSecurity]</p>	<p>Enables Secure Real-Time Transport Protocol (SRTP).</p> <ul style="list-style-type: none"> [0] Disable = (Default) SRTP is disabled. [1] Enable = SRTP is enabled. <p>Note: For this parameter to take effect, a device reset is required.</p>
<p>Web/EMS: Media Security Behavior</p>	<p>Determines the device's mode of operation when SRTP is used (i.e., when the parameter EnableMediaSecurity is set to 1).</p>

Parameter	Description
[MediaSecurityBehavior]	<ul style="list-style-type: none"> ▪ [0] Preferable = (Default) The device initiates encrypted calls. However, if negotiation of the cipher suite fails, an unencrypted call is established. Incoming calls that don't include encryption information are accepted. ▪ [1] Mandatory = The device initiates encrypted calls, but if negotiation of the cipher suite fails, the call is terminated. Incoming calls that don't include encryption information are rejected. ▪ [2] Disable = The IP Profile for which this parameter is set does not support encrypted calls (i.e., SRTP). ▪ [3] Preferable - Single Media = The device sends SDP with a single media ('m=') line only (e.g., m=audio 6000 RTP/AVP 4 0 70 96) with RTP/AVP and crypto keys. The remote UA can respond with SRTP or RTP parameters: <ul style="list-style-type: none"> ✓ If the remote SIP UA does not support SRTP, it uses RTP and ignores the crypto lines. ✓ In the opposite direction, if the device receives an SDP offer with a single media (as shown above), it responds with SRTP (RTP/SAVP) if the EnableMediaSecurity parameter is set to 1. If SRTP is not supported (i.e., EnableMediaSecurity is set to 0), it responds with RTP. <p>Notes:</p> <ul style="list-style-type: none"> ▪ Before configuring this parameter, set the EnableMediaSecurity parameter to 1. ▪ If this parameter is set to Preferable [3] and two 'm=' lines are received in the SDP offer, the device prefers the SAVP (secure audio video profile) regardless of the order in the SDP. ▪ Option [2] Disable is applicable only to IP Profiles. ▪ This parameter can also be configured per IP Profile, using the IPProfile parameter (see 'Configuring IP Profiles' on page 245).
Web: Master Key Identifier (MKI) Size EMS: Packet MKI Size [SRTPTxPacketMKISize]	Defines the size (in bytes) of the Master Key Identifier (MKI) in SRTP Tx packets. The range is 0 to 4. The default is 0 (i.e., new keys are generated without MKI). <p>Notes:</p> <ul style="list-style-type: none"> ▪ For the GW/IP-to-IP application, the device only initiates the MKI size. ▪ You can also configure MKI size in an IP Profile.
Web: Symmetric MKI Negotiation EMS: Enable Symmetric MKI [EnableSymmetricMKI]	Enables symmetric MKI negotiation. <ul style="list-style-type: none"> ▪ [0] Disable = (Default) The device includes the MKI in its 200 OK response according to the SRTPTxPacketMKISize parameter (if set to 0, then it is not included; if set to any other value, it is included with this value). ▪ [1] Enable = The answer crypto line contains (or excludes) an MKI value according to the selected crypto line in the offer. For example, assume that the device receives an INVITE containing the following two crypto lines in SDP: <pre style="background-color: #f0f0f0; padding: 5px;">a=crypto:2 AES_CM_128_HMAC_SHA1_80 inline:TAaxNnQt8/qLQMnDuG4vxYfWl6K7eBK/ufk04pR4 2^31 1:1 a=crypto:3 AES_CM_128_HMAC_SHA1_80 inline:bnuYZnMxSfUiGitviWJZmzr70F3AiRO015Vnh0kH 2^31</pre> The first crypto line includes the MKI parameter "1:1". In the 200 OK response, the device selects one of the crypto lines (i.e., '2' or '3'). Typically, it selects the first line that supports the crypto suite. If the

Parameter	Description
	<p>device selects crypto line '2', it includes the MKI parameter in its answer SDP, for example:</p> <pre>a=crypto:2 AES_CM_128_HMAC_SHA1_80 inline:R1VyAlxV/qwBjkEklU4kSJy13wCtYeZLq1/QFuxw 2^31 1:1</pre> <p>If the device selects a crypto line that does not contain the MKI parameter, then the MKI parameter is not included in the crypto line in the SDP answer (even if the SRTPTxPacketMKISize parameter is set to any value other than 0).</p> <p>Notes:</p> <ul style="list-style-type: none"> To enable symmetric MKI, the SRTPTxPacketMKISize parameter must be set to any value other than 0. You can also enable MKI negotiation per IP Profile.
<p>Web/EMS: SRTP offered Suites [SRTPofferedSuites]</p>	<p>Defines the offered crypto suites (cipher encryption algorithms) for SRTP.</p> <ul style="list-style-type: none"> [0] = (Default) All available crypto suites. [1] CIPHER SUITES AES CM 128 HMAC SHA1 80 = device uses AES-CM encryption with a 128-bit key and HMAC-SHA1 message authentication with a 80-bit tag. [2] CIPHER SUITES AES CM 128 HMAC SHA1 32 = device uses AES-CM encryption with a 128-bit key and HMAC-SHA1 message authentication with a 32-bit tag. <p>Note: This parameter also affects the selection of the crypto in the device's answer. For example, if the device receives an offer with two crypto lines containing HMAC_SHA1_80 and HMAC_SHA_32, it uses the HMAC_SHA_32 key in its SIP 200 OK response if the parameter is set to 2.</p>
<p>Web: Disable Authentication On Transmitted RTP Packets EMS: RTP AuthenticationDisable Tx [RTPAuthenticationDisableTx]</p>	<p>Enables authentication on transmitted RTP packets in a secured RTP session.</p> <ul style="list-style-type: none"> [0] Enable (default) [1] Disable
<p>Web: Disable Encryption On Transmitted RTP Packets EMS: RTP EncryptionDisable Tx [RTPEncryptionDisableTx]</p>	<p>Enables encryption on transmitted RTP packets in a secured RTP session.</p> <ul style="list-style-type: none"> [0] Enable (default) [1] Disable
<p>Web: Disable Encryption On Transmitted RTCP Packets EMS: RTCP EncryptionDisable Tx [RTCPEncryptionDisableTx]</p>	<p>Enables encryption on transmitted RTCP packets in a secured RTP session.</p> <ul style="list-style-type: none"> [0] Enable (default) [1] Disable
<p>[ResetSRTPStateUponRekey]</p>	<p>Enables synchronization of the SRTP state between the device and a server when a new SRTP key is generated upon a SIP session expire.</p>

Parameter	Description
	<p>This feature ensures that the roll-over counter (ROC), one of the parameters used in the SRTP encryption/decryption process of the SRTP packets, is synchronized on both sides for transmit and receive packets.</p> <ul style="list-style-type: none"> ▪ [0] = (Default) Disabled. ROC is not reset on the device side. ▪ [1] = Enabled. If the session expires causing a session refresh through a re-INVITE, the device or server generates a new key and the device resets the ROC index (and other SRTP fields) as done by the server, resulting in a synchronized SRTP. <p>Notes:</p> <ul style="list-style-type: none"> ▪ This feature can also be configured for an IP Profile. ▪ If this feature is disabled and the server resets the ROC upon a re-key generation, one-way voice may occur.

52.4.4 TLS Parameters

The Transport Layer Security (TLS) parameters are described in the table below.

TLS Parameters

Parameter	Description
Web/EMS: TLS Version [TLSVersion]	<p>Determines the supported versions of SSL/TLS (Secure Socket Layer/Transport Layer Security).</p> <ul style="list-style-type: none"> ▪ [0] SSL 2.0-3.0 and TLS 1.0 = (Default) SSL 2.0, SSL 3.0, and TLS 1.0 are supported. ▪ [1] TLS 1.0 Only = only TLS 1.0 is used. <p>When set to 0, SSL/TLS handshakes always start with SSL 2.0 and switch to TLS 1.0 if both peers support it. When set to 1, TLS 1.0 is the only version supported; clients attempting to contact the device using SSL 2.0 are rejected.</p> <p>Note: For this parameter to take effect, a device reset is required.</p>
Web: TLS Client Re-Handshake Interval EMS: TLS Re Handshake Interval [TLSReHandshakeInterval]	<p>Defines the time interval (in minutes) between TLS Re-Handshakes initiated by the device.</p> <p>The interval range is 0 to 1,500 minutes. The default is 0 (i.e., no TLS Re-Handshake).</p>
Web: TLS Mutual Authentication EMS: SIPS Require Client Certificate [SIPSRequireClientCertificate]	<p>Determines the device's behavior when acting as a server for TLS connections.</p> <ul style="list-style-type: none"> ▪ [0] Disable = (Default) The device does not request the client certificate. ▪ [1] Enable = The device requires receipt and verification of the client certificate to establish the TLS connection. <p>Notes:</p> <ul style="list-style-type: none"> ▪ For this parameter to take effect, a device reset is required. ▪ The SIPS certificate files can be changed using the parameters HTTPSCertFileName and HTTPSRootFileName.
Web/EMS: Peer Host Name Verification Mode	<p>Determines whether the device verifies the Subject Name of a remote certificate when establishing TLS connections.</p>

Parameter	Description
[PeerHostNameVerificationMode]	<ul style="list-style-type: none"> ▪ [0] Disable (default). ▪ [1] Server Only = Verify Subject Name only when acting as a client for the TLS connection. ▪ [2] Server & Client = Verify Subject Name when acting as a server or client for the TLS connection. <p>When a remote certificate is received and this parameter is not disabled, the value of SubjectAltName is compared with the list of available Proxies. If a match is found for any of the configured Proxies, the TLS connection is established.</p> <p>The comparison is performed if the SubjectAltName is either a DNS name (DNSName) or an IP address. If no match is found and the SubjectAltName is marked as 'critical', the TLS connection is not established. If DNSName is used, the certificate can also use wildcards ("*") to replace parts of the domain name.</p> <p>If the SubjectAltName is not marked as 'critical' and there is no match, the CN value of the SubjectName field is compared with the parameter TLSRemoteSubjectName. If a match is found, the connection is established. Otherwise, the connection is terminated.</p> <p>Note: If you set this parameter to [2] (Server & Client), for this functionality to operate, you also need to set the SIPSPRequireClientCertificate parameter to [1] (Enable).</p>
Web: TLS Client Verify Server Certificate EMS: Verify Server Certificate [VerifyServerCertificate]	<p>Determines whether the device, when acting as a client for TLS connections, verifies the Server certificate. The certificate is verified with the Root CA information.</p> <ul style="list-style-type: none"> ▪ [0] Disable (default) ▪ [1] Enable <p>Note: If Subject Name verification is necessary, the parameter PeerHostNameVerificationMode must be used as well.</p>
Web: Strict Certificate Extension Validation [RequireStrictCert]	<p>Enables the validation of the extensions (keyUsage and extendedKeyUsage) of peer certificates. This validation ensures that the signing CA is authorized to sign certificates and that the end-entity certificate is authorized to negotiate a secure TLS connection.</p> <ul style="list-style-type: none"> ▪ [0] Disable (default) ▪ [1] Enable
Web/EMS: TLS Remote Subject Name [TLSRemoteSubjectName]	<p>Defines the Subject Name that is compared with the name defined in the remote side certificate when establishing TLS connections.</p> <p>If the SubjectAltName of the received certificate is not equal to any of the defined Proxies Host names/IP addresses and is not marked as 'critical', the Common Name (CN) of the Subject field is compared with this value. If not equal, the TLS connection is not established. If the CN uses a domain name, the certificate can also use wildcards ("*") to replace parts of the domain name.</p> <p>The valid range is a string of up to 49 characters.</p> <p>Note: This parameter is applicable only if the parameter PeerHostNameVerificationMode is set to 1 or 2.</p>

Parameter	Description
Web: Client Cipher String [TLSCClientCipherString]	Defines the cipher-suite string for TLS clients. The valid value is up to 255 strings. The default is "ALL:!ADH". For example: TLSCClientCipherString = 'EXP' This parameter complements the HTTPSCipherString parameter (which affects TLS servers). For possible values and additional details, refer to: http://www.openssl.org/docs/apps/ciphers.html
[TLSPkeySize]	Defines the key size (in bits) for RSA public-key encryption for newly self-signed generated keys for SSH. <ul style="list-style-type: none"> ▪ [512] ▪ [768] ▪ [1024] (default) ▪ [2048]

52.4.5 SSH Parameters

Secure Shell (SSH) parameters are described in the table below.

SSH Parameters

Parameter	Description
Web/EMS: Enable SSH Server [SSHServerEnable]	Enables the device's embedded SSH server. <ul style="list-style-type: none"> ▪ [0] Disable (default) ▪ [1] Enable
Web/EMS: Server Port [SSHServerPort]	Defines the port number for the embedded SSH server. Range is any valid port number. The default port is 22.
Web/EMS: SSH Admin Key [SSHAdminKey]	Defines the RSA public key for strong authentication for logging in to the SSH interface (if enabled). The value should be a base64-encoded string. The value can be a maximum length of 511 characters.
Web: Require Public Key EMS: EMS: SSH Require Public Key [SSHRequirePublicKey]	Enables RSA public keys for SSH. <ul style="list-style-type: none"> ▪ [0] = (Default) RSA public keys are optional if a value is configured for the parameter SSHAdminKey. ▪ [1] = RSA public keys are mandatory. Note: To define the key size, use the TLSPkeySize parameter.
Web: Max Payload Size EMS: SSH Max Payload Size [SSHMaxPayloadSize]	Defines the maximum uncompressed payload size (in bytes) for SSH packets. The valid value is 550 to 32768. The default is 32768.
Web: Max Binary Packet Size EMS: SSH Max Binary Packet Size [SSHMaxBinaryPacketSize]	Defines the maximum packet size (in bytes) for SSH packets. The valid value is 582 to 35000. The default is 35000.
EMS: Telnet SSH Max Sessions [SSHMaxSessions]	Defines the maximum number of simultaneous SSH sessions. The valid range is 1 to 2. The default is 2 sessions.

Parameter	Description
Web: Enable Last Login Message [SSHEnableLastLoginMessage]	Enables message display in SSH sessions of the time and date of the last SSH login. The SSH login message displays the number of unsuccessful login attempts since the last successful login. <ul style="list-style-type: none"> [0] Disable [1] Enable (default) Note: The last SSH login information is cleared when the device is reset.
Web: Max Login Attempts [SSHMaxLoginAttempts]	Defines the maximum SSH login attempts allowed for entering an incorrect password by an administrator before the SSH session is rejected. The valid range is 1 to 3. the default is 3.

52.4.6 IPsec Parameters

The Internet Protocol security (IPsec) parameters are described in the table below.

IPsec Parameters

Parameter	Description
IPsec Parameters	
Web: Enable IP Security EMS: IPsec Enable [EnableIPsec]	Enables IPsec on the device. <ul style="list-style-type: none"> [0] Disable (default) [1] Enable Note: For this parameter to take effect, a device reset is required.
Web: IKE Certificate Ext Validate [IKEcertificateExtValidate]	Enables the validation of the extensions (keyUsage and extendedKeyUsage) of peer certificates. This validation ensures that the signing CA is authorized to sign certificates and that the end-entity certificate is authorized to negotiate a secure IPsec connection. <ul style="list-style-type: none"> [0] Disable (default) [1] Enable
IPsec Associations Table	
Web: IP Security Associations Table EMS: IPsec SA Table [IPsecSATable]	This table parameter defines the IPsec SA table. This table allows you to configure the Internet Key Exchange (IKE) and IP Security (IPsec) protocols. You can define up to 20 IPsec peers. The format of this parameter is as follows: [IPsecSATable] FORMAT IPsecSATable_Index = IPsecSATable_RemoteEndpointAddressOrName, IPsecSATable_AuthenticationMethod, IPsecSATable_SharedKey, IPsecSATable_SourcePort, IPsecSATable_DestPort, IPsecSATable_Protocol, IPsecSATable_Phase1SaLifetimeInSec, IPsecSATable_Phase2SaLifetimeInSec, IPsecSATable_Phase2SaLifetimeInKB, IPsecSATable_DPDmode, IPsecSATable_IPsecMode, IPsecSATable_RemoteTunnelAddress, IPsecSATable_RemoteSubnetIPAddress, IPsecSATable_RemoteSubnetPrefixLength, IPsecSATable_InterfaceName; [\IPsecSATable] For example:

Parameter	Description
	IPsecSatable 1 = 0, 10.3.2.73, 0, 123456789, 0, 0, 0, 0, 28800, 3600, ; In the above example, a single IPsec/IKE peer (10.3.2.73) is configured. Pre-shared key authentication is selected, with the pre-shared key set to 123456789. In addition, a lifetime of 28800 seconds is selected for IKE and a lifetime of 3600 seconds is selected for IPsec. Note: For a detailed description of this table, see 'Configuring IP Security Associations Table' on page 144.
IPsec Proposal Table	
Web: IP Security Proposal Table EMS: IPsec Proposal Table [IPsecProposalTable]	This table parameter defines up to four IKE proposal settings, where each proposal defines an encryption algorithm, an authentication algorithm, and a Diffie-Hellman group identifier. [IPsecProposalTable] FORMAT IPsecProposalTable_Index = IPsecProposalTable_EncryptionAlgorithm, IPsecProposalTable_AuthenticationAlgorithm, IPsecProposalTable_DHGroup; [\IPsecProposalTable] For example: IPsecProposalTable 0 = 3, 2, 1; IPsecProposalTable 1 = 2, 2, 1; In the example above, two proposals are defined: <ul style="list-style-type: none"> ▪ Proposal 0: AES, SHA1, DH group 2 ▪ Proposal 1: 3DES, SHA1, DH group 2 Note: For a detailed description of this table, see 'Configuring IP Security Proposal Table' on page 143.

52.4.7 OCSP Parameters

The Online Certificate Status Protocol (OCSP) parameters are described in the table below.

OCSP Parameters

Parameter	Description
Web: Enable OCSP Server EMS: OCSP Enable [OCSPEnable]	Enables or disables certificate checking using OCSP. <ul style="list-style-type: none"> ▪ [0] Disable (default) ▪ [1] Enable
Web: Primary Server IP EMS: OCSP Server IP [OCSPServerIP]	Defines the IP address of the OCSP server. The default IP address is 0.0.0.0.
Web: Secondary Server IP [OCSPSecondaryServerIP]	Defines the IP address (in dotted-decimal notation) of the secondary OCSP server (optional). The default IP address is 0.0.0.0.
Web: Server Port EMS: OCSP Server Port [OCSPServerPort]	Defines the OCSP server's TCP port number. The default port number is 2560.
Web: Default Response	Determines the default OCSP behavior when the server cannot be

Parameter	Description
When Server Unreachable EMS: OCSP Default Response [OCSPDefaultResponse]	contacted. <ul style="list-style-type: none"> [0] Reject = (Default) Rejects peer certificate. [1] Allow = Allows peer certificate.

52.4.8 IDS Parameters

The Intrusion Detection System (IDS) parameters are described in the table below.

Table 52-1: IDS Parameters

Parameter	Description
Web: Intrusion Detection System (IDS) CLI: enable-ids [EnableIDS]	Enables the IDS feature. <ul style="list-style-type: none"> [0] Disable (default) [1] Enable Note: For this parameter to take effect, a device reset is required.
CLI: ids-clear-period [IDSArmClearPeriod]	Defines the interval (in seconds) after which an IDS alarm is cleared from the Active Alarms table if no thresholds are crossed during this time. However, this "quiet" period must be at least twice the Threshold Window value. For example, if IDSArmClearPeriod is set to 20 sec and the Threshold Window is set to 15 sec, the IDSArmClearPeriod parameter is ignored and the alarm is cleared only after 30 seconds (2 x 15 sec). The valid value is 0 to 86400. The default is 300.
IDS Policy Table	
Web: IDS Policy Table [IDSPolicy]	Defines IDS Policies. The format of the ini file parameter is: [IDSPolicy] FORMAT IDSPolicy_Index = IDSPolicy_Name, IDSPolicy_Description; [\IDSPolicy] For a detailed description of this table, see 'Configuring IDS Policies' on page 149 .
IDS Rule Table	
Web: IDS Rule Table [IDSRule]	Defines rules for the IDS Policies. The format of the ini file parameter is: [IDSRule] FORMAT IDSRule_Index = IDSRule_Policy, IDSRule_RuleID, IDSRule_Reason, IDSRule_ThresholdScope, IDSRule_ThresholdWindow, IDSRule_MinorAlarmThreshold, IDSRule_MajorAlarmThreshold, IDSRule_CriticalAlarmThreshold; [\IDSRule] For a detailed description of this table, see 'Configuring IDS Policies' on page 149 .
IDS Match Table	

Parameter	Description
Web: IDS Match Table [IDSMATCH]	Defines target rules per IDS Policy. The format of the ini file parameter is: [IDSMATCH] FORMAT IDSMATCH_Index = IDSMATCH_SIPInterface, IDSMATCH_ProxySet, IDSMATCH_Subnet, IDSMATCH_Policy; [\IDSMATCH] For a detailed description of this table, see 'Assigning IDS Policies' on page 152.

52.5 RADIUS Parameters

The RADIUS parameters are described in the table below. For supported RADIUS attributes, see 'RADIUS Accounting CDR Attributes' on page 571.

RADIUS Parameters

Parameter	Description
RADIUS Accounting Parameters	
Web: Enable RADIUS Access Control [EnableRADIUS]	Enables the RADIUS application. <ul style="list-style-type: none"> ▪ [0] Disable (Default) ▪ [1] Enable Note: For this parameter to take effect, a device reset is required.
Web: Accounting Server IP Address [RADIUSAccServerIP]	Defines the IP address of the RADIUS accounting server.
Web: Accounting Port [RADIUSAccPort]	Defines the port of the RADIUS accounting server. The default is 1646.
Web/EMS: RADIUS Accounting Type [RADIUSAccountingType]	Determines when the RADIUS accounting messages are sent to the RADIUS accounting server. <ul style="list-style-type: none"> ▪ [0] At Call Release = (Default) Sent at call release only. ▪ [1] At Connect & Release = Sent at call connect and release. ▪ [2] At Setup & Release = Sent at call setup and release.
Web: AAA Indications EMS: Indications [AAAIindications]	Determines the Authentication, Authorization and Accounting (AAA) indications. <ul style="list-style-type: none"> ▪ [0] None = (Default) No indications. ▪ [3] Accounting Only = Only accounting indications are used.
General RADIUS Parameters	
Web: Use RADIUS for Web/Telnet Login EMS: Web Use Radius Login [WebRADIUSLogin]	Enables RADIUS queries for Web and Telnet login authentication. When enabled, logging into the device's Web and Telnet embedded servers is done through a RADIUS server. The device communicates with a user-defined RADIUS server and verifies the given username and password against a remote database, in a secure manner. <ul style="list-style-type: none"> ▪ [0] Disable (default) ▪ [1] Enable Notes:

Parameter	Description
	<ul style="list-style-type: none"> ▪ For RADIUS login authentication to function, you also need to set the following parameters: <ul style="list-style-type: none"> ✓ EnableRADIUS = 1 (Enable) ✓ WebAuthMode = 0 (Basic Mode) ▪ RADIUS authentication requires HTTP basic authentication, where the username and password are transmitted in clear text over the network. Therefore, it's recommended to set the HTTPSONly parameter to 1 in order to force the use of HTTPS, since the transport is encrypted. ▪ If using RADIUS authentication to log into the CLI, only the primary Web User Account, which has Security Administration access level, can access the device's CLI (see 'Configuring Web User Accounts' on page 64).
Web: RADIUS Authentication Server IP Address EMS: RADIUS Auth Server IP [RADIUSAuthServerIP]	Defines the IP address of the RADIUS authentication server. Note: For this parameter to take effect, a device reset is required.
Web: RADIUS Authentication Server Port EMS: RADIUS Auth Server Port [RADIUSAuthPort]	Defines the port of the RADIUS Authentication Server. Note: For this parameter to take effect, a device reset is required.
Web: RADIUS Shared Secret EMS: RADIUS Auth Server Secret [SharedSecret]	Defines the 'Secret' used to authenticate the device to the RADIUS server. This should be a cryptically strong password.
RADIUS Authentication Parameters	
Web: Default Access Level [DefaultAccessLevel]	Defines the default access level for the device when the RADIUS (authentication) response doesn't include an access level attribute. The valid range is 0 to 255. The default is 200 (i.e., Security Administrator).
Web: Device Behavior Upon RADIUS Timeout [BehaviorUponRadiusTimeout]	Defines the device's response upon a RADIUS timeout. <ul style="list-style-type: none"> ▪ [0] Deny Access = Denies access. ▪ [1] Verify Access Locally = (Default) Checks password locally.
Web: Local RADIUS Password Cache Mode [RadiusLocalCacheMode]	Determines the device's mode of operation regarding the timer (configured by the parameter RadiusLocalCacheTimeout) that determines the validity of the user name and password (verified by the RADIUS server). <ul style="list-style-type: none"> ▪ [0] Absolute Expiry Timer = When you access a Web page, the timeout doesn't reset, instead it continues decreasing. ▪ [1] Reset Timer Upon Access = (Default) Upon each access to a Web page, the timeout always resets (reverts to the initial value configured by RadiusLocalCacheTimeout).
Web: Local RADIUS Password Cache Timeout [RadiusLocalCacheTime]	Defines the time (in seconds) the locally stored user name and password (verified by the RADIUS server) are valid. When this time expires, the user name and password become invalid and a must be re-

Parameter	Description
out]	verified with the RADIUS server. The valid range is 1 to 0xFFFFFFFF. The default is 300 (5 minutes). <ul style="list-style-type: none"> ▪ [-1] = Never expires. ▪ [0] = Each request requires RADIUS authentication.
Web: RADIUS VSA Vendor ID [RadiusVSAVendorID]	Defines the vendor ID that the device accepts when parsing a RADIUS response packet. The valid range is 0 to 0xFFFFFFFF. The default is 5003.
Web: RADIUS VSA Access Level Attribute [RadiusVSAAccessAttribute]	Defines the code that indicates the access level attribute in the Vendor Specific Attributes (VSA) section of the received RADIUS packet. The valid range is 0 to 255. The default is 35.
[MaxRADIUSSessions]	Defines the number of concurrent calls that can communicate with the RADIUS server (optional). The valid range is 0 to 240. The default is 240.
EMS: RADIUS Auth Number of Retries [RADIUSRetransmission]	Defines the number of retransmission retries. The valid range is 1 to 10. The default is 3.
[RadiusTO]	Defines the time interval (measured in seconds) that the device waits for a response before a RADIUS retransmission is issued. The valid range is 1 to 30. The default is 10.

52.6 SIP Media Realm Parameters

The Media Realm parameters are described in the table below.

Media Realm Parameters

Parameter	Description
Media Realm Table	
Web: Media Realm Table EMS: VoIP > Media > Media Realm [CpMediaRealm]	This table parameter defines the Media Realm table. The Media Realm table allows you to divide a Media-type interface (defined in the Multiple Interface table) into several realms, where each realm is specified by a UDP port range. The format of this parameter is as follows: [CpMediaRealm] FORMAT CpMediaRealm_Index = CpMediaRealm_MediaRealmName, CpMediaRealm_IPv4IF, CpMediaRealm_IPv6IF, CpMediaRealm_PortRangeStart, CpMediaRealm_MediaSessionLeg, CpMediaRealm_PortRangeEnd, CpMediaRealm_TransRateRatio, CpMediaRealm_IsDefault; [CpMediaRealm] For example, CpMediaRealm 1 = Mrealm1, Voice, , 6600, 20, 6790, , 1; CpMediaRealm 2 = Mrealm2, Voice, , 6800, 10, 6890; , 0; Notes: <ul style="list-style-type: none"> ▪ For this parameter to take effect, a device reset is required.

Parameter	Description
	<ul style="list-style-type: none"> For a detailed description of this table, see 'Configuring Media Realms' on page 183.
Bandwidth Management per Media Realm Table	
Web: Bandwidth Management [BWManagement]	<p>This table parameter defines bandwidth management rules per Media Realm.</p> <p>The format of this parameter is as follows:</p> <p>[BWManagement] FORMAT BWManagement_Index = BWManagement_MediaRealmIndex, BWManagement_ThresholdIndex, BWManagement_RuleAction, BWManagement_Threshold, BWManagement_Hysteresis; [\BWManagement]</p> <p>Where ThresholdIndex is the bandwidth threshold rule type:</p> <ul style="list-style-type: none"> [0] High Threshold Rule [1] Critical Threshold Rule <p>Notes:</p> <ul style="list-style-type: none"> For this parameter to take effect, a device reset is required. This table can include up to two row entries (where 0 is the first index). For a detailed description of this table, see 'Configuring Bandwidth Management per Media Realm' on page 188.
Quality of Experience Parameters	
Web: Server IP CLI: server-ip [QOEServerIP]	<p>Defines the IP address of AudioCodes Session Experience Manager (SEM) server to where the quality experience reports are sent.</p> <p>Note: For this parameter to take effect, a device reset is required.</p>
Web: Port [QOEPort]	<p>Defines the port of the SEM server.</p> <p>The valid value range is 0 to 65534. The default is 5000.</p>
Web: Interface Name [QOEInterfaceName]	<p>Defines the IP network interface on which the quality experience reports are sent.</p> <p>The default is the OAMP interface.</p> <p>Note: For this parameter to take effect, a device reset is required.</p>
Web: Connection Mode [QOEConnectionMode]	<p>Defines the connection between the device and the SEM.</p> <ul style="list-style-type: none"> [0] Server = The device receives connection from the server. [1] Client (default) = The device connects to the SEM. [2] None <p>Note: Currently, only the client connection is supported.</p>
Web: Information Level [QOEInformationLevel]	<p>Defines the level (i.e., amount of detail) of voice quality information that is sent to the SEM server.</p> <ul style="list-style-type: none"> [0] Standard (default) [1] Enhanced [2] Debug

Parameter	Description
Web: Use Mos LQ [QOEUseMosLQ]	Enables the reporting of the MOS-LQ (listening quality). If disabled, the MOS-CQ (conversational quality) is reported. MOS-LQ measures the quality of audio for listening purposes only. MOS-LQ does not take into account bi-directional effects such as delay and echo. MOS-CQ takes into account listening quality in both directions, as well as the bi-directional effects. <ul style="list-style-type: none"> ▪ [0] Disable (default) ▪ [1] Enable
Media Realm > Quality of Experience Table	
Web: Media Realm > Quality Of Experience EMS: Media > Media Realm > Voice Quality Rules [QOERules]	This table configures Quality of Experience parameters per Media Realm. [QOERules] ORMAT QOERules_Index = QOERules_MediaRealmIndex, QOERules_RuleIndex, QOERules_MonitoredParam, QOERules_Direction, QOERules_Profile, QOERules_GreenYellowThreshold, QOERules_GreenYellowHysteresis, QOERules_YellowRedThreshold, QOERules_YellowRedHysteresis, QOERules_GreenYellowOperation, QOERules_GreenYellowOperationDetails, QOERules_YellowRedOperation, QOERules_YellowRedOperationDetails; [\QOERules] Note: For a detailed description of this table, see Configuring Quality of Experience Parameters per Media Realm on page 185.

52.7 Control Network Parameters

52.7.1 IP Group, Proxy, Registration and Authentication Parameters

The proxy server, registration and authentication SIP parameters are described in the table below.

Proxy, Registration and Authentication SIP Parameters

Parameter	Description
IP Group Table	
Web: IP Group Table EMS: Endpoints > IP Group [IPGroup]	This table configures IP Groups. The ini file format of this parameter is as follows: [IPGroup] FORMAT IPGroup_Index = IPGroup_Type, IPGroup_Description, IPGroup_ProxySetId, IPGroup_SIPGroupName, IPGroup_ContactUser, IPGroup_EnableSurvivability, IPGroup_ServingIPGroup, IPGroup_SipReRoutingMode, IPGroup_AlwaysUseRouteTable, IPGroup_RoutingMode, IPGroup_SRD, IPGroup_MediaRealm, IPGroup_ClassifyByProxySet, IPGroup_ProfileId, IPGroup_MaxNumOfRegUsers, IPGroup_InboundManSet, IPGroup_OutboundManSet, IPGroup_RegistrationMode, IPGroup_AuthenticationMode, IPGroup_MethodList, IPGroup_EnableSBCCClientForking, IPGroup_SourceUriInput, IPGroup_DestUriInput, IPGroup_ContactName;

Parameter	Description
	<p>[/IPGroup]</p> <p>Notes:</p> <ul style="list-style-type: none"> ▪ For this parameter to take effect, a device reset is required. ▪ For a description of this table, see 'Configuring IP Groups' on page 214.
Authentication per Port Table	
<p>Web: Authentication Table EMS: SIP Endpoints > Authentication [Authentication]</p>	<p>This table parameter defines a user name and password for authenticating each device port. The format of this parameter is as follows:</p> <p>[Authentication] FORMAT Authentication_Index = Authentication_UserId, Authentication_UserPassword, Authentication_Module, Authentication_Port; [Authentication]</p> <p>Where,</p> <ul style="list-style-type: none"> ▪ Module = Module number, where 1 denotes the module in Slot 1 ▪ Port = Port number, where 1 denotes the Port 1 of the module <p>For example: Authentication 1 = lee,1552,1,2; (user name "lee" with password 1552 for authenticating Port 2 of Module 1)</p> <p>Notes:</p> <ul style="list-style-type: none"> ▪ The indexing of this parameter starts at 0. ▪ For a description o this table, see Configuring Authentication on page 393.
Account Table	
<p>Web: Account Table EMS: SIP Endpoints > Account [Account]</p>	<p>This table parameter configures the Account table for registering and/or authenticating (digest) Trunk Groups or IP Groups (e.g., an IP-PBX) to another Serving IP Group (e.g., an Internet Telephony Service Provider - ITSP). The format of this parameter is as follows:</p> <p>[Account] FORMAT Account_Index = Account_ServedTrunkGroup, Account_ServedIPGroup, Account_ServingIPGroup, Account_Username, Account_Password, Account_HostName, Account_Register, Account_ContactUser, Account_ApplicationType; [Account]</p> <p>For example: Account 1 = 1, -1, 1, user, 1234, acl, 1, ITSP1;</p> <p>Note: For a detailed description of this table, see 'Configuring Account Table' on page 225.</p>
Proxy Registration Parameters	
<p>Web: Use Default Proxy EMS: Proxy Used [IsProxyUsed]</p>	<p>Enables the use of a SIP proxy server.</p> <ul style="list-style-type: none"> ▪ [0] No = (Default) Proxy isn't used and instead, the internal routing table is used.

Parameter	Description
	<ul style="list-style-type: none"> ▪ [1] Yes = Proxy server is used. Define the IP address of the proxy server in the Proxy Sets table (see 'Configuring Proxy Sets Table' on page 219). <p>Note: If you are not using a proxy server, you must define outbound IP call routing rules in the Outbound IP Routing Table (described in Configuring Outbound IP Routing Table on page 323).</p>
Web/EMS: Proxy Name [ProxyName]	Defines the Home Proxy domain name. If specified, this name is used as the Request-URI in REGISTER, INVITE and other SIP messages, and as the host part of the To header in INVITE messages. If not specified, the Proxy IP address is used instead. The valid value is a string of up to 49 characters. <p>Note: This parameter functions together with the UseProxyIPasHost parameter.</p>
Web: Use Proxy IP as Host [UseProxyIPasHost]	Enables the use of the proxy server's IP address (in dotted-decimal notation) as the host name in SIP From and To headers in REGISTER requests. <ul style="list-style-type: none"> ▪ [0] Disable (default) ▪ [1] Enable If this parameter is disabled and the device registers to an IP Group (i.e., proxy server), it uses the string configured by the ProxyName parameter as the host name in the REGISTER's Request-URI and uses the string configured by the IP Group table parameter, SIPGroupName as the host name in the To and From headers. If the IP Group is configured with a Proxy Set that has multiple IP addresses, all the REGISTER messages sent to these proxies are sent with the same host name. <p>Note: If this parameter is disabled and the ProxyName parameter is not configured, the proxy's IP address is used as the host name in the REGISTER Request-URI.</p>
Web: Redundancy Mode EMS: Proxy Redundancy Mode [ProxyRedundancyMode]	Determines whether the device switches back to the primary Proxy after using a redundant Proxy. <ul style="list-style-type: none"> ▪ [0] Parking = (Default) The device continues working with a redundant (now active) Proxy until the next failure, after which it works with the next redundant Proxy. ▪ [1] Homing = The device always tries to work with the primary Proxy server (i.e., switches back to the primary Proxy whenever it's available). <p>Note: To use this Proxy Redundancy mechanism, you need to enable the keep-alive with Proxy option, by setting the parameter EnableProxyKeepAlive to 1 or 2.</p>
Web: Proxy IP List Refresh Time EMS: IP List Refresh Time [ProxyIPListRefreshTime]	Defines the time interval (in seconds) between each Proxy IP list refresh. The range is 5 to 2,000,000. The default interval is 60.
Web: Enable Fallback to Routing Table EMS: Fallback Used [IsFallbackUsed]	Determines whether the device falls back to the Outbound IP Routing Table for call routing when Proxy servers are unavailable. <ul style="list-style-type: none"> ▪ [0] Disable = (Default) Fallback is not used. ▪ [1] Enable = The Outbound IP Routing Table is used when Proxy servers are unavailable.

Parameter	Description
	<p>When the device falls back to the Outbound IP Routing Table, it continues scanning for a Proxy. When the device locates an active Proxy, it switches from internal routing back to Proxy routing.</p> <p>Note: To enable the redundant Proxies mechanism, set the parameter EnableProxyKeepAlive to 1 or 2.</p>
Web/EMS: Prefer Routing Table [PreferRouteTable]	<p>Determines whether the device's internal routing table takes precedence over a Proxy for routing calls.</p> <ul style="list-style-type: none"> ▪ [0] No = (Default) Only a Proxy server is used to route calls. ▪ [1] Yes = The device checks the routing rules in the Outbound IP Routing Table for a match with the Tel-to-IP call. Only if a match is not found is a Proxy used.
Web/EMS: Always Use Proxy [AlwaysSendToProxy]	<p>Determines whether the device sends SIP messages and responses through a Proxy server.</p> <ul style="list-style-type: none"> ▪ [0] Disable = (Default) Use standard SIP routing rules. ▪ [1] Enable = All SIP messages and responses are sent to the Proxy server. <p>Note: This parameter is applicable only if a Proxy server is used (i.e., the parameter IsProxyUsed is set to 1).</p>
Web: SIP ReRouting Mode EMS: SIP Re-Routing Mode [SIPreroutingMode]	<p>Determines the routing mode after a call redirection (i.e., a 3xx SIP response is received) or transfer (i.e., a SIP REFER request is received).</p> <ul style="list-style-type: none"> ▪ [0] Standard = (Default) INVITE messages that are generated as a result of Transfer or Redirect are sent directly to the URI, according to the Refer-To header in the REFER message, or Contact header in the 3xx response. ▪ [1] Proxy = Sends a new INVITE to the Proxy. Note: This option is applicable only if a Proxy server is used and the parameter AlwaysSendtoProxy is set to 0. ▪ [2] Routing Table = Uses the Routing table to locate the destination and then sends a new INVITE to this destination. <p>Notes:</p> <ul style="list-style-type: none"> ▪ When this parameter is set to [1] and the INVITE sent to the Proxy fails, the device re-routes the call according to the Standard mode [0]. ▪ When this parameter is set to [2] and the INVITE fails, the device re-routes the call according to the Standard mode [0]. If DNS resolution fails, the device attempts to route the call to the Proxy. If routing to the Proxy also fails, the Redirect/Transfer request is rejected. ▪ When this parameter is set to [2], the XferPrefix parameter can be used to define different routing rules for redirect calls. ▪ This parameter is disregarded if the parameter AlwaysSendToProxy is set to 1.
Web/EMS: DNS Query Type [DNSQueryType]	<p>Enables the use of DNS Naming Authority Pointer (NAPTR) and Service Record (SRV) queries to resolve Proxy and Registrar servers and to resolve all domain names that appear in the SIP Contact and Record-Route headers.</p> <ul style="list-style-type: none"> ▪ [0] A-Record (default) ▪ [1] SRV ▪ [2] NAPTR <p>If set to A-Record [0], no NAPTR or SRV queries are performed.</p>

Parameter	Description
	<p>If set to SRV [1] and the Proxy/Registrar IP address parameter, Contact/Record-Route headers, or IP address defined in the Routing tables contain a domain name, an SRV query is performed. The device uses the first host name received from the SRV query. The device then performs a DNS A-record query for the host name to locate an IP address.</p> <p>If set to NAPTR [2], an NAPTR query is performed. If it is successful, an SRV query is sent according to the information received in the NAPTR response. If the NAPTR query fails, an SRV query is performed according to the configured transport type.</p> <p>If the Proxy/Registrar IP address parameter, the domain name in the Contact/Record-Route headers, or the IP address defined in the Routing tables contain a domain name with port definition, the device performs a regular DNS A-record query.</p> <p>If a specific Transport Type is defined, a NAPTR query is not performed.</p> <p>Note: To enable NAPTR/SRV queries for Proxy servers only, use the parameter ProxyDNSQueryType.</p>
Web: Proxy DNS Query Type [ProxyDNSQueryType]	<p>Enables the use of DNS Naming Authority Pointer (NAPTR) and Service Record (SRV) queries to discover Proxy servers.</p> <ul style="list-style-type: none"> ▪ [0] A-Record (default) ▪ [1] SRV ▪ [2] NAPTR <p>If set to A-Record [0], no NAPTR or SRV queries are performed.</p> <p>If set to SRV [1] and the Proxy IP address parameter contains a domain name without port definition (e.g., ProxyIP = domain.com), an SRV query is performed. The SRV query returns up to four Proxy host names and their weights. The device then performs DNS A-record queries for each Proxy host name (according to the received weights) to locate up to four Proxy IP addresses. Therefore, if the first SRV query returns two domain names and the A-record queries return two IP addresses each, no additional searches are performed.</p> <p>If set to NAPTR [2], an NAPTR query is performed. If it is successful, an SRV query is sent according to the information received in the NAPTR response. If the NAPTR query fails, an SRV query is performed according to the configured transport type.</p> <p>If the Proxy IP address parameter contains a domain name with port definition (e.g., ProxyIP = domain.com:5080), the device performs a regular DNS A-record query.</p> <p>If a specific Transport Type is defined, a NAPTR query is not performed.</p> <p>Note: When enabled, NAPTR/SRV queries are used to discover Proxy servers even if the parameter DNSQueryType is disabled.</p>
Web/EMS: Use Gateway Name for OPTIONS [UseGatewayNameForOptions]	<p>Determines whether the device uses its IP address or gateway name in keep-alive SIP OPTIONS messages.</p> <ul style="list-style-type: none"> ▪ [0] No = (Default) Use the device's IP address in keep-alive OPTIONS messages. ▪ [1] Yes = Use 'Gateway Name' (SIPGatewayName) in keep-alive OPTIONS messages. <p>The OPTIONS Request-URI host part contains either the device's IP address or a string defined by the parameter SIPGatewayName. The</p>

Parameter	Description
	device uses the OPTIONS request as a keep-alive message to its primary and redundant Proxies (i.e., the parameter EnableProxyKeepAlive is set to 1).
Web/EMS: User Name [UserName]	<p>Defines the user name used for registration and Basic/Digest authentication with a Proxy/Registrar server.</p> <p>The default is an empty string.</p> <p>Notes:</p> <ul style="list-style-type: none"> This parameter is applicable only if single device registration is used (i.e., the parameter AuthenticationMode is set to authentication per gateway). Instead of configuring this parameter, the Authentication table can be used (see Authentication on page 393).
Web/EMS: Password [Password]	<p>Defines the password for Basic/Digest authentication with a Proxy/Registrar server. A single password is used for all device ports.</p> <p>The default is 'Default_Passwd'.</p> <p>Note: Instead of configuring this parameter, the Authentication table can be used (see Authentication on page 393).</p>
Web/EMS: Cnonce [Cnonce]	<p>Defines the Cnonce string used by the SIP server and client to provide mutual authentication.</p> <p>The value is free format, i.e., 'Cnonce = 0a4f113b'. The default is 'Default_Cnonce'.</p>
Web/EMS: Mutual Authentication Mode [MutualAuthenticationMode]	<p>Determines the device's mode of operation when Authentication and Key Agreement (AKA) Digest Authentication is used.</p> <ul style="list-style-type: none"> [0] Optional = (Default) Incoming requests that don't include AKA authentication information are accepted. [1] Mandatory = Incoming requests that don't include AKA authentication information are rejected.
Web/EMS: Challenge Caching Mode [SIPChallengeCachingMode]	<p>Determines the mode for Challenge Caching, which reduces the number of SIP messages transmitted through the network. The first request to the Proxy is sent without authorization. The Proxy sends a 401/407 response with a challenge. This response is saved for further uses. A new request is re-sent with the appropriate credentials. Subsequent requests to the Proxy are automatically sent with credentials (calculated from the saved challenge). If the Proxy doesn't accept the new request and sends another challenge, the old challenge is replaced with the new one.</p> <ul style="list-style-type: none"> [0] None = (Default) Challenges are not cached. Every new request is sent without preliminary authorization. If the request is challenged, a new request with authorization data is sent. [1] INVITE Only = Challenges issued for INVITE requests are cached. This prevents a mixture of REGISTER and INVITE authorizations. [2] Full = Caches all challenges from the proxies. <p>Note: Challenge Caching is used with all proxies and not only with the active one.</p>
Proxy IP Table	
Web: Proxy IP Table EMS: Proxy IP	This table parameter configures the Proxy Set table with Proxy Set IDs, each with up to five Proxy server IP addresses (or fully qualified domain

Parameter	Description
[ProxyIP]	name/FQDN). Each Proxy Set can be defined with a transport type (UDP, TCP, or TLS). The format of this parameter is as follows: [ProxyIP] FORMAT ProxyIp_Index = ProxyIp_IpAddress, ProxyIp_TransportType, ProxyIp_ProxySetId; [ProxyIP] For example: ProxyIp 0 = 10.33.37.77, -1, 0; ProxyIp 1 = 10.8.8.10, 0, 2; ProxyIp 2 = 10.5.6.7, -1, 1; Notes: <ul style="list-style-type: none"> ▪ To assign various attributes (such as Proxy Load Balancing) per Proxy Set ID, use the parameter ProxySet. ▪ For a description of this table, see 'Configuring Proxy Sets Table' on page 219.
Proxy Set Table	
Web: Proxy Set Table EMS: Proxy Set [ProxySet]	This table parameter configures the Proxy Set ID table. It is used in conjunction with the ProxyIP table ini file parameter, which defines the IP addresses per Proxy Set ID. The ProxySet table ini file parameter defines additional attributes per Proxy Set ID. This includes, for example, Proxy keep-alive and load balancing and redundancy mechanisms (if a Proxy Set contains more than one proxy address). The format of this parameter is as follows: [ProxySet] FORMAT ProxySet_Index = ProxySet_EnableProxyKeepAlive, ProxySet_ProxyKeepAliveTime, ProxySet_ProxyLoadBalancingMethod, ProxySet_IsProxyHotSwap, ProxySet_SRD, ProxySet_ClassificationInput, ProxySet_ProxyRedundancyMode; [ProxySet] For example: ProxySet 0 = 0, 60, 0, 0, 0, , 1; ProxySet 1 = 1, 60, 1, 0, 1, , 0; Notes: <ul style="list-style-type: none"> ▪ For configuring the Proxy Set IDs and their IP addresses, use the parameter ProxyIP. ▪ For a description of this table, see 'Configuring Proxy Sets Table' on page 219.
Registrar Parameters	
Web: Enable Registration EMS: Is Register Needed [IsRegisterNeeded]	Enables the device to register to a Proxy/Registrar server. <ul style="list-style-type: none"> ▪ [0] Disable = (Default) The device doesn't register to Proxy/Registrar server. ▪ [1] Enable = The device registers to Proxy/Registrar server when the device is powered up and at every user-defined interval (configured by the parameter RegistrationTime). Note: The device sends a REGISTER request for each channel or for the entire device (according to the AuthenticationMode parameter).
Web/EMS: Registrar Name [RegistrarName]	Defines the Registrar domain name. If specified, the name is used as the Request-URI in REGISTER messages. If isn't specified (default), the Registrar IP address, or Proxy name or IP address is used instead. The valid range is up to 100 characters.

Parameter	Description
Web: Registrar IP Address EMS: Registrar IP [RegistrarIP]	Defines the IP address (or FQDN) and port number (optional) of the Registrar server. The IP address is in dotted-decimal notation, e.g., 201.10.8.1:<5080>. <p>Notes:</p> <ul style="list-style-type: none"> ▪ If not specified, the REGISTER request is sent to the primary Proxy server. ▪ When a port number is specified, DNS NAPTR/SRV queries aren't performed, even if the parameter DNSQueryType is set to 1 or 2. ▪ If the parameter RegistrarIP is set to an FQDN and is resolved to multiple addresses, the device also provides real-time switching (hotswap mode) between different Registrar IP addresses (the parameter IsProxyHotSwap is set to 1). If the first Registrar doesn't respond to the REGISTER message, the same REGISTER message is sent immediately to the next Proxy. To allow this mechanism, the parameter EnableProxyKeepAlive must be set to 0. ▪ When a specific transport type is defined using the parameter RegistrarTransportType, a DNS NAPTR query is not performed even if the parameter DNSQueryType is set to 2.
Web/EMS: Registrar Transport Type [RegistrarTransportType]	Determines the transport layer used for outgoing SIP dialogs initiated by the device to the Registrar. <ul style="list-style-type: none"> ▪ [-1] Not Configured (default) ▪ [0] UDP ▪ [1] TCP ▪ [2] TLS <p>Note: When set to 'Not Configured', the value of the parameter SIPTransportType is used.</p>
Web/EMS: Registration Time [RegistrationTime]	Defines the time interval (in seconds) for registering to a Proxy server. The value is used in the SIP Expires header. This parameter also defines the time interval between Keep-Alive messages when the parameter EnableProxyKeepAlive is set to 2 (REGISTER). Typically, the device registers every 3,600 sec (i.e., one hour). The device resumes registration according to the parameter RegistrationTimeDivider. The valid range is 10 to 2,000,000. The default is 180.
Web: Re-registration Timing [%] EMS: Time Divider [RegistrationTimeDivider]	Defines the re-registration timing (in percentage). The timing is a percentage of the re-register timing set by the Registrar server. The valid range is 50 to 100. The default is 50. For example: If this parameter is set to 70% and the Registration Expires time is 3600, the device re-sends its registration request after 3600 x 70% (i.e., 2520 sec). <p>Note: This parameter may be overridden if the parameter RegistrationTimeThreshold is greater than 0.</p>
Web/EMS: Registration Retry Time [RegistrationRetryTime]	Defines the time interval (in seconds) after which a registration request is re-sent if registration fails with a 4xx response or if there is no response from the Proxy/Registrar server. The default is 30 seconds. The range is 10 to 3600.

Parameter	Description
Web: Registration Time Threshold EMS: Time Threshold [RegistrationTimeThreshold]	Defines a threshold (in seconds) for re-registration timing. If this parameter is greater than 0, but lower than the computed re-registration timing (according to the parameter RegistrationTimeDivider), the re-registration timing is set to the following: timing set by the Registration server in the SIP Expires header minus the value of the parameter RegistrationTimeThreshold. The valid range is 0 to 2,000,000. The default is 0.
Web: Re-register On INVITE Failure EMS: Register On Invite Failure [RegisterOnInviteFailure]	Enables immediate re-registration if no response is received for an INVITE request sent by the device. <ul style="list-style-type: none"> ▪ [0] Disable (default) ▪ [1] Enable When enabled, the device immediately expires its re-registration timer and commences re-registration to the same Proxy upon any of the following scenarios: <ul style="list-style-type: none"> ▪ The response to an INVITE request is 407 (Proxy Authentication Required) without an authentication header included. ▪ The remote SIP UA abandons a call before the device has received any provisional response (indicative of an outbound proxy server failure). ▪ The remote SIP UA abandons a call and the only provisional response the device has received for the call is 100 Trying (indicative of a home proxy server failure, i.e., the failure of a proxy in the route after the outbound proxy). ▪ The device terminates a call due to the expiration of RFC 3261 Timer B or due to the receipt of a 408 (Request Timeout) response and the device has not received any provisional response for the call (indicative of an outbound proxy server failure). ▪ The device terminates a call due to the receipt of a 408 (Request Timeout) response and the only provisional response the device has received for the call is the 100 Trying provisional response (indicative of a home proxy server failure).
Web: ReRegister On Connection Failure EMS: Re Register On Connection Failure [ReRegisterOnConnectionFailure]	Enables the device to perform SIP re-registration upon TCP/TLS connection failure. <ul style="list-style-type: none"> ▪ [0] Disable (default) ▪ [1] Enable
Web: Gateway Registration Name EMS: Name [GWRegistrationName]	Defines the user name that is used in the From and To headers in SIP REGISTER messages. If no value is specified (default) for this parameter, the UserName parameter is used instead. Note: This parameter is applicable only for single registration per device (i.e., AuthenticationMode is set to 1). When the device registers each channel separately (i.e., AuthenticationMode is set to 0), the user name is set to the channel's phone number.
Web/EMS: Registration Mode [AuthenticationMode]	Determines the device's registration and authentication method. <ul style="list-style-type: none"> ▪ [0] Per Endpoint = Registration and authentication is performed separately for each endpoint/B-channel. This is typically used for FXS interfaces, where each endpoint registers (and authenticates) separately with its user name and password. ▪ [1] Per Gateway = (Default) Single registration and authentication for the entire device. This is typically used for FXO interfaces and digital modules.

Parameter	Description
	<ul style="list-style-type: none"> ▪ [3] Per FXS = Registration and authentication for FXS endpoints.
Web: Set Out-Of-Service On Registration Failure EMS: Set OOS On Registration Fail [OOSOnRegistrationFail]	Enables setting the endpoint, trunk, or entire device (i.e., all endpoints) to out-of-service if registration fails. <ul style="list-style-type: none"> ▪ [0] Disable (default) ▪ [1] Enable If the registration is per endpoint (i.e., AuthenticationMode is set to 0) or per Account (see Configuring Trunk Group Settings on page 293) and a specific endpoint/Account registration fails (SIP 4xx or no response), then that endpoint is set to out-of-service until a success response is received in a subsequent registration request. When the registration is per the entire device (i.e., AuthenticationMode is set to 1) and registration fails, all endpoints are set to out-of-service. If all the Accounts of a specific Trunk Group fail registration and if the Trunk Group comprises a complete trunk, then the entire trunk is set to out-of-service. <p>Note: The out-of-service method is configured using the FXSOOSBehavior parameter.</p>
[UnregistrationMode]	Enables the device to perform explicit unregisters. <ul style="list-style-type: none"> ▪ [0] Disable (default) ▪ [1] Enable = The device sends an asterisk ("*") value in the SIP Contact header, instructing the Registrar server to remove all previous registration bindings. The device removes SIP User Agent (UA) registration bindings in a Registrar, according to RFC 3261. Registrations are soft state and expire unless refreshed, but they can also be explicitly removed. A client can attempt to influence the expiration interval selected by the Registrar. A UA requests the immediate removal of a binding by specifying an expiration interval of "0" for that contact address in a REGISTER request. UA's should support this mechanism so that bindings can be removed before their expiration interval has passed. Use of the "*" Contact header field value allows a registering UA to remove all bindings associated with an address-of-record (AOR) without knowing their precise values. <p>Note: The REGISTER-specific Contact header field value of "*" applies to all registrations, but it can only be used if the Expires header field is present with a value of "0".</p>
Web/EMS: Add Empty Authorization Header [EmptyAuthorizationHeader]	Enables the inclusion of the SIP Authorization header in initial registration (REGISTER) requests sent by the device. <ul style="list-style-type: none"> ▪ [0] Disable (default) ▪ [1] Enable The Authorization header carries the credentials of a user agent (UA) in a request to a server. The sent REGISTER message populates the Authorization header with the following parameters: <ul style="list-style-type: none"> ▪ username - set to the value of the private user identity ▪ realm - set to the domain name of the home network ▪ uri - set to the SIP URI of the domain name of the home network ▪ nonce - set to an empty value ▪ response - set to an empty value For example:

Parameter	Description
	Authorization: Digest username=alice_private@home1.net, realm="home1.net", nonce="", response="e56131d19580cd833064787ecc" Note: This registration header is according to the IMS 3GPP TS24.229 and PKT-SP-24.220 specifications.
Web: Add initial Route Header [InitialRouteHeader]	Enables the inclusion of the SIP Route header in initial registration or re-registration (REGISTER) requests sent by the device. <ul style="list-style-type: none"> ▪ [0] Disable (default) ▪ [1] Enable When the device sends a REGISTER message, the Route header includes either the Proxy's FQDN, or IP address and port according to the configured Proxy Set, for example: Route: <sip:10.10.10.10;lr;transport=udp> or Route: <sip: pcscf-gm.ims.rr.com;lr;transport=udp>
EMS: Ping Pong Keep Alive [UsePingPongKeepAlive]	Enables the use of the carriage-return and line-feed sequences (CRLF) Keep-Alive mechanism, according to RFC 5626 "Managing Client-Initiated Connections in the Session Initiation Protocol (SIP)" for reliable, connection-orientated transport types such as TCP. <ul style="list-style-type: none"> ▪ [0] Disable (default) ▪ [1] Enable The SIP user agent/client (i.e., device) uses a simple periodic message as a keep-alive mechanism to keep their flow to the proxy or registrar alive (used for example, to keep NAT bindings open). For connection-oriented transports such as TCP/TLS this is based on CRLF. This mechanism uses a client-to-server "ping" keep-alive and a corresponding server-to-client "pong" message. This ping-pong sequence allows the client, and optionally the server, to tell if its flow is still active and useful for SIP traffic. If the client does not receive a pong in response to its ping, it declares the flow "dead" and opens a new flow in its place. In the CRLF Keep-Alive mechanism the client periodically (defined by the PingPongKeepAliveTime parameter) sends a double-CRLF (the "ping") then waits to receive a single CRLF (the "pong"). If the client does not receive a "pong" within an appropriate amount of time, it considers the flow failed. Note: The device sends a CRLF message to the Proxy Set only if the Proxy Keep-Alive feature (EnableProxyKeepAlive parameter) is enabled and its transport type is set to TCP or TLS. The device first sends a SIP OPTION message to establish the TCP/TLS connection and if it receives any SIP response, it continues sending the CRLF keep-alive sequences.
EMS: Ping Pong Keep Alive Time [PingPongKeepAliveTime]	Defines the periodic interval (in seconds) after which a "ping" (double-CRLF) keep-alive is sent to a proxy/registrar, using the CRLF Keep-Alive mechanism. The default range is 5 to 2,000,000. The default is 120. The device uses the range of 80-100% of this user-defined value as the actual interval. For example, if the parameter value is set to 200 sec, the interval used is any random time between 160 to 200 seconds. This prevents an "avalanche" of keep-alive by multiple SIP UAs to a specific server.

52.7.2 Network Application Parameters

The SIP network application parameters are described in the table below.

SIP Network Application Parameters

Parameter	Description
Signaling Routing Domain Table	
Web: SRD Settings EMS: SRD Table [SRD]	This table parameter configures the Signaling Routing Domain (SRD) table. The format of this parameter is as follows: [SRD] FORMAT SRD_Index = SRD_Name, SRD_MediaRealm, SRD_IntraSRDMediaAnchoring, SRD_BlockUnRegUsers, SRD_MaxNumOfRegUsers, SRD_EnableUnAuthenticatedRegistrations; [SRD] For example: SRD 1 = LAN1_SRD, Mrealm1, 0, 1, 15, 1; SRD 2 = LAN2_SRD, Mrealm2, 0, 1, 15, 1; Notes: <ul style="list-style-type: none"> The following parameters are not applicable: IntraSRDMediaAnchoring, BlockUnRegUsers, MaxNumOfRegUsers, and EnableUnAuthenticatedRegistrations. For a detailed description of this table, see 'Configuring SRD Table' on page 211.
SIP Interface Table	
Web: SIP Interface Table EMS: SIP Interfaces Table [SIPInterface]	This table parameter configures the SIP Interface table. The SIP Interface represents a SIP signaling entity, comprising ports (UDP, TCP, and TLS) and associated with a specific IP interface and an SRD ID. The format of this parameter is as follows: [SIPInterface] FORMAT SIPInterface_Index = SIPInterface_NetworkInterface, SIPInterface_ApplicationType, SIPInterface_UDPPort, SIPInterface_TCPPort, SIPInterface_TLSPort, SIPInterface_SRD, SIPInterface_MessagePolicy, SIPInterface_TLSMutualAuthentication, SIPInterface_TCPKeepaliveEnable, SIPInterface_ClassificationFailureResponseType; [SIPInterface] Note: For a detailed description of this table, see 'Configuring SIP Interface Table' on page 212.
TCP Keep Alive Idle Time [TCPKeepAliveTime]	Defines the interval (in sec) between the last data packet sent and the first keep-alive probe to send. The valid value is 10 to 65,000. The default is 60. Notes: <ul style="list-style-type: none"> Simple ACKs such as keep-alives are not considered data packets. TCP keepalive is enabled per SIP Interface in the SIP Interface table.
TCP Keep Alive Interval Time [TCPKeepAliveInterval]	Defines the interval (in sec) between consecutive keep-alive probes, regardless of what the connection has exchanged in the meantime. The valid value is 10 to 65,000. The default is 10.

Parameter	Description
	Note: TCP keepalive is enabled per SIP Interface in the SIP Interface table.
TCP Keep Alive Retry Number [TCPKeepAliveRetry]	Defines the number of unacknowledged keep-alive probes to send before considering the connection down. The valid value is 1 to 100. The default is 5. Note: TCP keepalive is enabled per SIP Interface in the SIP Interface table.
NAT Translation Table	
Web: NAT Translation Table [NATTranslation]	This table parameter defines NAT rules for translating source IP addresses per VoIP interface (SIP control and RTP media traffic) into NAT IP addresses. This allows, for example, the separation of VoIP traffic between different ISTP's, and topology hiding (of internal IP addresses to the "public" network). Each IP interface (configured in the Multiple Interface table - InterfaceTable parameter) can be associated with a NAT rule in this table, translating the source IP address and port of the outgoing packet into the NAT address (IP address and port range). The format of this parameter is as follows: [NATTranslation] FORMAT NATTranslation_Index = NATTranslation_SourceIPInterfaceName, NATTranslation_TargetIPAddress, NATTranslation_SourceStartPort, NATTranslation_SourceEndPort, NATTranslation_TargetStartPort, NATTranslation_TargetEndPort; [NATTranslation] Note: For a detailed description of this table, see 'Configuring NAT Translation per IP Interface' on page 133.

52.8 General SIP Parameters

The general SIP parameters are described in the table below.

General SIP Parameters

Parameter	Description
Web: SIP Remote Reset CLI: sip-remote-reset [EnableSIPRemoteReset]	Enables a specific device action upon the receipt of a SIP NOTIFY request, where the action depends on the value received in the Event header. <ul style="list-style-type: none"> ▪ [0] Disable (default) ▪ [1] Enable The action depends on the Event header value: <ul style="list-style-type: none"> ▪ 'check-sync;reboot=false': triggers the regular Automatic Update feature (if Automatic Update has been enabled on the device) ▪ 'check-sync;reboot=true': triggers a device reset Note: The Event header value is proprietary to AudioCodes.
Web/EMS: Max SIP Message Length [KB] [MaxSIPMessageLength]	Defines the maximum size (in Kbytes) for each SIP message that can be sent over the network. The device rejects messages exceeding this user-defined size. The valid value range is 1 to 50. The default is 50.

Parameter	Description
[SIPForceRport]	<p>Determines whether the device sends SIP responses to the UDP port from where SIP requests are received even if the 'rport' parameter is not present in the SIP Via header.</p> <ul style="list-style-type: none"> ▪ [0] = (Default) Disabled. The device sends the SIP response to the UDP port defined in the Via header. If the Via header contains the 'rport' parameter, the response is sent to the UDP port from where the SIP request is received. ▪ [1] = Enabled. SIP responses are sent to the UDP port from where SIP requests are received even if the 'rport' parameter is not present in the Via header.
Web: Reject Cancel after Connect CLI: reject-cancel-after-connect [RejectCancelAfterConnect]	<p>Determines whether the device accepts or rejects a SIP CANCEL request received after the receipt of a 200 OK, during an established call.</p> <ul style="list-style-type: none"> ▪ [0] = (Default) Accepts the CANCEL, by responding with a 200 OK and terminating the call session. ▪ [1] = Rejects the CANCEL, by responding with a SIP 481 Call/Transaction Does Not Exist, and maintaining the call session.
Web: Verify Received RequestURI CLI: verify-rcvd-requri [VerifyReceeedRequestUri]	<p>Enables the device to reject SIP requests (such as ACK, BYE, or re-INVITE) whose user part in the Request-URI is different from the user part received in the Contact header of the last sent SIP request.</p> <ul style="list-style-type: none"> ▪ [0] Disable = (Default) Even if the user is different, the device accepts the SIP request. ▪ [1] Enable = If the user is different, the device rejects the SIP request (BYE is responded with 481; re-INVITE is responded with 404; ACK is ignored).
Web: Max Number of Active Calls EMS: Maximum Concurrent Calls [MaxActiveCalls]	<p>Defines the maximum number of simultaneous active calls supported by the device. If the maximum number of calls is reached, new calls are not established.</p> <p>The valid range is 1 to the maximum number of supported channels. The default is the maximum available channels (i.e., no restriction on the maximum number of calls).</p>
Web: QoS statistics in SIP Release Call [QoSStatistics]	<p>Enables the device to include call quality of service (QoS) statistics in SIP BYE and SIP 200 OK response to BYE, using the proprietary SIP header X-RTP-Stat.</p> <ul style="list-style-type: none"> ▪ [0] = Disable (default) ▪ [1] = Enable <p>The X-RTP-Stat header provides the following statistics:</p> <ul style="list-style-type: none"> ▪ Number of received and sent voice packets ▪ Number of received and sent voice octets ▪ Received packet loss, jitter (in ms), and latency (in ms) <p>The X-RTP-Stat header contains the following fields:</p> <ul style="list-style-type: none"> ▪ PS=<voice packets sent> ▪ OS=<voice octets sent> ▪ PR=<voice packets received> ▪ OR=<voice octets received> ▪ PL=<receive packet loss> ▪ JI=<jitter in ms> ▪ LA=<latency in ms> <p>Below is an example of the X-RTP-Stat header in a SIP BYE message:</p>

Parameter	Description
	<pre> BYE sip:302@10.33.4.125 SIP/2.0 Via: SIP/2.0/UDP 10.33.4.126;branch=z9hG4bKac2127550866 Max-Forwards: 70 From: <sip:401@10.33.4.126;user=phone>;tag=1c2113553324 To: <sip:302@company.com>;tag=1c991751121 Call-ID: 991750671245200001912@10.33.4.125 CSeq: 1 BYE X-RTP-Stat: PS=207;OS=49680;;PR=314;OR=50240;PL=0;JI=600;LA=40; Supported: em,timer,replaces,path,resource-priority Allow: REGISTER,OPTIONS,INVITE,ACK,CANCEL,BYE,NOTIFY,PRACK ,REFER,INFO,SUBSCRIBE,UPDATE User-Agent: Sip-Gateway-/v.6.2A.008.006 Reason: Q.850 ;cause=16 ;text="local" Content-Length: 0 </pre>
Web/EMS: PRACK Mode [PrackMode]	Determines the PRACK (Provisional Acknowledgment) mechanism mode for SIP 1xx reliable responses. <ul style="list-style-type: none"> ▪ [0] Disable ▪ [1] Supported (default) ▪ [2] Required Notes: <ul style="list-style-type: none"> ▪ The Supported and Required headers contain the '100rel' tag. ▪ The device sends PRACK messages if 180/183 responses are received with '100rel' in the Supported or Required headers.
Web/EMS: Enable Early Media [EnableEarlyMedia]	Enables the Early Media feature. <p>Digital: Enables the device to send a 18x response with SDP instead of a 18x, allowing the media stream to be established prior to the answering of the call.</p> <p>Analog: Enables the device to send a 183 Session Progress response with SDP instead of a 180 Ringing, allowing the media stream to be established prior to the answering of the call.</p> <ul style="list-style-type: none"> ▪ [0] Disable (default) ▪ [1] Enable <p>Digital: The inclusion of the SDP in the 18x response depends on the ISDN Progress Indicator (PI). The SDP is sent only if PI is set to 1 or 8 in the received Proceeding, Alerting, or Progress PRI messages. See also the ProgressIndicator2IP parameter, which if set to 1 or 8, the device behaves as if it received the ISDN messages with the PI.</p> <ul style="list-style-type: none"> ▪ For the CAS protocol: See the ProgressIndicator2IP parameter. ▪ For the ISDN protocol: Sending a 183 response depends on the ISDN PI. It is sent only if PI is set to 1 or 8 in the received Proceeding or Alerting PRI messages. Sending 183 response also depends on the ReleaseIP2ISDNCallOnProgressWithCause parameter, which must be set to any value except 2. Notes: <ul style="list-style-type: none"> ▪ See also the IgnoreAlertAfterEarlyMedia parameter. This parameter allows, for example, to interwork Alert + PI to SIP 183 + SDP instead of 180 + SDP.

Parameter	Description
	<ul style="list-style-type: none"> ▪ You can also configure early SIP 183 response immediately upon receipt of an INVITE, using the EnableEarly183 parameter. ▪ Analog: To send a 183 response, you must also set the parameter ProgressIndicator2IP to 1. If it is equal to 0, 180 Ringing response is sent. ▪ This feature can also be configured as an IP Profile and/or Tel Profile.
Web/EMS: Enable Early 183 [EnableEarly183]	<p>Enables the device to send SIP 183 responses with SDP to the IP upon receipt of INVITE messages. This parameter is applicable to IP-to-Tel (ISDN) and IP-to-IP calls, and applies to all calls.</p> <ul style="list-style-type: none"> ▪ [0] Disable (default) ▪ [1] Enable <ul style="list-style-type: none"> ✓ IP-to-Tel calls: By sending the 183 response, the device opens an RTP channel before receiving the "progress" tone from the ISDN side. The device sends RTP packets immediately upon receipt of an ISDN Progress, Alerting with Progress indicator, or Connect message according to the initial negotiation without sending the 183 response again, thereby saving response time and avoiding early media clipping. ✓ IP-to-IP calls: Sending the 183 response enables SIP servers that require a stream of early media, to keep sessions open. <p>Notes:</p> <ul style="list-style-type: none"> ▪ To enable this feature, set the EnableEarlyMedia parameter to 1. ▪ When the BChannelNegotiation parameter is set to a non-Exclusive value (Preferred or Any), the EnableEarly183 parameter is ignored and a SIP 183 is not sent upon receipt of an INVITE. In such a case, you can set the ProgressIndicator2IP parameter to 1 (PI = 1) for the device to send a SIP 183 upon receipt of an ISDN Call Proceeding message. ▪ This feature can also be configured in an IP Profile.
[IgnoreAlertAfterEarlyMedia]	<p>Determines the device's interworking of Alerting messages from PRI to SIP.</p> <ul style="list-style-type: none"> ▪ [0] = Disabled (default) ▪ [1] = Enabled <p>When enabled, if the device sends a 183 response with an SDP (due to a received ISDN Progress or Proceeding with PI messages) and an Alerting message is then received from the Tel side (with or without Progress Indicator), the device does not send an additional 18x response, and the voice channel remains open. However, if the device did not send a 183 with an SDP and it receives an Alert without PI, the device sends a 180 (without SDP). If it receives an Alert with PI it sends a 183with an SDP.</p> <p>When disabled, the device sends additional 18x responses as a result of receiving Alerting and Progress messages, regardless of whether or not a 18x response was already sent.</p> <p>Note: This parameter is applicable only if the EnableEarlyMedia parameter is set to 1 (i.e., enabled).</p>
Web: 183 Message Behavior EMS: SIP 183 Behaviour [SIP183Behaviour]	<p>Digital: Defines the ISDN message that is sent when the 183 Session Progress message is received for IP-to-Tel calls. Analog: Defines the response of the device upon receipt of a SIP 183 response.</p> <ul style="list-style-type: none"> ▪ [0] Progress = (Default) Digital: The device sends a Progress

Parameter	Description
	message. Analog: A 183 response (without SDP) does not cause the device to play a ringback tone. <ul style="list-style-type: none"> ▪ [1] Alert = Digital: The device sends an Alerting message (upon receipt of a 183 response) instead of an ISDN Progress message. Analog: 183 response is handled by the device as if a 180 Ringing response is received, and the device plays a ringback tone.
[ReleaseIP2ISDNCallOnProgressWithCause]	Typically, if an Q.931 Progress message with a Cause is received from the PSTN for an outgoing IP-to-ISDN call and the EnableEarlyMedia parameter is set to 1 (i.e., the Early Media feature is enabled), the device interworks the Progress to 183 + SDP to enable the originating party to hear the PSTN announcement about the call failure. Conversely, if EnableEarlyMedia is set to 0, the device disconnects the call by sending a SIP 4xx response to the originating party. However, if the ReleaseIP2ISDNCallOnProgressWithCause parameter is set to 1, then the device sends a SIP 4xx response even if the EnableEarlyMedia parameter is set to 1. <ul style="list-style-type: none"> ▪ [0] = (Default) If a Progress with Cause message is received from the PSTN for an outgoing IP-to-ISDN call, the device does not disconnect the call by sending a SIP 4xx response to the originating party. ▪ [1] = The device sends a SIP 4xx response when the EnableEarlyMedia parameter is set to 0. ▪ [2] = The device always sends a SIP 4xx response, even if the EnableEarlyMedia parameter is set to 1.
Web: Session-Expires Time EMS: Sip Session Expires [SIPSessionExpires]	Defines the numerical value sent in the Session-Expires header in the first INVITE request or response (if the call is answered). The valid range is 1 to 86,400 sec. The default is 0 (i.e., the Session-Expires header is disabled).
Web: Minimum Session-Expires EMS: Minimal Session Refresh Value [MinSE]	Defines the time (in seconds) that is used in the Min-SE header. This header defines the minimum time that the user agent refreshes the session. The valid range is 10 to 100,000. The default is 90.
Web/EMS: Session Expires Disconnect Time CLI: session-exp-disconnect-time [SessionExpiresDisconnectTime]	Defines a session expiry timeout. The device disconnects the session (sends a SIP BYE) if the refresher does not send a refresh request before one-third (1/3) of the session expires time, or before the time configured by this parameter (the minimum of the two). The valid range is 0 to 32 (in seconds). The default is 32.
Web/EMS: Session Expires Method [SessionExpiresMethod]	Determines the SIP method used for session-timer updates. <ul style="list-style-type: none"> ▪ [0] Re-INVITE = (Default) Uses Re-INVITE messages for session-timer updates. ▪ [1] UPDATE = Uses UPDATE messages. Notes: <ul style="list-style-type: none"> ▪ The device can receive session-timer refreshes using both methods. ▪ The UPDATE message used for session-timer is excluded from the SDP body.
[RemoveToTagInFailureResponse]	Determines whether the device removes the 'to' header tag from final SIP failure responses to INVITE transactions. <ul style="list-style-type: none"> ▪ [0] = (Default) Do not remove tag. ▪ [1] = Remove tag.

Parameter	Description
[EnableRTCPAttribute]	<p>Enables the use of the 'rtcp' attribute in the outgoing SDP.</p> <ul style="list-style-type: none"> ▪ [0] = Disable (default) ▪ [1] = Enable
EMS: Options User Part [OPTIONSUserPart]	<p>Defines the user part value of the Request-URI for outgoing SIP OPTIONS requests. If no value is configured, the endpoint number (analog) or configuration parameter 'Username' value (digital) is used. A special value is 'empty', indicating that no user part in the Request-URI (host part only) is used.</p> <p>The valid range is a 30-character string. The default is an empty string (").</p>
Web: TDM Over IP Minimum Calls For Trunk Activation EMS: TDM Over IP Min Calls For Trunk Activation [TDMOverIPMinCallsForTrunkActivation]	<p>Defines the minimal number of SIP dialogs that must be established when using TDM Tunneling to consider the specific trunk as active.</p> <p>When using TDM Tunneling, if calls from this defined number of B-channels pertaining to a specific Trunk fail (i.e., SIP dialogs are not correctly set up), an AIS alarm is sent on this trunk toward the PSTN and all current calls are dropped. The originator gateway continues the INVITE attempts. When this number of calls succeed (i.e., SIP dialogs are correctly set up), the AIS alarm is cleared.</p> <p>The valid range is 0 to 31. The default is 0 (i.e., don't send AIS alarms).</p>
[TDMoIPInitiateInviteTime]	<p>Defines the time (in msec) between the first INVITE issued within the same trunk when implementing the TDM tunneling application.</p> <p>The valid value range is 500 to 1000. The default is 500.</p>
[TDMoIPInviteRetryTime]	<p>Defines the time (in msec) between call release and a new INVITE when implementing the TDM tunneling application.</p> <p>The valid value range is 10,000 to 20,000. The default is 10,000.</p>
Web: Fax Signaling Method EMS: Fax Used [IsFaxUsed]	<p>Determines the SIP signaling method for establishing and transmitting a fax session after a fax is detected.</p> <ul style="list-style-type: none"> ▪ [0] No Fax = (Default) No fax negotiation using SIP signaling. Fax transport method is according to the parameter FaxTransportMode. ▪ [1] T.38 Relay = Initiates T.38 fax relay. ▪ [2] G.711 Transport = Initiates fax/modem using the coder G.711 A-law/Mu-law with adaptations (see Note below). ▪ [3] Fax Fallback = Initiates T.38 fax relay. If the T.38 negotiation fails, the device re-initiates a fax session using the coder G.711 A-law/μ-law with adaptations (see the Note below). <p>Notes:</p> <ul style="list-style-type: none"> ▪ Fax adaptations (for options 2 and 3): <ul style="list-style-type: none"> ✓ Echo Cancellor = On ✓ Silence Compression = Off ✓ Echo Cancellor Non-Linear Processor Mode = Off ✓ Dynamic Jitter Buffer Minimum Delay = 40 ✓ Dynamic Jitter Buffer Optimization Factor = 13 ▪ If the device initiates a fax session using G.711 (option 2 and possibly 3), a 'gpmid' attribute is added to the SDP in the following format: <ul style="list-style-type: none"> ✓ For A-law: 'a=gpmid:8 vbd=yes;ecan=on' ✓ For μ-law: 'a=gpmid:0 vbd=yes;ecan=on' ▪ When this parameter is set to 1, 2, or 3, the parameter

Parameter	Description
	FaxTransportMode is ignored. <ul style="list-style-type: none"> ▪ When this parameter is set to 0, T.38 might still be used without the control protocol's involvement. To completely disable T.38, set FaxTransportMode to a value other than 1. ▪ This parameter can also be configured per IP Profile (using the IPProfile parameter). ▪ For more information on fax transport methods, see 'Fax/Modem Transport Modes' on page 160.
[HandleG711asVBD]	Enables the handling of G.711 as G.711 VBD coder. <ul style="list-style-type: none"> ▪ [0] = (Default) Disable. The device negotiates G.711 as a regular audio coder and sends an answer only with G.729 coder. For example, if the device is configured with G.729 and G.711 VBD coders and it receives an INVITE with an SDP offer containing G.729 and "regular" G.711 coders, it sends an SDP answer containing only the G.729 coder. ▪ [1] = Enable. The device assumes that the G.711 coder received in the INVITE SDP offer is a VBD coder. For example, if the device is configured with G.729 and G.711 VBD coders and it receives an INVITE with an SDP offer containing G.729 and "regular" G.711 coders, it sends an SDP answer containing G.729 and G.711 VBD coders, allowing a subsequent bypass (passthrough) session if fax/modem signals are detected during the call. <p>Note: This parameter is applicable only if G.711 VBD coder(s) with regular G.711 payload types 0 or 8 are configured for the device (using the CodersGroup parameter).</p>
[FaxVBDBehavior]	Determines the device's fax transport behavior when G.711 VBD coder is negotiated at call start. <ul style="list-style-type: none"> ▪ [0] = (Default) If the device is configured with a VBD coder (see the CodersGroup parameter) and is negotiated OK at call start, then both fax and modem signals are sent over RTP using the bypass payload type (and no mid-call VBD or T.38 Re-INVITES occur). ▪ [1] = If the IsFaxUsed parameter is set to 1, the channel opens with the FaxTransportMode parameter set to 1 (relay). This is required to detect mid-call fax tones and to send T.38 Re-INVITE messages upon fax detection. If the remote party supports T.38, the fax is relayed over T.38. <p>Notes:</p> <ul style="list-style-type: none"> ▪ If VBD coder negotiation fails at call start and if the IsFaxUsed parameter is set to 1 (or 3), then the channel opens with the FaxTransportMode parameter set to 1 (relay) to allow future detection of fax tones and sending of T.38 Re-INVITES. In such a scenario, the FaxVBDBehavior parameter has no effect. ▪ This feature can be used only if the remote party supports T.38 fax relay; otherwise, the fax fails.
[NoAudioPayloadType]	Defines the payload type of the outgoing SDP offer. The valid value range is 96 to 127 (dynamic payload type). The default is 0 (i.e. NoAudio is not supported). For example, if set to 120, the following is added to the INVITE SDP: <pre style="background-color: #f0f0f0; padding: 2px;">a=rtpmap:120 NoAudio/8000\r\n</pre> <p>Note: For incoming SDP offers, NoAudio is always supported.</p>
Web: SIP Transport Type EMS: Transport Type	Determines the default transport layer for outgoing SIP calls initiated by the device.

Parameter	Description
[SIPTransportType]	<ul style="list-style-type: none"> ▪ [0] UDP (default) ▪ [1] TCP ▪ [2] TLS (SIPS) <p>Notes:</p> <ul style="list-style-type: none"> ▪ It's recommended to use TLS for communication with a SIP Proxy and not for direct device-to-device communication. ▪ For received calls (i.e., incoming), the device accepts all these protocols. ▪ The value of this parameter is also used by the SAS application as the default transport layer for outgoing SIP calls.
Web: SIP UDP Local Port EMS: Local SIP Port [LocalSIPPort]	Defines the local UDP port for SIP messages. The valid range is 1 to 65534. The default is 5060.
Web: SIP TCP Local Port EMS: TCP Local SIP Port [TCPLocalSIPPort]	Defines the local TCP port for SIP messages. The valid range is 1 to 65535. The default is 5060.
Web: SIP TLS Local Port EMS: TLS Local SIP Port [TLSTLocalSIPPort]	Defines the local TLS port for SIP messages. The valid range is 1 to 65535. The default is 5061. Note: The value of this parameter must be different from the value of the parameter TCPLocalSIPPort.
Web/EMS: Enable SIPS [EnableSIPS]	Enables secured SIP (SIPS URI) connections over multiple hops. <ul style="list-style-type: none"> ▪ [0] Disable (default) ▪ [1] Enable <p>When the SIPTransportType parameter is set to 2 (i.e., TLS) and the parameter EnableSIPS is disabled, TLS is used for the next network hop only. When the parameter SIPTransportType is set to 2 or 1 (i.e., TCP or TLS) and EnableSIPS is enabled, TLS is used through the entire connection (over multiple hops).</p> <p>Note: If this parameter is enabled and the parameter SIPTransportType is set to 0 (i.e., UDP), the connection fails.</p>
Web/EMS: Enable TCP Connection Reuse [EnableTCPConnectionReuse]	Enables the reuse of the same TCP connection for all calls to the same destination. <ul style="list-style-type: none"> ▪ [0] Disable = Uses a separate TCP connection for each call. ▪ [1] Enable = (Default) Uses the same TCP connection for all calls. <p>Note: For the SAS application, this feature is configured using the SASConnectionReuse parameter.</p>
Web: Fake TCP alias [FakeTCPalias]	Enables the re-use of the same TCP/TLS connection for sessions with the same user, even if the "alias" parameter is not present in the SIP Via header of the first INVITE. <ul style="list-style-type: none"> ▪ [0] Disable = (Default) TCP/TLS connection reuse is done only if the "alias" parameter is present in the Via header of the first INVITE. ▪ [1] Enable <p>Note: To enable TCP/TLS connection re-use, set the EnableTCPConnectionReuse parameter to 1.</p>
Web/EMS: Reliable Connection Persistent Mode [ReliableConnectionPer]	Enables setting of all TCP/TLS connections as persistent and therefore, not released. <ul style="list-style-type: none"> ▪ [0] = (Default) Disable. All TCP connections (except those that are set to a proxy IP) are released if not used by any SIP

Parameter	Description
sistentMode]	<p>dialog\transaction.</p> <ul style="list-style-type: none"> [1] = Enable - TCP connections to all destinations are persistent and not released unless the device reaches 70% of its maximum TCP resources. <p>While trying to send a SIP message connection, reuse policy determines whether live connections to the specific destination are re-used.</p> <p>Persistent TCP connection ensures less network traffic due to fewer setting up and tearing down of TCP connections and reduced latency on subsequent requests due to avoidance of initial TCP handshake. For TLS, persistent connection may reduce the number of costly TLS handshakes to establish security associations, in addition to the initial TCP connection set up.</p> <p>Note: If the destination is a Proxy server, the TCP/TLS connection is persistent regardless of the settings of this parameter.</p>
Web/EMS: TCP Timeout [SIPTCPTimeout]	<p>Defines the Timer B (INVITE transaction timeout timer) and Timer F (non-INVITE transaction timeout timer), as defined in RFC 3261, when the SIP Transport Type is TCP.</p> <p>The valid range is 0 to 40 sec. The default is 64 multiplied by the SipT1Rtx parameter value. For example, if SipT1Rtx is set to 500 msec, then the default of SIPTCPTimeout is 32 sec.</p>
Web: SIP Destination Port EMS: Destination Port [SIPDestinationPort]	<p>Defines the SIP destination port for sending initial SIP requests. The valid range is 1 to 65534. The default port is 5060.</p> <p>Note: SIP responses are sent to the port specified in the Via header.</p>
Web: Use user=phone in SIP URL EMS: Is User Phone [IsUserPhone]	<p>Determines whether the 'user=phone' string is added to the SIP URI and SIP To header.</p> <ul style="list-style-type: none"> [0] No = 'user=phone' string is not added. [1] Yes = (Default) 'user=phone' string is part of the SIP URI and SIP To header.
Web: Use user=phone in From Header EMS: Is User Phone In From [IsUserPhoneInFrom]	<p>Determines whether the 'user=phone' string is added to the From and Contact SIP headers.</p> <ul style="list-style-type: none"> [0] No = (Default) Doesn't add 'user=phone' string. [1] Yes = 'user=phone' string is part of the From and Contact headers.
Web: Use Tel URI for Asserted Identity [UseTelURIForAssertedID]	<p>Determines the format of the URI in the P-Asserted-Identity and P-Preferred-Identity headers.</p> <ul style="list-style-type: none"> [0] Disable = (Default) 'sip:' [1] Enable = 'tel:'
Web: Tel to IP No Answer Timeout EMS: IP Alert Timeout [IPAlertTimeout]	<p>Defines the time (in seconds) that the device waits for a 200 OK response from the called party (IP side) after sending an INVITE message. If the timer expires, the call is released.</p> <p>The valid range is 0 to 3600. The default is 180.</p>
Web: Enable Remote Party ID EMS: Enable RPI Header [EnableRPIheader]	<p>Enables Remote-Party-Identity headers for calling and called numbers for Tel-to-IP calls.</p> <ul style="list-style-type: none"> [0] Disable (default). [1] Enable = Remote-Party-Identity headers are generated in SIP INVITE messages for both called and calling numbers.
Web: Enable History-Info Header	<p>Enables usage of the History-Info header.</p> <ul style="list-style-type: none"> [0] Disable (default)

Parameter	Description												
EMS: Enable History Info [EnableHistoryInfo]	<ul style="list-style-type: none"> ▪ [1] Enable <p>User Agent Client (UAC) Behavior:</p> <ul style="list-style-type: none"> ▪ Initial request: The History-Info header is equal to the Request-URI. If a PSTN Redirect number is received, it is added as an additional History-Info header with an appropriate reason. ▪ Upon receiving the final failure response, the device copies the History-Info as is, adds the reason of the failure response to the last entry, and concatenates a new destination to it (if an additional request is sent). The order of the reasons is as follows: <ol style="list-style-type: none"> a. Q.850 Reason b. SIP Reason c. SIP Response code ▪ Upon receiving the final response (success or failure), the device searches for a Redirect reason in the History-Info (i.e., 3xx/4xx SIP reason). If found, it is passed to ISDN according to the following table: <table border="1" data-bbox="528 813 1369 1102"> <thead> <tr> <th>SIP Reason Code</th> <th>ISDN Redirecting Reason</th> </tr> </thead> <tbody> <tr> <td>302 - Moved Temporarily</td> <td>Call Forward Universal (CFU)</td> </tr> <tr> <td>408 - Request Timeout</td> <td rowspan="3">Call Forward No Answer (CFNA)</td> </tr> <tr> <td>480 - Temporarily Unavailable</td> </tr> <tr> <td>487 - Request Terminated</td> </tr> <tr> <td>486 - Busy Here</td> <td>Call Forward Busy (CFB)</td> </tr> <tr> <td>600 - Busy Everywhere</td> <td></td> </tr> </tbody> </table> <ul style="list-style-type: none"> ▪ If history reason is a Q.850 reason, it is translated to the SIP reason (according to the SIP-ISDN tables) and then to ISDN Redirect reason according to the table above. <p>User Agent Server (UAS) Behavior:</p> <ul style="list-style-type: none"> ▪ The History-Info header is sent only in the final response. ▪ Upon receiving a request with History-Info, the UAS checks the policy in the request. If a 'session', 'header', or 'history' policy tag is found, the (final) response is sent without History-Info; otherwise, it is copied from the request. 	SIP Reason Code	ISDN Redirecting Reason	302 - Moved Temporarily	Call Forward Universal (CFU)	408 - Request Timeout	Call Forward No Answer (CFNA)	480 - Temporarily Unavailable	487 - Request Terminated	486 - Busy Here	Call Forward Busy (CFB)	600 - Busy Everywhere	
SIP Reason Code	ISDN Redirecting Reason												
302 - Moved Temporarily	Call Forward Universal (CFU)												
408 - Request Timeout	Call Forward No Answer (CFNA)												
480 - Temporarily Unavailable													
487 - Request Terminated													
486 - Busy Here	Call Forward Busy (CFB)												
600 - Busy Everywhere													
Web: Use Tgrp Information EMS: Use SIP Tgrp [UseSIPTrgp]	<p>Determines whether the SIP 'tgrp' parameter is used. This SIP parameter specifies the Trunk Group to which the call belongs (according to RFC 4904). For example, the SIP message below indicates that the call belongs to Trunk Group ID 1:</p> <pre>INVITE sip::+16305550100;tgrp=1;trunk-context=example.com@10.1.0.3;user=phone SIP/2.0</pre> <ul style="list-style-type: none"> ▪ [0] Disable = (Default) The 'tgrp' parameter isn't used. ▪ [1] Send Only = The Trunk Group number or name (configured in the Trunk Group Settings) is added to the 'tgrp' parameter value in the Contact header of outgoing SIP messages. If a Trunk Group number / name is not associated with the call, the 'tgrp' parameter isn't included. If a 'tgrp' value is specified in incoming messages, it is ignored. ▪ [2] Send and Receive = The functionality of outgoing SIP messages is identical to the functionality described for option [1]. In addition, for incoming SIP INVITEs, if the Request-URI includes a 'tgrp' parameter, the device routes the call according to that value (if 												

Parameter	Description
	<p>possible). The Contact header in the outgoing SIP INVITE (Tel-to-IP call) contains "tgrp=<source trunk group ID>;trunk-context=<gateway IP address>". The <source trunk group ID> is the Trunk Group ID where incoming calls from Tel is received. For IP-Tel calls, the SIP 200 OK device's response contains "tgrp=<destination trunk group ID>;trunk-context=<gateway IP address>". The <destination trunk group ID> is the Trunk Group ID used for outgoing Tel calls. The <gateway IP address> in "trunk-context" can be configured using the SIPGatewayName parameter.</p> <ul style="list-style-type: none"> ▪ [3] Hotline = Interworks the hotline "Off Hook Indicator" parameter between SIP and ISDN: <ul style="list-style-type: none"> ✓ For IP-to-ISDN calls: <ul style="list-style-type: none"> - The device interworks the SIP tgrp=hotline parameter (received in INVITE) to ISDN Setup with the Off Hook Indicator IE of "Voice", and "Speech" Bearer Capability IE. Note that the Off Hook Indicator IE is described in UCR 2008 specifications. - The device interworks the SIP tgrp=hotline-ccdata parameter (received in INVITE) to ISDN Setup with an Off Hook Indicator IE of "Data", and with "Unrestricted 64k" Bearer Capability IE. The following is an example of the INVITE with tgrp=hotline-ccdata: <pre style="background-color: #f0f0f0; padding: 5px;">INVITE sip:1234567;tgrp=hotline-ccdata;trunk-context=dsn.mil@example.com</pre> <ul style="list-style-type: none"> ✓ For ISDN-to-IP calls: <ul style="list-style-type: none"> - The device interworks ISDN Setup with an Off Hook Indicator of "Voice" to SIP INVITE with "tgrp=hotline;trunk-context=dsn.mil" in the Contact header. - The device interworks ISDN Setup with an Off Hook indicator of "Data" to SIP INVITE with "tgrp=hotline-ccdata;trunk-context=dsn.mil" in the Contact header. - If ISDN Setup does not contain an Off Hook Indicator IE and the Bearer Capability IE contains "Unrestricted 64k", the outgoing INVITE includes "tgrp=ccdata;trunk-context=dsn.mil". If the Bearer Capability IE contains "Speech", the INVITE in this case does not contain tgrp and trunk-context parameters. <ul style="list-style-type: none"> ▪ [4] Hotline Extended = Interworks the ISDN Setup message's hotline "OffHook Indicator" Information Element (IE) to SIP INVITE's Request-URI and Contact headers. (Note: For IP-to-ISDN calls, the device handles the call as described in option [3].) <ul style="list-style-type: none"> ✓ The device interworks ISDN Setup with an Off Hook Indicator of "Voice" to SIP INVITE Request-URI and Contact header with "tgrp=hotline;trunk-context=dsn.mil". ✓ The device interworks ISDN Setup with an Off Hook indicator of "Data" to SIP INVITE Request-URI and Contact header with "tgrp=hotline-ccdata;trunk-context=dsn.mil". ✓ If ISDN Setup does not contain an Off Hook Indicator IE and the Bearer Capability IE contains "Unrestricted 64k", the outgoing INVITE Request-URI and Contact header includes "tgrp=ccdata;trunk-context=dsn.mil". If the Bearer Capability IE contains "Speech", the INVITE in this case does not contain tgrp and trunk-context parameters. <p>Note: IP-to-Tel configuration (using the PSTNPrefix parameter) overrides the 'tgrp' parameter in incoming INVITE messages.</p>
Web/EMS: TGRP Routing Precedence	Determines the precedence method for routing IP-to-Tel calls - according to the Inbound IP Routing Table or according to the SIP 'tgrp'

Parameter	Description
[TGRProutingPrecedence]	<p>parameter.</p> <ul style="list-style-type: none"> ▪ [0] = (Default) IP-to-Tel routing is determined by the Inbound IP Routing Table (PSTNPrefix parameter). If a matching rule is not found in this table, the device uses the Trunk Group parameters for routing the call. ▪ [1] = The device first places precedence on the 'tgrp' parameter for IP-to-Tel routing. If the received INVITE Request-URI does not contain the 'tgrp' parameter or if the Trunk Group number is not defined, then the Inbound IP Routing Table is used for routing the call. <p>Below is an example of an INVITE Request-URI with the 'tgrp' parameter, indicating that the IP call should be routed to Trunk Group 7:</p> <pre>INVITE sip:200;tgrp=7;trunk-context=example.com@10.33.2.68;user=phone SIP/2.0</pre> <p>Notes:</p> <ul style="list-style-type: none"> ▪ For enabling routing based on the 'tgrp' parameter, the UseSIPTgrp parameter must be set to 2. ▪ For IP-to-Tel routing based on the 'dtg' parameter (instead of the 'tgrp' parameter), use the parameter UseBroadsoftDTG.
[UseBroadsoftDTG]	<p>Determines whether the device uses the 'dtg' parameter for routing IP-to-Tel calls to a specific Trunk Group.</p> <ul style="list-style-type: none"> ▪ [0] Disable (default) ▪ [1] Enable <p>When this parameter is enabled, if the Request-URI in the received SIP INVITE includes the 'dtg' parameter, the device routes the call to the Trunk Group according to its value. This parameter is used instead of the 'tgrp/trunk-context' parameters. The 'dtg' parameter appears in the INVITE Request-URI (and in the To header).</p> <p>For example, the received SIP message below routes the call to Trunk Group ID 56:</p> <pre>INVITE sip:123456@192.168.1.2;dtg=56;user=phone SIP/2.0</pre> <p>Note: If the Trunk Group is not found based on the 'dtg' parameter, the Inbound IP Routing Table is used instead for routing the call to the appropriate Trunk Group.</p>
Web/EMS: Enable GRUU [EnableGRUU]	<p>Determines whether the Globally Routable User Agent URIs (GRUU) mechanism is used, according to RFC 5627. This is used for obtaining a GRUU from a registrar and for communicating a GRUU to a peer within a dialog.</p> <ul style="list-style-type: none"> ▪ [0] Disable (default) ▪ [1] Enable <p>A GRUU is a SIP URI that routes to an instance-specific UA and can be reachable from anywhere. There are a number of contexts in which it is desirable to have an identifier that addresses a single UA (using GRUU) rather than the group of UA's indicated by an Address of Record (AOR). For example, in call transfer where user A is talking to user B, and user A wants to transfer the call to user C. User A sends a REFER to user C:</p> <pre>REFER sip:C@domain.com SIP/2.0 From: sip:A@domain.com;tag=99asd To: sip:C@domain.com Refer-To: (URI that identifies B's UA)</pre>

Parameter	Description
	<p>The Refer-To header needs to contain a URI that user C can use to place a call to user B. This call needs to route to the specific UA instance that user B is using to talk to user A. User B should provide user A with a URI that has to be usable by anyone. It needs to be a GRUU.</p> <ul style="list-style-type: none"> ▪ Obtaining a GRUU: The mechanism for obtaining a GRUU is through registrations. A UA can obtain a GRUU by generating a REGISTER request containing a Supported header field with the value “gruu”. The UA includes a “+sip.instance” Contact header parameter of each contact for which the GRUU is desired. This Contact parameter contains a globally unique ID that identifies the UA instance. The global unique ID is created from one of the following: <ul style="list-style-type: none"> ✓ If the REGISTER is per the device’s client (endpoint), it is the MAC address concatenated with the phone number of the client. ✓ If the REGISTER is per device, it is the MAC address only. ✓ When using TP, “User Info” can be used for registering per endpoint. Thus, each endpoint can get a unique id – its phone number. The globally unique ID in TP is the MAC address concatenated with the phone number of the endpoint. <p>If the remote server doesn’t support GRUU, it ignores the parameters of the GRUU. Otherwise, if the remote side also supports GRUU, the REGISTER responses contain the “gruu” parameter in each Contact header. This parameter contains a SIP or SIPS URI that represents a GRUU corresponding to the UA instance that registered the contact. The server provides the same GRUU for the same AOR and instance-id when sending REGISTER again after registration expiration. RFC 5627 specifies that the remote target is a GRUU target if its’ Contact URL has the “gr” parameter with or without a value.</p> <ul style="list-style-type: none"> ▪ Using GRUU: The UA can place the GRUU in any header field that can contain a URI. It must use the GRUU in the following messages: INVITE request, its 2xx response, SUBSCRIBE request, its 2xx response, NOTIFY request, REFER request and its 2xx response.
EMS: Is CISCO Sce Mode [IsCiscoSCEMode]	<p>Determines whether a Cisco gateway exists at the remote side.</p> <ul style="list-style-type: none"> ▪ [0] = (Default) No Cisco gateway exists at the remote side. ▪ [1] = A Cisco gateway exists at the remote side. <p>When a Cisco gateway exists at the remote side, the device must set the value of the ‘annexb’ parameter of the fntp attribute in the SDP to ‘no’. This logic is used if the parameter EnableSilenceCompression is set to 2 (enable without adaptation). In this case, Silence Suppression is used on the channel but not declared in the SDP.</p> <p>Note: The IsCiscoSCEMode parameter is applicable only when the selected coder is G.729.</p>
Web: User-Agent Information EMS: User Agent Display Info [UserAgentDisplayInfo]	<p>Defines the string that is used in the SIP User-Agent and Server response headers. When configured, the string <UserAgentDisplayInfo value>/software version’ is used, for example:</p> <pre>User-Agent: myproduct/v.6.40.010.006</pre> <p>If not configured, the default string, <AudioCodes product-name>/software version’ is used, for example:</p> <pre>User-Agent: Audiocodes-Sip-Gateway-Mediant1000/v.6.40.010.006</pre> <p>The maximum string length is 50 characters.</p> <p>Note: The software version number and preceding forward slash (/) cannot be modified. Therefore, it is recommended not to include a</p>

Parameter	Description
	forward slash in the parameter's value (to avoid two forward slashes in the SIP header, which may cause problems).
Web/EMS: SDP Session Owner [SIPSDPSessionOwner]	<p>Defines the value of the Owner line ('o' field) in outgoing SDP messages.</p> <p>The valid range is a string of up to 39 characters. The default is 'AudiocodesGW'.</p> <p>For example:</p> <pre>o=AudiocodesGW 1145023829 1145023705 IN IP4 10.33.4.126</pre>
[EnableSDPVersionNegotiation]	<p>Enables the device to ignore new SDP re-offers (from the media negotiation perspective) in certain scenarios (such as session expires). According to RFC 3264, once an SDP session is established, a new SDP offer is considered a new offer only when the SDP origin value is incremented. In scenarios such as session expires, SDP negotiation is irrelevant and thus, the origin field is not changed.</p> <p>Even though some SIP devices don't follow this behavior and don't increment the origin value even in scenarios where they want to re-negotiate, the device can assume that the remote party operates according to RFC 3264, and in cases where the origin field is not incremented, the device does not re-negotiate SDP capabilities.</p> <ul style="list-style-type: none"> ▪ [0] Disable = (Default) The device negotiates any new SDP re-offer, regardless of the origin field. ▪ [1] Enable = The device negotiates only an SDP re-offer with an incremented origin field.
Web/EMS: Subject [SIPSubject]	<p>Defines the Subject header value in outgoing INVITE messages. If not specified, the Subject header isn't included (default). The maximum length is up to 50 characters.</p>
[CoderPriorityNegotiation]	<p>Defines the priority for coder negotiation in the incoming SDP offer, between the device's or remote UA's coder list.</p> <ul style="list-style-type: none"> ▪ [0] = (Default) Coder negotiation is given higher priority to the remote UA's list of supported coders. ▪ [1] = Coder negotiation is given higher priority to the device's (local) supported coders list. ▪ Note: This parameter is applicable only to the Gateway/IP-to-IP application.
Web: Send All Coders on Retrieve [SendAllCodersOnRetrieve]	<p>Enables coder re-negotiation in the sent re-INVITE for retrieving an on-hold call.</p> <ul style="list-style-type: none"> ▪ [0] Disable = (Default) Sends only the initially chosen coder when the call was first established and then put on-hold. ▪ [1] Enable = Includes all supported coders in the SDP of the re-INVITE sent to the call made un-hold (retrieved). The used coder is therefore, re-negotiated. <p>This parameter is useful in the following call scenario example:</p> <ol style="list-style-type: none"> 1 Party A calls party B and coder G.711 is chosen. 2 Party B is put on-hold while Party A blind transfers Party B to Party C. 3 Party C answers and Party B is made un-hold. However, as Party C supports only G.729 coder, re-negotiation of the supported coder is required.

Parameter	Description
Web: Multiple Packetization Time Format EMS: Multi Ptime Format [MultiPtimeFormat]	Determines whether the 'mptime' attribute is included in the outgoing SDP. <ul style="list-style-type: none"> ▪ [0] None = (Default) Disabled. ▪ [1] PacketCable = Includes the 'mptime' attribute in the outgoing SDP - PacketCable-defined format. The 'mptime' attribute enables the device to define a separate packetization period for each negotiated coder in the SDP. The 'mptime' attribute is only included if this parameter is enabled even if the remote side includes it in the SDP offer. Upon receipt, each coder receives its 'ptime' value in the following precedence: from 'mptime' attribute, from 'ptime' attribute, and then from default value.
EMS: Enable P Time [EnablePtime]	Determines whether the 'ptime' attribute is included in the SDP. <ul style="list-style-type: none"> ▪ [0] = Remove the 'ptime' attribute from SDP. ▪ [1] = (Default) Include the 'ptime' attribute in SDP.
Web/EMS: 3xx Behavior [3xxBehavior]	Determines the device's behavior regarding call identifiers when a 3xx response is received for an outgoing INVITE request. The device can either use the same call identifiers (Call-ID, To, and From tags) or change them in the new initiated INVITE. <ul style="list-style-type: none"> ▪ [0] Forward = (Default) Use different call identifiers for a redirected INVITE message. ▪ [1] Redirect = Use the same call identifiers.
Web/EMS: Enable P-Charging Vector [EnablePChargingVector]	Enables the inclusion of the P-Charging-Vector header to all outgoing INVITE messages. <ul style="list-style-type: none"> ▪ [0] Disable (default) ▪ [1] Enable
Web/EMS: Retry-After Time [RetryAfterTime]	Defines the time (in seconds) used in the Retry-After header when a 503 (Service Unavailable) response is generated by the device. The time range is 0 to 3,600. The default is 0.
Web/EMS: Fake Retry After [sec] [FakeRetryAfter]	Determines whether the device, upon receipt of a SIP 503 response without a Retry-After header, behaves as if the 503 response included a Retry-After header and with the period (in seconds) specified by this parameter. <ul style="list-style-type: none"> ▪ [0] Disable (default) ▪ Any positive value (in seconds) for defining the period When enabled, this feature allows the device to operate with Proxy servers that do not include the Retry-After SIP header in SIP 503 (Service Unavailable) responses to indicate an unavailable service. The Retry-After header is used with the 503 (Service Unavailable) response to indicate how long the service is expected to be unavailable to the requesting SIP client. The device maintains a list of available proxies, by using the Keep-Alive mechanism. The device checks the availability of proxies by sending SIP OPTIONS every keep-alive timeout to all proxies. If the device receives a SIP 503 response to an INVITE, it also marks that the proxy is out of service for the defined "Retry-After" period.
Web/EMS: Enable P-Associated-URI Header [EnablePAssociatedURIHeader]	Determines the device usage of the P-Associated-URI header. This header can be received in 200 OK responses to REGISTER requests. When enabled, the first URI in the P-Associated-URI header is used in subsequent requests as the From/P-Asserted-Identity headers value. <ul style="list-style-type: none"> ▪ [0] Disable (default)

Parameter	Description
	<ul style="list-style-type: none"> ▪ [1] Enable <p>Note: P-Associated-URIs in registration responses is handled only if the device is registered per endpoint (using the User Information file).</p>
Web/EMS: Source Number Preference [SourceNumberPreference]	<p>Determines from which SIP header the source (calling) number is obtained in incoming INVITE messages.</p> <ul style="list-style-type: none"> ▪ If not configured (i.e., empty string) or if any string other than "From" or "Pai2" is configured, the calling number is obtained from a specific header using the following logic: <ol style="list-style-type: none"> a. P-Preferred-Identity header. b. If the above header is not present, then the first P-Asserted-Identity header is used. c. If the above header is not present, then the Remote-Party-ID header is used. d. If the above header is not present, then the From header is used. ▪ "From" = The calling number is obtained from the From header. ▪ "Pai2" = The calling number is obtained using the following logic: <ol style="list-style-type: none"> a. If a P-Preferred-Identity header is present, the number is obtained from it. b. If no P-Preferred-Identity header is present and two P-Asserted-Identity headers are present, the number is obtained from the second P-Asserted-Identity header. c. If only one P-Asserted-Identity header is present, the calling number is obtained from it. <p>Notes:</p> <ul style="list-style-type: none"> ▪ The "From" and "Pai2" values are not case-sensitive. ▪ Once a URL is selected, all the calling party parameters are set from this header. If P-Asserted-Identity is selected and the Privacy header is set to 'id', the calling number is assumed restricted.
[SelectSourceHeaderForCalledNumber]	<p>Determines the SIP header used for obtaining the called number (destination) for IP-to-Tel calls.</p> <ul style="list-style-type: none"> ▪ [0] Request-URI header = (Default) Obtains the destination number from the user part of the Request-URI. ▪ [1] To header = Obtains the destination number from the user part of the To header. ▪ [2] P-Called-Party-ID header = Obtains the destination number from the P-Called-Party-ID header.
Web/EMS: Forking Handling Mode [ForkingHandlingMode]	<p>Determines how the device handles the receipt of multiple SIP 18x forking responses for Tel-to-IP calls. The forking 18x response is the response with a different SIP to-tag than the previous 18x response. These responses are typically generated (initiated) by Proxy / Application servers that perform call forking, sending the device's originating INVITE (received from SIP clients) to several destinations, using the same CallID.</p> <ul style="list-style-type: none"> ▪ [0] Parallel handling = (Default) If SIP 18x with SDP is received, the device opens a voice stream according to the received SDP and disregards any subsequently received 18x forking responses (with or without SDP). If the first response is 180 without SDP, the device responds according to the PlayRBTone2TEL parameter and disregards the subsequent forking 18x responses. ▪ [1] Sequential handling = If 18x with SDP is received, the device opens a voice stream according to the received SDP. The device re-

Parameter	Description
	<p>opens the stream according to subsequently received 18x responses with SDP, or plays a ringback tone if 180 response without SDP is received. If the first received response is 180 without SDP, the device responds according to the PlayRBTone2TEL parameter and processes the subsequent 18x forking responses.</p> <p>Note: Regardless of this parameter setting, once a SIP 200 OK response is received, the device uses the RTP information and re-opens the voice stream, if necessary.</p>
Web: Forking Timeout [ForkingTimeout]	<p>Defines the timeout (in seconds) that is started after the first SIP 2xx response has been received for a User Agent when a Proxy server performs call forking (Proxy server forwards the INVITE to multiple SIP User Agents). The device sends a SIP ACK and BYE in response to any additional SIP 2xx received from the Proxy within this timeout. Once this timeout elapses, the device ignores any subsequent SIP 2xx.</p> <p>The number of supported forking calls per channel is 20. In other words, for an INVITE message, the device can receive up to 20 forking responses from the Proxy server.</p> <p>The valid range is 0 to 30. The default is 30.</p>
Web: Tel2IP Call Forking Mode [Tel2IPCallForkingMode]	<p>Enables Tel-to-IP call forking, whereby a Tel call can be routed to multiple IP destinations.</p> <ul style="list-style-type: none"> ▪ [0] Disable (default) ▪ [1] Enable <p>Note: Once enabled, routing rules must be assigned Forking Groups in the Outbound IP Routing table.</p>
Web/EMS: Enable Reason Header [EnableReasonHeader]	<p>Enables the usage of the SIP Reason header.</p> <ul style="list-style-type: none"> ▪ [0] Disable ▪ [1] Enable (default)
Web/EMS: Gateway Name CLI: gw-name [SIPGatewayName]	<p>Defines a name for the device (e.g., device123.com). This name is used as the host part of the SIP URI in the From header. If not specified, the device's IP address is used instead (default).</p> <p>Notes:</p> <ul style="list-style-type: none"> ▪ Ensure that the parameter value is the one with which the Proxy has been configured with to identify the device. ▪ This parameter can also be configured for an IP Group (in the IP Group table).
[ZeroSDPHandling]	<p>Determines the device's response to an incoming SDP that includes an IP address of 0.0.0.0 in the SDP's Connection Information field (i.e., "c=IN IP4 0.0.0.0").</p> <ul style="list-style-type: none"> ▪ [0] = (Default) Sets the IP address of the outgoing SDP's c= field to 0.0.0.0. ▪ [1] = Sets the IP address of the outgoing SDP c= field to the IP address of the device. If the incoming SDP doesn't contain the "a=inactive" line, the returned SDP contains the "a=recvnly" line.
Web/EMS: Enable Delayed Offer [EnableDelayedOffer]	<p>Determines whether the device sends the initial INVITE message with or without an SDP. Sending the first INVITE without SDP is typically done by clients for obtaining the far-end's full list of capabilities before sending their own offer. (An alternative method for obtaining the list of supported capabilities is by using SIP OPTIONS, which is not supported by every SIP agent.)</p> <ul style="list-style-type: none"> ▪ [0] Disable = (Default) The device sends the initial INVITE message with an SDP.

Parameter	Description
	<ul style="list-style-type: none"> ▪ [1] Enable = The device sends the initial INVITE message without an SDP.
[DisableCryptoLifetimeSDP]	<p>Enables the device to send "a=crypto" lines without the lifetime parameter in the SDP. For example, if the SDP contains "a=crypto:12 AES_CM_128_HMAC_SHA1_80 inline:hhQe10yZRcRcpIFPKH5xYY9R1de37ogh9G1MpvNp 2^31", it removes the lifetime parameter "2^31".</p> <ul style="list-style-type: none"> ▪ [0] Disable (default) ▪ [1] Enable
Web/EMS: Enable Contact Restriction [EnableContactRestriction]	<p>Determines whether the device sets the Contact header of outgoing INVITE requests to 'anonymous' for restricted calls.</p> <ul style="list-style-type: none"> ▪ [0] Disable (default) ▪ [1] Enable
[AnonymousMode]	<p>Determines whether the device's IP address is used as the URI host part instead of "anonymous.invalid" in the INVITE's From header for Tel-to-IP calls.</p> <ul style="list-style-type: none"> ▪ [0] = (Default) If the device receives a call from the Tel with blocked caller ID, it sends an INVITE with From: "anonymous"<anonymous@anonymous.invalid> ▪ [1] = The device's IP address is used as the URI host part instead of "anonymous.invalid". <p>This parameter may be useful, for example, for service providers who identify their SIP Trunking customers by their source phone number or IP address, reflected in the From header of the SIP INVITE. Therefore, even customers blocking their Caller ID can be identified by the service provider. Typically, if the device receives a call with blocked Caller ID from the PSTN side (e.g., Trunk connected to a PBX), it sends an INVITE to the IP with a From header as follows: From: "anonymous" <anonymous@anonymous.invalid>. This is in accordance with RFC 3325. However, when this parameter is set to 1, the device replaces the "anonymous.invalid" with its IP address.</p>
EMS: P Asserted User Name [PAssertedUserName]	<p>Defines a 'representative number' (up to 50 characters) that is used as the user part of the Request-URI in the P-Asserted-Identity header of an outgoing INVITE for Tel-to-IP calls.</p> <p>The default is null.</p>
EMS: Use URL In Refer To Header [UseAORInReferToHeader]	<p>Defines the source for the SIP URI set in the Refer-To header of outgoing REFER messages.</p> <ul style="list-style-type: none"> ▪ [0] = (Default) Use SIP URI from Contact header of the initial call. ▪ [1] = Use SIP URI from To/From header of the initial call.
Web: Enable User-Information Usage [EnableUserInfoUsage]	<p>Enables the usage of the User Information, which is loaded to the device in the User Information auxiliary file. For a description on User Information, see 'Loading Auxiliary Files' on page 499.</p> <ul style="list-style-type: none"> ▪ [0] Disable (default) ▪ [1] Enable <p>Note: For this parameter to take effect, a device reset is required.</p>
[HandleReasonHeader]	<p>Determines whether the device uses the value of the incoming SIP Reason header for Release Reason mapping.</p> <ul style="list-style-type: none"> ▪ [0] = Disregard Reason header in incoming SIP messages. ▪ [1] = (Default) Use the Reason header value for Release Reason

Parameter	Description
[EnableSilenceSupplnSDP]	mapping. Determines the device's behavior upon receipt of SIP Re-INVITE messages that include the SDP's 'silencesupp:off' attribute. <ul style="list-style-type: none"> ▪ [0] = (Default) Disregard the 'silencesupp' attribute. ▪ [1] = Handle incoming Re-INVITE messages that include the 'silencesupp:off' attribute in the SDP as a request to switch to the Voice-Band-Data (VBD) mode. In addition, the device includes the attribute 'a=silencesupp:off' in its SDP offer. Note: This parameter is applicable only if the G.711 coder is used.
[EnableRport]	Enables the usage of the 'rport' parameter in the Via header. <ul style="list-style-type: none"> ▪ [0] = Disabled (default) ▪ [1] = Enabled The device adds an 'rport' parameter to the Via header of each outgoing SIP message. The first Proxy that receives this message sets the 'rport' value of the response to the actual port from where the request was received. This method is used, for example, to enable the device to identify its port mapping outside a NAT. If the Via header doesn't include the 'rport' parameter, the destination port of the response is obtained from the host part of the Via header. If the Via header includes the 'rport' parameter without a port value, the destination port of the response is the source port of the incoming request. If the Via header includes 'rport' with a port value (e.g., rport=1001), the destination port of the response is the port indicated in the 'rport' parameter.
Web: Enable X-Channel Header EMS: X Channel Header [XChannelHeader]	Determines whether the SIP X-Channel header is added to SIP messages for providing information on the physical Trunk/B-channel on which the call is received or placed. <ul style="list-style-type: none"> ▪ [0] Disable = (Default) X-Channel header is not used. ▪ [1] Enable = X-Channel header is generated by the device and sent in INVITE messages and 180, 183, and 200 OK SIP responses. The header includes the Trunk number, B-channel, and the device's IP address. For example, 'x-channel: DS/DS1-5/8;IP=192.168.13.1', where: <ul style="list-style-type: none"> ✓ 'DS/DS-1' is a constant string ✓ '5' is the Trunk number ✓ '8' is the B-channel ✓ 'IP=192.168.13.1' is the device's IP address
Web/EMS: Progress Indicator to IP [ProgressIndicator2IP]	For Analog (FXS/FXO) interfaces: <ul style="list-style-type: none"> ▪ [-1] Not Configured = (Default) Default values are used. The default for FXO interfaces is 1; The default for FXS interfaces is 0. ▪ [0] No PI = For IP-to-Tel calls, the device sends a 180 Ringing response to IP after placing a call to a phone (FXS) or PBX (FXO). ▪ [1] PI = 1, [8] PI = 8: For IP-to-Tel calls, if the parameter EnableEarlyMedia is set to 1, the device sends a 183 Session Progress message with SDP immediately after a call is placed to a phone/PBX. This is used to cut-through the voice path before the remote party answers the call. This allows the originating party to listen to network Call Progress Tones (such as ringback tone or other network announcements). Digital interfaces: <ul style="list-style-type: none"> ▪ [-1] Not Configured = for ISDN spans, the progress indicator (PI) that

Parameter	Description
	<p>is received in ISDN Proceeding, Progress, and Alerting messages is used as described in the options below. (default)</p> <ul style="list-style-type: none"> ▪ [0] No PI = For IP-to-Tel calls, the device sends 180 Ringing SIP response to IP after receiving ISDN Alerting or (for CAS) after placing a call to PBX/PSTN. ▪ [1] PI =1, [8] PI =8: For IP-to-Tel calls, if the parameter EnableEarlyMedia is set to 1, the device sends 180 Ringing with SDP in response to an ISDN Alerting or it sends a 183 Session Progress message with SDP in response to only the first received ISDN Proceeding or Progress message after a call is placed to PBX/PSTN over the trunk. <p>Note: This parameter can also be configured per IP Profile (using the IPProfile parameter) and Tel Profile (using the TelProfile parameter).</p>
[EnableRekeyAfter181]	<p>Enables the device to send a re-INVITE with a new (different) SRTP key (in the SDP) if a SIP 181 response is received ("call is being forwarded"). The re-INVITE is sent immediately upon receipt of the 200 OK (when the call is answered).</p> <ul style="list-style-type: none"> ▪ [0] = Disable (default) ▪ [1] = Enable <p>Note: This parameter is applicable only if SRTP is used.</p>
[NumberOfActiveDialogs]	<p>Defines the maximum number of concurrent, outgoing SIP REGISTER dialogs. This parameter is used to control the registration rate. The valid range is 1 to 20. The default is 20.</p> <p>Notes:</p> <ul style="list-style-type: none"> ▪ Once a 200 OK is received in response to a REGISTER message, the REGISTER message is not considered in this maximum count limit. ▪ This parameter applies only to outgoing REGISTER messages (i.e., incoming is unlimited).
EMS: Transparent Coder On Data Call [TransparentCoderOnDataCall]	<ul style="list-style-type: none"> ▪ [0] = (Default) Only use coders from the coder list. ▪ [1] = Use Transparent coder for data calls (according to RFC 4040). <p>The Transparent coder can be used on data calls. When the device receives a Setup message from the ISDN with 'TransferCapabilities = data', it can initiate a call using the coder 'Transparent' (even if the coder is not included in the coder list).</p> <p>The initiated INVITE includes the following SDP attribute:</p> <pre>a=rtpmap:97 CLEARMODE/8000</pre> <p>The default payload type is set according to the CodersGroup parameter. If the Transparent coder is not defined, the default is set to 56. The payload type is negotiated with the remote side, i.e., the selected payload type is according to the remote side selection. The receiving device must include the 'Transparent' coder in its coder list.</p>
Web: IP to IP Application [EnableIP2IPApplication]	<p>Enables the IP-to-IP Call Routing application.</p> <ul style="list-style-type: none"> ▪ [0] Disable (default) ▪ [1] Enable <p>Note: For this parameter to take effect, a device reset is required.</p>
[IP2IPTranscodingMode]	<p>Note: This parameter is no longer valid and must not be used.</p> <p>Defines the voice transcoding mode (media negotiation) between two user agents for the IP-to-IP application. This parameter must always be</p>

Parameter	Description
	set to 1 when using the IP-to-IP application. <ul style="list-style-type: none"> ▪ [0] Only if Required = Do not force transcoding. Many of the media settings (such as gain control) are not implemented on the voice stream. The device passes packets RTP to RTP packets without any processing. ▪ [1] Force = (Default) Force transcoding on the outgoing IP leg. The device interworks the media by implementing DSP transcoding.
Web: Enable RFC 4117 Transcoding [EnableRFC4117Transcoding]	Enables transcoding of calls according to RFC 4117. <ul style="list-style-type: none"> ▪ [0] Disable (default) ▪ [1] Enable Notes: <ul style="list-style-type: none"> ▪ For this parameter to take effect, a device reset is required. ▪ For more information on transcoding, see Transcoding using Third-Party Call Control on page 451.
Web/EMS: Default Release Cause [DefaultReleaseCause]	Defines the default Release Cause (sent to IP) for IP-to-Tel calls when the device initiates a call release and an explicit matching cause for this release is not found. <p>The default release cause is NO_ROUTE_TO_DESTINATION (3). Other common values include NO_CIRCUIT_AVAILABLE (34), DESTINATION_OUT_OF_ORDER (27), etc.</p> Notes: <ul style="list-style-type: none"> ▪ The default release cause is described in the Q.931 notation and is translated to corresponding SIP 40x or 50x values (e.g., 3 to SIP 404, and 34 to SIP 503). ▪ Analog: For information on mapping PSTN release causes to SIP responses, see Mapping PSTN Release Cause to SIP Response on page 320. ▪ When the Trunk is disconnected or is not synchronized, the internal cause is 27. This cause is mapped, by default, to SIP 502. ▪ For mapping SIP-to-Q.931 and Q.931-to-SIP release causes, see Configuring Release Cause Mapping on page 315. ▪ For a list of SIP responses-Q.931 release cause mapping, see 'Alternative Routing to Trunk upon Q.931 Call Release Cause Code' on page 340.
Web: Enable Microsoft Extension [EnableMicrosoftExt]	Enables the modification of the called and calling number for numbers received with Microsoft's proprietary "ext=xxx" parameter in the SIP INVITE URI user part. Microsoft Office Communications Server sometimes uses this proprietary parameter to indicate the extension number of the called or calling party. <ul style="list-style-type: none"> ▪ [0] Disable (default) ▪ [1] Enable For example, if a calling party makes a call to telephone number 622125519100 Ext. 104, the device receives the SIP INVITE (from Microsoft's application) with the URI user part as INVITE sip:622125519100;ext=104@10.1.1.10 (or INVITE tel:622125519100;ext=104). If the parameter EnableMicrosoftExt is enabled, the device modifies the called number by adding an "e" as the prefix, removing the "ext=" parameter, and adding the extension number as the suffix (e.g., e622125519100 104). Once modified, the device can then manipulate the number further, using the Number Manipulation tables to leave only the last 3 digits (for example) for sending to a PBX.

Parameter	Description
EMS: Use SIP URI For Diversion Header [UseSIPURIForDiversionHeader]	Defines the URI format in the SIP Diversion header. <ul style="list-style-type: none"> [0] = 'tel:' (default) [1] = 'sip:'
[TimeoutBetween100And18x]	Defines the timeout (in msec) between receiving a 100 Trying response and a subsequent 18x response. If a 18x response is not received within this timeout period, the call is disconnected. The valid range is 0 to 180,000 (i.e., 3 minutes). The default is 32000 (i.e., 32 sec).
[EnableImmediateTrying]	Determines if and when the device sends a 100 Trying in response to an incoming INVITE request. <ul style="list-style-type: none"> [0] = 100 Trying response is sent upon receipt of a Proceeding message from the PSTN. [1] = (Default) 100 Trying response is sent immediately upon receipt of INVITE request.
[TransparentCoderPresentation]	Determines the format of the Transparent coder representation in the SDP. <ul style="list-style-type: none"> [0] = clearmode (default) [1] = X-CCD
[IgnoreRemoteSDPMKI]	Determines whether the device ignores the Master Key Identifier (MKI) if present in the SDP received from the remote side. <ul style="list-style-type: none"> [0] Disable (default) [1] Enable
[TrunkStatusReportingMode]	Determines whether the device responds to SIP OPTIONS if all the trunks pertaining to Trunk Group #1 are down or busy. <ul style="list-style-type: none"> [0] Disable (default) [1] Enable = If all the trunks pertaining to Trunk Group #1 are down or busy, the device does not respond to received SIP OPTIONS.
Web: Comfort Noise Generation Negotiation EMS: Comfort Noise Generation [ComfortNoiseNegotiation]	Enables negotiation and usage of Comfort Noise (CN). <ul style="list-style-type: none"> [0] Disable [1] Enable (default) <p>The use of CN is indicated by including a payload type for CN on the media description line of the SDP. The device can use CN with a codec whose RTP time stamp clock rate is 8,000 Hz (G.711/G.726). The static payload type 13 is used. The use of CN is negotiated between sides. Therefore, if the remote side doesn't support CN, it is not used. Regardless of the device's settings, it always attempts to adapt to the remote SIP UA's request for CNG, as described below.</p> <p>To determine CNG support, the device uses the ComfortNoiseNegotiation parameter and the codec's SCE (silence suppression setting) using the CodersGroup parameter.</p> <p>If the ComfortNoiseNegotiation parameter is enabled, then the following occurs:</p> <ul style="list-style-type: none"> If the device is the initiator, it sends a "CN" in the SDP only if the SCE of the codec is enabled. If the remote UA responds with a "CN" in the SDP, then CNG occurs; otherwise, CNG does not occur. If the device is the receiver and the remote SIP UA does not send a "CN" in the SDP, then no CNG occurs. If the remote side sends a "CN", the device attempts to be compatible with the remote side and

Parameter	Description
	<p>even if the codec's SCE is disabled, CNG occurs.</p> <p>If the ComfortNoiseNegotiation parameter is disabled, then the device does not send "CN" in the SDP. However, if the codec's SCE is enabled, then CNG occurs.</p>
[SDPEcanFormat]	<p>Defines the echo canceller format in the outgoing SDP. The 'ecan' attribute is used in the SDP to indicate the use of echo cancellation.</p> <ul style="list-style-type: none"> ▪ [0] = (Default) The 'ecan' attribute appears on the 'a=gpmde' line. ▪ [1] = The 'ecan' attribute appears as a separate attribute. ▪ [2] = The 'ecan' attribute is not included in the SDP. ▪ [3] = The 'ecan' attribute and the 'vbd' parameter are not included in the SDP. <p>Note: This parameter is applicable only when the IsFaxUsed parameter is set to 2, and for re-INVITE messages generated by the device as result of modem or fax tone detection.</p>
Web/EMS: First Call Ringback Tone ID [FirstCallIRBTId]	<p>Defines the index of the first ringback tone in the CPT file. This option enables an Application server to request the device to play a distinctive ringback tone to the calling party according to the destination of the call. The tone is played according to the Alert-Info header received in the 180 Ringing SIP response (the value of the Alert-Info header is added to the value of this parameter).</p> <p>The valid range is -1 to 1,000. The default is -1 (i.e., play standard ringback tone).</p> <p>Notes:</p> <ul style="list-style-type: none"> ▪ It is assumed that all ringback tones are defined in sequence in the CPT file. ▪ In case of an MLPP call, the device uses the value of this parameter plus 1 as the index of the ringback tone in the CPT file (e.g., if this value is set to 1, then the index is 2, i.e., 1 + 1).
Web: Reanswer Time EMS: Regret Time [RegretTime]	<p>Analog: Defines the time interval from when the user hangs up the phone until the call is disconnected (FXS). This allows the user to hang up and then pick up the phone (before this timeout) to continue the call conversation. Thus, it's also referred to as regret time.</p> <p>Digital: Defines the time period the device waits for an MFC R2 Resume (Reanswer) signal once a Suspend (Clear back) signal is received from the PBX. If this timer expires, the call is released. Note that this is applicable only to the MFC-R2 CAS Brazil variant.</p> <p>The valid range is 0 to 255 (in seconds). The default is 0.</p>
Web: Enable Reanswering Info [EnableReansweringINFO]	<p>Enables the device to send a SIP INFO message with the On-Hook/Off-Hook parameter when the FXS phone goes on-hook during an ongoing call and then off-hook again, within the user-defined regret timeout (configured by the parameter RegretTime). Therefore, the device notifies the far-end that the call has been re-answered.</p> <ul style="list-style-type: none"> ▪ [0] Disable (default) ▪ [1] Enable <p>This parameter is typically implemented for incoming IP-to-Tel collect calls to the FXS port. If the FXS user does not wish to accept the collect call, the user disconnects the call by on-hooking the phone. The device notifies the softswitch (or Application server) of the unanswered collect call (on-hook) by sending a SIP INFO message. As a result, the softswitch disconnects the call (sends a BYE message to the device). If the call is a regular incoming call and the FXS user on-hooks the phone without intending to disconnect the call, the softswitch does not</p>

Parameter	Description
	<p>disconnect the call (during the regret time). The INFO message format is as follows:</p> <pre>INFO sip:12345@10.50.228.164:5082 SIP/2.0 Via: SIP/2.0/UDP 127.0.0.1;branch=z9hG4bK_05_905924040-90579 From: <sip:+551137077803@ims.acme.com.br:5080;user=phone>;tag=008277765 To: <sip:notavailable@unknown.invalid>;tag=svw-0-1229428367 Call-ID: ConorCCR-0-LU-1229417827103300@dtas-stdn.fs5000group0-000.l CSeq: 1 INFO Contact: sip:10.20.7.70:5060 Content-Type: application/On-Hook (application/Off-Hook) Content-Length: 0</pre> <p>Notes:</p> <ul style="list-style-type: none"> ▪ This parameter is applicable only if the parameter RegretTime is configured. ▪ This parameter is applicable only to FXS interfaces.
<p>Web: PSTN Alert Timeout EMS: Trunk PSTN Alert Timeout [PSTNAlertTimeout]</p>	<p>Digital: Defines the Alert Timeout (in seconds) for calls sent to the PSTN. This timer is used between the time a Setup message is sent to the Tel side (IP-to-Tel call establishment) and a Connect message is received. If an Alerting message is received, the timer is restarted. If the timer expires before the call is answered, the device disconnects the call and sends a SIP 408 request timeout response to the SIP party that initiated the call.</p> <p>Analog: Defines the Alert Timeout (in seconds) for calls to the Tel side. This timer is used between the time a ring is generated (FXS) or a line is seized (FXO), until the call is connected. For example: If the FXS device receives an INVITE, it generates a ring to the phone and sends a SIP 180 Ringing response to the IP. If the phone is not answered within the time interval set by this parameter, the device cancels the call by sending a SIP 408 response.</p> <p>The valid value range is 1 to 600 (in seconds). The default is 180.</p> <p>Note: If per trunk configuration (using TrunkPSTNAlertTimeout) is set to other than default, the PSTNAlertTimeout parameter value is overridden.</p>
<p>Web/EMS: RTP Only Mode [RTPOnlyMode]</p>	<p>Enables the device to send and receive RTP packets to and from remote endpoints without the need to establish a SIP session. The remote IP address is determined according to the Outbound IP Routing table (Prefix parameter). The port is the same port as the local RTP port (configured by the BaseUDPPort parameter and the channel on which the call is received).</p> <ul style="list-style-type: none"> ▪ [0] Disable (default) ▪ [1] Transmit & Receive = Send and receive RTP packets. ▪ [2] Transmit Only= Send RTP packets only. ▪ [3] Receive Only= Receive RTP packets only. <p>Notes:</p> <ul style="list-style-type: none"> ▪ To activate the RTP Only feature without using ISDN / CAS signaling, you must do the following: <ul style="list-style-type: none"> ✓ Configure E1/T1 Transparent protocol type (set the ProtocolType parameter to 5 or 6). ✓ Enable the TDM-over-IP feature (set the EnableTDMoverIP

Parameter	Description
	parameter to 1). <ul style="list-style-type: none"> ▪ To configure the RTP Only mode per trunk, use the RTPOnlyModeForTrunk_x parameter. ▪ If per trunk configuration (using the RTPOnlyModeForTrunk_x parameter) is set to a value other than the default, the RTPOnlyMode parameter value is ignored.
[RTPOnlyModeForTrunk_x]	Enables the RTP Only feature per trunk, where ID denotes the trunk number (0 is the first trunk). For more information, see the RTPOnlyMode parameter. <p>Note: For using the global parameter (i.e., setting the RTP Only feature for all trunks), set this parameter to -1 (default).</p>
Web/EMS: SIT Q850 Cause [SITQ850Cause]	Defines the Q.850 cause value specified in the SIP Reason header that is included in a 4xx response when a Special Information Tone (SIT) is detected on an IP-to-Tel call. <p>The valid range is 0 to 127. The default is 34.</p> <p>Note: For mapping specific SIT tones, you can use the SITQ850CauseForNC, SITQ850CauseForIC, SITQ850CauseForVC, and SITQ850CauseForRO parameters.</p>
Web/EMS: SIT Q850 Cause For NC [SITQ850CauseForNC]	Defines the Q.850 cause value specified in the SIP Reason header that is included in a 4xx response when SIT-NC (No Circuit Found Special Information Tone) is detected from the TelPSTN for IP-to-Tel calls. <p>The valid range is 0 to 127. The default is 34.</p> <p>Notes:</p> <ul style="list-style-type: none"> ▪ When not configured (i.e., default), the SITQ850Cause parameter is used. ▪ This parameter is applicable only to FXO interfaces.
Web/EMS: SIT Q850 Cause For IC [SITQ850CauseForIC]	Defines the Q.850 cause value specified in the SIP Reason header that is included in a 4xx response when SIT-IC (Operator Intercept Special Information Tone) is detected from the PSTN for IP-to-Tel calls. <p>The valid range is 0 to 127. The default is -1 (not configured).</p> <p>Note: When not configured (i.e., default), the SITQ850Cause parameter is used.</p>
Web/EMS: SIT Q850 Cause For VC [SITQ850CauseForVC]	Defines the Q.850 cause value specified in the SIP Reason header that is included in a 4xx response when SIT-VC (Vacant Circuit - non-registered number Special Information Tone) is detected from the PSTN for IP-to-Tel calls. <p>The valid range is 0 to 127. The default is -1 (not configured).</p> <p>Note: When not configured (i.e., default), the SITQ850Cause parameter is used.</p>
Web/EMS: SIT Q850 Cause For RO [SITQ850CauseForRO]	Defines the Q.850 cause value specified in the SIP Reason header that is included in a 4xx response when SIT-RO (Reorder - System Busy Special Information Tone) is detected from the PSTN for IP-to-Tel calls. <p>The valid range is 0 to 127. The default is -1 (not configured).</p> <p>Note: When not configured (i.e., default), the SITQ850Cause parameter is used.</p>
[GWInboundManipulationSet]	Selects the Manipulation Set ID for manipulating all inbound INVITE messages. The Manipulation Set is defined using the MessageManipulations parameter. By default, no manipulation is done (i.e. Manipulation Set ID is set to -1).

Parameter	Description
[GWOutboundManipulationSet]	<p>Selects the Manipulation Set ID for manipulating all outbound INVITE messages. The Manipulation Set is defined using the MessageManipulations parameter. By default, no manipulation is done (i.e. Manipulation Set ID is set to -1).</p> <p>Note: This parameter is used only if the Outbound Message Manipulation Set parameter of the destination IP Group is not set.</p>
Out-of-Service (Busy Out) Parameters	
<p>Web/EMS: Enable Busy Out [EnableBusyOut]</p>	<p>Enables the Busy Out feature.</p> <ul style="list-style-type: none"> ▪ [0] Disable (Default) ▪ [1] Enable <p>When Busy Out is enabled and certain scenarios exist, the device does the following:</p> <ul style="list-style-type: none"> ▪ Analog: The FXS port behaves according to the settings of the FXSOOSBehavior parameter such as playing a reorder tone when the phone is off-hooked, or changing the line polarity. ▪ Digital: All E1/T1 trunks are automatically taken out of service by taking down the D-Channel or by sending a Service Out message for T1 PRI trunks supporting these messages (NI-2, 4/5-ESS, DMS-100, and Meridian). <p>These behaviors are done upon one of the following scenarios:</p> <ul style="list-style-type: none"> ▪ The device is physically disconnected from the network (i.e., Ethernet cable is disconnected). ▪ The Ethernet cable is connected, but the device is unable to communicate with any host. For this scenario, the LAN Watch-Dog must be activated (i.e., set the EnableLANWatchDog parameter to 1). ▪ The device can't communicate with the proxy (according to the Proxy Keep-Alive mechanism) and no other alternative route exists to send the call. ▪ The IP Connectivity mechanism is enabled (using the AltRoutingTel2IPEnable parameter) and there is no connectivity to any destination IP address. <p>Notes:</p> <ul style="list-style-type: none"> ▪ Analog: The FXSOOSBehavior parameter determines the behavior of the FXS endpoints when a Busy Out or Graceful Lock occurs. ▪ Analog: FXO endpoints during Busy Out and Lock are inactive. ▪ Analog: See the LifeLineType parameter for complementary optional behavior. ▪ Digital: The Busy Out behavior depends on the PSTN protocol type. ▪ Digital: The Busy-Out condition can also be applied to a specific Trunk Group. If there is no connectivity to the Serving IP Group of a specific Trunk Group (defined in the Trunk Group Settings table), all physical trunks pertaining to that Trunk Group are set to the Busy-Out condition. Each trunk uses the proper Out-Of-Service method according to the selected ISDN/CAS variant. ▪ Digital: To configure the method for setting digital trunks to Out-Of-Service, use the DigitalOOSBehavior parameter.
<p>Web/EMS: Graceful Busy Out Timeout [sec]</p>	<p>Defines the timeout interval (in seconds) for Out-of-Service graceful shutdown mode for busy trunks (per trunk) if communication fails with a</p>

Parameter	Description
[GracefulBusyOutTimeout]	Proxy server (or Proxy Set). In such a scenario, the device rejects new calls from the PSTN (Serving Trunk Group), but maintains currently active calls for this user-defined timeout. Once this timeout elapses, the device terminates currently active calls and takes the trunk out of service (sending the PSTN busy-out signal). Trunks on which no calls are active are immediately taken out of service regardless of the timeout. The range is 0 to 3,600. The default is 0. Note: This parameter is applicable only to digital interfaces.
Web: Digital Out-Of-Service Behavior EMS: Digital OOS Behavior For Trunk Value [DigitalOOSBehaviorForTrunk_x]	Determines the method for setting digital trunks to Out-Of-Service state per trunk. <ul style="list-style-type: none"> ▪ [-1] Not Configured = (Default) Use the settings of the DigitalOOSBehavior parameter for per device. ▪ [0] Default = Uses default behavior for each trunk (see note below). ▪ [1] Service = Sends ISDN In or Out of Service (only for ISDN protocols that support Service message). ▪ [2] D-Channel = Takes D-Channel down or up (ISDN only). ▪ [3] Alarm = Sends or clears PSTN AIS Alarm (ISDN and CAS). ▪ [4] Block = Blocks trunk (CAS only). Notes: <ul style="list-style-type: none"> ▪ This parameter is applicable only to digital interfaces. ▪ This parameter is applicable only if the parameter EnableBusyOut is set to 1. ▪ The default behavior (value 0) is as follows: <ul style="list-style-type: none"> ✓ ISDN: Use Service messages on supporting variants and use Alarm on non-supporting variants. ✓ CAS: Use Alarm. ▪ When updating this parameter value at run-time, you must stop the trunk and then restart it for the update to take effect. ▪ To determine the method for setting Out-Of-Service state for all trunks (i.e., per device), use the DigitalOOSBehavior parameter. ▪ The x in the <i>ini</i> file parameter name denotes the trunk number, where 0 is Trunk 1.
Web: Digital Out-Of-Service Behavior [DigitalOOSBehavior]	Determines the method for setting digital trunks to Out-of-Service state. This configuration applies to all the device's trunks. For a description of this parameter's options, see the DigitalOOSBehaviorForTrunk_x parameter. Notes: <ul style="list-style-type: none"> ▪ This parameter is applicable only to digital interfaces. ▪ To configure the method for setting Out-of-Service state per trunk, use the DigitalOOSBehaviorForTrunk_x parameter. ▪ To configure the timeout interval (in seconds) for Out-of-Service graceful shutdown mode for busy trunks if communication fails with a Proxy server (or Proxy Set), use the GracefulBusyOutTimeout parameter.
Web: Out-Of-Service Behavior EMS: FXS OOS Behavior [FXSOOSBehavior]	Determines the behavior of FXS endpoints when a Busy Out condition exists. <ul style="list-style-type: none"> ▪ [0] None = Silence is heard when the FXS endpoint goes off-hook. ▪ [1] Reorder Tone = (Default) The device plays a reorder tone to the connected phone / PBX. ▪ [2] Polarity Reversal = The device reverses the polarity of the

Parameter	Description
	<p>endpoint making it unusable (relevant, for example, for PBX DID lines).</p> <ul style="list-style-type: none"> ▪ [3] Reorder Tone + Polarity Reversal = Same as options [1] and [2]. ▪ [4] Current Disconnect = The device disconnects the current to the FXS endpoint. <p>Notes:</p> <ul style="list-style-type: none"> ▪ A device reset is required for this parameter to take effect when it is set to [2], [3], or [4]. ▪ This parameter is applicable only to FXS interfaces.
Retransmission Parameters	
Web: SIP T1 Retransmission Timer [msec] EMS: T1 RTX [SipT1Rtx]	<p>Defines the time interval (in msec) between the first transmission of a SIP message and the first retransmission of the same message. The default is 500.</p> <p>Note: The time interval between subsequent retransmissions of the same SIP message starts with SipT1Rtx. For INVITE requests, it is multiplied by two for each new retransmitted message. For all other SIP messages, it is multiplied by two until SipT2Rtx. For example, assuming SipT1Rtx = 500 and SipT2Rtx = 4000:</p> <ul style="list-style-type: none"> ▪ The first retransmission is sent after 500 msec. ▪ The second retransmission is sent after 1000 (2*500) msec. ▪ The third retransmission is sent after 2000 (2*1000) msec. ▪ The fourth retransmission and subsequent retransmissions until SIPMaxRtx are sent after 4000 (2*2000) msec.
Web: SIP T2 Retransmission Timer [msec] EMS: T2 RTX [SipT2Rtx]	<p>Defines the maximum interval (in msec) between retransmissions of SIP messages (except for INVITE requests). The default is 4000.</p> <p>Note: The time interval between subsequent retransmissions of the same SIP message starts with SipT1Rtx and is multiplied by two until SipT2Rtx.</p>
Web: SIP Maximum RTX EMS: Max RTX [SIPMaxRtx]	<p>Defines the maximum number of UDP transmissions of SIP messages (first transmission plus retransmissions). The range is 1 to 30. The default is 7.</p>
Web: Number of RTX Before Hot-Swap EMS: Proxy Hot Swap Rtx [HotSwapRtx]	<p>Defines the number of retransmitted INVITE/REGISTER messages before the call is routed (hot swap) to another Proxy/Registrar. The valid range is 1 to 30. The default is 3.</p> <p>Note: This parameter is also used for alternative routing. If a domain name in the Outbound IP Routing Table is resolved into two IP addresses, and if there is no response for HotSwapRtx retransmissions to the INVITE message that is sent to the first IP address, the device immediately initiates a call to the second IP address.</p>
SIP Message Manipulations Table	
Web: Message Manipulations EMS: Message Manipulations [MessageManipulations]	<p>This table parameter defines manipulation rules for SIP header messages. The format of this parameter is as follows:</p> <p>[MessageManipulations] FORMAT MessageManipulations_Index = MessageManipulations_ManSetID, MessageManipulations_MessageType,</p>

Parameter	Description
	MessageManipulations_Condition, MessageManipulations_ActionSubject, MessageManipulations_ActionType, MessageManipulations_ActionValue, MessageManipulations_RowRole; [MessageManipulations] For example, the below configuration changes the user part of the SIP From header to 200: MessageManipulations 1 = 0, Invite.Request, , Header.From.Url.User, 2, 200, 0; Note: For a detailed description of this table, see 'Configuring SIP Message Manipulation' on page 231.
Message Policy Table	
Web: Message Policy Table [MessagePolicy]	This table parameter configures SIP message policy rules for blocking (blacklist) unwanted incoming SIP messages or allowing (whitelist) receipt of desired messages. The format of this parameter is as follows: [MessagePolicy] FORMAT MessagePolicy_Index = MessagePolicy_Policy, MessagePolicy_MaxMessageLength, MessagePolicy_MaxHeaderLength, MessagePoliy_MaxBodyLength, MessagePolicy_MaxNumHeaders, MessagePolicy_MaxNumBodies, MessagePolicy_SendRejection, MessagePolicy_MethodListType, MessagePolicy_MethodList, MessagePolicy_BodyListType, MessagePolicy_BodyList; [/MessagePolicy] Note: For a detailed description of this table, see 'Configuring SIP Message Policy Rules'.

52.9 Coders and Profile Parameters

The profile parameters are described in the table below.

Profile Parameters

Parameter	Description
Coders Table / Coder Groups Table	
Web: Coders Table/Coder Group Settings EMS: Coders Group [CodersGroup0] [CodersGroup1] [CodersGroup2] [CodersGroup3] [CodersGroup4] [CodersGroup5] [CodersGroup6] [CodersGroup7] [CodersGroup8] [CodersGroup9]	This table parameter defines the device's coders. Each group can consist of up to 10 coders. The first Coder Group is the default coder list and the default Coder Group. The format of this parameter is as follows: [CodersGroup<0-9>] FORMAT CodersGroup0_Index = CodersGroup0_Name, CodersGroup0_pTime, CodersGroup0_rate, CodersGroup0_PayloadType, CodersGroup0_Sce; [\CodersGroup<0-9>] For example, below are defined two Coder Groups (0 and 1): [CodersGroup0] FORMAT CodersGroup0_Index = CodersGroup0_Name, CodersGroup0_pTime, CodersGroup0_rate, CodersGroup0_PayloadType, CodersGroup0_Sce; CodersGroup0 0 = g711Alaw64k, 20, 0, 255, 0;

Parameter	Description
	<p>CodersGroup0 1 = eg711Ulaw, 10, 0, 71, 0; CodersGroup0 2 = eg711Ulaw, 10, 0, 71, 0; [\CodersGroup0] [CodersGroup1] FORMAT CodersGroup1_Index = CodersGroup1_Name, CodersGroup1_pTime, CodersGroup1_rate, CodersGroup1_PayloadType, CodersGroup1_Sce; CodersGroup1 0 = Transparent, 20, 0, 56, 0; CodersGroup1 1 = g726, 20, 0, 23, 0; [\CodersGroup1]</p> <p>Notes:</p> <ul style="list-style-type: none"> ▪ For a list of supported coders and a detailed description of this table, see Configuring Coders on page 239. ▪ The coder name is case-sensitive.
IP Profile Table	
<p>Web: IP Profile Settings EMS: Protocol Definition > IP Profile [IPProfile]</p>	<p>This table parameter configures the IP Profile table. Each IP Profile ID includes a set of parameters (which are typically configured separately using their individual "global" parameters). You can later assign these IP Profiles to outbound IP routing rules (Prefix parameter), inbound IP routing rules and IP Groups.</p> <p>The format of this parameter is as follows: [IPProfile] FORMAT IpProfile_Index = IpProfile_ProfileName, IpProfile_IpPreference, IpProfile_CodersGroupID, IpProfile_IsFaxUsed, IpProfile_JitterBufMinDelay, IpProfile_JitterBufOptFactor, IpProfile_IPDiffServ, IpProfile_SigIPDiffServ, IpProfile_SCE, IpProfile_RTPRedundancyDepth, IpProfile_RemoteBaseUDPPort, IpProfile_CNGmode, IpProfile_VxxTransportType, IpProfile_NSEMode, IpProfile_IsDTMFUsed, IpProfile_PlayRBTone2IP, IpProfile_EnableEarlyMedia, IpProfile_ProgressIndicator2IP, IpProfile_EnableEchoCanceller, IpProfile_CopyDest2RedirectNumber, IpProfile_MediaSecurityBehaviour, IpProfile_CallLimit, IpProfile_DisconnectOnBrokenConnection, IpProfile_FirstTxDtmfOption, IpProfile_SecondTxDtmfOption, IpProfile_RxDTMFOption, IpProfile_EnableHold, IpProfile_InputGain, IpProfile_VoiceVolume, IpProfile_AddIEInSetup, IpProfile_SBCExtensionCodersGroupID, IpProfile_MediaIPVersionPreference, IpProfile_TranscodingMode, IpProfile_SBCAllowedCodersGroupID, IpProfile_SBCAllowedCodersMode, IpProfile_SBCMediaSecurityBehaviour, IpProfile_SBCRFC2833Behavior, IpProfile_SBCAlternativeDTMFMethod, IpProfile_SBCAssertIdentity, IpProfile_AMDSensitivityParameterSuit, IpProfile_AMDSensitivityLevel, IpProfile_AMDMaxGreetingTime, IpProfile_AMDMaxPostSilenceGreetingTime,</p>

Parameter	Description
	<p>IpProfile_SBCDiversionMode, IpProfile_SBCHistoryInfoMode, IpProfile_EnableQSIGTunneling, IpProfile_SBCFaxCodersGroupID, IpProfile_SBCFaxBehavior, IpProfile_SBCFaxOfferMode, IpProfile_SBCFaxAnswerMode, IpProfile_SbcPrackMode, IpProfile_SBCSessionExpiresMode, IpProfile_SBCRemoteUpdateSupport, IpProfile_SBCRemoteReinviteSupport, IpProfile_SBCRemoteDelayedOfferSupport, IpProfile_SBCRemoteReferBehavior, IpProfile_SBCRemote3xxBehavior, IpProfile_SBCRemoteMultiple18xSupport, IpProfile_SBCRemoteEarlyMediaResponseType, IpProfile_SBCRemoteEarlyMediaSupport, IpProfile_EnableSymmetricMKI, IpProfile_MKISize, IpProfile_SBCEnforceMKISize, IpProfile_SBCRemoteEarlyMediaRTP, IpProfile_SBCRemoteSupportsRFC3960, IpProfile_SBCRemoteCanPlayRingback, IpProfile_EnableEarly183, IpProfile_EarlyAnswerTimeout, IpProfile_SBC2833DTMFPayloadType, IpProfile_SBCUserRegistrationTime, IpProfile_ResetSRTPStateUponRekey, IpProfile_AmdMode, IpProfile_SBCReliableHeldToneSource, IpProfile_SBCPlayHeldTone, IpProfile_SBCRemoteHoldFormat, IpProfile_DelayTimeForInvite; [IPProfile]</p> <p>Note: For a description of this table, see 'Configuring IP Profiles' on page 245.</p>
Tel Profile Table	
Web: Tel Profile Settings EMS: Protocol Definition > Telephony Profile [TelProfile]	<p>This table parameter configures the Tel Profile table. Each Tel Profile ID includes a set of parameters (which are typically configured separately using their individual, "global" parameters). You can later assign these Tel Profile IDs to other elements such as in the Trunk Group TableEndpoint Phone Number table (TrunkGroup parameter). Therefore, Tel Profiles allow you to apply the same settings of a group of parameters to multiple channels, or apply specific settings to different channels.</p> <p>The format of this parameter is as follows:</p> <p>[TelProfile] FORMAT TelProfile_Index = TelProfile_ProfileName, TelProfile_TelPreference, TelProfile_CodersGroupID, TelProfile_IsFaxUsed, TelProfile_JitterBufMinDelay, TelProfile_JitterBufOptFactor, TelProfile_IPDiffServ, TelProfile_SigIPDiffServ, TelProfile_DtmfVolume, TelProfile_InputGain, TelProfile_VoiceVolume, TelProfile_EnableReversePolarity, TelProfile_EnableCurrentDisconnect, TelProfile_EnableDigitDelivery, TelProfile_EnableEC, TelProfile_MWIAAnalog, TelProfile_MWIDisplay, TelProfile_FlashHookPeriod, TelProfile_EnableEarlyMedia, TelProfile_ProgressIndicator2IP, TelProfile_TimeForReorderTone, TelProfile_EnableDIDWink, TelProfile_IsTwoStageDial, TelProfile_DisconnectOnBusyTone,</p>

Parameter	Description		
	<p>TelProfile_EnableVoiceMailDelay, TelProfile_DialPlanIndex, TelProfile_Enable911PSAP, TelProfile_SwapTelToIpPhoneNumbers, TelProfile_EnableAGC, TelProfile_ECNIpMode, TelProfile_DigitalCutThrough, TelProfile_EnableFXODoubleAnswer, TelProfile_CallPriorityMode;</p> <p>[TelProfile]</p> <p>Notes:</p> <ul style="list-style-type: none"> ▪ For a description of this parameter, see Configuring Tel Profiles on page 243. ▪ For a detailed description of each parameter, see its corresponding "global" parameter. 		
	TelProfile Field	Web Name	Global Parameter
	TelProfile_ProfileName	Profile Name	-
	TelProfile_TelPreference	Profile Preference	-
	TelProfile_CodersGroupID	Coder Group	CodersGroup0
	TelProfile_IsFaxUsed	Fax Signaling Method	IsFaxUsed
	TelProfile_JitterBufMinDelay	Dynamic Jitter Buffer Minimum Delay	DJBufMinDelay
	TelProfile_JitterBufOptFactor	Dynamic Jitter Buffer Optimization Factor	DJBufOptFactor
	TelProfile_IPDiffServ	RTP IP DiffServ	PremiumServiceClassMediaDiffServ
	TelProfile_SigIPDiffServ	Signaling DiffServ	PremiumServiceClassControlDiffServ
	TelProfile_DtmfVolume	DTMF Volume	DTMFVolume
	TelProfile_InputGain	Input Gain	InputGain
	TelProfile_VoiceVolume	Voice Volume	VoiceVolume
	TelProfile_EnableReversePolarity	Enable Polarity Reversal	EnableReversalPolarity
	TelProfile_EnableCurrentDisconnect	Enable Current Disconnect	EnableCurrentDisconnect
	TelProfile_EnableDigitDelivery	Enable Digit Delivery	EnableDigitDelivery
	TelProfile_EnableEC	Echo Canceler	EnableEchoCanceller
	TelProfile_MWIAnalog	MWI Analog Lamp	MWIAnalogLamp
	TelProfile_MWIDisplay	MWI Display	MWIDisplay
	TelProfile_FlashHookPeriod	Flash Hook Period	FlashHookPeriod
	TelProfile_EnableEarlyMedia	Enable Early Media	EnableEarlyMedia
	TelProfile_ProgressIndicator2IP	Progress Indicator to IP	ProgressIndicator2IP
	TelProfile_TimeForReorderTone	Time For Reorder Tone	TimeForReorderTone

Parameter	Description		
	TelProfile_EnableDIDWink	Enable DID Wink	EnableDIDWink
	TelProfile_IsTwoStageDial	Dialing Mode	IsTwoStageDial
	TelProfile_DisconnectOnBusyTone	Disconnect Call on Detection of Busy Tone	DisconnectOnBusyTone
	TelProfile_EnableVoiceMailDelay	Enable Voice Mail Delay	-
	TelProfile_DialPlanIndex	Dial Plan Index	DialPlanIndex
	TelProfile_Enable911PSAP	Enable 911 PSAP	Enable911PSAP
	TelProfile_SwapTelToIPPhoneNumbers	Swap Tel To IP Phone Numbers	SwapTEI2IPCalled&CallingNumbers
	TelProfile_EnableAGC	Enable AGC	EnableAGC
	TelProfile_ECnlpMode	EC NLP Mode	ECNLPMode
	TelProfile_DigitalCutThrough	-	DigitalCutThrough
	TelProfile_EnableFXODoubleAnswer	-	EnableFXODoubleAnswer
	TelProfile_CallPriorityMode	-	CallPriorityMode
The parameter IpPreference parameter EnableVo.			

52.10 Channel Parameters

This subsection describes the device's channel parameters.

52.10.1 Voice Parameters

The voice parameters are described in the table below.

Voice Parameters

Parameter	Description
Web/EMS: Input Gain [InputGain]	<p>Defines the pulse-code modulation (PCM) input gain control (in decibels). This parameter sets the level for the received (Tel/PSTN-to-IP) signal.</p> <p>The valid range is -32 to 31 dB. The default is 0 dB.</p> <p>Note: This parameter can also be configured in an IP Profile and/or a Tel Profile.</p>
Web: Voice Volume EMS: Volume (dB) [VoiceVolume]	<p>Defines the voice gain control (in decibels). This parameter sets the level for the transmitted (IP-to-Tel/PSTN) signal.</p> <p>The valid range is -32 to 31 dB. The default is 0 dB.</p> <p>Note: This parameter can also be configured in an IP Profile and/or a Tel Profile.</p>
EMS: Payload Format [VoicePayloadFormat]	<p>Determines the bit ordering of the G.726/G.727 voice payload format.</p> <ul style="list-style-type: none"> [0] = (Default) Little Endian

Parameter	Description
	<ul style="list-style-type: none"> [1] = Big Endian <p>Note: To ensure high voice quality when using G.726/G.727, both communicating ends should use the same endianness format. Therefore, when the device communicates with a third-party entity that uses the G.726/G.727 voice coder and voice quality is poor, change the settings of this parameter (between Big Endian and Little Endian).</p>
Web: MF Transport Type [MFTransportType]	Currently, not supported.
Web: Enable Answer Detector [EnableAnswerDetector]	Currently, not supported.
Web: Answer Detector Activity Delay [AnswerDetectorActivityDelay]	Defines the time (in 100-msec resolution) between activating the Answer Detector and the time that the detector actually starts to operate. The valid range is 0 to 1023. The default is 0.
Web: Answer Detector Silence Time [AnswerDetectorSilenceTime]	Currently, not supported.
Web: Answer Detector Redirection [AnswerDetectorRedirection]	Currently, not supported.
Web: Answer Detector Sensitivity EMS: Sensitivity [AnswerDetectorSensitivity]	Defines the Answer Detector sensitivity. The range is 0 (most sensitive) to 2 (least sensitive). The default is 0.
Web: Silence Suppression EMS: Silence Compression Mode [EnableSilenceCompression]	<p>Determines the Silence Suppression support. Silence Suppression is a method for conserving bandwidth on VoIP calls by not sending packets when silence is detected.</p> <ul style="list-style-type: none"> [0] Disable = (Default) Silence Suppression is disabled. [1] Enable = Silence Suppression is enabled. [2] Enable without Adaptation = A single silence packet is sent during a silence period (applicable only to G.729). <p>Note: If the selected coder is G.729, the value of the 'annexb' parameter of the frmt attribute in the SDP is determined by the following rules:</p> <ul style="list-style-type: none"> If EnableSilenceCompression is 0: 'annexb=no'. If EnableSilenceCompression is 1: 'annexb=yes'. If EnableSilenceCompression is 2 and IsCiscoSCEMode is 0: 'annexb=yes'. If EnableSilenceCompression is 2 and IsCiscoSCEMode is 1: 'annexb=no'. <p>Note: This parameter can also be configured in an IP Profile.</p>
Web: Echo Canceler EMS: Echo Canceller Enable [EnableEchoCanceller]	<p>Enables echo cancellation (i.e., echo from voice calls is removed).</p> <ul style="list-style-type: none"> [0] Disable [1] Enable (default) <p>Note: This parameter can also be configured in an IP Profile and/or a Tel Profile.</p>

Parameter	Description
Web: Max Echo Canceller Length [MaxEchoCancellerLength]	Defines the maximum Echo Canceller Length (in msec), which is the maximum echo path delay (tail length) for which the echo canceller is designed to operate: <ul style="list-style-type: none"> ▪ [0] Default = (Default) Based on various internal device settings to attain maximum channel capacity ▪ [11] 64 msec ▪ [22] 128 msec Notes: <ul style="list-style-type: none"> ▪ For this parameter to take effect, a device reset is required. ▪ Using 128 msec may reduce channel capacity. For example: with DSP Template 0 and number of spans 4, the capacity is reduced from 120 to 100. The reduction depends on the combination of “DSP Template” and “Number of Spans”. For accurate figures, see DSP Templates on page 839. ▪ When housed with an analog/BRI module, the device (Mediant 1000) can use a max. echo canceller length of 64 msec. ▪ When housed with PRI TRUNKS module, the device (Mediant 1000) can use a max. echo canceller length of 128 msec. ▪ When housed with an MPM module (in Slot #6), no channel reduction occurs (for Mediant 1000). ▪ It is unnecessary to configure the parameter EchoCancellerLength, as it automatically acquires its value from this parameter.
EMS: Echo Canceller Hybrid Loss [ECHybridLoss]	Defines the four-wire to two-wire worst-case Hybrid loss, the ratio between the signal level sent to the hybrid and the echo level returning from the hybrid. <ul style="list-style-type: none"> ▪ [0] = (Default) 6 dB ▪ [1] = N/A ▪ [2] = 0 dB ▪ [3] = 3 dB
EMS: ECN Ip Mode [ECNLPMode]	Defines the echo cancellation Non-Linear Processing (NLP) mode. <ul style="list-style-type: none"> ▪ [0] = (Default) NLP adapts according to echo changes ▪ [1] = Disables NLP ▪ [2] = Silence output NLP Note: This parameter can also be configured in a Tel Profile.
[EchoCancellerAggressiveNLP]	Enables the Aggressive NLP at the first 0.5 second of the call. <ul style="list-style-type: none"> ▪ [0] = Disable ▪ [1] = (Default) Enable. The echo is removed only in the first half of a second of the incoming IP signal. Note: For this parameter to take effect, a device reset is required.
[RTPSIDCoeffNum]	Defines the number of spectral coefficients added to an SID packet being sent according to RFC 3389. The valid values are [0] (default), [4] , [6] , [8] and [10] .

52.10.2 Coder Parameters

The coder parameters are described in the table below.

Coder Parameters

Parameter	Description
[EnableEVRCVAD]	<p>Enables the EVRC voice activity detector.</p> <ul style="list-style-type: none"> [0] = Disable (default) [1] = Enable <p>Note: Supported for EVRC and EVRC-B coders.</p>
EMS: VBR Coder DTX Min [EVRCDTXMin]	<p>Defines the minimum gap between two SID frames when using the EVRC voice activity detector. Units are in EVRC frame size (20 msec).</p> <p>The range is 0 to 20000. The default is 12.</p> <p>Note: Supported for EVRC and EVRC-B coders.</p>
EMS: VBR Coder DTX Max [EVRCDTXMax]	<p>Defines the maximum gap between two SID frames when using the EVRC voice activity detector. Units are in EVRC frame size (20 msec).</p> <p>The range is 0 to 20000. The default is 32.</p> <p>Note: This parameter is applicable only to EVRC and EVRC-B coders.</p>
EMS: VBR Coder Header Format [VBRCoderHeaderFormat]	<p>Determines the format of the RTP header for VBR coders.</p> <ul style="list-style-type: none"> [0] = (Default) Payload only (no header, TOC, or m-factor) - similar to RFC 3558 Header Free format. [1] = Supports RFC 2658 - 1 byte for interleaving header (always 0), TOC, no m-factor. [2] = Payload including TOC only, allow m-factor. [3] = RFC 3558 Interleave/Bundled format.
EMS: VBR Coder Hangover [VBRCoderHangover]	<p>Defines the required number of silence frames at the beginning of each silence period when using the VBR coder silence suppression.</p> <p>The range is 0 to 255. The default is 1.</p>
EMS: AMR Coder Header Format [AMRCoderHeaderFormat]	<p>Determines the payload format of the AMR header.</p> <ul style="list-style-type: none"> [0] = Non-standard multiple frames packing in a single RTP frame. Each frame has a CMR and TOC header. [1] = AMR frame according to RFC 3267 bundling. [2] = AMR frame according to RFC 3267 interleaving. [3] = AMR is passed using the AMR IF2 format. <p>Note: Bandwidth Efficient mode is not supported; the mode is always Octet-aligned.</p>
Web: DSP Version Template Number EMS: Version Template Number [DSPVersionTemplateNumber]	<p>Determines the DSP template used by the device. Each DSP template supports specific coders, channel capacity, and features. The default is DSP Template 0.</p> <p>You can load different DSP templates to analog and digital modules using the syntax DSPVersionTemplateNumber=x where:</p> <ul style="list-style-type: none"> x = 0 or 1 for DSP templates of analog modules

Parameter	Description
	<ul style="list-style-type: none"> y = 0 to 5 for DSP templates of digital and MPM modules <p>Notes:</p> <ul style="list-style-type: none"> For this parameter to take effect, a device reset is required. For a list of supported DSP templates, see DSP Templates on page 839.

52.10.3 DTMF Parameters

The dual-tone multi-frequency (DTMF) parameters are described in the table below.

DTMF Parameters

Parameter	Description
Web/EMS: DTMF Transport Type [DTMFTransportType]	Determines the DTMF transport type. <ul style="list-style-type: none"> [0] Mute DTMF = DTMF digits are removed from the voice stream and are not relayed to remote side. [2] Transparent DTMF = DTMF digits remain in the voice stream. [3] RFC 2833 Relay DTMF = (Default) DTMF digits are removed from the voice stream and are relayed to remote side according to RFC 2833. [7] RFC 2833 Relay Decoder Mute = DTMF digits are sent according to RFC 2833 and muted when received. <p>Note: This parameter is automatically updated if the parameters TxDTMFOption or RxDTMFOption are configured.</p>
Web: DTMF Volume (-31 to 0 dB) EMS: DTMF Volume (dBm) [DTMFVolume]	Defines the DTMF gain control value (in decibels) to the PSTN or analog side. The valid range is -31 to 0 dB. The default is -11 dB. <p>Note: This parameter can also be configured in a Tel Profile.</p>
Web: DTMF Generation Twist EMS: DTMF Twist Control [DTMFGenerationTwist]	Defines the range (in decibels) between the high and low frequency components in the DTMF signal. Positive decibel values cause the higher frequency component to be stronger than the lower one. Negative values cause the opposite effect. For any parameter value, both components change so that their average is constant. The valid range is -10 to 10 dB. The default is 0 dB. <p>Note: For this parameter to take effect, a device reset is required.</p>
EMS: DTMF Inter Interval (msec) [DTMFInterDigitInterval]	Defines the time (in msec) between generated DTMF digits to PSTN side (if TxDTMFOption = 1, 2 or 3). The default is 100 msec. The valid range is 0 to 32767.
EMS: DTMF Length (msec) [DTMFDigitLength]	Defines the time (in msec) for generating DTMF tones to the PSTN side (if TxDTMFOption = 1, 2 or 3). It also configures the duration that is sent in INFO (Cisco) messages. The valid range is 0 to 32767. The default is 100.
EMS: Rx DTMF Relay Hang Over Time (msec) [RxDTMFHangOverTime]	Defines the Voice Silence time (in msec) after playing DTMF or MF digits to the Tel/PSTN side that arrive as Relay from the IP side. Valid range is 0 to 2,000 msec. The default is 1,000 msec.
EMS: Tx DTMF Relay Hang	Defines the Voice Silence time (in msec) after detecting the end of

Parameter	Description
Over Time (msec) [TxDTMFHangOverTime]	DTMF or MF digits at the Tel/PSTN side when the DTMF Transport Type is either Relay or Mute. Valid range is 0 to 2,000 msec. The default is 1,000 msec.
Web/EMS: NTE Max Duration [NTEMaxDuration]	Defines the maximum time for sending Named Telephony Events / NTEs (RFC 4733/2833 DTMF relay) to the IP side, regardless of the DTMF signal duration on the TDM side. The range is -1 to 200,000,000 msec. The default is -1 (i.e., NTE stops only upon detection of an End event).

52.10.4 RTP, RTCP and T.38 Parameters

The RTP, RTCP and T.38 parameters are described in the table below.

RTP/RTCP and T.38 Parameters

Parameter	Description
Web: Dynamic Jitter Buffer Minimum Delay EMS: Minimal Delay (dB) [DJBufMinDelay]	Defines the minimum delay (in msec) for the Dynamic Jitter Buffer. The valid range is 0 to 150. The default delay is 10. Notes: <ul style="list-style-type: none"> This parameter can also be configured in an IP Profile and/or a Tel Profile. For more information on Jitter Buffer, see Dynamic Jitter Buffer Operation on page 169.
Web: Dynamic Jitter Buffer Optimization Factor EMS: Opt Factor [DJBufOptFactor]	Defines the Dynamic Jitter Buffer frame error/delay optimization factor. The valid range is 0 to 12. The default factor is 10. Notes: <ul style="list-style-type: none"> For data (fax and modem) calls, set this parameter to 12. This parameter can also be configured in an IP Profile and/or a Tel Profile. For more information on Jitter Buffer, see Dynamic Jitter Buffer Operation on page 169.
Web/EMS: Analog Signal Transport Type [AnalogSignalTransportType]	Determines the analog signal transport type. <ul style="list-style-type: none"> [0] Ignore Analog Signals = (Default) Ignore. [1] RFC 2833 Analog Signal Relay = Transfer hookflash using RFC 2833.
Web: RTP Redundancy Depth EMS: Redundancy Depth [RTPRedundancyDepth]	Enables the device to generate RFC 2198 redundant packets. This can be used for packet loss where the missing information (audio) can be reconstructed at the receiver's end from the redundant data that arrives in subsequent packets. This is required, for example, in wireless networks where a high percentage (up to 50%) of packet loss can be experienced. <ul style="list-style-type: none"> [0] 0 = (Default) Disable. [1] 1 = Enable - previous voice payload packet is added to current packet. Notes: <ul style="list-style-type: none"> When enabled, you can configure the payload type, using the

Parameter	Description
	RFC2198PayloadType parameter. <ul style="list-style-type: none"> The RTP redundancy dynamic payload type can be included in the SDP, by using the EnableRTPRedundancyNegotiation parameter. This parameter can also be configured in an IP Profile.
Web: Enable RTP Redundancy Negotiation [EnableRTPRedundancyNegotiation]	Enables the device to include the RTP redundancy dynamic payload type in the SDP, according to RFC 2198. <ul style="list-style-type: none"> [0] Disable (default) [1] Enable When enabled, the device includes in the SDP message the RTP payload type "RED" and the payload type configured by the parameter RFC2198PayloadType. <pre>a=rtpmap:<PT> RED/8000</pre> Where <PT> is the payload type as defined by RFC2198PayloadType. The device sends the INVITE message with "a=rtpmap:<PT> RED/8000" and responds with a 18x/200 OK and "a=rtpmap:<PT> RED/8000" in the SDP. Notes: <ul style="list-style-type: none"> For this feature to be functional, you must also set the parameter RTPRedundancyDepth to 1 (i.e., enabled). Currently, the negotiation of "RED" payload type is not supported and therefore, it should be configured to the same PT value for both parties.
Web: RFC 2198 Payload Type EMS: Redundancy Payload Type [RFC2198PayloadType]	Defines the RTP redundancy packet payload type according to RFC 2198. <p>The range is 96 to 127. The default is 104.</p> Note: This parameter is applicable only if the parameter RTPRedundancyDepth is set to 1.
Web: Packing Factor EMS: Packetization Factor [RTPPackagingFactor]	N/A. Controlled internally by the device according to the selected coder.
Web/EMS: Basic RTP Packet Interval [BasicRTPPacketInterval]	N/A. Controlled internally by the device according to the selected coder.
Web: RTP Directional Control [RTPDirectionControl]	N/A. Controlled internally by the device according to the selected coder.
Web/EMS: RFC 2833 TX Payload Type [RFC2833TxPayloadType]	Defines the Tx RFC 2833 DTMF relay dynamic payload type. <p>The valid range is 96 to 99, and 106 to 127. The default is 96. The 100, 102 to 105 range is allocated for proprietary usage.</p> Notes: <ul style="list-style-type: none"> Certain vendors (e.g., Cisco) use payload type 101 for RFC 2833. When RFC 2833 payload type negotiation is used (i.e., the parameter TxDTMFOption is set to 4), this payload type is used for the received DTMF packets. If negotiation isn't used, this payload type is used for receive and for transmit.

Parameter	Description
Web/EMS: RFC 2833 RX Payload Type [RFC2833RXPayloadType]	Defines the Rx RFC 2833 DTMF relay dynamic payload type. The valid range is 96 to 99, and 106 to 127. The default is 96. The 100, 102 to 105 range is allocated for proprietary usage. Notes: <ul style="list-style-type: none"> ▪ Certain vendors (e.g., Cisco) use payload type 101 for RFC 2833. ▪ When RFC 2833 payload type negotiation is used (i.e., the parameter TxDTMFOption is set to 4), this payload type is used for the received DTMF packets. If negotiation isn't used, this payload type is used for receive and for transmit.
[EnableDetectRemoteMACChange]	Determines whether the device changes the RTP packets according to the MAC address of received RTP packets and according to Gratuitous Address Resolution Protocol (GARP) messages. <ul style="list-style-type: none"> ▪ [0] = Nothing is changed. ▪ [1] = If the device receives RTP packets with a different source MAC address (than the MAC address of the transmitted RTP packets), then it sends RTP packets to this MAC address and removes this IP entry from the device's ARP cache table. ▪ [2] = (Default) The device uses the received GARP packets to change the MAC address of the transmitted RTP packets. ▪ [3] = Options 1 and 2 are used. Notes: <ul style="list-style-type: none"> ▪ For this parameter to take effect, a device reset is required. ▪ If the device is located in a network subnet which is connected to other gateways using a router that uses Virtual Router Redundancy Protocol (VRRP) for redundancy, then set this parameter to 0 or 2.
Web: RTP Base UDP Port EMS: Base UDP Port [BaseUDPport]	Defines the lower boundary of the UDP port used for RTP, RTCP (RTP port + 1) and T.38 (RTP port + 2). For example, if the Base UDP Port is set to 6000, then one channel may use the ports RTP 6000, RTCP 6001, and T.38 6002, while another channel may use RTP 6010, RTCP 6011, and T.38 6012, and so on. The range of possible UDP ports is 6,000 to 64,000. The default base UDP port is 6000. Once this parameter is configured, the UDP port range (lower to upper boundary) is calculated as follows: <ul style="list-style-type: none"> ▪ BaseUDPport to (BaseUDPport + 255*10) Notes: <ul style="list-style-type: none"> ▪ For this parameter to take effect, a device reset is required. ▪ The UDP ports are allocated randomly to channels. ▪ You can define a UDP port range per Media Realm (see Configuring Media Realms on page 183). ▪ If RTP Base UDP Port is not a factor of 10, the following message is generated: 'invalid local RTP port'.
Web: Remote RTP Base UDP Port EMS: Remote Base UDP Port [RemoteBaseUDPPort]	Defines the lower boundary of UDP ports used for RTP, RTCP and T.38 by a remote device. If this parameter is set to a non-zero value, ThroughPacket™ (RTP multiplexing) is enabled. The device uses this parameter (and BaseUDPPort) to identify and distribute the payloads from the received multiplexed IP packet to the

Parameter	Description
	<p>relevant channels.</p> <p>The valid range is the range of possible UDP ports: 6,000 to 64,000. The default is 0 (i.e., RTP multiplexing is disabled).</p> <p>Notes:</p> <ul style="list-style-type: none"> ▪ The value of this parameter on the local device must equal the value of BaseUDPPort on the remote device. ▪ To enable RTP multiplexing, the parameters L1L1ComplexTxUDPPort and L1L1ComplexRxUDPPort must be set to a non-zero value. ▪ When VLANs are used, RTP multiplexing is not supported. ▪ This parameter can also be configured in an IP Profile. ▪ For more information on RTP multiplexing, see RTP Multiplexing (ThroughPacket) on page 173.
Web: RTP Multiplexing Local UDP Port [L1L1ComplexTxUDPPort]	<p>Defines the local (source) UDP port for outgoing multiplexed RTP packets, for RTP multiplexing.</p> <p>The valid value is the range of possible UDP ports: 6,000 to 64,000. The default is 0 (i.e., RTP multiplexing is disabled).</p> <p>Note: For this parameter to take effect, a device reset is required.</p>
Web: RTP Multiplexing Remote UDP Port [L1L1ComplexRxUDPPort]	<p>Defines the remote UDP port to where the multiplexed RTP packets are sent and the local UDP port for incoming multiplexed RTP packets, for RTP multiplexing.</p> <p>The valid value is the range of possible UDP ports: 6,000 to 64,000. The default is 0 (i.e., RTP multiplexing is disabled).</p> <p>Notes:</p> <ul style="list-style-type: none"> ▪ For this parameter to take effect, a device reset is required. ▪ All devices that participate in the same RTP multiplexing session must use this same port.
EMS: No Op Enable [NoOpEnable]	<p>Enables the transmission of RTP or T.38 No-Op packets.</p> <ul style="list-style-type: none"> ▪ [0] = Disable (default) ▪ [1] = Enable <p>This mechanism ensures that the NAT binding remains open during RTP or T.38 silence periods.</p>
EMS: No Op Interval [NoOpInterval]	<p>Defines the time interval in which RTP or T.38 No-Op packets are sent in the case of silence (no RTP/T.38 traffic) when No-Op packet transmission is enabled.</p> <p>The valid range is 20 to 65,000 msec. The default is 10,000.</p> <p>Note: To enable No-Op packet transmission, use the NoOpEnable parameter.</p>
EMS: No Op Payload Type [RTPNoOpPayloadType]	<p>Defines the payload type of No-Op packets.</p> <p>The valid range is 96 to 127 (for the range of Dynamic RTP Payload Type for all types of non hard-coded RTP Payload types, refer to RFC 3551). The default is 120.</p> <p>Note: When defining this parameter, ensure that it doesn't cause collision with other payload types.</p>

Parameter	Description
[RTCPActivationMode]	<p>Disables RTCP traffic when there is no RTP traffic. This feature is useful, for example, to stop RTCP traffic that is typically sent when calls are put on hold (by an INVITE with 'a=inactive' in the SDP).</p> <ul style="list-style-type: none"> ▪ [0] Active Always = (Default) RTCP is active even during inactive RTP periods, i.e., when the media is in 'recvonly' or 'inactive' mode. ▪ [1] Inactive Only If RTP Inactive = No RTCP is sent when RTP is inactive.
RTP Control Protocol Extended Reports (RTCP XR) Parameters	
Web: Enable RTCP XR EMS: RTCP XR Enable [VQMonEnable]	<p>Enables voice quality monitoring and RTCP XR, according to Internet-Draft draft-ietf-sipping-rtcp-summary-13.</p> <ul style="list-style-type: none"> ▪ [0] Disable (default) ▪ [1] Enable <p>Note: For this parameter to take effect, a device reset is required.</p>
Web: Minimum Gap Size EMS: GMin [VQMonGMin]	<p>Defines the voice quality monitoring - minimum gap size (number of frames).</p> <p>The default is 16.</p>
Web/EMS: Burst Threshold [VQMonBurstHR]	<p>Defines the voice quality monitoring - excessive burst alert threshold.</p> <p>The default is -1 (i.e., no alerts are issued).</p>
Web/EMS: Delay Threshold [VQMonDelayTHR]	<p>Defines the voice quality monitoring - excessive delay alert threshold.</p> <p>The default is -1 (i.e., no alerts are issued).</p>
Web: R-Value Delay Threshold EMS: End of Call Rval Delay Threshold [VQMonEOCRValTHR]	<p>Defines the voice quality monitoring - end of call low quality alert threshold.</p> <p>The default is -1 (i.e., no alerts are issued).</p>
Web: RTCP XR Packet Interval EMS: Packet Interval [RTCPInterval]	<p>Defines the time interval (in msec) between adjacent RTCP reports.</p> <p>The valid value range is 0 to 65,535. The default is 5,000.</p>
Web: Disable RTCP XR Interval Randomization EMS: Disable Interval Randomization [DisableRTCPRandomize]	<p>Determines whether RTCP report intervals are randomized or whether each report interval accords exactly to the parameter RTCPInterval.</p> <ul style="list-style-type: none"> ▪ [0] Disable = (Default) Randomize ▪ [1] Enable = No Randomize
EMS: RTCP XR Collection Server Transport Type [RTCPXRESCTransportType]	<p>Defines the transport layer used for outgoing SIP dialogs initiated by the device to the RTCP XR Collection Server.</p> <ul style="list-style-type: none"> ▪ [-1] Not Configured (default) ▪ [0] UDP ▪ [1] TCP ▪ [2] TLS <p>Note: When set to [-1], the value of the SIPTransportType parameter is used.</p>
Web: RTCP XR Collection Server EMS: Esc IP	<p>Defines the IP address of the Event State Compositor (ESC). The device sends RTCP XR reports to this server, using SIP PUBLISH messages. The address can be configured as a numerical IP</p>

Parameter	Description
[RTCPXREscIP]	address or as a domain name.
Web: RTCP XR Report Mode EMS: Report Mode [RTCPXRReportMode]	Determines whether RTCP XR reports are sent to the Event State Compositor (ESC) and defines the interval at which they are sent. <ul style="list-style-type: none"> ▪ [0] Disable = (Default) RTCP XR reports are not sent to the ESC. ▪ [1] End Call = RTCP XR reports are sent to the ESC at the end of each call. ▪ [2] End Call & Periodic = RTCP XR reports are sent to the ESC at the end of each call and periodically according to the RTCPInterval parameter.

52.11 Gateway and IP-to-IP Parameters

52.11.1 Fax and Modem Parameters

The fax and modem parameters are described in the table below.

Fax and Modem Parameters

Parameter	Description
Web: Fax Transport Mode EMS: Transport Mode [FaxTransportMode]	Determines the fax transport mode used by the device. <ul style="list-style-type: none"> ▪ [0] Disable = transparent mode ▪ [1] T.38 Relay (default) ▪ [2] Bypass ▪ [3] Events Only Note: This parameter is overridden by the parameter IsFaxUsed. If the parameter IsFaxUsed is set to 1 (T.38 Relay) or 3 (Fax Fallback), then FaxTransportMode is always set to 1 (T.38 relay).
Web: V.21 Modem Transport Type EMS: V21 Transport [V21ModemTransportType]	Determines the V.21 modem transport type. <ul style="list-style-type: none"> ▪ [0] Disable = (Default) Disable (Transparent) ▪ [2] Enable Bypass ▪ [3] Events Only = Transparent with Events Note: This parameter can also be configured in an IP Profile.
Web: V.22 Modem Transport Type EMS: V22 Transport [V22ModemTransportType]	Determines the V.22 modem transport type. <ul style="list-style-type: none"> ▪ [0] Disable = Disable (Transparent) ▪ [2] Enable Bypass (default) ▪ [3] Events Only = Transparent with Events Note: This parameter can also be configured in an IP Profile.
Web: V.23 Modem Transport Type EMS: V23 Transport [V23ModemTransportType]	Determines the V.23 modem transport type. <ul style="list-style-type: none"> ▪ [0] Disable = Disable (Transparent) ▪ [2] Enable Bypass (default) ▪ [3] Events Only = Transparent with Events Note: This parameter can also be configured in an IP Profile.
Web: V.32 Modem Transport Type EMS: V32 Transport [V32ModemTransportType]	Determines the V.32 modem transport type. <ul style="list-style-type: none"> ▪ [0] Disable = Disable (Transparent) ▪ [2] Enable Bypass (default)

Parameter	Description
	<ul style="list-style-type: none"> ▪ [3] Events Only = Transparent with Events <p>Notes:</p> <ul style="list-style-type: none"> ▪ This parameter applies only to V.32 and V.32bis modems. ▪ This parameter can also be configured in an IP Profile.
Web: V.34 Modem Transport Type EMS: V34 Transport [V34ModemTransportType]	Determines the V.90/V.34 modem transport type. <ul style="list-style-type: none"> ▪ [0] Disable = Disable (Transparent) ▪ [2] Enable Bypass (default) ▪ [3] Events Only = Transparent with Events <p>Note: This parameter can also be configured in an IP Profile.</p>
EMS: Bell Transport Type [BellModemTransportType]	Determines the Bell modem transport method. <ul style="list-style-type: none"> ▪ [0] = Transparent (default) ▪ [2] = Bypass ▪ [3] = Transparent with events
Web/EMS: Fax CNG Mode [FaxCNGMode]	Determines the device's handling of fax relay upon detection of a fax CNG tone from originating faxes. <ul style="list-style-type: none"> ▪ [0] Doesn't send T.38 Re-INVITE = (Default) SIP re-INVITE is not sent. ▪ [1] Sends on CNG tone = Sends a SIP re-INVITE with T.38 parameters in SDP to the terminating fax upon detection of a fax CNG tone, if the CNGDetectorMode parameter is set to 1. <p>Notes:</p> <ul style="list-style-type: none"> ▪ This feature is applicable only if the IsFaxUsed parameter is set to [1] or [3]. ▪ The device also sends T.38 re-INVITE if the CNGDetectorMode parameter is set to [2], regardless of the FaxCNGMode parameter settings.
Web/EMS: CNG Detector Mode [CNGDetectorMode]	Determines whether the device detects the fax calling tone (CNG). <ul style="list-style-type: none"> ▪ [0] Disable = (Default) The originating device doesn't detect CNG; the CNG signal passes transparently to the remote side. ▪ [1] Relay = CNG is detected on the originating side. CNG packets are sent to the remote side according to T.38 (if IsFaxUsed = 1) and the fax session is started. A SIP Re-INVITE message isn't sent and the fax session starts by the terminating device. This option is useful, for example, when the originating device is located behind a firewall that blocks incoming T.38 packets on ports that have not yet received T.38 packets from the internal network (i.e., originating device). To also send a Re-INVITE message upon detection of a fax CNG tone in this mode, set the parameter FaxCNGMode to 1. ▪ [2] Events Only = CNG is detected on the originating side and a fax session is started by the originating side using the Re-INVITE message. Usually, T.38 fax session starts when the 'preamble' signal is detected by the answering side. Some SIP devices don't support the detection of this fax signal on the answering side and thus, in these cases it is possible to configure the device to start the T.38 fax session when the CNG tone is detected by the originating side. However, this mode is not recommended. <p>Note: This parameter can also be configured in an IP Profile.</p>

Parameter	Description
Web: Fax Relay Enhanced Redundancy Depth EMS: Enhanced Relay Redundancy Depth [FaxRelayEnhancedRedundancyDepth]	Defines the number of times that control packets are retransmitted when using the T.38 standard. The valid range is 0 to 4. The default is 2.
Web: Fax Relay Redundancy Depth EMS: Relay Redundancy Depth [FaxRelayRedundancyDepth]	Defines the number of times that each fax relay payload is retransmitted to the network. <ul style="list-style-type: none"> ▪ [0] = (Default) No redundancy ▪ [1] = One packet redundancy ▪ [2] = Two packet redundancy Note: This parameter is applicable only to non-V.21 packets.
Web: Fax Relay Max Rate (bps) EMS: Relay Max Rate [FaxRelayMaxRate]	Defines the maximum rate (in bps) at which fax relay messages are transmitted (outgoing calls). <ul style="list-style-type: none"> ▪ [0] 2400 = 2.4 kbps ▪ [1] 4800 = 4.8 kbps ▪ [2] 7200 = 7.2 kbps ▪ [3] 9600 = 9.6 kbps ▪ [4] 12000 = 12.0 kbps ▪ [5] 14400 = 14.4 kbps (default) Note: The rate is negotiated between both sides (i.e., the device adapts to the capabilities of the remote side). Negotiation of the T.38 maximum supported fax data rate is provided in SIP's SDP T38MaxBitRate parameter. The negotiated T38MaxBitRate is the minimum rate supported between the local and remote endpoints.
Web: Fax Relay ECM Enable EMS: Relay ECM Enable [FaxRelayECMEnable]	Enables Error Correction Mode (ECM) mode during fax relay. <ul style="list-style-type: none"> ▪ [0] Disable ▪ [1] Enable (default)
Web: Fax/Modem Bypass Coder Type EMS: Coder Type [FaxModemBypassCoderType]	Determines the coder used by the device when performing fax/modem bypass. Typically, high-bit-rate coders such as G.711 should be used. <ul style="list-style-type: none"> ▪ [0] G.711A-law = (Default) G.711 A-law 64 ▪ [1] G.711Mu-law = G.711 μ-law
Web: Fax/Modem Bypass Packing Factor EMS: Packetization Period [FaxModemBypassM]	Defines the number (20 msec) of coder payloads used to generate a fax/modem bypass packet. The valid range is 1, 2, or 3 coder payloads. The default is 1 coder payload.
[FaxModemNTEMode]	Determines whether the device sends RFC 2833 ANS/ANSam events upon detection of fax and/or modem Answer tones (i.e., CED tone). <ul style="list-style-type: none"> ▪ [0] = Disabled (default) ▪ [1] = Enabled Note: This parameter is applicable only when the fax or modem transport type is set to bypass or Transparent-with-Events.
Web/EMS: Fax Bypass Payload Type [FaxBypassPayloadType]	Defines the fax bypass RTP dynamic payload type. The valid range is 96 to 120. The default is 102.

Parameter	Description
EMS: Modem Bypass Payload Type [ModemBypassPayloadType]	Defines the modem bypass dynamic payload type. The range is 0-127. The default is 103.
EMS: Relay Volume (dBm) [FaxModemRelayVolume]	Defines the fax gain control. The range is -18 to -3, corresponding to -18 dBm to -3 dBm in 1-dB steps. The default is -6 dBm fax gain control.
Web/EMS: Fax Bypass Output Gain [FaxBypassOutputGain]	Defines the fax bypass output gain control. The range is -31 to +31 dB, in 1-dB steps. The default is 0 (i.e., no gain).
Web/EMS: Modem Bypass Output Gain [ModemBypassOutputGain]	Defines the modem bypass output gain control. The range is -31 dB to +31 dB, in 1-dB steps. The default is 0 (i.e., no gain).
EMS: Basic Packet Interval [FaxModemBypassBasicRTPPacketInterval]	Defines the basic frame size used during fax/modem bypass sessions. <ul style="list-style-type: none"> ▪ [0] = (Default) Determined internally ▪ [1] = 5 msec (not recommended) ▪ [2] = 10 msec ▪ [3] = 20 msec <p>Note: When set to 5 msec (1), the maximum number of simultaneous channels supported is 120.</p>
EMS: Dynamic Jitter Buffer Minimal Delay (dB) [FaxModemBypassDJBufMinDelay]	Defines the Jitter Buffer delay (in milliseconds) during fax and modem bypass session. The range is 0 to 150 msec. The default is 40.
EMS: Enable Inband Network Detection [EnableFaxModemInbandNetworkDetection]	Enables in-band network detection related to fax/modem. <ul style="list-style-type: none"> ▪ [0] = (Default) Disable. ▪ [1] = Enable. When this parameter is enabled on Bypass and transparent with events mode (VxxTransportType is set to 2 or 3), a detection of an Answer Tone from the network triggers a switch to bypass mode in addition to the local Fax/Modem tone detections. However, only a high bit-rate coder voice session effectively detects the Answer Tone sent by a remote endpoint. This can be useful when, for example, the payload of voice and bypass is the same, allowing the originator to switch to bypass mode as well.
EMS: NSE Mode [NSEMode]	Enables Cisco compatible fax and modem bypass mode. <ul style="list-style-type: none"> ▪ [0] = (Default) NSE disabled ▪ [1] = NSE enabled <p>In NSE bypass mode, the device starts using G.711 A-Law (default) or G.711μ-Law according to the FaxModemBypassCoderType parameter. The payload type used with these G.711 coders is a standard one (8 for G.711 A-Law and 0 for G.711 μ-Law). The parameters defining payload type for the 'old' Bypass mode FaxBypassPayloadType and ModemBypassPayloadType are not used with NSE Bypass. The bypass packet interval is selected according to the FaxModemBypassBasicRtpPacketInterval parameter.</p> <p>Notes:</p>

Parameter	Description
	<ul style="list-style-type: none"> ▪ This feature can be used only if the VxxModemTransportType parameter is set to 2 (Bypass). ▪ If NSE mode is enabled, the SDP contains the following line: 'a=rtpmap:100 X-NSE/8000'. ▪ To use this feature: <ul style="list-style-type: none"> ✓ The Cisco gateway must include the following definition: 'modem passthrough nse payload-type 100 codec g711alaw'. ✓ Set the Modem transport type to Bypass mode (VxxModemTransportType is set to 2) for all modems. ✓ Configure the gateway parameter NSEPayloadType = 100. ▪ This parameter can also be configured in an IP Profile.
EMS: NSE Payload Type [NSEPayloadType]	Defines the NSE payload type for Cisco Bypass compatible mode. The valid range is 96-127. The default is 105. Note: Cisco gateways usually use NSE payload type of 100.
EMS: T38 Use RTP Port [T38UseRTPPort]	Defines the port (with relation to RTP port) for sending and receiving T.38 packets. <ul style="list-style-type: none"> ▪ [0] = (Default) Use the RTP port +2 to send/receive T.38 packets. ▪ [1] = Use the same port as the RTP port to send/receive T.38 packets. Notes: <ul style="list-style-type: none"> ▪ For this parameter to take effect, you must reset the device. ▪ When the device is configured to use V.152 to negotiate audio and T.38 coders, the UDP port published in SDP for RTP and for T38 must be different. Therefore, set the T38UseRTPPort parameter to 0.
Web/EMS: T.38 Max Datagram Size [T38MaxDatagramSize]	Defines the maximum size of a T.38 datagram that the device can receive. This value is included in the outgoing SDP when T.38 is used. The valid range is 120 to 600. The default is 238.
Web/EMS: T38 Fax Max Buffer [T38FaxMaxBufferSize]	Defines the maximum size (in bytes) of the device's T.38 buffer. This value is included in the outgoing SDP when T.38 is used for fax relay over IP. The valid range is 500 to 3000. The default is 1024.
Web: Detect Fax on Answer Tone EMS: Enables Detection of FAX on Answer Tone [DetFaxOnAnswerTone]	Determines when the device initiates a T.38 session for fax transmission. <ul style="list-style-type: none"> ▪ [0] Initiate T.38 on Preamble = (Default) The device to which the called fax is connected initiates a T.38 session on receiving HDLC Preamble signal from the fax. ▪ [1] Initiate T.38 on CED = The device to which the called fax is connected initiates a T.38 session on receiving a CED answer tone from the fax. This option can only be used to relay fax signals, as the device sends T.38 Re-INVITE on detection of any fax/modem Answer tone (2100 Hz, amplitude modulated 2100 Hz, or 2100 Hz with phase reversals). The modem signal fails when using T.38 for fax relay. Note: This parameters is applicable only if the parameter IsFaxUsed is set to 1 (T.38 Relay) or 3 (Fax Fallback).
Web: T38 Fax Session	Enables fax transmission of T.38 "no-signal" packets to the

Parameter	Description
Immediate Start [T38FaxSessionImmediateStart]	<p>terminating fax machine.</p> <ul style="list-style-type: none"> ▪ [0] Disable (default) ▪ [1] Immediate Start on Fax = Device activates T.38 fax relay upon receipt of a re-INVITE with T.38 only in the SDP. ▪ [2] Immediate Start on Fax & Voice = Device activates T.38 fax relay upon receipt of a re-INVITE with T.38 and audio media in the SDP. <p>This parameter is used for transmission from fax machines connected to the device and located inside a NAT. Generally, the firewall blocks T.38 (and other) packets received from the WAN, unless the device behind NAT sends at least one IP packet from the LAN to the WAN through the firewall. If the firewall blocks T.38 packets sent from the termination IP fax, the fax fails.</p> <p>To overcome this, the device sends No-Op (“no-signal”) packets to open a pinhole in the NAT for the answering fax machine. The originating fax does not wait for an answer, but immediately starts sending T.38 packets to the terminating fax machine.</p> <p>Note: To enable No-Op packet transmission, use the NoOpEnable and NoOpInterval parameters.</p>

52.11.2 DTMF and Hook-Flash Parameters

The DTMF and hook-flash parameters are described in the table below.

DTMF and Hook-Flash Parameters

Parameter	Description
Hook-Flash Parameters	
Web/EMS: Hook-Flash Code [HookFlashCode]	<p>For analog interfaces: Defines the digit pattern that when received from the Tel side, indicates a Hook Flash event. For digital interfaces: Defines the digit pattern used by the PBX to indicate a Hook Flash event. When this pattern is detected from the Tel side, the device responds as if a Hook Flash event has occurred and sends a SIP INFO message if the HookFlashOption parameter is set to 1, 5, 6, or 7 (indicating a Hook Flash). If configured and a Hook Flash indication is received from the IP side, the device generates this pattern to the Tel side.</p> <p>The valid range is a 25-character string. The default is a null string.</p> <p>Note: This parameter can also be configured in a Tel Profile.</p>
Web/EMS: Hook-Flash Option [HookFlashOption]	<p>Determines the hook-flash transport type (i.e., method by which hook-flash is sent and received). For digital interfaces (E1/T1): This feature is applicable only if the HookFlashCode parameter is configured.</p> <ul style="list-style-type: none"> ▪ [0] Not Supported = (Default) Hook-Flash indication is not sent. ▪ [1] INFO = Sends proprietary INFO message (Broadsoft) with Hook-Flash indication. The device sends the INFO message as follows: <p>Content-Type: application/broadsoft; version=1.0 Content-Length: 17 event flashhook</p>

Parameter	Description
	<ul style="list-style-type: none"> ▪ [4] RFC 2833 = This option is currently not supported. ▪ [5] INFO (Lucent) = Sends proprietary SIP INFO message with Hook-Flash indication. The device sends the INFO message as follows: Content-Type: application/hook-flash Content-Length: 11 signal=hf ▪ [6] INFO (NetCentrex) = Sends proprietary SIP INFO message with Hook-Flash indication. The device sends the INFO message as follows: Content-Type: application/dtmf-relay Signal=16 Where 16 is the DTMF code for hook flash. ▪ [7] INFO (HUAWAEI) = Sends a SIP INFO message with Hook-Flash indication. The device sends the INFO message as follows: Content-Length: 17 Content-Type: application/sscc event=flashhook <p>Notes:</p> <ul style="list-style-type: none"> ▪ The device can interwork DTMF HookFlashCode to SIP INFO messages with Hook Flash indication (for digital interfaces). ▪ FXO interfaces support only the receipt of RFC 2833 Hook-Flash signals and INFO [1] type. ▪ FXS interfaces send Hook-Flash signals only if the EnableHold parameter is set to 0.
Web: Min. Flash-Hook Detection Period [msec] EMS: Min Flash Hook Time [MinFlashHookTime]	Defines the minimum time (in msec) for detection of a hook-flash event. Detection is guaranteed for hook-flash periods of at least 60 msec (when setting the minimum time to 25). Hook-flash signals that last a shorter period of time are ignored. The valid range is 25 to 300. The default is 300. <p>Notes:</p> <ul style="list-style-type: none"> ▪ For this parameter to take effect, a device reset is required. ▪ This parameter is applicable only to FXS interfaces. ▪ It's recommended to reduce the detection time by 50 msec from the desired value. For example, if you want to set the value to 200 msec, then enter 150 msec (i.e., 200 minus 50).
Web: Max. Flash-Hook Detection Period [msec] EMS: Flash Hook Period [FlashHookPeriod]	Defines the hook-flash period (in msec) for both Tel and IP sides (per device). For the IP side, it defines the hook-flash period that is reported to the IP. For the analog side, it defines the following: <ul style="list-style-type: none"> ▪ FXS interfaces: <ul style="list-style-type: none"> ✓ Maximum hook-flash detection period. A longer signal is considered an off-hook or on-hook event. ✓ Hook-flash generation period upon detection of a SIP INFO message containing a hook-flash signal. ▪ FXO interfaces: Hook-flash generation period. The valid range is 25 to 3,000. The default is 700. <p>Notes:</p> <ul style="list-style-type: none"> ▪ For this parameter to take effect, you need to reset the device. ▪ For FXO interfaces, a constant of 100 msec must be added to the

Parameter	Description
	<p>required hook-flash period. For example, to generate a 450 msec hook-flash, set this parameter to 550.</p> <ul style="list-style-type: none"> This parameter can also be configured in a Tel Profile.
DTMF Parameters	
EMS: Use End of DTMF [MGCPDTMFDetectionPoint]	<p>Determines when the detection of DTMF events is notified.</p> <ul style="list-style-type: none"> [0] = DTMF event is reported at the end of a detected DTMF digit. [1] = (Default) DTMF event is reported at the start of a detected DTMF digit.
Web: Declare RFC 2833 in SDP EMS: Rx DTMF Option [RxDTMFOption]	<p>Defines the supported receive DTMF negotiation method.</p> <ul style="list-style-type: none"> [0] No = Don't declare RFC 2833 telephony-event parameter in SDP. [3] Yes = (Default) Declare RFC 2833 telephony-event parameter in SDP. <p>The device is always receptive to RFC 2833 DTMF relay packets. Therefore, it is always correct to include the 'telephony-event' parameter as default in the SDP. However, some devices use the absence of the 'telephony-event' in the SDP to decide to send DTMF digits in-band using G.711 coder. If this is the case, you can set this parameter to 0.</p> <p>Note: This parameter can also be configured in an IP Profile.</p>
Tx DTMF Option Table	
Web/EMS: Tx DTMF Option [TxDTMFOption]	<p>This table parameter configures up to two preferred transmit DTMF negotiation methods. The format of this parameter is as follows: [TxDTMFOption] FORMAT TxDTMFOption_Index = TxDTMFOption_Type; [TxDTMFOption]</p> <p>Where Type is:</p> <ul style="list-style-type: none"> [0] Not Supported = (Default) No negotiation - DTMF digits are sent according to the parameters DTMFTransportType and RFC2833PayloadType. [1] INFO (Nortel) = Sends DTMF digits according to IETF Internet-Draft draft-choudhuri-sip-info-digit-00. [2] NOTIFY = Sends DTMF digits according to IETF Internet-Draft draft-mahy-sipping-signaled-digits-01. [3] INFO (Cisco) = Sends DTMF digits according to Cisco format. [4] RFC 2833. [5] INFO (Korea) = Sends DTMF digits according to Korea Telecom format. <p>For example: TxDTMFOption 0 = 1; TxDTMFOption 1 = 3;</p> <p>Notes:</p> <ul style="list-style-type: none"> DTMF negotiation methods are prioritized according to the order of their appearance. When out-of-band DTMF transfer is used ([1], [2], [3], or [5]), the parameter DTMFTransportType is automatically set to 0 (DTMF digits are erased from the RTP stream). When RFC 2833 (4) is selected, the device: <ul style="list-style-type: none"> a. Negotiates RFC 2833 payload type using local and remote

Parameter	Description
	<p>SDPs.</p> <ul style="list-style-type: none"> b. Sends DTMF packets using RFC 2833 payload type according to the payload type in the received SDP. c. Expects to receive RFC 2833 packets with the same payload type as configured by the parameter RFC2833PayloadType. d. Removes DTMF digits in transparent mode (as part of the voice stream). <ul style="list-style-type: none"> ▪ When TxDTMFOption is set to 0, the RFC 2833 payload type is set according to the parameter RFC2833PayloadType for both transmit and receive. ▪ If an ISDN phone user presses digits (e.g., for interactive voice response / IVR applications such as retrieving voice mail messages), ISDN Information messages received by the device for each digit are sent in the voice channel to the IP network as DTMF signals, according to the settings of the TxDTMFOption parameter. ▪ The table ini file parameter TxDTMFOption can be repeated twice for configuring the DTMF transmit methods. ▪ This parameter can also be configured in an IP Profile.
[DisableAutoDTMFMute]	<p>Enables the automatic muting of DTMF digits when out-of-band DTMF transmission is used.</p> <ul style="list-style-type: none"> ▪ [0] = (Default) Automatic mute is used. ▪ [1] = No automatic mute of in-band DTMF. <p>When this parameter is set to 1, the DTMF transport type is set according to the parameter DTMFTransportType and the DTMF digits aren't muted if out-of-band DTMF mode is selected (TxDTMFOption set to 1, 2 or 3). This enables the sending of DTMF digits in-band (transparent of RFC 2833) in addition to out-of-band DTMF messages.</p> <p>Note: Usually this mode is not recommended.</p>
Web/EMS: Enable Digit Delivery to IP [EnableDigitDelivery2IP]	<p>Enables the Digit Delivery feature whereby DTMF digits are sent to the destination IP address after the Tel-to-IP call is answered.</p> <ul style="list-style-type: none"> ▪ [0] Disable (default). ▪ [1] Enable = Enable digit delivery to IP. <p>To enable this feature, modify the called number to include at least one 'p' character. The device uses the digits before the 'p' character in the initial INVITE message. After the call is answered, the device waits for the required time (number of 'p' multiplied by 1.5 seconds), and then sends the rest of the DTMF digits using the method chosen (in-band or out-of-band).</p> <p>Notes:</p> <ul style="list-style-type: none"> ▪ For this parameter to take effect, a device reset is required. ▪ The called number can include several 'p' characters (1.5 seconds pause), for example, 1001pp699, 8888p9p300.
Web: Enable Digit Delivery to Tel EMS: Enable Digit Delivery [EnableDigitDelivery]	<p>Enables the Digit Delivery feature, which sends DTMF digits of the called number to the device's port (analog)/B-channel (digital) (phone line) after the call is answered (i.e., line is off-hooked for FXS, or seized for FXO) for IP-to-Tel calls.</p> <ul style="list-style-type: none"> ▪ [0] Disable (default). ▪ [1] Enable = Enable Digit Delivery feature for the FXO/FXS device. <p>For digital interfaces: If the called number in IP-to-Tel call includes the characters 'w' or 'p', the device places a call with the first part of the called number (before 'w' or 'p') and plays DTMF digits after the call is</p>

Parameter	Description
	<p>answered. If the character 'w' is used, the device waits for detection of a dial tone before it starts playing DTMF digits. For example, if the called number is '1007766p100', the device places a call with 1007766 as the destination number, then after the call is answered it waits 1.5 seconds ('p') and plays the rest of the number (100) as DTMF digits.</p> <p>Additional examples: 1664wpp102, 66644ppp503, and 7774w100pp200.</p> <p>Notes:</p> <ul style="list-style-type: none"> ▪ For this parameter to take effect, a device reset is required. ▪ For analog interfaces: The called number can include characters 'p' (1.5 seconds pause) and 'd' (detection of dial tone). If character 'd' is used, it must be the first 'digit' in the called number. The character 'p' can be used several times. For example (for FXS/FXO interfaces), the called number can be as follows: d1005, dpp699, p9p300. To add the 'd' and 'p' digits, use the usual number manipulation rules. ▪ For analog interfaces: To use this feature with FXO interfaces, configure the device to operate in one-stage dialing mode. ▪ If this parameter is enabled, it is possible to configure the FXS/FXO interface to wait for dial tone per destination phone number (before or during dialing of destination phone number). Therefore, the parameter <code>IsWaitForDialTone</code> (configurable for the entire device) is ignored. ▪ For analog interfaces: The FXS interface send SIP 200 OK responses only after the DTMF dialing is complete. ▪ This parameter can also be configured in a Tel Profile.
<p>[ReplaceNumberSignWithEscapeChar]</p>	<p>Determines whether to replace the number sign (#) with the escape character (%23) in outgoing SIP messages for Tel-to-IP calls.</p> <ul style="list-style-type: none"> ▪ [0] Disable (default). ▪ [1] Enable = All number signs #, received in the dialed DTMF digits are replaced in the outgoing SIP Request-URI and To headers with the escape sign %23. <p>Notes:</p> <ul style="list-style-type: none"> ▪ This parameter is applicable only if the parameter <code>IsSpecialDigits</code> is set 1. ▪ This parameter is applicable only to analog interfaces.
<p>Web: Special Digit Representation EMS: Use Digit For Special DTMF [UseDigitForSpecialDTMF]</p>	<p>Defines the representation for 'special' digits ('*' and '#') that are used for out-of-band DTMF signaling (using SIP INFO/NOTIFY).</p> <ul style="list-style-type: none"> ▪ [0] Special = (Default) Uses the strings '*' and '#'. ▪ [1] Numeric = Uses the numerical values 10 and 11.

52.11.3 Digit Collection and Dial Plan Parameters

The digit collection and dial plan parameters are described in the table below.

Digit Collection and Dial Plan Parameters

Parameter	Description
Web/EMS: Dial Plan Index [DialPlanIndex]	<p>Defines the Dial Plan index to use in the external Dial Plan file. The Dial Plan file is loaded to the device as a .dat file (converted using the DConvert utility). The Dial Plan index can be defined globally or per Tel Profile.</p> <p>The valid value range is 0 to 7, where 0 denotes PLAN1, 1 denotes PLAN2, and so on. The default is -1, indicating that no Dial Plan file is used.</p> <p>Notes:</p> <ul style="list-style-type: none"> ▪ If this parameter is configured to select a Dial Plan index, the settings of the parameter DigitMapping are ignored. ▪ If this parameter is configured to select a Dial Plan index from an external Dial Plan file, the device first attempts to locate a matching digit pattern in the Dial Plan file, and if not found, then attempts to locate a matching digit pattern in the Digit Map rules configured by the DigitMapping parameter. ▪ This parameter is applicable also to ISDN with overlap dialing. ▪ For E1 CAS MFC-R2 variants (which don't support terminating digit for the called party number, usually I-15), this parameter and the DigitMapping parameter are ignored. Instead, you can define a Dial Plan template per trunk using the parameter CasTrunkDialPlanName_x (or in the Trunk Settings page). ▪ This parameter can also be configured in a Tel Profile. ▪ For more information on the Dial Plan file, see 'Dialing Plans for Digit Collection' on page 508.
[Tel2IPSourceNumberMappingDialPlanIndex]	<p>Defines the Dial Plan index in the external Dial Plan file for the Tel-to-IP Source Number Mapping feature.</p> <p>The valid value range is 0 to 7, defining the Dial Plan index [Plan x] in the Dial Plan file. The default is -1 (disabled).</p> <p>For more information on this feature, see 'Modifying ISDN-to-IP Calling Party Number' on page 512.</p>
Web: Digit Mapping Rules EMS: Digit Map Patterns [DigitMapping]	<p>Defines the digit map pattern (used to reduce the dialing period when ISDN overlap dialing for digital interfaces). If the digit string (i.e., dialed number) matches one of the patterns in the digit map, the device stops collecting digits and establishes a call with the collected number.</p> <p>The digit map pattern can contain up to 52 options (rules), each separated by a vertical bar (). The maximum length of the entire digit pattern is 152 characters. The available notations include the following:</p> <ul style="list-style-type: none"> ▪ [n-m]: Range of numbers (not letters). ▪ . (single dot): Repeat digits until next notation (e.g., T). ▪ x: Any single digit. ▪ T: Dial timeout (configured by the TimeBetweenDigits parameter). ▪ S: Short timer (configured by the TimeBetweenDigits parameter; default is two seconds) that can be used when a

Parameter	Description
	<p>specific rule is defined after a more general rule. For example, if the digit map is 99 998, then the digit collection is terminated after the first two 9 digits are received. Therefore, the second rule of 998 can never be matched. But when the digit map is 99s 998, then after dialing the first two 9 digits, the device waits another two seconds within which the caller can enter the digit 8.</p> <p>An example of a digit map is shown below: 11xS 00T [1-7]xxx 8xxxxxxx #xxxxxxx *xx 91xxxxxxxxx 9011x.T In the example above, the last rule can apply to International numbers: 9 for dialing tone, 011 Country Code, and then any number of digits for the local number ('x').</p> <p>Notes:</p> <ul style="list-style-type: none"> ▪ For ISDN interfaces, the digit map mechanism is applicable only when ISDN overlap dialing is used (ISDNRxOverlap is set to 1). ▪ If the DialPlanIndex parameter is configured (to select a Dial Plan index), then the device first attempts to locate a matching digit pattern in the Dial Plan file, and if not found, then attempts to locate a matching digit pattern in the Digit Map rules configured by the DigitMapping parameter. ▪ For more information on digit mapping, see 'Digit Mapping' on page 344.
Web: Max Digits in Phone Num EMS: Max Digits in Phone Number [MaxDigits]	<p>Defines the maximum number of collected destination number digits that can be received (i.e., dialed) from the Tel side (analog) when Tel-to-IP ISDN overlap dialing is performed (digital). When the number of collected digits reaches this maximum, the device uses these digits for the called destination number.</p> <p>The valid range is 1 to 49. The default is 5 for analog and 30 for digital.</p> <p>Notes:</p> <ul style="list-style-type: none"> ▪ Instead of using this parameter, Digit Mapping rules can be configured. ▪ Dialing ends when any of the following scenarios occur: <ul style="list-style-type: none"> ✓ Maximum number of digits is dialed ✓ Interdigit Timeout (TimeBetweenDigits) expires ✓ Pound (#) key is pressed ✓ Digit map pattern is matched
Web: Inter Digit Timeout for Overlap Dialing [sec] EMS: Interdigit Timeout (Sec) [TimeBetweenDigits]	<p>For analog interfaces: Defines the time (in seconds) that the device waits between digits that are dialed by the user.</p> <p>For ISDN overlap dialing: Defines the time (in seconds) that the device waits between digits that are received from the PSTN or IP during overlap dialing.</p> <p>When this inter-digit timeout expires, the device uses the collected digits to dial the called destination number.</p> <p>The valid range is 1 to 10. The default is 4.</p>
Web: Enable Special Digits EMS: Use '#' For Dial Termination [IsSpecialDigits]	<p>Determines whether the asterisk (*) and pound (#) digits can be used in DTMF.</p> <ul style="list-style-type: none"> ▪ [0] Disable = Use '*' or '#' to terminate number collection (refer to the parameter UseDigitForSpecialDTMF). (Default.) ▪ [1] Enable = Allows '*' and '#' for telephone numbers dialed by a

Parameter	Description
	user or for the endpoint telephone number. Note: These symbols can always be used as the first digit of a dialed number even if you disable this parameter.

52.11.4 Voice Mail Parameters

The voice mail parameters are described in the table below. For more information on the Voice Mail application, refer to the *CPE Configuration Guide for Voice Mail*.

Voice Mail Parameters

Parameter	Description																		
Web/EMS: Voice Mail Interface [VoiceMailInterface]	Enables the device's Voice Mail application and determines the communication method used between the PBX and the device. <ul style="list-style-type: none"> ▪ [0] None (default) ▪ [1] DTMF ▪ [2] SMDI ▪ [3] QSIG ▪ [4] SETUP Only = Applicable only to ISDN. ▪ [5] MATRA/AASTRA QSIG ▪ [6] QSIG SIEMENS = QSIG MWI activate and deactivate messages include Siemens Manufacturer Specific Information (MSI) ▪ [7] IP2IP = The device's IP-to-IP application is used for interworking between an IP Voice Mail server and the device. This is implemented for sending unsolicited SIP NOTIFY messages received from the Voice Mail server to an IP Group (configured using the NotificationIPGroupID parameter). ▪ [8] ETSI = Euro ISDN, according to ETS 300 745-1 V1.2.4, section 9.5.1.1. Enables MWI interworking from IP to Tel, typically used for BRI phones. <p>Note: To disable voice mail per Trunk Group, you can use a Tel Profile with the EnableVoiceMailDelay parameter set to disabled (0). This eliminates the phenomenon of call delay on Trunks not implementing voice mail when voice mail is enabled using this global parameter.</p>																		
Web: Enable VoiceMail URI EMS: Enable VMURI [EnableVMURI]	Enables the interworking of target and cause for redirection from Tel to IP and vice versa, according to RFC 4468. <ul style="list-style-type: none"> ▪ [0] Disable (default) ▪ [1] Enable Upon receipt of an ISDN Setup message with Redirect values, the device maps the Redirect phone number to the SIP 'target' parameter and the Redirect number reason to the SIP 'cause' parameter in the Request-URI. <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="padding: 2px;">Redirecting Reason</td> <td style="padding: 2px;">>></td> <td style="padding: 2px;">SIP Response Code</td> </tr> <tr> <td style="padding: 2px;">Unknown</td> <td style="padding: 2px;">>></td> <td style="padding: 2px;">404</td> </tr> <tr> <td style="padding: 2px;">User busy</td> <td style="padding: 2px;">>></td> <td style="padding: 2px;">486</td> </tr> <tr> <td style="padding: 2px;">No reply</td> <td style="padding: 2px;">>></td> <td style="padding: 2px;">408</td> </tr> <tr> <td style="padding: 2px;">Deflection</td> <td style="padding: 2px;">>></td> <td style="padding: 2px;">487/480</td> </tr> <tr> <td style="padding: 2px;">Unconditional</td> <td style="padding: 2px;">>></td> <td style="padding: 2px;">302</td> </tr> </table>	Redirecting Reason	>>	SIP Response Code	Unknown	>>	404	User busy	>>	486	No reply	>>	408	Deflection	>>	487/480	Unconditional	>>	302
Redirecting Reason	>>	SIP Response Code																	
Unknown	>>	404																	
User busy	>>	486																	
No reply	>>	408																	
Deflection	>>	487/480																	
Unconditional	>>	302																	

Parameter	Description
	<p>Others >> 302</p> <p>If the device receives a Request-URI that includes a 'target' and 'cause' parameter, the 'target' is mapped to the Redirect phone number and the 'cause' is mapped to the Redirect number reason.</p>
[WaitForBusyTime]	<p>Defines the time (in msec) that the device waits to detect busy and/or reorder tones. This feature is used for semi-supervised PBX call transfers (i.e., the LineTransferMode parameter is set to 2).</p> <p>The valid value range is 0 to 20000 (i.e., 20 sec). The default is 2000 (i.e., 2 sec).</p>
<p>Web/EMS: Line Transfer Mode</p> <p>[LineTransferMode]</p>	<p>Defines the call transfer method used by the device. This parameter is applicable to FXO call transfer as well as E1/T1 CAS call transfer if the TrunkTransferMode_x parameter is set to 3 (CAS Normal) or 1 (CAS NFA).</p> <ul style="list-style-type: none"> ▪ [0] None = (Default) IP. ▪ [1] Blind = PBX blind transfer: <ul style="list-style-type: none"> ✓ Analog (FXO): After receiving a SIP REFER message from the IP side, the device (FXO) sends a hook-flash to the PBX, dials the digits (that are received in the Refer-To header), and then immediately releases the line (i.e., on-hook). The PBX performs the transfer internally. ✓ E1/T1 CAS: When a SIP REFER message is received, the device performs a blind transfer, by performing a CAS wink, waiting a user-defined time (configured by the WaitForDialTime parameter), dialing the Refer-To number, and then releasing the call. The PBX performs the transfer internally. ▪ [2] Semi Supervised = PBX semi-supervised transfer: <ul style="list-style-type: none"> ✓ Analog (FXO): After receiving a SIP REFER message from the IP side, the device sends a hook-flash to the PBX, and then dials the digits (that are received in the Refer-To header). If no busy or reorder tones are detected (within the user-defined interval set by the WaitForBusyTime parameter), the device completes the call transfer by releasing the line. If these tones are detected, the transfer is cancelled, the device sends a SIP NOTIFY message with a failure reason in the NOTIFY body (such as 486 if busy tone detected), and generates an additional hook-flash toward the FXO line to restore connection to the original call. ✓ E1/T1 CAS: The device performs a CAS wink, waits a user-defined time (configured by the WaitForDialTime parameter), and then dials the Refer-To number. If during the user-defined interval set by the WaitForBusyTime parameter, no busy or reorder tones are detected, the device completes the call transfer by releasing the line. If during this interval, the device detects these tones, the transfer operation is cancelled, the device sends a SIP NOTIFY message with a failure reason (e.g., 486 if a busy tone is detected), and then generates an additional wink toward the CAS line to restore connection with the original call. ▪ [3] Supervised = PBX Supervised transfer: <ul style="list-style-type: none"> ✓ Analog (FXO): After receiving a SIP REFER message from the IP side, the device sends a hook-flash to the PBX, and then dials the digits (that are received in the Refer-To header). The

Parameter	Description
	<p>device waits for connection of the transferred call and then completes the call transfer by releasing the line. If speech is not detected, the transfer is cancelled, the device sends a SIP NOTIFY message with a failure reason in the NOTIFY body (such as 486 if busy tone detected) and generates an additional hook-flash toward the FXO line to restore connection to the original call.</p> <ul style="list-style-type: none"> ✓ E1/T1 CAS: The device performs a supervised transfer to the PBX. The device performs a CAS wink, waits a user-defined time (configured by the WaitForDialTime parameter), and then dials the Refer-To number. The device completes the call transfer by releasing the line only after detection of the transferred party answer. To enable answer supervision, you also need to do the following: <ol style="list-style-type: none"> 1) Enable voice detection (i.e., set the EnableVoiceDetection parameter to 1). 2) Set the EnableDSPIPMDetectors parameter to 1. 3) Install the IPMDetector DSP option Software License Key.
SMDI Parameters	
Web/EMS: Enable SMDI [SMDI]	Enables Simplified Message Desk Interface (SMDI) interface on the device. <ul style="list-style-type: none"> ▪ [0] Disable = (Default) Normal serial ▪ [1] Enable (Bellcore) ▪ [2] Ericsson MD-110 ▪ [3] NEC (ICS) <p>Notes:</p> <ul style="list-style-type: none"> ▪ For this parameter to take effect, a device reset is required. ▪ When the RS-232 connection is used for SMDI messages (Serial SMDI), it cannot be used for other applications, for example, to access the Command Line Interface (CLI).
Web/EMS: SMDI Timeout [SMDITimeout]	Defines the time (in msec) that the device waits for an SMDI Call Status message before or after a Setup message is received. This parameter synchronizes the SMDI and analog CAS interfaces. If the timeout expires and only an SMDI message is received, the SMDI message is dropped. If the timeout expires and only a Setup message is received, the call is established. The valid range is 0 to 10000 (i.e., 10 seconds). The default is 2000.
Message Waiting Indication (MWI) Parameters	
Web: MWI Off Digit Pattern EMS: MWI Off Code [MWIOffCode]	Defines the digit code used by the device to notify the PBX that there are no messages waiting for a specific extension. This code is added as prefix to the dialed number. The valid range is a 25-character string.
Web: MWI On Digit Pattern EMS: MWI On Code [MWIONCode]	Defines the digit code used by the device to notify the PBX of messages waiting for a specific extension. This code is added as prefix to the dialed number. The valid range is a 25-character string.
Web: MWI Suffix Pattern EMS: MWI Suffix Code [MWISuffixCode]	Defines the digit code used by the device as a suffix for 'MWI On Digit Pattern' and 'MWI Off Digit Pattern'. This suffix is added to the generated DTMF string after the extension number. The valid range is a 25-character string.

Parameter	Description
Web: MWI Source Number EMS: MWI Source Name [MWISourceNumber]	Defines the calling party's phone number used in the Q.931 MWI Setup message to PSTN. If not configured, the channel's phone number is used as the calling number.
[MWISubscribeIPGroupID]	<p>Defines the IP Group ID used when subscribing to an MWI server. The 'The SIP Group Name' field value of the IP Group table is used as the Request-URI host name in the outgoing MWI SIP SUBSCRIBE message. The request is sent to the IP address defined for the Proxy Set that is associated with the IP Group. The Proxy Set's capabilities such as proxy redundancy and load balancing are also applied to the message.</p> <p>For example, if the 'SIP Group Name' field of the IP Group is set to "company.com", the device sends the following SUBSCRIBE message:</p> <pre>SUBSCRIBE sip:company.com...</pre> <p>Instead of:</p> <pre>SUBSCRIBE sip:10.33.10.10...</pre> <p>Note: If this parameter is not configured, the MWI SUBSCRIBE message is sent to the MWI server as defined by the MWIServerIP parameter.</p>
[NotificationIPGroupID]	<p>Defines the IP Group ID to which the device sends SIP NOTIFY MWI messages.</p> <p>Notes:</p> <ul style="list-style-type: none"> This is used for MWI Interrogation. For more information on the interworking of QSIG MWI to IP, see Message Waiting Indication on page 357. To determine the handling method of MWI Interrogation messages, use the TrunkGroupSettings_MWIIterrogationType, parameter (in the Trunk Group Settings table).
[MWIQsigMsgCentreID PartyNumber]	<p>Defines the Message Centred ID party number used for QSIG MWI messages. If not configured (default), the parameter is not included in MWI (activate and deactivate) QSIG messages. The valid value is a string.</p>
Digit Patterns The following digit pattern parameters apply only to voice mail applications that use the DTMF communication method. For the available pattern syntaxes, refer to the <i>CPE Configuration Guide for Voice Mail</i> .	
Web: Forward on Busy Digit Pattern (Internal) EMS: Digit Pattern Forward On Busy [DigitPatternForwardOn Busy]	<p>Defines the digit pattern used by the PBX to indicate 'call forward on busy' when the original call is received from an internal extension. The valid range is a 120-character string.</p>
Web: Forward on No Answer Digit Pattern (Internal) EMS: Digit Pattern Forward On No Answer [DigitPatternForwardOn NoAnswer]	<p>Defines the digit pattern used by the PBX to indicate 'call forward on no answer' when the original call is received from an internal extension. The valid range is a 120-character string.</p>

Parameter	Description
Web: Forward on Do Not Disturb Digit Pattern (Internal) EMS: Digit Pattern Forward On DND [DigitPatternForwardOnDND]	Defines the digit pattern used by the PBX to indicate 'call forward on do not disturb' when the original call is received from an internal extension. The valid range is a 120-character string.
Web: Forward on No Reason Digit Pattern (Internal) EMS: Digit Pattern Forward No Reason [DigitPatternForwardNoReason]	Defines the digit pattern used by the PBX to indicate 'call forward with no reason' when the original call is received from an internal extension. The valid range is a 120-character string.
Web: Forward on Busy Digit Pattern (External) EMS: VM Digit Pattern On Busy External [DigitPatternForwardOnBusyExt]	Defines the digit pattern used by the PBX to indicate 'call forward on busy' when the original call is received from an external line (not an internal extension). The valid range is a 120-character string.
Web: Forward on No Answer Digit Pattern (External) EMS: VM Digit Pattern On No Answer Ext [DigitPatternForwardOnNoAnswerExt]	Defines the digit pattern used by the PBX to indicate 'call forward on no answer' when the original call is received from an external line (not an internal extension). The valid range is a 120-character string.
Web: Forward on Do Not Disturb Digit Pattern (External) EMS: VM Digit Pattern On DND External [DigitPatternForwardOnDNDExt]	Defines the digit pattern used by the PBX to indicate 'call forward on do not disturb' when the original call is received from an external line (not an internal extension). The valid range is a 120-character string.
Web: Forward on No Reason Digit Pattern (External) EMS: VM Digit Pattern No Reason External [DigitPatternForwardNoReasonExt]	Defines the digit pattern used by the PBX to indicate 'call forward with no reason' when the original call is received from an external line (not an internal extension). The valid range is a 120-character string.
Web: Internal Call Digit Pattern EMS: Digit Pattern Internal Call [DigitPatternInternalCall]	Defines the digit pattern used by the PBX to indicate an internal call. The valid range is a 120-character string.
Web: External Call Digit Pattern EMS: Digit Pattern External Call [DigitPatternExternalCall]	Defines the digit pattern used by the PBX to indicate an external call. The valid range is a 120-character string.

Parameter	Description
Web: Disconnect Call Digit Pattern EMS: Tel Disconnect Code [TelDisconnectCode]	Defines a digit pattern that when received from the Tel side, indicates the device to disconnect the call. The valid range is a 25-character string.
Web: Digit To Ignore Digit Pattern EMS: Digit To Ignore [DigitPatternDigitToIgnore]	Defines a digit pattern that if received as Src (S) or Redirect (R) numbers is ignored and not added to that number. The valid range is a 25-character string.

52.11.5 Supplementary Services Parameters

This subsection describes the device's supplementary telephony services parameters.

52.11.5.1 Caller ID Parameters

The caller ID parameters are described in the table below.

Caller ID Parameters

Parameter	Description
Caller ID Permissions Table	
Web: Caller ID Permissions Table EMS: SIP Endpoints > Caller ID [EnableCallerID]	This table parameter enables (per port) Caller ID generation (for FXS interfaces) and detection (for FXO interfaces). The format of this parameter is as follows: [EnableCallerID] FORMAT EnableCallerID_Index = EnableCallerID_IsEnabled, EnableCallerID_Module, EnableCallerID_Port; [EnableCallerID] Where, <ul style="list-style-type: none"> Module = Module number, where 1 denotes the module in Slot 1. Port = Port number, where 1 denotes Port 1 of a module. For example: EnableCallerID 0 = 1,3,1; (caller ID enabled on Port 1 of Module 3) EnableCallerID 1 = 0,3,2; (caller ID disabled on Port 2 of Module 3) Notes: <ul style="list-style-type: none"> The indexing of this parameter starts at 0. For a detailed description of this table, see Configuring Caller ID Permissions on page 399.
Caller Display Information Table	
Web: Caller Display Information Table EMS: SIP Endpoints > Caller ID [CallerDisplayInfo]	This table parameter enables the device to send Caller ID information to the IP side when a call is made. The called party can use this information for caller identification. The information configured in this table is sent in the SIP INVITE message's From header. The format of this parameter is as follows: [CallerDisplayInfo] FORMAT CallerDisplayInfo_Index = CallerDisplayInfo_DisplayString,

Parameter	Description
	<p>CallerDisplayInfo_IsCidRestricted, CallerDisplayInfo_Module, CallerDisplayInfo_Port; [CallerDisplayInfo] Where,</p> <ul style="list-style-type: none"> ▪ Module = Module number, where 1 denotes the module in Slot 1. ▪ Port = Port number, where 1 denotes Port 1 of a module. <p>For example: CallerDisplayInfo 0 = Susan C.,0,1,1; ("Susan C." is sent as the Caller ID for Port 1 of Module 1) CallerDisplayInfo 1 = Mark M.,0,1,2; ("Mark M." is sent as Caller ID for Port 2 of Module 1)</p> <p>Notes:</p> <ul style="list-style-type: none"> ▪ The indexing of this table ini file parameter starts at 0. ▪ For a detailed description of this table, see Configuring Caller Display Information on page 396.
Web/EMS: Enable Caller ID [EnableCallerID]	<p>Enables Caller ID.</p> <ul style="list-style-type: none"> ▪ [0] Disable (default) ▪ [1] Enable <p>If the Caller ID service is enabled, then for FXS interfaces, calling number and Display text (from IP) are sent to the device's port. For FXO interfaces, the Caller ID signal is detected and sent to IP in the SIP INVITE message (as 'Display' element). For information on the Caller ID table, see Configuring Caller Display Information on page 396. To disable/enable caller ID generation per port, see Configuring Call Forward on page 397.</p>
Web: Caller ID Type EMS: Caller id Types [CallerIDType]	<p>Determines the standard used for detection (FXO) and generation (FXS) of Caller ID, and detection (FXO) / generation (FXS) of MWI (when specified) signals:</p> <ul style="list-style-type: none"> ▪ [0] Standard Bellcore = (Default) Caller ID and MWI ▪ [1] Standard ETSI = Caller ID and MWI ▪ [2] Standard NTT ▪ [4] Standard BT = Britain ▪ [16] Standard DTMF Based ETSI ▪ [17] Standard Denmark = Caller ID and MWI ▪ [18] Standard India ▪ [19] Standard Brazil <p>Notes:</p> <ul style="list-style-type: none"> ▪ Typically, the Caller ID signals are generated / detected between the first and second rings. However, sometimes the Caller ID is detected before the first ring signal. In such a scenario, set the RingsBeforeCallerID parameter to 0. ▪ Caller ID detection for Britain [4] is not supported on the device's FXO ports. Only FXS ports can generate the Britain [4] Caller ID. ▪ To select the Bellcore Caller ID sub standard, use the BellcoreCallerIDTypeOneSubStandard parameter. To select the ETSI Caller ID substandard, use the ETSICallerIDTypeOneSubStandard parameter. ▪ To select the Bellcore MWI sub standard, use the BellcoreVMWITypeOneStandard parameter. To select the ETSI MWI sub standard, use the ETSIVMWITypeOneStandard

Parameter	Description																											
	<p>parameter.</p> <ul style="list-style-type: none"> If you define Caller ID Type as NTT [2], you need to define the NTT DID signaling form (FSK or DTMF) using the <code>NTTDIDSignallingForm</code> parameter. 																											
<p>Web: Enable FXS Caller ID Category Digit For Brazil Telecom [AddCPCPrefix2BrazilCallerID]</p>	<p>Enables the interworking of Calling Party Category (cpc) code from SIP INVITE messages to FXS Caller ID first digit.</p> <ul style="list-style-type: none"> [0] Disable (default) [1] Enable <p>When this parameter is enabled, the device sends the Caller ID number (calling number) with the cpc code (received in the SIP INVITE message) to the device's FXS port. The cpc code is added as a prefix to the caller ID (after IP-to-Tel calling number manipulation). For example, assuming that the incoming INVITE contains the following From (or P-Asserted-Id) header:</p> <pre>From:<sip:+551137077801;cpc=payphone@10.20.7.35>;tag=53700</pre> <p>The calling number manipulation removes "+55" (leaving 10 digits), and then adds the prefix 7, the cpc code for payphone user. Therefore, the Caller ID number that is sent to the FXS port, in this example is 71137077801.</p> <p>If the incoming INVITE message doesn't contain the 'cpc' parameter, nothing is added to the Caller ID number.</p> <table border="1" data-bbox="539 1032 1375 1532"> <thead> <tr> <th>CPC Value in Received INVITE</th> <th>CPC Code Prefixed to Caller ID (Sent to FXS Endpoint)</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>cpc=unknown</td> <td>1</td> <td>Unknown user</td> </tr> <tr> <td>cpc=subscribe</td> <td>1</td> <td>-</td> </tr> <tr> <td>cpc=ordinary</td> <td>1</td> <td>Ordinary user</td> </tr> <tr> <td>cpc=priority</td> <td>2</td> <td>Pre-paid user</td> </tr> <tr> <td>cpc=test</td> <td>3</td> <td>Test user</td> </tr> <tr> <td>cpc=operator</td> <td>5</td> <td>Operator</td> </tr> <tr> <td>cpc=data</td> <td>6</td> <td>Data call</td> </tr> <tr> <td>cpc=payphone</td> <td>7</td> <td>Payphone user</td> </tr> </tbody> </table> <p>Notes:</p> <ul style="list-style-type: none"> This parameter is applicable only to FXS interfaces. For this parameter to be enabled, you must also set the parameter <code>EnableCallingPartyCategory</code> to 1. 	CPC Value in Received INVITE	CPC Code Prefixed to Caller ID (Sent to FXS Endpoint)	Description	cpc=unknown	1	Unknown user	cpc=subscribe	1	-	cpc=ordinary	1	Ordinary user	cpc=priority	2	Pre-paid user	cpc=test	3	Test user	cpc=operator	5	Operator	cpc=data	6	Data call	cpc=payphone	7	Payphone user
CPC Value in Received INVITE	CPC Code Prefixed to Caller ID (Sent to FXS Endpoint)	Description																										
cpc=unknown	1	Unknown user																										
cpc=subscribe	1	-																										
cpc=ordinary	1	Ordinary user																										
cpc=priority	2	Pre-paid user																										
cpc=test	3	Test user																										
cpc=operator	5	Operator																										
cpc=data	6	Data call																										
cpc=payphone	7	Payphone user																										
<p>[EnableCallerIDTypeTwo]</p>	<p>Disables the generation of Caller ID type 2 when the phone is off-hooked. Caller ID type 2 (also known as off-hook Caller ID) is sent to a currently busy telephone to display the caller ID of the waiting call.</p> <ul style="list-style-type: none"> [0] = Caller ID type 2 isn't played. [1] = (Default) Caller ID type 2 is played. 																											
<p>EMS: Caller ID Timing Mode [AnalogCallerIDTimingM]</p>	<p>Determines when Caller ID is generated.</p> <ul style="list-style-type: none"> [0] = (Default) Caller ID is generated between the first two rings. [1] = The device attempts to find an optimized timing to generate 																											

Parameter	Description
ode]	the Caller ID according to the selected Caller ID type. Notes: <ul style="list-style-type: none"> ▪ This parameter is applicable only to FXS interfaces. ▪ If this parameter is set to 1 and used with distinctive ringing, the Caller ID signal doesn't change the distinctive ringing timing. ▪ For this parameter to take effect, a device reset is required.
EMS: Bellcore Caller ID Type One Sub Standard [BellcoreCallerIDTypeOneSubStandard]	Determines the Bellcore Caller ID sub-standard. <ul style="list-style-type: none"> ▪ [0] = (Default) Between rings. ▪ [1] = Not ring related. Note: For this parameter to take effect, a device reset is required.
EMS: ETSI Caller ID Type One Sub Standard [ETSICallerIDTypeOneSubStandard]	Determines the ETSI FSK Caller ID Type 1 sub-standard (FXS only). <ul style="list-style-type: none"> ▪ [0] = (Default) ETSI between rings. ▪ [1] = ETSI before ring DT_AS. ▪ [2] = ETSI before ring RP_AS. ▪ [3] = ETSI before ring LR_DT_AS. ▪ [4] = ETSI not ring related DT_AS. ▪ [5] = ETSI not ring related RP_AS. ▪ [6] = ETSI not ring related LR_DT_AS. Note: For this parameter to take effect, a device reset is required.
Web: Asserted Identity Mode EMS: Asserted ID Mode [AssertedIdMode]	Determines whether the SIP header P-Asserted-Identity or P-Preferred-Identity is used in the generated SIP INVITE, 200 OK, or UPDATE request for Caller ID (or privacy). These headers are used to present the originating party's Caller ID. The Caller ID is composed of a Calling Number and a Calling Name (optional). <ul style="list-style-type: none"> ▪ [0] Disabled = (Default) P-Asserted-Identity nor P-Preferred-Identity headers are not added. ▪ [1] Add P-Asserted-Identity ▪ [2] Add P-Preferred-Identity The header used also depends on the calling Privacy (allowed or restricted). These headers are used together with the Privacy header. If Caller ID is restricted (i.e., P-Asserted-Identity is not sent), the Privacy header includes the value 'id' ('Privacy: id'). Otherwise, for allowed Caller ID, 'Privacy: none' is used. If Caller ID is restricted (received from PSTN / Tel or configured in the device), the From header is set to <anonymous@anonymous.invalid>. <p>The 200 OK response can contain the connected party CallerID - Connected Number and Connected Name. For example, if the call is answered by the device, the 200 OK response includes the P-Asserted-Identity with Caller ID. The device interworks (in some ISDN variants), the Connected Party number and name from Q.931 Connect message to SIP 200 OK with the P-Asserted-Identity header. In the opposite direction, if the ISDN device receives a 200 OK with P-Asserted-Identity header, it interworks it to the Connected party number and name in the Q.931 Connect message, including its privacy.</p>
Web/EMS: Use Destination As Connected Number [UseDestinationAsConnectedNumber]	Enables the device to include the Called Party Number, from outgoing Tel calls (after number manipulation), in the SIP P-Asserted-Identity header. The device includes the SIP P-Asserted-Identity header in 180 Ringing and 200 OK responses for IP-to-Tel calls. <ul style="list-style-type: none"> ▪ [0] Disable (default)

Parameter	Description
	<ul style="list-style-type: none"> [1] Enable <p>Notes:</p> <ul style="list-style-type: none"> If the received Q.931 Connect message contains a Connected Party Number, this number is used in the P-Asserted-Identity header in 200 OK response. For this feature, you must also enable the device to include the P-Asserted-Identity header in 180/200 OK responses, by setting the parameter AssertedIDMode to Add P-Asserted-Identity. This parameter is applicable to ISDN, CAS, and/or FXO interfaces.
Web: Caller ID Transport Type EMS: Transport Type [CallerIDTransportType]	<p>Determines the device's behavior for Caller ID detection.</p> <ul style="list-style-type: none"> [0] Disable = The caller ID signal is not detected - DTMF digits remain in the voice stream. [1] Relay = (Currently not applicable.) [3] Mute = (Default) The caller ID signal is detected from the Tel/PSTN side and then erased from the voice stream. <p>Note: Caller ID detection is applicable only to FXO interfaces.</p>
Reject Anonymous Calls Per Port Table	
[RejectAnonymousCallPerPort]	<p>This table parameter determines whether the device rejects incoming anonymous calls per FXS port. If enabled, when a device's FXS interface receives an anonymous call, it rejects the call and responds with a SIP 433 (Anonymity Disallowed) response.</p> <p>The format of this parameter is as follows:</p> <p>[RejectAnonymousCallPerPort] FORMAT RejectAnonymousCallPerPort_Index = RejectAnonymousCallPerPort_Enabled, RejectAnonymousCallPerPort_Port, RejectAnonymousCallPerPort_Module; [RejectAnonymousCallPerPort]</p> <p>Where,</p> <ul style="list-style-type: none"> Enable = accept [0] (default) or reject [1] incoming anonymous calls. Port = Port number. Module = Module number. <p>For example: RejectAnonymousCallPerPort 0 = 0,1,1; RejectAnonymousCallPerPort 1 = 1,2,1;</p> <p>Note: This parameter is applicable only to FXS interfaces.</p>

52.11.5.2 Call Waiting Parameters

The call waiting parameters are described in the table below.

Call Waiting Parameters

Parameter	Description
Web/EMS: Enable Call Waiting [EnableCallWaiting]	<p>Enables the Call Waiting feature.</p> <ul style="list-style-type: none"> [0] Disable [1] Enable (Default)

Parameter	Description
	<p>For digital interfaces: If enabled and the device initiates a Tel-to-IP call to a destination that is busy, it plays a call waiting ringback tone to the caller. The tone is played only if the destination returns a 182 "Queued" SIP response.</p> <p>For FXS interface: If enabled, when an FXS interface receives a call on a busy endpoint, it responds with a 182 response (and not with a 486 busy). The device plays a call waiting indication signal. When hook-flash is detected, the device switches to the waiting call. The device that initiated the waiting call plays a call waiting ringback tone to the calling party after a 182 response is received.</p> <p>Notes:</p> <ul style="list-style-type: none"> ▪ The device's Call Progress Tones (CPT) file must include a Call Waiting ringback tone (caller side) and a call waiting tone (called side, FXS only). ▪ FXS interfaces: The EnableHold parameter must be enabled on both the calling and the called side. ▪ Analog interfaces: You can use the table parameter CallWaitingPerPort to enable Call Waiting per port. ▪ Analog interfaces: For information on the Call Waiting feature, see Call Waiting on page 356.
EMS: Send 180 For Call Waiting [Send180ForCallWaiting]	Determines the SIP response code for indicating Call Waiting. <ul style="list-style-type: none"> ▪ [0] = (Default) Use 182 Queued response to indicate call waiting. ▪ [1] = Use 180 Ringing response to indicate call waiting.
Call Waiting Table	
Web: Call Waiting Table EMS: SIP Endpoints > Call Waiting [CallWaitingPerPort]	This table parameter configures call waiting per FXS port. The format of this parameter is as follows: [CallWaitingPerPort] FORMAT CallWaitingPerPort_Index = CallWaitingPerPort_IsEnabled, CallWaitingPerPort_Module, CallWaitingPerPort_Port; [CallWaitingPerPort] For example: CallWaitingPerPort 0 = 0,1,1; (call waiting disabled for Port 1 of Module 1) CallWaitingPerPort 1 = 1,1,2; (call waiting enabled for Port 2 of Module 1) <p>Notes:</p> <ul style="list-style-type: none"> ▪ This parameter is applicable only to FXS ports. ▪ For a detailed description of this table, see Configuring Call Waiting on page 400.
Web: Number of Call Waiting Indications EMS: Call Waiting Number of Indications [NumberOfWaitingIndications]	Defines the number of call waiting indications that are played to the called telephone that is connected to the device for Call Waiting. The valid range is 1 to 100 indications. The default is 2. <p>Note: This parameter is applicable only to FXS ports.</p>
Web: Time Between Call Waiting Indications EMS: Call Waiting Time Between Indications [TimeBetweenWaitingIndications]	Defines the time (in seconds) between consecutive call waiting indications for call waiting. The valid range is 1 to 100. The default is 10. <p>Note: This parameter is applicable only to FXS ports.</p>

Parameter	Description
Web/EMS: Time Before Waiting Indications [TimeBeforeWaitingIndications]	<p>Defines the interval (in seconds) before a call waiting indication is played to the port that is currently in a call.</p> <p>The valid range is 0 to 100. The default time is 0 seconds.</p> <p>Note: This parameter is applicable only to FXS ports.</p>
Web/EMS: Waiting Beep Duration [WaitingBeepDuration]	<p>Defines the duration (in msec) of call waiting indications that are played to the port that is receiving the call.</p> <p>The valid range is 100 to 65535. The default is 300.</p> <p>Note: This parameter is applicable only to FXS ports.</p>
EMS: First Call Waiting Tone ID [FirstCallWaitingToneID]	<p>Defines the index of the first Call Waiting Tone in the CPT file. This feature enables the called party to distinguish between different call origins (e.g., external versus internal calls).</p> <p>There are three ways to use the distinctive call waiting tones:</p> <ul style="list-style-type: none"> ▪ Playing the call waiting tone according to the SIP Alert-Info header in the received 180 Ringing SIP response. The value of the Alert-Info header is added to the value of the FirstCallWaitingToneID parameter. ▪ Playing the call waiting tone according to PriorityIndex in the ToneIndex table parameter. ▪ Playing the call waiting tone according to the parameter "CallWaitingTone#" of a SIP INFO message. <p>The device plays the tone received in the 'play tone CallWaitingTone#' parameter of an INFO message plus the value of this parameter minus 1.</p> <p>The valid range is -1 to 1,000. The default is -1 (i.e., not used).</p> <p>Notes:</p> <ul style="list-style-type: none"> ▪ This parameter is applicable only to analog interfaces. ▪ It is assumed that all Call Waiting Tones are defined in sequence in the CPT file. ▪ SIP Alert-Info header examples: <ul style="list-style-type: none"> ✓ Alert-Info:<Bellcore-dr2> ✓ Alert-Info:<http://.../Bellcore-dr2> (where "dr2" defines call waiting tone #2) ▪ The SIP INFO message is according to Broadsoft's application server definition. Below is an example of such an INFO message: <pre data-bbox="555 1489 1374 1794"> INFO sip:06@192.168.13.2:5060 SIP/2.0 Via:SIP/2.0/UDP 192.168.13.40:5060;branch=z9hG4bK040066422630 From: <sip:4505656002@192.168.13.40:5060>;tag=1455352915 To: <sip:06@192.168.13.2:5060> Call-ID:0010-0008@192.168.13.2 CSeq:342168303 INFO Content-Length:28 Content-Type:application/broadsoft play tone CallWaitingTone1 </pre>

52.11.5.3 Call Forwarding Parameters

The call forwarding parameters are described in the table below.

Call Forwarding Parameters

Parameter	Description
Web: Enable Call Forward [EnableForward]	Enables the Call Forwarding feature. <ul style="list-style-type: none"> ▪ [0] Disable ▪ [1] Enable (Default) For FXS interfaces, the Call Forward table (FwdInfo parameter) must be defined to use the Call Forward service. The device uses SIP REFER messages for call forwarding. Note: To use this service, the devices at both ends must support this option.
Call Forwarding Table	
Web: Call Forwarding Table EMS: Analog Gateway Provisioning > Tab: Call Forward [FwdInfo]	This table parameter configures call forwarding of IP-to-Tel calls (using SIP 302 response) to other device ports or an IP destination, based on the device's port to which the call was originally routed. The format of this parameter is as follows: [FwdInfo] FORMAT FwdInfo_Index = FwdInfo_Type, FwdInfo_Destination, FwdInfo_NoReplyTime, FwdInfo_Module, FwdInfo_Port; [FwdInfo] Where, <ul style="list-style-type: none"> ▪ Module = Module number, where 1 denotes the module in Slot 1. ▪ Port = Port number, where 1 denotes Port 1 of a module. For example: <ul style="list-style-type: none"> ▪ Below configuration forwards calls originally destined to Port 1 of Module 1 to "1001" upon On Busy: FwdInfo 0 = 1,1001,30,1,1; ▪ Below configuration forwards calls originally destined to Port 2 of Module 1 to an IP address upon On Busy: FwdInfo 1 = 1,2003@10.5.1.1,30,1,2; Notes: <ul style="list-style-type: none"> ▪ The indexing of this parameter starts at 0. ▪ For a detailed description of this table, see Configuring Call Forward on page 397.
Call Forward Reminder Ring Parameters	
Notes: <ul style="list-style-type: none"> ▪ These parameters are applicable only to FXS interfaces. ▪ For a description of this feature, see Call Forward Reminder Ring on page 354. 	
Web/EMS: Enable NRT Subscription [EnableNRTSubscription]	Enables endpoint subscription for Ring reminder event notification feature. <ul style="list-style-type: none"> ▪ [0] Disable (default) ▪ [1] Enable
Web: AS Subscribe IPGroupID [ASSubscribeIPGroupID]	Defines the IP Group ID that contains the Application server for Subscription. The valid value range is 1 to 8. The default is -1 (i.e., not configured).

Parameter	Description
Web: NRT Retry Subscription Time EMS: NRT Subscription Retry Time [NRTSubscribeRetryTime]	Defines the Retry period (in seconds) for Dialog subscription if a previous request failed. The valid value range is 10 to 7200. The default is 120.
Web/EMS: Call Forward Ring Tone ID [CallForwardRingToneID]	Defines the ringing tone type played when call forward notification is accepted. The valid value range is 1 to 5. The default is 1.

52.11.5.4 Message Waiting Indication Parameters

The message waiting indication (MWI) parameters are described in the table below.

MWI Parameters

Parameter	Description
Web: Enable MWI EMS: MWI Enable [EnableMWI]	Enables Message Waiting Indication (MWI). <ul style="list-style-type: none"> [0] Disable (default). [1] Enable Notes: <ul style="list-style-type: none"> This parameter is applicable only to FXS interfaces. The device supports only the receipt of SIP MWI NOTIFY messages (the device doesn't generate these messages). For more information on MWI, see 'Message Waiting Indication' on page 357.
Web/EMS: MWI Analog Lamp [MWIAnalogLamp]	Enables the visual display of MWI. <ul style="list-style-type: none"> [0] Disable (default). [1] Enable = Enables visual MWI by supplying line voltage of approximately 100 VDC to activate the phone's lamp. Notes: <ul style="list-style-type: none"> This parameter is applicable only for FXS interfaces. This parameter can also be configured in a Tel Profile.
Web/EMS: MWI Display [MWIDisplay]	Enables sending MWI information to the phone display. <ul style="list-style-type: none"> [0] Disable = (Default) MWI information isn't sent to display. [1] Enable = The device generates an MWI message (determined by the parameter CallerIDType), which is displayed on the MWI display. Note: <ul style="list-style-type: none"> This parameter is applicable only to FXS interfaces. This parameter can also be configured in a Tel Profile.
Web: Subscribe to MWI EMS: Enable MWI Subscription [EnableMWISubscription]	Enables subscription to an MWI server. <ul style="list-style-type: none"> [0] No (default) [1] Yes Notes: <ul style="list-style-type: none"> To configure the MWI server address, use the MWIServerIP parameter. To configure whether the device subscribes per endpoint or per the

Parameter	Description
	entire device, use the parameter SubscriptionMode.
Web: MWI Server IP Address EMS: MWI Server IP [MWIServerIP]	Defines the MWI server's IP address. If provided, the device subscribes to this IP address. The MWI server address can be configured as a numerical IP address or as a domain name. If not configured, the Proxy IP address is used instead.
Web/EMS: MWI Server Transport Type [MWIServerTransportType]	<p>Determines the transport layer used for outgoing SIP dialogs initiated by the device to the MWI server.</p> <ul style="list-style-type: none"> ▪ [-1] Not Configured (default) ▪ [0] UDP ▪ [1] TCP ▪ [2] TLS <p>Note: When set to 'Not Configured', the value of the parameter SIPTransportType is used.</p>
Web: MWI Subscribe Expiration Time EMS: MWI Expiration Time [MWIExpirationTime]	<p>Defines the MWI subscription expiration time in seconds.</p> <p>The default is 7200 seconds. The range is 10 to 2,000,000.</p>
Web: MWI Subscribe Retry Time EMS: Subscribe Retry Time [SubscribeRetryTime]	<p>Defines the subscription retry time (in seconds) after last subscription failure.</p> <p>The default is 120 seconds. The range is 10 to 2,000,000.</p>
Web: Subscription Mode [SubscriptionMode]	<p>Determines the method the device uses to subscribe to an MWI server.</p> <ul style="list-style-type: none"> ▪ [0] Per Endpoint = (Default) Each endpoint subscribes separately - typically used for FXS interfaces. ▪ [1] Per Gateway = Single subscription for the entire device - typically used for FXO interfaces.
EMS: ETSI VMWI Type One Standard [ETSIVMWITypeOneStandard]	<p>Determines the ETSI Visual Message Waiting Indication (VMWI) Type 1 sub-standard.</p> <ul style="list-style-type: none"> ▪ [0] = (Default) ETSI VMWI between rings ▪ [1] = ETSI VMWI before ring DT_AS ▪ [2] = ETSI VMWI before ring RP_AS ▪ [3] = ETSI VMWI before ring LR_DT_AS ▪ [4] = ETSI VMWI not ring related DT_AS ▪ [5] = ETSI VMWI not ring related RP_AS ▪ [6] = ETSI VMWI not ring related LR_DT_AS <p>Note: For this parameter to take effect, a device reset is required.</p>
EMS: Bellcore VMWI Type One Standard [BellcoreVMWITypeOneStandard]	<p>Determines the Bellcore VMWI sub-standard.</p> <ul style="list-style-type: none"> ▪ [0] = (Default) Between rings. ▪ [1] = Not ring related. <p>Note: For this parameter to take effect, a device reset is required.</p>

52.11.5.5 Call Hold Parameters

The call hold parameters are described in the table below.

Call Hold Parameters

Parameter	Description
Web/EMS: Enable Hold [EnableHold]	<p>For digital interfaces: Enables interworking of the Hold/Retrieve supplementary service from PRI to SIP.</p> <p>For analog interfaces: Enables the Call Hold feature that allows users, connected to the device, to place a call on hold (or remove from hold). This is done using the phone's Hook Flash button. On receiving a hold request, the remote party is placed on hold and hears the hold tone.</p> <ul style="list-style-type: none"> ▪ [0] Disable ▪ [1] Enable (default) <p>Notes:</p> <ul style="list-style-type: none"> ▪ For digital interfaces: To support interworking of the Hold/Retrieve supplementary service from SIP to ISDN (for QSIG and Euro ISDN), set the parameter EnableHold2ISDN to 1. ▪ For analog interfaces: To use this service, the devices at both ends must support this option. ▪ This parameter can also be configured in an IP Profile.
Web/EMS: Hold Format [HoldFormat]	<p>Determines the format of the SDP in the Re-INVITE hold request.</p> <ul style="list-style-type: none"> ▪ [0] 0.0.0.0 = (Default) The SDP "c=" field contains the IP address "0.0.0.0" and the "a=inactive" attribute. ▪ [1] Send Only = The SDP "c=" field contains the device's IP address and the "a=sendonly" attribute. ▪ [2] x.y.z.t = The SDP "c=" field contains the device's IP address and the "a=inactive" attribute. <p>Notes:</p> <ul style="list-style-type: none"> ▪ The device does not send any RTP packets when it is in hold state. ▪ For digital interfaces: This parameter is applicable only to QSIG and Euro ISDN protocols.
Web/EMS:Held Timeout [HeldTimeout]	<p>Defines the time interval that the device allows for a call to remain on hold. If a Resume (un-hold Re-INVITE) message is received before the timer expires, the call is renewed. If this timer expires, the call is released (terminated).</p> <ul style="list-style-type: none"> ▪ [-1] = (Default) The call is placed on hold indefinitely until the initiator of the on hold retrieves the call again. ▪ [0 - 2400] = Time to wait (in seconds) after which the call is released.
Web: Call Hold Reminder Ring Timeout EMS: CHRR Timeout [CHRRTIMEOUT]	<p>Defines the duration (in seconds) that the Call Hold Reminder Ring is played. If a user hangs up while a call is still on hold or there is a call waiting, then the FXS interface immediately rings the extension for the duration specified by this parameter. If the user off-hooks the phone, the call becomes active.</p> <p>The valid range is 0 to 600. The default is 30.</p> <p>Notes:</p> <ul style="list-style-type: none"> ▪ This parameter is applicable only to FXS interfaces. ▪ This Reminder Ring feature can be disabled using the DisableReminderRing parameter.
	Disables the reminder ring, which notifies the FXS user of a call on hold

Parameter	Description
[DisableReminderRing]	<p>or a waiting call when the phone is returned to on-hook position.</p> <ul style="list-style-type: none"> [0] = (Default) The reminder ring feature is active. In other words, if a call is on hold or there is a call waiting and the phone is changed from offhook to onhook, the phone rings (for a duration defined by the CHRRTimeout parameter) to "remind" you of the call hold or call waiting. [1] = Disables the reminder ring. If a call is on hold or there is a call waiting and the phone is changed from offhook to onhook, the call is released (and the device sends a SIP BYE to the IP). <p>Notes:</p> <ul style="list-style-type: none"> This parameter is applicable only to FXS interfaces. This parameter is typically used for MLPP, allowing preemption to clear held calls.
[PlayDTMFduringHold]	<p>Determines whether the device sends DTMF signals (or DTMF SIP INFO message) when a call is on hold.</p> <ul style="list-style-type: none"> [0] = (Default) Disable. [1] = Enable - If the call is on hold, the device stops playing the Held tone (if it is played) and sends DTMF: <ul style="list-style-type: none"> ✓ To Tel side: plays DTMF digits according to the received SIP INFO message(s). (The stopped held tone is not played again.) ✓ To IP side: sends DTMF SIP INFO messages to an IP destination if it detects DTMF digits from the Tel side.

52.11.5.6 Call Transfer Parameters

The call transfer parameters are described in the table below.

Call Transfer Parameters

Parameter	Description
Web/EMS: Enable Transfer [EnableTransfer]	<p>Enables the Call Transfer feature.</p> <ul style="list-style-type: none"> [0] Disable [1] Enable = (Default) The device responds to a REFER message with the Referred-To header to initiate a call transfer. For analog interfaces: If the transfer service is enabled, the user can activate Transfer using hook-flash signaling. If this service is enabled, the remote party performs the call transfer. <p>Notes:</p> <ul style="list-style-type: none"> To use call transfer, the devices at both ends must support this option. To use call transfer, set the parameter EnableHold to 1.
Web: Transfer Prefix EMS: Logical Prefix For Transferred Call [xferPrefix]	<p>Defines the string that is added as a prefix to the transferred/forwarded called number when the REFER/3xx message is received.</p> <p>Notes:</p> <ul style="list-style-type: none"> The number manipulation rules apply to the user part of the Refer-To and/or Contact URI before it is sent in the INVITE message. This parameter can be used to apply different manipulation rules to differentiate transferred/forwarded (only for analog interfaces) number from the originally dialed number.
Web: Transfer Prefix IP 2	<p>Defines the prefix that is added to the destination number received in the</p>

Parameter	Description
Tel [XferPrefixIP2Tel]	<p>SIP Refer-To header (for IP-to-Tel calls). This parameter is applicable to FXO/CAS blind transfer modes, i.e., LineTransferMode = 1, 2 or 3, and TrunkTransferMode = 1 or 3 (for CAS).</p> <p>The valid range is a string of up to 9 characters. The default is an empty string.</p> <p>Note: This parameter is also applicable to ISDN Blind Transfer, according to AT&T Toll Free Transfer Connect Service (TR 50075) "Courtesy Transfer-Human-No Data". To support this transfer mode, you need to configure the parameter XferPrefixIP2Tel to "*" and the parameter TrunkTransferMode to 5.</p>
Web/EMS: Enable Semi-Attended Transfer [EnableSemiAttendedTransfer]	<p>Determines the device behavior when Transfer is initiated while in Alerting state.</p> <ul style="list-style-type: none"> ▪ [0] Disable = (Default) Send REFER with the Replaces header. ▪ [1] Enable = Send CANCEL, and after a 487 response is received, send REFER without the Replaces header.
Web: Blind EMS: Blind Transfer [KeyBlindTransfer]	<p>Defines the keypad sequence to activate blind transfer for established Tel-to-IP calls. The Tel user can perform blind transfer by dialing the KeyBlindTransfer digits, followed by a transferee destination number.</p> <p>After the KeyBlindTransfer DTMF digits sequence is dialed, the current call is put on hold (using a Re-INVITE message), a dial tone is played to the channel, and then the phone number collection starts.</p> <p>After the destination phone number is collected, it is sent to the transferee in a SIP REFER request in a Refer-To header. The call is then terminated and a confirmation tone is played to the channel. If the phone number collection fails due to a mismatch, a reorder tone is played to the channel.</p> <p>Note: For FXS/FXO interfaces, it is possible to configure whether the KeyBlindTransfer code is added as a prefix to the dialed destination number, by using the parameter KeyBlindTransferAddPrefix.</p>
EMS: Blind Transfer Add Prefix [KeyBlindTransferAddPrefix]	<p>Determines whether the device adds the Blind Transfer code (defined by the KeyBlindTransfer parameter) to the dialed destination number.</p> <ul style="list-style-type: none"> ▪ [0] Disable (default) ▪ [1] Enable <p>Note: This parameter is applicable only to FXO and FXS interfaces.</p>
EMS: Blind Transfer Disconnect Timeout [BlindTransferDisconnectTimeout]	<p>Defines the duration (in milliseconds) for which the device waits for a disconnection from the Tel side after the Blind Transfer Code (KeyBlindTransfer) has been identified. When this timer expires, a SIP REFER message is sent toward the IP side. If this parameter is set to 0, the REFER message is immediately sent.</p> <p>The valid value range is 0 to 1,000,000. The default is 0.</p>
Web: QSIG Path Replacement Mode [QSIGPathReplacementMode]	<p>Enables QSIG transfer for IP-to-Tel and Tel-to-IP calls.</p> <ul style="list-style-type: none"> ▪ [0] IP2QSIGTransfer = (Default) Enables IP-to-QSIG transfer. ▪ [1] QSIG2IPTransfer = Enables QSIG-to-IP transfer.

Parameter	Description
[ReplaceTel2IPCallingNumTimeout]	<p>Defines the maximum duration (timeout) to wait between call Setup and Facility with Redirecting Number for replacing the calling number (for Tel-to-IP calls).</p> <p>The valid value range is 0 to 10,000 msec. The default is 0.</p> <p>The interworking of the received Setup message to a SIP INVITE is suspended when this parameter is set to any value greater than 0. This means that the redirecting number in the Setup message is not checked. When a subsequent Facility with Call Transfer Complete/Update is received with a non-empty Redirection Number, the Calling Number is replaced with the received redirect number in the sent INVITE message. If the timeout expires, the device sends the INVITE without changing the calling number.</p> <p>Notes:</p> <ul style="list-style-type: none"> ▪ The suspension of the INVITE message occurs for all calls. ▪ This parameter is applicable to QSIG.
Web: Call Transfer using re-INVITES [EnableCallTransferUsingReinvites]	<p>Enables call transfer using re-INVITES.</p> <ul style="list-style-type: none"> ▪ [0] Disable = (Default) Call transfer is done using REFER messages. ▪ [1] Enable = Call transfer is done by sending re-INVITE messages (instead of REFER). <p>Notes:</p> <ul style="list-style-type: none"> ▪ The device uses two DSP channels per transferred call. Thus, to use this feature, you also need to configure the maximum number of available DSP channels, using the MediaChannels parameter. ▪ This parameter is applicable only to FXS interfaces.
Web: IP2IP Transfer Mode [IP2IPTransfermode]	<p>Determines the interworking of incoming mid-call SIP REFER messages to outgoing REFER messages, for calls pertaining to the IP-to-IP application.</p> <ul style="list-style-type: none"> ▪ [0] Disable = (Default) Upon receipt of a REFER message, the device sends an INVITE to the refer-to destination with or without the Replaces header. ▪ [1] Enable = Upon receipt of a REFER message, the device forwards the REFER message and all relevant SIP messages from and to the transferor, to the target destination during call transfer. For consultation call transfer, the REFER message contains a 'replaces' parameter in the Refer-To header. In this case, the outgoing REFER also contains a 'replaces' parameter in the Refer-To header. <p>Note: This parameter is applicable to blind and consultation call transfers.</p>

52.11.5.7 Three-Way Conferencing Parameters

The three-way conferencing parameters are described in the table below.

Three-Way Conferencing Parameters

Parameter	Description
Web: Enable 3-Way Conference EMS: Enable 3 Way [Enable3WayConference]	<p>Enables the 3-Way Conference feature.</p> <ul style="list-style-type: none"> ▪ [0] Disable (default) ▪ [1] Enable <p>Note: For this parameter to take effect, a device reset is required.</p>

Parameter	Description
Web: Three Way Conference Mode EMS: 3 Way Mode [3WayConferenceMode]	<p>Determines the mode of operation when the 3-Way Conference feature is used.</p> <ul style="list-style-type: none"> ▪ [0] AudioCodes Media Server = (Default) The Conference-initiating INVITE (sent by the device) uses the ConferenceID concatenated with a unique identifier as the Request-URI. This same Request-URI is set as the Refer-To header value in the REFER messages that are sent to the two remote parties. This conference mode is used when operating with AudioCodes IPMedia conferencing server. ▪ [1] Non-AudioCodes Media Server = The Conference-initiating INVITE (sent by the device) uses only the ConferenceID as the Request-URI. The conference server sets the Contact header of the 200 OK response to the actual unique identifier (Conference URI) to be used by the participants. This Conference URI is then included (by the device) in the Refer-To header value in the REFER messages sent by the device to the remote parties. The remote parties join the conference by sending INVITE messages to the conference using this conference URI. ▪ [2] On Board = On-board, three-way conference. The conference is established on the device without the need of an external Conference server. You can limit the number of simultaneous, on-board 3-way conference calls, by using the MaxInBoardConferenceCalls parameter. The device sets up the conference call using its IP media channels. These channels are obtained from the IP media module (i.e., MPM module). Note that the device must be housed with MPM module(s) to support three-way conferencing. The device supports up to five simultaneous, on-board three-way conference calls. <p>Notes:</p> <ul style="list-style-type: none"> ▪ This parameter is applicable only to FXS and BRI interfaces. ▪ Three-way conferencing using an external conference server is supported only by FXS interfaces. ▪ The on-board 3-way conference mode is not supported by Mediant 600. ▪ When using an external conference server (options [0] or [1]), a conference call with up to six participants can be established.
Web: Max 3 Way Conference EMS: Max In Board Calls [MaxInBoardConferenceCalls]	<p>Defines the maximum number of simultaneous, on-board three-way conference calls.</p> <p>The valid range is 0 to 5. The default is 2.</p> <p>Notes:</p> <ul style="list-style-type: none"> ▪ For enabling on-board, three-way conferencing, use the 3WayConferenceMode parameter. ▪ This parameter is applicable only to FXS and BRI interfaces.
Web: Establish Conference Code EMS: Establish Code [ConferenceCode]	<p>Defines the DTMF digit pattern, which upon detection generates the conference call when three-way conferencing is enabled (Enable3WayConference is set to 1).</p> <p>The valid range is a 25-character string. The default is "!" (Hook-Flash).</p> <p>Note: If the FlashKeysSequenceStyle parameter is set to 1 or 2, the setting of the ConferenceCode parameter is overridden.</p>

Parameter	Description
Web/EMS: Conference ID [ConferenceID]	Defines the Conference Identification string. The valid value is a string of up to 16 characters. The default is "conf". For 3-way conferencing using an external media server: The device uses this identifier in the conference-initiating INVITE that is sent to the media server when the Enable3WayConference parameter is set to 1. When using the Mediant 1000 Media Processing Module (MPM): To join a conference, the INVITE URI must include this Conference ID string preceded by the number of the participants in the conference and terminated by a unique number. For example: INVITE sip:4conf1234@10.1.10.10. INVITE messages with the same URI join the same conference.
Web: Use Different RTP port After Hold CLI: use-different-rtp-port-after-hold [UseDifferentRTPportAfterHold]	Enables the use of different RTP ports for the two calls involved in a three-way conference call made by the FXS endpoint in the initial outgoing INVITE requests. <ul style="list-style-type: none"> ▪ [0] Disable = First and second calls use the same RTP port in the initial outgoing INVITE request. If a three-way conference is then made, the device sends a re-INVITE to the held call to retrieve it and to change the RTP port to a different port number. For example: The first call is made on port 6000 and placed on hold. The second call is made, also on port 6000. The device sends a re-INVITE to the held call to retrieve it and changes the port to 6010. ▪ [1] Enable = First and second calls use different RTP ports in the initial outgoing INVITE request. If a three-way conference is then made, the device sends a re-INVITE to the held call to retrieve it, without changing the port of the held call. Notes: <ul style="list-style-type: none"> ▪ When this feature is enabled and only one RTP port is available, only one call can be made by the FXS endpoint, as there is no free RTP port for a second call. ▪ When this feature is enabled and you are using the Call Forking feature, every forked call is sent with a different RTP port. As the device can fork a call to up to 10 destinations, the device requires at least 10 free RTP ports. ▪ This parameter is applicable only to FXS interfaces.

52.11.5.8 MLPP and Emergency Call Parameters

The Multilevel Precedence and Preemption (MLPP) and emergency E911 call parameters are described in the table below.

MLPP and Emergency E911 Call Parameters

Parameter	Description
Web/EMS: Call Priority Mode [CallPriorityMode]	Enables priority call handling for all calls. <ul style="list-style-type: none"> ▪ [0] Disable (default). ▪ [1] MLPP = MLPP Priority Call handling is enabled. MLPP prioritizes call handling whereby the relative importance of various kinds of communications is strictly defined, allowing higher precedence communication at the expense of lower precedence communications. Higher priority calls override less priority calls

Parameter	Description
	<p>when, for example, congestion occurs in a network.</p> <ul style="list-style-type: none"> ▪ [2] Emergency = Preemption of IP-to-Tel E911 emergency calls. If the device receives an E911 call and there are unavailable channels to receive the call, the device terminates one of the channel calls and sends the E911 call to that channel. The preemption is done only on a channel pertaining to the same Trunk Group for which the E911 call was initially destined and if the channel select mode (configured by the ChannelSelectMode parameter) is set to other than "By Dest Number" (0). The preemption is done only if the incoming IP-to-Tel call is identified as an emergency call. The device identifies emergency calls by one of the following: <ul style="list-style-type: none"> ✓ The destination number of the IP call matches one of the numbers defined by the EmergencyNumbers parameter. (For E911, you must define this parameter with the value "911".) ✓ The incoming SIP INVITE message contains the "emergency" value in the Priority header. <p>Notes:</p> <ul style="list-style-type: none"> ▪ This parameter is applicable to FXS/FXO, CAS, and ISDN. ▪ For FXO interfaces, the preemption is done only on existing IP-to-Tel calls. In other words, if all the current FXO channels are busy with calls that were initiated by the FXO (i.e., Tel-to-IP calls), new incoming emergency IP-to-Tel calls are dropped. ▪ MLPP and Emergency services can also be configured in a Tel Profile. ▪ For more information, see 'Pre-empting Existing Call for E911 IP-to-Tel Call' on page 369.
Emergency E911 Parameters	
[E911Gateway]	<p>Enables Enhanced 9-1-1(E9-1-1) support for ELIN handling in Microsoft Lync Server 2010 environment.</p> <ul style="list-style-type: none"> ▪ [0] = Disable (default) ▪ [1] = Enable ▪ [2] = Location-based manipulations
[E911CallbackTimeout]	<p>Defines the maximum interval within which the PSAP can use the ELIN to call back the E9-1-1 caller. This interval starts from when the initial call established with the PSAP is terminated.</p> <p>The valid range is 1 to 60 (minutes). The default is 30.</p>
Web: Emergency Special Release Cause [EmergencySpecialReleaseCause]	<p>Enables the device to send a SIP 503 "Service Unavailable" response if an emergency call cannot be established (i.e., rejected). This can occur, for example, due to the PSTN (for example, the destination is busy or not found) or ELIN Gateway (for example, lack of resources or an internal error).</p> <ul style="list-style-type: none"> ▪ [0] = Disable (default) ▪ [1] = Enable
EMS: Enable 911 PSAP [Enable911PSAP]	<p>Enables the support for the E911 DID protocol, according to the Bellcore GR-350-CORE standard. This protocol defines signaling between E911 Tandem Switches and the PSAP, using analog loop-start lines. The FXO device can be installed instead of an E911 switch, connected directly to PSAP DID loop-start lines.</p> <ul style="list-style-type: none"> ▪ [0] = Disable (default) ▪ [1] = Enable

Parameter	Description
	<p>Notes:</p> <ul style="list-style-type: none"> ▪ This parameter is applicable only to FXO interfaces. ▪ This parameter can also be configured in a Tel Profile.
Web/EMS: Emergency Numbers [EmergencyNumbers]	<p>Defines a list of “emergency” numbers.</p> <p>For FXS: When one of these numbers is dialed, the outgoing INVITE message includes the SIP Priority and Resource-Priority headers. If the user places the phone on-hook, the call is not disconnected. Instead, a Hold Re-INVITE request is sent to the remote party. Only if the remote party disconnects the call (i.e., a BYE is received) or a timer expires (set by the EmergencyRegretTimeout parameter) is the call terminated.</p> <p>For FXO, CAS, and ISDN: These emergency numbers are used for the preemption of E911 IP-to-Tel calls when there are unavailable or busy channels. In this scenario, the device terminates one of the busy channels and sends the emergency call to this channel. This feature is enabled by setting the CallPriorityMode parameter to 2 (“Emergency”). For a description of this feature, see 'Pre-empting Existing Call for E911 IP-to-Tel Call' on page 369.</p> <p>The list can include up to four different numbers, where each number can be up to four digits long.</p> <p>Example: EmergencyNumbers = ‘100’,’911’,’112’</p>
Web: Emergency Calls Regret Timeout EMS: Emergency Regret Timeout [EmergencyRegretTimeout]	<p>Defines the time (in minutes) that the device waits before tearing-down an emergency call (defined by the parameter EmergencyNumbers). Until this time expires, an emergency call can only be disconnected by the remote party, typically, by a Public Safety Answering Point (PSAP). The valid range is 1 to 30. The default is 10.</p> <p>Note: This parameter is applicable only to FXS interfaces.</p>
Multilevel Precedence and Preemption (MLPP) Parameters	
Web: MLPP Default Namespace EMS: Default Name Space [MLPPDefaultNamespace]	<p>Determines the namespace used for MLPP calls received from the ISDN side without a Precedence IE and destined for an Application server. This value is used in the Resource-Priority header of the outgoing SIP INVITE request.</p> <ul style="list-style-type: none"> ▪ [1] DSN (default) ▪ [2] DOD ▪ [3] DRSN ▪ [5] UC ▪ [7] CUC <p>Note: If the ISDN message contains a Precedence IE, the device automatically interworks the "network identity" digits in the IE to the network domain subfield in the Resource-Priority header. For more information, see Multilevel Precedence and Preemption on page 381.</p>
[ResourcePriorityNetworkDomains]	<p>Defines up to 32 user-defined MLPP network domain names (namespaces). This value is used in the AS-SIP Resource-Priority header of the outgoing SIP INVITE request. This parameter is used in combination with the MLPPDefaultNamespace parameter, where you need to enter the table row index as its value.</p> <p>This parameter is also used for mapping the Resource-Priority field value of the SIP Resource-Priority header to the ISDN PRI Precedence Level IE. The mapping is configured by the field, EnableIp2TelInterworking:</p> <ul style="list-style-type: none"> ▪ Disabled: The network-domain field in the Resource-Priority header

Parameter	Description
	<p>is set to "0 1 0 0" (i.e., "routine") in the Precedence Level field.</p> <ul style="list-style-type: none"> Enabled: The network-domain field in the Resource-Priority header is set in the Precedence Level field according to Table 5.3.2.12-4 (Mapping of RPH r-priority Field to PRI Precedence Level Value). <p>The domain name can be a string of up to 10 characters.</p> <p>The format of this table ini file parameter is as follows: FORMAT ResourcePriorityNetworkDomains_Index = ResourcePriorityNetworkDomains_Name, ResourcePriorityNetworkDomains_EnableIp2TelInterworking; ResourcePriorityNetworkDomains 1 = dsn, 0; ResourcePriorityNetworkDomains 2 = dod, 0; ResourcePriorityNetworkDomains 3 = drsn, 0; ResourcePriorityNetworkDomains 5 = uc, 1; ResourcePriorityNetworkDomains 7 = cuc, 0; [\ResourcePriorityNetworkDomains]</p> <p>Notes:</p> <ul style="list-style-type: none"> Indices 1, 2, 3, 5, and 7 cannot be modified and are defined for DSN, DOD, DRSN, UC, and CUC, respectively. If the MLPPDefaultNamespace parameter is set to -1, interworking from PSTN NI digits is done automatically.
Web/EMS: Default Call Priority [SIPDefaultCallPriority]	Determines the default call priority for MLPP calls. <ul style="list-style-type: none"> [0] 0 = (Default) ROUTINE [2] 2 = PRIORITY [4] 4 = IMMEDIATE [6] 6 = FLASH [8] 8 = FLASH-OVERRIDE [9] 9 = FLASH-OVERRIDE-OVERRIDE <p>If the incoming SIP INVITE request doesn't contain a valid priority value in the SIP Resource-Priority header, the default is used in the Precedence IE (after translation to the relevant ISDN Precedence value) of the outgoing PRI Setup message.</p> <p>If the incoming PRI Setup message doesn't contain a valid Precedence Level value, the default is used in the Resource-Priority header of the outgoing SIP INVITE request. In this scenario, the character string is sent without translation to a numerical value.</p>
Web: MLPP DiffServ EMS: Diff Serv [MLPPDiffserv]	Defines the DiffServ value (differentiated services code point/DSCP) used in IP packets containing SIP messages that are related to MLPP calls. This parameter defines DiffServ for incoming and outgoing MLPP calls with the Resource-Priority header. <p>The valid range is 0 to 63. The default is 50.</p>
Web/EMS: Preemption Tone Duration [PreemptionToneDuration]	Defines the duration (in seconds) in which the device plays a preemption tone to the Tel and IP sides if a call is preempted. <p>The valid range is 0 to 60. The default is 3.</p> <p>Note: If set to 0, no preemption tone is played.</p>
Web: MLPP Normalized Service Domain EMS: Normalized Service Domain [MLPPNormalizedServiceDomain]	Defines the MLPP normalized service domain string. If the device receives an MLPP ISDN incoming call, it uses the parameter (if different from 'FFFFFF') as a Service domain in the SIP Resource-Priority header in outgoing INVITE messages. If the parameter is configured to 'FFFFFF', the Resource-Priority header is set to the MLPP Service

Parameter	Description
eDomain]	Domain obtained from the Precedence IE. The valid value is 6 hexadecimal digits. The default is '000000'. Note: This parameter is applicable only to the MLPP NI-2 ISDN variant with CallPriorityMode set to 1.
[MLPPNetworkIdentifier]	Defines the MLPP network identifier (i.e., International prefix or Telephone Country Code/TCC) for IP-to-ISDN calls, according to the UCR 2008 and ITU Q.955 specifications. The valid range is 1 to 999. The default is 1 (i.e., USA). The MLPP network identifier is sent in the Facility IE of the ISDN Setup message. For example: <ul style="list-style-type: none"> ▪ MLPPNetworkIdentifier set to default (i.e., USA, 1): PlaceCall- MLPPNetworkID:0100 MlppServiceDomain:123abc, MlppPrecLevel:5 Fac(1c): 91 a1 15 02 01 05 02 01 19 30 0d 0a 01 05 0a 01 01 04 05 01 00 12 3a bc ▪ MLPPNetworkIdentifier set to 490: PlaceCall- MLPPNetworkID:9004 MlppServiceDomain:123abc, MlppPrecLevel:5 Fac(1c): 91 a1 15 02 01 0a 02 01 19 30 0d 0a 01 05 0a 01 01 04 05 90 04 12 3a bc
Web: MLPP Default Service Domain EMS: Default Service Domain [MLPPDefaultServiceDomain]	Defines the MLPP default service domain string. If the device receives a non-MLPP ISDN incoming call (without a Precedence IE), it uses the parameter (if different than "FFFFFF") as a Service domain in the SIP Resource-Priority header in outgoing (Tel-to-IP calls) INVITE messages. This parameter is used in conjunction with the parameter SIPDefaultCallPriority. If MLPPDefaultServiceDomain is set to 'FFFFFF', the device interworks the non-MLPP ISDN call to non-MLPP SIP call, and the outgoing INVITE does not contain the Resource-Priority header. The valid value is a 6 hexadecimal digits. The default is "000000". Note: This parameter is applicable only to the MLPP NI-2 ISDN variant with CallPriorityMode set to 1.
Web/EMS: Precedence Ringing Type [PrecedenceRingingType]	Defines the index of the Precedence Ringing tone in the Call Progress Tones (CPT) file. This tone is used when the parameter CallPriorityMode is set to 1 and a Precedence call is received from the IP side. The valid range is -1 to 16. The default is -1 (i.e., plays standard ringing tone). Note: This parameter is applicable only to analog interfaces.
EMS: E911 MLPP Behavior [E911MLPPBehavior]	Defines the E911 (or Emergency Telecommunication Services/ETS) MLPP Preemption mode: <ul style="list-style-type: none"> ▪ [0] = (Default) Standard Mode - ETS calls have the highest priority and preempt any MLPP call. ▪ [1] = Treat as routine mode - ETS calls are handled as routine calls. Note: This parameter is applicable only to analog interfaces.
[RPRRequired]	Determines whether the SIP resource-priority tag is added in the SIP Require header of the INVITE message for Tel-to-IP calls. <ul style="list-style-type: none"> ▪ [0] Disable = Excludes the SIP resource-priority tag from the SIP Require header. ▪ [1] Enable = (Default) Adds the SIP resource-priority tag in the SIP

Parameter	Description
	Require header. Note: This parameter is applicable only to MLPP priority call handling (i.e., only when the CallPriorityMode parameter is set to 1).
Multiple Differentiated Services Code Points (DSCP) per MLPP Call Priority Level (Precedence) Parameters The MLPP service allows placement of priority calls, where properly validated users can preempt (terminate) lower-priority phone calls with higher-priority calls. For each MLPP call priority level, the DSCP can be set to a value from 0 to 63. The Resource Priority value in the Resource-Priority SIP header can be one of the following:	
MLPP Precedence Level 0 (lowest) 2 4 6 8 9 (highest)	Precedence Level in Resource-Priority SIP Header routine priority immediate flash flash-override flash-override-override
Web/EMS: RTP DSCP for MLPP Routine [MLPPRoutineRTPDSCP]	Defines the RTP DSCP for MLPP Routine precedence call level. The valid range is -1 to 63. The default is -1. Note: If set to -1, the DiffServ value is taken from the global parameter PremiumServiceClassMediaDiffServ or as defined in IP Profiles per call.
Web/EMS: RTP DSCP for MLPP Priority [MLPPPriorityRTPDSCP]	Defines the RTP DSCP for MLPP Priority precedence call level. The valid range is -1 to 63. The default is -1. Note: If set to -1, the DiffServ value is taken from the global parameter PremiumServiceClassMediaDiffServ or as defined in IP Profiles per call.
Web/EMS: RTP DSCP for MLPP Immediate [MLPPImmediateRTPDSCP]	Defines the RTP DSCP for MLPP Immediate precedence call level. The valid range is -1 to 63. The default is -1. Note: If set to -1, the DiffServ value is taken from the global parameter PremiumServiceClassMediaDiffServ or as defined in IP Profiles per call.
Web/EMS: RTP DSCP for MLPP Flash [MLPPFlashRTPDSCP]	Defines the RTP DSCP for MLPP Flash precedence call level. The valid range is -1 to 63. The default is -1. Note: If set to -1, the DiffServ value is taken from the global parameter PremiumServiceClassMediaDiffServ or as defined in IP Profiles per call.
Web/EMS: RTP DSCP for MLPP Flash Override [MLPPFlashOverRTPDSCP]	Defines the RTP DSCP for MLPP Flash-Override precedence call level. The valid range is -1 to 63. The default is -1. Note: If set to -1, the DiffServ value is taken from the global parameter PremiumServiceClassMediaDiffServ or as defined in IP Profiles per call.
Web/EMS: RTP DSCP for MLPP Flash-Override-Override [MLPPFlashOverOverRTPDSCP]	Defines the RTP DSCP for MLPP Flash-Override-Override precedence call level. The valid range is -1 to 63. The default is -1. Note: If set to -1, the DiffServ value is taken from the global parameter PremiumServiceClassMediaDiffServ or as defined in IP Profiles per call.

52.11.5.9 Call Cut-Through Parameters

The call cut-through parameters are described in the table below.

Call Cut-Through Parameters

Parameter	Description
Web: Enable Calls Cut Through EMS: Cut Through [CutThrough]	<p>Enables FXS endpoints to receive incoming IP calls while the port is in off-hook state.</p> <ul style="list-style-type: none"> ▪ [0] Disable (default) ▪ [1] Enable <p>If enabled, the FXS interface answers the call and 'cuts through' the voice channel if there is no other active call on the port, even if the port is in off-hook state.</p> <p>When the call is terminated (by the remote IP party), the device plays a reorder tone for a user-defined time (configured by the <code>CutThroughTimeForReorderTone</code> parameter) and is then ready to answer the next incoming call without on-hooking the phone.</p> <p>The waiting call is automatically answered by the device when the current call is terminated (configured by setting the parameter <code>EnableCallWaiting</code> to 1).</p> <p>Note: This feature is applicable only to FXS interfaces.</p>
[DigitalCutThrough]	<p>Enables PSTN CAS channels/endpoints to receive incoming IP calls even if the B-channels are in off-hook state.</p> <ul style="list-style-type: none"> ▪ [0] Disabled (default) ▪ [1] Enabled <p>When enabled, this feature operates as follows:</p> <ol style="list-style-type: none"> 1 A Tel-to-IP call is established (connected) by the device for a B-channel. 2 The device receives a SIP BYE (i.e., IP side ends the call) and plays a reorder tone to the PSTN side for the duration set by the <code>CutThroughTimeForReOrderTone</code> parameter. The device releases the call towards the IP side (sends a SIP 200 OK). 3 The PSTN side, for whatever reason, remains off-hook. 4 If a new IP call is received for this B-channel after the reorder tone has ended, the device "cuts through" the channel and connects the call immediately (despite the B-channel being in physical off-hook state) without playing a ring tone. If an IP call is received while the reorder tone is played, the device rejects the call. <p>Notes:</p> <ul style="list-style-type: none"> ▪ If this parameter is disabled and the PSTN side remains in off-hook state after the IP call ends the call, the device releases the call after 60 seconds. ▪ A special CAS table can be used to report call status events (Active/Idle) to the PSTN side during Cut Through mode. ▪ This feature can also be configured in a Tel Profile and therefore, assigned to specific B-channels that use specific CAS tables.

52.11.5.10 Automatic Dialing Parameters

The automatic dialing upon off-hook parameters are described in the table below.

Automatic Dialing Parameters

Parameter	Description
Automatic Dialing Table	
Web: Automatic Dialing Table EMS: Analog Gateway Provisioning > Automatic dialing [TargetOfChannel]	<p>This table parameter defines telephone numbers that are automatically dialed when a specific FXS or FXO port is off-hooked. The format of this parameter is as follows:</p> <p>[TargetOfChannel] FORMAT TargetOfChannel_Index = TargetOfChannel_Destination, TargetOfChannel_Type, TargetOfChannel_Module, TargetOfChannel_Port, TargetOfChannel_HotLineToneDuration; [TargetOfChannel]</p> <p>For example, the below configuration defines automatic dialing of phone number 911 when the phone connected to Port 1 of Module 1 is off-hooked for over 10 seconds: TargetOfChannel 0 = 911, 1, 1, 1, 10;</p> <p>Notes:</p> <ul style="list-style-type: none"> ▪ The first index of this table ini file parameter is 0. ▪ TargetOfChannel_Module is the module number, where 1 denotes the module in Slot 1. ▪ TargetOfChannel_Port is the port number, where 1 denotes Port 1 on the module. ▪ This is parameter is applicable only to FXS and FXO interfaces. ▪ For a detailed description of this table, see 'Configuring Automatic Dialing' on page 394.

52.11.5.11 Direct Inward Dialing Parameters

The Direct Inward Dialing (DID) parameters are described in the table below.

DID Parameters

Parameter	Description
Web/EMS: DID Wink [EnableDIDWink]	<p>Enables Direct Inward Dialing (DID) using Wink-Start signaling, typically used for signaling between an E-911 switch and the PSAP.</p> <ul style="list-style-type: none"> ▪ [0] Disable (default) ▪ [1] Single = The device can be used for connection to EIA/TIA-464B DID Loop Start lines. Both FXO (detection) and FXS (generation) are supported: <ul style="list-style-type: none"> ✓ The FXO interface dials DTMF (or MF) digits upon detection of a Wink signal, instead of a dial tone. ✓ The FXS interface generates a Wink signal upon detection of an off-hook state, instead of playing a dial tone. <p>Example: (Wink) KP I(I) xxx-xxxx ST (Off Hook) Where:</p> <ul style="list-style-type: none"> ✓ I = one or two information digits ✓ x = ANI

Parameter	Description
	<p>Note: The FXO interface generates such MF digits when the Enable911PSAP parameter is set to 1.</p> <ul style="list-style-type: none"> ▪ [2] Double Wink = Double-wink signaling. The FXS interface generates the first Wink upon detection of an off-hook state in the line. The second Wink is generated after a user-defined interval (configured by the TimeBetweenDIDWinks parameter), after which the DTMF/MF digits are collected by the device. Digits that arrive between the first and second Wink are ignored as they contain the same number. Example: (Wink) KP 911 ST (Wink) KP I(I) xxx-xxxx ST (Off Hook) ▪ [3] Wink & Polarity= The FXS interface generates the first Wink after it detects an off-hook state. A polarity change from normal to reversed is generated after a user-defined time (configured by the TimeBetweenDIDWinks parameter). DTMF/MF digits are collected by the device only after this polarity change. Digits that arrive between the first Wink and the polarity change are ignored as they always contain the same number. In this mode, the FXS interface does not generate a polarity change to normal if the Tel-to-IP call is answered by an IP party. Polarity reverts to normal when the call is released. Example: (Wink) KP 911 ST (Polarity) KP I(I) xxx-xxxx ST (Off Hook) <p>Notes:</p> <ul style="list-style-type: none"> ▪ The options [2] and [3] are applicable only to FXS interfaces. ▪ The EnableReversalPolarity and PolarityReversalType parameters must be set to [1] for FXS interfaces. ▪ See also the Enable911PSAP parameter. ▪ This parameter can also be configured in a Tel Profile.
[TimeBetweenDIDWinks]	<p>Defines the interval (in msec) for wink signaling:</p> <ul style="list-style-type: none"> ▪ Double-wink signaling [2]: interval between the first and second wink. ▪ Wink and Polarity signaling [3]: interval between wink and polarity change. <p>The valid range is 100 to 2000. The default is 1000.</p> <p>Note: See the EnableDIDWink parameter for configuring the wink signaling type.</p>
Web/EMS: Delay Before DID Wink [DelayBeforeDIDWink]	<p>Defines the time interval (in msec) between the detection of the off-hook and the generation of the DID Wink.</p> <p>The valid range is 0 to 1,000. The default is 0.</p> <p>Note: This parameter is applicable only to FXS interfaces.</p>
EMS: NTT DID Signalling Form [NTTDIDSignallingForm]	<p>Determines the type of DID signaling support for NTT (Japan) modem: DTMF- or Frequency Shift Keying (FSK)-based signaling. The devices can be connected to Japan's NTT PBX using 'Modem' DID lines. These DID lines are used to deliver a called number to the PBX.</p> <ul style="list-style-type: none"> ▪ [0] = (Default) FSK-based signaling ▪ [1] = DTMF-based signaling <p>Note: This parameter is applicable only to FXS interfaces.</p>
EMS: Enable DID [EnableDID]	<p>This table parameter enables support for Japan NTT 'Modem' DID. FXS interfaces can be connected to Japan's NTT PBX using 'Modem' DID lines. These DID lines are used to deliver a called number to the PBX. The DID signal can be sent alone or combined with an NTT Caller ID signal.</p> <p>The format of this parameter is as follows: [EnableDID] FORMAT EnableDID_Index = EnableDID_IsEnable, EnableDID_Port,</p>

Parameter	Description
	<p>EnableDID_Module; [EnableDID] Where,</p> <ul style="list-style-type: none"> IsEnable = Enables [1] or disables [0] (default) Japan NTT Modem DID support. Port = Port number. Module = Module number. <p>For example: EnableDID 0 = 1,1,2; (DID is enabled on Port 1 of Module 2) Note: This parameter is applicable only to FXS interfaces.</p>
[WinkTime]	<p>Defines the time (in msec) elapsed between two consecutive polarity reversals. This parameter can be used for DID signaling, for example, E911 lines to the Public Safety Answering Point (PSAP), according to the Bellcore GR-350-CORE standard (refer to the ini file parameter Enable911PSAP).</p> <p>The valid range is 0 to 4,294,967,295. The default is 200.</p> <p>Notes:</p> <ul style="list-style-type: none"> This parameter is applicable to FXS and FXO interfaces. For this parameter to take effect, a device reset is required.

52.11.5.12 ISDN BRI Parameters

The automatic dialing upon off-hook parameters are described in the table below.

Automatic Dialing Parameters

Parameter	Description
ISDN Supplementary Services Table	
<p>Web: ISDN Supp Services Table EMS: Digital Gateway Provisioning > ISDN Supplementary Services [ISDNSuppServ]</p>	<p>This table parameter defines BRI phone extension numbers per BRI port and configures various ISDN supplementary services per BRI endpoint. The format of this parameter is as follows:</p> <p>[ISDNSuppServ] FORMAT ISDNSuppServ_Index = ISDNSuppServ_PhoneNumber, ISDNSuppServ_Module, ISDNSuppServ_Port, ISDNSuppServ_UserId, ISDNSuppServ_UserPassword, ISDNSuppServ_CallerID, ISDNSuppServ_IsPresentationRestricted, ISDNSuppServ_IsCallerIDEnabled;</p> <p>[\ISDNSuppServ] For example: ISDNSuppServ 0 = 400, 1, 1, user, pass, callerid, 0, 1; ISDNSuppServ 1 = 401, 1, 1, user, pass, callerid, 0, 1;</p> <p>Note: For a detailed description of this table, see 'Configuring ISDN BRI Supplementary Services' on page 385.</p>
BRI-to-SIP Supplementary Services Codes for Call Forward	
<p>Note: Upon receipt of an ISDN Facility message for call forward from the BRI phone, the device sends a SIP INVITE to the softswitch with a user-defined code in the SIP To header, representing the reason for the call forward. For more information on BRI call forwarding, see 'BRI Call Forwarding' on page 356.</p>	

Parameter	Description
Web/EMS: Call Forward Unconditional [SuppServCodeCFU]	Defines the prefix code for activating Call Forward Unconditional sent to the softswitch. The valid value is a string. The default is an empty string. Note: The string must be enclosed in single apostrophe (e.g., '*72').
Web/EMS: Call Forward Unconditional Deactivation [SuppServCodeCFUDeact]	Defines the prefix code for deactivating Call Forward Unconditional Deactivation sent to the softswitch. The valid value is a string. The default is an empty string. Note: The string must be enclosed in single apostrophe (e.g., '*72').
Web: Call Forward on Busy EMS: Code Call Forward on Busy [SuppServCodeCFB]	Defines the prefix code for activating Call Forward on Busy sent to the softswitch. The valid value is a string. The default is an empty string. Note: The string must be enclosed in single apostrophe (e.g., '*72').
Web: Call Forward on Busy Deactivation EMS: Code Call Forward on Busy Deactivation [SuppServCodeCFBDeact]	Defines the prefix code for deactivating Call Forward on Busy Deactivation sent to the softswitch. The valid value is a string. The default is an empty string. Note: The string must be enclosed in single apostrophe (e.g., '*72').
Web: Call Forward on No Reply EMS: Code Call Forward on No Reply [SuppServCodeCFNR]	Defines the prefix code for activating Call Forward on No Reply sent to the softswitch. The valid value is a string. The default is an empty string. Note: The string must be enclosed in single apostrophe (e.g., '*72').
Call Forward on No Reply Deactivation EMS: Code Call Forward on No Reply Deactivation [SuppServCodeCFNRDeact]	Defines the prefix code for deactivating Call Forward on No Reply Deactivation sent to the softswitch. The valid value is a string. The default is an empty string. Note: The string must be enclosed in single apostrophe (e.g., '*72').

52.11.5.13 TTY/TDD Parameters

The TTY (telephone typewriter) or telecommunications device for the deaf (TDD) is an electronic device for text communication via a telephone line for those with impaired hearing. The TTY/TDD parameters are described in the table below.

TTY Parameters

Parameter	Description
EMS: TTY Transport Type [TTYTransportType]	Defines the device's transferring method of TTY signals during a call. <ul style="list-style-type: none"> ▪ [0] = (Default) Disable. ▪ [2] = Relay (signals sent over the EVRC codec) - TTY phone device transfer using In-Band Relay mode for TTY signal transport. Note: To support TTY Relay (2), you must configure the device to use the EVRC coder.

52.11.6 PSTN Parameters

This subsection describes the device's PSTN parameters.

52.11.6.1 General Parameters

The general PSTN parameters are described in the table below.

General PSTN Parameters

Parameter	Description
Web/EMS: Protocol Type [ProtocolType]	<p>Defines the PSTN protocol for all the Trunks. To configure the protocol type for a specific Trunk, use the <i>ini</i> file parameter ProtocolType_x:</p> <ul style="list-style-type: none"> ▪ [0] NONE ▪ [1] E1 EURO ISDN = ISDN PRI Pan-European (CTR4) protocol ▪ [2] T1 CAS = Common T1 robbed bits protocols including E&M wink start, E&M immediate start, E&M delay dial/start and loop-start and ground start. ▪ [3] T1 RAW CAS ▪ [4] T1 TRANSPARENT = Transparent protocol, where no signaling is provided by the device. Timeslots 1 to 24 of all trunks are mapped to DSP channels. ▪ [5] E1 TRANSPARENT 31 = Transparent protocol, where no signaling is provided by the device. Timeslots 1 to 31 of each trunk are mapped to DSP channels. ▪ [6] E1 TRANSPARENT 30 = Transparent protocol, where no signaling is provided by the device. Timeslots 1 to 31, excluding time slot 16 of all trunks are mapped to DSP channels. ▪ [7] E1 MFCR2 = Common E1 MFC/R2 CAS protocols (including line signaling and compelled register signaling). ▪ [8] E1 CAS = Common E1 CAS protocols (including line signaling and MF/DTMF address transfer). ▪ [9] E1 RAW CAS ▪ [10] T1 NI2 ISDN = National ISDN 2 PRI protocol ▪ [11] T1 4ESS ISDN = ISDN PRI protocol for the Lucent™/AT&T™ 4ESS switch. ▪ [12] T1 5ESS 9 ISDN = ISDN PRI protocol for the Lucent™/AT&T™ 5ESS-9 switch. ▪ [13] T1 5ESS 10 ISDN = ISDN PRI protocol for the Lucent™/AT&T™ 5ESS-10 switch. ▪ [14] T1 DMS100 ISDN = ISDN PRI protocol for the Nortel™ DMS switch. ▪ [15] J1 TRANSPARENT ▪ [16] T1 NTT ISDN = ISDN PRI protocol for the Japan - Nippon Telegraph Telephone (known also as INS 1500). ▪ [17] E1 AUSTEL ISDN = ISDN PRI protocol for the Australian Telecom. ▪ [18] E1 HKT ISDN = ISDN PRI (E1) protocol for the Hong Kong - HKT. ▪ [19] E1 KOR ISDN = ISDN PRI protocol for Korean Operator

Parameter	Description
	<p>(similar to ETSI).</p> <ul style="list-style-type: none"> ▪ [20] T1 HKT ISDN = ISDN PRI (T1) protocol for the Hong Kong - HKT. ▪ [21] E1 QSIG = ECMA 143 QSIG over E1 ▪ [22] E1 TNZ = ISDN PRI protocol for Telecom New Zealand (similar to ETSI) ▪ [23] T1 QSIG = ECMA 143 QSIG over T1 ▪ [30] E1 FRENCH VN6 ISDN = France Telecom VN6 ▪ [31] E1 FRENCH VN3 ISDN = France Telecom VN3 ▪ [34] T1 EURO ISDN = ISDN PRI protocol for Euro over T1 ▪ [35] T1 DMS100 Meridian ISDN = ISDN PRI protocol for the Nortel™ DMS Meridian switch ▪ [36] T1 NI1 ISDN = National ISDN 1 PRI protocol ▪ [40] E1 NI2 ISDN = National ISDN 2 PRI protocol over E1 ▪ [50] BRI EURO ISDN = Euro ISDN over BRI ▪ [51] BRI N12 ISDN ▪ [52] BRI DMS 100 ISDN ▪ [53] BRI 5ESS 10 ISDN ▪ [54] BRI QSIG = QSIG over BRI ▪ [55] BRI VN6 = VN6 over BRI ▪ [56] BRI NTT = BRI ISDN Japan (Nippon Telegraph) ▪ [57] BRI IUA <p>Notes:</p> <ul style="list-style-type: none"> ▪ All PRI trunks must be configured as the same line type (either E1 or T1). The device can support different variants of CAS and PRI protocols on different E1/T1 spans (no more than four simultaneous PRI variants). ▪ BRI trunks can operate together with E1 or T1 trunks.
[ProtocolType_x]	Defines the protocol type for a specific trunk ID (where x denotes the Trunk ID and 0 is the first trunk). For more information, see the ProtocolType parameter.
[ISDNTimerT310]	Defines the T310 override timer for DMS, Euro ISDN, and ISDN NI2 variants. An ISDN timer is started when a Q.931 Call Proceeding message is received. The timer is stopped when a Q.931 Alerting, Connect, or Disconnect message is received from the other end. If no ISDN Alerting, Progress, or Connect message is received within the duration of T310 timer, the call clears. The valid value range is 0 to 600 seconds. The default is 0 (i.e., use the default timer value according to the protocol's specifications). <p>Notes:</p> <ul style="list-style-type: none"> ▪ For this parameter to take effect, a device reset is required. ▪ When both the parameters ISDNDmsTimerT310 and ISDNTimerT310 are configured, the value of the parameter ISDNTimerT310 prevails.
[ISDNDMSTimerT310]	Defines the override T310 timer for the DMS-100 ISDN variant. T310 defines the timeout between the receipt of a Proceeding message and the receipt of an Alerting/Connect message. The valid range is 10 to 30. The default is 10 (seconds). <p>Notes:</p>

Parameter	Description
	<ul style="list-style-type: none"> ▪ Instead of configuring this parameter, it is recommended to use the parameter ISDNTimerT310. ▪ This parameter is applicable only to Nortel DMS and Nortel MERIDIAN PRI variants (ProtocolType = 14 and 35).
[ISDNTimerT301]	<p>Defines the override T301 timer (in seconds). The T301 timer is started when a Q.931 Alert message is received. The timer is stopped when a Q.931 Connect/Disconnect message is received from the other side. If no Connect or Disconnect message is received within the duration of T301, the call is cleared.</p> <p>The valid range is 0 to 2400. The default is 0 (i.e., the default T301 timer value - 180 seconds - is used). If set to any other value than 0, it overrides the timer with this value.</p> <p>Notes:</p> <ul style="list-style-type: none"> ▪ For this parameter to take effect, a device reset is required. ▪ This parameter is applicable only to the QSIG variant.
[ISDNJapanNTTTimerT3JA]	<p>Defines the T3_JA timer (in seconds). This parameter overrides the internal PSTN T301 timeout on the Users Side (TE side). If an outgoing call from the device to ISDN is not answered during this timeout, the call is released.</p> <p>The valid range is 10 to 240. The default is 50.</p> <p>Notes:</p> <ul style="list-style-type: none"> ▪ This timer is also affected by the parameter PSTNAlertTimeout. ▪ This parameter is applicable only to the Japan NTT PRI variant (ProtocolType = 16).
Web/EMS: Trace Level [TraceLevel]	<p>Defines the trace level:</p> <ul style="list-style-type: none"> ▪ [0] No Trace (default) ▪ [1] Full ISDN Trace ▪ [2] Layer 3 ISDN Trace ▪ [3] Only ISDN Q.931 Messages Trace ▪ [4] Layer 3 ISDN No Duplication Trace
Web/EMS: Framing Method [FramingMethod]	<p>Determines the physical framing method for the trunk.</p> <ul style="list-style-type: none"> ▪ [0] Extended Super Frame = (Default) Depends on protocol type: <ul style="list-style-type: none"> ✓ E1: E1 CRC4 MultiFrame Format extended G.706B (same as c) ✓ T1: T1 Extended Super Frame with CRC6 (same as D) ▪ [1] Super Frame = T1 SuperFrame Format (as B). ▪ [a] E1 FRAMING DDF = E1 DoubleFrame Format - CRC4 is forced to off ▪ [b] E1 FRAMING MFF CRC4 = E1 CRC4 MultiFrame Format - CRC4 is always on ▪ [c] E1 FRAMING MFF CRC4 EXT = E1 CRC4 MultiFrame Format extended G.706B - auto negotiation is on. If the negotiation fails, it changes automatically to CRC4 off (ddf) ▪ [A] T1 FRAMING F4 = T1 4-Frame multiframe. ▪ [B] T1 FRAMING F12 = T1 12-Frame multiframe (D4). ▪ [C] T1 FRAMING ESF = T1 Extended SuperFrame without CRC6 ▪ [D] T1 FRAMING ESF CRC6 = T1 Extended SuperFrame with

Parameter	Description
	CRC6 <ul style="list-style-type: none"> ▪ [E] T1 FRAMING F72 = T1 72-Frame multiframe (SLC96) ▪ [F] T1 FRAMING ESF CRC6 J2 = J1 Extended SuperFrame with CRC6 (Japan) Note: This parameter is not configurable for BRI interfaces; the device automatically uses the BRI framing method.
[FramingMethod_x]	Same as the description for parameter FramingMethod, but for a specific trunk ID (where x denotes the Trunk ID and 0 is the first Trunk).
Web/EMS: Clock Master [ClockMaster]	Determines the Tx clock source of the E1/T1 line. <ul style="list-style-type: none"> ▪ [0] Recovered = (Default) Generate the clock according to the Rx of the E1/T1 line. ▪ [1] Generated = Generate the clock according to the internal TDM bus. Notes: <ul style="list-style-type: none"> ▪ The source of the internal TDM bus clock is determined by the parameter TDMBusClockSource. ▪ This parameter is applicable only to E1/T1 interfaces.
[ClockMaster_x]	Same as the description for parameter ClockMaster, but for a specific Trunk ID (where x denotes the Trunk ID and 0 is the first Trunk). Note: This parameter is applicable only to E1/T1 interfaces.
Web/EMS: Line Code [LineCode]	Selects B8ZS or AMI for T1 spans, and HDB3 or AMI for E1 spans. <ul style="list-style-type: none"> ▪ [0] B8ZS = (Default) B8ZS line code (for T1 trunks only). ▪ [1] AMI = AMI line code. ▪ [2] HDB3 = HDB3 line code (for E1 trunks only). Note: This parameter is not configurable for BRI interfaces; the device automatically uses the Modified Alternate Mark Invert (MAMI) line code.
[LineCode_x]	Same as the description for parameter LineCode, but for a specific trunk ID (where 0 denotes the first trunk).
[TrunkLifeLineType]	Determines the scenarios upon which the PSTN Fallback (lifeline) feature is activated. This feature redirects IP calls to the PSTN upon a power outage, a LAN disconnection, or lack of IP connectivity (i.e., no ping), thereby guaranteeing call continuity. PSTN Fallback is supported if the device houses one or two E1/T1 ("TRUNKS") modules, where each module provides two or four spans. In the event of a PSTN fallback, the module's metallic relay switch automatically connects trunk Port 1 (I) to Port 2 (II), and / or trunk Port 3 (III) to Port 4 (IIII), of the same module. Therefore, if for example, a PBX trunk is connected to Port 1 and the PSTN network is connected to Port 2, when PSTN fallback is activated, calls from the PBX are routed directly to the PSTN through Port 2. <ul style="list-style-type: none"> ▪ [0] = (Default) Activate PSTN Fallback upon power outage. ▪ [1] = Activate PSTN Fallback upon power outage or detection of LAN disconnection. ▪ [2] = Activate PSTN Fallaback on power outage, detection of LAN disconnection, or loss of ping (i.e., no IP connectivity).

Parameter	Description
	<p>Notes:</p> <ul style="list-style-type: none"> ▪ For this parameter to take effect, a device reset is required. ▪ PSTN Fallback is supported only between ports on the same module. ▪ PSTN Fallback is supported only for ISDN when the number of supported channels (e.g., 30) is less than the maximum number of possible channels provided by the physical ports (e.g., two E1 trunks). When the number of supported channels (e.g., 60) equals the maximum number of channels provided by the physical ports (e.g., two E1 trunks), then other protocols such as CAS are also supported. ▪ The PSTN Fallback feature has no relation to the PSTN Fallback Software License Key.
[AdminState]	<p>Defines the administrative state for all trunks.</p> <ul style="list-style-type: none"> ▪ [0] = Lock the trunk; stops trunk traffic to configure the trunk protocol type. ▪ [1] = Shutting down (read only). ▪ [2] = (Default) Unlock the trunk; enables trunk traffic. <p>Notes:</p> <ul style="list-style-type: none"> ▪ For this parameter to take effect, a device reset is required. ▪ When the device is locked from the Web interface, this parameter changes to 0. ▪ To define the administrative state per trunk, use the TrunkAdministrativeState parameter.
[TrunkAdministrativeState_x]	<p>Defines the administrative state per trunk, where x denotes the trunk number.</p> <ul style="list-style-type: none"> ▪ [0] = Lock the trunk; stops trunk traffic to configure the trunk protocol type. ▪ [1] = shutting down (read only). ▪ [2] = (Default) Unlock the trunk; enables trunk traffic.
Web/EMS: Line Build Out Loss [LineBuildOut.Loss]	<p>Defines the line build out loss for the selected T1 trunk.</p> <ul style="list-style-type: none"> ▪ [0] 0 dB (default) ▪ [1] -7.5 dB ▪ [2] -15 dB ▪ [3] -22.5 dB <p>Note: This parameter is applicable only to T1 trunks.</p>
[TDMHairPinning]	<p>Defines static TDM hair-pinning (cross-connection) performed at initialization. The connection is between trunks with an option to exclude a single B-channel in each trunk. Format example: T0-T1/B3,T2-T3,T4-T5/B2.</p> <p>Note: For this parameter to take effect, a device reset is required.</p>
Web: Enable TDM Tunneling EMS: TDM Over IP [EnableTDMoverIP]	<p>Enables TDM tunneling.</p> <ul style="list-style-type: none"> ▪ [0] Disable (default) ▪ [1] Enable <p>When TDM Tunneling is enabled, the originating device automatically initiates SIP calls from all enabled B-channels pertaining to E1/T1/J1 spans that are configured with the 'Transparent' protocol. The called number of each call is the internal phone number of the B-channel from where the call</p>

Parameter	Description
	<p>originates. The 'The Inbound IP Routing Table is used to define the destination IP address of the terminating device. The terminating device automatically answers these calls if its E1/T1 protocol is set to 'Transparent' (ProtocolType = 5).</p> <p>Notes:</p> <ul style="list-style-type: none"> For this parameter to take effect, a device reset is required. For an overview on TDM tunneling, see 'TDM Tunneling' on page 281.

52.11.6.2 TDM Bus and Clock Timing Parameters

The TDM Bus parameters are described in the table below.

TDM Bus and Clock Timing Parameters

Parameter	Description
TDM Bus Parameters	
Web/EMS: PCM Law Select [PCMLawSelect]	<p>Determines the type of pulse-code modulation (PCM) companding algorithm law in input and output TDM bus.</p> <ul style="list-style-type: none"> [1] Alaw [3] MuLaw <p>The default is automatically selected according to the Protocol Type of the selected trunk: E1 defaults to ALaw, T1 defaults to MuLaw. If the Protocol Type is set to NONE, the default is MuLaw.</p> <p>Notes:</p> <ul style="list-style-type: none"> For this parameter to take effect, a device reset is required. Typically, A-Law is used for E1 spans and Mu-Law for T1/J1 spans.
Web/EMS: Idle PCM Pattern [IdlePCMPattern]	<p>Defines the PCM Pattern that is applied to the E1/T1 timeslot (B-channel) when the channel is idle.</p> <p>The range is 0 to 255. The default is set internally according to the Law select 1 (0xFF for Mu-Law; 0x55 for A-law).</p> <p>Note: For this parameter to take effect, a device reset is required.</p>
Web/EMS: Idle ABCD Pattern [IdleABCDPattern]	<p>Defines the ABCD (CAS) Pattern that is applied to the CAS signaling bus when the channel is idle.</p> <p>The valid range is 0x0 to 0xF. The default is -1 (i.e., default pattern is 0000).</p> <p>Notes:</p> <ul style="list-style-type: none"> For this parameter to take effect, a device reset is required. This parameter is applicable only when using PSTN interface with CAS protocols.
Web/EMS: TDM Bus Clock Source [TDMBusClockSource]	<p>Determines the clock source to which the device synchronizes.</p> <ul style="list-style-type: none"> [1] Internal = (Default) Generate clock from local source. [4] Network = Recover clock from PSTN line.
Web/EMS: TDM Bus Local Reference [TDMBusLocalReference]	<p>Defines the physical Trunk ID from which the device recovers (receives) its clock synchronization.</p> <p>The range is 0 to the maximum number of Trunks. The default is</p>

Parameter	Description
	0. Note: This parameter is applicable only if the parameter TDMBusClockSource is set to 4 and the parameter TDMBusPSTNAutoClockEnable is set to 0.
Web/EMS: TDM Bus Enable Fallback [TDMBusEnableFallback]	Defines the automatic fallback of the clock. <ul style="list-style-type: none"> ▪ [0] Manual (default) ▪ [1] Auto Non-Revertive ▪ [2] Auto Revertive
Web: TDM Bus Fallback Clock Source EMS: TDM Bus Fallback Clock [TDMBusFallbackClock]	Determines the fallback clock source on which the device synchronizes in the event of a clock failure. <ul style="list-style-type: none"> ▪ [4] Network (default) ▪ [8] H.110_A ▪ [9] H.110_B ▪ [10] NetReference1 ▪ [11] NetReference2
Web/EMS: TDM Bus Net Reference Speed [TDMBusNetrefSpeed]	Defines the NetRef frequency (for both generation and synchronization). <ul style="list-style-type: none"> ▪ [0] 8 kHz (default) ▪ [1] 1.544 MHz ▪ [2] 2.048 MHz
Web: TDM Bus PSTN Auto FallBack Clock EMS: TDM Bus Auto Fall Back Enable [TDMBusPSTNAutoClockEnable]	Enables the PSTN trunk Auto-Fallback Clock feature. <ul style="list-style-type: none"> ▪ [0] Disable = (Default) Recovers the clock from the E1/T1 line defined by the parameter TDMBusLocalReference. ▪ [1] Enable = Recovers the clock from any connected synchronized slave E1/T1 line. If this trunk loses its synchronization, the device attempts to recover the clock from the next trunk. Note that initially, the device attempts to recover the clock from the trunk defined by the parameter TDMBusLocalReference. Notes: <ul style="list-style-type: none"> ▪ For this parameter to take effect, a device reset is required. ▪ This parameter is relevant only if the parameter TDMBusClockSource is set to 4.
Web: TDM Bus PSTN Auto Clock Reverting EMS: TDM Bus Auto Fall Back Reverting Enable [TDMBusPSTNAutoClockRevertingEnable]	Enables the PSTN trunk Auto-Fallback Reverting feature. If enabled and a trunk returning to service has an AutoClockTrunkPriority parameter value that is higher than the priority of the local reference trunk (set in the TDMBusLocalReference parameter), the local reference reverts to the trunk with the higher priority that has returned to service for the device's clock source. <ul style="list-style-type: none"> ▪ [0] Disable (default) ▪ [1] Enable Notes: <ul style="list-style-type: none"> ▪ For this parameter to take effect, a device reset is required. ▪ This parameter is applicable only when the TDMBusPSTNAutoClockEnable parameter is set to 1.
Web: Auto Clock Trunk Priority EMS: Auto Trunk Priority	Defines the trunk priority for auto-clock fallback (per trunk parameter).

Parameter	Description
[AutoClockTrunkPriority]	<ul style="list-style-type: none"> 0 to 99 = priority, where 0 (default) is the highest. 100 = the SW never performs a fallback to that trunk (usually used to mark untrusted source of clock). <p>Note: Fallback is enabled when the TDMBusPSTNAutoClockEnable parameter is set to 1.</p>

52.11.6.3 CAS Parameters

The Common Channel Associated (CAS) parameters are described in the table below. Note that CAS is not applicable to BRI interfaces.

CAS Parameters

Parameter	Description
Web: CAS Transport Type EMS: CAS Relay Transport Mode [CASTransportType]	Determines the ABCD signaling transport type over IP. <ul style="list-style-type: none"> [0] CAS Events Only = (Default) Disable CAS relay. [1] CAS RFC2833 Relay = Enable CAS relay mode using RFC 2833. The CAS relay mode can be used with the TDM tunneling feature to enable tunneling over IP for both voice and CAS signaling bearers.
[CASAddressingDelimiters]	Enables the addition of delimiters to the received address or received ANI digits string. <ul style="list-style-type: none"> [0] = (default) Disable. The address and ANI strings remain without delimiters. [1] = Enable. Delimiters such as '*', '#', and 'ST' are added to the received address or received ANI digits string.
[CASDelimitersPaddingUsage]	Defines the digits string delimiter padding usage per trunk. <ul style="list-style-type: none"> [0] = (Default) Default address string padding: '*XXX#' (where XXX is the digit string that begins with '*' and ends with '#', when using padding). [1] = Special use of asterisks delimiters: '*XXX*YYY*' (where XXX is the address, YYY is the source phone number, and '*' is the only delimiter padding). <p>Note: For this parameter to take effect, a device reset is required.</p>
Web: CAS Table per Trunk EMS: Trunk CAS Table Index [CASTableIndex_x]	Defines the CAS protocol per trunk from a list of CAS protocols defined by the parameter CASFileName_x. For example, the below configuration specifies Trunks 0 and 1 to use the E&M Winkstart CAS (E_M_WinkTable.dat) protocol, and Trunks 2 and 3 to use the E&M Immediate Start CAS (E_M_ImmediateTable.dat) protocol: <pre>CASFileName_0 = 'E_M_WinkTable.dat' CASFileName_1 = 'E_M_ImmediateTable.dat' CASTableIndex_0 = 0 CASTableIndex_1 = 0 CASTableIndex_2 = 1 CASTableIndex_3 = 1</pre> <p>Notes:</p> <ul style="list-style-type: none"> You can define CAS tables per B-channel using the parameter CASChannelIndex.

Parameter	Description
Web: Dial Plan EMS: Dial Plan Name [CASTrunkDialPlanName_x]	<ul style="list-style-type: none"> The x in the ini file parameter name denotes the trunk number, where 0 is Trunk 1. Defines the CAS Dial Plan name per trunk. The range is up to 11 characters. For example, the below configures E1_MFCR2 trunk with a single protocol (Trunk 5): <pre>ProtocolType_5 = 7 CASFileName_0='R2_Korea_CP_ANI.dat' CASTableIndex_5 = 0 DialPlanFileName = 'DialPlan_USA.dat' CASTrunkDialPlanName_5 = 'AT_T'</pre> Note: The x in the ini file parameter name denotes the trunk number, where 0 is Trunk 1.
[CASFileName_x]	Defines the CAS file name (e.g., 'E_M_WinkTable.dat') that defines the CAS protocol, where x denotes the CAS file ID (0-7). It is possible to define up to eight different CAS files by repeating this parameter. Each CAS file can be associated with one or more of the device's trunks, using the parameter CASTableIndex_x. Note: For this parameter to take effect, a device reset is required.
Web/EMS: CAS Table per Channel [CASChannelIndex]	Defines the loaded CAS protocol table index per B-channel pertaining to a CAS trunk. This parameter is assigned a string value and can be set in one of the following two formats: <ul style="list-style-type: none"> CAS table per channel: Each channel is separated by a comma and the value entered denotes the CAS table index used for that channel. The syntax is <CAS index>,<CAS index> (e.g., "1,2,1,2..."). For this format, 31 indices must be defined for E1 trunks (including dummy for B-channel 16), or 24 indices for T1 trunks. Below is an example for configuring a T1 CAS trunk (Trunk 5) with several CAS variants: <pre>ProtocolType_5 = 7 CASFILENAME_0='E_M_FGBWinkTable.dat' CASFILENAME_1='E_M_FGDWinkTable.dat' CASFILENAME_2='E_M_WinkTable.txt' CasChannelIndex_5 = '0,0,0,1,1,1,2,2,2,0,0,0,1,1,1,0,1,2,0,2,1,2,2,2' CASDelimitersPaddingUsage_5 = 1</pre> CAS table per channel group: Each channel group is separated by a colon and each channel is separated by a comma. The syntax is <x-y channel range>:<CAS table index>, (e.g., "1-10:1,11-31:3"). Every B-channel (including 16 for E1) must belong to a channel group. Below is an example for configuring an E1 CAS trunk (Trunk 5) with several CAS variants: <pre>ProtocolType_5 = 8 CASFILENAME_2='E1_R2D' CASFILENAME_7= E_M_ImmediateTable_A-Bit.txt' CasChannelIndex_5 = '1-10:2,11-20:7,21-31:2'</pre> Notes: <ul style="list-style-type: none"> To configure this parameter, the trunk must first be stopped. Only one of these formats can be implemented; not both. When this parameter is not configured, a single CAS table for

Parameter	Description
	the entire trunk is used, configured by the parameter CASTableIndex.
[CASTablesNum]	Defines how many CAS protocol configurations files are loaded. The valid range is 1 to 8. Note: For this parameter to take effect, a device reset is required.
CAS State Machines Parameters	
Note: For configuring the CAS State Machine table using the Web interface, see 'Configuring CAS State Machines' on page 277.	
Web: Generate Digit On Time [CASStateMachineGenerateDigitOnTime]	Generates digit on-time (in msec). The value must be a positive value. The default is -1.
Web: Generate Inter Digit Time [CASStateMachineGenerateInterDigitTime]	Generates digit off-time (in msec). The value must be a positive value. The default is -1.
Web: DTMF Max Detection Time [CASStateMachineDTMFMaxOnDetectionTime]	Detects digit maximum on time (according to DSP detection information event) in msec units. The value must be a positive value. The default is -1.
Web: DTMF Min Detection Time [CASStateMachineDTMFMinOnDetectionTime]	Detects digit minimum on time (according to DSP detection information event) in msec units. The digit time length must be longer than this value to receive a detection. Any number may be used, but the value must be less than CasStateMachineDTMFMaxOnDetectionTime. The value must be a positive value. The default is -1.
Web: MAX Incoming Address Digits [CASStateMachineMaxNumOfIncomingAddressDigits]	Defines the limitation for the maximum address digits that need to be collected. After reaching this number of digits, the collection of address digits is stopped. The value must be an integer. The default is -1.
Web: MAX Incoming ANI Digits [CASStateMachineMaxNumOfIncomingANIDigits]	Defines the limitation for the maximum ANI digits that need to be collected. After reaching this number of digits, the collection of ANI digits is stopped. The value must be an integer. The default is -1.
Web: Collect ANI [CASStateMachineCollectANI]	In some cases, when the state machine handles the ANI collection (not related to MFCR2), you can enable the state machine to collect ANI or discard ANI. <ul style="list-style-type: none"> ▪ [0] No = Don't collect ANI. ▪ [1] Yes = Collect ANI. ▪ [-1] Default = Default value.
Web: Digit Signaling System [CASStateMachineDigitSignalingSystem]	Defines which Signaling System to use in both directions (detection\generation). <ul style="list-style-type: none"> ▪ [0] DTMF = DTMF signaling. ▪ [1] MF = (Default) MF signaling. ▪ [-1] Default = Default value.

52.11.6.4 ISDN Parameters

The ISDN parameters are described in the table below.

ISDN Parameters

Parameter	Description
Web: ISDN Termination Side EMS: Termination Side [TerminationSide]	<p>Determines the ISDN termination side.</p> <ul style="list-style-type: none"> ▪ [0] User side = (Default) ISDN User Termination Equipment (TE) side. ▪ [1] Network side = ISDN Network Termination (NT) side. <p>Note: Select 'User side' when the PSTN or PBX side is configured as 'Network side' and vice versa. If you don't know the device's ISDN termination side, choose 'User side'. If the D-channel alarm is indicated, choose 'Network Side'.</p> <p>The BRI module supports the ITU-T I.430 standard, which defines the ISDN-BRI layer 1 specification. The BRI and PRI ports are configured similarly, using this parameter. When an NT port is active, it drives a 38-V line and sends an INFO1 signal (as defined in ITU-T I.430 Table 4) on the data line to synchronize to a TE port that might be connected to it. To stop the voltage and the INFO1 signal on the line, stop the trunk using the Stop Trunk button.</p>
[TerminationSide_x]	Same as the description for parameter TerminationSide, but for a specific trunk ID (where x denotes the Trunk ID and 0 is the first Trunk).
BRI Layer 2 Mode [BriLayer2Mode]	<p>Determines whether Point-to-Point or Point-to-Multipoint mode for BRI ports.</p> <ul style="list-style-type: none"> ▪ [0] Point to Point (default) ▪ [1] Point to Multipoint = Must be configured for Network side.
Web/EMS: B-channel Negotiation [BchannelNegotiation]	<p>Determines the ISDN B-Channel negotiation mode.</p> <ul style="list-style-type: none"> ▪ [0] Preferred ▪ [1] Exclusive (default) ▪ [2] Any <p>Notes:</p> <ul style="list-style-type: none"> ▪ This parameter is applicable only to ISDN protocols. ▪ For some ISDN variants, when 'Any' (2) is selected, the Setup message excludes the Channel Identification IE. ▪ The 'Any' (2) option is applicable only if the following conditions are met: <ul style="list-style-type: none"> ✓ The parameter TerminationSide is set to 0 ('User side'). ✓ The PSTN protocol type (ProtocolType) is configured as Euro ISDN.
NFAS Parameters	
Note: These parameters are applicable to PRI interfaces.	
Web: NFAS Group Number EMS: Group Number [NFASGroupNumber_x]	<p>Defines the ISDN Non-Facility Associated Signaling (NFAS) group number (NFAS member) per trunk.</p> <ul style="list-style-type: none"> ▪ [0] = (Default) Non-NFAS trunk. ▪ [1] to [12] = NFAS group number. <p>Trunks that belong to the same NFAS group have the same</p>

Parameter	Description
	number. With NFAS, you can use a single D-channel to control multiple PRI interfaces. Notes: <ul style="list-style-type: none"> ▪ For this parameter to take effect, a device reset is required. ▪ This parameter is applicable only to T1 ISDN protocols. ▪ The x in the ini file parameter name denotes the trunk number, where 0 is Trunk 1. ▪ For more information on NFAS, see 'ISDN Non-Facility Associated Signaling (NFAS)' on page 285.
Web/EMS: D-channel Configuration [DChConfig_x]	Defines primary, backup (optional), and B-channels only, per trunk. <ul style="list-style-type: none"> ▪ [0] PRIMARY= (Default) Primary Trunk - contains a D-channel that is used for signaling. ▪ [1] BACKUP = Backup Trunk - contains a backup D-channel that is used if the primary D-channel fails. ▪ [2] NFAS = NFAS Trunk - contains only 24 B-channels, without a signaling D-channel. Notes: <ul style="list-style-type: none"> ▪ This parameter is applicable only to T1 ISDN protocols. ▪ The x in the ini file parameter name denotes the trunk number, where 0 is Trunk 1.
Web: NFAS Interface ID EMS: ISDN NFAS Interface ID [ISDNNFASInterfaceID_x]	Defines a different Interface ID per T1 trunk. The valid range is 0 to 100. The default interface ID equals the trunk's ID. Notes: <ul style="list-style-type: none"> ▪ To set the NFAS interface ID, configure ISDNIBehavior_x to include '512' feature per T1 trunk. ▪ The x in the ini file parameter name denotes the trunk number, where 0 is Trunk 1. ▪ For more information on NFAS, see 'ISDN Non-Facility Associated Signaling (NFAS)' on page 285.
Web: Enable ignoring ISDN Disconnect with PI [KeepISDNCallOnDisconnectWithPI]	Allows the device to ignore ISDN Disconnect messages with PI 1 or 8. <ul style="list-style-type: none"> ▪ [1] = The call (in connected state) is not released if a Q.931 Disconnect with PI (PI = 1 or 8) message is received during the call. ▪ [0] = (Default) The call is disconnected.
Web: PI For Setup Message [PIForSetupMsg]	Determines whether and which Progress Indicator (PI) information element (IE) is added to the sent ISDN Setup message. Some ISDN protocols such as NI-2 or Euro ISDN can optionally contain PI = 1 or PI = 3 in the Setup message. <ul style="list-style-type: none"> ▪ [0] = PI is not added (default). ▪ [1] = PI 1 is added to a sent ISDN Setup message - call is not end-to-end ISDN. ▪ [3] = PI 3 is added to a sent ISDN Setup message - calling equipment is not ISDN.
ISDN Flexible Behavior Parameters ISDN protocol is implemented in different switches/PBXs by different vendors. Several implementations may vary slightly from the specification. Therefore, to provide a flexible interface that supports these ISDN variants, the ISDN behavior parameters can be used.	

Parameter	Description
Web/EMS: Incoming Calls Behavior [ISDNInCallsBehavior]	<p>Determines the bit-field used to determine several behavior options that influence how the ISDN Stack INCOMING calls behave.</p> <ul style="list-style-type: none"> ▪ [32] DATA CONN RS = The device automatically sends a Q.931 Connect (answer) message on incoming Tel calls (Q.931 Setup). ▪ [64] VOICE CONN RS = The device sends a Connect (answer) message on incoming Tel calls. ▪ [2048] CHAN ID IN FIRST RS = (Default) The device sends Channel ID in the first response to an incoming Q.931 Call Setup message. Otherwise, the Channel ID is sent only if the device requires changing the proposed Channel ID. ▪ [4096] USER SETUP ACK = The Setup Ack message is sent by the SIP Gateway application layer and not automatically by the PSTN stack. By default, this bit is set. ▪ [8192] CHAN ID IN CALL PROC = The device sends Channel ID in a Q.931 Call Proceeding message. ▪ [65536] PROGR IND IN SETUP ACK = The device includes Progress Indicator (PI=8) in Setup Ack message if an empty called number is received in an incoming Setup message. This option is applicable to the overlap dialing mode. The device also plays a dial tone (for TimeForDialTone) until the next called number digits are received. By default, this bit is set. ▪ [2147483648] USER SCREEN INDICATOR = When the device receives two Calling Number IE's in the Setup message, the device, by default, uses only one of the numbers according to the following: <ul style="list-style-type: none"> ✓ Network provided, Network provided - the first calling number is used ✓ Network provided, User provided: the first one is used ✓ User provided, Network provided: the second one is used ✓ User provided, user provided: the first one is used <p>When this bit is configured, the device behaves as follows:</p> <ul style="list-style-type: none"> ✓ Network provided, Network provided: the first calling number is used ✓ Network provided, User provided: the second one is used ✓ User provided, Network provided: the first one is used ✓ User provided, user provided: the first one is used <p>Note: When using the <i>ini</i> file to configure the device to support several ISDNInCallsBehavior features, enter a summation of the individual feature values. For example, to support both [2048] and [65536] features, set ISDNInCallsBehavior = 67584 (i.e., 2048 + 65536).</p>
[ISDNInCallsBehavior_x]	<p>Same as the description for the parameter ISDNInCallsBehavior, but per trunk (i.e., where x denotes the Trunk ID).</p>
Web/EMS: Q.931 Layer Response Behavior [ISDNIBehavior]	<p>Bit-field used to determine several behavior options that influence the behaviour of the Q.931 protocol.</p> <ul style="list-style-type: none"> ▪ [0] = Disable (default). ▪ [1] NO STATUS ON UNKNOWN IE = Q.931 Status message isn't sent if Q.931 received message contains an unknown/unrecognized IE. By default, the Status message is sent.

Parameter	Description
	<p>Note: This value is applicable only to ISDN variants in which sending of Status message is optional.</p> <ul style="list-style-type: none"> ▪ [2] NO STATUS ON INV OP IE = Q.931 Status message isn't sent if an optional IE with invalid content is received. By default, the Status message is sent. Note: This option is applicable only to ISDN variants in which sending of Status message is optional. ▪ [4] ACCEPT UNKNOWN FAC IE = Accepts unknown/unrecognized Facility IE. Otherwise, the Q.931 message that contains the unknown Facility IE is rejected (default). Note: This option is applicable only to ISDN variants where a complete ASN1 decoding is performed on Facility IE. ▪ [128] SEND USER CONNECT ACK = The Connect ACK message is sent in response to received Q.931 Connect; otherwise, the Connect ACK is not sent. Note: This option is applicable only to Euro ISDN User side outgoing calls. ▪ [512] EXPLICIT INTERFACE ID = Enables to configure T1 NFAS Interface ID (refer to the parameter ISDNNFASInterfaceID_x). Note: This value is applicable only to 4/5ESS, DMS, NI-2 and HKT variants. ▪ [2048] ALWAYS EXPLICIT = Always set the Channel Identification IE to explicit Interface ID, even if the B-channel is on the same trunk as the D-channel. Note: This value is applicable only to 4/5ESS, DMS and NI-2 variants. ▪ [32768] ACCEPT MU LAW =Mu-Law is also accepted in ETSI. ▪ [65536] EXPLICIT PRES SCREENING = The calling party number (octet 3a) is always present even when presentation and screening are at their default. Note: This option is applicable only to ETSI, NI-2, and 5ESS. ▪ [131072] STATUS INCOMPATIBLE STATE = Clears the call on receipt of Q.931 Status with incompatible state. Otherwise, no action is taken (default). ▪ [262144] STATUS ERROR CAUSE = Clear call on receipt of Status according to cause value. ▪ [524288] ACCEPT A LAW =A-Law is also accepted in 5ESS. ▪ [2097152] RESTART INDICATION = Upon receipt of a Restart message, acEV_PSTN_RESTART_CONFIRM is generated. ▪ [4194304] FORCED RESTART = On data link (re)initialization, send RESTART if there is no call. ▪ [67108864] NS ACCEPT ANY CAUSE = Accept any Q.850 Cause IE from ISDN. Note: This option is applicable only to Euro ISDN. ▪ [134217728] NS_BRI_DL_ALWAYS_UP (0x08000000) = By default, the BRI D-channel goes down if there are no active calls. If this option is configured, the BRI D-channel is always up and synchronized. ▪ [536870912] Alcatel coding for redirect number and display name is accepted by the device. Note: This option is applicable only to QSIG (and relevant for specific Alcatel PBXs such as OXE). ▪ [1073741824] QSI ENCODE INTEGER = If this bit is set,

Parameter	Description
	<p>INTEGER ASN.1 type is used in operator coding (compliant to new ECMA standards); otherwise, OBJECT IDENTIFIER ASN.1 type is used.</p> <p>Note: This option is applicable only to QSIG.</p> <ul style="list-style-type: none"> ▪ [2147483648] 5ESS National Mode For Bch Maintenance = Use the National mode of AT&T 5ESS for B-channel maintenance. <p>Notes:</p> <ul style="list-style-type: none"> ▪ To configure the device to support several ISDNBehavior features, enter a summation of the individual feature values. For example, to support both [512] and [2048] features, set the parameter ISDNBehavior is set to 2560 (i.e., 512 + 2048). ▪ When configuring in the Web interface, to select the options click the arrow button and then for each required option select 1 to enable.
[ISDNBehavior_x]	Same as the description for parameter ISDNBehavior, but for a specific trunk ID.
<p>Web: General Call Control Behavior EMS: General CC Behavior [ISDNGeneralCCBehavior]</p>	<p>Bit-field for determining several general CC behavior options. To select the options, click the arrow button, and then for each required option, select 1 to enable. The default is 0 (i.e., disable).</p> <ul style="list-style-type: none"> ▪ [2] = Data calls with interworking indication use 64 kbps B-channels (physical only). ▪ [8] REVERSE CHAN ALLOC ALGO = Channel ID allocation algorithm. ▪ [16] = The device clears down the call if it receives a NOTIFY message specifying 'User-Suspended'. A NOTIFY (User-Suspended) message is used by some networks (e.g., in Italy or Denmark) to indicate that the remote user has cleared the call, especially in the case of a long distance voice call. ▪ [32] CHAN ID 16 ALLOWED = Applies only to ETSI E1 lines (30B+D). Enables handling the differences between the newer QSIG standard (ETS 300-172) and other ETSI-based standards (ETS 300-102 and ETS 300-403) in the conversion of B-channel ID values into timeslot values: <ul style="list-style-type: none"> ✓ In 'regular ETSI' standards, the timeslot is identical to the B-channel ID value, and the range for both is 1 to 15 and 17 to 31. The D-channel is identified as channel-id #16 and carried into the timeslot #16. ✓ In newer QSIG standards, the channel-id range is 1 to 30, but the timeslot range is still 1 to 15 and 17 to 31. The D-channel is not identified as channel-id #16, but is still carried into the timeslot #16. <p>When this bit is set, the channel ID #16 is considered as a valid B-channel ID, but timeslot values are converted to reflect the range 1 to 15 and 17 to 31. This is the new QSIG mode of operation. When this bit is not set (default), the channel_id #16 is not allowed, as for all ETSI-like standards.</p> ▪ [64] USE T1 PRI = PRI interface type is forced to T1. ▪ [128] USE E1 PRI = PRI interface type is forced to E1. ▪ [256] START WITH B CHAN OOS = B-channels start in the Out-Of-Service state (OOS). ▪ [512] CHAN ALLOC LOWEST = CC allocates B-channels

Parameter	Description
	<p>starting from the lowest available B-channel id.</p> <ul style="list-style-type: none"> ▪ [1024] CHAN ALLOC HIGHEST = CC allocates B-channels starting from the highest available B-channel id. ▪ [16384] CC_TRANSPARENT_UUI bit: The UUI-protocol implementation of CC is disabled allowing the application to freely send UUI elements in any primitive, regardless of the UUI-protocol requirements (UUI Implicit Service 1). This allows more flexible application control on the UUI. When this bit is not set (default behavior), CC implements the UUI-protocol as specified in the ETS 300-403 standards for Implicit Service 1. ▪ [65536] GTD5 TBCT = CC implements the VERIZON-GTD-5 Switch variant of the TBCT Supplementary Service, as specified in FSD 01-02-40AG Feature Specification Document from Verizon. Otherwise, TBCT is implemented as specified in GR-2865-CORE specification (default behavior). <p>Note: When using the <i>ini</i> file to configure the device to support several ISDNGeneralCCBehavior features, add the individual feature values. For example, to support both [16] and [32] features, set ISDNGeneralCCBehavior = 48 (i.e., 16 + 32).</p>
Web/EMS: Outgoing Calls Behavior [ISDNOutCallsBehavior]	<p>Determines several behaviour options (bit fields) that influence the behaviour of the ISDN Stack outgoing calls. To select options, click the arrow button, and then for each required option, select 1 to enable. The default is 0 (i.e., disable).</p> <ul style="list-style-type: none"> ▪ [2] USER SENDING COMPLETE = The default behavior of the device (when this bit is not set) is to automatically generate the Sending-Complete IE in the Setup message. This behavior is used when overlap dialing is not needed. When overlap dialing is needed, set this bit and the behavior is changed to suit the scenario, i.e., Sending-Complete IE is added when required in the Setup message for Enblock mode or in the last Digit with Overlap mode. ▪ [16] USE MU LAW = The device sends G.711-m-Law in outgoing voice calls. When disabled, the device sends G.711-A-Law in outgoing voice calls. Note: This option is applicable only to the Korean variant. ▪ [128] DIAL WITH KEYPAD = The device uses the Keypad IE to store the called number digits instead of the CALLED_NB IE. Note: This option is applicable only to the Korean variant (Korean network). This is useful for Korean switches that don't accept the CALLED_NB IE. ▪ [256] STORE CHAN ID IN SETUP = The device forces the sending of a Channel-Id IE in an outgoing Setup message even if it's not required by the standard (i.e., optional) and no Channel-Id has been specified in the establishment request. This is useful for improving required compatibility with switches. On BRI lines, the Channel-Id IE indicates 'any channel'. On PRI lines, it indicates an unused channel ID, preferred only. ▪ [572] USE A LAW = The device sends G.711 A-Law in outgoing voice calls. When disabled, the device sends the default G.711-Law in outgoing voice calls. Note: This option is applicable only to the E10 variant. ▪ [1024] = Numbering plan/type for T1 IP-to-Tel calling numbers are defined according to the manipulation tables or according

Parameter	Description
	<p>to the RPID header (default). Otherwise, the plan/type for T1 calls are set according to the length of the calling number.</p> <ul style="list-style-type: none"> ▪ [2048] = The device accepts any IA5 character in the called_nb and calling_nb strings and sends any IA5 character in the called_nb, and is not restricted to extended digits only (i.e., 0-9, *,#). ▪ [16384] DLCI REVERSED OPTION = Behavior bit used in the IUA interface groups to indicate that the reversed format of the DLCI field must be used. <p>Note: When using the <i>ini</i> file to configure the device to support several ISDNOutCallsBehavior features, add the individual feature values. For example, to support both [2] and [16] features, set ISDNOutCallsBehavior = 18 (i.e., 2 + 16).</p>
[ISDNOutCallsBehavior_x]	Same as the description for parameter ISDNOutCallsBehavior, but for a specific trunk ID.
Web: ISDN NS Behaviour 2 [ISDNNSBehaviour2]	<p>Bit-field to determine several behavior options that influence the behavior of the Q.931 protocol.</p> <ul style="list-style-type: none"> ▪ [8] NS BEHAVIOUR2 ANY UUI = Any User to User Information Element (UUIE) is accepted for any protocol discriminator. This is useful for interoperability with non-standard switches. ▪ [16] NS BEHAVIOUR2 DISPLAY = The Display IE is accepted even if it is not defined in the QSIG ISDN protocol standard. This is applicable only when configuration is QSI. ▪ [64] NS BEHAVIOUR2 FAC REJECT = When this bit is set, the device answers with a Facility IE message with the Reject component on receipt of Facility IE with unknown/invalid Invoke component. This bit is implemented in QSIG and ETSI variants.
[PSTNExtendedParams]	<p>Determines the bit map for special PSTN behavior parameters:</p> <ul style="list-style-type: none"> ▪ [0] = (Default) Applicable for NI-2 ISDN and QSIG "Networking Extensions". This bit (i.e., bit #0) is responsible for the Invoke ID size: <ul style="list-style-type: none"> ✓ If this bit is not set (default), then the Invoke ID size is always one byte, with a value of 01 to 7f. ✓ If this bit is set, then the Invoke ID size is one or two bytes according to the Invoke ID value. ▪ [2] = Applicable to the ROSE format (according to the old QSIG specifications). This bit (i.e., bit #1) is responsible for the QSIG octet 3. According to the ECMA-165 new version, octet 3 in all QSIG supplementary services Facility messages should be 0x9F = Networking Extensions. However, according to the old version, the value should be 0x91 = ROSE: <ul style="list-style-type: none"> ✓ If this bit is not set (default): 0x9F = Networking Extensions. ✓ If this bit is set: 0x91 = ROSE. ▪ [3] = Use options [0] and [2] above. <p>Note: For this parameter to take effect, a device reset is required.</p>

52.11.7 ISDN and CAS Interworking Parameters

The ISDN and CAS interworking parameters are described in the table below.

ISDN and CAS Interworking Parameters

Parameter	Description
ISDN Parameters	
Web: Send Local Time To ISDN Connect [SendLocalTimeToISDNConnect]	Determines the device's handling of the date and time sent in the ISDN Connect message (Date / Time IE) upon receipt of SIP 200 OK messages. <ul style="list-style-type: none"> ▪ [0] Disable = (Default) If the SIP 200 OK includes the Date header, the device sends its value in the ISDN Connect Date / Time IE. If the 200 OK does not include this header, it does not add the Date / Time IE to the sent ISDN Connect message. ▪ [1] Enable = If the SIP 200 OK includes the Date header, the device sends its value (i.e. date and time) in the ISDN Connect Date / Time IE. If the 200 OK does not include this header, the device uses its internal, local date and time for the Date / Time IE, which it adds to the sent ISDN Connect message. ▪ [2] Always Send Local Date and Time = The device always sends its local date and time (obtained from its internal clock) to PBXs in ISDN Q.931 Connect messages (Date / Time IE). It does this regardless of whether or not the incoming SIP 200 OK includes the Date header. If the SIP 200 OK includes the Date header, the device ignores its value. <p>Notes:</p> <ul style="list-style-type: none"> ▪ This feature is applicable only to Tel-to-IP calls. ▪ For IP-to-Tel calls, this parameter is not applicable. Only if the incoming ISDN Connect message contains the Date / Time IE does the device add the Date header to the sent SIP 200 OK message.
Web/EMS: Min Routing Overlap Digits [MinOverlapDigitsForRouting]	Defines the minimum number of overlap digits to collect (for ISDN overlap dialing) before sending the first SIP message for routing Tel-to-IP calls. The valid value range is 0 to 49. The default is 1. <p>Note: This parameter is applicable when the ISDNRxOverlap parameter is set to [2].</p>
Web/EMS: ISDN Overlap IP to Tel Dialing [ISDNtxOverlap]	Enables ISDN overlap dialing for IP-to-Tel calls. This feature is part of ISDN-to-SIP overlap dialing according to RFC 3578. <ul style="list-style-type: none"> ▪ [0] Disable (default) ▪ [1] Enable When enabled, for each received INVITE of the same dialog session, the device sends an ISDN Setup (and subsequent ISDN Info Q.931 messages) with the collected digits to the Tel side. For all subsequent INVITEs received, the device sends a SIP 484 Address Incomplete response in order to maintain the current dialog session and receive additional digits from subsequent INVITEs. <p>Note: When IP-to-Tel overlap dialing is enabled, to send ISDN Setup messages without the Sending Complete IE, the ISDNOutCallsBehavior parameter must be set to USER SENDING COMPLETE (2).</p>
Web: Enable Receiving of Overlap Dialing	Determines the receiving (Rx) type of ISDN overlap dialing for Tel-to-IP calls, per trunk.

Parameter	Description
[ISDNRxOverlap_x]	<ul style="list-style-type: none"> ▪ [0] None = (Default) Disabled. ▪ [1] Local receiving = ISDN Overlap Dialing - the complete number is sent in the INVITE Request-URI user part. The device receives ISDN called number that is sent in the 'Overlap' mode. The ISDN Setup message is sent to IP only after the number (including the Sending Complete IE) is fully received (via Setup and/or subsequent Info Q.931 messages). In other words, the device waits until it has received all the ISDN signaling messages containing parts of the called number, and only then it sends a SIP INVITE with the entire called number in the Request-URI. ▪ [2] Through SIP = Interworking of ISDN Overlap Dialing to SIP, based on RFC 3578. The device interworks ISDN to SIP by sending digits each time they are received (from Setup and subsequent Info Q.931 messages) to the IP, using subsequent SIP INVITE messages. <p>Notes:</p> <ul style="list-style-type: none"> ▪ When option [2] is configured, you can define the minimum number of overlap digits to collect before sending the first SIP message for routing the call, using the MinOverlapDigitsForRouting parameter. ▪ When option [2] is configured, even if SIP 4xx responses are received during this ISDN overlap receiving, the device does not release the call. ▪ The MaxDigits parameter can be used to limit the length of the collected number for ISDN overlap dialing (if Sending Complete is not received). ▪ If a digit map pattern is defined (using the DigitMapping or DialPlanIndex parameters), the device collects digits until a match is found (e.g., for closed numbering schemes) or until a timer expires (e.g., for open numbering schemes). If a match is found (or the timer expires), the digit collection process is terminated even if Sending Complete is not received. ▪ For enabling ISDN overlap dialing for IP-to-Tel calls, use the ISDNTxOverlap parameter. ▪ The x in the ini file parameter name denotes the trunk number, where 0 is Trunk 1. ▪ For more information on ISDN overlap dialing, see 'ISDN Overlap Dialing' on page 288.
[ISDNRxOverlap]	Same as the description for parameter ISDNRxOverlap_x, but for all trunks.
Web/EMS: Mute DTMF In Overlap [MuteDTMFInOverlap]	<p>Enables the muting of in-band DTMF detection until the device receives the complete destination number from the ISDN (for Tel-to-IP calls). In other words, the device does not accept DTMF digits received in the voice stream from the PSTN, but only accepts digits from ISDN Info messages.</p> <ul style="list-style-type: none"> ▪ [0] Don't Mute (default). ▪ [1] Mute DTMF in Overlap Dialing = The device ignores in-band DTMF digits received during ISDN overlap dialing (disables the DTMF in-band detector). <p>Note: This parameter is applicable to ISDN Overlap mode only when dialed numbers are sent using Q.931 Information messages.</p>
[ConnectedNumberType]	Defines the Numbering Type of the ISDN Q.931 Connected Number IE that the device sends in the Connect message to the ISDN (for Tel-to-IP

Parameter	Description
	calls). This is interworked from the P-Asserted-Identity header in SIP 200 OK. The default is [0] (i.e., unknown).
[ConnectedNumberPlan]	Defines the Numbering Plan of the ISDN Q.931 Connected Number IE that the device sends in the Connect message to the ISDN (for Tel-to-IP calls). This is interworked from the P-Asserted-Identity header in SIP 200 OK. The default is [0] (i.e., unknown).
Web/EMS: Enable ISDN Tunneling Tel to IP [EnableISDNTunnelingTel2IP]	Enables ISDN Tunneling. <ul style="list-style-type: none"> ▪ [0] Disable (default). ▪ [1] Using Header = Enable ISDN Tunneling from ISDN PRI to SIP using a proprietary SIP header. ▪ [2] Using Body = Enable ISDN Tunneling from ISDN PRI to SIP using a dedicated message body. When ISDN Tunneling is enabled, the device sends all ISDN PRI messages using the correlated SIP messages. The ISDN Setup message is tunneled using SIP INVITE, all mid-call messages are tunneled using SIP INFO, and ISDN Disconnect/Release message is tunneled using SIP BYE messages. The raw data from the ISDN is inserted into a proprietary SIP header (X-ISDNTunnelingInfo) or a dedicated message body (application/isdn) in the SIP messages. Notes: <ul style="list-style-type: none"> ▪ For this feature to function, you must set the parameter ISDNDuplicateQ931BuffMode to 128 (i.e., duplicate all messages). ▪ ISDN tunneling is applicable for all ISDN variants as well as QSIG.
Web/EMS: Enable ISDN Tunneling IP to Tel [EnableISDNTunnelingIP2Tel]	Enables ISDN Tunneling for IP-to-Tel calls. <ul style="list-style-type: none"> ▪ [0] Disable (default) ▪ [1] Enable ISDN Tunneling from IP to ISDN When ISDN Tunneling is enabled, the device extracts raw data received in the proprietary SIP header, x-isdntunnelinginfo, or a dedicated message body (application/isdn) in the SIP message and then sends the data in an ISDN message to the PSTN. If the raw data in this SIP header is suffixed with the string "ADDE", then the raw data is extracted and added as Informational Elements (IE) in the outgoing Q.931 message. The tunneling of the x-isdntunnelinginfo SIP header with IEs is converted from INVITE, 180, and 200 OK SIP messages to Q.931 SETUP, ALERT, and CONNECT respectively. For example, if the following SIP header is received, <pre style="background-color: #f0f0f0; padding: 5px;">x-isdntunnelinginfo: ADDE1C269FAA 06 800100820100A10F020136 0201F0A00702010102021F69</pre> then it is added as an IE to the outgoing Q.931 message as 1C269FAA 06 800100820100A10F020136 0201F0A00702010102021F69, where, for example, "1C269F" is a 26 byte length Facility IE. Note: This feature is similar to that of the AddIEinSetup parameter. If both parameters are configured, the x-isdntunneling parameter takes precedence.
Web/EMS: Enable QSIG Tunneling [EnableQSIGTunneling]	Enables QSIG tunneling-over-SIP for all calls. This is according to IETF Internet-Draft draft-elwell-sipping-qsig-tunnel-03 and ECMA-355 and ETSI TS 102 345. <ul style="list-style-type: none"> ▪ [0] Disable (default). ▪ [1] Enable = Enable QSIG tunneling from QSIG to SIP and vice

Parameter	Description
	<p>versa. All QSIG messages are sent as raw data in corresponding SIP messages using a dedicated message body.</p> <p>Notes:</p> <ul style="list-style-type: none"> ▪ This feature can also be configured in an IP Profile. ▪ QSIG tunneling must be enabled on originating and terminating devices. ▪ To enable this function, set the <code>ISDNDuplicateQ931BuffMode</code> parameter to 128 (i.e., duplicate all messages). ▪ To define the format of encapsulated QSIG messages, use the <code>QSIGTunnelingMode</code> parameter. ▪ Tunneling according to ECMA-355 is applicable to all ISDN variants (in addition to the QSIG protocol). ▪ For more information on QSIG tunneling, see 'QSIG Tunneling' on page 284.
[QSIGTunnelingMode]	<p>Defines the format of encapsulated QSIG message data in the SIP message MIME body.</p> <ul style="list-style-type: none"> ▪ [0] = (Default) ASCII presentation of Q.931 QSIG message. ▪ [1] = Binary encoding of Q.931 QSIG message (according to ECMA-355, RFC 3204, and RFC 2025). <p>Note: This parameter is applicable only if the QSIG Tunneling feature is enabled (using the <code>EnableQSIGTunneling</code> parameter).</p>
<p>Web: Enable Hold to ISDN EMS: Enable Hold 2 ISDN [EnableHold2ISDN]</p>	<p>Enables SIP-to-ISDN interworking of the Hold/Retrieve supplementary service.</p> <ul style="list-style-type: none"> ▪ [0] Disable (default) ▪ [1] Enable <p>Notes:</p> <ul style="list-style-type: none"> ▪ This parameter is applicable to Euro ISDN variants - from TE (user) to NT (network). ▪ This parameter is applicable also to QSIG BRI. ▪ If the parameter is disabled, the device plays a held tone to the Tel side when a SIP request with 0.0.0.0 or "inactive" in SDP is received. An appropriate CPT file with the held tone should be used.
<p>EMS: Duplicate Q931 Buff Mode [ISDNDuplicateQ931BuffMode]</p>	<p>Determines the activation/deactivation of delivering raw Q.931 messages.</p> <ul style="list-style-type: none"> ▪ [0] = (Default) ISDN messages aren't duplicated. ▪ [128] = All ISDN messages are duplicated. <p>Note: For this parameter to take effect, a device reset is required.</p>
<p>Web/EMS: ISDN SubAddress Format [ISDNSubAddressFormat]</p>	<p>Determines the encoding format of the SIP Tel URI parameter 'isub', which carries the encoding type of ISDN subaddresses. This is used to identify different remote ISDN entities under the same phone number (ISDN Calling and Called numbers) for interworking between ISDN and SIP networks.</p> <ul style="list-style-type: none"> ▪ [0] = (Default) ASCII - IA5 format that allows up to 20 digits. Indicates that the 'isub' parameter value needs to be encoded using ASCII characters. ▪ [1] = BCD (Binary Coded Decimal) - allows up to 40 characters (digits and letters). Indicates that the 'isub' parameter value needs to be encoded using BCD when translated to an ISDN message. ▪ [2] = User Specified

Parameter	Description
	<p>For IP-to-Tel calls, if the incoming SIP INVITE message includes subaddress values in the 'isub' parameter for the Called Number (in the Request-URI) and/or the Calling Number (in the From header), these values are mapped to the outgoing ISDN Setup message.</p> <p>If the incoming ISDN Setup message includes 'subaddress' values for the Called Number and/or the Calling Number, these values are mapped to the outgoing SIP INVITE message's 'isub' parameter in accordance with RFC 4715.</p>
[IgnoreISDNSubaddresses]	<p>Determines whether the device ignores the Subaddress from the incoming ISDN Called and Calling numbers when sending to IP.</p> <ul style="list-style-type: none"> ▪ [0] = (Default) If an incoming ISDN Q.931 Setup message contains a Called/Calling Number Subaddress, the Subaddress is interworked to the SIP 'isub' parameter according to RFC. ▪ [1] = The device removes the ISDN Subaddress and does not include the 'isub' parameter in the Request-URI and does not process INVITEs with this parameter.
[ISUBNumberOfDigits]	<p>Defines the number of digits (from the end) that the device takes from the called number (received from the IP) for the isub number (in the sent ISDN Setup message). This feature is only applicable for IP-to-ISDN calls.</p> <p>The valid value range is 0 to 36. The default is 0.</p> <p>This feature operates as follows:</p> <ol style="list-style-type: none"> 1 If an isub parameter is received in the Request-URI, for example, INVITE sip:9565645;isub=1234@host.domain:user=phone SIP/2.0 then the isub value is sent in the ISDN Setup message as the destination subaddress. 2 If the isub parameter is not received in the user part of the Request-URI, the device searches for it in the URI parameters of the To header, for example, To: "Alex" <sip: 9565645@host.domain;isub=1234> If present, the isub value is sent in the ISDN Setup message as the destination subaddress. 3 If the isub parameter is not present in the Request-URI header nor To header, the device does the following: <ul style="list-style-type: none"> ✓ If the called number (that appears in the user part of the Request-URI) starts with zero (0), for example, INVITE sip:05694564@host.domain:user=phone SIP/2.0 then the device maps this called number to the destination number of the ISDN Setup message, and the destination subaddress in this ISDN Setup message remains empty. ✓ If the called number (that appears in the user part of the Request-URI) does not start with zero, for example, INVITE sip:5694564@host.domain:user=phone SIP/2.0 then the device maps this called number to the destination number of the ISDN Setup message, and the destination subaddress in this ISDN Setup message then contains y digits from the end of the called number. The y number of digits can be configured using the ISUBNumberOfDigits parameter. The default value of ISUBNumberOfDigits is 0, thus, if this parameter is not configured, and 1) and 2) scenarios (described above) have not provided an isub value, the subaddress remains empty.

Parameter	Description
Web: Default Cause Mapping From ISDN to SIP [DefaultCauseMapISDN2IP]	Defines a single default ISDN release cause that is used (in ISDN-to-IP calls) instead of all received release causes, except when the following Q.931 cause values are received: Normal Call Clearing (16), User Busy (17), No User Responding (18), or No Answer from User (19). The range is any valid Q.931 release cause (0 to 127). The default is 0 (i.e., not configured - static mapping is used).
Release Cause Mapping from ISDN to SIP Table	
Web: Release Cause Mapping Table EMS: ISDN to SIP Cause Mapping [CauseMapISDN2SIP]	This table parameter maps ISDN Q.850 Release Causes to SIP responses. The format of this parameter is as follows: [CauseMapISDN2SIP] FORMAT CauseMapISDN2SIP_Index = CauseMapISDN2SIP_IsdnReleaseCause, CauseMapISDN2SIP_SipResponse; [CauseMapISDN2SIP] Where, <ul style="list-style-type: none"> ▪ IsdnReleaseCause = Q.850 Release Cause ▪ SipResponse = SIP Response For example: CauseMapISDN2SIP 0 = 50,480; CauseMapISDN2SIP 0 = 6,406; When a Release Cause is received (from the PSTN side), the device searches this mapping table for a match. If the Q.850 Release Cause is found, the SIP response assigned to it is sent to the IP side. If no match is found, the default static mapping is used. Note: This parameter can appear up to 12 times.
Release Cause Mapping from SIP to ISDN Table	
Web: Release Cause Mapping Table EMS: SIP to ISDN Cause Mapping [CauseMapSIP2ISDN]	This table parameter maps SIP responses to Q.850 Release Causes. The format of this parameter is as follows: [CauseMapSIP2ISDN] FORMAT CauseMapSIP2ISDN_Index = CauseMapSIP2ISDN_SipResponse, CauseMapSIP2ISDN_IsdnReleaseCause; [CauseMapSIP2ISDN] Where, <ul style="list-style-type: none"> ▪ SipResponse = SIP Response ▪ IsdnReleaseCause = Q.850 Release Cause For example: CauseMapSIP2ISDN 0 = 480,50; CauseMapSIP2ISDN 0 = 404,3; When a SIP response is received (from the IP side), the device searches this mapping table for a match. If the SIP response is found, the Q.850 Release Cause assigned to it is sent to the PSTN. If no match is found, the default static mapping is used. Note: This parameter can appear up to 12 times.
Web/EMS: Enable Calling Party Category [EnableCallingPartyCategory]	Determines whether Calling Party Category (CPC) is mapped between SIP and PRI. <ul style="list-style-type: none"> ▪ [0] Disable = (Default) Don't relay the CPC between SIP and PRI. ▪ [1] Enable = The CPC is relayed between SIP and PRI.

Parameter	Description
	<p>If enabled, the CPC received in the Originating Line Information (OLI) IE of an incoming ISDN Setup message is relayed to the From/P-Asserted-Identity headers using the 'cpc' parameter in the outgoing INVITE message, and vice versa.</p> <p>For example (calling party is a payphone):</p> <pre>From: <sip:2000;cpc=payphone@10.8.23.70>;tag=1c1806157451</pre> <p>Note: This feature is applicable only to the NI-2 PRI variant.</p>
<p>[UserToUserHeaderFormat]</p>	<p>Defines the interworking between the SIP INVITE's User-to-User header and the ISDN User-to-User (UU) IE data.</p> <ul style="list-style-type: none"> ▪ [0] = (Default) SIP header format: X-UserToUser. ▪ [1] = SIP header format: User-to-User with Protocol Discriminator (pd) attribute (according to IETF Internet-Draft draft-johnston-sipping-cc-uu-04). For example: <pre>User-to-User=3030373435313734313635353b313233343b3834;pd=4</pre> ▪ [2] = SIP header format: User-to-User with encoding=hex at the end and pd embedded as the first byte (according to IETF Internet-Draft draft-johnston-sipping-cc-uu-03). For example: <pre>User-to-User=043030373435313734313635353b313233343b3834;encoding=hex</pre> <p>where "04" at the beginning of this message is the pd.</p> ▪ [3] = Interworks the SIP User-to-User header containing text format to ISDN UUIE in hexadecimal format, and vice versa. For example: <p>SIP Header in text format:</p> <pre>User-to-User=01800213027b712a;NULL;4582166;</pre> <p>Translated to hexadecimal in the ISDN UUIE:</p> <pre>303138303032313330323762373132613b4e554c4c3b343538323136363b</pre> <p>The Protocol Discriminator (pd) used in UUIE is "04" (IUA characters).</p> <p>Note: This parameter is applicable for Tel-to-IP and IP-to-Tel calls.</p>
<p>Web/EMS: Remove CLI when Restricted [RemoveCLIWhenRestricted]</p>	<p>Determines (for IP-to-Tel calls) whether the Calling Number and Calling Name IEs are removed from the ISDN Setup message if the presentation is set to Restricted.</p> <ul style="list-style-type: none"> ▪ [0] No = (Default) IE's are not removed. ▪ [1] Yes = IE's are removed.
<p>Web/EMS: Remove Calling Name [RemoveCallingName]</p>	<p>Enables the device to remove the Calling Name from SIP-to-ISDN calls for all trunks.</p> <ul style="list-style-type: none"> ▪ [0] Disable = (Default) Does not remove Calling Name. ▪ [1] Enable = Removes Calling Name. <p>Note: Some PSTN switches / PBXs may not be configured to support the receipt of the "Calling Name" information. These switches might respond to an ISDN Setup message (including the Calling Name) with an ISDN "REQUESTED_FAC_NOT_SUBSCRIBED" failure. This parameter can be set to Enable (1) to remove the "Calling Name" from SIP-to-ISDN calls and allow the call to proceed.</p>
<p>Web: Remove Calling Name</p>	<p>Enables the device to remove the Calling Name per trunk for SIP-to-ISDN calls.</p>

Parameter	Description
EMS: Remove Calling Name For Trunk Mode [RemoveCallingNameForTrunk_x]	<ul style="list-style-type: none"> ▪ [-1] Use Global Parameter = (Default) Settings of the global parameter RemoveCallingName are used. ▪ [0] Disable = Does not remove Calling Name. ▪ [1] Enable = Remove Calling Name. <p>Note: The x in the ini file parameter name denotes the trunk number, where 0 is Trunk 1.</p>
Web/EMS: Progress Indicator to ISDN [ProgressIndicator2ISDN_x]	<p>Determines the Progress Indicator (PI) to ISDN, per trunk.</p> <ul style="list-style-type: none"> ▪ [-1] Not Configured = (Default) The PI in ISDN messages is set according to the parameter PlayRBTone2Tel. ▪ [0] No PI = PI is not sent to ISDN. ▪ [1] PI = 1; [8] PI = 8: The PI value is sent to PSTN in Q.931/Proceeding and Alerting messages. Typically, the PSTN/PBX cuts through the audio channel without playing local ringback tone, enabling the originating party to hear remote Call Progress Tones or network announcements. <p>Note: The x in the ini file parameter name denotes the trunk number, where 0 is Trunk 1.</p>
Web: Set PI in Rx Disconnect Message EMS: Set PI For Disconnect Msg [PIForDisconnectMsg_x]	<p>Defines the device's behavior when a Disconnect message is received from the ISDN before a Connect message is received, per trunk.</p> <ul style="list-style-type: none"> ▪ [-1] Not Configured = (Default) Sends a 183 SIP response according to the received progress indicator (PI) in the ISDN Disconnect message. If PI = 1 or 8, the device sends a 183 response, enabling the PSTN to play a voice announcement to the IP side. If there isn't a PI in the Disconnect message, the call is released. ▪ [0] No PI = Doesn't send a 183 response to IP. The call is released. ▪ [1] PI = 1; [8] PI = 8: Sends a 183 response to IP. <p>Note: The x in the ini file parameter name denotes the trunk number, where 0 is Trunk 1.</p>
EMS: Connect On Progress Ind [ConnectOnProgressInd]	<p>Enables the play of announcements from IP to PSTN without the need to answer the Tel-to-IP call. It can be used with PSTN networks that don't support the opening of a TDM channel before an ISDN Connect message is received.</p> <ul style="list-style-type: none"> ▪ [0] = (Default) Connect message isn't sent after SIP 183 Session Progress message is received. ▪ [1] = Connect message is sent after SIP 183 Session Progress message is received.
Web: Local ISDN Ringback Tone Source EMS: Local ISDN RB Source [LocalISDNRBSource_x]	<p>Determines whether the ringback tone is played to the ISDN by the PBX/PSTN or by the device, per trunk.</p> <ul style="list-style-type: none"> ▪ [0] PBX = (Default) PBX/PSTN. ▪ [1] Gateway = The device plays the ringback tone. <p>Notes:</p> <ul style="list-style-type: none"> ▪ This parameter is applicable to ISDN protocols. ▪ This parameter is used together with the parameter PlayRBTone2Trunk. ▪ The x in the ini file parameter name denotes the trunk number, where 0 is Trunk 1.
Web/EMS: PSTN Alert Timeout [TrunkPSTNAlertTimeo]	<p>Defines the Alert Timeout (ISDN T301 timer) in seconds for outgoing calls to PSTN, per trunk. This timer is used between the time that an ISDN Setup message is sent to the Tel side (IP-to-Tel call</p>

Parameter	Description
ut_x]	establishment) and a Connect message is received. If Alerting is received, the timer is restarted. The range is 1 to 600. The default is 180. Note: The x in the ini file parameter name denotes the trunk number, where 0 is Trunk 1.
Web: B-Channel Negotiation EMS: B-Channel Negotiation For Trunk Mode [BChannelNegotiationForTrunk_x]	Determines the ISDN B-channel negotiation mode, per trunk. <ul style="list-style-type: none"> ▪ [-1] Not Configured = (Default) Use per device configuration of the BChannelNegotiation parameter. ▪ [0] Preferred. ▪ [1] Exclusive. ▪ [2] Any. Notes: <ul style="list-style-type: none"> ▪ This parameter is applicable to ISDN protocols. ▪ The option 'Any' is only applicable if TerminationSide is set to 0 (i.e., User side). ▪ The x in the ini file parameter name denotes the trunk number, where 0 is Trunk 1.
[SendISDNServiceAfterRestart]	Enables the device to send an ISDN SERVICE message per trunk upon device reset. The message (transmitted on the trunk's D-channel) indicates the availability of the trunk's B-channels (i.e., trunk in service). <ul style="list-style-type: none"> ▪ [0] = Disable (default) ▪ [1] = Enable
EMS: Support Redirect InFacility [SupportRedirectInFacility]	Determines whether the Redirect Number is retrieved from the Facility IE. <ul style="list-style-type: none"> ▪ [0] = (Default) Not supported. ▪ [1] = Supports partial retrieval of Redirect Number (number only) from the Facility IE in ISDN Setup messages. This is applicable to Redirect Number according to ECMA-173 Call Diversion Supplementary Services. Note: To enable this feature, the parameter ISDNDuplicateQ931BuffMode must be set to 1.
[CallReroutingMode]	Determines whether ISDN call rerouting (call forward) is performed by the PSTN instead of by the SIP side. This call forwarding is based on Call Deflection for Euro ISDN (ETS-300-207-1) and QSIG (ETSI TS 102 393). <ul style="list-style-type: none"> ▪ [0] Disable (default). ▪ [1] Enable = Enables ISDN call rerouting. When the device sends the INVITE message to the remote SIP entity and receives a SIP 302 response with a Contact header containing a URI host name that is the same as the device's IP address, the device sends a Facility message with a Call Rerouting invoke method to the ISDN and waits for the PSTN side to disconnect the call. Note: When this parameter is enabled, ensure that you configure in the Inbound IP Routing Table (PSTNPrefix <i>ini</i> file parameter) a rule to route the redirected call (using the user part from the 302 Contact header) to the same Trunk Group from where the incoming Tel-to-IP call was received.

Parameter	Description
EMS: Enable CIC [EnableCIC]	<p>Determines whether the Carrier Identification Code (CIC) is relayed to ISDN.</p> <ul style="list-style-type: none"> ▪ [0] = (Default) Do not relay the Carrier Identification Code (CIC) to ISDN. ▪ [1] = CIC is relayed to the ISDN in Transit Network Selection (TNS) IE. <p>If enabled, the CIC code (received in an INVITE Request-URI) is included in a TNS IE in the ISDN Setup message. For example: INVITE sip:555666;cic=2345@100.2.3.4 sip/2.0.</p> <p>Notes:</p> <ul style="list-style-type: none"> ▪ This feature is supported only for SIP-to-ISDN calls. ▪ The parameter AddCicAsPrefix can be used to add the CIC as a prefix to the destination phone number for routing IP-to-Tel calls.
EMS: Enable AOC [EnableAOC]	<p>Determines whether ISDN Advice of Charge (AOC) messages are interworked with SIP.</p> <ul style="list-style-type: none"> ▪ [0] = (Default) Not used. ▪ [1] = AOC messages are interworked to SIP (in receive direction) and sent to the PSTN in the transmit direction. <p>The device supports both the receipt and sending of ISDN (Euro ISDN) AOC messages:</p> <ul style="list-style-type: none"> ▪ AOC messages can be received during a call (Facility messages) or at the end of a call (Disconnect or Release messages). The device converts the AOC messages into SIP INFO (during a call) and BYE (end of a call) messages, using a proprietary AOC SIP header. The device supports both Currency and Pulse AOC messages. ▪ AOC messages can be sent during a call (Facility messages) or at the end of a call (Disconnect or Release messages). This is done by assigning the Charge Code index to the desired routing rule in the Outbound IP Routing table. For more information, see 'Advice of Charge Services for Euro ISDN' on page 387.
Web: IPMedia Detectors EMS: DSP Detectors Enable [EnableDSPIPMDetectors]	<p>Enables the device's DSP detectors.</p> <ul style="list-style-type: none"> ▪ [0] = Disable (default) ▪ [1] = Enable <p>Notes:</p> <ul style="list-style-type: none"> ▪ For this parameter to take effect, a device reset is required. ▪ The device's Software License Key must contain the 'IPMDetector' DSP option. ▪ When enabled (1), the number of available channels is reduced.
Web: Add IE in SETUP EMS: IE To Be Added In Q.931 Setup [AddIEinSetup]	<p>Adds an optional Information Element (IE) data (in hex format) to ISDN Setup messages. For example, to add IE '0x20,0x02,0x00,0xe1', enter the value "200200e1".</p> <p>Notes:</p> <ul style="list-style-type: none"> ▪ This IE is sent from the Trunk Group IDs that are defined by the parameter SendIEonTG. ▪ You can configure different IE data for Trunk Groups by defining this parameter for different IP Profiles (using the IPProfile parameter) and then assigning the required IP Profile ID in the Inbound IP Routing Table (PSTNPrefix). ▪ This feature is similar to that of the EnableISDNTunnelingIP2Tel parameter. If both parameters are configured, the

Parameter	Description
	EnableISDN TunnelingIP2Tel parameter takes precedence.
Web: Trunk Groups to Send IE EMS: List Of Trunk Groups To Send IE [SendIEonTG]	Defines Trunk Group IDs (up to 50 characters) from where the optional ISDN IE (defined by the parameter AddIEinSetup) is sent. For example: '1,2,4,10,12,6'. Notes: <ul style="list-style-type: none"> ▪ You can configure different IE data for Trunk Groups by defining this parameter for different IP Profile IDs (using the parameter IPProfile), and then assigning the required IP Profile ID in the Inbound IP Routing Table (PSTNPrefix). ▪ When IP Profiles are used for configuring different IE data for Trunk Groups, this parameter is ignored.
Web: Enable User-to-User IE for Tel to IP EMS: Enable UUI Tel 2 Ip [EnableUUITel2IP]	Enables transfer of User-to-User (UU) IE from ISDN PRI to SIP. <ul style="list-style-type: none"> ▪ [0] Disable (default) ▪ [1] Enable The device supports the following ISDN PRI-to-SIP interworking: Setup to SIP INVITE, Connect to SIP 200 OK, User Information to SIP INFO, Alerting to SIP 18x response, and Disconnect to SIP BYE response messages. Note: The interworking of ISDN User-to-User IE to SIP INFO is applicable only to the Euro ISDN, QSIG, and 4ESS PRI variants.
Web: Enable User-to-User IE for IP to Tel EMS: Enable UUI Ip 2 Tel [EnableUUIIP2Tel]	Enables interworking of SIP user-to-user information (UUI) to User-to-User IE in ISDN Q.931 messages. <ul style="list-style-type: none"> ▪ [0] Disable = (Default) Received UUI is not sent in ISDN message. ▪ [1] Enable = The device interworks UUI from SIP to ISDN messages. The device supports the following SIP-to-ISDN interworking of UUI: <ul style="list-style-type: none"> ✓ SIP INVITE to Q.931 Setup ✓ SIP REFER to Q.931 Setup ✓ SIP 200 OK to Q.931 Connect ✓ SIP INFO to Q.931 User Information ✓ SIP 18x to Q.931 Alerting ✓ SIP BYE to Q.931 Disconnect Notes: <ul style="list-style-type: none"> ▪ The interworking of ISDN User-to-User IE to SIP INFO is applicable only to the Euro ISDN, QSIG, and 4ESS PRI variants. ▪ To interwork the UUIE header from SIP-to-ISDN messages with the 4ESS ISDN variant, the ISDNGeneralCCBehavior parameter must be set to 16384.
[Enable911LocationIdIP2Tel]	Enables interworking of Emergency Location Identification from SIP to PRI. <ul style="list-style-type: none"> ▪ [0] = Disabled (default) ▪ [1] = Enabled When enabled, the From header received in the SIP INVITE is translated into the following ISDN IE's: <ul style="list-style-type: none"> ▪ Emergency Call Control. ▪ Generic Information - to carry the Location Identification Number information. ▪ Generic Information - to carry the Calling Geodetic Location information. Note: This capability is applicable only to the NI-2 ISDN variant.

Parameter	Description														
[EarlyAnswerTimeout]	<p>Defines the duration (in seconds) that the device waits for an ISDN Connect message from the called party (Tel side), started from when it sends a Setup message. If this timer expires, the call is answered by sending a SIP 200 OK message (to the IP side).</p> <p>The valid range is 0 to 2400. The default is 0 (i.e., disabled).</p> <p>Note: This parameter can be configured per IP Profile.</p>														
Web/EMS: Trunk Transfer Mode [TrunkTransferMode]	<p>Determines the trunk transfer method (for all trunks) when a SIP REFER message is received. The transfer method depends on the Trunk's PSTN protocol (configured by the parameter ProtocolType) and is applicable only when one of these protocols are used:</p> <table border="1" data-bbox="515 645 1367 1169"> <thead> <tr> <th data-bbox="515 645 837 694">PSTN Protocol</th> <th data-bbox="837 645 1367 694">Transfer Method (Described Below)</th> </tr> </thead> <tbody> <tr> <td data-bbox="515 694 837 743">E1 Euro ISDN [1]</td> <td data-bbox="837 694 1367 743">ECT [2] or InBand [5]</td> </tr> <tr> <td data-bbox="515 743 837 824">E1 QSIG [21], T1 QSIG [23]</td> <td data-bbox="837 743 1367 824">Single Step Transfer [4], Path Replacement Transfer [2], or InBand [5]</td> </tr> <tr> <td data-bbox="515 824 837 936">T1 NI2 ISDN [10], T1 4ESS ISDN [11], T1 5ESS 9 ISDN [12]</td> <td data-bbox="837 824 1367 936">TBCT [2] or InBand [5]</td> </tr> <tr> <td data-bbox="515 936 837 981">T1 DMS-100 ISDN [14]</td> <td data-bbox="837 936 1367 981">RTL [2] or InBand [5]</td> </tr> <tr> <td data-bbox="515 981 837 1093">T1 RAW CAS [3], T1 CAS [2], E1 CAS [8], E1 RAW CAS [9]</td> <td data-bbox="837 981 1367 1093">[1] CAS NFA DMS-100 or [3] CAS Normal transfer</td> </tr> <tr> <td data-bbox="515 1093 837 1169">T1 DMS-100 Meridian ISDN [35]</td> <td data-bbox="837 1093 1367 1169">RTL [2] or InBand [5]</td> </tr> </tbody> </table> <p>The valid values of this parameter are described below:</p> <ul style="list-style-type: none"> ▪ [0] = Not supported (default). ▪ [1] = Supports CAS NFA DMS-100 transfer. When a SIP REFER message is received, the device performs a Blind Transfer by executing a CAS Wink, waits for an acknowledged Wink from the remote side, dials the Refer-to number to the switch, and then releases the call. Note: A specific NFA CAS table is required. ▪ [2] = Supports ISDN (PRI/BRI) transfer - Release Link Trunk (RLT) (DMS-100), Two B Channel Transfer (TBCT) (NI2), Explicit Call Transfer (ECT) (EURO ISDN), and Path Replacement (QSIG). When a SIP REFER message is received, the device performs a transfer by sending Facility messages to the PBX with the necessary information on the call's legs to be connected. The different ISDN variants use slightly different methods (using Facility messages) to perform the transfer. Notes: <ul style="list-style-type: none"> ✓ For RLT ISDN transfer, the parameter SendISDNTransferOnConnect must be set to 1. ✓ The parameter SendISDNTransferOnConnect can be used to define if the TBCT/ECT transfer is performed after receipt of Alerting or Connect messages. For RLT, the transfer is always done after receipt of Connect (SendISDNTransferOnConnect is set to 1). ✓ This transfer can be performed between B-channels from 	PSTN Protocol	Transfer Method (Described Below)	E1 Euro ISDN [1]	ECT [2] or InBand [5]	E1 QSIG [21], T1 QSIG [23]	Single Step Transfer [4], Path Replacement Transfer [2], or InBand [5]	T1 NI2 ISDN [10], T1 4ESS ISDN [11], T1 5ESS 9 ISDN [12]	TBCT [2] or InBand [5]	T1 DMS-100 ISDN [14]	RTL [2] or InBand [5]	T1 RAW CAS [3], T1 CAS [2], E1 CAS [8], E1 RAW CAS [9]	[1] CAS NFA DMS-100 or [3] CAS Normal transfer	T1 DMS-100 Meridian ISDN [35]	RTL [2] or InBand [5]
PSTN Protocol	Transfer Method (Described Below)														
E1 Euro ISDN [1]	ECT [2] or InBand [5]														
E1 QSIG [21], T1 QSIG [23]	Single Step Transfer [4], Path Replacement Transfer [2], or InBand [5]														
T1 NI2 ISDN [10], T1 4ESS ISDN [11], T1 5ESS 9 ISDN [12]	TBCT [2] or InBand [5]														
T1 DMS-100 ISDN [14]	RTL [2] or InBand [5]														
T1 RAW CAS [3], T1 CAS [2], E1 CAS [8], E1 RAW CAS [9]	[1] CAS NFA DMS-100 or [3] CAS Normal transfer														
T1 DMS-100 Meridian ISDN [35]	RTL [2] or InBand [5]														

Parameter	Description
	<p>different trunks or Trunk Groups, by using the parameter EnableTransferAcrossTrunkGroups.</p> <ul style="list-style-type: none"> ✓ The device initiates the ECT process after receiving a SIP REFER message only for trunks that are configured to User side. ▪ [3] = Supports CAS Normal transfer. When a SIP REFER message is received, the device performs a Blind Transfer by executing a CAS Wink, dialing the Refer-to number to the switch, and then releasing the call. ▪ [4] = Supports QSIG Single Step transfer (PRI/BRI): <ul style="list-style-type: none"> IP-to-Tel: When a SIP REFER message is received, the device performs a transfer by sending a Facility message to the PBX, initiating Single Step transfer. Once a success return result is received, the transfer is completed. Tel-to-IP: When a Facility message initiating Single Step transfer is received from the PBX, a SIP REFER message is sent to the IP side. ▪ [5] = IP-to-Tel Blind Transfer mode supported for ISDN (PRI/BRI) protocols and implemented according to AT&T Toll Free Transfer Connect Service (TR 50075) "Courtesy Transfer-Human-No Data". When the device receives a SIP REFER message, it performs a blind transfer by first dialing the DTMF digits (transfer prefix) defined by the parameter XferPrefixIP2Tel (configured to "*8" for AT&T service), and then (after 500 msec) the device dials the DTMF of the number (referred) from the Refer-To header sip:URI userpart. If the hostpart of the Refer-To sip:URI contains the device's IP address, and if the Trunk Group selected according to the IP to Tel Routing table is the same Trunk Group as the original call, then the device performs the in-band DTMF transfer; otherwise, the device sends the INVITE according to regular transfer rules. After completing the in-band transfer, the device waits for the ISDN Disconnect message. If the Disconnect message is received during the first 5 seconds, the device sends a SIP NOTIFY with 200 OK message; otherwise, the device sends a NOTIFY with 4xx message. ▪ [6] = Supports AT&T toll free out-of-band blind transfer for trunks configured with the 4ESS ISDN protocol. AT&T courtesy transfer is a supplementary service which enables a user (e.g., user "A") to transform an established call between it and user "B" into a new call between users "B" and "C", whereby user "A" does not have a call established with user "C" prior to call transfer. The device handles this feature as follows: <ul style="list-style-type: none"> ✓ IP-to-Tel (user side): When a SIP REFER message is received, the device initiates a transfer by sending a Facility message to the PBX. ✓ Tel-to-IP (network side): When a Facility message initiating an out-of-band blind transfer is received from the PBX, the device sends a SIP REFER message to the IP side (if the EnableNetworkISDNTransfer parameter is set to 1). <p>Note: For configuring trunk transfer mode per trunk, use the parameter TrunkTransferMode_x.</p>
[TrunkTransferMode_x]	Determines the trunk transfer mode per trunk (where x is the Trunk ID). For configuring trunk transfer mode for all trunks and for a description of the parameter options, refer to the parameter TrunkTransferMode.
[EnableTransferAcrossTrunkGroups]	Determines whether the device allows ISDN ECT, RLT or TBCT IP-to-Tel call transfers between B-channels of different Trunk Groups.

Parameter	Description
	<ul style="list-style-type: none"> ▪ [0] = (Default) Disable - ISDN call transfer is only between B-channels of the same Trunk Group. ▪ [1] = Enable - the device performs ISDN transfer between any two PSTN calls (between any Trunk Group) handled by the device. <p>Note: The ISDN transfer also requires that you configure the parameter TrunkTransferMode_x to 2.</p>
Web: ISDN Transfer Capabilities EMS: Transfer Capability To ISDN [ISDNTransferCapability_x]	Defines the IP-to-ISDN Transfer Capability of the Bearer Capability IE in ISDN Setup messages, per trunk. <ul style="list-style-type: none"> ▪ [-1] Not Configured ▪ [0] Audio 3.1 (default) ▪ [1] Speech ▪ [2] Data <p>Notes:</p> <ul style="list-style-type: none"> ▪ If this parameter is not configured or is set to -1, Audio 3.1 capability is used. ▪ The Audio 7 option is currently not supported. ▪ The x in the ini file parameter name denotes the trunk number, where 0 is Trunk 1.
[TransferCapabilityForDataCalls]	Defines the ISDN Transfer Capability for data calls. <ul style="list-style-type: none"> ▪ [0] = (Default) ISDN Transfer Capability for data calls is 64k unrestricted (data). ▪ [1] = ISDN Transfer Capability for data calls is determined according to the ISDNTransferCapability parameter.
Web: ISDN Transfer On Connect EMS: Send ISDN Transfer On Connect [SendISDNTransferOnConnect]	This parameter is used for the ECT/TBCT/RLT/Path Replacement ISDN transfer methods. Usually, the device requests the PBX to connect an incoming and outgoing call. This parameter determines if the outgoing call (from the device to the PBX) must be connected before the transfer is initiated. <ul style="list-style-type: none"> ▪ [0] Alert = (Default) Enables ISDN Transfer if the outgoing call is in Alerting or Connect state. ▪ [1] Connect = Enables ISDN Transfer only if the outgoing call is in Connect state. <p>Note: For RLT ISDN transfer (TrunkTransferMode = 2 and ProtocolType = 14 DMS-100), this parameter must be set to 1.</p>
[ISDNTransferCompleteTimeout]	Defines the timeout (in seconds) for determining ISDN call transfer (ECT, RLT, or TBCT) failure. If the device does not receive any response to an ISDN transfer attempt within this user-defined time, the device identifies this as an ISDN transfer failure and subsequently performs a hairpin TDM connection or sends a SIP NOTIFY message with a SIP 603 response (depending whether hairpin is enabled or disabled, using the parameter DisableFallbackTransferToTDM). The valid range is 1 to 10. The default is 4.
Web/EMS: Enable Network ISDN Transfer [EnableNetworkISDNTransfer]	Determines whether the device allows interworking of network-side received ECT/TBCT Facility messages (NI2 TBCT - Two B-channel Transfer and ETSI ECT - Explicit Call Transfer) to SIP REFER. <ul style="list-style-type: none"> ▪ [0] Disable = Rejects ISDN transfer requests. ▪ [1] Enable = (Default) The device sends a SIP REFER message to the remote call party if ECT/TBCT Facility messages are received from the ISDN side (e.g., from a PBX).

Parameter	Description
[DisableFallbackTransferToTDM]	Enables "hairpin" TDM transfer upon ISDN (ECT, RLT, or TBCT) call transfer failure. When this feature is enabled and an ISDN call transfer failure occurs, the device sends a SIP NOTIFY message with a SIP 603 Decline response. <ul style="list-style-type: none"> ▪ [0] = (Default) The device performs a hairpin TDM transfer upon ISDN call transfer. ▪ [1] = Hairpin TDM transfer is disabled.
Web: Enable QSIG Transfer Update [EnableQSIGTransferUpdate]	Determines whether the device interworks QSIG Facility messages with CallTransferComplete or CallTransferUpdate invoke application protocol data units (APDU) to SIP UPDATE messages with P-Asserted-Identity and optional Privacy headers. This feature is supported for IP-to-Tel and Tel-to-IP calls. <ul style="list-style-type: none"> ▪ [0] Disable = (Default) Ignores QSIG Facility messages with CallTransferComplete or CallTransferUpdate invokes. ▪ [1] Enable For example, assume A and C are PBX call parties and B is the SIP IP phone: <ol style="list-style-type: none"> 1 A calls B; B answers the call. 2 A places B on hold and calls C; C answers the call. 3 A performs a call transfer (the transfer is done internally by the PBX); B and C are connected to one another. In the above example, the PBX updates B that it is now talking with C. The PBX updates this by sending a QSIG Facility message with CallTransferComplete invoke APDU. The device interworks this message to a SIP UPDATE message containing a P-Asserted-Identity header with the number and name derived from the QSIG CallTransferComplete RedirectionNumber and RedirectionName. Notes: <ul style="list-style-type: none"> ▪ For IP-to-Tel calls, the RedirectionNumber and RedirectionName in the CallTransferComplete invoke is derived from the P-Asserted-Identity and Privacy headers in the received SIP INFO message. ▪ To include the P-Asserted-Identity header in outgoing SIP UPDATE messages, set the AssertedIDMode parameter to Add P-Asserted-Identity.
EMS: CAS Detection Of Hook Flash [CASSendHookFlash]	Enables sending Wink signal toward CAS trunks. <ul style="list-style-type: none"> ▪ [0] = Disable (default) ▪ [1] = Enable If the device receives a mid-call SIP INFO message with flashhook event body (as shown below) and this parameter is set to 1, the device generates a wink signal toward the CAS trunk. The CAS wink signal is done by changing the A bit from 1 to 0, and then back to 1 for 450 msec. <pre style="background-color: #f0f0f0; padding: 5px;"> INFO sip:4505656002@192.168.13.40:5060 SIP/2.0 Via: SIP/2.0/UDP 192.168.13.2:5060 From: <sip:06@192.168.13.2:5060> To: <sip:4505656002@192.168.13.40:5060>;tag=132878796-1040067870294 Call-ID: 0010-0016-D69A7DA8-1@192.168.13.2 CSeq:2 INFO Content-Type: application/broadsoft Content-Length: 17 </pre>

Parameter	Description
	event flashhook Note: This parameter is applicable only to T1 CAS protocols.

52.11.8 Answer and Disconnect Supervision Parameters

The answer and disconnect supervision parameters are described in the table below.

Answer and Disconnect Parameters

Parameter	Description
Web: Answer Supervision EMS: Enable Voice Detection [EnableVoiceDetection]	<p>Enables the sending of SIP 200 OK upon detection of speech, fax, or modem.</p> <ul style="list-style-type: none"> [1] Yes = The device sends a SIP 200 OK (in response to an INVITE message) when speech, fax, or modem is detected from the Tel side. [0] No = (Default) The device sends a SIP 200 OK only after it completes dialing to the Tel side. <p>Typically, this feature is used only when early media (enabled using the EnableEarlyMedia parameter) is used to establish the voice path before the call is answered.</p> <p>Notes:</p> <ul style="list-style-type: none"> FXO interfaces: This feature is applicable only to one-stage dialing (FXO). Digital interfaces: To activate this feature, set the EnableDSPIPMDetectors parameter to 1. Digital interfaces: This feature is applicable only when the protocol type is CAS.
Web/EMS: Max Call Duration (min) [MaxCallDuration]	<p>Defines the maximum duration (in minutes) of a call. If this duration is reached, the device terminates the call. This feature is useful for ensuring available resources for new calls, by ensuring calls are properly terminated.</p> <p>The valid range is 0 to 35,791. The default is 0 (i.e., no limitation).</p>
[MinCallDuration]	<p>Defines the minimum call duration (in seconds) for the Tel side. If an established call is terminated by the IP side before this duration expires, the device terminates the call with the IP side, but delays the termination toward the Tel side until this timeout expires.</p> <p>The valid value range is 0 to 10 seconds, where 0 (default) disables this feature.</p> <p>For example: assume the minimum call duration is set to 10 seconds and an IP phone hangs up a call established with a BRI phone after 2 seconds. As the call duration is less than the minimum call duration, the device does not disconnect the call on the Tel side. However, it sends a SIP 200 OK immediately upon receipt of the BYE to disconnect from the IP phone. The call is disconnected from the Tel side only when the call duration is greater than or equal to the minimum call duration.</p> <p>Notes:</p> <ul style="list-style-type: none"> This parameter is applicable to IP-to-Tel and Tel-to-IP calls. This parameter is applicable only to ISDN and CAS protocols.

Parameter	Description
Web/EMS: Disconnect on Dial Tone [DisconnectOnDialTone]	Determines whether the device disconnects a call when a dial tone is detected from the PBX. <ul style="list-style-type: none"> ▪ [0] Disable = (Default) Call is not released. ▪ [1] Enable = Call is released if a dial tone is detected on the device's FXO port. Notes: <ul style="list-style-type: none"> ▪ This parameter is applicable only to FXO interfaces. ▪ This option is in addition to the mechanism that disconnects a call when either busy or reorder tones are detected.
Web: Send Digit Pattern on Connect EMS: Connect Code [TelConnectCode]	Defines a digit pattern to send to the Tel side after a SIP 200 OK is received from the IP side. The digit pattern is a user-defined DTMF sequence that is used to indicate an answer signal (e.g., for billing). The valid range is 1 to 8 characters. Note: This parameter is applicable to FXO/CAS.
Web: Disconnect on Broken Connection EMS: Disconnect Calls on Broken Connection [DisconnectOnBrokenConnection]	Determines whether the device releases the call if RTP packets are not received within a user-defined timeout. <ul style="list-style-type: none"> ▪ [0] No ▪ [1] Yes (default) Notes: <ul style="list-style-type: none"> ▪ The timeout is configured by the BrokenConnectionEventTimeout parameter. ▪ This feature is applicable only if the RTP session is used without Silence Compression. If Silence Compression is enabled, the device doesn't detect a broken RTP connection. ▪ During a call, if the source IP address (from where the RTP packets are received) is changed without notifying the device, the device filters these RTP packets. To overcome this, set the DisconnectOnBrokenConnection parameter to 0; the device doesn't detect RTP packets arriving from the original source IP address and switches (after 300 msec) to the RTP packets arriving from the new source IP address. ▪ This parameter can also be configured in an IP Profile.
Web: Broken Connection Timeout EMS: Broken Connection Event Timeout [BrokenConnectionEventTimeout]	Defines the time period (in 100-msec units) after which a call is disconnected if an RTP packet is not received. The valid range is from 3 (i.e., 300 msec) to an unlimited value (e.g., 20 hours). The default is 100 (i.e., 10000 msec or 10 seconds). Notes: <ul style="list-style-type: none"> ▪ This parameter is applicable only if the parameter DisconnectOnBrokenConnection is set to 1. ▪ Currently, this feature functions only if Silence Suppression is disabled.
Web: Disconnect Call on Silence Detection EMS: Disconnect On Detection Of Silence [EnableSilenceDisconnect]	Determines whether calls are disconnected after detection of silence. <ul style="list-style-type: none"> ▪ [1] Yes = The device disconnects calls in which silence occurs (in both call directions) for more than a user-defined time. ▪ [0] No = (Default) Call is not disconnected when silence is detected. The silence duration can be configured by the FarEndDisconnectSilencePeriod parameter (default 120). Note: To activate this feature, set the parameters EnableSilenceCompression and FarEndDisconnectSilenceMethod to 1.
Web: Silence Detection	Defines the duration of the silence period (in seconds) after which the

Parameter	Description
Period [sec] EMS: Silence Detection Time Out [FarEndDisconnectSilencePeriod]	call is disconnected. The range is 10 to 28,800 (i.e., 8 hours). The default is 120 seconds. Note: For this parameter to take effect, a device reset is required.
Web: Silence Detection Method [FarEndDisconnectSilenceMethod]	Determines the silence detection method. <ul style="list-style-type: none"> [0] None = Silence detection option is disabled. [1] Packets Count = According to packet count. Note: For this parameter to take effect, a device reset is required.
[FarEndDisconnectSilenceThreshold]	Defines the threshold of the packet count (in percentages) below which is considered silence by the device. The valid range is 1 to 100%. The default is 8%. Notes: <ul style="list-style-type: none"> This parameter is applicable only if silence is detected according to packet count (FarEndDisconnectSilenceMethod is set to 1). For this parameter to take effect, a device reset is required.
[BrokenConnectionDuringSilence]	Enables the generation of the BrokenConnection event during a silence period if the channel's NoOp feature is enabled (using the parameter NoOpEnable) and if the channel stops receiving NoOp RTP packets. <ul style="list-style-type: none"> [0] Disable (default) [1] Enable
Web: Trunk Alarm Call Disconnect Timeout [TrunkAlarmCallDisconnectTimeout]	Defines the duration (in seconds) to wait after an E1/T1 trunk "Red" alarm (LOS / LOF) is raised, before the device disconnects the SIP call. If this timeout expires and the alarm is still raised, the device sends a SIP BYE message to terminate the call. If the alarm is cleared before this timeout expires, the call is not terminated, but continues as normal. The range is 1 to 3600. The default is 0 (20 for E1 and 40 for T1).
Web: Disconnect Call on Busy Tone Detection (ISDN) EMS: Isdn Disconnect On Busy Tone [ISDNDisconnectOnBusyTone]	Determines whether a call is disconnected upon detection of a busy tone (for ISDN). <ul style="list-style-type: none"> [0] Disable = (Default) Do not disconnect call upon detection of busy tone. [1] Enable = Disconnect call upon detection of busy tone. Notes: <ul style="list-style-type: none"> This parameter is applicable only to ISDN protocols. IP-to-ISDN calls are disconnected on detection of SIT tones only in call alert state. If the call is in connected state, the SIT does not disconnect the calls. Detection of busy or reorder tones disconnects the IP-to-ISDN calls also in call connected state. For IP-to-CAS calls, detection of busy, reorder, or SIT tones disconnect the calls in any call state.
Web: Disconnect Call on Busy Tone Detection (CAS) EMS: Disconnect On Detection End Tones [DisconnectOnBusyTone]	Determines whether a call is disconnected upon detection of a busy tone. <ul style="list-style-type: none"> [0] Disable = Call is not disconnected upon detection of a busy tone. [1] Enable = (Default) Call is released upon detection of busy or reorder (fast busy) tone. Notes: <ul style="list-style-type: none"> Digital interfaces: This parameter is applicable only to CAS protocols.

Parameter	Description
	<ul style="list-style-type: none"> ▪ Analog interfaces: This parameter is applicable only to FXO interfaces. ▪ This parameter is also applicable to the IP-to-IP application. ▪ This parameter can also be configured in a Tel Profile.
Polarity (Current) Reversal for Call Release (Analog Interfaces) Parameters	
[SetDefaultLinePolarity State]	<p>Defines the FXO line polarity, required for DID signaling.</p> <ul style="list-style-type: none"> ▪ [0] = Positive line polarity ▪ [1] = Negative line polarity ▪ [2] = (Default) Auto - The device detects the polarity upon power-up or upon insertion of the RJ-11 cable, and uses it as a reference polarity. <p>Typically, if the RJ-11 cabling is connected correctly (without crossing, Tip to Tip, Ring to Ring), the Tip line is positive compared to the Ring line. In this case, set this parameter to 0. With this configuration, the device assumes that the idle line polarity is Tip line positive.</p> <p>When the device receives a SIP INVITE, it checks the FXO line polarity. If the polarity is "Reversed", it skips this FXO line and goes to the next line.</p> <p>Notes:</p> <ul style="list-style-type: none"> ▪ To take advantage of this new feature, configure all FXO lines as a single Trunk Group with ascending or descending channel select mode, and configure routing rules to route incoming INVITE messages to this Trunk Group. ▪ This parameter is applicable only to FXO interfaces.
Web: Enable Polarity Reversal EMS: Enable Reversal Polarity [EnableReversalPolarity]	<p>Enables the polarity reversal feature for call release.</p> <ul style="list-style-type: none"> ▪ [0] Disable = (Default) Disable the polarity reversal service. ▪ [1] Enable = Enable the polarity reversal service. <p>If the polarity reversal service is enabled, the FXS interface changes the line polarity on call answer and then changes it back on call release. The FXO interface sends a 200 OK response when polarity reversal signal is detected (applicable only to one-stage dialing) and releases a call when a second polarity reversal signal is detected.</p> <p>Note: This parameter can also be configured in a Tel Profile.</p>
Web/EMS: Enable Current Disconnect [EnableCurrentDisconnect]	<p>Enables call release upon detection of a Current Disconnect signal.</p> <ul style="list-style-type: none"> ▪ [0] Disable = (Default) Disable the current disconnect service. ▪ [1] Enable = Enable the current disconnect service. <p>If the current disconnect service is enabled:</p> <ul style="list-style-type: none"> ▪ The FXO releases a call when a current disconnect signal is detected on its port. ▪ The FXS interface generates a 'Current Disconnect Pulse' after a call is released from IP. <p>The current disconnect duration is configured by the CurrentDisconnectDuration parameter. The current disconnect threshold (FXO only) is configured by the CurrentDisconnectDefaultThreshold parameter. The frequency at which the analog line voltage is sampled is configured by the TimeToSampleAnalogLineVoltage parameter.</p> <p>Note: This parameter can also be configured in a Tel Profile.</p>
EMS: Polarity Reversal Type	Defines the voltage change slope during polarity reversal or wink.

Parameter	Description
[PolarityReversalType]	<ul style="list-style-type: none"> ▪ [0] = (Default) Soft reverse polarity. ▪ [1] = Hard reverse polarity. <p>Notes:</p> <ul style="list-style-type: none"> ▪ This parameter is applicable only to FXS interfaces. ▪ Some Caller ID signals use reversal polarity and/or Wink signals. In these cases, it is recommended to set the parameter <code>PolarityReversalType</code> to 1 (Hard). ▪ For this parameter to take effect, a device reset is required.
EMS: Current Disconnect Duration [CurrentDisconnectDuration]	<p>Defines the duration (in msec) of the current disconnect pulse. The range is 200 to 1500. The default is 900.</p> <p>Notes:</p> <ul style="list-style-type: none"> ▪ This parameter is applicable for FXS and FXO interfaces. ▪ The FXO interface detection window is 100 msec below the parameter's value and 350 msec above the parameter's value. For example, if this parameter is set to 400 msec, then the detection window is 300 to 750 msec. ▪ For this parameter to take effect, a device reset is required.
[CurrentDisconnectDefaultThreshold]	<p>Defines the line voltage threshold at which a current disconnect detection is considered.</p> <p>The valid range is 0 to 20 Volts. The default is 4 Volts.</p> <p>Notes:</p> <ul style="list-style-type: none"> ▪ This parameter is applicable only to FXO interfaces. ▪ For this parameter to take effect, a device reset is required.
[TimeToSampleAnalogLineVoltage]	<p>Defines the frequency at which the analog line voltage is sampled (after offhook), for detection of the current disconnect threshold.</p> <p>The valid range is 100 to 2500 msec. The default is 1000 msec.</p> <p>Notes:</p> <ul style="list-style-type: none"> ▪ This parameter is applicable only to FXO interfaces. ▪ For this parameter to take effect, a device reset is required.

52.11.9 Tone Parameters

This subsection describes the device's tone parameters.

52.11.9.1 Telephony Tone Parameters

The telephony tone parameters are described in the table below.

Tone Parameters

Parameter	Description
[EnableMOH]	<p>Enables the option for using an external audio source that is connected to the device's AUDIO connector (on the CPU module). When enabled, the device uses the incoming audio from this connector instead of playing the held tone defined in the Call Progress Tones (CPT) file.</p> <ul style="list-style-type: none"> ▪ [0] = (Default) Disable ▪ [1] = Enable

Parameter	Description
	<p>Note: EnableHold must be set to 1 to enable this feature.</p>
<p>[PlayHeldToneForIP2IP]</p>	<p>Enables playing a held tone to an IP-to-IP leg instead of placing it on hold.</p> <ul style="list-style-type: none"> ▪ [0] = (Default) Disabled. The device interworks the re-INVITE with 'a=inactive' from one SIP leg to another SIP leg. ▪ [1] = Enabled. The device plays a held tone to the IP if it receives a re-INVITE with 'a=inactive' in the SDP from the party initiating the call hold. The held tone must be configured in the CPT or PRT file. <p>Note: This parameter is applicable only to the IP-to-IP application.</p>
<p>Web: SIP Hold Behavior [SIPHoldBehavior]</p>	<p>Enables the device to handle incoming re-INVITE messages with the "a=sendonly" attribute in the SDP, in the same way as if an "a=inactive" is received in the SDP. When enabled, the device plays a held tone to the Tel phone and responds with a SIP 200 OK containing the "a=recvonly" attribute in the SDP.</p> <ul style="list-style-type: none"> ▪ [0] Disable (default) ▪ [1] Enable
<p>Web/EMS: Dial Tone Duration [sec] [TimeForDialTone]</p>	<p>Defines the duration (in seconds) that the dial tone is played (for digital interfaces, to an ISDN terminal).</p> <p>For digital interfaces: This parameter is applicable for overlap dialing when ISDNInCallsBehavior is set to 65536. The dial tone is played if the ISDN Setup message doesn't include the called number.</p> <p>The valid range is 0 to 60. The default is 5.</p> <p>For analog interfaces: FXS interfaces play the dial tone after the phone is picked up (off-hook). FXO interfaces play the dial tone after the port is seized in response to ringing (from PBX/PSTN). The valid range is 0 to 60. The default time is 16.</p> <p>Notes for analog interfaces:</p> <ul style="list-style-type: none"> ▪ During play of dial tone, the device waits for DTMF digits. ▪ This parameter is not applicable when Automatic Dialing is enabled.
<p>Web/EMS: Stutter Tone Duration [StutterToneDuration]</p>	<p>Defines the duration (in msec) of the confirmation tone. A stutter tone is played (instead of a regular dial tone) when a Message Waiting Indication (MWI) is received. The stutter tone is composed of a confirmation tone (Tone Type #8), which is played for the defined duration (StutterToneDuration) followed by a stutter dial tone (Tone Type #15). Both these tones are defined in the CPT file.</p> <p>The range is 1,000 to 60,000. The default is 2,000 (i.e., 2 seconds).</p> <p>Notes:</p> <ul style="list-style-type: none"> ▪ This parameter is applicable only to FXS interfaces. ▪ If you want to configure the duration of the confirmation tone to longer than 16 seconds, you must increase the value of the parameter TimeForDialTone accordingly. ▪ The MWI tone takes precedence over the call forwarding reminder tone. For more information on MWI, see Message Waiting Indication on page 357.
<p>Web: FXO AutoDial Play</p>	<p>Determines whether the device plays a busy / reorder tone to the</p>

Parameter	Description
BusyTone EMS: Auto Dial Play Busy Tone [FXOAutoDialPlayBusyTone]	PSTN side if a Tel-to-IP call is rejected by a SIP error response (4xx, 5xx or 6xx). If a SIP error response is received, the device seizes the line (off-hook), and then plays a busy / reorder tone to the PSTN side (for the duration defined by the parameter TimeForReorderTone). After playing the tone, the line is released (on-hook). <ul style="list-style-type: none"> ▪ [0] = Disable (default) ▪ [1] = Enable Note: This parameter is applicable only to FXO interfaces.
Web: Hotline Dial Tone Duration EMS: Hot Line Tone Duration [HotLineToneDuration]	Defines the duration (in seconds) of the hotline dial tone. If no digits are received during this duration, the device initiates a call to a user-defined number (configured in the Automatic Dialing table - TargetOfChannel - see Configuring Automatic Dialing on page 394). The valid range is 0 to 60. The default is 16. Notes: <ul style="list-style-type: none"> ▪ This parameter is applicable to FXS and FXO interfaces. ▪ You can define the Hotline duration per FXS/FXO port using the Automatic Dialing table.
Web/EMS: Reorder Tone Duration [sec] [TimeForReorderTone]	For analog interfaces: Defines the duration (in seconds) that the device plays a busy or reorder tone before releasing the line. Typically, after playing the busy or reorder tone for this duration, the device starts playing an offhook warning tone. For digital interfaces: Defines the duration (in seconds) that the CAS device plays a busy or reorder tone before releasing the line. The valid range is 0 to 254. The default is 0 seconds for analog interfaces and 10 seconds for digital interfaces. Note that the Web interface denotes the default value (for analog and digital interfaces) as a string value of "255". Notes: <ul style="list-style-type: none"> ▪ The selected busy or reorder tone is according to the SIP release cause code received from IP. ▪ This parameter is also applicable for ISDN when the PlayBusyTone2ISDN parameter is set to 2. ▪ This parameter can also be configured in a Tel Profile.
Web: Time Before Reorder Tone [sec] EMS: Time For Reorder Tone [TimeBeforeReorderTone]	Defines the delay interval (in seconds) from when the device receives a SIP BYE message (i.e., remote party terminates call) until the device starts playing a reorder tone to the FXS phone. The valid range is 0 to 60. The default is 0. Note: This parameter is applicable only to FXS interfaces.
Web: Cut Through Reorder Tone Duration [sec] [CutThroughTimeForReOrderTone]	Defines the duration (in seconds) of the reorder tone played to the PSTN side after the IP call party releases the call, for the Cut-Through feature. After the tone stops playing, an incoming call is immediately answered if the FXS is off-hooked (for analog interfaces) or the PSTN is connected (for digital interfaces). The valid values are 0 to 30. The default is 0 (i.e., no reorder tone is played). Note: To enable the Cut-Through feature, use the DigitalCutThrough (for CAS channels) or CutThrough (for FXS channels) parameters.

Parameter	Description
Web/EMS: Enable Comfort Tone [EnableComfortTone]	Determines whether the device plays a comfort tone (Tone Type #18) to the FXS/FXO endpoint after a SIP INVITE is sent and before a SIP 18x response is received. <ul style="list-style-type: none"> ▪ [0] Disable (default) ▪ [1] Enable Note: This parameter is applicable to FXS and FXO interfaces.
[WarningToneDuration]	Defines the duration (in seconds) for which the offhook warning tone is played to the user. The valid range is -1 to 2,147,483,647. The default is 600. Notes: <ul style="list-style-type: none"> ▪ A negative value indicates that the tone is played infinitely. ▪ This parameter is applicable only to analog interfaces.
Web: Play Busy Tone to Tel [PlayBusyTone2ISDN]	Enables the device to play a busy or reorder tone to the PSTN after a Tel-to-IP call is released. <ul style="list-style-type: none"> ▪ [0] Don't Play = (Default) Immediately sends an ISDN Disconnect message. ▪ [1] Play when Disconnecting = Sends an ISDN Disconnect message with PI = 8 and plays a busy or reorder tone to the PSTN (depending on the release cause). ▪ [2] Play before Disconnect = Delays the sending of an ISDN Disconnect message for a user-defined time (configured by the TimeForReorderTone parameter) and plays a busy or reorder tone to the PSTN. This is applicable only if the call is released from the IP [Busy Here (486)] or Not Found (404)] before it reaches the Connect state; otherwise, the Disconnect message is sent immediately and no tones are played. Note: This parameter is applicable only to digital PSTN interfaces.
Web: Play Ringback Tone to Tel EMS: Play Ring Back Tone To Tel [PlayRBTone2Tel]	Determines the playing method of the ringback tone to the Tel (for analog interfaces) or Trunk (for digital interfaces) side. For digital interfaces: This parameter applies to all trunks that are not configured by the PlayRBTone2Trunk parameter (which defines ringback tone per Trunk). <ul style="list-style-type: none"> ▪ [0] Don't Play = <ul style="list-style-type: none"> ✓ Analog Interfaces: Ringback tone is not played. ✓ Digital Interfaces: The device configured for ISDN / CAS doesn't play a ringback tone. No PI is sent to the ISDN unless the ProgressIndicator2ISDN_x parameter is configured differently. ▪ [1] Play on Local = <ul style="list-style-type: none"> ✓ Analog Interfaces: Plays a ringback tone to the Tel side of the call when a SIP 180/183 response is received. ✓ Digital Interfaces: The device configured for CAS plays a local ringback tone to the PSTN upon receipt of a SIP 180 Ringing response (with or without SDP). Note that the receipt of a 183 response does not cause the device configured for CAS to play a ringback tone (unless the SIP183Behaviour parameter is set to 1). The device configured for ISDN operates according to the LocalISDNRBSsource parameter: <ol style="list-style-type: none"> 1) If the device receives a 180 Ringing response (with or without SDP) and the LocalISDNRBSsource parameter is

Parameter	Description
	<p>set to 1, it plays a ringback tone and sends an ISDN Alert with PI = 8 (unless the ProgressIndicator2ISDN_x parameter is configured differently).</p> <p>2) If the LocalISDNRBSsource parameter is set to 0, the device doesn't play a ringback tone and an Alert message without PI is sent to the ISDN. In this case, the PBX / PSTN plays the ringback tone to the originating terminal. Note that the receipt of a 183 response does not cause the device configured for ISDN to play a ringback tone; the device issues a Progress message (unless SIP183Behaviour is set to 1). If the SIP183Behaviour parameter is set to 1, the 183 response is handled the same way as a 180 Ringing response.</p> <ul style="list-style-type: none"> ▪ [2] Prefer IP = (Default): <ul style="list-style-type: none"> ✓ Analog Interfaces: Plays a ringback tone to the Tel side only if a 180/183 response without SDP is received. If 180/183 with SDP message is received, the device cuts through the voice channel and doesn't play the ringback tone. ✓ Digital Interfaces: Plays according to 'Early Media'. If a SIP 180 response is received and the voice channel is already open (due to a previous 183 early media response or due to an SDP in the current 180 response), the device configured for ISDN / CAS doesn't play the ringback tone; PI = 8 is sent in an ISDN Alert message (unless the ProgressIndicator2ISDN_x parameter is configured differently). If a 180 response is received, but the 'early media' voice channel is not opened, the device configured for CAS plays a ringback tone to the PSTN. The device configured for ISDN operates according to the LocalISDNRBSsource parameter: <ul style="list-style-type: none"> 1) If LocalISDNRBSsource is set to 1, the device plays a ringback tone and sends an ISDN Alert with PI = 8 to the ISDN (unless the ProgressIndicator2ISDN_x parameter is configured differently). 2) If LocalISDNRBSsource is set to 0, the device doesn't play a ringback tone. No PI is sent in the ISDN Alert message (unless the ProgressIndicator2ISDN_x parameter is configured differently). In this case, the PBX / PSTN plays a ringback tone to the originating terminal. Note that the receipt of a 183 response results in an ISDN Progress message (unless SIP183Behaviour is set to 1). If SIP183Behaviour is set to 1 (183 is handled the same way as a 180 + SDP), the device sends an Alert message with PI = 8, without playing a ringback tone. ▪ [3] Play Local Until Remote Media Arrive = Plays a ringback tone according to received media. The behaviour is similar to [2]. If a SIP 180 response is received and the voice channel is already open (due to a previous 183 early media response or due to an SDP in the current 180 response), the device plays a local ringback tone if there are no prior received RTP packets. The device stops playing the local ringback tone as soon as it starts receiving RTP packets. At this stage, if the device receives additional 18x responses, it does not resume playing the local ringback tone. Note that for ISDN trunks, this option is applicable only if the LocalISDNRBSsource parameter

Parameter	Description
	is set to 1. Note: This parameter is applicable to the Gateway and IP-to-IP applications.
Web: Play Ringback Tone to Trunk [PlayRBTone2Trunk_x]	Determines the playing method of the ringback tone to the trunk side per trunk. <ul style="list-style-type: none"> ▪ [-1] Not configured = (Default) The settings of the PlayRBTone2Tel parameter is used. ▪ [0] Don't Play = When the device is configured for ISDN / CAS, it doesn't play a ringback tone. No Progress Indicator (PI) is sent to the ISDN unless the ProgressIndicator2ISDN_x parameter is configured differently. ▪ [1] Play on Local = When the device is configured for CAS, it plays a local ringback tone to the PSTN upon receipt of a SIP 180 Ringing response (with or without SDP). Note that the receipt of a SIP 183 response does not cause the device configured for CAS to play a ringback tone (unless the SIP183Behaviour parameter is set to 1). When the device is configured for ISDN, it operates according to the LocalISDNRBSorce parameter, as follows: <ul style="list-style-type: none"> ✓ If the device receives a SIP 180 Ringing response (with or without SDP) and the LocalISDNRBSorce parameter is set to 1, it plays a ringback tone and sends an ISDN Alert with PI = 8 (unless the ProgressIndicator2ISDN_x parameter is configured differently). ✓ If the LocalISDNRBSorce parameter is set to 0, the device doesn't play a ringback tone and an Alert message without PI is sent to the ISDN. In this case, the PBX / PSTN plays the ringback tone to the originating terminal. Note that the receipt of a 183 response does not cause the device to play a ringback tone; the device sends a Progress message (unless SIP183Behaviour is set to 1). If the SIP183Behaviour parameter is set to 1, the 183 response is handled the same way as a 180 Ringing response. ▪ [2] Prefer IP = Plays according to 'Early Media'. If a SIP 180 response is received and the voice channel is already open (due to a previous 183 early media response or due to an SDP in the current 180 response), the device configured for ISDN / CAS doesn't play the ringback tone; PI = 8 is sent in an ISDN Alert message (unless the ProgressIndicator2ISDN_x parameter is configured differently). If a 180 response is received, but the 'early media' voice channel is not opened, the device configured for CAS plays a ringback tone to the PSTN. The device configured for ISDN operates according to the LocalISDNRBSorce parameter: <ul style="list-style-type: none"> ✓ If LocalISDNRBSorce is set to 1, the device plays a ringback tone and sends an ISDN Alert with PI = 8 to the ISDN (unless the ProgressIndicator2ISDN_x parameter is configured differently). ✓ If LocalISDNRBSorce is set to 0, the device doesn't play a ringback tone. No PI is sent in the ISDN Alert message (unless the ProgressIndicator2ISDN_x parameter is configured differently). In this case, the PBX / PSTN plays a ringback tone to the originating terminal. Note that the receipt of a 183 response results in an ISDN Progress

Parameter	Description
	<p>message (unless SIP183Behaviour is set to 1). If SIP183Behaviour is set to 1 (183 is handled the same way as a 180 with SDP), the device sends an Alert message with PI = 8 without playing a ringback tone.</p> <ul style="list-style-type: none"> ▪ [3] Play Local Until Remote Media Arrive = Plays tone according to received media. The behaviour is similar to option [2]. If a SIP 180 response is received and the voice channel is already open (due to a previous 183 early media response or due to an SDP in the current 180 response), the device plays a local ringback tone if there are no prior received RTP packets. The device stops playing the local ringback tone as soon as it starts receiving RTP packets. At this stage, if the device receives additional 18x responses, it does not resume playing the local ringback tone. Note that for ISDN trunks, this option is applicable only if LocalISDNRBSsource is set to 1. <p>Notes:</p> <ul style="list-style-type: none"> ▪ This parameter is applicable only to the Gateway (GW) application (i.e., not the IP-to-IP application). ▪ This parameter is applicable only to digital PSTN interfaces. ▪ The x in the ini file parameter name denotes the trunk number, where 0 is Trunk 1.
<p>Web: Play Ringback Tone to IP EMS: Play Ring Back Tone To IP [PlayRBTone2IP]</p>	<p>Determines whether the device plays a ringback tone to the IP side for IP-to-Tel calls.</p> <ul style="list-style-type: none"> ▪ [0] Don't Play = (Default) Ringback tone isn't played. ▪ [1] Play = Ringback tone is played after SIP 183 session progress response is sent. <p>For digital modules: If configured to 1 ('Play') and EnableEarlyMedia is set to 1, the device plays a ringback tone according to the following:</p> <ul style="list-style-type: none"> ▪ For CAS interfaces: the device opens a voice channel, sends a 183+SDP response, and then plays a ringback tone to IP. ▪ For ISDN interfaces: if a Progress or an Alerting message with PI (1 or 8) is received from the ISDN, the device opens a voice channel, sends a 183+SDP or 180+SDP response, but doesn't play a ringback tone to IP. If PI (1 or 8) is received from the ISDN, the device assumes that ringback tone is played by the ISDN switch. Otherwise, the device plays a ringback tone to IP after receiving an Alerting message from the ISDN. It sends a 180+SDP response, signaling to the calling party to open a voice channel to hear the played ringback tone. <p>Notes:</p> <ul style="list-style-type: none"> ▪ To enable the device to send a 183/180+SDP responses, set the EnableEarlyMedia parameter to 1. ▪ If the EnableDigitDelivery parameter is set to 1, the device doesn't play a ringback tone to IP and doesn't send 183 or 180+SDP responses. ▪ This parameter can also be configured in an IP Profile.
<p>Web: Play Local RBT on ISDN Transfer EMS: Play RBT On ISDN Transfer [PlayRBTOnISDNTransfer]</p>	<p>Determines whether the device plays a local ringback tone for ISDN's Two B Channel Transfer (TBCT), Release Line Trunk (RLT), or Explicit Call Transfer (ECT) call transfers to the originator when the second leg receives an ISDN Alerting or Progress message.</p>

Parameter	Description
	<ul style="list-style-type: none"> ▪ [0] Don't Play (default) ▪ [1] Play <p>Notes:</p> <ul style="list-style-type: none"> ▪ For Blind transfer, the local ringback tone is played to first call PSTN party when the second leg receives the ISDN Alerting or Progress message. ▪ For Consulted transfer, the local ringback tone is played when the second leg receives ISDN Alerting or Progress message if the Progress message is received after a SIP REFER. ▪ This parameter is applicable only if the parameter SendISDNTransferOnConnect is set to 1.
Web: MFC R2 Category EMS: R2 Category [R2Category]	Defines the tone for MFC R2 calling party category (CPC). The parameter provides information on the calling party such as National or International call, Operator or Subscriber and Subscriber priority. The value range is 1 to 15 (defining one of the MFC R2 tones). The default is 1.
Tone Index Table	
Web: Tone Index Table EMS: Analog Gateway Provisioning > Tone Index [ToneIndex]	This table parameter configures the Tone Index table, which allows you to define distinctive ringing and call waiting tones per FXS endpoint (or for a range of FXS endpoints). The format of this parameter is as follows: [ToneIndex] FORMAT ToneIndex_Index = ToneIndex_FXSPort_First, ToneIndex_FXSPort_Last, ToneIndex_SourcePrefix, ToneIndex_DestinationPrefix, ToneIndex_PriorityIndex; [ToneIndex] For example, the configuration below plays the tone Index #3 to FXS ports 1 and 2 if the source number prefix of the received call is 20. ToneIndex 1 = 1, 2, 20*, , 3; Note: For a detailed description of this table, see Configuring FXS Distinctive Ringing and Call Waiting Tones per Source/Destination Number.

52.11.9.2 Tone Detection Parameters

The signal tone detection parameters are described in the table below.

Tone Detection Parameters

Parameter	Description
EMS: DTMF Enable [DTMFDetectorEnable]	Enables the detection of DTMF signaling. <ul style="list-style-type: none"> ▪ [0] = Disable ▪ [1] = Enable (default)
EMS: MF R1 Enable [MFR1DetectorEnable]	Enables the detection of MF-R1 signaling. <ul style="list-style-type: none"> ▪ [0] = Disable (default) ▪ [1] = Enable
EMS: R1.5 Detection Standard	Determines the MF-R1 protocol used for detection.

Parameter	Description
[R1DetectionStandard]	<ul style="list-style-type: none"> ▪ [0] = ITU (default) ▪ [1] = R1.5 <p>Note: For this parameter to take effect, a device reset is required.</p>
EMS: User Defined Tone Enable [UserDefinedToneDetectorEnable]	<p>Enables the detection of User Defined Tones signaling, applicable for Special Information Tone (SIT) detection.</p> <ul style="list-style-type: none"> ▪ [0] = Disable (default) ▪ [1] = Enable
EMS: SIT Enable [SITDetectorEnable]	<p>Enables SIT detection according to the ITU-T recommendation E.180/Q.35.</p> <ul style="list-style-type: none"> ▪ [0] = Disable (default) ▪ [1] = Enable <p>To disconnect IP-to-ISDN calls when a SIT tone is detected, the following parameters must be configured:</p> <ul style="list-style-type: none"> ▪ SITDetectorEnable = 1 ▪ UserDefinedToneDetectorEnable = 1 ▪ ISDNDisconnectOnBusyTone = 1 (applicable for Busy, Reorder and SIT tones) <p>Another parameter for handling the SIT tone is SITQ850Cause, which determines the Q.850 cause value specified in the SIP Reason header that is included in a 4xx response when a SIT tone is detected on an IP-to-Tel call.</p> <p>To disconnect IP-to-CAS calls when a SIT tone is detected, the following parameters must be configured (applicable to FXO interfaces):</p> <ul style="list-style-type: none"> ▪ SITDetectorEnable = 1 ▪ UserDefinedToneDetectorEnable = 1 ▪ DisconnectOnBusyTone = 1 (applicable for busy, reorder, and SIT tones) <p>Notes:</p> <ul style="list-style-type: none"> ▪ For this parameter to take effect, a device reset is required. ▪ The IP-to-ISDN call is disconnected on detection of a SIT tone only in call alert state. If the call is in connected state, the SIT does not disconnect the call. Detection of busy or reorder tones disconnect these calls also in call connected state. ▪ For IP-to-CAS calls, detection of busy, reorder, or SIT tones disconnect the call in any call state.
EMS: UDT Detector Frequency Deviation [UDTDetectorFrequencyDeviation]	<p>Defines the deviation (in Hz) allowed for the detection of each signal frequency.</p> <p>The valid range is 1 to 50. The default is 50.</p> <p>Note: For this parameter to take effect, a device reset is required.</p>
EMS: CPT Detector Frequency Deviation [CPTDetectorFrequencyDeviation]	<p>Defines the deviation (in Hz) allowed for the detection of each CPT signal frequency.</p> <p>The valid range is 1 to 30. The default is 10.</p> <p>Note: For this parameter to take effect, a device reset is required.</p>

52.11.9.3 Metering Tone Parameters

The metering tone parameters are described in the table below.

Metering Tone Parameters

Parameter	Description
Web: Generate Metering Tones EMS: Metering Mode [PayPhoneMeteringMode]	Determines the method used to configure the metering tones that are generated to the Tel side. <ul style="list-style-type: none"> [0] Disable = (Default) Metering tones aren't generated. [1] Internal Table = Metering tones are generated according to the device's Charge Code table (using the ChargeCode parameter). Notes: <ul style="list-style-type: none"> This parameter is applicable only to FXS interfaces and ISDN Euro trunks for sending AOC Facility messages (see Advice of Charge Services for Euro ISDN on page 387). If you select 'Internal Table', you must configure the Charge Codes table, using the ChargeCode parameter (see Configuring Charge Codes Table on page 391).
Web: Analog Metering Type EMS: Metering Type [MeteringType]	Determines the metering method for generating pulses (sinusoidal metering burst frequency) by the FXS port. <ul style="list-style-type: none"> [0] 12 KHz = (Default) 12 kHz sinusoidal bursts. [1] 16 KHz = 16 kHz sinusoidal bursts. [2] = Polarity Reversal pulses. Notes: <ul style="list-style-type: none"> For this parameter to take effect, a device reset is required. This parameter is applicable only to FXS interfaces.
Web: Analog TTX Voltage Level EMS: TTX Voltage Level [AnalogTTXVoltageLevel]	Determines the metering signal/pulse voltage level (TTX). <ul style="list-style-type: none"> [0] 0V = 0 Vrms sinusoidal bursts. [1] 0.5V = (Default) 0.5 Vrms sinusoidal bursts. [2] 1V = 1 Vrms sinusoidal bursts Notes: <ul style="list-style-type: none"> For this parameter to take effect, a device reset is required. This parameter is applicable only to FXS interfaces.
Charge Codes Table	
Web: Charge Codes Table EMS: Charge Codes [ChargeCode]	This table parameter configures metering tones and their time intervals that the FXS interface generates to the Tel side or the E1 trunk (EuroISDN) sends in AOC Facility messages to the PSTN (i.e., PBX). The format of this parameter is as follows: [ChargeCode] FORMAT ChargeCode_Index = ChargeCode_EndTime1, ChargeCode_PulseInterval1, ChargeCode_PulsesOnAnswer1, ChargeCode_EndTime2, ChargeCode_PulseInterval2, ChargeCode_PulsesOnAnswer2, ChargeCode_EndTime3, ChargeCode_PulseInterval3, ChargeCode_PulsesOnAnswer3, ChargeCode_EndTime4, ChargeCode_PulseInterval4, ChargeCode_PulsesOnAnswer4; [ChargeCode] Where, <ul style="list-style-type: none"> EndTime = Period (1 - 4) end time.

Parameter	Description
	<ul style="list-style-type: none"> PulseInterval = Period (1 - 4) pulse interval. PulsesOnAnswer = Period (1 - 4) pulses on answer. <p>For example: ChargeCode 1 = 7,30,1,14,20,2,20,15,1,0,60,1; ChargeCode 2 = 5,60,1,14,20,1,0,60,1; ChargeCode 3 = 0,60,1; ChargeCode 0 = 6, 3, 1, 12, 2, 1, 18, 5, 2, 0, 2, 1;</p> <p>Notes:</p> <ul style="list-style-type: none"> To associate a configured Charge Code to an outgoing Tel-to-IP call, use the Outbound IP Routing Table. To configure the Charge Codes table using the Web interface, see Configuring Charge Codes Table on page 391.

52.11.10 Telephone Keypad Sequence Parameters

The telephony keypad sequence parameters are described in the table below.

Telephone Keypad Sequence Parameters

Parameter	Description
Web/EMS: Call Pickup Key [KeyCallPickup]	<p>Defines the keying sequence for performing a call pick-up. Call pick-up allows the FXS endpoint to answer another telephone's incoming call by pressing this user-defined sequence of digits. When the user dials these digits (e.g., #77), the incoming call from another phone is forwarded to the user's phone.</p> <p>The valid value is a string of up to 15 characters (0-9, #, and *). The default is undefined.</p> <p>Notes:</p> <ul style="list-style-type: none"> Call pick-up is configured only for FXS endpoints pertaining to the same Trunk Group. This parameter is applicable only to FXS interfaces.
Prefix for External Line	
[Prefix2ExtLine]	<p>Defines a string prefix (e.g., '9' dialed for an external line) that when dialed, the device plays a secondary dial tone (i.e., stutter tone) to the FXS line and then starts collecting the subsequently dialed digits from the FXS line.</p> <p>The valid range is a one-character string. The default is an empty string.</p> <p>Notes:</p> <ul style="list-style-type: none"> You can enable the device to add this string as the prefix to the collected (and sent) digits, using the parameter AddPrefix2ExtLine. This parameter is applicable only to FXS interfaces.
[AddPrefix2ExtLine]	<p>Determines whether the prefix string for accessing an external line (defined by the parameter Prefix2ExtLine) is added to the dialed number as the prefix and together sent to the IP destination (Tel-to-IP calls).</p> <ul style="list-style-type: none"> [0] = Disable (default) [1] = Enable <p>For example, if this parameter is enabled and the prefix string for the external line is defined as "9" (using the parameter Prefix2ExtLine) and the FXS user wants to make a call to destination "123", the device collects</p>

Parameter	Description
	and sends all the dialed digits, including the prefix string, as "9123" to the IP destination number. Note: This parameter is applicable only to FXS interfaces.
Hook Flash Parameters	
Web: Flash Keys Sequence Style [FlashKeysSequenceStyle]	Determines the hook-flash key sequence for FXS interfaces. <ul style="list-style-type: none"> ▪ [0] Flash hook = (Default) Only the phone's flash button is used, according to the following scenarios: <ul style="list-style-type: none"> ✓ During an existing call, if the user presses the flash button, the call is put on hold; a dial tone is heard and the user is able to initiate a second call. Once the second call is established, on-hooking transfers the first (held) call to the second call. ✓ During an existing call, if a call comes in (call waiting), pressing the flash button places the active call on hold and answers the waiting call; pressing flash again toggles between these two calls. ▪ [1] Sequence 1 = Sequence of flash and digit: <ul style="list-style-type: none"> ✓ Flash + 1: holds a call or toggles between two existing calls ✓ Flash + 2: makes a call transfer. ✓ Flash + 3: makes a three-way conference call (if the Three-Way Conference feature is enabled, i.e., the parameter Enable3WayConference is set to 1 and the parameter 3WayConferenceMode is set to 2). ▪ [2] Sequence 2 = Sequence of flash and digit: <ul style="list-style-type: none"> ✓ Flash only: Places a call on hold. ✓ Flash + 1: <ol style="list-style-type: none"> 1) When the device handles two calls (an active and a held call) and this key sequence is dialed, it sends a SIP BYE message to the active call and the previously held call becomes the active call. 2) When there is an active call and an incoming waiting call, if this key sequence is dialed, the device disconnects the active call and the waiting call becomes an active call. ✓ Flash + 2: Places a call on hold and answers a call-waiting call, or toggles between active and on-hold calls. ✓ Flash + 3: Makes a three-way conference call. This is applicable only if the Enable3WayConference parameter is set to 1 and the 3WayConferenceMode parameter is set to 2, and the device houses the MPM modules. Note that the settings of the ConferenceCode parameter is ignored. ✓ Flash + 4: Makes a call transfer. Note: This parameter is applicable only to FXS interfaces.
Web: Flash Keys Sequence Timeout [FlashKeysSequenceTimeout]	Defines the Flash keys sequence timeout - the time (in msec) that the device waits for digits after the user presses the Flash button (Flash Hook + Digit mode - when the parameter FlashKeysSequenceStyle is set to 1 or 2). The valid range is 100 to 5,000. The default is 2,000.
Keypad Feature - Call Forward Parameters	
Web: Forward Unconditional EMS: Call Forward Unconditional [KeyCFUnCond]	Defines the keypad sequence to activate the immediate call forward option.

Parameter	Description
Web: Forward No Answer EMS: Call Forward No Answer [KeyCFNoAnswer]	Defines the keypad sequence to activate the forward on no answer option.
Web: Forward On Busy EMS: Call Forward Busy [KeyCFBusy]	Defines the keypad sequence to activate the forward on busy option.
Web: Forward On Busy or No Answer EMS: CF Busy Or No Answer [KeyCFBusyOrNoAnswer]	Defines the keypad sequence to activate the forward on 'busy or no answer' option.
Web: Do Not Disturb EMS: CF Do Not Disturb [KeyCFDoNotDisturb]	Defines the keypad sequence to activate the Do Not Disturb option (immediately reject incoming calls).
<p>To activate the required forward method from the telephone:</p> <ol style="list-style-type: none"> 1 Dial the user-defined sequence number on the keypad; a dial tone is heard. 2 Dial the telephone number to which the call is forwarded (terminate the number with #); a confirmation tone is heard. 	
Web: Forward Deactivate EMS: Call Forward Deactivation [KeyCFDeact]	Defines the keypad sequence to deactivate any of the call forward options. After the sequence is pressed, a confirmation tone is heard.
Keypad Feature - Caller ID Restriction Parameters	
Web: Restricted Caller ID Activate EMS: CLIR [KeyCLIR]	Defines the keypad sequence to activate the restricted Caller ID option. After the sequence is pressed, a confirmation tone is heard.
Web: Restricted Caller ID Deactivate EMS: CLIR Deactivation [KeyCLIRDeact]	Defines the keypad sequence to deactivate the restricted Caller ID option. After the sequence is pressed, a confirmation tone is heard.
Keypad Feature - Hotline Parameters	
Web: Hot-line Activate EMS: Hot Line [KeyHotLine]	<p>Defines the keypad sequence to activate the delayed hotline option. To activate the delayed hotline option from the telephone, perform the following:</p> <ol style="list-style-type: none"> 1 Dial the user-defined sequence number on the keypad; a dial tone is heard. 2 Dial the telephone number to which the phone automatically dials after a configurable delay (terminate the number with #); a confirmation tone is heard.
Web: Hot-line	Defines the keypad sequence to deactivate the delayed hotline option.

Parameter	Description
Deactivate EMS: Hot Line Deactivation [KeyHotLineDeact]	After the sequence is pressed, a confirmation tone is heard.
Keypad Feature - Transfer Parameters	
Note: See the description of the KeyBlindTransfer parameter for this feature.	
Keypad Feature - Call Waiting Parameters	
Web: Call Waiting Activate EMS: Keypad Features CW [KeyCallWaiting]	Defines the keypad sequence to activate the Call Waiting option. After the sequence is pressed, a confirmation tone is heard.
Web: Call Waiting Deactivate EMS: Keypad Features CW Deact [KeyCallWaitingDeact]	Defines the keypad sequence to deactivate the Call Waiting option. After the sequence is pressed, a confirmation tone is heard.
Keypad Feature - Reject Anonymous Call Parameters	
Web: Reject Anonymous Call Activate EMS: Reject Anonymous Call [KeyRejectAnonymousCall]	Defines the keypad sequence to activate the reject anonymous call option, whereby the device rejects incoming anonymous calls. After the sequence is pressed, a confirmation tone is heard.
Web: Reject Anonymous Call Deactivate EMS: Reject Anonymous Call Deact [KeyRejectAnonymousCallDeact]	Defines the keypad sequence that de-activates the reject anonymous call option. After the sequence is pressed, a confirmation tone is heard.

52.11.11 General FXO Parameters

The general FXO and FXS parameters are described in the table below.

General FXO and FXS Parameters

Parameter	Description
FXS Parameters	
Web: FXS Coefficient Type EMS: Country Coefficients [FXSCountryCoefficients]	Determines the FXS line characteristics (AC and DC) according to USA or Europe (TBR21) standards. <ul style="list-style-type: none"> ▪ [66] Europe = TBR21 ▪ [70] USA = (Default) United States Note: For this parameter to take effect, a device reset is required.

Parameter	Description
FXO Parameters	
Web: FXO Coefficient Type EMS: Country Coefficients [CountryCoefficients]	<p>Determines the FXO line characteristics (AC and DC) according to USA or TBR21 standard.</p> <ul style="list-style-type: none"> ▪ [66] Europe = TBR21 ▪ [70] USA = (Default) United States <p>Note: For this parameter to take effect, a device reset is required.</p>
[FXODCTermination]	<p>Defines the FXO line DC termination (i.e., resistance).</p> <ul style="list-style-type: none"> ▪ [0] = (Default) DC termination is set to 50 Ohms. ▪ [1] = DC termination set to 800 Ohms. The termination changes from 50 to 800 Ohms only when moving from onhook to offhook. <p>Note: For this parameter to take effect, a device reset is required.</p>
[EnableFXOCurrentLimit]	<p>Enables limiting the FXO loop current to a maximum of 60 mA (according to the TBR21 standard).</p> <ul style="list-style-type: none"> ▪ [0] = (Default) FXO line current limit is disabled. ▪ [1] = FXO loop current is limited to a maximum of 60 mA. <p>Note: For this parameter to take effect, a device reset is required.</p>
[FXONumberOfRings]	<p>Defines the number of rings before the device's FXO interface answers a call by seizing the line.</p> <p>The valid range is 0 to 10. The default is 0.</p> <p>When set to 0, the FXO seizes the line after one ring. When set to 1, the FXO seizes the line after two rings.</p> <p>Notes:</p> <ul style="list-style-type: none"> ▪ This parameter is applicable only if automatic dialing is not used. ▪ If caller ID is enabled and if the number of rings defined by the parameter RingsBeforeCallerID is greater than the number of rings defined by this parameter, the greater value is used.
Web/EMS: Dialing Mode [IsTwoStageDial]	<p>Determines the dialing mode for IP-to-Tel (FXO) calls.</p> <ul style="list-style-type: none"> ▪ [0] One Stage = One-stage dialing. In this mode, the device seizes one of the available lines (according to the ChannelSelectMode parameter), and then dials the destination phone number received in the INVITE message. To specify whether the dialing must start after detection of the dial tone or immediately after seizing the line, use the IsWaitForDialTone parameter. ▪ [1] Two Stages = (Default) Two-stage dialing. In this mode, the device seizes one of the PSTN/PBX lines without performing any dialing, connects the remote IP user to the PSTN/PBX, and all further signaling (dialing and Call Progress Tones) is performed directly with the PBX without the device's intervention. <p>Note: This parameter can also be configured in a Tel Profile.</p>
Web/EMS: Waiting For Dial Tone	Determines whether or not the device waits for a dial tone

Parameter	Description
[IsWaitForDialTone]	before dialing the phone number for IP-to-Tel (FXO) calls. <ul style="list-style-type: none"> ▪ [0] No ▪ [1] Yes (default) When one-stage dialing and this parameter are enabled, the device dials the phone number (to the PSTN/PBX line) only after it detects a dial tone. If this parameter is disabled, the device immediately dials the phone number after seizing the PSTN/PBX line without 'listening' for a dial tone. <p>Notes:</p> <ul style="list-style-type: none"> ▪ The correct dial tone parameters must be configured in the CPT file. ▪ The device may take 1 to 3 seconds to detect a dial tone (according to the dial tone configuration in the CPT file). If the dial tone is not detected within 6 seconds, the device releases the call and sends a SIP 500 "Server Internal Error" response.
Web: Time to Wait before Dialing [msec] EMS: Time Before Dial [WaitForDialTime]	For digital interfaces: Defines the delay after hook-flash is generated and until dialing begins. Applies to call transfer (i.e., the parameter TrunkTransferMode is set to 3) on CAS protocols. For analog interfaces: Defines the delay before the device starts dialing on the FXO line in the following scenarios: <ul style="list-style-type: none"> ▪ The delay between the time the line is seized and dialing begins during the establishment of an IP-to-Tel call. Note: Applicable only for one-stage dialing when the parameter IsWaitForDialTone is disabled. ▪ The delay between detection of a Wink and the start of dialing during the establishment of an IP-to-Tel call (for DID lines, EnableDIDWink is set to 1). ▪ For call transfer - the delay after hook-flash is generated and dialing begins. The valid range (in milliseconds) is 0 to 20,000 (i.e., 20 seconds). The default is 1,000 (i.e., 1 second).
Web: Ring Detection Timeout [sec] EMS: Timeout Between Rings [FXOBetweenRingTime]	Defines the timeout (in seconds) for detecting the second ring after the first detected ring. If automatic dialing is not used and Caller ID is enabled, the device seizes the line after detection of the second ring signal (allowing detection of caller ID sent between the first and the second rings). If the second ring signal is not received within this timeout, the device doesn't initiate a call to IP. If automatic dialing is used, the device initiates a call to IP when the ringing signal is detected. The FXO line is seized only if the remote IP party answers the call. If the remote party doesn't answer the call and the second ring signal is not received within this timeout, the device releases the IP call. This parameter is typically set to between 5 and 8. The default is 8. <p>Notes:</p> <ul style="list-style-type: none"> ▪ This parameter is applicable only for Tel-to-IP calls. ▪ This timeout is calculated from the end of the ring until the start of the next ring. For example, if the ring cycle is two

Parameter	Description
	seconds on and four seconds off, the timeout value should be configured to five seconds (i.e., greater than the off time, e.g., four).
Web: Rings before Detecting Caller ID EMS: Rings Before Caller ID [RingsBeforeCallerID]	Determines the number of rings before the device starts detecting Caller ID. <ul style="list-style-type: none"> ▪ [0] 0 = Before first ring. ▪ [1] 1 = (Default) After first ring. ▪ [2] 2 = After second ring.
Web/EMS: Guard Time Between Calls [GuardTimeBetweenCalls]	Defines the time interval (in seconds) after a call has ended and a new call can be accepted for IP-to-Tel (FXO) calls. The valid range is 0 to 10. The default is 1. Note: Occasionally, after a call ends and on-hook is applied, a delay is required before placing a new call (and performing off-hook). This is necessary to prevent incorrect hook-flash detection or other glare phenomena.
Web: FXO Double Answer [EnableFXODoubleAnswer]	Enables the FXO Double Answer feature, which rejects (disconnects) incoming Tel (FXO)-to-IP collect calls and signals (informs) this call denial to the PSTN. <ul style="list-style-type: none"> ▪ [0] Disable (default) ▪ [1] Enable Note: This feature can also be configured in a Tel Profile.

52.11.12 Trunk Groups and Routing Parameters

The routing parameters are described in the table below.

Routing Parameters

Parameter	Description
Trunk Group Table	
Web: Trunk Group Table EMS: SIP Endpoints > Phones [TrunkGroup]	This table parameter configures and activates the device's endpoints/Trunk channels. This is done by defining telephone numbers and assigning them to Trunk Groups. The format of this parameter is shown below: [TrunkGroup] FORMAT TrunkGroup_Index = TrunkGroup_TrunkGroupNum, TrunkGroup_FirstTrunkId, TrunkGroup_FirstBChannel, TrunkGroup_LastBChannel, TrunkGroup_FirstPhoneNumber, TrunkGroup_ProfileId, TrunkGroup_LastTrunkId, TrunkGroup_Module; [TrunkGroup] For example: The configuration below assigns Trunk 1 (channels 1 to 30) of Module 1 to Trunk Group ID 2: TrunkGroup 0 = 2, 0, 1, 30, 50000, 0, 0, 1; The configuration below assigns BRI channels 1 through 4 of Module 2 to Trunk Group ID 2 with phone numbers 208 to 211:

Parameter	Description
	TrunkGroup 1 = 2, 0, 1, 4, 208, 0, 0 ,2; Notes: <ul style="list-style-type: none"> ▪ Trunk Group ID 1 is denoted as 0 in the table. ▪ This parameter can appear up to four times per module. ▪ For a description of this table, see Configuring Trunk Group Table on page 291.
Trunk Group Settings	
Web: Trunk Group Settings EMS: SIP Routing > Hunt Group [TrunkGroupSettings]	This table parameter configures the rules for channel allocation per Trunk Group. The format of this parameter is as follows: [TrunkGroupSettings] FORMAT TrunkGroupSettings_Index = TrunkGroupSettings_TrunkGroupId, TrunkGroupSettings_ChannelSelectMode, TrunkGroupSettings_RegistrationMode, TrunkGroupSettings_GatewayName, TrunkGroupSettings_ContactUser, TrunkGroupSettings_ServingIPGroup, TrunkGroupSettings_MWIInterrogationType, TrunkGroupSettings_TrunkGroupName; [TrunkGroupSettings] For example: TrunkGroupSettings 0 = 1, 0, 5, branch-hq, user, 1, 255, ; TrunkGroupSettings 1 = 2, 1, 0, localname, user1, 2, 255, ; Note: For a description of this table, see 'Configuring Trunk Group Settings' on page 293.
Web: Channel Select Mode EMS: Channel Selection Mode [ChannelSelectMode]	Defines the method for allocating incoming IP-to-Tel calls to a channel for all Trunk Groups. <ul style="list-style-type: none"> ▪ [0] By Dest Phone Number (default) ▪ [1] Cyclic Ascending ▪ [2] Ascending ▪ [3] Cyclic Descending ▪ [4] Descending ▪ [5] Dest Number + Cyclic Ascending. ▪ [6] By Source Phone Number ▪ [7] Trunk Cyclic Ascending ▪ [8] Trunk & Channel Cyclic Ascending ▪ [9] Ring to Hunt Group ▪ [10] Select Trunk by ISDN SuppServ Table ▪ [11] Dest Number + Ascending Notes: <ul style="list-style-type: none"> ▪ For a detailed description of the parameter's options, see 'Configuring Trunk Group Settings' on page 293. ▪ Channel select mode per Trunk Group can be configured in the Trunk Group Settings (see 'Configuring Trunk Group Settings' on page 293).
Web: Default Destination Number [DefaultNumber]	Defines the default destination phone number, which is used if the received message doesn't contain a called party number and no phone number is configured in the Trunk Group Table' (see Configuring the Trunk Group Table on page 291). This parameter is used as a starting number for the list of channels comprising all the device's Trunk Groups.

Parameter	Description
	The default is 1000.
Web: Source IP Address Input [SourceIPAddressInput]	Determines which IP address the device uses to determine the source of incoming INVITE messages for IP-to-Tel routing. <ul style="list-style-type: none"> ▪ [-1] = (Default) Auto Decision - if the IP-to-IP feature is enabled, this parameter is automatically set to Layer 3 Source IP. If the IP-to-IP feature is disabled, this parameter is automatically set to SIP Contact Header (1). ▪ [0] SIP Contact Header = The IP address in the Contact header of the incoming INVITE message is used. ▪ [1] Layer 3 Source IP = The actual IP address (Layer 3) from where the SIP packet was received is used.
Web: Use Source Number As Display Name EMS: Display Name [UseSourceNumberAsDisplayName]	Determines the use of Tel Source Number and Display Name for Tel-to-IP calls. <ul style="list-style-type: none"> ▪ [0] No = (Default) If a Tel Display Name is received, the Tel Source Number is used as the IP Source Number and the Tel Display Name is used as the IP Display Name. If no Display Name is received from the Tel side, the IP Display Name remains empty. ▪ [1] Yes = If a Tel Display Name is received, the Tel Source Number is used as the IP Source Number and the Tel Display Name is used as the IP Display Name. If no Display Name is received from the Tel side, the Tel Source Number is used as the IP Source Number and also as the IP Display Name. ▪ [2] Overwrite = The Tel Source Number is used as the IP Source Number and also as the IP Display Name (even if the received Tel Display Name is not empty). ▪ [3] Original = Similar to option [2], except that the operation is done before regular calling number manipulation.
Web/EMS: Use Display Name as Source Number [UseDisplayNameAsSourceNumber]	Determines the use of Source Number and Display Name for IP-to-Tel calls. <ul style="list-style-type: none"> ▪ [0] No = (Default) If IP Display Name is received, the IP Source Number is used as the Tel Source Number and the IP Display Name is used as the Tel Display Name. If no Display Name is received from IP, the Tel Display Name remains empty. ▪ [1] Yes = If an IP Display Name is received, it is used as the Tel Source Number and also as the Tel Display Name, and Presentation is set to Allowed (0). If no Display Name is received from IP, the IP Source Number is used as the Tel Source Number and Presentation is set to Restricted (1). For example: When 'From: 100 <sip:200@201.202.203.204>' is received, the outgoing Source Number and Display Name are set to '100' and the Presentation is set to Allowed (0). When 'From: <sip:100@101.102.103.104>' is received, the outgoing Source Number is set to '100' and the Presentation is set to Restricted (1).
Web: Use Routing Table for Host Names and Profiles EMS: Use Routing Table For Host Names [AlwaysUseRouteTable]	Determines whether to use the device's routing table to obtain the URI host name and optionally, an IP profile (per call) even if a Proxy server is used. <ul style="list-style-type: none"> ▪ [0] Disable = (Default) Don't use internal routing table. ▪ [1] Enable = Use the Outbound IP Routing Table. Notes:

Parameter	Description
	<ul style="list-style-type: none"> This parameter appears only if the 'Use Default Proxy' parameter is enabled. The domain name is used instead of a Proxy name or IP address in the INVITE SIP URI.
Web/EMS: Tel to IP Routing Mode [RouteModeTel2IP]	For a description of this parameter, see 'Configuring Outbound IP Routing Table' on page 323.
Outbound IP Routing Table	
Web: Outbound IP Routing Table EMS: SIP Routing > Tel to IP [Prefix]	This table parameter configures the Outbound IP Routing Table for routing Tel-to-IP and IP-to-IP calls. The format of this parameter is as follows: [PREFIX] FORMAT PREFIX_Index = PREFIX_DestinationPrefix, PREFIX_DestAddress, PREFIX_SourcePrefix, PREFIX_ProfileId, PREFIX_MeteringCode, PREFIX_DestPort, PREFIX_SrcIPGroupID, PREFIX_DestHostPrefix, PREFIX_DestIPGroupID, PREFIX_SrcHostPrefix, PREFIX_TransportType, PREFIX_SrcTrunkGroupID, PREFIX_DestSRD, PREFIX_CostGroup, PREFIX_ForkingGroup; [PREFIX] For example: PREFIX 0 = *, domain.com, *, 0, 255, \$\$, -1, , 1, , -1, -1, -1,;; PREFIX 1 = 20, 10.33.37.77, *, 0, 255, \$\$, -1, , 2, , 0, -1,;; Note: For a detailed description of this table, see 'Configuring Outbound IP Routing Table' on page 323.
Inbound IP Routing Table	
Web: Inbound IP Routing Table EMS: SIP Routing > IP to Hunt [PSTNPrefix]	This table parameter configures the routing of IP-to-Trunk Groups (or inbound IP Groups). The format of this parameter is as follows: [PSTNPrefix] ORMAT PstnPrefix_Index = PstnPrefix_DestPrefix, PstnPrefix_TrunkGroupID, PstnPrefix_SourcePrefix, PstnPrefix_SourceAddress, PstnPrefix_ProfileId, PstnPrefix_SrcIPGroupID, PstnPrefix_DestHostPrefix, PstnPrefix_SrcHostPrefix, PstnPrefix_SrcSRDID, PstnPrefix_TrunkId; [PSTNPrefix] For example: PstnPrefix 0 = 100, 1, 200, *, 0, 2, , , ;; PstnPrefix 1 = *, 2, *, , 1, 3, acl, joe, , , ;; Note: For a detailed description of this table, see 'Configuring Inbound IP Routing Table' on page 332.
Web/EMS: IP to Tel Routing Mode [RouteModeIP2Tel]	Determines whether to route IP calls to the Trunk Group (or IP Group) before or after manipulation of the destination number (configured in 'Configuring Source/Destination Number Manipulation Rules' on page 299). <ul style="list-style-type: none"> [0] Route calls before manipulation = (Default) Calls are routed before the number manipulation rules are applied. [1] Route calls after manipulation = Calls are routed after the number manipulation rules are applied.
Web: IP Security EMS: Secure Call From IP	Determines the device's policy on accepting or blocking SIP calls (IP-to-Tel calls). This is useful in preventing unwanted SIP calls, SIP

Parameter	Description
[SecureCallsFromIP]	<p>messages, and/or VoIP spam.</p> <ul style="list-style-type: none"> ▪ [0] Disable = (Default) The device accepts all SIP calls. ▪ [1] Secure Incoming calls = The device accepts SIP calls (i.e., calls from the IP side) only from IP addresses that are defined in the Outbound IP Routing Table or Proxy Set table, or IP addresses resolved from DNS servers from FQDN values defined in the Proxy Set table. All other incoming calls are rejected. ▪ [2] Secure All calls = The device accepts SIP calls only from IP addresses (in dotted-decimal notation format) that are defined in the Outbound IP Routing Table table or Proxy Set table, and rejects all other incoming calls. In addition, if an FQDN is defined in the routing table or Proxy Set table, the call is allowed to be sent only if the resolved DNS IP address appears in one of these tables; otherwise, the call is rejected. Therefore, the difference between this option and option [1] is that this option is concerned only about numerical IP addresses that are defined in the tables. <p>Note: If this parameter is set to [1] or [2], when using Proxies or Proxy Sets, it is unnecessary to configure the Proxy IP addresses in the routing table. The device allows SIP calls received from the Proxy IP addresses even if these addresses are not configured in the routing table.</p>
Web/EMS: Filter Calls to IP [FilterCalls2IP]	<p>Enables filtering of Tel-to-IP calls when a Proxy is used (i.e., IsProxyUsed parameter is set to 1 - see 'Configuring Proxy and Registration Parameters' on page 228).</p> <ul style="list-style-type: none"> ▪ [0] Don't Filter = (Default) The device doesn't filter calls when using a Proxy. ▪ [1] Filter = Filtering is enabled. <p>When this parameter is enabled and a Proxy is used, the device first checks the Outbound IP Routing Table before making a call through the Proxy. If the number is not allowed (i.e., number isn't listed in the table or a call restriction routing rule of IP address 0.0.0.0 is applied), the call is released.</p> <p>Note: When no Proxy is used, this parameter must be disabled and filtering is according to the Outbound IP Routing Table.</p>
[IP2TelTaggingDestDialPlanIndex]	<p>Determines the Dial Plan index in the external Dial Plan file (.dat) in which string labels ("tags") are defined for tagging incoming IP-to-Tel calls. The special "tag" is added as a prefix to the called party number, and then the Inbound IP Routing Table uses this "tag" instead of the original prefix. Manipulation is then performed (after routing) in the Manipulation table which strips the "tag" characters before sending the call to the endpoint.</p> <p>The valid values are 0 to 7, where 0 denotes PLAN1, 1 denotes PLAN2, and so on. The default is -1 (i.e., no dial plan file used). The routing label can be up to 9 (text) characters.</p> <p>Notes:</p> <ul style="list-style-type: none"> ▪ This parameter is applicable only to digital interfaces. ▪ The routing must be configured to be performed before manipulation. ▪ For more information on this feature, see Dial Plan Prefix Tags for IP-to-Tel Routing on page 510.
[EnableETSIDiversion]	<p>Determines the method in which the Redirect Number is sent to the Tel side.</p>

Parameter	Description
Web: Add CIC [AddCicAsPrefix]	<ul style="list-style-type: none"> ▪ [0] = (Default) Q.931 Redirecting Number Information Element (IE). ▪ [1] = ETSI DivertingLegInformation2 in a Facility IE. <p>Determines whether to add the Carrier Identification Code (CIC) as a prefix to the destination phone number for IP-to-Tel calls. When this parameter is enabled, the 'cic' parameter in the incoming SIP INVITE can be used for IP-to-Tel routing decisions. It routes the call to the appropriate Trunk Group based on this parameter's value.</p> <ul style="list-style-type: none"> ▪ [0] No (default) ▪ [1] Yes <p>For digital interfaces: The SIP 'cic' parameter enables the transmission of the 'cic' parameter from the SIP network to the ISDN. The 'cic' parameter is a three- or four-digit code used in routing tables to identify the network that serves the remote user when a call is routed over many different networks. The 'cic' parameter is carried in the SIP INVITE and maps to the ISDN Transit Network Selection Information Element (TNS IE) in the outgoing ISDN Setup message (if the EnableCIC parameter is set to 1). The TNS IE identifies the requested transportation networks and allows different providers equal access support, based on customer choice.</p> <p>For example, as a result of receiving the below INVITE, the destination number after number manipulation is cic+167895550001: INVITE sip:5550001;cic=+16789@172.18.202.60:5060;user=phone SIP/2.0</p> <p>Note: After the cic prefix is added, the Inbound IP Routing Table can be used to route this call to a specific Trunk Group. The Destination Number IP to Tel Manipulation table must be used to remove this prefix before placing the call to the ISDN.</p>
[FaxReroutingMode]	<p>Enables re-routing of Tel-to-IP calls that are identified as fax calls. If a CNG tone is detected on the Tel side of a Tel-to-IP call, the prefix string "FAX" is appended to the destination number before routing and manipulation. If you enter the string value, "FAX" as the destination number in the Outbound IP Routing table, the routing rule is used to route the call and the destination number manipulation mechanism is used to remove the "FAX" prefix, if required. Note that the "FAX" prefix string in routing and manipulation tables is case-sensitive.</p> <p>If the initial INVITE used to establish the voice call (not fax) was already sent, a CANCEL (if not connected yet) or a BYE (if already connected) is sent to release the voice call.</p> <ul style="list-style-type: none"> ▪ [0] Disable (default) ▪ [1] Rerouting without Delay ▪ [2] Progress and Delay = Incoming ISDN calls are delayed until a CNG tone detection or timeout, set by the FaxReroutingDelay parameter. If the EnableComfortTone parameter is set to 1, a Q.931 Progress message with Protocol Discriminator set to 1 is sent to the PSTN and a comfort tone is played accordingly to the PSTN. When the timeout expires, the device sends an INVITE to a specific IP Group or to a fax server, according to the Outbound IP Routing table rules. This option is applicable only to ISDN. ▪ [3] Connect and Delay = Incoming ISDN calls are delayed until a CNG tone detection or timeout, set by the FaxReroutingDelay parameter. A Q.931 Connect message is sent to the PSTN. If the

Parameter	Description
	<p>EnableComfortTone parameter is set to 1, a comfort tone is played to the PSTN. When the timeout expires, the device sends an INVITE to a specific IP Group or to a fax server according to the Outbound IP Routing table rules. This option is applicable only to ISDN.</p> <p>Note: This parameter has replaced the EnableFaxRerouting parameter. For backward compatibility, the EnableFaxRerouting parameter set to 1 is equivalent to the FaxReroutingMode parameter set to 1.</p>
[FaxReroutingDelay]	<p>Defines the maximum time interval (in seconds) that the device waits for CNG detection before re-routing calls identified as fax calls to fax destinations (terminating fax machine).</p> <p>The valid value range is 1-10. The default is 5.</p>
Web: ENUM Resolution CLI: enum-service-domain [EnumService]	<p>Defines the ENUM service for translating telephone numbers to IP addresses or domain names (FQDN). For example, e164.arpa, e164.customer.net, or NREnum.net.</p> <p>The valid value is a string of up to 50 characters. The default is "e164.arpa".</p> <p>Note: ENUM-based routing is configured in the Outbound IP Routing table using the "ENUM" string value as the destination address to denote this parameter's value.</p>

52.11.13 IP Connectivity Parameters

The IP connectivity parameters are described in the table below.

IP Connectivity Parameters

Parameter	Description
Web: Enable Alt Routing Tel to IP EMS: Enable Alternative Routing [AltRoutingTel2IPEnable]	<p>Enables the Alternative Routing feature for Tel-to-IP calls.</p> <ul style="list-style-type: none"> ▪ [0] Disable = (Default) Disables the Alternative Routing feature. ▪ [1] Enable = Enables the Alternative Routing feature. ▪ [2] Status Only = The Alternative Routing feature is disabled, but read-only information on the QoS of the destination IP addresses is provided.
Web: Alt Routing Tel to IP Mode EMS: Alternative Routing Mode [AltRoutingTel2IPMode]	<p>Determines the IP Connectivity event(s) reason for triggering Alternative Routing.</p> <ul style="list-style-type: none"> ▪ [0] None = Alternative routing is not used. ▪ [1] Connectivity = Alternative routing is performed if a ping or SIP OPTIONS message to the initial destination fails (determined according to the AltRoutingTel2IPConnMethod parameter). ▪ [2] QoS = Alternative routing is performed if poor QoS is detected. ▪ [3] Both = (Default) Alternative routing is performed if either ping or SIP OPTIONS to initial destination fails, poor QoS is detected, or the DNS host name is not resolved. <p>Notes:</p> <ul style="list-style-type: none"> ▪ QoS is quantified according to delay and packet loss calculated according to previous calls. QoS statistics are reset if no new data is received within two minutes.

Parameter	Description
	<ul style="list-style-type: none"> To receive quality information (displayed in the 'Quality Status' and 'Quality Info.' fields in 'Viewing IP Connectivity' on page 558) per destination, this parameter must be set to 2 or 3.
Web: Alt Routing Tel to IP Connectivity Method EMS: Alternative Routing Telephone to IP Connection Method [AltRoutingTel2IPConnMethod]	Determines the method used by the device for periodically querying the connectivity status of a destination IP address. <ul style="list-style-type: none"> [0] ICMP Ping = (Default) Internet Control Message Protocol (ICMP) ping messages. [1] SIP OPTIONS = The remote destination is considered offline if the latest OPTIONS transaction timed out. Any response to an OPTIONS request, even if indicating an error, brings the connectivity status to online.
Web: Alt Routing Tel to IP Keep Alive Time EMS: Alternative Routing Keep Alive Time [AltRoutingTel2IPKeepAliveTime]	Defines the time interval (in seconds) between SIP OPTIONS Keep-Alive messages used for the IP Connectivity application. The valid range is 5 to 2,000,000. The default is 60.
Web: Max Allowed Packet Loss for Alt Routing [%] [IPConnQoSMaxAllowedPL]	Defines the packet loss (in percentage) at which the IP connection is considered a failure and Alternative Routing mechanism is activated. The default is 20%.
Web: Max Allowed Delay for Alt Routing [msec] [IPConnQoSMaxAllowedDelay]	Defines the transmission delay (in msec) at which the IP connection is considered a failure and the Alternative Routing mechanism is activated. The range is 100 to 10,000. The default is 250.

52.11.14 Alternative Routing Parameters

The alternative routing parameters are described in the table below.

Alternative Routing Parameters

Parameter	Description
Web/EMS: Redundant Routing Mode [RedundantRoutingMode]	Determines the type of redundant routing mechanism when a call can't be completed using the main route. <ul style="list-style-type: none"> [0] Disable = No redundant routing is used. If the call can't be completed using the main route (using the active Proxy or the first matching rule in the Routing table), the call is disconnected. [1] Routing Table = (Default) Internal routing table is used to locate a redundant route. [2] Proxy = Proxy list is used to locate a redundant route. <p>Note: To implement the Redundant Routing Mode mechanism, you first need to configure the parameter AltRouteCauseTEL2IP (Reasons for Alternative Routing table).</p>
[EnableAltMapTel2IP]	Enables different Tel-to-IP destination number manipulation rules per routing rule when several (up to three) Tel-to-IP routing rules are defined and if alternative routing using release causes is used. For example, if an INVITE message for a Tel-to-IP call is returned with a SIP 404 Not Found response, the call can be re-sent to a different destination number (as defined using the parameter

Parameter	Description
	NumberMapTel2IP). <ul style="list-style-type: none"> ▪ [0] = Disable (default) ▪ [1] = Enable
Web/EMS: Alternative Routing Tone Duration [ms] [AltRoutingToneDuration]]	Defines the duration (in milliseconds) for which the device plays a tone to the endpoint on each attempt for Tel-to-IP alternative routing. When the device finishes playing the tone, a new SIP INVITE message is sent to the new IP destination. The tone played is the call forward tone (Tone Type #25 in the CPT file). The valid range is 0 to 20,000. The default is 0 (i.e., no tone is played). Note: This parameter is applicable only to Tel-to-IP alternative routing.
Reasons for Alternative Tel-to-IP Routing Table	
Web: Reasons for Alternative Routing EMS: Alt Route Cause Tel to IP [AltRouteCauseTel2IP]	This table parameter configures SIP call failure reason values received from the IP side. If an IP call is released as a result of one of these reasons, the device attempts to locate an alternative IP route for the call in the Outbound IP Routing Table (if a Proxy is not used) or used as a redundant Proxy (you need to set the parameter RedundantRoutingMode to 2). The release reason for Tel-to-IP calls is provided in SIP 4xx, 5xx, and 6xx response codes. The format of this parameter is as follows: [AltRouteCauseTel2IP] FORMAT AltRouteCauseTel2IP_Index = AltRouteCauseTel2IP_ReleaseCause; [AltRouteCauseTel2IP] For example: AltRouteCauseTel2IP 0 = 486; (Busy Here) AltRouteCauseTel2IP 1 = 480; (Temporarily Unavailable) AltRouteCauseTel2IP 2 = 408; (No Response) Note: For a detailed description of this table, see 'Alternative Routing Based on SIP Responses' on page 338.
Reasons for Alternative IP-to-Tel Routing Table	
Web: Reasons for Alternative IP-to-Tel Routing EMS: Alt Route Cause IP to Tel [AltRouteCauseIP2Tel]	This table parameter configures call failure reason values received from the PSTN side (in Q.931 presentation). If a call is released as a result of one of these reasons, the device attempts to locate an alternative Trunk Group for the call in the Inbound IP Routing Table. The format of this parameter is as follows: [AltRouteCauseIP2Tel] FORMAT AltRouteCauseIP2Tel_Index = AltRouteCauseIP2Tel_ReleaseCause; [AltRouteCauseIP2Tel] For example: AltRouteCauseIP2Tel 0 = 3 (No Route to Destination) AltRouteCauseIP2Tel 1 = 1 (Unallocated Number) AltRouteCauseIP2Tel 2 = 17 (Busy Here) AltRouteCauseIP2Tel 2 = 27 (Destination Out of Order) Note: For a detailed description of this table, see 'Alternative Routing to Trunk upon Q.931 Call Release Cause Code' on page 340.
Forward On Busy Trunk Destination Table	
Web/EMS: Forward On	This table parameter configures the Forward On Busy Trunk

Parameter	Description
Busy Trunk Destination [ForwardOnBusyTrunkDest]	Destination table. This table allows you to define an alternative IP destination if a trunk is busy for IP-to-Tel calls. The format of this parameter is as follows: [ForwardOnBusyTrunkDest] FORMAT ForwardOnBusyTrunkDest_Index = ForwardOnBusyTrunkDest_TrunkGroupId, ForwardOnBusyTrunkDest_ForwardDestination; [ForwardOnBusyTrunkDest] For example, the below configuration forwards IP-to-Tel calls to destination user "112" at host IP address 10.13.4.12, port 5060, using transport protocol TCP, if Trunk Group ID 2 is unavailable: ForwardOnBusyTrunkDest 1 = 2, 112@10.13.4.12:5060;transport=tcp; Note: For a detailed description of this table, see 'Alternative Routing to IP Destination upon Busy Trunk' on page 341.

52.11.15 Number Manipulation Parameters

The number manipulation parameters are described in the table below.

Number Manipulation Parameters

Parameter	Description
[ManipulateIP2PSTNReferTo]	Enables the manipulation of the called party (destination) number according to the SIP Refer-To header received by the device for TDM (PSTN) blind transfer. The number in the SIP Refer-To header is manipulated for all types of blind transfers to the PSTN (TBCT, ECT, RLT, QSIG, FXO, and CAS). <ul style="list-style-type: none"> ▪ [0] Disable (default) ▪ [1] Enable During the blind transfer, the device initiates a new call to the PSTN and the destination number of this call can be manipulated if this parameter is enabled. When enabled, the manipulation is done as follows: <ol style="list-style-type: none"> 1 If you configure a value for the xferPrefix parameter, then this value (string) is added as a prefix to the number in the Refer-To header. 2 This called party number is then manipulated using the IP-to-Tel Destination Phone Number Manipulation table. The source number of the transferred call is taken from the original call, according to its initial direction: <ul style="list-style-type: none"> ✓ Source number of the original call if it is a Tel-to-IP call ✓ Destination number of the original call if it is an IP-to-Tel call This source number can also be used as the value for the 'Source Prefix' field in the IP-to-Tel Destination Phone Number Manipulation table. The local IP address is used as the value for the 'Source IP Address' field. Note: This manipulation does not affect IP-to-Trunk Group routing rules.
Web: Use EndPoint Number As Calling Number Tel2IP EMS: Use EP Number As Calling Number Tel to IP [UseEPNumAsCallingNum]	Enables the use of the B-channel number as the calling number (sent in the From field of the INVITE) instead of the number received in the Q.931 Setup message, for Tel-to-IP calls. <ul style="list-style-type: none"> ▪ [0] Disable (default)

Parameter	Description
Tel2IP]	<ul style="list-style-type: none"> ▪ [1] Enable <p>For example, if the incoming calling party number in the Q.931 Setup message is "12345" and the B-channel number is 17, then the outgoing INVITE From header is set to "17" instead of "12345".</p> <p>Note: When enabled, this feature is applied before routing and manipulation on the source number.</p>
Web: Use EndPoint Number As Calling Number IP2Tel EMS: Use EP Number As Calling Number IP to Tel [UseEPNumAsCallingNumIP2Tel]	<p>Enables the use of the B-channel number as the calling party number (sent in the Q.931 Setup message) instead of the number received in the From header of the INVITE, for IP-to-Tel calls.</p> <ul style="list-style-type: none"> ▪ [0] Disable (default) ▪ [1] Enable <p>For example, if the incoming INVITE From header contains "12345" and the destined B-channel number is 17, then the outgoing calling party number in the Q.931 Setup message is set to "17" instead of "12345".</p> <p>Note: When enabled, this feature is applied after routing and manipulation on the source number (i.e., just before sending to the Tel side).</p>
Web: Tel2IP Default Redirect Reason [Tel2IPDefaultRedirectReason]	<p>Determines the default redirect reason for Tel-to-IP calls when no redirect reason (or "unknown") exists in the received Q931 ISDN Setup message. The device includes this default redirect reason in the SIP History-Info header of the outgoing INVITE.</p> <p>If a redirect reason exists in the received Setup message, this parameter is ignored and the device sends the INVITE message with the reason according to the received Setup message. If this parameter is not configured (-1), the outgoing INVITE is sent with the redirect reason as received in the Setup message (if none or "unknown" reason, then without a reason).</p> <ul style="list-style-type: none"> ▪ [-1] Not Configured = (Default) Received redirect reason is not changed ▪ [1] Busy = Call forwarding busy ▪ [2] No Reply = Call forwarding no reply ▪ [9] DTE Out of Order = Call forwarding DTE out of order ▪ [10] Deflection = Call deflection ▪ [15] Systematic/Unconditional = Call forward unconditional
Web: Redirect Number SIP to TEL EMS: Set IP To Tel Redirect Screening Indicator [SetIp2TelRedirectScreeningInd]	<p>Determines the value of the Redirect Number screening indicator in ISDN Setup messages.</p> <ul style="list-style-type: none"> ▪ [-1] Not Configured (default) ▪ [0] User Provided ▪ [1] User Passed ▪ [2] User Failed ▪ [3] Network Provided <p>Note: This parameter is applicable only to digital PSTN interfaces (ISDN).</p>
Web: Set IP-to-TEL Redirect Reason [SetIp2TelRedirectReason]	<p>Defines the redirect reason for IP-to-Tel calls. If redirect (diversion) information is received from the IP, the redirect reason is set to the value of this parameter before the device sends it on to the Tel.</p> <ul style="list-style-type: none"> ▪ [-1] Not Configured (default) ▪ [0] Unkown ▪ [1] Busy

Parameter	Description
	<ul style="list-style-type: none"> ▪ [2] No Reply ▪ [3] Network Busy ▪ [4] Deflection ▪ [9] DTE out of Order ▪ [10] Forwarding DTE ▪ [13] Transfer ▪ [14] PickUp ▪ [15] Systematic/Unconditional <p>Note: This parameter is applicable only to digital PSTN interfaces (ISDN).</p>
Web: Set TEL-to-IP Redirect Reason [SetTel2IpRedirectReason]	Defines the redirect reason for Tel-to-IP calls. If redirect (diversion) information is received from the Tel, the redirect reason is set to the value of this parameter before the device sends it on to the IP. <ul style="list-style-type: none"> ▪ [-1] Not Configured (default) ▪ [0] Unkown ▪ [1] Busy ▪ [2] No Reply ▪ [3] Network Busy ▪ [4] Deflection ▪ [9] DTE out of Order ▪ [10] Forwarding DTE ▪ [13] Transfer ▪ [14] PickUp ▪ [15] Systematic/Unconditional <p>Note: This parameter is applicable only to digital PSTN interfaces (ISDN).</p>
Web: Send Screening Indicator to IP EMS: Screening Indicator To IP [ScreeningInd2IP]	Overrides the calling party's number (CPN) screening indication in the received ISDN SETUP message for Tel-to-IP calls. <ul style="list-style-type: none"> ▪ [-1] Not Configured = (Default) Not configured (interworking from ISDN to IP) or set to 0 for CAS. ▪ [0] User Provided = CPN set by user, but not screened (verified). ▪ [1] User Passed = CPN set by user, verified and passed. ▪ [2] User Failed = CPN set by user, and verification failed. ▪ [3] Network Provided = CPN set by network. <p>Note: This parameter is applicable only if the Remote Party ID (RPID) header is enabled.</p>
Web: Send Screening Indicator to ISDN EMS: Screening Indicator To ISDN [ScreeningInd2ISDN]	Overrides the screening indicator of the calling party's number for IP-to-Tel ISDN calls. <ul style="list-style-type: none"> ▪ [-1] Not Configured = (Default) Not configured (interworking from IP to ISDN). ▪ [0] User Provided = user provided, not screened. ▪ [1] User Passed = user provided, verified and passed. ▪ [2] User Failed = user provided, verified and failed. ▪ [3] Network Provided = network provided <p>Note: This parameter is applicable only to digital PSTN interfaces (ISDN).</p>
Web: Copy Destination Number to Redirect Number EMS: Copy Dest to Redirect	Determines whether the device copies the received ISDN (digital interfaces) called number to the outgoing SIP Diversion header for Tel-to-IP calls (even if a Redirecting Number IE is not received in the ISDN)

Parameter	Description
Number [CopyDest2RedirectNumber]	<p>Setup message, for digital interfaces). Therefore, the called number is used as a redirect number. Call redirection information is typically used for Unified Messaging and voice mail services to identify the recipient of a message.</p> <ul style="list-style-type: none"> ▪ [0] Don't copy = (Default) Disable. ▪ [1] Copy after phone number manipulation = Copies the called number after manipulation. The device first performs Tel-to-IP destination phone number manipulation (i.e., on the SIP To header), and only then copies the manipulated called number to the SIP Diversion header for the Tel-to-IP call. Therefore, with this option, the called and redirect numbers are identical. ▪ [2] Copy before phone number manipulation = Copies the called number before manipulation. The device first copies the original called number to the SIP Diversion header, and then performs Tel-to-IP destination phone number manipulation. Therefore, this allows you to have different numbers for the called (i.e., SIP To header) and redirect (i.e., SIP Diversion header) numbers. <p>Notes:</p> <ul style="list-style-type: none"> ▪ For digital interfaces: If the incoming ISDN-to-IP call includes a Redirect Number, this number is overridden by the new called number if this parameter is set to [1] or [2]. ▪ When configured in an IP Profile, this parameter can also be used for IP-to-Tel calls. The device can overwrite the redirect number with the destination number from the received SIP INVITE message in the outgoing ISDN call. This is achieved by assigning an IP Profile (IPProfile parameter) defined with the CopyDest2RedirectNumber parameter set to 1, to the IP-to-Tel Routing table (PSTNPrefix parameter). Even if there is no SIP Diversion or History header in the incoming INVITE message, the outgoing Q.931 Setup message will contain a redirect number. ▪ This parameter can also be configured in an IP Profile.
[ReplaceCallingWithRedirectNumber]	<p>Enables the replacement of the calling number with the redirect number for ISDN-to-IP calls.</p> <ul style="list-style-type: none"> ▪ [0] = Disable (default) ▪ [1] = The calling name is removed and left blank. The outgoing INVITE message excludes the redirect number that was used to replace the calling number. The replacement is done only if a redirect number is present in the incoming Tel call. ▪ [2] = Manipulation is done on the new calling party number (after manipulation of the original calling party number, using the Tel2IPSourceNumberMappingDialPlanIndex parameter), but before the regular calling or redirect number manipulation: <ul style="list-style-type: none"> ✓ If a redirect number exists, it replaces the calling party number. If there is no redirect number, the calling number is left unchanged. ✓ If there is a calling "display" name, it remains unchanged. ✓ The redirect number remains unchanged and is included in the SIP Diversion header.
Web/EMS: Add Trunk Group ID as Prefix [AddTrunkGroupAsPrefix]	<p>Determines whether the Trunk Group ID is added as a prefix to the destination phone number (i.e., called number) for Tel-to-IP calls.</p> <ul style="list-style-type: none"> ▪ [0] No = (Default) Don't add Trunk Group ID as prefix. ▪ [1] Yes = Add Trunk Group ID as prefix to called number.

Parameter	Description
	<p>Notes:</p> <ul style="list-style-type: none"> ▪ This option can be used to define various routing rules. ▪ To use this feature, you must configure the Trunk Group IDs (see Configuring Trunk Group Table on page 291).
Web: Add Trunk ID as Prefix EMS: Add Port ID As Prefix [AddPortAsPrefix]	Determines whether or not the port number / Trunk ID is added as a prefix to the called (destination) number for Tel-to-IP calls. <ul style="list-style-type: none"> ▪ [0] No (Default) ▪ [1] Yes If enabled, the device adds the following prefix to the called phone number: slot number (a single digit in the range of 1 to 6) and port number / Trunk ID (single digit in the range 1 to 8). For example, for the first trunk/channel located in the first slot, the number "11" is added as the prefix. <p>This option can be used to define various routing rules.</p>
Web/EMS: Add Trunk Group ID as Prefix to Source [AddTrunkGroupAsPrefixToSource]	Determines whether the device adds the Trunk Group ID (from where the call originated) as the prefix to the calling number (i.e. source number). <ul style="list-style-type: none"> ▪ [0] No (default) ▪ [1] Yes
Web: Replace Empty Destination with B-channel Phone Number EMS: Replace Empty Dst With Port Number [ReplaceEmptyDstWithPortNumber]	Determines whether the internal channel number is used as the destination number if the called number is missing. <ul style="list-style-type: none"> ▪ [0] No (default) ▪ [1] Yes <p>Note: This parameter is applicable only to Tel-to-IP calls and if the called number is missing.</p>
[CopyDestOnEmptySource]	Determines whether the destination number is copied to the source number if no source number is present, for Tel-to-IP calls. <ul style="list-style-type: none"> ▪ [0] = (Default) Source Number is left empty. ▪ [1] = If the Source Number of a Tel-to-IP call is empty, the Destination Number is copied to the Source Number.
Web: Add NPI and TON to Calling Number EMS: Add NPI And TON As Prefix To Calling Number [AddNPIandTON2CallingNumber]	Determines whether the Numbering Plan Indicator (NPI) and Type of Numbering (TON) are added to the Calling Number for Tel-to-IP calls. <ul style="list-style-type: none"> ▪ [0] No = (Default) Do not change the Calling Number. ▪ [1] Yes = Add NPI and TON to the Calling Number ISDN Tel-to-IP call. For example: After receiving a Calling Number of 555, NPI of 1, and TON of 3, the modified number becomes 13555. This number can later be used for manipulation and routing.
Web: Add NPI and TON to Called Number EMS: Add NPI And TON As Prefix To Called Number [AddNPIandTON2CalledNumber]	Determines whether NPI and TON are added to the Called Number for Tel-to-IP calls. <ul style="list-style-type: none"> ▪ [0] No = (Default) Do not change the Called Number. ▪ [1] Yes = Add NPI and TON to the Called Number of ISDN Tel-to-IP call. For example: After receiving a Called Number of 555, NPI of 1 and TON of 3, the modified number becomes 13555. This number can later be used for manipulation and routing.

Parameter	Description
Web: Add NPI and TON to Redirect Number [AddNPIandTON2RedirectNumber]	<p>Determines whether the NPI and TON values are added as the prefix to the Redirect number in INVITE messages' Diversion or History-Info headers, for ISDN Tel-to-IP calls.</p> <ul style="list-style-type: none"> ▪ [0] Yes (Default) ▪ [1] No
Web: IP to Tel Remove Routing Table Prefix EMS: Remove Prefix [RemovePrefix]	<p>Determines whether or not the device removes the prefix (as configured in the Inbound IP Routing Table - see 'Configuring Inbound IP Routing Table' on page 332) from the destination number for IP-to-Tel calls, before sending it to the Tel.</p> <ul style="list-style-type: none"> ▪ [0] No (default) ▪ [1] Yes <p>For example: To route an incoming IP-to-Tel call with destination number "21100", the Inbound IP Routing Table is scanned for a matching prefix. If such a prefix is found (e.g., "21"), then before the call is routed to the corresponding Trunk Group, the prefix "21" is removed from the original number, and therefore, only "100" remains.</p> <p>Notes:</p> <ul style="list-style-type: none"> ▪ This parameter is applicable only if number manipulation is performed after call routing for IP-to-Tel calls (i.e., RouteModelP2Tel parameter is set to 0). ▪ Similar operation (of removing the prefix) is also achieved by using the usual number manipulation rules.
Web/EMS: Swap Redirect and Called Numbers [SwapRedirectNumber]	<ul style="list-style-type: none"> ▪ [0] No = (Default) Don't change numbers. ▪ [1] Yes = Incoming ISDN call that includes a redirect number (sometimes referred to as 'original called number') uses the redirect number instead of the called number.
[UseReferredByForCallingNumber]	<p>Determines whether the device uses the number from the URI in the SIP Referred-By header as the calling number in the outgoing Q.931 Setup message, when SIP REFER messages are received.</p> <ul style="list-style-type: none"> ▪ [0] = (Default) No ▪ [1] = Yes <p>Notes:</p> <ul style="list-style-type: none"> ▪ This parameter is applicable to all ISDN (TBCT, RLT, ECT) and CAS blind call transfers (except for in-band) and when the device receives SIP REFER messages with a Referred-By header. ▪ This manipulation is done before regular IP-to-Tel source number manipulation.
[SwapTel2IPCalled&CallingNumbers]	<p>Determines whether the device swaps the calling and called numbers received from the Tel side (for Tel-to-IP calls). The SIP INVITE message contains the swapped numbers.</p> <ul style="list-style-type: none"> ▪ [0] = (Default) Disabled ▪ [1] = Swap calling and called numbers <p>Note: This parameter can also be configured in a Tel Profile.</p>
Web/EMS: Add Prefix to Redirect Number [Prefix2RedirectNumber]	<p>Defines a string prefix that is added to the Redirect number received from the Tel side. This prefix is added to the Redirect Number in the SIP Diversion header.</p> <p>The valid range is an 8-character string. The default is an empty string.</p>
Web: Add Number Plan and Type to RPI Header	<p>Determines whether the TON/PLAN parameters are included in the Remote-Party-ID (RPID) header.</p>

Parameter	Description
EMS: Add Ton 2 RPI [AddTON2RPI]	<ul style="list-style-type: none"> ▪ [0] No ▪ [1] Yes (default) If the Remote-Party-ID header is enabled (EnableRPIHeader = 1) and AddTON2RPI = 1, it's possible to configure the calling and called number type and number plan using the Number Manipulation tables for Tel-to-IP calls.
Web/EMS: Source Manipulation Mode [SourceManipulationMode]	Determines the SIP headers containing the source number after manipulation: <ul style="list-style-type: none"> ▪ [0] = (Default) The SIP From and P-Asserted-Identity headers contain the source number after manipulation. ▪ [1] = Only SIP From header contains the source number after manipulation, while the P-Asserted-Identity header contains the source number before manipulation.
Calling Name Manipulations IP-to-Tel Table	
[CallingNameMapIp2Tel]	Configures rules for manipulating the calling name (caller ID) in the received SIP message for IP-to-Tel calls. This can include modifying or removing the calling name. The format of this table ini file parameter is as follows: <pre>[CallingNameMapIp2Tel] FORMAT CallingNameMapIp2Tel_Index = CallingNameMapIp2Tel_DestinationPrefix, CallingNameMapIp2Tel_SourcePrefix, CallingNameMapIp2Tel_CallingNamePrefix, CallingNameMapIp2Tel_SourceAddress, CallingNameMapIp2Tel_RemoveFromLeft, CallingNameMapIp2Tel_RemoveFromRight, CallingNameMapIp2Tel_LeaveFromRight, CallingNameMapIp2Tel_Prefix2Add, CallingNameMapIp2Tel_Suffix2Add; [\CallingNameMapIp2Tel]</pre> <p>Note: For a detailed description of this table, see 'Configuring SIP Calling Name Manipulation' on page 306.</p>
Calling Name Manipulations Tel-to-IP Table	
[CallingNameMapTel2Ip]	This table parameter configures rules for manipulating the calling name (caller ID) for Tel-to-IP calls. This can include modifying or removing the calling name. <pre>[CallingNameMapTel2Ip] FORMAT CallingNameMapTel2Ip_Index = CallingNameMapTel2Ip_DestinationPrefix, CallingNameMapTel2Ip_SourcePrefix, CallingNameMapTel2Ip_CallingNamePrefix, CallingNameMapTel2Ip_SrcTrunkGroupID, CallingNameMapTel2Ip_SrcIPGroupID, CallingNameMapTel2Ip_RemoveFromLeft, CallingNameMapTel2Ip_RemoveFromRight, CallingNameMapTel2Ip_LeaveFromRight, CallingNameMapTel2Ip_Prefix2Add, CallingNameMapTel2Ip_Suffix2Add; [\CallingNameMapTel2Ip]</pre> <p>Note: For a detailed description of this table, see 'Configuring SIP Calling Name Manipulation' on page 306.</p>
Destination Phone Number Manipulation for IP-to-Tel Calls Table	

Parameter	Description
Web: Destination Phone Number Manipulation Table for IP > Tel Calls EMS: SIP Manipulations > Destination IP to Telcom [NumberMapIP2Tel]	This table parameter manipulates the destination number of IP-to-Tel calls. The format of this parameter is as follows: [NumberMapIP2Tel] FORMAT NumberMapIP2Tel_Index = NumberMapIP2Tel_DestinationPrefix, NumberMapIP2Tel_SourcePrefix, NumberMapIP2Tel_SourceAddress, NumberMapIP2Tel_NumberType, NumberMapIP2Tel_NumberPlan, NumberMapIP2Tel_RemoveFromLeft, NumberMapIP2Tel_RemoveFromRight, NumberMapIP2Tel_LeaveFromRight, NumberMapIP2Tel_Prefix2Add, NumberMapIP2Tel_Suffix2Add, NumberMapIP2Tel_IsPresentationRestricted; [NumberMapIP2Tel] For example: NumberMapIP2Tel 0 = 01,034,10.13.77.8,\$\$,0,\$\$,2,\$\$,667,\$\$; NumberMapIP2Tel 1 = 10,10,1.1.1.1,255,255,3,0,5,100,\$\$,255; Note: For a detailed description of this table, see 'Configuring Source/Destination Number Manipulation' on page 299.
EMS: Perform Additional IP2TEL Destination Manipulation [PerformAdditionalIP2TEL DestinationManipulation]	Enables additional destination number manipulation for IP-to-Tel calls. The additional manipulation is done on the initially manipulated destination number, and this additional rule is also configured in the manipulation table (NumberMapIP2Tel parameter). This enables you to configure only a few manipulation rules for complex number manipulation requirements (that generally require many rules). <ul style="list-style-type: none"> ▪ [0] = Disable (default) ▪ [1] = Enable
Destination Phone Number Manipulation for Tel-to-IP Calls Table	
Web: Destination Phone Number Manipulation Table for Tel > IP Calls EMS: SIP Manipulations > Destination Telcom to IPs [NumberMapTel2IP]	This table parameter manipulates the destination number of Tel-to-IP calls. The format of this parameter is as follows: [NumberMapTel2Ip] FORMAT NumberMapTel2Ip_Index = NumberMapTel2Ip_DestinationPrefix, NumberMapTel2Ip_SourcePrefix, NumberMapTel2Ip_SourceAddress, NumberMapTel2Ip_NumberType, NumberMapTel2Ip_NumberPlan, NumberMapTel2Ip_RemoveFromLeft, NumberMapTel2Ip_RemoveFromRight, NumberMapTel2Ip_LeaveFromRight, NumberMapTel2Ip_Prefix2Add, NumberMapTel2Ip_Suffix2Add, NumberMapTel2Ip_IsPresentationRestricted, NumberMapTel2Ip_SrcTrunkGroupID, NumberMapTel2Ip_SrcIPGroupID; [NumberMapTel2Ip] For example: NumberMapTel2Ip 0 = 01,\$\$,*,0,0,2,\$\$,971,\$\$,,\$\$,,\$\$; NumberMapTel2Ip 1 = 10,10,*,255,255,3,0,5,100,\$\$,255,\$\$,,\$\$; Note: For a detailed description of this table, see 'Configuring Source/Destination Number Manipulation' on page 299.
Source Phone Number Manipulation for IP-to-Tel Calls Table	
Web: Source Phone Number Manipulation Table for IP > Tel Calls EMS: SIP Manipulations > Source IP to Telcom	This parameter table manipulates the source number for IP-to-Tel calls. The format of this parameter is as follows: [SourceNumberMapIP2Tel] FORMAT SourceNumberMapIP2Tel_Index = SourceNumberMapIP2Tel_DestinationPrefix,

Parameter	Description
[SourceNumberMapIP2Tel]	SourceNumberMapIp2Tel_SourcePrefix, SourceNumberMapIp2Tel_SourceAddress, SourceNumberMapIp2Tel_NumberType, SourceNumberMapIp2Tel_NumberPlan, SourceNumberMapIp2Tel_RemoveFromLeft, SourceNumberMapIp2Tel_RemoveFromRight, SourceNumberMapIp2Tel_LeaveFromRight, SourceNumberMapIp2Tel_Prefix2Add, SourceNumberMapIp2Tel_Suffix2Add, SourceNumberMapIp2Tel_IsPresentationRestricted; [SourceNumberMapIp2Tel] For example: SourceNumberMapIp2Tel 0 = 22,03,\$,\$,\$,\$,\$,2,667,\$,\$,\$; SourceNumberMapIp2Tel 1 = 034,01,1.1.1.1,\$\$,0,2,\$,\$,\$,972,\$\$,10; Note: For a detailed description of this table, see 'Configuring Source/Destination Number Manipulation' on page 299.
EMS: Perform Additional IP2TEL Source Manipulation [PerformAdditionalIP2TEL SourceManipulation]	Enables additional source number manipulation for IP-to-Tel calls. The additional manipulation is done on the initially manipulated source number, and this additional rule is also configured in the manipulation table (SourceNumberMapIP2Tel parameter). This enables you to configure only a few manipulation rules for complex number manipulation requirements (that generally require many rules). <ul style="list-style-type: none"> ▪ [0] = Disable (default) ▪ [1] = Enable
Source Phone Number Manipulation for Tel-to-IP Calls Table	
Web: Source Phone Number Manipulation Table for Tel > IP Calls EMS: SIP Manipulations > Source Telcom to IP [SourceNumberMapTel2IP]	This table parameter manipulates the source phone number for Tel-to-IP calls. The format of this parameter is as follows: [SourceNumberMapTel2Ip] FORMAT SourceNumberMapTel2Ip_Index = SourceNumberMapTel2Ip_DestinationPrefix, SourceNumberMapTel2Ip_SourcePrefix, SourceNumberMapTel2Ip_SourceAddress, SourceNumberMapTel2Ip_NumberType, SourceNumberMapTel2Ip_NumberPlan, SourceNumberMapTel2Ip_RemoveFromLeft, SourceNumberMapTel2Ip_RemoveFromRight, SourceNumberMapTel2Ip_LeaveFromRight, SourceNumberMapTel2Ip_Prefix2Add, SourceNumberMapTel2Ip_Suffix2Add, SourceNumberMapTel2Ip_IsPresentationRestricted, NumberMapTel2Ip_SrcTrunkGroupID, NumberMapTel2Ip_SrcIPGroupID; [SourceNumberMapTel2Ip] For example: SourceNumberMapTel2Ip 0 = 22,03,\$\$,0,0,\$\$,2,\$\$,667,\$\$,0,\$,\$,\$; SourceNumberMapTel2Ip 0 = 10,10,*,255,255,3,0,5,100,\$\$,255,\$,\$,\$; Note: For a detailed description of this table, see 'Configuring Source/Destination Number Manipulation' on page 299.
Redirect Number IP -to-Tel Table	
Web: Redirect Number IP -> Tel EMS: Redirect Number Map	This table parameter manipulates the redirect number for IP-to-Tel calls. The format of this parameter is as follows:

Parameter	Description
IP to Tel [RedirectNumberMapIp2Tel]	[RedirectNumberMapIp2Tel] FORMAT RedirectNumberMapIp2Tel_Index = RedirectNumberMapIp2Tel_DestinationPrefix, RedirectNumberMapIp2Tel_RedirectPrefix, RedirectNumberMapIp2Tel_SourceAddress, RedirectNumberMapIp2Tel_SrcHost, RedirectNumberMapIp2Tel_DestHost, RedirectNumberMapIp2Tel_NumberType, RedirectNumberMapIp2Tel_NumberPlan, RedirectNumberMapIp2Tel_RemoveFromLeft, RedirectNumberMapIp2Tel_RemoveFromRight, RedirectNumberMapIp2Tel_LeaveFromRight, RedirectNumberMapIp2Tel_Prefix2Add, RedirectNumberMapIp2Tel_Suffix2Add, RedirectNumberMapIp2Tel_IsPresentationRestricted; [RedirectNumberMapIp2Tel] For example: RedirectNumberMapIp2Tel 1 = *, 88, *, , , 1, 1, 2, 0, 255, 9, , 255; Note: For a description of this table, see Configuring Redirect Number Manipulation on page 309.
Redirect Number Tel-to-IP Table	
Web: Redirect Number Tel -> IP EMS: Redirect Number Map Tel to IP [RedirectNumberMapTel2IP]	This table parameter manipulates the Redirect Number for Tel-to-IP calls. The format of this parameter is as follows: [RedirectNumberMapTel2IP] FORMAT RedirectNumberMapTel2IP_Index = RedirectNumberMapTel2IP_DestinationPrefix, RedirectNumberMapTel2IP_RedirectPrefix, RedirectNumberMapTel2IP_RemoveFromLeft, RedirectNumberMapTel2IP_RemoveFromRight, RedirectNumberMapTel2IP_LeaveFromRight, RedirectNumberMapTel2IP_Prefix2Add, RedirectNumberMapTel2IP_Suffix2Add, RedirectNumberMapTel2IP_IsPresentationRestricted, RedirectNumberMapTel2IP_SrcTrunkGroupID, RedirectNumberMapTel2IP_SrcIPGroupID; [RedirectNumberMapTel2IP] For example: RedirectNumberMapTel2IP 1 = *, *, 4, 0, 255, , , 255, -1, -1; Note: For a description of this table, see 'Configuring Redirect Number Manipulation' on page 309.
Phone Context Table	
Web: Phone Context Table EMS: SIP Manipulations > Phone Context [PhoneContext]	This table parameter configures the Phone Context table. This parameter maps NPI and TON to the SIP 'phone-context' parameter, and vice versa. The format for this parameter is as follows: [PhoneContext] FORMAT PhoneContext_Index = PhoneContext_Npi, PhoneContext_Ton, PhoneContext_Context; [PhoneContext] For example: PhoneContext 0 = 0,0,unknown.com PhoneContext 1 = 1,1,host.com

Parameter	Description
	PhoneContext 2 = 9,1,na.e164.host.com Note: For a detailed description of this table, see 'Mapping NPI/TON to SIP Phone-Context' on page 313.
Web/EMS: Add Phone Context As Prefix [AddPhoneContextAsPrefix]	Determines whether the received Phone-Context parameter is added as a prefix to the outgoing ISDN Setup message with (for digital interfaces) Called and Calling numbers. <ul style="list-style-type: none"> ▪ [0] Disable (default) ▪ [1] Enable

52.12 Least Cost Routing Parameters

The Least Cost Routing (LCR) parameters are described in the table below.

LCR Parameters

Parameter	Description
Web: Routing Rule Groups Table [RoutingRuleGroups]	This table parameter enables the LCR feature and configures the average call duration and default call cost. The default call cost determines whether routing rules that are not configured with a Cost Group are considered as a higher or lower cost route compared to other matching routing rules that are assigned Cost Groups. [RoutingRuleGroups] FORMAT RoutingRuleGroups_Index = RoutingRuleGroups_LCREnable, RoutingRuleGroups_LCRAverageCallLength, RoutingRuleGroups_LCRDefaultCost; [\RoutingRuleGroups] Note: For a detailed description of this table, see 'Enabling LCR and Configuring Default LCR' on page 204.
Web: Cost Group Table EMS: Cost Group Provisioning > Cost Group [CostGroupTable]	This table parameter configures the Cost Groups for LCR, where each Cost Group is configured with a name, fixed call connection charge, and a call rate (charge per minute). [CostGroupTable] FORMAT CostGroupTable_Index = CostGroupTable_CostGroupName, CostGroupTable_DefaultConnectionCost, CostGroupTable_DefaultMinuteCost; [\CostGroupTable] For example: CostGroupTable 2 = "Local Calls", 2, 1; Note: For a detailed description of this table, see 'Configuring Cost Groups' on page 206.

Parameter	Description
Web: Cost Group > Time Band Table EMS: Time Band Provisioning > Time Band [CostGroupTimebands]	This table parameter configures time bands and associates them with Cost Groups. [CostGroupTimebands] FORMAT CostGroupTimebands_TimebandIndex = CostGroupTimebands_StartTime, CostGroupTimebands_EndTime, CostGroupTimebands_ConnectionCost, CostGroupTimebands_MinuteCost; [CostGroupTimebands] Note: For a detailed description of this table, see 'Configuring Time Bands for Cost Groups' on page 207.

52.13 LDAP Parameters

The Lightweight Directory Access Protocol (LDAP) parameters are described in the table below. For more information on routing based on LDAP, see 'Routing Based on LDAP Active Directory Queries' on page 193.

LDAP Parameters

Parameter	Description
Web: LDAP Service [LDAPServiceEnable]	Enables the LDAP feature. <ul style="list-style-type: none"> [0] Disable (default) [1] Enable Note: For this parameter to take effect, a device reset is required.
Web: LDAP Server IP EMS: Server Ip [LDAPServerIP]	Defines the LDAP server's address as an IP address (in dotted-decimal notation, e.g., 192.10.1.255). The default is 0.0.0.0.
Web: LDAP Server Port EMS: Server Port [LDAPServerPort]	Defines the LDAP server's port number. The valid value range is 0 to 65535. The default port number is 389.
Web: LDAP Server Domain Name EMS: Server Domain Name [LDAPServerDomainName]	Defines the host name (FQDN) of the LDAP server. The device tries to connect to the LDAP server according to the IP address list received in the DNS query. If there is no connection to the LDAP server or the connection to the LDAP server fails, the device tries to connect to the LDAP server with the next IP address in the DNS query list. Note: The 'LDAP Server IP' parameter takes precedence over this parameter. Thus, if you want to use an FQDN, keep the 'LDAP Server IP' parameter empty.
Web: LDAP Password EMS: Password [LDAPPassword]	Defines the LDAP server's user password.
Web: LDAP Bind DN EMS: Bind DN [LDAPBindDN]	Defines the LDAP server's bind Distinguished Name (DN). This is used as the username during connection and binding to the server. For example: LDAPBindDN = "CN=Search user,OU=Labs,DC=OCSR2,DC=local" Note: The DN is used to uniquely name an Active Directory object.
Web: LDAP Search Dn	Defines up to three search DN's for LDAP search queries. These are

Parameter	Description
EMS: Search DN [LDAPSearchDN]	the DN subtrees where the search is done. This parameter is mandatory for the search. The format of this parameter is as follows: [LdapSearchDNs] FORMAT LdapSearchDNs_Index = LdapSearchDNs_Base_Path; [\LdapSearchDNs] For example: LdapSearchDNs 0 = "CN=Search user,OU=NY,DC=OCSR2,DC=local"; LdapSearchDNs 1 = "CN=Search user,OU=SF,DC=OCSR2,DC=local"; In this example, the DN path is defined by the LDAP names, cn (common name), ou (organizational unit) and dc (domain component). Note: If you configure multiple DN's, you can specify whether the search is done sequentially or in parallel, using the LDAPSearchDNsinParallel parameter.
[LDAPSearchDNsinParallel]	Defines the LDAP query DN search method in the AD database if multiple search DN's are configured, using the LDAPSearchDNs parameter. <ul style="list-style-type: none"> ▪ [0] Sequential = If the first DN search fails, the search is done on the next configured DN, and so on. ▪ [1] Parallel (Default)
Web: LDAP Server Max Respond Time EMS: Server Max Respond Time [LDAPServerMaxRespondTime]	Defines the time (in seconds) that the device waits for LDAP server responses. The valid value range is 0 to 86400. The default is 3000.
[LDAPDebugMode]	Determines whether to enable the LDAP task debug messages. This is used for providing debug information regarding LDAP tasks. The valid value range is 0 to 3. The default is 0.
Web: MS LDAP OCS Number attribute name EMS: LDAP ocs Number Attribute Name [MSLDAPOCSNumAttribute Name]	Defines the name of the attribute that represents the user OCS number in the Microsoft AD database. The valid value is a string of up to 49 characters. The default is "msRTCSIP-PrimaryUserAddress".
Web: MS LDAP PBX Number attribute name [MSLDAPPBXNumAttribute Name]	Defines the name of the attribute that represents the user PBX number in the Microsoft AD database. The valid value is a string of up to 49 characters. The default is "telephoneNumber".
Web: MS LDAP MOBILE Number attribute name [MSLDAPMobileNumAttribute Name]	Defines the name of the attribute that represents the user Mobile number in the Microsoft AD database. The valid value is a string of up to 49 characters. The default is "mobile".

Parameter	Description
[MSLDAPPrivateNumAttribute]	Defines the name of the attribute that represents the user's private number in the AD. If this value equals the value of the MSLDAPPrimaryKey or MSLDAPSecondaryKey parameter, then the device queries the AD for the destination number in this private attribute name; otherwise, this parameter is not used as a search key. The default is "msRTCSIP-PrivateLine".
[MSLDAPDisplayNameAttribute]	Defines the attribute name that represents the Calling Name in the AD for LDAP queries based on calling number. The valid value is a string of up to 49 characters. The default is "displayName".
[MSLDAPPrimaryKey]	Defines the name of the attribute used as a query search key for the destination number in the AD. This is used instead of the "PBX" attribute name (configured by the MSLDAPPBXNumAttributeName parameter). The default is not configured.
[MSLDAPSecondaryKey]	Defines the name of the attribute used as the second query search key for the destination number in the AD, if the primary search key or PBX search is not found.
LDAP Cache Service [LDAPCacheEnable]	Enables the LDAP cache service. <ul style="list-style-type: none"> [0] Disable (default) [1] Enable Notes: <ul style="list-style-type: none"> For this parameter to take effect, a device reset is required. For more information on LDAP caching, see 'Configuring the Device's LDAP Cache' on page 194.
LDAP Cache Entry Timeout [LDAPCacheEntryTimeout]	Defines the duration (in minutes) that an entry in the LDAP cache is valid. If the timeout expires, the cached entry is only used if there is no connectivity with the LDAP server. The default is 1200.
LDAP Cache Entry Removal Timeout [LDAPCacheEntryRemovalTimeout]	Defines the duration (in hours) after which the LDAP entry is removed from the cache. The default is 0.

52.14 Standalone Survivability Parameters

The Stand-alone Survivability (SAS) parameters are described in the table below.

SAS Parameters

Parameter	Description
Web: Enable SAS EMS: Enable [EnableSAS]	Enables the Stand-Alone Survivability (SAS) feature. <ul style="list-style-type: none"> [0] Disable (default) [1] Enable When enabled, the device receives the registration requests from different SIP entities in the local network and then forwards them to the

Parameter	Description
	defined proxy. If the connection to the proxy fails ('Emergency Mode'), the device serves as a proxy by allowing calls internal to the local network or outgoing to PSTN. Note: For this parameter to take effect, a device reset is required.
Web: SAS Local SIP UDP Port EMS: Local SIP UDP [SASLocalSIPUDPPort]	Defines the local UDP port for sending and receiving SIP messages for SAS. The SIP entities in the local network need to send the registration requests to this port. When forwarding the requests to the proxy ('Normal Mode'), this port serves as the source port. The valid range is 1 to 65,534. The default is 5080.
Web: SAS Default Gateway IP EMS: Default Gateway IP [SASDefaultGatewayIP]	Defines the Default Gateway used in SAS 'Emergency Mode'. When an incoming SIP INVITE is received and the destination Address-Of-Record is not included in the SAS database, the request is immediately sent to this default gateway. The address can be configured as an IP address (dotted-decimal notation) or as a domain name (up to 49 characters). You can also configure the IP address with a destination port, e.g., "10.1.2.3:5060". The default is a null string, i.e., the local IP address of the gateway.
Web: SAS Registration Time EMS: Registration Time [SASRegistrationTime]	Defines the value of the SIP Expires header that is sent in a 200 OK response to an incoming REGISTER message when in SAS 'Emergency Mode'. The valid range is 0 (Analog) or 10 (Digital) to 2,000,000. The default is 20.
Web: SAS Local SIP TCP Port EMS: Local SIP TCP Port [SASLocalSIPTCPPort]	Defines the local TCP port used to send/receive SIP messages for the SAS application. The SIP entities in the local network need to send the registration requests to this port. When forwarding the requests to the proxy ('Normal Mode'), this port serves as the source port. The valid range is 1 to 65,534. The default is 5080.
Web: SAS Local SIP TLS Port EMS: Local SIP TLS Port [SASLocalSIPTLSPort]	Defines the local TLS port used to send/receive SIP messages for the SAS application. The SIP entities in the local network need to send the registration requests to this port. When forwarding the requests to the proxy ('Normal Mode'), this port serves as the source port. The valid range is 1 to 65,534. The default is 5081.
Web: SAS Connection Reuse [SASConnectionReuse]	Enables the re-use of the same TCP connection for sessions with the same user in the SAS application. <ul style="list-style-type: none"> ▪ [0] Disable ▪ [1] Enable (default) The device can use the same TCP connection for multiple SIP requests / responses for a specific SIP UA. The benefits of this feature include less CPU and memory usage because fewer TCP connections are open and reduced network congestion. For example, assume the following: <ul style="list-style-type: none"> ▪ User A sends a REGISTER message to SAS with transport=TCP. ▪ User B sends an INVITE message to A using SAS. In this scenario, the SAS application forwards the INVITE request using the TCP connection that User A initially opened with the REGISTER message.
Web/EMS: Enable Record-Route [SASEnableRecordRoute]	Determines whether the device's SAS application adds the SIP Record-Route header to SIP requests. This ensures that SIP messages traverse the device's SAS agent by including the SAS IP address in the Record-Route header.

Parameter	Description
	<ul style="list-style-type: none"> ▪ [0] Disable (default) ▪ [1] Enable <p>The Record-Route header is inserted in a request by a SAS proxy to force future requests in the dialog session to be routed through the SAS agent. Each traversed proxy in the path can insert this header, causing all future dialogs in the session to pass through it as well.</p> <p>When this feature is enabled, the SIP Record-Route header includes the URI "lr" parameter, indicating loose routing, for example:</p> <pre>Record-Route: <sip:server10.biloxi.com;lr></pre>
Web: SAS Proxy Set EMS: Proxy Set [SASProxySet]	<p>Defines the Proxy Set (index number) used in SAS Normal mode to forward REGISTER and INVITE requests from users that are served by the SAS application.</p> <p>The valid range is 0 to 5. The default is 0 (i.e., default Proxy Set).</p>
Web: Redundant SAS Proxy Set EMS: Redundant Proxy Set [RedundantSASProxySet]	<p>Defines the Proxy Set (index number) used in SAS Emergency mode for fallback when the user is not found in the Registered Users database. Each time a new SIP request arrives, the SAS application checks whether the user is listed in the registration database. If the user is located in the database, the request is sent to the user. If the user is not found, the request is forwarded to the next redundant SAS defined in the Redundant SAS Proxy Set. If that SAS Proxy IP appears in the Via header of the request, it is not forwarded (thereby, preventing loops in the request's course). If no such redundant SAS exists, the SAS sends the request to its default gateway (configured by the parameter SASDefaultGatewayIP).</p> <p>The valid range is -1 to 5. The default is -1 (i.e., no redundant Proxy Set).</p>
Web/EMS: SAS Block Unregistered Users [SASBlockUnRegUsers]	<p>Determines whether the device rejects SIP INVITE requests received from unregistered SAS users. This applies to SAS Normal and Emergency modes.</p> <ul style="list-style-type: none"> ▪ [0] Un-Block = (Default) Allow INVITE from unregistered SAS users. ▪ [1] Block = Reject dialog-establishment requests from un-registered SAS users.
[SASEnableContactReplice]	<p>Enables the device to change the SIP Contact header so that it points to the SAS host and therefore, the top-most SIP Via header and the Contact header point to the same host.</p> <ul style="list-style-type: none"> ▪ [0] (default) = Disable - when relaying requests, the SAS agent adds a new Via header (with the SAS IP address) as the top-most Via header and retains the original Contact header. Thus, the top-most Via header and the Contact header point to different hosts. ▪ [1] = Enable - the device changes the Contact header so that it points to the SAS host and therefore, the top-most Via header and the Contact header point to the same host. <p>Note: Operating in this mode causes all incoming dialog requests to traverse the SAS, which may cause load problems.</p>
Web: SAS Survivability Mode EMS: Survivability Mode [SASSurvivabilityMode]	<p>Determines the Survivability mode used by the SAS application.</p> <ul style="list-style-type: none"> ▪ [0] Standard = (Default) Incoming INVITE and REGISTER requests are forwarded to the defined Proxy list of SASProxySet in Normal mode and handled by the SAS application in Emergency mode. ▪ [1] Always Emergency = The SAS application does not use Keep-

Parameter	Description
	<p>Alive messages towards the SASProxySet, instead it always operates in Emergency mode (as if no Proxy in the SASProxySet is available).</p> <ul style="list-style-type: none"> ▪ [2] Ignore Register = Use regular SAS Normal/Emergency logic (same as option [0]), but when in Normal mode incoming REGISTER requests are ignored. ▪ [3] Auto-answer REGISTER = When in Normal mode, the device responds to received REGISTER requests by sending a SIP 200 OK (instead of relaying the registration requests to a Proxy), and enters the registrations in its SAS database. ▪ [4] Use Routing Table only in Normal mode = The device uses the IP-to-IP Routing table to route IP-to-IP SAS calls only when in SAS Normal mode (and is unavailable when SAS is in Emergency mode). This allows routing of SAS IP-to-IP calls to different destinations (and not only to the SAS Proxy Set).
Web: SAS Subscribe Response [SASSubscribeResponse]	<p>Defines the SIP response upon receipt of a SUBSCRIBE message when SAS is in Emergency mode. For example, if this parameter is set to "200", then SAS sends a SIP 200 OK in response to a SUBSCRIBE message, when in Emergency mode.</p> <p>The valid value is 200 to 699. The default is 489.</p>
Web: Enable ENUM [SASEnableENUM]	<p>Enables SAS to perform ENUM (E.164 number to URI mapping) queries when receiving INVITE messages in SAS emergency mode.</p> <ul style="list-style-type: none"> ▪ [0] Disable (default) ▪ [1] Enable
Web: SAS Binding Mode EMS: Binding Mode [SASBindingMode]	<p>Determines the SAS application database binding mode.</p> <ul style="list-style-type: none"> ▪ [0] URI = (Default) If the incoming AoR in the INVITE requests is using a 'tel:' URI or 'user=phone' is defined, the binding is performed according to the user part of the URI only. Otherwise, the binding is according to the entire URI, i.e., User@Host. ▪ [1] User Part only = The binding is always performed according to the User Part only.
Web: SAS Emergency Numbers [SASEmergencyNumbers]	<p>Defines emergency numbers for the device's SAS application. When the device's SAS agent receives a SIP INVITE (from an IP phone) that includes one of the emergency numbers (in the SIP user part), it forwards the INVITE to the default gateway (configured by the parameter SASDefaultGatewayIP), i.e., the device itself, which sends the call directly to the PSTN. This is important for routing emergency numbers such as 911 (in North America) directly to the PSTN. This is applicable to SAS operating in Normal and Emergency modes.</p> <p>Up to four emergency numbers can be defined, where each number can be up to four digits.</p>
[SASEmergencyPrefix]	<p>Defines a prefix that is added to the Request-URI user part of the INVITE message that is sent by the device's SAS agent when in Emergency mode to the default gateway or to any other destination (using the IP-to-IP Routing table). This parameter is required to differentiate between normal SAS calls routed to the default gateway and emergency SAS calls. Therefore, this allows you to define different manipulation rules for normal and emergency calls.</p> <p>This valid value is a character string. The default is an empty "" string.</p>
Web: SAS Entering Emergency Mode [SASEnteringEmergency]	<p>Determines for which sent SIP message types the device enters SAS Emergency mode if no response is received for them from the proxy server.</p>

Parameter	Description
yMode]	<ul style="list-style-type: none"> ▪ [0] = (Default) SAS enters Emergency mode only if no response is received from sent SIP OPTIONS messages. ▪ [1] = SAS enters Emergency mode if no response is received from sent SIP OPTIONS, INVITE, or REGISTER messages. <p>Note: If the keep-alive mechanism is disabled for the Proxy Set (in the Proxy Set table) and this parameter is set to [1], SAS enters Emergency mode only if no response is received from sent INVITE or REGISTER messages.</p>
Web: SAS Inbound Manipulation Mode [SASInboundManipulationMode]	<p>Enables destination number manipulation of incoming INVITE messages when SAS is in Emergency mode. The manipulation rule is done in the IP to IP Inbound Manipulation table.</p> <ul style="list-style-type: none"> ▪ [0] None (default) ▪ [1] Emergency Only <p>Notes:</p> <ul style="list-style-type: none"> ▪ Inbound manipulation applies only to INVITE requests. ▪ For more information on SAS inbound manipulation, see 'Manipulating Destination Number of Incoming INVITE' on page 434.
SAS Registration Manipulation Table	
Web: SAS Registration Manipulation EMS: Stand-Alone Survivability [SASRegistrationManipulation]	<p>This table parameter configures the SAS Registration Manipulation table. This table is used by the SAS application to manipulate the SIP Request-URI user part of incoming INVITE messages and of incoming REGISTER request AoR (To header), before saving it to the registered users database. The format of this table parameter is as follows:</p> <p>[SASRegistrationManipulation] FORMAT SASRegistrationManipulation_Index = SASRegistrationManipulation_RemoveFromRight, SASRegistrationManipulation_LeaveFromRight; [SASRegistrationManipulation]</p> <p>For example, the manipulation rule below routes an INVITE with Request-URI header "sip:7184002@10.33.4.226" to user "4002@10.33.4.226" (i.e., keep only four digits from right of user part):</p> <pre>SASRegistrationManipulation 0 = 0, 4;</pre> <p>Notes:</p> <ul style="list-style-type: none"> ▪ You can only configure one index entry. ▪ For a detailed description of this table, see 'Manipulating Destination Number of Incoming INVITE' on page 434.
Web: SAS IP-to-IP Routing Table	
[IP2IPRouting]	<p>This table parameter configures the IP-to-IP Routing table for SAS routing rules. The format of this parameter is as follows:</p> <p>[IP2IPRouting] FORMAT IP2IPRouting_Index = IP2IPRouting_SrcIPGroupID, IP2IPRouting_SrcUsernamePrefix, IP2IPRouting_SrcHost, IP2IPRouting_DestUsernamePrefix, IP2IPRouting_DestHost, IP2IPRouting_DestType, IP2IPRouting_DestIPGroupID, IP2IPRouting_DestSRDID, IP2IPRouting_DestAddress, IP2IPRouting_DestPort, IP2IPRouting_DestTransportType, IP2IPRouting_AltRouteOptions; [IP2IPRouting]</p> <p>For example:</p>

Parameter	Description
	IP2IPRouting 1 = -1, *, *, *, *, 0, -1, -1, , 0, -1, 0; Note: For a detailed description of this table parameter, see 'SAS Routing Based on IP-to-IP Routing Table' on page 437.

52.15 IP Media Parameters

The IP media parameters are described in the table below.

IP Media Parameters

Parameter	Description
Web: Number of Media Channels EMS: Media Channels [MediaChannels]	Defines the maximum number of DSP channels allocated for various functionalities such as IP streaming, IP conferencing, IP transcoding, IP-to-IP sessions. The RTP streams for IP-to-IP calls always transverse the device and two DSP channels are allocated per IP-to-IP session. Therefore, the maximum number of media channels for IP-to-IP calls is 120, corresponding to 60 IP-to-IP calls. The maximum number of media channels depends on the number of installed Media Processing (MPM) modules. For more information, see DSP Channel Resources on page 181. The default is 0. Notes: <ul style="list-style-type: none"> For this parameter to take effect, a device reset is required. For IP conferencing, the MPM module must be installed in Slot #6. If the MPM module is installed in Slot #6, the first DSP channel is used for a conference and the second DSP, supporting up to 20 channels, is used for transcoding. Other DSP channels can be used for PSTN interfaces.
[EnableIPMediaChannels]	Enables IP media channel support. <ul style="list-style-type: none"> [0] = Disable (default) [1] = Enable Notes: <ul style="list-style-type: none"> This parameter is applicable only to Mediant 1000. For this parameter to take effect, a device reset is required.
[IPmediaChannels]	This table ini file parameter defines the number of DSP channels that are "borrowed" from each of the device's digital modules for IP media functionality. The format of this parameter is as follows: [IPMediaChannels] FORMAT IPMediaChannels_Index = IPMediaChannels_ModuleID, IPMediaChannels_DSPChannelsReserved; [\IPMediaChannels] For example, the below settings use 15 and 10 DSP channels from modules 1 and 2, respectively: IPMediaChannels 1 = 1, 15; IPMediaChannels 2 = 2, 10; Notes: <ul style="list-style-type: none"> This parameter is applicable only to Mediant 1000. The value of DSPChannelsReserved must be in multiples of 5

Parameter	Description
	<p>(since the reservation is done per DSP device and not per DSP channel).</p> <ul style="list-style-type: none"> ▪ By default, the MPM module is set to the maximum value of IPM channels, therefore, there is no need to define it. ▪ By default, a digital module (i.e., TRUNKS module) is set to 0 IPM channels. ▪ For DSP utilization options, see DSP Channel Resources on page 181.
Web: Enable Voice Streaming [EnableVoiceStreaming]	<p>Enables the HTTP Voice Streaming application (play/record).</p> <ul style="list-style-type: none"> ▪ [0] Disable (default) ▪ [1] Enable <p>Note: For this parameter to take effect, a device reset is required.</p>
[VoiceStreamUploadMethod]	<p>Defines the HTTP request type for loading the voice stream to the file server.</p> <ul style="list-style-type: none"> ▪ [0] = POST (default) ▪ [1] = PUT <p>Notes:</p> <ul style="list-style-type: none"> ▪ For this parameter to take effect, a device reset is required. ▪ This parameter is applicable only to MSCML recording.
[VoiceStreamUploadPostURI]	<p>Defines the URI used on the POST request to upload voice data from the media server to a Web server.</p> <p>Note: For this parameter to take effect, a device reset is required.</p>
[APSEnabled]	<p>Determines the Voice Prompt index reference. This parameter must always be set to 0 (disabled).</p> <ul style="list-style-type: none"> ▪ [0] = APS disabled. Local Voice Prompts file is used. An audio reference in a play request (such as http://localhost/0) indicates that the Voice Prompt at index 0 in the Voice Prompts file is played. ▪ [1] = (Default) APS enabled. An audio reference (such as http://localhost/99) indicates that the audio segment provisioned on the APS with segment ID 99 is played. <p>Notes: For this parameter to take effect, a device reset is required.</p>
Web: NetAnn Announcement ID [NetAnnAnncID]	<p>Defines the NetAnn identification string (up to 16 characters) for playing an announcement using the NetAnn interface. The application server sends a regular SIP INVITE message with a SIP URI that includes this identifier string and a "play=" parameter that identifies the necessary announcement. The default is 'annc'.</p> <p>Example 1: INVITE sip: annc@10.2.3.4;play=http://localhost/1. Example 2: INVITE sip: annc@10.2.3.4;play=http://10.2.3.4/Annc/ello.wav.</p>
Web: MSCML ID [MSCMLID]	<p>Defines the Media Server Control Markup Language (MSCML) identification string (up to 16 characters). To start an MSCML session, the application server sends a regular SIP INVITE message with a SIP URI that includes this string. The default is 'ivr'.</p> <p>For example: INVITE sip:ivr@10.2.3.4 Subsequent INFO messages carry the requests and responses.</p>

Parameter	Description
Web: Transcoding ID [TranscodingID]	<p>Defines the Transcoding identification string (up to 16 characters) used for identifying an incoming Transcoding call. The default is 'trans'.</p> <p>For more information on Transcoding, see NetAnn Interface on page 467.</p>
AMS Parameters	
[AmsProfile]	<p>Enables advanced audio. This parameter must be set to 0.</p> <ul style="list-style-type: none"> ▪ [0] = Disable (default) ▪ [1] = Enable <p>Note: For this parameter to take effect, a device reset is required.</p>
[AASPackagesProfile]	<p>Must be set to 3 to use advanced audio.</p> <p>Note: For this parameter to take effect, a device reset is required.</p>
Conferencing Parameters	
Web/EMS: Conference ID CLI: conf-id [ConferenceID]	<p>Defines the Conference Identification string.</p> <p>The valid value is a string of up to 16 characters. The default is "conf".</p> <p>Note: To join a conference, the INVITE URI must include the Conference ID string preceded by the number of the participants in the conference and terminated by a unique number. For example:</p> <pre>INVITE sip:4conf1234@10.1.10.10</pre> <p>INVITE messages with the same URI join the same conference.</p>
Web: Beep on Conference [BipOnConference]	<p>Enables playing a beep when a participant joins or leaves a conference (in the latter case, a beep of a different pitch is heard).</p> <ul style="list-style-type: none"> ▪ [0] Disable ▪ [1] Enable (default)
Web: Enable Conference DTMF Clamping [EnableConferenceDTMFClamp]	<p>Determines the device logic once a DTMF is received on any conference participant. If enabled, the DTMF is not regenerated toward the other conference participants. This logic is only relevant for simple conferencing (NetAnn).</p> <ul style="list-style-type: none"> ▪ [0] Disable ▪ [1] Enable (default)
Web: Enable Conference DTMF Reporting [EnableConferenceDTMFReporting]	<p>Determines the device logic once a DTMF is received on any conference participant. If enabled, the device reports this DTMF in an out-of-band SIP message (according to TxDTMFOptions). This logic is only relevant for simple conferencing (NetAnn).</p> <ul style="list-style-type: none"> ▪ [0] Disable (default) ▪ [1] Enable
Web: Active Speakers Min. Interval [ActiveSpeakersNotificationMinInterval]	<p>Defines the minimum interval (in 100 msec units) between each Active Speaker Notification (ASN) events report. These events report on the active speakers in a conference. The event is issued whenever the active speakers change.</p> <p>Minimum configurable interval between events is 500 msec (5 units). The range is 5 to 2147483647 units. The default is 20 (i.e., 100 msec).</p>
Web: Playback Audio Format [cpPlayCoder]	<p>Determines the coder when playing a RAW file.</p> <ul style="list-style-type: none"> ▪ [1] G711 Mulaw ▪ [2] G711 Alaw (default)

Parameter	Description
Web: Record Audio Format [cpRecordCoder]	Determines the coder for recording all supported file types. <ul style="list-style-type: none"> [1] G711 Mulaw [2] G711 Alaw (default) Note: For this parameter to take effect, a device reset is required.
Web: End of Record Trim [cpEndOfRecordCutTime]	Defines the maximum amount (in milliseconds) of audio to remove from the end of a recording. This is used to remove the DTMF signals generated by the end user for terminating the record. The valid range is 0 to 65,535. The default is 0.
[NFSCClientMaxRetransmission]	Since NFS is carried over UDP, retransmission is performed for messages without a response. This parameter enables the user to define the maximum number of retransmissions performed for such a command. By default, the parameter is not used and the number of retransmissions is derived from the parameter ServerRespondTimeout. The range is 1 to 100. The default is 0 (derived from ServerRespondTimeout).
[StreamingPlayingUnderRunTimeout]	Defines the maximum time (in msec) that the device waits for the streaming server to acknowledge data sent to it. The range is 100 to 10,000. The default is 5,000.
[StreamingRecordingOverRunTimeout]	Defines the maximum time (in msec) that the streaming server waits to acknowledge a data request sent from the device. The range is 100 to 10,000. The default is 5,000.
[ServerRespondTimeout]	Defines the maximum time (in msec) that the device must wait for a response when operating with a remote server. The valid range is 1,000 to 90,000. The default is 5,000.
Automatic Gain Control (AGC) Parameters	
Web: Enable AGC EMS: AGC Enable [EnableAGC]	Enables the AGC mechanism. The AGC mechanism adjusts the level of the received signal to maintain a steady (configurable) volume level. <ul style="list-style-type: none"> [0] Disable (default) [1] Enable Notes: <ul style="list-style-type: none"> This parameter can also be configured in a Tel Profile. For a description of AGC, see Automatic Gain Control (AGC) on page 179.
Web: AGC Slope EMS: Gain Slope [AGCGainSlope]	Determines the AGC convergence rate: <ul style="list-style-type: none"> [0] 0 = 0.25 dB/sec [1] 1 = 0.50 dB/sec [2] 2 = 0.75 dB/sec [3] 3 = 1.00 dB/sec (default) [4] 4 = 1.25 dB/sec [5] 5 = 1.50 dB/sec [6] 6 = 1.75 dB/sec [7] 7 = 2.00 dB/sec [8] 8 = 2.50 dB/sec [9] 9 = 3.00 dB/sec

Parameter	Description
	<ul style="list-style-type: none"> ▪ [10] 10 = 3.50 dB/sec ▪ [11] 11 = 4.00 dB/sec ▪ [12] 12 = 4.50 dB/sec ▪ [13] 13 = 5.00 dB/sec ▪ [14] 14 = 5.50 dB/sec ▪ [15] 15 = 6.00 dB/sec ▪ [16] 16 = 7.00 dB/sec ▪ [17] 17 = 8.00 dB/sec ▪ [18] 18 = 9.00 dB/sec ▪ [19] 19 = 10.00 dB/sec ▪ [20] 20 = 11.00 dB/sec ▪ [21] 21 = 12.00 dB/sec ▪ [22] 22 = 13.00 dB/sec ▪ [23] 23 = 14.00 dB/sec ▪ [24] 24 = 15.00 dB/sec ▪ [25] 25 = 20.00 dB/sec ▪ [26] 26 = 25.00 dB/sec ▪ [27] 27 = 30.00 dB/sec ▪ [28] 28 = 35.00 dB/sec ▪ [29] 29 = 40.00 dB/sec ▪ [30] 30 = 50.00 dB/sec ▪ [31] 31 = 70.00 dB/sec
Web: AGC Redirection EMS: Redirection [AGCRedirection]	Determines the AGC direction. <ul style="list-style-type: none"> ▪ [0] 0 = (Default) AGC works on signals from the TDM side. ▪ [1] 1 = AGC works on signals from the IP side.
Web: AGC Target Energy EMS: Target Energy [AGCTargetEnergy]	Defines the signal energy value (dBm) that the AGC attempts to attain. The valid range is 0 to -63 dBm. The default is -19 dBm.
EMS: Minimal Gain [AGCMinGain]	Defines the minimum gain (in dB) by the AGC when activated. The range is 0 to -31. The default is -20. Note: For this parameter to take effect, a device reset is required.
EMS: Maximal Gain [AGCMaxGain]	Defines the maximum gain (in dB) by the AGC when activated. The range is 0 to 18. The default is 15. Note: For this parameter to take effect, a device reset is required.
EMS: Disable Fast Adaptation [AGCDisableFastAdaptation]	Enables the AGC Fast Adaptation mode. <ul style="list-style-type: none"> ▪ [0] = Disable (default) ▪ [1] = Enable Note: For this parameter to take effect, a device reset is required.
Answer Machine Detector (AMD) Parameters	
Web: Web: Answer Machine Detector Sensitivity Parameter Suite [AMDSensitivityParameterSuite]	Determines the AMD Parameter Suite that you want the device to use. <ul style="list-style-type: none"> ▪ [0] = (Default) USA Parameter Suite with 8 detection sensitivity levels (from 0 to 7). ▪ [1] = USA Parameter Suite with high detection sensitivity resolution (16 sensitivity levels, from 0 to 15). ▪ [2]-[3] = Other countries parameter suites with up to 16 sensitivity

Parameter	Description
	<p>levels.</p> <p>Notes:</p> <ul style="list-style-type: none"> The sensitivity level is selected by the <code>AMDSensitivityLevel</code> parameter. This parameter can also be configured in an IP Profile.
<p>Web: Answer Machine Detector Sensitivity Level [AMDSensitivityLevel]</p>	<p>Defines the AMD detection sensitivity level of the selected AMD Parameter Suite.</p> <p>The valid value range is 0 (for best detection of an answering machine) to 15 (for best detection of a live call). The default is 8.</p> <p>Notes:</p> <ul style="list-style-type: none"> This parameter is applicable only if the <code>AMDSensitivityParameterSuite</code> parameter is set to any option other than 0. This parameter can also be configured in an IP Profile.
<p>Web: Answer Machine Detector Sensitivity EMS: Sensitivity [AMDDetectionSensitivity]</p>	<p>Defines the AMD detection sensitivity level of the selected Parameter Suite.</p> <p>AMD can be useful in automatic dialing applications. In some of these applications, it is important to detect if a human voice or an answering machine is answering the call. AMD can be activated and deactivated only after a channel is already open.</p> <p>The valid value range is 0 to 7, where 0 is the best detection for answering machines and 7 is the best detection for live calls (i.e., voice detection). The default is 3.</p> <p>Notes:</p> <ul style="list-style-type: none"> This parameter is applicable only if the <code>AMDSensitivityParameterSuite</code> parameter is set to 0. To enable the AMD feature, set the <code>EnableDSPIPMDetectors</code> parameter to 1. For more information on AMD, see Answer Machine Detector (AMD) on page 175.
<p>Web: AMD Sensitivity File [AMDSensitivityFileName]</p>	<p>Defines the name of the AMD Sensitivity file that contains the AMD Parameter Suites.</p> <p>Notes:</p> <ul style="list-style-type: none"> This file must be in binary format (.dat). You can use the <code>DConvert</code> utility to convert the original file format from XML to .dat. You can load this file using the Web interface (see Loading Auxiliary Files on page 499).
[AMDSensitivityFileUrl]	<p>Defines the URL path to the AMD Sensitivity file for downloading from a remote server.</p>
[AMDMINimumVoiceLength]	<p>Defines the AMD minimum voice activity detection duration (in 5-ms units). Voice activity duration below this threshold is ignored and considered as non-voice.</p> <p>The valid value range is 10 to 100. The default is 42 (i.e., 210 ms).</p>
<p>EMS: AMD Max Greeting Time [AMDMaxGreetingTime]</p>	<p>Defines the maximum duration to detect greeting message.</p> <p>Note: This parameter can also be configured in an IP Profile.</p>
<p>EMS: AMD Max Post Silence Greeting Time [AMDMaxPostGreetings]</p>	<p>Defines the maximum duration of silence from after the greeting time is over (defined by <code>AMDMaxGreetingTime</code>) until the AMD decision.</p>

Parameter	Description
ilenceTime]	Note: This parameter can also be configured in an IP Profile.
EMS: Time Out [AMDTIMEOUT]	Defines the timeout (in msec) between receiving Connect messages from the ISDN and sending AMD results. The valid range is 1 to 30,000. The default is 2,000 (i.e., 2 seconds).
Web/EMS: AMD Beep Detection Mode [AMDBEEPDETECTIONMODE]	Determines the AMD beep detection mode. This mode detects the beeps played at the end of an answering machine message, by using the X-Detect header extension. The device sends a SIP INFO message containing the field values Type=AMD and SubType=Beep. This feature allows users of certain third-party, Application server to leave a voice message after an answering machine plays the "beep". <ul style="list-style-type: none"> ▪ [0] Disabled (default) ▪ [1] Start After AMD ▪ [2] Start Immediately
Web: Answer Machine Detector Beep Detection Timeout EMS: Beep Detection Timeout [AMDBEEPDETECTIONTIMEOUT]	Defines the AMD beep detection timeout (i.e., the duration that the beep detector functions from when detection is initiated). This is used for detecting beeps at the end of an answering machine message. The valid value is in units of 100 milliseconds, from 0 to 1638. The default is 200 (i.e., 20 seconds).
Web: Answer Machine Detector Beep Detection Sensitivity EMS: Beep Detection Sensitivity [AMDBEEPDETECTIONSENSITIVITY]	Defines the AMD beep detection sensitivity for detecting beeps at the end of an answering machine message. The valid value is 0 to 3, where 0 (default) is the least sensitive.
Web: AMD mode [AMDmode]	Enables the device to disconnect the IP-to-Tel call upon detection of an answering machine on the Tel side (i.e., AMD). In such a scenario, the device sends a SIP BYE message upon AMD. <ul style="list-style-type: none"> ▪ [0] = (Default) Device does not disconnect call upon detection of an answering machine. ▪ [1] = Device disconnects call upon detection of an answering machine. Notes: <ul style="list-style-type: none"> ▪ This feature does not need the receipt of the SIP X-Detect header in the incoming INVITE to activate the AMD. ▪ This feature can also be configured for an IP Profile.
Energy Detector Parameters	
Enable Energy Detector [EnableEnergyDetector]	Enables the Energy Detector feature. This feature generates events (notifications) when the signal received from the PSTN is higher or lower than a user-defined threshold (defined by the EnergyDetectorThreshold parameter). <ul style="list-style-type: none"> ▪ [0] Disable (default) ▪ [1] Enable
Energy Detector Quality Factor [EnergyDetectorQualityFactor]	Defines the Energy Detector's sensitivity level. The valid range is 0 to 10, where 0 is the lowest sensitivity and 10 the highest sensitivity. The default is 4.
Energy Detector	Defines the Energy Detector's threshold. A signal below or above this

Parameter	Description
Threshold [EnergyDetectorThreshold]	threshold invokes an 'Above' or 'Below' event. The threshold is calculated as follows: Actual Threshold = -44 dBm + (EnergyDetectorThreshold * 6) The valid value range is 0 to 7. The default is 3 (i.e., -26 dBm).
Pattern Detection Parameters	
Note: For an overview on the pattern detector feature for TDM tunneling, see DSP Pattern Detector on page 284.	
Web: Enable Pattern Detector [EnablePatternDetector]	Enables the Pattern Detector (PD) feature. <ul style="list-style-type: none"> ▪ [0] Disable (default) ▪ [1] Enable
[PDPattern]	Defines the patterns that can be detected by the Pattern Detector. The valid range is 0 to 0xFF. Note: For this parameter to take effect, a device reset is required.
[PDThreshold]	Defines the number of consecutive patterns to trigger the pattern detection event. The valid range is 0 to 31. The default is 5. Note: For this parameter to take effect, a device reset is required.
Media Resource Control Protocol (MRCP) / Real Time Streaming Protocol (RTSP) Parameters	
[MRCPDefaultMIMETYPE]	Determines the default format for speech recognition for inline grammars. <ul style="list-style-type: none"> ▪ [0] = (Default) Indicates GRXML ▪ [1] = Indicates GL (Nuance format)
[MRCPEnabled]	Activates the Media Resource Control Protocol (MRCP) functionality. <ul style="list-style-type: none"> ▪ [0] = Disable (default) ▪ [1] = Activate
[MRCPMaxPorts]	Defines the number of ports that are allocated to running MRCP-related activities such as speech recognition and text-to-speech. A port is considered duplex, so that speech recognition and text-to-speech can run on the same port. The value should not exceed the number of channels in the system. The range is 0 - 120. The default is 10.
[MRCPServerName]	Defines the hostname of the MRCP server. This is used to build a URI for the server. The default is NULL.
[MRCPServerIp]	Defines the IP address of the MRCP speech server. The default is 0.0.0.0.
[MRCPServerPort]	Defines the control port on the MRCP speech server. The range is 0 - 65,535. The default is 554.
[RTSPConnectionRetryInterval]	Defines the time (in seconds) that the system must wait before trying to create a socket for the RTSP speech server if the socket was never created or was created and then brought down. The range is 0 - 65,535. The default is 10. Note: For this parameter to take effect, a device reset is required.
[RTSPEnabled]	Activates the RTSP functionality.

Parameter	Description
	<ul style="list-style-type: none"> ▪ [0] = Disable (default) ▪ [1] = Activate <p>Note: For this parameter to take effect, a device reset is required.</p>
[RTSPMaxPorts]	Defines the number of channels that can be simultaneously active in RTSP sessions. The range is 0 - 20. The default is 10. <p>Note: For this parameter to take effect, a device reset is required.</p>

52.16 Auxiliary and Configuration File Name Parameters

The configuration files (i.e., auxiliary files) can be loaded to the device using the Web interface or a TFTP session. For loading these files using the *ini* file, you need to configure these files in the *ini* file and configured whether they must be stored in the non-volatile memory. The table below lists the *ini* file parameters associated with these auxiliary files. For more information on the auxiliary files, see 'Loading Auxiliary Files' on page 499.

Auxiliary and Configuration File Parameters

Parameter	Description
General Parameters	
[SetDefaultOnIniFileProcess]	Determines if all the device's parameters are set to their defaults before processing the updated <i>ini</i> file. <ul style="list-style-type: none"> ▪ [0] = Disable - parameters not included in the downloaded <i>ini</i> file are not returned to default settings (i.e., retain their current settings). ▪ [1] = Enable (default). <p>Note: This parameter is applicable only for automatic HTTP update or Web <i>ini</i> file upload (not applicable if the <i>ini</i> file is loaded using BootP).</p>
[SaveConfiguration]	Determines if the device's configuration (parameters and files) is saved to flash (non-volatile memory). <ul style="list-style-type: none"> ▪ [0] = Configuration isn't saved to flash memory. ▪ [1] = (Default) Configuration is saved to flash memory.
Auxiliary and Configuration File Name Parameters	
Web/EMS: Call Progress Tones File [CallProgressTonesFileName]	Defines the name of the file containing the Call Progress Tones definitions. For more information on how to create and load this file, refer to <i>DConvert Utility User's Guide</i> . <p>Note: For this parameter to take effect, a device reset is required.</p>
Web/EMS: Voice Prompts File [VoicePromptsFileName]	Defines the name (and path) of the file containing the Voice Prompts. <p>Notes:</p> <ul style="list-style-type: none"> ▪ For this parameter to take effect, a device reset is required. ▪ This parameter is applicable only to Mediant 1000. ▪ For more information on this file, see Voice Prompts File on page 507.
Web/EMS: Prerecorded Tones File [PrerecordedTonesFileName]	Defines the name (and path) of the file containing the Prerecorded Tones. <p>Note: For this parameter to take effect, a device reset is required.</p>

Parameter	Description
me]	
Web: CAS File EMS: Trunk Cas Table Index [CASFileName_x]	Defines the CAS file name (e.g., 'E_M_WinkTable.dat'), which defines the CAS protocol (where x denotes the CAS file ID 0 to 7). It is possible to define up to eight different CAS files by repeating this parameter. Each CAS file can be associated with one or more of the device's trunks, using the parameter CASTableIndex or it can be associated per B-channel using the parameter CASChannelIndex. Note: For this parameter to take effect, a device reset is required.
Web: Dial Plan EMS: Dial Plan Name [CasTrunkDialPlanName_x]	Defines the Dial Plan name (up to 11-character strings) per trunk. Note: The x in the ini file parameter name denotes the trunk number, where 0 is Trunk 1.
Web: Dial Plan File EMS: Dial Plan File Name [DialPlanFileName]	Defines the name (and path) of the Dial Plan file. This file should be created using AudioCodes DConvert utility (refer to <i>DConvert Utility User's Guide</i>).
[UserInfoFileName]	Defines the name (and path) of the file containing the User Information data.

52.17 Automatic Update Parameters

The automatic update of software and configuration files parameters are described in the table below.

Automatic Update of Software and Configuration Files Parameters

Parameter	Description
General Automatic Update Parameters	
[AutoUpdateCmpFile]	Enables the Automatic Update mechanism for the <i>cmp</i> file. <ul style="list-style-type: none"> [0] = (Default) The Automatic Update mechanism doesn't apply to the <i>cmp</i> file. [1] = The Automatic Update mechanism includes the <i>cmp</i> file. Note: For this parameter to take effect, a device reset is required.
[AutoUpdateFrequency]	Defines the number of minutes that the device waits between automatic updates. The default is 0 (i.e., the update at fixed intervals mechanism is disabled). Note: For this parameter to take effect, a device reset is required.
[AutoUpdatePredefined Time]	Defines schedules (time of day) for automatic updates. The format of this parameter is: 'HH:MM', where <i>HH</i> denotes the hour and <i>MM</i> the minutes, for example, 20:18. Notes: <ul style="list-style-type: none"> For this parameter to take effect, a device reset is required. The actual update time is randomized by five minutes to reduce the load on the Web servers.
EMS: AUPD Verify Certificates [AUPDVerifyCertificates]	Determines whether the Automatic Update mechanism verifies server certificates when using HTTPS. <ul style="list-style-type: none"> [0] = Disable (default) [1] = Enable
[AUPDCheckIfIniChanged]	Determines whether the Automatic Update mechanism performs CRC checking to determine if the <i>ini</i> file has changed prior to processing. <ul style="list-style-type: none"> [0] = (Default) Do not check CRC. The <i>ini</i> file is loaded whenever the server provides it. [1] = Check CRC for the entire file. Any change, including line order, causes the <i>ini</i> file to be re-processed. [2] = Check CRC for individual lines. Use this option when the HTTP server scrambles the order of lines in the provided <i>ini</i> file.
[ResetNow]	Invokes an immediate device reset. This option can be used to activate offline (i.e., not on-the-fly) parameters that are loaded using the parameter <i>IniFileUrl</i> . <ul style="list-style-type: none"> [0] = (Default) The immediate restart mechanism is disabled. [1] = The device immediately resets after an <i>ini</i> file with this parameter set to 1 is loaded.
Software/Configuration File URL Path for Automatic Update Parameters	
[CmpFileURL]	Defines the name of the <i>cmp</i> file and the path to the server (IP address or FQDN) from where the device can load the <i>cmp</i> file and update itself. The <i>cmp</i> file can be loaded using HTTP/HTTPS, FTP, FTPS, or NFS. For example: <code>http://192.168.0.1/filename</code> Notes:

Parameter	Description
	<ul style="list-style-type: none"> ▪ For this parameter to take effect, a device reset is required. ▪ When this parameter is configured, the device always loads the <i>cmp</i> file after it is reset. ▪ The <i>cmp</i> file is validated before it's burned to flash. The checksum of the <i>cmp</i> file is also compared to the previously burnt checksum to avoid unnecessary resets. ▪ The maximum length of the URL address is 255 characters.
[IniFileURL]	<p>Defines the name of the <i>ini</i> file and the path to the server (IP address or FQDN) on which it is located. The <i>ini</i> file can be loaded using HTTP/HTTPS, FTP, FTPS, or NFS.</p> <p>For example: http://192.168.0.1/filename http://192.8.77.13/config<MAC> https://<username>:<password>@<IP address>/<file name></p> <p>Notes:</p> <ul style="list-style-type: none"> ▪ For this parameter to take effect, a device reset is required. ▪ When using HTTP or HTTPS, the date and time of the <i>ini</i> file are validated. Only more recently dated <i>ini</i> files are loaded. ▪ The optional string <MAC> is replaced with the device's MAC address. Therefore, the device requests an <i>ini</i> file name that contains its MAC address. This option allows the loading of specific configurations for specific devices. ▪ The maximum length of the URL address is 99 characters.
[PrtFileURL]	<p>Defines the name of the Prerecorded Tones (PRT) file and the path to the server (IP address or FQDN) on which it is located.</p> <p>For example: http://server_name/file, https://server_name/file.</p> <p>Note: The maximum length of the URL address is 99 characters.</p>
[CptFileURL]	<p>Defines the name of the CPT file and the path to the server (IP address or FQDN) on which it is located.</p> <p>For example: http://server_name/file, https://server_name/file.</p> <p>Note: The maximum length of the URL address is 99 characters.</p>
[VpFileURL]	<p>Defines the name of the Voice Prompts file and the path to the server (IP address or FQDN) on which it is located.</p> <p>For example: http://server_name/file, https://server_name/file.</p> <p>Notes:</p> <ul style="list-style-type: none"> ▪ The maximum length of the URL address is 99 characters. ▪ This parameter is applicable only to Mediant 1000.
[CasFileURL]	<p>Defines the name of the CAS file and the path to the server (IP address or FQDN) on which it is located.</p> <p>For example: http://server_name/file, https://server_name/file.</p> <p>Note: The maximum length of the URL address is 99 characters.</p>
[TLSSRootFileUri]	<p>Defines the name of the TLS trusted root certificate file and the URL from where it can be downloaded.</p> <p>Note: For this parameter to take effect, a device reset is required.</p>
[TLSCertFileUri]	<p>Defines the name of the TLS certificate file and the URL from where it can be downloaded.</p> <p>Note: For this parameter to take effect, a device reset is required.</p>

Parameter	Description
[TLSPkeyFileUrl]	Defines the URL for downloading a TLS private key file using the Automatic Update facility.
[UserInfoFileURL]	Defines the name of the User Information file and the path to the server (IP address or FQDN) on which it is located. For example: http://server_name/file, https://server_name/file Note: The maximum length of the URL address is 99 characters.

53 DSP Templates

This section lists the DSP templates supported by the device. Each DSP template provides support for specific voice coders (as well as channel capacity and various features).



Notes:

- The maximum number of channels on any form of analog, digital and MPM modules assembly is 120.
- To select the DSP Template that you want to use on the device, see Configuring DSP Templates on page 181.
- Installation and use of voice coders is subject to obtaining the appropriate license and royalty payments.
- The number of channels refers to the maximum channel capacity of the device.
- For additional DSP templates, contact your AudioCodes representative.

53.1 Analog Interfaces

The DSP templates for analog interfaces are shown in the table below.

DSP Firmware Templates for Analog (FXS/FXO) Interfaces

	DSP Template	
	0, 1, 2, 4, 5, 6	10, 11, 12, 14, 15, 16
	Number of Channels	
Default Settings	4	3
With SRTP	3	3
Voice Coder		
G.711 A/Mu-law PCM	Yes	Yes
G.727	Yes	Yes
G.726 ADPCM	Yes	Yes
G.723.1	Yes	Yes
G.729 A, B	Yes	Yes
G.722	-	Yes

53.2 BRI Interfaces

The table below lists the supported channel capacity per DSP firmware template for BRI interfaces:

Table 53-1: DSP Firmware Templates for BRI Interfaces

	DSP Template					
	0, 1, 2, 4, 5, 6			10, 11, 12, 14, 15, 16		
	Number of BRI Spans					
	4	8	20	4	8	20
Default Settings	Number of Channels					
	8	16	40	6	12	30
With SRTP	8	16	40	6	12	30
Voice Coder						
G.711 A/Mu-law PCM	Yes			Yes		
G.727	Yes			Yes		
G.726 ADPCM	Yes			Yes		
G.723.1	Yes			Yes		
G.729 A, B	Yes			Yes		
G.722	-			Yes		

53.3 E1/T1 Interfaces

The DSP templates for E1/T1 interfaces are shown in the table below.

DSP Firmware Templates for E1/T1 Interfaces

	DSP Template														
	0 or 10			1 or 11			2 or 12			5 or 15			6 or 16		
	Number of Spans														
	1	2	4	1	2	4	1	2	4	1	2	4	1	2	4
	Number of Channels														
Default settings	31	62	120	31	48	80	24	36	60	24	36	60	31	60	100
With 128 ms EC	31	60	100	31	48	80	24	36	60	24	36	60	31	60	100
With SRTP	31	60	100	-	-	-	24	36	60	24	36	60	31	48	80
With IPM Features (*)	31	60	100	-	-	-	-	-	-	-	-	-	31	60	100
With IPM Features & SRTP	31	48	80	-	-	-	-	-	-	-	-	-	31	48	80
Voice Coder															
G.711 A-law/Mm-law PCM	Yes			Yes			Yes			Yes			Yes		
G.727	Yes			Yes			Yes			Yes			-		
G.726 ADPCM	Yes			Yes			Yes			Yes			-		
G.723.1	Yes			-			-			-			-		
G.729 A, B	Yes			Yes			Yes			Yes			Yes		
GSM FR	Yes			Yes			-			-			-		
MS GSM	Yes			Yes			-			-			-		
iLBC	-			-			-			Yes			-		
EVRC	-			-			Yes			-			-		
QCELP	-			-			Yes			-			-		
AMR	-			Yes			-			-			-		
GSM EFR	-			Yes			-			-			-		
G.722	-			-			-			-			Yes		
Transparent	Yes			Yes			Yes			Yes			Yes		



Notes: IPM Features refers to the configuration that includes at least one of the following:

- Mounted MPM module in Slot #6 for conference applications.
- IPM detectors (e.g., Answer Detector) are enabled.
- The IP Media Channels featured is enabled.

53.4 Media Processing Interfaces

The DSP templates for the media processing interfaces (i.e., MPM module) are shown in the table below.



Notes:

- The MPM module DSP templates are applicable only to Mediant 1000.
- Assembly of the MPM module in Slot #6 enables DSP conferencing capabilities.
- To use the MPM module, the device must be installed with the IP Media Channels Software License Key.

DSP Firmware Templates for MPM Module

Supplementary Capabilities			DSP Template										
			0 or 10		1 or 11		2 or 12		5 or 15		6 or 16		
			Assembly Slot no.										
			1-5	6	1-5	6	1-5	6	1-5	6	1-5	6	
S RTP	Detectors	IPM	Conference	Number of Channels									
				-	-	-	40	-	32	-	24	-	24
Yes	-	-	40	-	-	-	24	-	24	-	40	-	
-	Yes	-	40	-	-	-	-	-	-	-	40	-	
Yes	Yes	-	32	-	-	-	-	-	-	-	32	-	
-	-	Yes	40	20	32	16	24	12	24	12	40	20	
Yes	-	Yes	32	16	-	-	24	12	24	12	32	16	
Yes	Yes	Yes	32	16	-	-	-	-	-	-	32	16	
Voice Coder													
G.711 A-law/Mm-law PCM			Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	
G.727			Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	-	-	
G.726 ADPCM			Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	-	-	
G.723.1			Yes	-	-	-	-	-	-	-	-	-	
G.729 A, B			Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	
GSM FR			Yes	Yes	-	-	-	-	-	-	-	-	
MS GSM			Yes	Yes	-	-	-	-	-	-	-	-	
iLBC			-	-	-	-	-	-	Yes	-	-	-	
EVRC			-	-	-	Yes	-	-	-	-	-	-	
QCELP			-	-	-	Yes	-	-	-	-	-	-	
AMR			-	Yes	-	-	-	-	-	-	-	-	
GSM EFR			-	Yes	-	-	-	-	-	-	-	-	
G.722			-	-	-	-	-	-	-	-	-	Yes	
Transparent			Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	

Reader's Notes

54 Selected Technical Specifications



Notes:

- All specifications in this document are subject to change without prior notice.
- The compliance and regulatory information can be downloaded from AudioCodes Web site at <http://www.audiocodes.com/library>.

54.1 Mediant 600

The table below lists the main technical specifications of the Mediant 600.

Mediant 600 Functional Specifications

Function	Specification
Interfaces	
E1/T1/J1	1, 2 or fractional (15 DS0) span spans using RJ-48c connectors
BRI S/T	4 or 8 ports (8/16 calls) using RJ-45 connectors
Analog	4 FXS ports using RJ-11 connectors
Ethernet	Dual Redundant Ethernet 10/100Base-TX Ethernet ports via 2 RJ-45 connectors
RS-232	RS-232 for configuration and troubleshooting
Media Processing	
Voice Coders	G.711, G.722, G.723.1, G.729A/B, G.726, GSM FR, MS GSM, iLBC, EVRC, QCELP, AMR, GSM EFR. Independent dynamic vocoder selection per channel, VAD, CNG.
Echo Cancellation	G.165 and G.168-2002, with 32, 64 or 128 tail length.
QoS	802.1p/Q VLAN tagging, DiffServ, voice quality monitoring, RTCP XR DTMF/MF Transport Packet side or PSTN side detection and generation, RFC 2833 compliant DTMF relay, Call Progress tone detection and generation IP Transport, VoIP (RTP/RTCP) per IETF RFC 3550 and 3551.
Fax and Modem Transport	T.38 compliant (real time fax), Automatic bypass to PCM or ADPCM.
Stand Alone Survivability (SAS) Application	
SAS	SAS ensures call continuity between LAN SIP clients upon connectivity failure with IP Centrex services (e.g., WAN IP PBX).
Max. Capacity	
Registered Users	600

Function	Specification
Signaling	
E1/T1 CAS	E&M, Loop Start, Feature Group-D, E911CAMA, R2 MFC, numerous protocol and country variants
ISDN PRI	ETSI/EURO, ANSI NI2, DMS-100, 5ESS, VN3, VN4, VN6 QSIG (Basic Call and Supplementary Services) and other variants
Control & Management	
Control Protocols	SIP
Operations & Management	AudioCodes Element Management System Embedded HTTP Web Server Telnet SNMP V2/V3
Remote configuration and software download	TFTP, HTTP, HTTPS, DHCP and BootP, RADIUS, Syslog (for events, alarms and CDRs)
Security	
Security Protocols	IPSec, HTTPS, TLS (SIPS), SSL, Web access list, RADIUS login and SRTP
Hardware Specifications	
Power Supply	Single universal power supply 100-240V 0.5A 50-60 Hz
Physical	1U high, 19-inch wide
Dimensions	306 x 273 x 44 mm

54.2 Mediant 1000

The table below lists the main technical specifications of the Mediant 1000.

Mediant 1000 Functional Specifications

Function	Specification
Interfaces	
Modularity and Capacity	Voice interface: Equipped with 6 Slots that can host voice modules. Up to a maximum of 24 analog ports or 4 digital spans.
Digital Modules	1, 2 or 4 E1/T1/J1 spans using RJ-48c connectors per module. Up to 4 digital modules (maximum 4 spans per gateway). Optional 1+1 or 2+2 fallback spans.
Analog FXO and FXS Modules	4 ports using RJ-11 connectors per module; Up to 6 modules per gateway, Ground Start and Loop Start.
BRI Module	4 BRI ports (8 calls) per module, up to 5 modules per gateway with S/T interfaces. Supports Euro ISDN, NI2, 5ESS or QSIG.
Media Processing Module	Hosting media processing features: conferencing, play/record over HTTP or NFS.
I/O	MOH (Music On Hold), NB (Night Bell).
Ethernet	Dual Redundant 10/100Base-TX Ethernet ports via 2 RJ-45 connectors.
RS-232	Debugging and configuration.
Media Processing	
Voice Coders	G.711, G.722, G.723.1, G.729A/B, G.726, GSM FR, MS GSM, iLBC, EVRC, QCELP, AMR, GSM EFR. Independent dynamic vocoder selection per channel.
Echo Cancellation	G.165 and G.168-2002, with 32, 64 or 128 tail length.
Quality Enhancement	Dynamic programmable jitter buffer, VAD, CNG, 802.1p/Q VLAN tagging, DiffServ, voice quality monitoring, G.729B, RTCP XR.
DTMF/MF Transport	Packet side or PSTN side detection and generation, RFC 2833 compliant DTMF relay. Call Progress tones detection and generation.
IP Transport	VoIP (RTP/RTCP) per IETF RFC 3550 and 3551.
Fax and Modem Transport	T.38 compliant (real time fax), Automatic bypass to PCM or ADPCM.
Stand Alone Survivability (SAS) Application	
Max. Registered Users	Supports up to 600 registered users in its Registration database. SAS ensures call continuity between LAN SIP clients upon connectivity failure with IP Centrex services (e.g., WAN IP PBX).
Max. Capacity	
Registered Users (IP-to-IP, SAS)	600

Function	Specification
OSN Server Platform - Embedded, Partner application platform for third-party services	
CPU	<ul style="list-style-type: none"> ▪ OSN1: Intel™ Celeron™ 600 Mhz ▪ OSN2: Intel Pentium M 1.4 GHz
Memory	<ul style="list-style-type: none"> ▪ OSN1: One SODIMM slot 512M or 1G RAM ▪ OSN2: 1 or 2 GRAM
Storage	<ul style="list-style-type: none"> ▪ OSN1: Single/Dual hard disk drives ▪ OSN2: Single SATA HDD
Interfaces	<ul style="list-style-type: none"> ▪ OSN1: 10/100Base-TX, USB, RS-232, NB relay, MOH ▪ OSN2: 10/100Base-TX, USB, RS-232
Signaling	
Digital – PSTN Protocols	CAS: MF-R1: T1 CAS (E&M, Loop start, Feature Group-D, E911CAMA), E1 CAS (R2 MFC) ISDN PRI: ETSI/EURO ISDN, ANSI NI2 and other variants (DMS-100, 5ESS) QSIG (Basic and supplementary), VN3, VN4, VN6
Analog Signaling	FXS; Caller ID; polarity reversal; metering tones, distinctive ringing, visual message waiting indication, Loop Start, Ground Start
Control & Management	
Control Protocols	SIP, MSCML
Operations & Management	AudioCodes Element Management System Embedded HTTP Web Server Telnet SNMP V2, V3 Remote configuration and software download via TFTP, HTTP, HTTPS, DHCP and BootP, RADIUS, Syslog (for events, alarms and CDRs) Auto Update
Security	
	IPSec, HTTPS, TLS (SIPS), SSL, Web access list, RADIUS login and SRTP2
Hardware Specifications	
Power Supply	Single universal power supply 100-240V 50-60 Hz 1.5A max., optional redundant power supply
Physical	1U high, 19-inch wide

Reader's Notes



User's Manual Ver. 6.6