

Dell™ PowerConnect™ 5324 Systems
User's Guide Addendum

Notes, Notices, and Cautions



NOTE: A NOTE indicates important information that helps you make better use of your computer.



NOTICE: A NOTICE indicates either potential damage to hardware or loss of data and tells you how to avoid the problem.



CAUTION: A CAUTION indicates a potential for property damage, personal injury, or death.

Information in this document is subject to change without notice.

© 2006 Dell Inc. All rights reserved.

Reproduction in any manner whatsoever without the written permission of Dell Inc. is strictly forbidden.

Trademarks used in this text: *Dell*, *Dell OpenManage*, the *DELL* logo, and *PowerConnect* are trademarks of Dell Inc. *Microsoft* and *Windows* are registered trademarks of Microsoft Corporation.

Other trademarks and trade names may be used in this document to refer to either the entities claiming the marks and names or their products. Dell Inc. disclaims any proprietary interest in trademarks and trade names other than its own.

September 2006

New Features

This document is an addendum to the PowerConnect 5324 user guide and includes the following topics:

- Configuring LLDP
- Defining SNMP Parameters
- HTTP/HTTPS Upload/Download
- Defining STP Root Guard
- Configuring Multiple Spanning Tree
- Configuring QinQ
- Configuring Load Balancing

Configuring LLDP

The *Link Layer Discovery Protocol* (LLDP) allows network managers to troubleshoot and enhance network management by discovering and maintaining network topologies over multi-vendor environments. LLDP discovers network neighbors by standardizing methods for network devices to advertise themselves to other system, and to store discovered information. Device discovery information includes:


- Device Identification
- Device Capabilities
- Device Configuration

The advertising device transmits multiple advertisement message sets in a single LAN packet. The multiple advertisement sets are sent in the packet *Type Length Value* (TLV) field. LLDP devices must support chassis and port ID advertisement, as well as system name, system ID, system description, and system capability advertisements.

The **LLDP Properties** page contains fields for configuring LLDP.

To open the **LLDP Properties** Page, click **Security** → **LLDP** → **LLDP Properties** in the tree view.

Figure 1-1. LLDP Properties



Enable LLDP — Indicates if LLDP is enabled on the device. The possible field values are:

Checked — Indicates that LLDP is enabled on the device.

Unchecked — Indicates that LLDP is disabled on the device. This is the default value.

Updates Interval (5-32768) — Indicates that rate at which LLDP advertisement updates are sent. The possible field range is 5 - 32768 seconds. The default value is 30 seconds.

Hold Time (2-10) — Indicates the amount of time that LLDP packets are held before the packets are discarded. The possible field range is 2 - 10 seconds. The field default is 4 seconds.

Reinitializing Delay (1-10) — Indicates the amount of time that passes between disabling LLDP and when reinitializing begins. The possible field range is 1 - 10 seconds. The field default is 2 seconds.

Transmit Delay (1-8192) — Indicates the amount of time that passes between successive LLDP frame transmissions due to changes in the LLDP local systems MIB. The possible field value is 1 – 8192 seconds. The field default is 2 seconds.

Configuring LLDP Using CLI Commands

Table 1-1. LLDP Properties CLI Commands

CLI Command	Description
<code>lldp enable (global)</code>	Enables enable Link Layer Discovery Protocol.
<code>lldp hold-multiplier number</code>	Specifies the time that the receiving device should hold a Link Layer Discovery Protocol (LLDP) packet before discarding it.
<code>lldp reinit-delay Seconds</code>	Specifies the minimum time an LLDP port will wait before reinitializing.
<code>lldp tx-delay Seconds</code>	Specifies the delay between successive LLDP frame transmissions.

The following is an example of the CLI commands:


```
Console(config)# interface ethernet g5
Console(config-if)# lldp enable
```

Defining LLDP Port Settings

The LLDP Port Settings page allows network administrators to define LLDP port settings, including the port number, the LLDP port number, and the type of port information advertised.

The Port Settings page contains fields for configuring LLDP. To open the Port Settings page, click Security → LLDP → Port Settings in the tree view.

Figure 1-2. Port Settings



Port — Contains a list of ports on which LLDP is enabled.

State — Indicates the port type on which LLDP is enabled. The possible field values are:

Tx Only — Enables transmitting LLDP packets only.

Rx Only — Enables receiving LLDP packets only.

Tx & Rx — Enables transmitting and receiving LLDP packets. This is the default value.

Disable — Indicates that LLDP is disabled on the port.

Use Default — Indicates that information included in the TLVs is per the device defaults. The possible field values are:

Checked — Enables sending the device default LLDP advertisements.

Unchecked — Indicates that the device LLDP advertisement settings are disabled, and LLDP advertisement settings are user defined. This is the default value.

Optional TLVs — Contains a list of optional TLVs advertised by the port. For the complete list, see the **Available TLVs** field.

Available TLVs — Contains a list of available TLVs that can be advertised by the port. The possible field values are:

- Port Description**— Advertises the port description.
- System Name** — Advertises the system name.
- System Description** — Advertises the system description.
- System Capabilities** — Advertises the system capabilities.

Management IP Address — Indicates the management IP address that is advertised from the interface.

The **LLDP Port Table** page displays the LLDP Port Configuration. To open the **LLDP Port Table**, click **Security** → **LLDP** → **Port Settings** → **Show All** in the tree view.

Figure 1-3. LLDP Port Table




Table 1-2. LLDP Port settings CLI Commands

CLI Command	Description
<code>clear lldp rx interface</code>	Restarts the LLDP RX state machine and clearing the neighbors table
<code>lldp optional-tlv tlv1 [tlv2 ... tlv5]</code>	Specifies which optional TLVs from the basic set should be transmitted
<code>lldp enable [rx tx both]</code>	To enable Link Layer Discovery Protocol (LLDP) on an interface.


The following is an example of the CLI commands:

```
Console(config)# interface ethernet g5  
Console(config-if)# lldp enable
```


Viewing Advertised Information

The LLDP Advertised Information page displays the information advertised by specific ports when advertising LLDP information. To open the Advertised Information page, click **Security** → **LLDP** → **Advertised Information** in the tree view.

Figure 1-4. Advertised Information



The screenshot shows the Dell OpenManage Switch Administrator interface. The left sidebar contains a tree view with the following structure:

- Home
 - System
 - General
 - SNTP
 - Logs
 - IP Addressing
 - Diagnostics
 - Management Se
 - LLDP
 - LLDP Proper
 - Port Settings
 - Advertised I**
 - Neighbors Int
 - SNMP
 - File Manager
 - Advanced Settin
 - Switch
 - Network Securit
 - Ports
 - Address Tables
 - GARP
 - Spanning Tree
 - VLAN
 - Link Aggregator
 - Multicast Suppo
 - Statistics/RMON
 - Quality of Service

The main content area is titled "Advertised Information" and displays a table with the following data:

Port No.	g1
Device ID	000033665522
Capabilities	Bridge
System Name	
System Description	Neyland 24T
Port Description	Ethernet Interface
Management Address	Not Advertised

Port — Displays the port number from which the advertised information is sent.

Device ID — Displays the advertised device ID.

Capabilities — Displays the advertised device capabilities.

System Name — Displays the advertised system name.

System Description — Displays the advertised system description.

Port Description — Displays the advertised port description.

Management Address — Displays the advertised management address.

Displaying the Advertised Information Table

To open the Advertised Information Table, click Security → LLDP → Advertised Information → Show All in the tree view.

Figure 1-5. Advertised Information Table

Advertised Information table

Refresh

Port No.	Device ID	Capabilities	System Name	System Description	Port Description	Management Address
1						

Apply Changes

Table 1-3. LLDP Advertised Information CLI Commands

CLI Command	Description
<code>show lldp local ethernet interface</code>	Displays LLDP information advertised from a specific port.


The following is an example of the CLI commands:

```
Switch# show lldp local ethernet 1
Device ID: 0060.704C.73FF
Port ID: 1
Capabilities: Bridge
System Name: ts-7800-1
System description:
Port description:
Management address: 172.16.1.8
802.3 MAC/PHY Configuration/Status
Auto-negotiation support: Supported
Auto-negotiation status: Enabled
Auto-negotiation Advertised Capabilities: 100BASE-TX full duplex,
1000BASE-T full duplex
Operational MAU type: 1000BaseTFD
LLDP-MED capabilities: Network Policy, Location Identification
LLDP-MED Device type: Network Connectivity
LLDP-MED Network policy
Application type: Voice
Flags: Tagged VLAN
VLAN ID: 2
Layer 2 priority: 0
DSCP: 0
LLDP-MED Power over Ethernet
Device Type: Power Sourcing Entity
Power source: Primary Power Source
Power priority: High
Power value: 9.6 Watts
LLDP-MED Location
Coordinates: 54:53:c1:f7:51:57:50:ba:5b:97:27:80:00:00:67:01
```

Viewing the LLDP Neighbor Information

The **Neighbors Information** page contains information received from neighboring device LLDP advertisements. To open the **Neighbor Information** page, click **Security** → **LLDP** → **Neighbors Information** in the tree view.

Figure 1-6. Neighbors Information



Port — Displays the neighboring port number.

Device ID — Displays the neighboring device ID.

Port ID — Displays the neighboring port ID

Capabilities — Displays the neighboring device capabilities.

System Name — Displays the neighboring system time.

- 1 Select a port.
- 2 Click **Apply Changes**. The port advertisement information is displayed.

Displaying the Neighbor Information Table

- 1 Click **Security** → **LLDP** → **Neighbors Information** in the tree view.
- 2 Click **Show All**. The Neighbor Table opens:

Figure 1-7. Neighbors Table

Neighbors Table Refresh

Port	Device ID	Port ID	Capabilities	System Name
------	-----------	---------	--------------	-------------

Clear Neighbors Table

Table 1-4. LLDP Neighbor Information CLI Commands

CLI Command	Description
<code>show lldp neighbors interface</code>	Displays information about neighboring devices discovered using Link Layer Discovery Protocol (LLDP)

The following is an example of the CLI commands:

Switch# `show lldp neighbors`

Port	Device ID	Port ID	Hold Time	Capabilities	System Name
1	0060.704C.73FE	1	117	B	ts-7800-2
1	0060.704C.73FD	1	93	B	ts-7800-2
2	0060.704C.73F C	9	1	B, R	ts-7900-1
3	0060.704C.73FB	1	92	W	ts-7900-2

Defining SNMP Parameters

Simple Network Management Protocol (SNMP) provides a method for managing network devices. Devices supporting SNMP run a local software (agent).

The SNMP agents maintain a list of variables, which are used to manage the device. The variables are defined in the Management Information Base (MIB). The MIB contains the variables controlled by the agent. The SNMP protocol defines the MIB specification format, as well as the format used to access the information over the network.


Access rights to the SNMP agents are controlled by access strings. To communicate with the device, the Embedded Web Server submits a valid community string for authentication. To open the SNMP page, click **System** → **SNMP** in the tree view.

This section contains information for managing the SNMP configuration.

Defining SNMP Global Parameters

The **SNMP Global Parameters** page permits enabling both SNMP and Authentication notifications. To open the **SNMP Global Parameters** page, click **System** → **SNMP** → **Global Parameters** in the tree view.

Figure 1-8. Global Parameters



Local Engine ID (10 - 64 Hex Characters) — Indicates the local device engine ID. The field value is a hexadecimal string. Each byte in hexadecimal character strings is two hexadecimal digits. Each byte can be separated by a period or a colon. The Engine ID must be defined before SNMPv3 is enabled.

For stand-alone devices select a default Engine ID that is comprised of Enterprise number and the default MAC address.

Use Default — Uses the device generated Engine ID. The default Engine ID is based on the device MAC address and is defined per standard as:

First 4 octets — first bit = 1, the rest is IANA Enterprise number.

Fifth octet — Set to 3 to indicate the MAC address that follows.

Last 6 octets — MAC address of the device.

SNMP Notifications — Enables or disables the router sending SNMP notifications.

Authentication Notifications — Enables or disables the router sending SNMP traps when authentication fails.

Enabling SNMP Notifications

- 1 Open the **SNMP Global Parameters** page.
- 2 Select **Enable** in the **SNMP Notifications** field.
- 3 Click **Apply Changes**.

SNMP notifications are enabled, and the device is updated.

Enabling Authentication Notifications

- 1 Open the **SNMP Global Parameters** page.
- 2 Select **Enable** in the **Authentication Notifications** field.
- 3 Click **Apply Changes**.

Enabling SNMP Notifications Using CLI Commands

The following table summarizes the equivalent CLI commands for viewing fields displayed in the **SNMP Global Parameters** page.

Table 1-5. SNMP Notification Commands

CLI Command	Description
<code>snmp-server enable traps</code>	Enables the router to send Simple Network Management Protocol traps.
<code>snmp-server trap authentication</code>	Enables the router to send Simple Network Management Protocol traps when authentication fails.
<code>show snmp</code>	Checks the status of SNMP communications.

Table 1-5. SNMP Notification Commands

CLI Command	Description
snmp-server engine ID local { <i>engineid-string</i> default }	Indicates the local device engine ID. The field values is a hexadecimal string. Each byte in hexadecimal character strings is two hexadecimal digits. Each byte can be separated by a period or colon. The Engine ID must be defined before SNMPv3 is enabled.

The following is an example of the CLI commands:

```
Console (config)# snmp-server enable traps
Console (config)# snmp-server trap authentication
Console# show snmp

Community-String  Community-Access  View name  IP address
-----
public            read only        view-1     All

Community-String  Group name          IP address  Type
-----
Traps are enabled.
Authentication-failure trap is enabled.

Version 1,2 notifications
Target      Type      Community  Version  Udp  Filter  To  Retries
Address     -----
-----

Version 3 notifications
Target      Type      Username   Security  Udp  Filter  To  Retries
Address     -----
-----
                                     -    -


System Contact: Robert
System Location: Marketing
```

Defining SNMP View Settings

SNMP Views provides access or blocks access to device features or feature aspects. For example, a view can be defined which states that SNMP group A has read only (R/O) access to Multicast groups, while SNMP group B has read-write (R/W) access to Multicast groups. Feature access is granted via the MIB name, or MIB Object ID. The Up and Down arrows allow navigating through the MIB tree, and MIB branches.

To open the SNMPv3 View Settings page, click **System** → **SNMP** → **View Settings** in the tree view.

Figure 1-9. SNMPv3 View Settings



View Name — Contains a list of user-defined views. The view name can contain a maximum of 30 alphanumeric characters. The possible field values are:

Default — Displays the default user-defined view.

DefaultSuper — Displays the default super user-defined view.

New Object ID Subtree — Indicates the device feature OID included or excluded in the selected SNMP view.

Selected from List — Select the device feature OID by using the Up and Down buttons to scroll through a list of all device OIDs.

Insert — Specify the device feature OID.


View Type — Indicates if the defined OID branch will be included or excluded in the selected SNMP view.

Adding a View

- 1 Open the SNMPv3 View Settings page.
- 2 Click Add.

The Add a View page opens.

Figure 1-10. Add a View



- 3 Define the field.
- 4 Click Apply Changes.
The SNMP View is added, and the device is updated.

Displaying the View Table

- 1 Open the SNMPv3 View Settings page.
- 2 Click Show All.
The View Table page opens.

Figure 1-11. View Table

[Refresh](#)

View Name		Default	
Object ID Subtree	View Type	Remove	
1 1	Included	<input type="checkbox"/>	<input type="checkbox"/>
2 1.3.6.1.6.3.13	Excluded	<input type="checkbox"/>	<input type="checkbox"/>
3 1.3.6.1.6.3.16	Excluded	<input type="checkbox"/>	<input type="checkbox"/>
4 1.3.6.1.6.3.18	Excluded	<input type="checkbox"/>	<input type="checkbox"/>
5 1.3.6.1.6.3.12.1.2	Excluded	<input type="checkbox"/>	<input type="checkbox"/>
6 1.3.6.1.6.3.12.1.3	Excluded	<input type="checkbox"/>	<input type="checkbox"/>
7 1.3.6.1.6.3.15.1.2	Excluded	<input type="checkbox"/>	<input type="checkbox"/>
8 1.3.6.1.4.1.69.2.7.2	Excluded	<input type="checkbox"/>	<input type="checkbox"/>

Defining SNMP Views Using CLI Commands

The following table summarizes the equivalent CLI commands for defining fields displayed in the SNMPv3 View Settings page.

Figure 1-12. SNMP View CLI Commands

CLI Command	Description
<code>snmp-server view view-name oid-tree {included excluded}</code>	Creates or updates a view entry.

Figure 1-12. SNMP View CLI Commands

CLI Command	Description
show snmp views [viewname]	Displays the configuration of views.

The following is an example of CLI commands:

```

Console (config)# snmp-server view user1 1 included
Console (config)# end
Console # show snmp views

Name                OID Tree                Type
-----
user1                iso                      included
Default              iso                      included
Default              snmpVacmMIB             excluded
Default              usmUser                  excluded
Default              rndCommunityTable       excluded
DefaultSuper         iso                      included

```

Defining SNMP Access Control

The Access Control Add Group page provides information for creating SNMP groups, and assigning SNMP access control privileges to SNMP groups. Groups allow network managers to assign access rights to specific device features, or features aspects. To open the Access Control Group page, click **System** → **SNMP** → **Access Control** in the tree view.

Figure 1-13. Access Control Group

The screenshot shows the Dell OpenManage Switch Administrator interface. The top navigation bar includes 'Support', 'Help', 'About', and 'Log Out'. The Dell logo is prominently displayed. Below the logo, the version '10.6.5.49' and the page title 'SNMP - Access Control Group' are visible. A navigation tree on the left lists various system settings, with 'Access Control' highlighted. The main content area is titled 'SNMP - Access Control Group' and contains two main sections: 'Query Access Control Configuration' and 'Modify Access Control Operation'. The 'Query' section has three dropdown menus for 'Group Name', 'Security Model', and 'Security Level'. The 'Modify' section has three checkboxes for 'Read', 'Write', and 'Notify', each followed by a dropdown menu. An 'Apply Changes' button is located at the bottom of the configuration area.

Group Name — The user-defined group to whom access control rules are applied. The field range is up to 30 characters.

Security Model — Defines the SNMP version attached to the group. The possible field values are:

SNMPv1 — SNMPv1 is defined for the group.

SNMPv2 — SNMPv2 is defined for the group.

SNMPv3 — SNMPv3 is defined for the group.

Security Level — The security level attached to the group. Security levels apply to SNMPv3 only. The possible field values are:

No Authentication — Neither the Authentication nor the Privacy security levels are assigned to the group.

Authentication — Authenticates SNMP messages, and ensures the SNMP messages origin is authenticated.

Operation — Defines the group access rights. The possible field values are:

Read — The management access is restricted to read-only, and changes cannot be made to the assigned SNMP view.

Write — The management access is read-write and changes can be made to the assigned SNMP view.

Notify — Sends traps for the assigned SNMP view.

Defining SNMP Groups

- 1 Open the Access Control Group page.
- 2 Click Add.

The Add an Access Control Group page opens:

Figure 1-14. Add an Access Control Group

Add an Access Control Group

Group Name (1-30 Characters)

Security Model

Security Level

Operation Read Write Notify

[Apply Changes](#)

- 3 Define the fields in the Add an Access Control Group page.
- 4 Click Apply Changes.

The group is added, and the device is updated.

Displaying the Access Table

- 1 Open the Access Control Group page.
- 2 Click Show All.

The Access Table opens.

Access Table

Group Name	SNMP Version	Security Level	Operation			Remove
			Read	Write	Notify	

Removing SNMP Groups

- 1 Open the Access Control Group page.
- 2 Click **Show All**. The Access Table opens.
- 3 Select an **SNMP group**.
- 4 Check the **Remove** checkbox.
- 5 Click **Apply Changes**. The SNMP group is deleted, and the device is updated.

Defining SNMP Access Control Using CLI Commands

The following table summarizes the equivalent CLI commands for defining fields displayed in the Access Control Group page.

Figure 1-15. SNMP Access Control CLI Commands

CLI Command	Description
<code>snmp-server group groupname {v1 v2 v3 {noauth auth priv}} [read readview] [write writeview] [notify notifyview]</code>	Configure a new Simple Network Management Protocol (SNMP) group, or a table that maps SNMP users to SNMP views.
<code>show snmp groups [groupname]</code>	Displays the configuration of groups.

The following is an example of the CLI commands:

```
console (config)# snmp-server group user-group v3 priv read user-view
```

Assigning SNMP User Security

The SNMPv3 User Security Model (USM) page enables assigning system users to SNMP groups, as well as defining the user authentication method.

To open the SNMPv3 User Security Model (USM) page, click **System** → **SNMP** → **User Security Model** in the tree view.

Figure 1-16. SNMPv3 User Security Model

The screenshot shows the Dell OpenManage Switch Administrator interface. The top navigation bar includes the Dell logo, the version number 10.6.5.49, and the page title 'SNMPv3 - User Security Model'. On the left is a tree view with 'System' expanded to 'SNMP', and 'User Security Model' selected. The main content area is titled 'SNMPv3 - User Security Model' and contains the following configuration fields:

- User Name: A dropdown menu.
- Engine ID (5-32 Hex Characters Pairs): A dropdown menu.
- Group Name: A dropdown menu.
- Authentication Method: A dropdown menu with 'None' selected.
- Password (0-32 Characters): A text input field.
- Authentication Key (MD5-16; SHA-20 hexa chars): A text input field.
- Privacy Key (16 hexa chars): A text input field.

Below the fields is a 'Remove' button and an 'Apply Changes' button.

User Name — Contains a list of user-defined user names. The field range is up to 30 alphanumeric characters.

Engine (5-32 Hex Characters Pairs) — Indicates either the local or remote SNMP entity, to which the user is connected. Changing or removing the local SNMP Engine ID deletes the SNMPv3 User Database.

Group Name — Contains a list of user-defined SNMP groups. SNMP groups are defined in the **Access Control Group** page.

Authentication Method — The authentication method used to authenticate users. The possible field values are:

MD5 Key — Users are authenticated using the HMAC-MD5 algorithm.

SHA Key — Users are authenticated using the HMAC-SHA-96 authentication level.

MD5 Password — Indicates that HMAC-MD5-96 password is used for authentication. The user should enter a password.

SHA Password — Users are authenticated using the HMAC-SHA-96 authentication level. The user should enter a password.

None — No user authentication is used.

Password (0-32 Characters) — Modifies the user-defined password for a group. Passwords can contain a maximum of 32 alphanumeric characters.

Authentication Key (MD5-16; SHA-20 hexa chars) — Defines the HMAC-MD5-96 or HMAC-SHA-96 authentication level. The authentication and privacy keys are entered to define the authentication key. If only authentication is required, 16 bytes are defined for MD5. If both privacy and authentication are required, 32 bytes are defined for MD5. Each byte in hexadecimal character strings is two hexadecimal digits. Each byte can be separated by a period or a colon.

Privacy Key (16 hexa characters) — If only authentication is required, 20 bytes are defined. If both privacy and authentication are required, 16 bytes are defined. Each byte in hexadecimal character strings is two hexadecimal digits. Each byte can be separated by a period or colon.

Remove — When checked, removes users from a specified group.

Adding Users to a Group

- 1 Open the SNMPv3 User Security Model page.
- 2 Click Add.

The Add SNMPv3 User Name page opens.

Figure 1-17. Add SNMPv3 User Name

The screenshot shows a configuration form for adding a new SNMPv3 user. The form is titled "Add SNMPv3 User Name" and contains the following fields:

- User Name (1-30 Characters):** A text input field.
- Engine ID:** Radio buttons for "Local" (selected) and "Remote".
- Group Name:** A dropdown menu.
- Authentication Method:** A dropdown menu with "None" selected.
- Password (1-32 Characters):** A text input field.
- Authentication Key (MD5-16; SHA-20 Hex Characters pairs):** A text input field.
- Privacy Key (16 Hex Characters pairs):** A text input field.

At the bottom of the form is a button labeled "Apply Changes".

- 3 Define the relevant fields.
- 4 Click **Apply Changes**.

The user is added to the group, and the device is updated.

Displaying the User Security Model Table

- 1 Open the SNMPv3 User Security Model (USM) page.
- 2 Click Show All.

The User Security Model Table opens.

Figure 1-18. User Security Model Table

User Security Model Table

User Name	Group Name	Engine ID	Authentication	Remove
<input type="button" value="Apply Changes"/>				

Deleting an User Security Model Table Entry

- 1 Open the SNMPv3 User Security Model (USM) page.
- 2 Click Show All. The User Security Model Table opens.
- 3 Select a User Security Model Table entry.
- 4 Check the Remove checkbox.
- 5 Click Apply Changes. The User Security Model Table entry is deleted, and the device is updated.

Defining SNMP Users Using CLI Commands

The following table summarizes the equivalent CLI commands for defining fields displayed in the SNMPv3 User Security Model page.

Table 1-6. SNMP User CLI Commands

CLI Command	Description
snmp-server user <i>username groupname</i> [remote <i>engineid-string</i>][auth-md5 <i>password</i> auth-sha <i>password</i> auth-md5- key <i>md5-des-key</i> auth-sha-key <i>sha-des-</i> <i>key</i>]	Configures a new SNMP V3 user.
show snmp users [<i>username</i>]	Displays the configuration of users.

The following is an example of the CLI commands:

```

console (config)# snmp-server user John user-group auth-md5 1234
console (config)# end
console (config)# show snmp users


```

Name	Group Name	Auth Method	Remote
-----	-----	-----	-----
John	user-group	md5	

Defining Communities

Access rights are managed by defining communities in the **Community Table**. When the community names are changed, access rights are also changed. To open the SNMP Communities page, click **System** → **SNMP** → **Community** in the tree view.

Figure 1-19. SNMP Community



SNMP Management Station — A list of management station IP addresses.

Community String — Functions as a password and used to authenticate the selected management station to the device.

Access Mode — Defines the access rights of the community. The possible field values are:

Read Only — The management access is restricted to read-only, for all MIBs except the community table, for which there is no access.

Read Write — The management access is read-write, for all MIBs except the community table, for which there is no access.

SNMP Admin — The management access is read-write for all MIBs, including the community table.

Remove — Removes a community, when selected.

Defining a New Community

- 1 Open the **SNMP Community** page.
- 2 Click **Add**.

The **Add SNMP Community** page opens:

Figure 1-20. Add SNMP Community
Add SNMP Community

- 3 Select one of the following:
 - Management Station** — Defines an SNMP community for a specific management station. (A value of 0.0.0.0 specifies all management stations.)
 - All** — Defines an SNMP community for all management stations.
- 4 Define the remaining fields.
- 5 Click **Apply Changes**.
The new community is saved, and the device is updated.

Displaying all Communities

- 1 Open the **SNMP Community** page.
- 2 Click **Show All**.
The **Community Table** opens:

Figure 1-21. Community Table



Deleting Communities

- 1 Open the SNMP Community page.
- 2 Click **Show All**.
The **Community Table** opens.
- 3 Select a community from the **Community Table**.
- 4 Select the **Remove** check box.
- 5 Click **Apply Changes**.
The selected community entry is deleted, and the device is updated.

Configuring Communities Using CLI Commands

The following table summarizes the equivalent CLI commands for setting fields displayed in the SNMP Community page.

Table 1-7. SNMP Community CLI Commands

CLI Command	Description
<code>snmp-server community string [ro rw su] [ip-address]</code>	Sets up the community access string to permit access to SNMP protocol.
<code>snmp-server host {ip-address hostname} community-string [1 2]</code>	Determines the trap type sent to the selected recipient.
<code>show snmp</code>	Checks the SNMP communities status.

The following is an example of the CLI commands:

```
console(config)# snmp-server community public_1 su 1.1.1.1
console(config)# snmp-server community public_2 rw 2.2.2.2
console(config)# snmp-server community public_3 ro 3.3.3.3
console(config)# snmp-server host 1.1.1.1 public_1 1
console(config)# snmp-server host 2.2.2.2 public_2 2
console(config)#

console# show snmp

Community-String      Community-Access      IP address
-----
public_1              super                 1.1.1.1
public_2              readwrite             2.2.2.2
public_3              readonly              3.3.3.3

Traps are enabled.
Authentication-failure trap is enabled.


Trap-Rec-Address      Trap-Rec-Community    Version
-----
1.1.1.1              public_1              1
2.2.2.2              public_2              2

System Contact: 345 6789
System Location: 1234 5678
console#
```

Defining SNMPv3 Notification Filters

The SNMPv3 Notification Filter page permits filtering traps based on OIDs. Each OID is linked to a device feature or a feature aspect. The SNMPv3 - Notification Filter page also allows network managers to filter notifications. To open the SNMPv3 Notification Filter page, click **System** → **SNMP** → **Notification Filter** in the tree view.

Figure 1-22. SNMPv3 - Notification Filters



Notification Filter Name — The user-defined notification filter.

New Object Identifier Tree — The OID for which notifications are sent or blocked. If a filter is attached to an OID, traps or informs are generated and sent to the trap recipients. Object IDs are selected from either the Select from List or the Object ID List.

Notification Filter Type — Indicates whether informs or traps are sent regarding the OID to the trap recipients.

Excluded — Restricts sending OID traps or informs.

Included — Sends OID traps or informs.

Adding SNMP Filters

- 1 Open the SNMPv3 Notification Filter page.
- 2 Click Add.
The Add Filter page opens.

Figure 1-23. Add Filter

Add Filter

Filter Name (1-30 Characters)

New Object Identifier Tree Select from List Object ID

Filter Type

- 3 Define the relevant fields.
- 4 Click **Apply Changes**.
The new filter is added, and the device is updated.

Displaying the Filter Table

- 1 Open the SNMPv3 Notification Filter page.
- 2 Click **Show All**.
The Filter Table opens.

Figure 1-24. Filter Table

Filter Table

Filter Name

	Object Identifier Subtree	Filter Type	Remove
1	<input type="text"/>	<input type="text" value="Included"/>	<input type="checkbox"/>

Removing a Filter

- 1 Open the SNMPv3 Notification Filter page.
- 2 Click **Show All**. The **Filter Table** opens.
- 3 Select a **Filter Table** entry.
- 4 Check the **Remove** checkbox. The filter entry is deleted, and the device is updated.

Configuring Notification Filters Using CLI Commands

The following table summarizes equivalent CLI commands for defining fields displayed in the [SNMPv3 - Notification Filters](#) page.

Table 1-8. SNMP Notification Filter CLI Commands

CLI Command	Description
<code>snmp-server filter</code> <i>filter-name oid-tree</i> { included excluded }	Creates or updates an SNMP notification filter.
<code>show snmp filters</code> [<i>filtername</i>]	Displays the configuration of SNMP notification filters.

The following is an example of CLI commands:

```
Console (config)# snmp-server filter user1 iso included
Console(config)# end
Console # show snmp filters

Name                OID Tree            Type
-----            -
user1                iso                  Included
```

Defining SNMP Notification Recipients

The [Notification Recipients](#) page contains information for defining filters that determine whether traps are sent to specific users, and the trap type sent. SNMP notification filters provide the following services:

- Identifying Management Trap Targets
- Trap Filtering
- Selecting Trap Generation Parameters
- Providing Access Control Checks

To open the [Notification Recipients](#) page, click [System](#) → [SNMP](#) → [Notification Recipient](#) in the tree view.

Figure 1-25. Notification Recipients

The screenshot shows the 'SNMP - Notification Recipients' configuration page in the Dell OpenManage Switch Administrator. The interface includes a navigation tree on the left with categories like System, IP Addressing, and SNMP. The main area is titled 'SNMP - Notification Recipients' and contains several configuration sections:

- Recipient IP:** A dropdown menu.
- Notification Type:** A dropdown menu set to 'Traps'.
- SNMPv1,2 Section:**
 - Community String:** A dropdown menu.
 - Notification Version:** A dropdown menu set to 'SNMPv1'.
- SNMPv3 Section:**
 - User Name:** A dropdown menu.
 - Security Level:** A dropdown menu set to 'No Authentication'.
- UDP Port (1-65535):** A text input field containing '162'.
- Filter Name:** A dropdown menu.
- Timeout (1-300):** A text input field containing '15' with '(Sec)' next to it.
- Retries (1-255):** A text input field containing '3'.
- Remove Notification Recipient:** A checkbox.

Buttons for 'Print', 'Refresh', 'Add', 'Show All', and 'Apply Changes' are located at the bottom of the configuration area.

Recipient IP — Indicates the IP address to whom the traps are sent.

Notification Type — The notification sent. The possible field values are:

Traps — Traps are sent.

Informs — Informs are sent.

SNMPv1,2 — SNMP versions 1 and 2 are enabled for the selected recipient. Define the following fields for SNMPv1 and SNMPv2:

Community String (1-20 Characters) — Identifies the community string of the trap manager.

Notification Version — Determines the trap type. The possible field values are:

SNMPv1 — SNMP Version 1 traps are sent.

SNMPv2 — SNMP Version 2 traps are sent.

SNMPv3 — SNMPv3 is used to send and receive traps. Define the following fields for SNMPv3:

User Name — The user to whom SNMP notifications are sent.

Security Level — Defines the means by which the packet is authenticated. The possible field values are:

No Authentication — The packet is neither authenticated nor encrypted.

Authentication — The packet is authenticated.

Privacy — The packet is both authenticated and encrypted.

UDP Port (1-65535) — The UDP port used to send notifications. The default is 162.

Filter Name — Includes or excludes SNMP filters.

Timeout (1-300) — The amount of time (seconds) the device waits before resending informs. The default is 15 seconds.

Retries (1-255) — The amount of times the device resends an inform request. The default is 3.

Remove Notification Recipient — When checked, removes selected notification recipients.

Adding a New Trap Recipients

- 1 Open Notification Recipients page.
- 2 Click Add.

The Add Notification Recipients page opens.

Add Notification Recipient

Recipient IP (X.X.X)

Notification Type

SNMPv1,2

Community String (1-20 Characters)

Notification Version

SNMPv3

User Name (1-20 Characters)

Security Level

UDP Port (1-65535)

Filter Name

Timeout (1-300) (sec)

Retries (1-255)

- 3 Define the relevant fields.
- 4 Click **Apply Changes**.

The notification recipient is added, and the device is updated.

Displaying Notification Recipients Tables

- 1 Open Notification Recipients page.
- 2 Click **Show All**.

The Notification Recipients Tables page opens.

Figure 1-26. Notification Recipients Tables

Notification Recipients Tables Refresh

SNMPv1,2 Notification Recipient

Recipients IP	Notification Type	Community String	Notification Version	UDP Port	Filter Name	Timeout	Retries	Remove
1	<input type="checkbox"/>							<input type="checkbox"/>

SNMPv3 Notification Recipient

Recipients IP	Notification Type	User Name	Security Level	UDP Port	Filter Name	Timeout	Retries	Remove
1	<input type="checkbox"/>							<input type="checkbox"/>

Apply Changes

Deleting Notification Recipients

- 1 Open Notification Recipients page.
- 2 Click Show All.
The Notification Recipients Tables page opens.
- 3 Select a notification recipient in either the SNMPV1,2 Notification Recipient or SNMPv3 Notification Recipient Tables.
- 4 Check the Remove checkbox.
- 5 Click Apply Changes. The recipient is deleted, and the device is updated.

Configuring SNMP Notification Recipients Using CLI Commands

The following table summarizes the equivalent CLI commands for viewing fields displayed in the SNMP Trap Settings page.

Table 1-9. SNMP Notification Recipients CLI Commands

CLI Command	Description
<code>snmp-server host {ipaddress hostname} community-string [traps informs] [1 2] [udp-port port] [filter filtername] [timeout seconds] [retries retries]</code>	Creates or updates a notification recipient receiving notifications in SNMP version 1 or 2.

Table 1-9. SNMP Notification Recipients CLI Commands

CLI Command	Description
<code>snmp-server v3-host {ip-address hostname} username [traps informs] {noauth auth priv} [udp-port port] [filter filtername] [timeout seconds] [retries retries]</code>	Creates or updates a notification recipient receiving notifications in SNMP version 3.
<code>show snmp</code>	Shows the current SNMP configuration.

The following is an example of the CLI commands:

```

console (config)# snmp-server host 172.16.1.1 private
console# show snmp
Community-String  Community-Access  View name      IP address
-----
public            read only      user-view      All
private          read write    default        172.16.1.1
private          su             DefaultSuper   172.17.1.1

```

HTTP/HTTPS Upload/Download

Downloading Files

The File Download From Server page contains fields for downloading system image and Configuration files from the TFTP server to the device or the HTTP/S server. To open the File Download From Server page, click System → File Management → File Download in the tree view.

Figure 1-27. File Download From Server

The screenshot shows the Dell OpenManage Switch Administrator interface. The top navigation bar includes 'Support', 'Help', 'About', and 'Log Out'. The main content area is titled 'File Download from Server' and contains three main sections:

- Firmware Download:** Includes a radio button for 'Firmware Download' (selected), a 'Download via TFTP' radio button, and a 'Download via HTTP' radio button. Below are fields for 'Server IP Address' (with a '(X.X.X)' placeholder), 'Source File Name (1-159 Characters)', and 'Destination File' (with a dropdown menu set to 'Software Image').
- Active Image:** Includes a field for 'Active Image' (set to 'Image 1') and a field for 'Active Image After Reset' (with a dropdown menu set to 'Image 1').
- Configuration Download:** Includes a radio button for 'Configuration Download', a 'Server IP Address' field (with a '(X.X.X)' placeholder), a 'Source File Name (1-159 Characters)' field, and a 'Destination' field (with a dropdown menu set to 'Running Configuration').

At the bottom of the form is an 'Apply Changes' button. The left sidebar shows a tree view with 'File Download' selected under 'File Management'.

Firmware Download — The Firmware file is downloaded. If **Firmware Download** is selected, the **Configuration Download** fields are grayed out.

Configuration Download — The Configuration file is downloaded. If **Configuration Download** is selected, the **Firmware Download** fields are grayed out.

Download via TFTP — Enables initiating an upload via the TFTP server.

Download via HTTP — Enables initiating an upload via the HTTP server or HTTPS server.

Firmware Download

Server IP Address — The Server IP Address from which the firmware files are downloaded.

Source File Name — Indicates the file to be downloaded.

Destination File — The destination file type to which the file is downloaded. The possible field values are:

Software Image — Downloads the image file.

Boot Code — Downloads the Boot file.

Active Image

Active Image — The Image file that is currently active.

Active Image After Reset — The Image file that is active after the device is reset.



NOTE: The image file overwrites the non-active image. It is recommended to designate that the nonactive image will become the active image after reset, and then to reset the device following the download. During the image file download, a dialog box opens which displays the download progress. The window closes automatically when the download is complete.

Configuration Download

Server IP Address — The Server IP Address from which the configuration files are downloaded.

Source File Name — Indicates the configuration files to be downloaded.

Destination — The destination file to which the configuration file is downloaded.

The possible field values are:

Running Configuration — Downloads commands into the Running Configuration file.

Startup Configuration — Downloads the Startup Configuration file, and overwrites it.

Backup Configuration — Downloads commands into the Configuration file.

Downloading Files

- 1 Open the **File Download From Server** page.
- 2 Define the file type to download.
- 3 Define the fields.
- 4 Click **Apply Changes**.

The software is downloaded to the device.

Downloading Files Using CLI Commands

The following table summarizes the equivalent CLI commands for setting fields displayed in the **File Download From Server** page.

Table 1-10. File Download CLI Commands

CLI Command	Description
<code>copy source-url destination-url [snmp]</code>	Copies any file from a source to a destination.

The following is an example of the CLI commands:

```
console# copy running-config tftp://11.1.1.2/pp.txt
```


Uploading Files

The **File Upload to Server** page contains fields for uploading the software from the TFTP server to the device. The image file can also be uploaded from the **File Upload to Server** page. To open the **File Upload to Server** page, click **System** → **File Management** → **File Upload** in the tree view.

Figure 1-28. File Upload to Server

The screenshot shows the Dell OpenManage Switch Administrator interface. The top navigation bar includes 'Support', 'Help', 'About', and 'Log Out'. The main content area is titled 'File Upload to Server' and contains several sections for file uploads. The 'Firmware Upload' and 'Configuration Upload' sections at the top have radio buttons. Below these are the 'Software Image Upload' and 'Configuration Upload' sections, each with input fields for 'TFTP Server IP Address', 'Destination File Name (1-160 Characters)', and 'Transfer File Name'. The 'Software Image Upload' section has a dropdown menu for 'Transfer File Name' with 'Running Configuration' selected. An 'Apply Changes' button is located at the bottom of the page.

Firmware Upload — Indicates that the upload is for firmware. If **Firmware Upload** is selected, the **Configuration Upload** fields are grayed out.

Configuration Upload — Indicates that the upload is for configuration files. If **Configuration Upload** is selected, the **Firmware Upload** fields are grayed out.

Upload via TFTP — Enables initiating an upload via the TFTP server.

Upload via HTTP — Enables initiating an upload via the HTTP or HTTPS server. Only configuration files can be uploaded using HTTP or HTTPS server.

Software Image Upload

TFTP Server IP Address — The TFTP Server IP Address to which the Image file is uploaded.

Destination File Name (1-160 Characters) — Indicates the Image file path to which the file is uploaded.

Configuration Upload

TFTP Server IP Address — The TFTP Server IP Address to which the Configuration file is uploaded.

Destination File Name (1-160 Characters) — Indicates the Configuration file path to which the file is uploaded.

Transfer File Name — The software file to which the configuration is uploaded. The possible field values are:

Running Configuration — Uploads the Running Configuration file.

Startup Configuration — Uploads the Startup Configuration file.

Backup Configuration — Uploads the Backup Configuration file.

Uploading Files

- 1 Open the **File Upload to Server** page.
- 2 Define the file type to upload.
- 3 Define the fields.
- 4 Click **Apply Changes**.

The software is uploaded to the device.

Uploading Files Using CLI Commands

The following table summarizes the equivalent CLI commands for setting fields displayed in the **File Upload to Server** page.

Table 1-11. File Upload CLI Commands

CLI Command	Description
<code>copy source-url destination-url [snmp]</code>	Copies any file from a source to a destination.


The following is an example of the CLI commands:

```

console# copy image tftp://10.6.6.64/uploaded.ros
!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!
!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!
!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!
!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!
!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!
!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!
!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!

Copy: 4234656 bytes copied in 00:00:33 [hh:mm:ss]
01-Jan-2000 07:30:42 %COPY-W-TRAP: The copy operation was
completed successfully

```


 **NOTE:** Each "!" indicates that 10 packets were successfully transferred.

Copying Files

Files can be copied and deleted from the **Copy Files** page. To open the **Copy Files** page, click **System**→ **File Management**→ **Copy Files** in the tree view.

Figure 1-29. Copy Files

i



Copy Configuration — When selected, copies either the Running Configuration, Startup Configuration or Backup Configuration files. The possible field values are:

Source — Copies either the Running Configuration, Startup Configuration or Backup Configuration files.

Destination — The file to which the Running Configuration, Startup Configuration or Backup Configuration file is copied.

Restore Configuration Factory Defaults — When selected, specifies that the factory configuration default files should be reset. When unselected, maintains the current configuration settings.

Copying Files

- 1 Open the **Copy Files** page.
- 2 Define the **Source** and **Destination** fields.
- 3 Click **Apply Changes**.
The file is copied, and the device is updated.

Restoring Company Factory Default Settings

- 1 Open the Copy Files page.
- 2 Click Restore Company Factory Defaults.
- 3 Click Apply Changes.

The company factory default settings are restored, and the device is updated.

Copying and Deleting Files Using CLI Commands

The following table summarizes the equivalent CLI commands for setting fields displayed in the Copy Files page.

Table 1-12. Copy Files CLI Commands

CLI Command	Description
<code>copy source-url destination-url [snmp]</code>	Copies any file from a source to a destination.
<code>delete startup-config</code>	Deletes the startup-config file.

The following is an example of the CLI commands:


```
Console# copy running-config startup-config
01-Jan-2000 01:55:03 %COPY-W-TRAP: The copy operation was
completed successfully
Copy succeeded
```

Defining STP Root Guard

Defining STP Global Settings

The Spanning Tree Global Settings page contains parameters for enabling STP on the device. To open the Spanning Tree Global Settings page, click Switch→ Spanning Tree→ Global Settings in the tree view.

Figure 1-30. Spanning Tree Global Settings



The Spanning Tree Global Settings page contains the following fields:

Spanning Tree State — Enables or disables STP, Rapid STP, or MSTP on the device.

STP Operation Mode — Indicates the STP mode by which STP is enabled on the device. The possible field values are:

Classic STP — Enables Classic STP on the device. This is the default value.

Rapid STP — Enables Rapid STP on the device.

Multiple STP — Enables Multiple STP on the device.

Path Cost Default Values — Specifies the method used to assign default path costs to STP ports. The possible field values are:

Short — Specifies 1 through 65,535 range for port path costs. This is the default value.

Long — Specifies 1 through 200,000,000 range for port path costs.

The default path costs assigned to an interface vary according to the selected method:

Interface	Long	Short
LAG	20,000	4
1000 Mbps	20,000	4
100 Mbps	200,000	19
10 Mbps	2,000,000	100

BPDU Handling — Determines how BPDU packets are managed when STP is disabled on the port/ device. BPDUs are used to transmit spanning tree information. The possible field values are:

Filtering — Filters BPDU packets when spanning tree is disabled on an interface. This is the default value.

Flooding — Floods BPDU packets when spanning tree is disabled on an interface.

Priority (0-61440) — Specifies the bridge priority value. When switches or bridges are running STP, each is assigned a priority. After exchanging BPDUs, the device with the lowest priority value becomes the Root Bridge. The default value is 32768. The port priority value is provided in increments of 4096. For example, 4096, 8192, 12288, etc.

Hello Time (1-10) — Specifies the device Hello Time. The Hello Time indicates the amount of time in seconds a root bridge waits between configuration messages. The default is 2 seconds.

Max Age (6-40) — Specifies the device Maximum Age Time. The Maximum Age Time indicates the amount of time in seconds a bridge waits before sending configuration messages. The default max age is 20 seconds.

Forward Delay (4-30) — Specifies the device forward delay time. The Forward Delay Time indicates the amount of time in seconds a bridge remains in a listening and learning state before forwarding packets. The default is 10 seconds.

Bridge ID — Identifies the Bridge priority and MAC address.

Root Bridge ID — Identifies the Root Bridge priority and MAC address.

Root Port — Indicates the port number that offers the lowest cost path from this bridge to the Root Bridge. It is significant when the Bridge is not the Root.

Root Path Cost — The cost of the path from this bridge to the root.

Topology Changes Counts — Specifies the total amount of STP state changes that have occurred.

Last Topology Change — Indicates the amount of time that has elapsed since the bridge was initialized or reset, and the last topographic change occurred. The time is displayed in a D/H/M/S format, for example, 2D/5H/10M/4S.

Defining STP Global Parameters

- 1 Open the [page](#).
- 2 Select **Enable** in the **Spanning Tree State** field.
- 3 Select the STP mode in the **STP Operation Mode** field, and define the bridge settings.
- 4 Click **Apply Changes**.
STP is enabled on the device.

Modifying STP Global Parameters

- 1 Open the [page](#).
- 2 Define the fields in the dialog.
- 3 Click **Apply Changes**.
The STP parameters are modified, and the device is updated.

Defining STP Global Parameters Using CLI Commands

The following table summarizes the equivalent CLI commands for defining STP global parameters as displayed in the Spanning Tree Global Settings page.

Table 1-13. STP Global Parameter CLI Commands

CLI Command	Description
<code>spanning-tree</code>	Enables spanning tree functionality.
<code>spanning-tree mode {stp rstp mstp}</code>	Configures the mode of the spanning tree protocol.
<code>spanning-tree priority priority</code>	Configures the spanning tree priority.
<code>spanning-tree hello-time seconds</code>	Configures the spanning tree bridge Hello Time, which is how often the device broadcasts Hello messages to other devices.
<code>spanning-tree max-age seconds</code>	Configures the spanning tree bridge maximum age.
<code>spanning-tree forward-time seconds</code>	Configures the spanning tree bridge forward time, which is the amount of time a port remains in the listening and learning states before entering the forwarding state.

Table 1-13. STP Global Parameter CLI Commands (continued)

CLI Command	Description
show spanning-tree [ethernet <i>interface</i> port-channel <i>port-</i> <i>channel-number</i>] [instance <i>instance-id</i>]	Displays spanning tree configuration.
show spanning-tree [detail] [active blockedports] [instance <i>instance-id</i>]	Displays detailed spanning tree information on active or blocked ports.
show spanning-tree mst- configuration	Displays spanning tree MST configuration identifier.

The following is an example of the CLI commands:

```
console(config)# spanning-tree
console(config)# spanning-tree mode rstp
console(config)# spanning-tree priority 12288
console(config)# spanning-tree hello-time 5
console(config)# spanning-tree max-age 12
console(config)# spanning-tree forward-time 25
console(config)# exit
console# show spanning-tree
Spanning tree enabled mode MSTP
Default port cost method: short

Gathering information .....
##### MST 0 Vlans Mapped: 16-4094
CST Root ID Priority 20480
    Address          00:30:ab:00:00:08
    Path Cost        4
    Root Port        ch2
    This switch is the IST master
    Hello Time 2 sec Max Age 20 sec Forward Delay 15 sec

Bridge ID Priority          32768
    Address          00:00:00:16:00:64
    Max hops         20

Name  State  Prio.Nbr  Cost  Sts  Role  PortFast  Type
----  -
1/e2  enabled  128.2    100  DSBL  Dsbl   No        P2p Intr
1/e3  enabled  128.3    100  DSBL  Dsbl   No        P2p Intr
1/e4  enabled  128.4    100  DSBL  Dsbl   No        P2p Intr
1/e5  enabled  128.5    19   FRW   Desg   Yes       P2p Intr
```

```

1/e6 enabled 128.6 100 DSBL Dsbl No P2p Intr
1/e7 enabled 128.7 100 DSBL Dsbl No P2p Intr
1/e8 enabled 128.8 100 DSBL Dsbl No P2p Intr
1/e9 enabled 128.9 100 DSBL Dsbl No P2p Intr
1/e10 enabled 128.10 100 DSBL Dsbl No P2p Intr
1/e11 enabled 128.11 19 DSBL Desg Yes P2p Intr

```

```
console# show spanning-tree active
```

```
Spanning tree enabled mode MSTP
```

```
Default port cost method: short
```

```
Gathering information .....
```

```
##### MST 0 Vlans Mapped: 16-4094
```

```
CST Root ID Priority 20480
```

```
Address 00:30:ab:00:00:08
```

```
Path Cost 4
```

```
Root Port ch2
```

```
This switch is the IST master
```

```
Hello Time 2 sec Max Age 20 sec Forward Delay 15 sec
```

```
Bridge ID Priority 32768
```

```
Address 00:00:00:16:00:64
```

```
Max hops 20
```

```


Name State Prio.Nbr Cost Sts Role PortFast Type
---- -
1/e5 enabled 128.2 19 FRW Desg Yes P2p Intr
1/e7 enabled 128.7 19 DSCR Altn No P2p Bound (STP)
1/e11 enabled 128.11 19 FRW Desg Yes P2p Intr
1/e15 enabled 128.15 19 FRW Desg No P2p Intr
1/e22 enabled 128.22 19 FRW Desg Yes P2p Intr

```

Defining STP Port Settings

The STP Port Settings page contains fields for assigning STP properties to individual ports. To open the STP Port Settings page, click Switch→ Spanning Tree→ Port Settings in the tree view.

Figure 1-31. STP Port Settings



Port — Port on which STP is enabled.

STP — Enables or disables STP on the port.

Fast Link — When selected, enables Fast Link mode for the port. If Fast Link mode is enabled for a port, the **Port State** is automatically placed in the **Forwarding** state when the port link is up. Fast Link mode optimizes the time it takes for the STP protocol to converge. STP convergence can take 30-60 seconds in large networks.

Root Guard — When checked, prevents devices outside the network core from being assigned the spanning tree root.

Port State — The current port STP state. If enabled, the port state determines what forwarding action is taken on traffic. Possible port states are:

Disabled — The port link is currently down.

Blocking — The port is currently blocked and cannot be used to forward traffic or learn MAC addresses. Blocking is displayed when Classic STP is enabled.

Listening — The port is currently in the listening mode. The port cannot forward traffic nor can it learn MAC addresses.

Learning — The port is currently in the learning mode. The port cannot forward traffic however it can learn new MAC addresses.

Forwarding — The port is currently in the forwarding mode. The port can forward traffic and learn new MAC addresses.

Speed — Speed at which the port is operating.

Path Cost (1-200000000) — The port contribution to the root path cost. The path cost is adjusted to a higher or lower value, and is used to forward traffic when a path being rerouted.

Default Path Cost — The default path cost of the port is automatically set by the port speed and the default path cost method.

The default values for long path costs are:

Ethernet - 2000000

Fast Ethernet - 200000

Gigabit Ethernet - 20000

The default values for short path costs (short path costs are the default) are:

Ethernet - 100

Fast Ethernet - 19

Gigabit Ethernet - 4

Priority (0-240, in steps of 16) — The priority value of the port. The priority value influences the port choice when a bridge has two ports connected in a loop. The priority value is between 0-240. The priority value is provided in increments of 16.

Designated Bridge ID — The bridge priority and the MAC Address of the designated bridge.

Designated Port ID — The selected port's priority and interface.

Designated Cost — The cost of the port participating in the STP topology. Ports with a lower cost are less likely to be blocked if STP detects loops.

Forward Transitions — The number of times the port has changed from the **Blocking** state to the **Forwarding** state.

LAG — The LAG to which the port is attached.

Enabling STP on a Port

- 1 Open the **STP Port Settings** page.
- 2 Select **Enabled** in the **STP Port Status** field.
- 3 Define the **Fast Link**, **Path Cost**, and the **Priority** fields.
- 4 Click **Apply Changes**.

STP is enabled on the port.

Modifying STP Port Properties

- 1 Open the STP Port Settings page.
- 2 Modify the Priority, Fast Link, Path Cost, and the Fast Link fields.
- 3 Click Apply Changes.

The STP port parameters are modified, and the device is updated.

Displaying the STP Port Table

- 1 Open the STP Port Settings page.
- 2 Click Show All.

The STP Port Table opens.

Defining STP Port Settings Using CLI Commands

The following table summarizes the equivalent CLI commands for defining STP port parameters as displayed in the STP Port Settings page.

Table 1-14. STP Port Settings CLI Commands

CLI Command	Description
<code>spanning-tree disable</code>	Disables spanning tree on a specific port.
<code>spanning-tree cost <i>cost</i></code>	Configures the spanning tree cost contribution of a port.
<code>spanning-tree port-priority <i>priority</i></code>	Configures port priority.
<code>spanning-tree portfast</code>	Enables PortFast mode.
<code>show spanning-tree [ethernet <i>interface</i> port-channel <i>port-channel-number</i>]</code>	Displays spanning tree configuration.
<code>spanning-tree guard root</code>	Enables root guard on all the spanning tree instances on that interface.

The following is an example of the CLI commands:

```
console(config)# interface ethernet g5
console(config-if)# spanning-tree disable
console(config-if)# spanning-tree cost 35000
console(config-if)# spanning-tree port-priority 96
console(config-if)# exit
console(config)# exit
console# show spanning-tree ethernet g5


Port g5 disabled
State: disabled                               Role: disabled
Port id: 96.5                                 Port cost: 35000
Type: P2p (configured: Auto) STP             Port Fast: No (configured: No)
Designated bridge Priority : 32768           Address: 00:e8:00:b4:c0:00
Designated port id: 96.5                     Designated path cost: 19
Number of transitions to forwarding state: 0
BPDU: sent 0, received 0

console#
```

Defining STP LAG Settings

The STP LAG Settings page contains fields for assigning STP aggregating port parameters. To open the STP LAG Settings page, click Switch→ Spanning Tree→ LAG Settings in the tree view.

Figure 1-32. STP LAG Settings



Select a LAG — The user-defined LAG. For more information, see "Defining LAG Membership" in the *Dell PowerConnect 5324 User Guide*.

STP — Enables or disables STP on the LAG.

Fast Link — Enables Fast Link mode for the LAG. If Fast Link mode is enabled for a LAG, the **LAG State** is automatically placed in the **Forwarding** state when the LAG is up. Fast Link mode optimizes the time it takes for the STP protocol to converge. STP convergence can take 30-60 seconds in large networks.

Root Guard — When checked, prevents devices outside the network core from being assigned the spanning tree root.

LAG State — Current STP state of a LAG. If enabled, the LAG state determines what forwarding action is taken on traffic. If the bridge discovers a malfunctioning LAG, the LAG is placed in the **Broken** state. Possible LAG states are:

Disabled — The LAG link is currently down.

Blocking — The LAG is blocked and cannot be used to forward traffic or learn MAC addresses.

Listening — The LAG is in the listening mode and cannot forward traffic or learn MAC addresses.

Learning — The LAG is in the learning mode and cannot forward traffic, but it can learn new MAC addresses.

Forwarding — The LAG is currently in the forwarding mode, and it can forward traffic and learn new MAC addresses.

Broken — The LAG is currently malfunctioning and cannot be used for forwarding traffic.

Path Cost (1-200000000) — Amount the LAG contributes to the root path cost. The path cost is adjusted to a higher or lower value, and is used to forward traffic when a path being rerouted. The path cost has a value of 1 to 200000000. If the path cost method is short, the LAG cost default value is 4. If the path cost method is long, the LAG cost default value is 20000.

Default Path Cost — When selected, the LAG path cost returns to its default value.

Priority (0-240, in steps of 16) — The priority value of the LAG. The priority value influences the LAG choice when a bridge has two looped ports. The priority value is between 0-240, in increments of 16.

Designated Bridge ID — The bridge priority and the MAC Address of the designated bridge.

Designated Port ID — The port priority and interface number of the designated port.

Designated Cost — The cost of the designated bridge.

Forward Transitions — The number of times the **LAG State** has changed from the **Blocking** state to a **Forwarding** state.

Modifying the LAG STP Parameters

- 1 Open the **STP LAG Settings** page.
- 2 Select a LAG from the **Select a LAG** drop-down menu.
- 3 Modify the fields as desired.
- 4 Click **Apply Changes**.

The STP LAG parameters are modified, and the device is updated.

Defining STP LAG Settings Using CLI Commands

The following table summarizes the equivalent CLI commands for defining STP LAG settings.

Table 1-15. STP LAG Settings CLI Commands

CLI Command	Description
spanning-tree	Enables spanning tree.
spanning-tree disable	Disables spanning tree on a specific LAG.
spanning-tree cost <i>cost</i>	Configures the spanning tree cost contribution of a LAG.
spanning-tree port-priority <i>priority</i>	Configures port priority.

Table 1-15. STP LAG Settings CLI Commands

CLI Command	Description
<code>spanning-tree guard root</code>	Enables root guard on all the spanning tree instances on that interface.
<code>show spanning-tree [ethernet <i>interface</i> port-channel <i>port-channel-number</i>]</code>	Displays spanning tree configuration.
<code>show spanning-tree [detail] [active blockedports]</code>	Displays detailed spanning tree information on active or blocked ports

The following is an example of the CLI commands:

```
console(config)# interface port-channel 1  
console(config-if)# spanning-tree port-priority 16
```

Configuring Multiple Spanning Tree

MSTP operation maps VLANs into STP instances. Multiple Spanning Tree provides differing load balancing scenario. For example, while port A is blocked in one STP instance, the same port is placed in the *Forwarding State* in another STP instance.

In addition, packets assigned to various VLANs are transmitted along different paths within Multiple Spanning Trees Regions (MST Regions). Regions are one or more Multiple Spanning Tree bridges by which frames can be transmitted. To open the MSTP Settings page, click **Switch** → **Spanning Tree** → **MSTP Settings** in the tree view.

Figure 1-33. MSTP Settings

The screenshot shows the Dell OpenManage Switch Administrator interface for version 10.6.5.49. The left navigation pane is expanded to 'Spanning Tree'. The main content area is titled 'MSTP Settings' and is divided into two sections: 'Global Settings' and 'Instance Settings'.

Global Settings

Region Name (1-32 Characters)	00:00:33:66:55:22
Revision (0-65535)	0
Max Hops (1-40)	20
IST Master	32768-00:00:33:66:55:22

Instance Settings

Instance ID	1
Included VLANs	
Bridge Priority (0-61440, in steps of 4096)	32768
Designated Root Bridge ID	32768-00:00:33:66:55:22
Root Port	0
Root Path Cost	0
Bridge ID	32768-00:00:33:66:55:22
Remaining Hops	

Region Name (1-32 Characters) — Indicates user-defined MSTP region name.

Revision (0-65535) — Defines unsigned 16-bit number that identifies the current MST configuration revision. The revision number is required as part of the MST configuration. The possible field range is 0-65535.

Max Hops (1-40) — Defines the total number of hops that occur in a specific region before the BPDU is discarded. Once the BPDU is discarded, the port information is aged out. The possible field range is 1-40. The field default is 20 hops.

IST Master — Indicates the Internal Spanning Tree Master ID. The IST Master is the specified instance root.

Instance ID — Defines the MSTP instance. The field range is 0-15.

Included VLANs — Maps the selected VLANs to the selected instance. Each VLAN belongs to one instance.

Bridge Priority (0-61440) — Specifies the selected spanning tree instance device priority. The field range is 0-61440

Designated Root Bridge ID — Indicates the ID of the bridge with the lowest path cost to the instance ID.

Root Port — Indicates the selected instance's root port.

Root Path Cost — Indicates the selected instance's path cost.

Bridge ID — Indicates the bridge ID of the selected instance.

Remaining Hops — Indicates the number of hops remaining to the next destination.

Displaying the MSTP Instance Table

- 1 Open the MSTP Settings page.
- 2 Click Show All to open the MSTP Instance Table.

Figure 1-34. MSTP Instance Table

MSTP VLAN to Instance Mapping Table

Refresh

	VLAN	Instance ID (0-15)
1	VLAN 1	0
2	VLAN 2	0

Defining MST Instances Using CLI Commands

The following table summarizes the equivalent CLI commands for defining MST instance groups as displayed in the MSTP Settings page.

Table 1-16. MSTP Instances CLI Commands


CLI Command	Description
<code>spanning-tree mst configuration</code>	Enters MST Configuration mode.
<code>instance instance-id {add remove} vlan vlan-range</code>	Maps VLANs to the MST instance
<code>name string</code>	Sets the configuration name.
<code>revision value</code>	Sets the configuration revision number
<code>spanning-tree mst instance-id port-priority priority</code>	Sets the priority of a port.
<code>spanning-tree mst instance-id priority priority</code>	Sets the device priority for the specified spanning tree instance.
<code>spanning-tree mst max-hops hop-count</code>	Sets the number of hops in an MST region before the BPDU is discarded and the information held for a port is aged.
<code>spanning-tree mst instance-id cost cost</code>	Sets the path cost of the port for MST calculations
<code>exit</code>	Exits the MST region configuration mode and applies configuration changes

Table 1-16. MSTP Instances CLI Commands

CLI Command	Description
abort	Exits the MSTP region configuration mode without applying configuration changes.
show {current pending}	Displays the current or pending MSTP region configuration.

Defining MSTP Interface Settings

The MSTP Interface Settings page contains parameters assigning MSTP settings to specific interfaces. To open the MSTP Interface Settings page, click **Switch** → **Spanning Tree** → **MSTP Interface Settings** in the tree view.

Figure 1-35. MSTP Interface Settings

Instance ID — Defines the VLAN group to which the interface is assigned. Possible field range is 0-15.

Interface — Assigns either ports or LAGs to the selected MSTP instance.

Port State — Indicates whether the port is enabled or disabled in the specific instance.

Type — Indicates whether MSTP treats the port as a point-to-point port, or a port connected to a hub, and whether the port is internal to the MSTP region or a boundary port. If the port is a boundary port, it also indicates whether the device on the other side of the link is working in RSTP or STP mode.

Role — Indicates the port role assigned by the STP algorithm in order to provide to STP paths. The possible field values are:

Root — Provides the lowest cost path to forward packets to root device.

Designated — Indicates the port or LAG via which the designated device is attached to the LAN.

Alternate — Provides an alternate path to the root device from the root interface.

Backup — Provides a backup path to the designated port path toward the Spanning Tree leaves. Backup ports occur only when two ports are connected in a loop by a point-to-point link. Backup ports also occur when a LAN has two or more connections connected to a shared segment.

Disabled — Indicates the port is not participating in the Spanning Tree.

Interface Priority (0-240,in steps of 16) — Defines the interface priority for specified instance. The default value is 128.

Path Cost — Indicates the port contribution to the Spanning Tree instance root path cost. If the Long path cost method was specified in the page, the field value range is 1-200,000,000. If the Short path cost method was specified, the field value range is 1-65,535.

Default Path Cost — If the Long path cost method was specified in the page, the default path cost values are:

Ethernet (10 Mbps) - 2,000,000

Fast Ethernet (100 Mbps) - 200,000

Gigabit Ethernet (1000 Mbps) - 20,000

Port-Channel - 20,000

If the Short path cost method was specified, the default path cost values are:

Ethernet (10 Mbps) - 100

Fast Ethernet (100 Mbps) - 19

Gigabit Ethernet (1000 Mbps) - 4

Port-Channel - 4

Root — Provides the lowest cost path to forward packets to the root device.

Designated Bridge ID — The bridge ID number that connects the link or shared LAN to the root.

Designated Port ID — The Port ID Number on the designated bridge that connects the link or the shared LAN to the root.

Designated Cost — Cost of the path from the link or the shared LAN to the root.

Forward Transitions — Number of times the port changed to the forwarding state.

Remain Hops — Indicates the number of hops remaining to the next destination.

Viewing the MSTP Interface Table

- 1 Open the **MSTP Interface Settings** page.
- 2 Click **Show All**.

The MSTP Interface Table page opens:

Figure 1-36. MSTP Interface Table

MSTP Interface Table Refresh

Instance ID

Interface	State	Role	Type	Interface Priority	Path Cost	Default Path Cost	Designated Bridge ID	Designated Port ID	Designated Cost
1			Boundary	<input type="text"/>	<input type="text"/>	<input type="checkbox"/>			

Apply Changes


Configuring QinQ

This section contains information for configuring Customer VLANs using the Web Interface and using the CLI. QinQ tagging allows network managers to add an additional tag to previously tagged packets. Customer VLANs are configured using QinQ. Adding additional tags to the packets helps create more VLAN space. The added tag provides VLAN ID to each customer, this ensures private and segregated network traffic. The VLAN ID tag is assigned to a customer port in the service providers network. The designated port then provides additional services to the packets with the double-tags. This allows administrators to expand service to VLAN users. To configure customer VLANs:

To configure customer VLANs:

- 1 Click Switch > VLAN > VLAN Membership. The VLAN Membership page opens.

Figure 1-37. VLAN Membership



- 2 Click **Add**. The Create New VLAN page opens:

Figure 1-38. Create New VLAN

- 3 Define the **VLAN ID** and **VLAN Name** field.
- 4 Click **Apply Changes**.
- 5 Click **Switch > VLAN > Port Settings**. The **Port Settings** page opens.

Figure 1-39. Port Settings

- 6 Select the port.
- 7 Set the *Port VLAN Mode* field to *Customer*.
- 8 Define the remaining fields.
- 9 Click **Apply Changes**. The VLAN Port settings are saved, and the device is updated.
- 10 Click **Show All**. The *VLAN Port Table* opens.

Figure 1-40. VLAN Port Table

VLAN Port Table

Port	Port VLAN Mode	PVID	Frame Type	Ingress Filtering	Current Reserved VLAN	Reserve VLAN for Internal Use
1 g1	Customer	1	Admit All	Enable		
2 g2	Access	1	Admit All	Enable		
3 g3	Trunk	1	Admit All	Enable		
4 g4	Customer	1	Admit All	Enable		

- 11 Select the Port VLAN Mode.
- 12 Click **Apply Changes**. The customer VLAN is defined, and the device is updated.

VLAN Port Settings Using CLI Commands

The following table summarizes the equivalent CLI commands for viewing fields displayed in the **VLAN Port Settings** page.

Table 1-17. QinQ CLI Commands

CLI Command
Console>enable
Console#config
Console (config)#
Console (config)# vlan database
Console (config-vlan)# vlan 100
Console (config-vlan)# exit
Console (config)# interface ethernet e5
Console (config-if)# switchport mode customer
Console (config-if)# switchport customer vlan 100
Console (config-if)# exit
Console (config)# interface ethernet e10
Console (config-if)# switchport mode trunk
Console (config-if)# switchport trunk allowed vlan add 100
Console (config-if)# exit

The following is an example of the QinQ show commands.

```

Console# show interfaces switchport ethernet 1/e5
Port: 1/e5
Port Mode: Customer
Gvrp Status: disabled
Ingress Filtering: true
Acceptable Frame Type: admitAll
Ingress Untagged VLAN ( NATIVE ): 100
Protected: Disabled

```

Port is member in:

Vlan	Name	Egress	Port
n		rule	Membership
			Type
---	-----	-----	-----
-	-----	---	-----
100	100	Untagged	Static

Forbidden VLANS:

Vlan	Name
----	-----

Classification rules:

Protocol based VLANs:

Group ID	Vlan ID
-----	-----

Mac based VLANs:

```
Group ID      Vlan ID
-----
```

Subnet based VLANs:

```
Group ID      Vlan ID
-----
```

console#

Configuring Load Balancing

Load Balancing enables the even distribution of data and/or processing packets across available network resources. For example, load balancing may distribute the incoming packets evenly to all servers, or redirect the packets to the next available server. Load Balancing is configured on the **LAG Configuration** page.

NOTE: LAGs can be configured according to the following load balancing types: Layer 2 or Layer 2 and Layer 3 or Layer 2, Layer 3 and Layer 4.


The **LAG Configuration** page contains fields for configuring parameters for configured LAGs. The device supports up to eight ports per LAG, and eight LAGs per system.

For information about Link **Aggregated Groups** and assigning ports to LAGs, refer to **Aggregating Ports** in the *Dell PowerConnect 5324 User Guide*.

To open the **LAG Configuration** page, click **Switch**→**Ports**→**LAG Configuration** in the tree view.

NOTE: If port configuration is modified while the port is a LAG member, the configuration change is only effective after the port is removed from the LAG.

Figure 1-41. LAG Configuration



The **LAG Configuration** page contains the following fields:

Load Balance — Indicates the load balancing type enabled on the LAG. The possible field values are:

Layer 2 — Enables load balancing based on static and dynamic MAC addresses.

Layer 2-3 — Enables load balancing based on static and dynamic MAC addresses, and source and destination IP addresses.

Layer 2-3-4 — Enables load balancing based on static and dynamic MAC addresses, source and destination IP addresses, and Source and Destination UDP/TCP ports.

LAG — The LAG number.

Description (0-64 Characters) — Provides a user-defined description of the configured LAG.

LAG Type — The port types that comprise the LAG.

Admin Status — Enables or disables traffic forwarding through the selected LAG.

Current LAG Status — Indicates if the LAG is currently operating.

Re-Activate Suspended LAG — Reactivates a suspended LAG.

Operational Status — Operational status of the LAG.

Admin Auto Negotiation — Enables or disables Auto Negotiation on the LAG. Auto-negotiation is a protocol between two link partners that enables a LAG to advertise its transmission rate, duplex mode and flow control (the flow control default is disabled) abilities to its partner.

Current Auto Negotiation — The currently configured Auto Negotiation setting.

Admin Speed — The speed at which the LAG is operating.

Current LAG Speed — The currently configured speed at which the LAG is operating.

Admin Back Pressure — Enables or disables Back Pressure mode on the LAG. Back Pressure mode is effective on the ports operating in Half Duplex in the LAG.

Current Back Pressure — The currently configured Back Pressure setting.

Admin Flow Control — Enables/disables flow control, or enables the auto negotiation of flow control on the LAG. Flow Control mode is effective on the ports operating in Full Duplex in the LAG.

Current Flow Control — The user-designated flow control setting.

Defining LAG Parameters

- 1 Open the **LAG Configuration** page.
- 2 Select a LAG in the **LAG** field.
- 3 Define the fields.
- 4 Click **Apply Changes**.

The LAG parameters are saved to the device.

Modifying LAG Parameters

- 1 Open the **LAG Configuration** page.
- 2 Select a LAG in the **LAG** field.
- 3 Modify the fields.

4 Click Apply Changes.

The LAG parameters are saved to the device.

Displaying the LAG Configuration Table:

- 1 Open the LAG Configuration page.
- 2 Click Show All.

The LAG Configuration Table opens:

Figure 1-42. LAG Configuration Table
LAG Configuration Table

LAG	Description	LAG Type	LAG Status	LAG Speed	Auto Negotiation	Back Pressure	Flow Control
1	1		Up		Enable	Disable	Disable
2	2		Up		Enable	Disable	Disable
3	3		Up		Enable	Disable	Disable
4	4		Up		Enable	Disable	Disable
5	5		Up		Enable	Disable	Disable
6	6		Up		Enable	Disable	Disable
7	7		Up		Enable	Disable	Disable
8	8		Up		Enable	Disable	Disable

Configuring LAGs with CLI Commands

The following table summarizes the equivalent CLI commands for configuring LAGs as displayed in the LAG Configuration page.

Table 1-18. LAG Configuration CLI Commands

CLI Command	Description
interface port-channel <i>port-channel-number</i>	Enters the interface configuration mode of a specific port-channel.
port-channel load-balance { <i>layer-2 /layer 2-3 /layer 2-3-4</i> }	Configures the load balancing policy of the port channeling.

Table 1-18. LAG Configuration CLI Commands

CLI Command	Description
description <i>string</i>	Adds a description to an interface configuration.
shutdown	Disables interfaces that are part of the currently set context.
speed <i>bps</i>	Configures the speed of a given ethernet interface when not using auto negotiation.
autobaud	Sets the line for automatic baud rate detection.
negotiation	Enables auto negotiation operation for the speed and duplex parameters of a given interface.
back-pressure	Enables Back Pressure on a given interface
flowcontrol { auto on off rx tx }	Configures the Flow Control on a given interface.
show interfaces configuration [ethernet <i>interface</i> port-channel <i>port-channel-number</i>]	Displays the configuration for all configured interfaces.
show interfaces status [ethernet <i>interface</i> port-channel <i>port-channel-number</i>]	Displays the status for all configured interfaces.
show interfaces description [ethernet <i>interface</i> port-channel <i>port-channel-number</i>]	Displays the description for all configured interfaces.
show interfaces port-channel [<i>port-channel-number</i>]	Displays Port-channel information (which ports are members of that port-channel, and whether they are currently active or not).

The following is an example of the CLI commands:

```
console(config-if)# channel-group 1 mode on
console(config-if)# exit
console(config)# interface range e g21-24
console(config-if)# channel-group 1 mode on
console(config-if)# ex
console(config)# interface ethernet g5
console(config-if)# channel-group 2 mode on
console(config-if)# exit
console(config)# exit

console# show interfaces port-channel
Channel          Ports
-----
ch1              Inactive: g(21-24)
ch2              Active: g5
ch3
ch4
ch5
ch6
ch7
ch8
console#
```