FUJ!FILM

YF07797-121

1 **E**N

DIGITAL CAMERA

FINEPIX S2500HD/S2700HD Series S1800/S1900 Series

S1600/S1700 Series

Owner's Manual

Thank you for your purchase of this product. This manual describes how to use your FUJIFILM FinePix S2500HD/S2700HD-series, S1800/S1900-series, or S1600/S1700-series digital camera and the supplied software. Be sure that you have read and understood its contents before using the camera.



For information on related products, visit our website at http://www.fuiifilm.com/products/index.html













Before You Begin

First Steps

Basic Photography and Playback

More on Photography

More on Playback

Movies

Connections

Menus

Technical Notes

Troubleshooting

Appendix

IMPORTANT SAFETY INSTRUCTIONS

- · Read Instructions: All the safety and operating instructions should be read before the appliance is operated.
- · Retain Instructions: The safety and operating instructions should be retained for future reference
- · Heed Warnings: All warnings on the appliance and in the operating instructions should be adhered to
- Follow Instructions: All operating and use instructions should be followed.

Installation

Power Sources: This video product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supply to your home, consult your appliance dealer or local power company. For video products intended to operate from battery power, or other sources, refer to the operating instructions.

Grounding or Polarization: This video product is equipped with a polarized alternating-current line plug (a plug having one blade wider than the other). This plug will fit into the power outlet only one way. This is a safety feature. If you are unable to insert the plua fully into the outlet. try reversing the plug. If the plug should still fail to fit, contact your electrician to replace your obsolete outlet. Do not defeat the safety purpose of the polarized plug.

Alternate Warnings: This video product is equipped with a three-wire grounding-type plug, a plug having a third (grounding) pin. This plug will only fit into a grounding-type power outlet. This is a safety feature. If you are unable to insert the plug into the outlet, contact your electrician to replace your obsolete outlet. Do not defeat the safety purpose of the grounding type plug.

Overloading: Do not overload wall outlets and extension cords as this can result in a risk of fire or electric shock.

Ventilation: Slots and openings in the cabinet are provided for ventilation, to ensure reliable operation of the video product and to protect it from overheating, and these openered. The openings should never be blocked by placing the video product on a bed, sofa, rug, or other similar surface.

This video product should not be placed in a built-in installation such as a bookcase or rack unless proper ventilation is provided or the manufacturer's instructions have been adhered to. This video product should never be placed near or over a radiator or heat register.

Attachments: Do not use attachments not recommended by the video product manufacturer as they may cause hazards

Water and Moisture: Do not use this video product near water-for example, near a bath tub, wash bowl, kitchen sink, or laundry tub, in a wet basement, or near a swimming pool, and the like

Power-Cord Protection: Power-supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them, paying particular attention to cords at plugs, convenience receptacles, and the point where they exit from the appliance.

Accessories: Do not place this video product on an unstable cart, stand, tripod, bracket, or table. The video product may fall, causing serious iniury to a child or adult, and serious ings must not be blocked or cov-damage to the appliance. Use only with a cart, stand, tripod, bracket, or table recommended by the manufacturer, or sold with the video product. Any mounting of the appliance should follow the manufacturer's instructions. and should use a mounting accessory recommended by the manufacturer.


> An appliance and cart combination should be moved with care. Quick stops, excessive force, and uneven surfaces mav

cause the appliance and cart combination to overturn.

Antennas

Outdoor Antenna Grounding: If an outside antenna or cable system is connected to the video product, be sure the antenna or cable system is grounded so as to provide some protection against voltage surges and built-up static charges. Section 810 of the National Flectrical Code, ANSI/ NFPA No. 70, provides information with respect to proper grounding of the mast and supporting structure, grounding of the lead-in wire to an antenna discharge unit, size of grounding conductors, location of antenna discharge unit, connection to grounding electrodes, and requirements for the grounding electrode.

EXAMPLE OF ANTENNA GROUNDING AS PER NATIONAL ELECTRICAL CODE



Power Service Groundina Conductors Electrode System (NEC) (NFC SECTION ART 250, PART H) 810-21)

Power Lines: An outside antenna system should not be located in the vicinity of overhead power lines or other electric light or power circuits, or where it can fall into such power and refer servicing to qualified serlines or circuits. When installing an outside antenna system, extreme conditions: care should be taken to keep from • When the power-supply cord or touching such power lines or circuits as contact with them might be fatal. • If liquid has been spilled, or objects

Use

Cleaning: Unplug this video product from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning.

Object and Liquid Entry: Never push objects of any kind into this video product through openings as they may touch dangerous voltage points or short out parts that could result in a fire or electric shock. Never spill liquid of any kind on the video product.

Lightning: For added protection for this video product receiver during a lightning storm, or when it is left unattended and unused for long periods of time, unplug it from the wall outlet and disconnect the antenna or cable system. This will prevent damage to the video product due to lightning and power-line surges.

Service

Servicing: Do not attempt to service this video product yourself as opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel.

Damage Requiring Service: Unplug this video product from the wall outlet

vice personnel under the following

- plug is damaged.
- have fallen into the video product.
- · If the video product has been exposed to rain or water.
- · If the video product has been dropped or the cabinet has been damaged.

If the video product does not operate normally follow the operating instructions. Adjust only those controls that are covered by the operating instructions as an improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the video product to its normal operation.

When the video product exhibits a distinct change in performancethis indicates a need for service.

Replacement Parts: When replacement parts are required, be sure the service technician has used replacement parts specified by the manufacturer or have the same characteristics as the original part. Unauthorized substitutions may result in fire, electric shock or other hazards

Safety Check: Upon completion of any service or repairs to this video product, ask the service technician to perform safety checks to determine that the video product is in proper operating condition.

Be sure to read these notes before use

Safety Notes

 Make sure that you use your camera correctly. Read these safety notes and your Owner's Manual carefully before use. · After reading these safety notes, store them in a safe place.

About the Icons

The icons shown below are used in this document to indicate the severity of the injury or damage that can result if the information indicated by the icon is ignored and the product is used incorrectly as a result.



This icon indicates that death or serious injury can result if the information is ianored.



This icon indicates that personal injury or material damage can result if the information is ignored

The icons shown below are used to indicate the nature of the instructions which are to be observed.



Triangular icons tell you that this information requires attention ("Impor-



Circular icons with a diagonal bar tell you that the action indicated is prohibited ("Prohibited").



Filled circles with an exclamation mark indicate an action that must be performed ("Required").

WARNING



If a problem arises, turn the camera off, remove the batteries, and disconnect and unplug the AC power adapter. Continued use of the camera when it is emitting smoke. is emitting any unusual odor, or is in any other abnormal state can cause a fire or electric shock. Contact your FUJIFILM dealer. power socket



Do not allow water or foreign objects to enter the camera. If water or foreign objects get inside the camera, turn the camera off, remove the batteries, and disconnect and unplug the AC power adapter. Continued use of the camera can cause a fire or electric shock. Contact your FUJIFILM dealer.

/ WARNING



Do not use the camera in the bathroom or shower. This can cause a fire or electric shock



Never attempt to change or take apart the camera. (Never open the casing.) Do not use the camera when it has been dropped or the casing is damaged. This can cause a fire or electric shock. Contact your FUJIFILM dealer.



Do not change, head or unduly twist or pull the connection cord and do not place heavy objects on the connection cord. These actions could damage the cord and cause a fire or electric shock. If the cord is damaged, contact your FUJIFILM dealer.



Do not place the camera on an unstable surface. This can cause the camera to fall or tip over and cause injury.



<u>Never attempt to take pictures while in motion</u>. Do not use the camera while you are walking or driving a vehicle. This can result in you falling down or being involved in a traffic accident



Do not touch any metal parts of the camera during a thunderstorm. This can cause an electric shock due to induced current from the lightning discharge.



<u>**Do not use the batteries except as specified.**</u> Load the batteries as shown by the indicator



<u>Do not heat, change or take apart the batteries. Do not drop or subject the batteries to impacts. Do not store the batteries with metallic products.</u> Any of these actions can cause the batteries to burst or leak and cause fire or injury as a result.



Use only the batteries or AC power adapters specified for use with this camera. Do not use voltages other than the power supply voltage shown. The use of other power sources



If the batteries leak and fluid gets in contact with your eyes, skin or clothing, flush the affected area with clean water and seek medical attention or call an emergency number right away.



When carrying the batteries, install them in a digital camera or keep them in the hard case. When storing the batteries, keep them in the hard case. When discarding, cover the battery terminals with insulation tape. Contact with other metallic objects or batteries could cause the batteries to ignite or burst.



<u>Keep memory cards out of the reach of small children.</u> Because memory cards are small, they can be swallowed by children. Be sure to store memory cards out of the reach of small children. If a child swallows a memory card, seek medical attention or call an emergency number.

CAUTION



Do not use this camera in locations affected by oil fumes, steam, humidity or dust. This can cause a fire or electric shock.



Do not leave this camera in places subject to extremely high temperatures. Do not leave the camera in locations such as a sealed vehicle or in direct sunlight. This can cause a fire.



<u>Keep out of the reach of small children.</u> This product could cause injury in the hands of a child.



Do not place heavy objects on the camera. This can cause the heavy object to tip over or fall and cause injury.



Do not move the camera while the AC power adapter is still connected. Do not pull on the connection cord to disconnect the AC power adapter. This can damage the power cord or cables and cause a fire or electric shorth.



Do not cover or wrap the camera or the AC power adapter in a cloth or blanket. This can cause heat to build up and distort the casing or cause a fire.



When you are cleaning the camera or you do not plan to use the camera for an extended period.remove the batteries and disconnect and unplug the AC power adapter. Failure to do so can cause a fire or electric shock.



When charging ends, unplug the charger from the power socket. Leaving the charger plugged into the power socket can cause a fire.



Using a flash too close to a person's eyes may temporarily affect the eyesight. Take particular care when photographing infants and young children.



When a memory card is removed, the card could come out of the slot too quickly. Use your finaer to hold it and aently release the card.



<u>Request regular internal testing and cleaning for your camera</u>. Build-up of dust in your camera can cause a fire or electric shock. Contact your FUJIFILM dealer to request internal cleaning every two years. Please note that this service is not free of charge.

Using Batteries

The following describes the proper use of batteries and how to prolong their life. Incorrect use can shorten battery life or cause leakage, overheating, fire, or explosion.

Compatible Batteries

The camera takes AA alkaline, rechargeable Ni-MH (nickel-metal hydride), or UL-certified lithium batteries. Do not use manganese, nickel-cadmium (Ni-Cd), or non-UL certified lithium batteries, as the heat generated by these batteries could damage the camera or cause malfunction.

Battery capacity varies with make and storage conditions. Some commercially-available batteries may have less capacity than the batteries provided with the camera.

Cautions: Handling Batteries

 Do not use batteries that are leaking. deformed, or discolored. Warning: If the batteries leak, clean the battery compartment thoroughly before inserting new batteries. If fluid from the battery comes into contact with skin or clothing, flush the affected area with water. Iffluid enters your eves,

immediately flush the affected area with water and seek medical attention. Do not rub your eyes. Failure to observe this precaution could result in loss of eyesight.

- · Do not transport or store with metal objects such as necklaces or hairpins.
- Do not disassemble or modify the batteries or battery casing.
- · Do not expose to strong physical shocks.
- · Do not expose to water, flame, or heat, or store in warm or humid conditions
- · Keep out of reach of infants and small children
- Insert in the correct orientation.
- Do not mix old and new batteries. batteries with different charge levels, or batteries of different types.
- · If the camera will not be used for an extended period, remove the batteries. Note that the camera clock will be reset (pg. 14).
- · The batteries may be warm to the touch immediately after use. Turn

the camera off and allow the batteries to cool before handling.

- Battery capacity tends to decrease at low temperatures. Keep spare batteries in a pocket or other warm place and exchange as necessary. Cold batteries may recover some of their charge when warmed.
- · Fingerprints and other foreign matter on the battery terminals can reduce battery performance. Thoroughly clean the terminals with a soft, dry cloth before inserting the batteries in the camera.

Ni-MH Batteries

The capacity of Ni-MH batteries may be temporarily reduced when new, after long periods of disuse, or if they are repeatedly recharged before being fully discharged. This is normal and does not indicate a malfunction. Capacity can be increased by repeatedly discharging the batteries using the **DISCHARGE** option in the camera setup menu (pg. 100) and recharging them using a battery charger (sold separately). Do not use this option with alkaline batteries.

The camera draws a small amount of • Do not use with other devices current even when off. Ni-MH batteries that have been left in the camera. for an extended period may be drawn down to the point that they no longer hold a charge. Battery performance may also drop if the batteries are run • The adapter may hum or become hot to down in a device such as a flashlight. Use the DISCHARGE option in the • If the adapter causes radio intercamera setup menu to discharge Ni-MH batteries. Batteries that no lon-

ger hold a charge even after repeatedly being discharged and recharged have reached the end of their service life and must be replaced.

Ni-MH batteries can be recharged in a battery charger (sold separately). Batteries may become warm to the touch after charging. Refer to the instructions provided with the charger for more information. Use the charger with compatible batteries only.

Ni-MH batteries gradually lose their charge when not in use.

Disposal

Dispose of used batteries in accord with local regulations.

AC Power Adapters (Available Separately) Use only FUJIFILM AC power adapt-

ers designated for use with this camera. Other adapters could damage the camera

- The adapter is for indoor use only.
- · Be sure the DC plug is securely connected to the camera.
- · Turn the camera off before disconnecting the adapter. Disconnect the adapter by the plug, not the cable.
- Do not disassemble.
- · Do not expose to high heat and humidity.
- · Do not subject to strong physical shocks
- the touch during use. This is normal.
- ference, reorient or relocate the receiving antenna.

Using the Camera

To ensure that images are recorded correctly, do not subject the camera to impact or physical shocks while images are being recorded.

Electrical Interference

This camera may interfere with hospital or aviation equipment. Consult with hospital or airline staff before using the camera in a hospital or on an aircraft.

Liquid Crystal

In the event that the monitor or electronic viewfinder is damaged, care should be taken to avoid contact with liquid crystal. Take the urgent action indicated should any of the following situations arise:

- · If liquid crystal comes in contact with your skin, clean the area with a cloth and then wash thoroughly with soap and running water.
- If liquid crystal enters your eyes, flush the affected eye with clean water for at least 15 minutes and then seek medical assistance
- · If liquid crystal is swallowed, rinse your mouth thoroughly with water. Drink large quantities of water and induce vomiting, then seek medical assistance

Take Test Shots

Before taking photographs on important occasions (such as at weddings or before taking the camera on a trip). take a test shot and view the result to ensure that the camera is functioning normally. FUJIFILM Corporation can not accept liability for damages or lost profits incurred as a result of product malfunction.

NOTICES

To prevent fire or shock hazard, do not expose the unit to rain or moisture.

Please read the "Safety Notes" (pages iii–v) and make sure you understand them before using the camera.

Perchlorate Material—special handling may apply. See http://www.dtsc.ca.gov/hazardouswaste/perchlorate.

For Customers in the U.S.A.

Tested To Comply With FCC Standards FOR HOME OR OFFICE USE

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

CAUTION

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- · Reorient or relocate the receiving antenna.
- · Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
 You are cautioned that any changes or modifications not expressly approved in this manual could void the user's authority to operate the equipment.

Notes on the Grant

To comply with Part 15 of the FCC Rules, this product must be used with a FUJIFILM-specified ferrite-core A/V cable, USB cable, and DC supply cord.

For Customers in Canada

CAUTION: This Class B digital apparatus complies with Canadian ICES-003.

EC Declaration of Conformity

We

Name: FUJIFILM Electronic Imaging Europe GmbH

Address: Benzstrasse 2 47533 Kleve, Germany

declare that the product

Product Name: FUJIFILM DIGITAL CAMERA FinePix S2500HD/

S2700HD series, S1800/S1900 series, S1600/S1700

series

Manufacturer's Name: FUJIFILM Corporation

Manufacturer's Address: 7-3, AKASAKA 9-CHOME, MINATO-KU,

TOKYO 107-0052 JAPAN

conforms to the following Standards:

Safety: EN60950-1: 2006

EMC: EN55022: 2006 Class B

EN55024: 1998 + A1: 2001 + A2: 2003

EN61000-3-2: 2006

EN61000-3-3: 1995 + A1: 2001 + A2: 2005

C. Breus

following the provision of the EMC Directive (2004/108/EC) and Low Voltage Directive (2006/95/EC).

((

Place

Kleve. Germanv December 1, 2009

Date Signature, Managing Director

Disposal of Electrical and Electronic Equipment in Private Households

Disposal of Used Electrical and Electronic Equipment (Applicable in the European Union, Norway, Iceland and Liechtenstein)



This symbol on the product, or in the manual and in the warranty, and/or on its packaging indicates that this product shall not be treated as household waste.

Instead it should be taken to an applicable collection point for the recycling of electrical and electronic equipment.

By ensuring this product is disposed of correctly, you will help prevent potential negative consequences to the environment and human health, which could otherwise be caused by inappropriate waste handling of this product.



This symbol on the batteries or accumulators indicates that those batteries shall not be treated as household waste.

If your equipment contains easy removable batteries or accumulators please dispose these separately according to your local requirements.

The recycling of materials will help to conserve natural resources. For more detailed information about recycling this product, please contact your local city office, your household waste disposal service or the shop where you purchased the product.

In Countries Outside the European Union, Norway, Iceland and Liechtenstein

If you wish to discard this product, including the batteries or accumulators, please contact your local authorities and ask for the correct way of disposal.

Notes on Copyright

Unless intended solely for personal use, images recorded using your digital camera system cannot be used in ways that infringe copyright laws without the consent of the owner. Note that some restrictions apply to the photographing of stage performances, entertainments, and exhibits, even when intended purely for personal use. Users are also asked to note that the transfer of memory cards containing images or data protected under copyright laws is only permissible within the restrictions imposed by those copyright laws.

Trademark Information

Macintosh, Power Macintosh, Power Mac, PowerBook, QuickTime, and Mac OS are trademarks of Apple Inc. in the U.S.A. and other countries. Microsoft, Windows, the Windows logo, Windows Vista logo are trademarks or registered trademarks of Microsoft Corporation in the United States and/or other countries. "Windows" is an abbreviation used in reference to the Microsoft Windows operating system. Adobe and Adobe Reader are either trademarks or registered trademarks of Adobe Systems Incorporated in the U.S.A. and/or other countries. HDMI, the HDMI logo, and High-Definition Multimedia Interface are either trademarks or registered trademarks of HDMI Licensing, LLC. The SDHC logo is a trademark.

Note: The "Designed for Microsoft® Windows® XP" and "CERTIFIED FOR Windows Vista™" logos apply only to the camera and camera hardware driver.

About This Manual

Before using the camera, read this manual and the warnings on pages ii–vii. For information on specific topics, consult the sources below.

✓ Camera Q & Apg. ix Know what you want to do but don't know the name for it? Find the answer in "Camera Q & A."

✓ Warning Messages and Displayspg. 111
Find out what's behind that flashing icon or error message in the display.

✓ Restrictions on Camera Settings......Basic Manual
See the Basic Manual for restrictions on the options available in each shooting mode.

Memory Cards

Pictures can be stored in the camera's internal memory or on optional SD and SDHC memory cards. In this manual, SD memory cards are referred to as "memory cards." For more information, see page 10.

Camera Q & A

Find items by task.

Camera Setup

Question	Key phrase	See page
How do I set the camera clock?	Date and time	14
Can I set the clock to local time when I travel?	Time difference	99
How do I keep the display from turning off automatically?	Auto power off	98
How do I make the display brighter or darker?	LCD brightness	97
How do I stop the camera beging and clicking?	Operation and shutter volume	94
How do I stop the camera beeping and clicking?	Silent mode	18
What are the parts of the camera called?	Parts of the camera	2
What do the icons in the display mean?	Displays	4
How do I use the menus?	Menus	69
What's behind that flashing icon or error message?	Messages and displays	111
How much charge is left in the battery?	Battery level	15
Can I increase the capacity of rechargeable Ni-MH batteries?	Discharge	100

Sharing Pictures

Question	Key phrase	See page
Can I print pictures on my home printer?	Printing pictures	57
Can I copy my pictures to my computer?	Viewing pictures on a computer	63

Taking Pictures

Question	Key phrase	See page
How many pictures can I take?	Memory capacity	116
Is there a quick and easy way to take snapshots?	node 🗅	15
How can I avoid blurred pictures?	Dual IS mode	17
How can I make good portraits?	Intelligent Face Detection	21
Can the camera automatically adjust settings for different scenes?	SRAUTO mode	35
Can I choose my own settings for different scenes?	Scene position	35
How can I be sure my subject is smiling when I take a photograph?	Smile detection	37
How can I be sure that nobody blinked when the photo was taken?	Blink detection	23
How do I shoot close-ups?	Macro mode (close-ups)	26
How do I keep the flash from firing?		
How do I stop my subjects' eyes glowing red when I use the flash?	Flash mode	27
How do I "fill-in" shadows on back-lit subjects?		
How do I take a series of pictures in a single burst?	Continuous Shooting mode	29
How do I take a group portrait that includes the photographer?	Self-timer mode	75
How do I shoot a panorama?	PANORAMA mode	39
How do I turn off the lamp on the front of the camera?	AF-assist illuminator	25
How do I frame pictures with the subject off to one side?	Focus lock	24
Can I choose shutter speed and aperture?	P, S, A, and M modes	40
Can I save and recall camera settings?	C mode	45
How do I adjust exposure?	Exposure compensation	33
How do I shoot movies?	Recording movies	52
How do I frame pictures in the viewfinder?	EVF/LCD button	5

Viewing Pictures

Question	Key phrase	See page
How do I view my pictures?	Single-frame playback	46
How do I delete the current picture?	The 🖆 button	20
Can I select other pictures for deletion?	Deleting pictures	50
Can I zoom in on pictures during playback?	Playback zoom	47
How do I view a lot of pictures at once?	Multi-frame playback	49
How do I view all pictures taken on the same day?	Sort by date	49
Can I protect my pictures from accidental deletion?	Protect	86
Can I hide the icons in the display when viewing my pictures?	Choosing a display format	46
Can I view my pictures in a slide show?	Slide show	82
Can I add a short voice memo to my pictures?	Voice memo	89
Can I crop unwanted elements out of my pictures?	Crop (trimming)	91
Can I make small copies of my pictures?	Resize	92
Can I copy pictures from internal memory to a memory card?	Сору	87
How do I view my pictures on TV?	Viewing pictures on TV	55

Table of Contents

For Your Safety ii IMPORTANT SAFETY INSTRUCTIONS ii Safety Notes iii NOTICES vi
About This Manualviii
Camera Q & Aix
Before You Begin
Introduction1
Symbols and Conventions1
Supplied Accessories1
Parts of the Camera2
Camera Displays4
The Mode Dial6
First Steps
The Strap and Lens Cap7
Inserting the Batteries8
Inserting a Memory Card10
Turning the Camera on and Off13
Shooting Mode13
Playback Mode13
Basic Setup14

Basic Photography and Playback	
Taking Pictures in 🗖 (Auto) Mode	15
Viewing Pictures	20
More on Photography	
5 . <i>V</i>	
Intelligent Face Detection and Red-Eye Removal	21
Blink Detection	23
Focus Lock	24
Macro and Super Macro Modes (Close-ups)	26
4 Using the Flash (Intelligent Flash)	27
💁 Continuous Shooting (Burst Mode)	29
🖪 Instant Zoom	31
🔁 Exposure Compensation	
Shooting Mode	35
AUTO	35
SRAUTO SCENE RECOGNITION	35
SP SCENE POSITION	35
PANORAMA MODE	
P, S, A, and M Modes	40
C: CUSTOM MODE	45

More on Playback	
More on Playback	
Playback Options	46
Playback Zoom	47
Viewing Photo Information	48
Multi-Frame Playback	49
Sort by Date	
Deleting Pictures	
•	
Movies	
Recording Movies	52
▶ Viewing Movies	54
• 41	
Connections	
Viewing Pictures on TV	55
Printing Pictures via USB	
Connecting the Camera	
Printing Selected Pictures	57
Printing the DPOF Print Order	58
Creating a DPOF Print Order	60
Viewing Pictures on a Computer	
Installing FinePixViewer	
Connecting the Camera	

Menus	
Jsing the Menus: Shooting Mode	6
Using the F-Mode Menu	6
F-Mode Menu Options	7
ISO ISO	7
	7
	7
FINEPIX COLOR	7
Using the Shooting Menu	7
Shooting Menu Options	7
SELF-TIMER	
PHOTOMETRY	
WB WHITE BALANCE	7
☐ HIGH-SPEED SHOOTING	7
■ FOCUSING	7
AF AF MODE	7
\$ SHARPNESS	8
£ FLASH	8
■ BRACKETING	8

Using the Menus: Playback Mode	81
Using the F -Mode Menu	81
F-Mode Menu Options	82
■ SLIDE SHOW	82
Using the Playback Menu	83
Playback Menu Options	84
■ RED EYE REMOVAL	
☑ IMAGE ROTATE	85
on PROTECT	86
COPY COPY	87
■ VOICE MEMO	89
■ CROP	91
RESIZE	92
The Setup Menu	93
Using the Setup Menu	93
Setup Menu Options	94
☑ IMAGE DISP	95
FRAME NO	96
DIGITAL ZOOM	97
PLAYBACK VOLUME	97
ELCD BRIGHTNESS	
FORMAT	98
AUTO POWER OFF	98
TIME DIFFERENCE	99
DISCHARGE (Ni-MH Batteries Only)	100

Technical Notes	
Optional Accessories	101
Accessories from FUJIFILM	102
Caring for the Camera	103
Troubleshooting	
Troubleshooting	104
Warning Messages and Displays	111
Appendix	
Glossary	115
Internal Memory/Memory Card Capacity	116
Specifications	118

Introduction

Symbols and Conventions

The following symbols are used in this manual:

\(\) Caution: This information should be read before use to ensure correct operation.

← Note: Points to note when using the camera.

園 **Tip**: Additional information that may be helpful when using the camera.

Menus and other text in the camera monitor are shown in bold. In the illustrations in this manual, the monitor display may be simplified for explanatory purposes.

Supplied Accessories

The following items are included with the camera:



AA alkaline (LR6) batteries (×4)



USB-A/V cable



Strap





Lens cap





FinePix CD

• Basic Manual

Parts of the Camera

For more information, refer to the page listed to the right of each item.







1	Strap eyelet7
2	Zoom control16, 47
3	Shutter button19
4	(Intelligent Face Detection/red-eye removal)
	button21
5	♠ (burst mode) button29

6	ON/OFF switch	13
7	Indicator lamp	19
8	Mode dial	6
9	AF-assist illuminator	25
	Self-timer lamp	75
10	Flash	27

11	\$ (flash pop-up) button	27
12	Microphone	52, 89
13	Speaker	54, 90
14	Lens	13



15	Electronic viewfinder5	23	EVF/LCD (display selection) button 5
16	Selector button (see below)	24	▶ (playback) button20, 46
17	Monitor4	25	F (photo mode) button69, 81
18	DISP (display)/BACK button 17, 46	26	Terminal cover55, 57, 67
19	(exposure compensation/photo info)	27	Memory card slot11
	button33, 48	28	Connector for USB-A/V cable
20	Tripod mount		55, 57, 67
21	Battery-chamber cover8	29	HDMI connector55
22	Battery-chamber latch8		




III Tip: Monitor Brightness

Pressing the 🔅 button briefly increases monitor brightness, making the display easier to see in bright light. Normal brightness is restored when a photograph is taken.

Camera Displays

The following indicators may appear during shooting and playback. The indicators displayed vary with camera settings.

■ Shooting




* • Indicates that no memory card is inserted and that pictures will be stored in the camera's internal memory (pg. 10).

1	lmage quality	72
2	Image size	71
3	Sensitivity	70
4	White balance	77
5	Flash mode	27
6	Silent mode	18
7	Intelligent Face Detection	
	indicator	21
8	Dual IS mode	17
9	Shooting mode	35
10	Battery level	15
11	Macro (close-ups) mode	26
12	High-speed mode	78
13	Burst mode	29
_	•	

4	Self-timer indicator75
5	Date and time14
6	Shutter speed and aperture41
7	Number of available frames116
8	FinePix color72
9	Metering76
0	Blur warning27, 107, 111
1	Monitor brightness3
2	Focus frame18
3	Internal memory indicator*10
4	Exposure compensation
	indicator33
5	Exposure indicator44

■ Playback



1	Protected image	.86
	DPOF print indicator	
3	Red-eye removal indicator 21,	84
4	Intelligent Face Detection	
	indicator	.21

5	Silent mode indicator18
6	Playback mode indicator20, 46
7	Voice memo indicator89
8	Gift image46
9	Frame number96


The Electronic Viewfinder (EVF)

The electronic viewfinder provides the same information as the monitor, and can be used when bright lighting conditions make the display in the monitor difficult to see. To switch between the monitor and electronic viewfinder, press the **EVF/LCD** button (your selection remains in effect when the camera is turned off or the mode dial is rotated to another setting).



The Mode Dial


To select a shooting mode, align the mode icon with the mark next to the mode dial.



(AUTO): A simple "point-and-shoot" mode recommended for first-time users of digital cameras (pg. 15).

SRAUTO (SCENE RECOGNITION): A "point-and-shoot" mode in which the camera automatically adjusts settings to suit the scene (pg. 35).

SP (SCENE POSITION): Choose a scene suited to the subject or shooting conditions and let the camera do the rest (pg. 35).



P, S, A, M: Select for full control over camera settings, including aperture (**M** and **A**) and/or shutter speed (**M** and **S**; pg. 40).

C (CUSTOM): Recall stored settings for modes **P**, **S**, **A**, and **M** (pg. 45).


(MOVIE): Record movies with sound (pg. 52).

(PANORAMA): Take a series of photographs and combine them to form a panorama (pg. 39).

The Strap and Lens Cap

Attaching the Strap

Attach the strap to the two strap eyelets as shown below.



**** Caution


To avoid dropping the camera, be sure the strap is correctly secured.

The Lens Cap

Attach the lens cap as shown.



To avoid losing the lens cap, pass the supplied string through the eyelet (①) and secure the lens cap to the strap (②).



Inserting the Batteries

The camera takes four AA alkaline, lithium, or rechargeable Ni-MH batteries. A set of four alkaline batteries is supplied with the camera. Insert the batteries in the camera as described below.

Open the battery-chamber cover.

Slide the battery-chamber latch in the direction shown and open the battery-chamber cover.



← Note

Be sure the camera is off before opening the battery-chamber cover.

**** Cautions

- Do not open the battery-chamber cover when the camera is on. Failure to observe this precaution could result in damage to image files or memory cards.
- Do not use excessive force when handling the battery-chamber cover.

2 Insert the batteries.

Insert the batteries in the orientation shown by the "+" and "-" marks inside the battery chamber.



**** Cautions

- Insert the batteries in the correct orientation.
- Never use batteries with peeling or damaged casing or mix old and new batteries, batteries with different charge levels, or batteries of different types.
 Failure to observe these precautions could result in the batteries leaking or overheating.



Battery casing

• Never use manganese or Ni-Cd batteries.

- The capacity of alkaline batteries varies with the manufacturer and drops at temperatures below 10°C/32°F; Ni-MH batteries are recommended.
- Fingerprints and other soil on the battery terminals can shorten battery life.

? Close the battery-chamber cover.

Close the battery-chamber cover and slide it in until the latch clicks into place.



N Caution

Do not use force. If the battery-chamber cover does not close, check that the batteries are in the correct orientation and try again.

■ Tip: Using an AC Adapter

The camera can be powered by an optional AC adapter and DC coupler (sold separately).

Choosing the Battery Type

After replacing the batteries with batteries of a different type, select the battery type using the **BATTERY TYPE** option in the setup menu (pg.



94) to ensure that the battery level is displayed correctly and the camera does not turn off unexpectedly.

Inserting a Memory Card

Although the camera can store pictures in internal memory, SD memory cards (sold separately) can be used to store additional pictures.

When no memory card is inserted, appears in the monitor and internal memory is used for recording and playback. Note that because camera malfunction could cause internal memory to become corrupted, the pictures in internal memory should periodically be transferred to a computer and saved on the computer hard disk or on removable media such as CDs or DVDs. The pictures in internal memory can also be copied to a memory card (see page 87). To prevent internal memory from becoming full, be sure to delete pictures when they are no longer needed.

When a memory card is inserted as described below, the card will be used for recording and playback.

■ Compatible Memory Cards

SanDisk SD and SDHC memory cards have been approved for use in the camera. A complete list of approved memory cards is available at http://www.fujifilm.com/products/digital_cameras/index.html. Operation is not guaranteed with other cards. The camera can not be used with https://www.fujifilm.com/products/digital_cameras/index.html. Operation is not guaranteed with other cards. The camera can not be used with https://www.fujifilm.com/products/digital_cameras/index.html. Operation is not guaranteed with other cards. The camera can not be used with https://www.fujifilm.com/products/digital_cameras/index.html.

**** Caution

Memory cards can be locked, making it impossible to format the card or to record or delete images. Before inserting a memory card, slide the write-protect switch to the unlocked position.



Write-protect switch

Inserting a Memory Card

1 Open the battery-chamber cover.


← Note

Be sure the camera is off before opening the batterychamber cover.



) Insert the memory card.

Holding the memory card in the orientation shown below, slide it in until it clicks into place at the back of the slot.





Be sure card is in correct orientation; do not insert at an angle or use force. If the memory card is not correctly inserted, pictures will be recorded to internal memory.

? Close the battery-chamber cover.

Close the battery-chamber cover and slide it in until the latch clicks into place.



Removing Memory Cards

After confirming that the camera is off, press the card in and then release it slowly. The card can now be removed by hand.



∇ Cautions

- The memory card may spring out if you remove your finger immediately after pushing the card in.
- Memory cards may be warm to the touch after being removed from the camera. This is normal and does not indicate a malfunction.


**** Cautions

- Do not turn the camera off or remove the memory card while the memory card is being formatted or data are being recorded to or deleted from the card. Failure to observe this precaution could damage the card.
- Format memory cards before first use, and be sure to reformat all memory cards after using them in a computer or other device. For more information on formatting memory cards, see page 98.
- Memory cards are small and can be swallowed; keep out of reach of children. If a child swallows a memory card, seek medical assistance immediately.
- miniSD or microSD adapters that are larger or smaller than the standard dimensions of an SD card may not eject normally; if the card does not eject, take the camera to an authorized service representative. Do not forcibly remove the card.
- Do not affix labels to memory cards. Peeling labels can cause camera malfunction.
- Movie recording may be interrupted with some types of memory card. Use a card with a class 4 write speed (4 MB/s) or better when shooting HD movies.
- The data in internal memory may be erased or corrupted when the camera is repaired. Please note that the repairer will be able to view pictures in internal memory.
- Formatting a memory card or internal memory in the camera creates a folder in which pictures are stored. Do not rename or delete this folder or use a computer or other device to edit, delete, or rename image files. Always use the camera to delete pictures from memory cards and internal memory; before editing or renaming files, copy them to a computer and edit or rename the copies, not the originals.

Turning the Camera on and Off

Shooting Mode

Slide the **ON/OFF** switch in the direction shown below. The lens will extend automatically.



Slide the **ON/OFF** switch to turn the camera off.

▼ Tip: Switching to Playback Mode


Press the **b** button to start playback. Press the shutter button halfway to return to shooting mode.

Cautions

- Forcibly preventing the lens from extending could cause damage or product malfunction.
- Pictures can be affected by fingerprints and other marks on the lens. Keep the lens clean.
- The **ON/OFF** button does not completely disconnect the camera from its power supply.

Playback Mode

To turn the camera on and begin playback, press the ▶ button for about a second.



Press the **D** button again or slide the **ON/OFF** switch to turn the camera off.

■ Tip: Switching to Shooting Mode

To exit to shooting mode, press the shutter button halfway. Press the **D** button to return to playback.

▼ Tip: Auto Power Off

The camera will turn off automatically if no operations are performed for the length of time selected in the **AUTO POWER OFF** menu (see page 98). To turn the camera on, use the **ON/OFF** switch or press the **D** button for about a second.

Basic Setup

A language-selection dialog is displayed the first time the camera is turned on. Set up the camera as described below (for information on resetting the clock or changing languages, see page 94).

1 Choose a language.




1.1 Press the selector up, down, left, or right to highlight a language.



1.2 Press MENU/OK.



2 Set the date and time.



2.1 Press the selector left or right to highlight the year, month, day, hour, or minute and press up or down to change. To change the order in which the year, month, and day are displayed, highlight the date format and press the selector up or down.



2.2 Press **MENU/OK**. A battery type message will be displayed; if the type differs from the type inserted in the camera, use the setup menu **BATTERY TYPE** option (pg. 94) to specify the correct type.




▼ Tip: The Camera Clock

If the batteries are removed for an extended period, the camera clock and battery type will be reset and the language-selection dialog will be displayed when the camera is turned on. If the batteries are left in the camera for about 10 hours, the battery can be removed for about 24 hours without resetting the clock, language, or battery type.

Taking Pictures in (Auto) Mode


This section describes how to take pictures in (auto) mode.

1 Turn the camera on.Slide the **ON/OFF** switch to turn the camera on.




2 Select mode.

Rotate the mode dial to .



3 Check the battery level. Check the battery level in the display.




Indicator	Description
NO ICON	Batteries are partially discharged.
1 4	Batteries are low. Replace as soon
(red)	as possible.
② 🗖 Batteries are exhausted. Turn of	
(blinks red)	era off and replace batteries.

← Note

A battery warning may not be displayed before the camera turns off, particularly if batteries are reused after having once been exhausted. Power consumption varies greatly from mode to mode; the low battery warning () may not be displayed or may be displayed only briefly before the camera turns off in some modes or when switching from shooting to playback mode.

4 Frame the picture.

Position the main subject in the focus frame and use the zoom control to frame the picture in the display.





By default setting, the camera uses optical zoom only. If desired, digital zoom (pg. 97) can be used to zoom in closer

Holding the Camera

Hold the camera steady with both hands and brace your elbows against your sides. Shaking or unsteady hands can blur your shots.



To prevent pictures that are out of focus or too dark (underexposed), keep your fingers and other objects away from the lens and flash.




▼ Tip: Focus Lock

Use focus lock (pg. 24) to focus on subjects that are not in the focus frame.

Shooting Information

To choose the shooting information and guides displayed, press the **DISP/BACK** button.




To use best framing, position the main subject at the intersection of two lines or align one of the horizontal lines with the horizon. Use focus lock (pg. 24) to focus on subjects that will not be in the center of the frame in the final photograph.

Best framing

Avoiding Blurred Pictures

If the subject is poorly lit, blurring caused by camera shake can be reduced using the



tripod.


movement is also reduced (dual IS mode).

Sensitivity is raised when dual IS is in effect. Note that blurring may still occur depending on the scene. We recommend that you turn dual IS off when using a



Silent Mode

In situations in which camera sounds or lights may be unwelcome, hold the **DISP/BACK** button down until to is displayed (note that silent mode is not available during movie or voice memo playback).



The camera speaker and AF-assist illuminator/self-timer lamp turn off and volume (pg. 94) can not be adjusted (note that the AF-assist illuminator may still light when ♥ is selected in scene mode). To restore normal operation, press the DISP/BACK button until the tion is no longer displayed.

5 Focus.

Press the shutter button halfway to focus on the main subject in the focus frame.



Focus frame Camera selects small focus frame and focuses on subject

← Note

The lens may make a noise when the camera focuses. This is normal.

If the camera is able to focus, it will beep twice and the indicator lamp will glow green.

If the camera is unable to focus, the focus frame will turn red, **!AF** will be displayed, and the indicator lamp will blink green. Change the composition or use focus lock (pg. 24).


6 Shoot.

Smoothly press the shutter button the rest of the way down to take the picture.



▼ Tip: The Shutter Button

The shutter button has two positions. Pressing the shutter button halfway (①) sets focus and exposure; to shoot, press the shutter button the rest of the way down (②).



← Note

If the subject is poorly lit, the AF-assist illuminator may light to assist focus (pg. 25). For information on using the flash when lighting is poor, see page 27.

The Indicator Lamp



The indicator lamp shows camera status as follows:

The indicator famp shows carriera status as follows.		
Camera status		
Focus locked.		
Blur, focus, or exposure warning. Pic-		
ture can be taken.		
Recording pictures. Additional pic-		
tures can be taken.		
Recording pictures. No additional pic-		
tures can be taken at this time.		
Flash charging; flash will not fire when		
picture is taken.		
Lens or memory error (internal memory		
or memory card full or not formatted,		
format error, or other memory error).		


▼ Tip: Warnings

Detailed warnings appear in the display. See pages 111–114 for more information.

Viewing Pictures

Pictures can be viewed in the monitor. When taking important photographs, take a test shot and check the results.

1 Press the **b** button.



The most recent picture will be displayed in the monitor.



2 View additional pictures.

Press the selector right to view pictures in the order recorded, left to view pictures in reverse order.




Press the shutter button to exit to shooting mode.

Deleting Pictures

To delete the picture currently displayed in the monitor, press the selector up (面). The following dialog will be displayed.





To delete the picture, press the selector left to highlight **OK** and press **MENU/OK**. To exit without deleting the picture, highlight **CANCEL** and press **MENU/OK**.



関 Tip: The Playback Menu


Pictures can also be deleted from the playback menu (pg. 50).


Intelligent Face Detection and Red-Eye Removal

Intelligent Face Detection allows the camera to automatically detect human faces and set focus and exposure for a face anywhere in the frame for shots that emphasize portrait subjects. Choose for group portraits (in horizontal or vertical orientations) to prevent the camera from focusing on the background. Intelligent Face Detection also offers a blink detection option as well as red-eye removal for removing "red-eye" effects caused by the flash.

1 Turn Intelligent Face Detection on.

Press the button to cycle through settings as shown below.





Option	Description
	Intelligent Face Detection and
	red-eye removal off.
	Intelligent Face Detection and
	red-eye removal on. Use with
	the flash.
FACE DETECTION	Intelligent Face Detection on;
	rod-ove removal off

2 Frame the picture.

If a face is detected, it will be indicated by a green border. If there is more than one face in the frame, the camera will select the face clos-



Green border

est to the center; other faces are indicated by white borders.

3 Focus.

Press the shutter button halfway to set focus and exposure for the subject in the green border.



∇ Caution

If no face is detected when the shutter button is pressed halfway (pg. 106), the camera will focus on the subject at the center of the display and red-eye will not be removed.

4 Shoot.

Press the shutter button all the way down to shoot.



N Caution

If the subject moves as the shutter button is pressed, their face may not be in the area indicated by the green border when the picture is taken. If the number of faces is large, additional time may be required for processing.

If PACE DETECTION REMOVAL ON is selected, the picture will be processed to reduce red-eye before it is recorded.

Intelligent Face Detection


Intelligent Face Detection is recommended when using the self-timer for group- or self-portraits (pg. 76).



When a picture taken with Intelligent Face Detection is displayed, the camera can automatically select faces for red-eye removal (pg. 84), playback zoom (pg. 47), slide shows (pg. 82), printing (pg. 61), and cropping (pg. 91).

Blink Detection

If an option other than **OFF** is selected for **IMAGE DISP** (pg. 95), a warning will be displayed if the camera detects subjects who may have blinked when the picture was taken. If **ZOOM** (**CONTINUOUS**) is selected, you can press the **1** button to zoom in on these subjects; a new face is selected each time the **1** button is pressed.



If you are satisfied with the results, press **MENU/OK** to save the picture. If you want to try again, press the selector up to delete the picture and then take another photograph.

N Caution

Blink detection is not performed if the camera fails to detect a face or when **OFF** is selected for **IMAGE DISP**.

Focus Lock

To compose photographs with off-center subjects:

1 Position the subject in the focus frame.



7 Focus.

Press the shutter button halfway to set focus and exposure. Focus and exposure will remain locked while the shutter button is pressed halfway (AF/AE lock).



Repeat steps 1 and 2 as desired to refocus before taking the picture.

3 Recompose the picture. Keeping the shutter button pressed

Keeping the shutter button pressed halfway, recompose the picture.



4 Shoot.

Press the shutter-release button the rest of the way down to take the picture.



Press the rest of the way down

Autofocus

Although the camera boasts a high-precision autofocus system, it may be unable to focus on the subjects listed below. If the camera is unable to focus using autofocus, use focus lock (pg. 24) to focus on another subject at the same distance and then recompose the photograph.

Very shiny subjects such as mirrors or car bodies.





- Subjects photographed through a window or other reflective object.
- Dark subjects and subjects that absorb rather than reflect light, such as hair or fur.
- Insubstantial subjects, such as smoke or flame.
- Subjects that show little contrast with the background (for example, subjects in clothing that is the same color as the background).
- Subjects positioned in front of or behind a highcontrast object that is also in the focus frame (for example, a subject photographed against a backdrop of highly contrasting elements).

The AF-Assist Illuminator

If the subject is poorly lit, the AF-assist illuminator will light to assist the focus operation when the shutter button is pressed halfway.



← Notes

- Avoid shining the AF-assist illuminator directly into your subject's eyes. See page 94 for information on disabling the AF-assist illuminator.
- The camera may be unable to focus using the AFassist illuminator in some cases. If the camera is unable to focus in macro mode (pg. 26), try increasing the distance to the subject.
- The AF-assist illuminator is not available in silent mode

Macro and Super Macro Modes (Close-ups)

For close-ups, press the selector left (to choose from the macro options shown below.



When macro mode is in effect, the camera focuses on subjects near the center of the frame. Use the zoom control to compose pictures. In super macro mode, zoom can not be adjusted and the flash can not be used.

← Notes

- Use of a tripod is recommended to prevent blur caused by camera shake.
- Flash compensation may be required when using the flash (pg. 80).

4 Using the Flash (Intelligent Flash)

When the flash is used, the camera's *Intelligent Flash* system instantly analyzes the scene based on such factors as the brightness of the subject, its position in the frame, and its distance from the camera. Flash output and sensitivity are adjusted to ensure that the main subject is correctly exposed while preserving the effects of ambient background lighting, even in dimly-lit indoor scenes. Use the flash when lighting is poor, for example when shooting at night or indoors under low light.

1 Raise the flash.

Press the flash pop-up button to raise the flash.


Turning the Flash Off

Lower the flash where flash photography is prohibited or to capture natural lighting under dim light. At slow shutter speeds, **!o*** will be displayed to warn that pictures may be blurred; use of a tripod is recommended.



7 Choose a flash mode.

Press the selector right (\$\frac{4}{2}\$). The flash mode changes each time the selector is pressed.



Mode	Description
AUTO (AUTO FLASH)	The flash fires when required. Recommended in most situations.
3 (FORCED FLASH)	coloration when shooting in bright light.
\$4 (SLOW SYNCHRO)	Capture both the main subject and the background under low light (note that brightly lit scenes may be overexposed).

3 Focus.

Press the shutter button halfway to focus. If the flash will fire, 3 will be displayed when the shutter button is pressed halfway. At slow shutter speeds, 5 will appear in the display to warn that pictures may be blurred; use of a tripod is recommended.



4 Shoot.

Press the shutter button the rest of the way down to shoot.

**** Caution

The flash may fire several times with each shot. Do not move the camera until shooting is complete.



← Note

For restrictions on flash settings, see page 41 of the Basic Manual.

Red-Eye Removal

When PACE DETECTION REMOVAL ON is selected for Intelligent Face Detection (pg. 21), red-eye removal (A) is available in AUTO (A), FORCED FLASH (A), and SLOW SYNCHRO (A) modes. Red-eye removal minimizes "red-eye" caused when light from the flash is reflected from the subject's retinas as shown in the illustration at right.



Q Continuous Shooting (Burst Mode)

Capture motion in a series of pictures.

1 Choose a continuous shooting mode.

Press the **\(\)** button to display continuous shooting options. Press the selector up or down to highlight the desired option and press **MENU/OK**.

Mode	Description
₽ (TOP 20 S)	The camera takes up to 20 pictures while the shutter button is pressed.
M≟ (TOP 10 M)	The camera takes up to 10 pictures while the shutter button is pressed.
(LONG PERIOD)	The camera takes pictures while the shutter button is pressed. Shooting ends when the shutter button is released or memory is full.
(LAST 3)	The camera takes up to 40 pictures while the shutter button is pressed, but only the last three frames are recorded.
(BRACKETING)	Each time the shutter-release button is pressed, the camera takes three shots: one using the metered value for exposure, the second overexposed by the amount selected for BRACKETING in the shooting menu (pg. 80), and the third underexposed by the same amount (the camera may not be able to use the selected bracketing increment if the amount of over- or under-exposure exceeds the limits of the exposure metering system).
₾ (TOP 3)	The camera takes up to three pictures while the shutter button is pressed.
OFF	Continuous shooting mode off. One picture is taken each time the shutter button is pressed.





7 Focus.

Press the shutter button halfway to focus.



3 Shoot.

Pictures will be taken while the shutter button is pressed. Shooting ends when the shutter button is released, memory is full, or the selected number of shots has been taken.



- Focus and exposure are determined by the first frame in each series. The flash turns off automatically (pg. 27); the previously-selected flash mode is restored when continuous shooting is turned off.
- Frame rate varies with shutter speed.
- If the self-timer is used when 🚡 and 🖳 are selected, only one picture will be taken when the shutter button is pressed.
- At a setting of 🙉, white lines may appear in bright areas of the image; these can be avoided by choosing 🙉 mode.
- The number of pictures that can be recorded depends on the memory available. Bracketing is only available if there is sufficient memory for three pictures. Additional time may be required to record pictures when shooting ends. In •, •, and modes, pictures are displayed in the monitor while recording is in progress.



Instant Zoom

In instant zoom, the area surrounding the frame is visible in the display. Use to frame erratically moving subjects such as children, pets, and athletes at sporting events.


1 Position the subject in the focus frame. Use the zoom control to frame the subject in the center of the display.






2 Choose a frame.

Press the selector down ((23)) to cycle through framing options as shown below.






The frame is displayed as shown at right. The composition can be adjusted using the zoom control.



3 Focus and shoot.

The framed area will be enlarged to create a full-sized picture.



■ Intelligent Face Detection

Intelligent Face Detection will not detect faces outside the selected frame.

**** Caution

■ Digital Zoom

1 Enable digital zoom.Select **ON** for the **Q DIGITAL ZOOM** option in the setup menu (pg. 97).


2 Choose a subject.

Frame the subject in the center of the display using digital zoom.



? Press the selector down (□).

The camera will zoom to the maximum optical zoom position with the area that will be recorded using digital zoom indicated by a frame at the center of the display.






4 Frame the picture.


Use the zoom control to choose the area that will be included in the final photograph.





5 Focus and shoot.

The framed area will be enlarged to create a full-sized picture.



N Caution


Pictures taken using the instant zoom are lower quality than pictures taken using normal zoom.

Exposure Compensation

Use exposure compensation when photographing very bright, very dark, or high-contrast subjects.

Press the 🔀 button.

The exposure indicator will be displayed.







Choose a value.

Press the selector left or right. The effect is visible in the display.









Return to shooting mode.

Press the **b**utton to return to shooting mode.

▲ Take pictures.

A 🔀 icon and exposure indicator are displayed at settings other than ±0. Exposure compensation is not reset when the camera is turned off; to restore normal exposure control, choose a value of ±0.

More on Photography

Choosing an Exposure Compensation Value

• Backlit subjects: choose values from +% EV to +1% EV (for an explanation of the term "EV", see the Glossary on page 115)



• Highly reflective subjects or very bright scenes (e.g., snowfields): +1 EV



- Scenes that are mostly sky: +1~EV
- Spotlit subjects (particularly if photographed against dark backgrounds): –3/3 EV
- Subjects with low reflectivity (pine trees or dark-colored foliage): -4/3 EV

Shooting Mode

Choose a shooting mode according to the scene or type of subject. To choose a shooting mode, rotate the mode dial to the desired setting (pg. 6). The following modes are available:

AUTO

Choose for crisp, clear snapshots (pg. 15). This mode is recommended in most situations.

SRAUTO SCENE RECOGNITION

In this mode, the camera automatically analyzes the composition and selects the appropriate scene mode according to the subject and shooting conditions. The selected mode is displayed when the shutter button is pressed halfway.

Mode	Type of subject or scene detected
0	Portrait: Human portrait subject.
0	Landscape: Man-made or natural landscape.
G	Night landscape: Poorly lit landscape.
Ø	Macro: Subject close to camera.
•	Night portrait: Poorly lit portrait subject.
<u>_</u>	Back-lit portrait: Back-lit portrait subject.

← Notes: SRAUTO

- (AUTO) will be selected if the subject does not match the scenes listed above.
- The camera focuses continuously on the faces of portrait subjects or on subjects near the center of the frame. This increases the drain on the battery, and the sound of the camera focusing may be audible.

SP SCENE POSITION

The camera offers a choice of "scenes," each adapted to particular shooting conditions or a specific type of subject, which can be assigned to the **SP** position on the mode dial:

Rotate the mode dial to **SP**.



Press MENU/OK to display the shooting menu.



3 Press the selector up or down to highlight **SCENE POSITION**.



4 Press the selector right to display a list of scenes.



5 Press the selector up or down to highlight a scene.



6 Press **MENU/OK** to select the highlighted option.



Until the setting is changed as described above, the chosen scene will be selected whenever the mode dial is rotated to **SP**.

Natural Light

Capture natural light indoors, under low light, or where the flash can not be used. The flash turns off and sensitivity is raised to reduce blur.

● 4 Natural & 4


This mode helps ensure good results with backlit subjects and in other situations with difficult lighting. Before shooting, raise the flash; pictures can only be taken when the flash is raised. Each time the shutter button is pressed, the camera takes two shots: one shot without the flash to preserve natural lighting, followed immediately by a second shot with the flash. Do not move the camera until shooting is complete.


← Notes

- Do not use where flash photography is prohibited.
- Only available if memory remains for two pictures.
- Burst mode is not available.

Zoom Bracketing

Each time the shutter button is pressed, the camera takes three pictures: one at the current zoom ratio with an image size of , a second zoomed in 1.4× and cropped to , and a third zoomed in 2× and cropped to ; (pictures will only be taken if there is enough memory for three images). Two frames are displayed to show the areas that will be included in the second and third pictures; the outer frame shows the area that will be recorded at 1.4× zoom, the inner frame the area that will be recorded at 2× zoom. Press the selector down to choose from wide and tall crops.





← Notes

- Digital zoom can not be used. If digital zoom is active when when mode is selected, zoom will be set to the maximum optical zoom position.
- Burst shooting options are limited to **a** and **OFF**.

Smile

The shutter is released automatically when Intelligent Face Detection detects a smiling face.

Portrait

Choose this mode for soft-toned portraits with natural skin tones.

▲ Landscape

Choose this mode for crisp, clear daylight shots of buildings and landscapes.

🛰 Sport

Choose this mode when photographing moving subjects. Et HIGH-SPEED SHOOTING turns on automatically and priority is given to faster shutter speeds.

♥ Night

Choose this mode for poorly lit twilight or night scenes. Sensitivity is automatically raised to reduce blur caused by camera shake.

⋆ Night (Tripod)

Choose this mode for slow shutter speeds when shooting at night. Use a tripod to prevent blur.

Fireworks

Slow shutter speeds are used to capture the expanding burst of light from a firework. Press the button to display a shutter-speed selection dialog and press the selector up and down to choose a shutter speed.

🛎 Sunset

Choose this mode to record the vivid colors in sunrises and sunsets.

Snow

Choose for crisp, clear shots that capture the brightness of scenes dominated by shining white snow.

♣↑ Beach

Choose for crisp, clear shots that capture the brightness of sunlit beaches.

₹ Party

Capture indoor background lighting under lowlight conditions.

☆ Flower

Choose for vivid close-ups of flowers. The camera focuses in the macro range.

EXT Text

Take clear pictures of text or drawings in print. The camera focuses in the macro range.

PANORAMA MODE

In this mode, you can take up to three pictures and join them together to form a panorama. Use of a tripod is recommended to assist in composing overlapping shots.

1 Rotate the mode dial to PANORAMA,



2 Press the selector up to select a frame, and press the selector left or right to highlight a pan direction and press **MENU/OK**.





3 Take a photograph. Exposure and white balance for the panorama are set with the first shot.



Press **MENU/OK**. An edge of the picture you have just taken will be displayed at one side of the frame.





Frame the next shot to overlap with the previous picture.



- **6** Take the second shot as described in steps 3–4 (to create a panorama from only two frames, press the selector up after the second shot).
- 7 Take the last shot, framing it to overlap the second picture. Press MENU/ OK to complete the panorama (the individual shots are not saved).





8 Press **MENU/OK** to save the picture.

Printing Pictures Taken in Panorama Mode

Depending on the number of photographs they contain, panoramas may not print correctly on some sizes of paper. Part of the image may not be printed or the image may print with unusually wide margins at the top and bottom or left and right.


P, S, A, and M Modes

P, S, A, and **M** modes provide full access to the shooting and **F**-mode menus. **S, A**, and **M** modes also offer control over shutter speed and/or aperture.

Mode	Description
P (PROGRAM	The camera sets exposure automati-
AE; pg. 41)	cally.
S (SHUTTER	You choose the shutter speed, letting
PRIORITY AE;	the camera set aperture for optimal
pg. 42)	exposure.
A (APERTURE	You choose the aperture, letting the
PRIORITY AE;	camera set shutter speed for optimal
pg. 43)	exposure.
M (MANUAL;	You choose both shutter speed and
pg. 44)	aperture.

P: PROGRAM AE

In this mode, the camera sets exposure automatically. If desired, you can choose different combinations of shutter speed and aperture that will produce the same exposure (program shift).



**** Caution

If the subject is outside the metering range of the camera, the shutter speed and aperture displays will show "---". Press the shutter button halfway to measure exposure again.



Program Shift

Press the button to choose the desired combination of shutter speed and aperture. Values that differ from those automatically selected by the camera are shown in yellow. The default values can be restored by raising the flash, rotating the mode dial to another setting, turning the camera off, or selecting playback mode. Program shift is not available when the flash is raised.





S: SHUTTER PRIORITY AE

In this mode, you choose the shutter speed while the camera adjusts aperture for optimal exposure.

1 Rotate the mode dial to S.



2 Press the **☑** button. Shutter speed and aperture will be displayed.



Shutter speed

3 Press the selector up or down to choose the shutter speed.



4 Press the **≥** button to exit to shooting mode.



5 Take pictures. If the correct exposure can not be achieved at the selected shutter speed, aperture will be displayed in red when the shutter button is pressed halfway. Adjust shutter speed until the correct exposure can be achieved.

Caution

If the subject is outside the metering range of the camera, the aperture display will show "---". Press the shutter button halfway to measure exposure again.

A: APERTURE PRIORITY AE

In this mode, you choose the aperture while the camera adjusts shutter speed for optimal exposure.

1 Rotate the mode dial to **A**.



2 Press the **☑** button. Shutter speed and aperture will be displayed.



Aperture 3

3 Press the selector up or down to choose the aperture.



4 Press the **■** button to exit to shooting mode.



5 Take pictures. If the correct exposure can not be achieved at the selected aperture, shutter speed will be displayed in red when the shutter button is pressed halfway. Adjust aperture until the correct exposure can be achieved.

**** Caution

If the subject is outside the metering range of the camera, the shutter speed display will show "---". Press the shutter button halfway to measure exposure again.

M: MANUAL


In this mode, you choose both shutter speed and aperture. If desired, exposure can be altered from the value suggested by the camera.

1 Rotate the mode dial to M.



2 Press the **☑** button. Shutter speed and aperture will be displayed.





3 Press the selector up or down to choose the shutter speed.



4 Press the selector left or right to choose the aperture.




5 Press the **≥** button to exit to shooting mode.



6 Take pictures.


The Exposure Indicator

The amount the picture will be under- or over-exposed at current settings is shown by the exposure indicator. Pictures taken with the indicator to the left of center ("-") will be underexposed, pictures taken with the indicator is to the right of center ("+"), over-exposed.



C: CUSTOM MODE


In **P**, **S**, **A**, and **M** modes, the **CUSTOM SET** option in the shooting menu (pg. 74) can be used to save current camera and menu settings. These settings are recalled whenever the mode dial is rotated to **C** (custom mode).



Menu/setting	Settings saved	
F-mode menu	ISO, ■ IMAGE SIZE, ➡ IMAGE QUALITY, 🗖 FINEPIX COLOR	
	☐ PHOTOMETRY, ☐ WHITE BALANCE, ☐ HIGH-SPEED SHOOTING, ☐ FOCUSING, ☐ AF MODE,	
Shooting menu	S SHARPNESS, 图 FLASH, ☐ BRACKETING	
Setup menu	☑ IMAGE DISP, ☑ DUAL IS MODE, AF ILLUMINATOR, ☑ DIGITAL ZOOM, EVF/LCD MODE	
Other	Shooting mode (P, S, A , or M), continuous shooting mode, Intelligent Face Detection, instant zoom, macro mode, exposure compensation, flash mode, shutter speed, aperture, display type (EVF/LCD), indicators/best framing	

Playback Options

To view the most recent picture in the monitor, press the **D** button.





Press the selector right to view pictures in the order recorded, left to view pictures in reverse order. Keep the selector pressed to scroll rapidly to the desired frame.





← Note

Pictures taken using other cameras are indicated by a **\mathbb{H}** ("gift image") icon during playback.

Playback Zoom

Select **T** to zoom in on pictures displayed in single-frame playback; select **W** to zoom out. When the picture is zoomed in, the selector can be used to view areas of the image not currently visible in the display.





Zoom indicator

Navigation window shows portion of image currently displayed in monitor

Press **DISP/BACK** to exit zoom.

← Note

The maximum zoom ratio varies with image size. Playback zoom is not available with resized copies or copies cropped to a size of 640.

Intelligent Face Detection

Pictures taken with Intelligent Face Detection (pg. 21) are indicated by a 🖳 icon. Press the 🔛 button to zoom in on the subject selected with Intelligent Face Detection. You can



then use the zoom control to zoom in and out.

Viewing Photo Information

To view or hide the photo information listed below in single-frame playback, press







① Image quality and size, ② Sensitivity, ③ Shutter speed/aperture, ④ FinePix color, ⑤ Flash mode, ⑥ White balance, ⑦ Exposure compensation, ⑧ Frame number, ⑨ Picture (overexposed areas blink on and off), ⑩ Histogram

Histograms

Histograms show the distribution of tones in the image. Brightness is shown by the horizontal axis, the number of pixels by the vertical axis.

Optimal exposure: Pixels are distributed in an even curve throughout the tone range.



Overexposed: Pixels are clustered at the right side of the graph.



Underexposed: Pixels are clustered at the left side of the graph.

Multi-Frame Playback

To change the number of images displayed during playback, select **W**.



Select **W** to increase the number of pictures displayed to two, nine, or a hundred.











Select **T** to reduce the number of images displayed.

Use the selector to highlight images and press **MENU/OK** to view the highlighted image full frame. In the nine- and hundred-frame displays, press the selector up or down to view more pictures.

III Tip: Two-Frame Display

Two-frame display can be used to compare pictures taken in •• mode.



Sort by Date

Choose sort-by-date mode to view pictures taken on a selected date.

1 Press **DISP/BACK** until the sort-by-date screen is displayed.





Use the selector up or down to highlight a date. Keep the selector pressed to scroll rapidly to the desired date.



3 Press the selector left or right to scroll through the pictures taken on the highlighted date. Keep the selector pressed to scroll rapidly to the desired frame



Deleting Pictures

The **ERASE** option in the playback menu can be used to delete still pictures and movies, increasing the amount of space available on the memory card or in internal memory (for information on deleting pictures in single-frame playback, see page 20). *Note that deleted pictures can not be recovered. Copy important pictures to a computer or other storage device before proceeding.*

1 Press **MENU/OK** to display the playback menu.

PLAYBACK MENU



4 Press the selector up or down to highlight **FRAME** or **ALL FRAMES**.



Press MENU/OK to display options for the selected item (see following page).



2 Press the selector up or down to highlight **ERASE**.



3 Press the selector right to display delete options.







- When a memory card is inserted, pictures will be deleted from the memory card; otherwise, pictures will be deleted from internal memory.
- Protected pictures can not be deleted. Remove protection from any pictures you wish to delete (pg. 86).
- If a message appears stating that the selected images are part of a DPOF print order, press MENU/OK to delete the pictures.

■ FRAME: Deleting Selected Images

Selecting **FRAME** displays the dialog shown at right.



Press the selector left or right to scroll through pictures and press **MENU/OK** to delete the current picture (the picture is deleted immediately; be careful not delete the wrong picture).



Press **DISP/BACK** to exit when all the desired pictures have been deleted.

■ ALL FRAMES: Deleting All Images

Selecting **ALL FRAMES** displays the confirmation shown at right.



Highlight **OK** and press **MENU/OK** to delete all unprotected pictures.



The dialog shown at right is displayed during deletion. Press **DISP/BACK** to cancel before all pictures have been deleted (any pictures deleted before the between the displayed by the best and before the best transfer or the best transfer o



leted before the button was pressed can not be recovered).

Recording Movies

Shoot short movies at 30 frames per second. Sound is recorded via the built-in microphone; do not cover the microphone during recording.


1 Rotate the mode dial to ♣ (movie mode).



12 (25) (12s) 7 (15s) 7 (15s)

Time available is displayed in monitor

Press the **F** button and select a frame size from the **QUALITY** menu. Choose **QUALITY** menu. Choose **QUALITY** menus pixels) for an aspect ratio



of 16:9 (High Definition), **640** (640×480 pixels) for high-quality standard definition movies, or **820** (320×240 pixels) for longer movies. Press **MENU/OK** to exit to movie mode.

Press MENU/OK to display the shooting menu and select the type of zoom available in movie mode from the MOVIE



ZOOM TYPE menu. Choose **OPP OPTICAL** to enable optical zoom (note that sounds made by the camera during zoom may be recorded). Choose **DI DIGITAL** to enable digital zoom (note that digital zoom may produce lower quality images than optical zoom). Press **MENU/OK** exit to movie mode.

Avoiding Blurred Pictures

If the subject is poorly lit, blurring caused by camera shake can be reduced using the **DUAL IS MODE** option in the setup menu (pg. 94). In node, blur caused by subject movement is also reduced (dual IS mode).

Sensitivity is raised when dual IS is in effect. Note that blurring may still occur depending on the scene. We recommend that you turn dual IS off when using a tripod.

1 Press the shutter button all the way down to start recording.





← Note

Exposure and white balance are adjusted automatically throughout recording. The color and brightness of the image may vary from that displayed before recording begins.

■ Tip

There is no need to keep the shutter button pressed during recording.

5 Press the shutter button halfway to end recording. Recording ends automatically when the movie reaches maximum length or memory is full.



N Caution

The indicator lamp lights while movies are being recorded. Do not open the battery chamber during shooting or while the indicator lamp is lit. Failure to observe this precaution could prevent the movie from being played back.

- Vertical or horizontal streaks may appear in movies containing very bright subjects. This is normal and does not indicate a malfunction.
- The **EVF/LCD MODE** option in the setup menu is fixed at **30 fps** in movie mode.


▶ Viewing Movies

During playback (pg. 46), movies are displayed in the monitor as shown at right. The following operations can be performed while a movie is displayed:



Operation	Description
Start/pause	Press the selector down to start playback.
playback	Press again to pause.
End playback/ delete	Press the selector up to end playback. If playback is not in progress, pressing the selector up will delete the current movie.
Advance/ rewind	Press the selector right to advance, left to rewind. If playback is paused, the movie will advance or rewind one frame each time the selector is pressed.
Adjust volume	Press MENU/OK to pause playback and display volume controls. Press the selector up or down to adjust the volume; press MENU/OK again to set the volume.

Progress is shown in the monitor during playback.



▼ Tip: Viewing Movies on a Computer


Copy movies to the computer before viewing.

**** Caution

Do not cover the speaker during playback.

Viewing Pictures on TV

1 Connect the camera to a TV and tune the television to the video channel to show pictures to a group. The supplied USB-A/V cable connects as shown below. Turn the camera off before connecting the cable.



HDMI (S2500HD/S2700HD series Only)

An HDMI cable (available from third-party suppliers; pg. 101, 115) can be used to connect \$2500HD/\$2700HD-series cameras to High Definition (HD) devices (playback only). The USB cable can not be used while an HDMI cable is connected.



2 Press F for about a second to turn the camera on. The camera monitor turns off and pictures and movies are played back on the TV. Note that the camera volume controls have no effect on sounds played on the TV; use the television volume controls to adjust the volume.

- Image quality drops during movie playback.
- An optional accessory is required to view HD movies recorded with S1600/S1700-series and S1800/S1900-series cameras on an HD device. Visit the following website for more information:
 http://www.fujifilm.com/products/digital_cameras/accessories/hdtv/

**** Caution

When connecting the cable, be sure the connectors are fully inserted.

Printing Pictures via USB


If the printer supports PictBridge, the camera can be connected directly to the printer and pictures can be printed without first being copied to a computer. Note that depending on the printer, not all the functions described below may be supported.



Connecting the Camera

1 Connect the supplied USB-A/V cable as shown and turn the printer on.





Printing Selected Pictures

Press the selector left or right to display a picture you wish to print.



2 Press the selector up or down to choose the number of copies (up to 99).



3 Repeat steps 1–2 to select additional pictures. Press **MENU/OK** to display a confirmation dialog when settings are complete.





⚠ Press **MENU/OK** to start printing.



▼ Tip: Printing the Date of Recording

To print the date of recording on pictures, press **DISP/BACK** in steps 1–2 to display the PictBridge menu (see "Printing the DPOF Print Order," below). Press the selector up or down to highlight **PRINT WITH DATE G** and press **MENU/OK** to return to the PictBridge display (to print pictures without the date of recording, select **PRINT WITHOUT DATE**). To ensure that the date is correct, set the camera clock before taking pictures.

← Note


If no pictures are selected when the **MENU/OK** button is pressed, the camera will print one copy of the current picture.

Printing the DPOF Print Order

To print the print order created with ▶ PRINT ORDER (DPOF) in the playback F-mode menu (pg. 82):

1 In the PictBridge display, press **DISP/ BACK** to open the PictBridge menu.





Press the selector up or down to highlight **PRINT DPOF**.



Press MENU/OK to display a confirmation dialog.







1 Press **MENU/OK** to start printing.



During Printing

The message shown at right is displayed during printing. Press DISP/BACK to cancel before all pictures are printed (depending on the printer, printing may end before the current picture has printed).



If printing is interrupted, press **D** to turn the camera off and then on again.

Disconnecting the Camera

Confirm that "PRINTING" is not displayed in the monitor and turn the camera off. Disconnect the USB cable.

- Print pictures from internal memory or a memory card that has been formatted in the camera
- If the printer does not support date printing, the **PRINT WITH DATE** option will not be available in the PictBridge menu and the date will not be printed on the pictures in the DPOF print order.
- When pictures are printed via direct USB connection, page size, print quality, and border selections are made using the printer.

Creating a DPOF Print Order

The PRINT ORDER (DPOF) option in the playback F-mode menu can be used to create a digital "print order" for PictBridge-compatible printers (pg. 57) or devices that support DPOF.

DPOF

DPOF (Digital Print Order Format) is standard that allows pictures to be printed from "print orders" stored in internal memory or on a memory card. The information in the order includes the pictures to be printed, date imprint, and the number of copies of each picture.

■ WITH DATE [/ WITHOUT DATE

To modify the DPOF print order, select ▶ PRINT ORDER (DPOF) in the playback F-mode menu and press the selector up or down to highlight WITH DATE or WITHOUT DATE.



Press **MENU/OK** and follow the steps below.

 Press the selector left or right to display a picture you wish to include in or remove from the print order.



Press the selector up or down to choose the number of copies (up to 99). To remove a picture from the order, press the selector down until the number of copies is 0.



■ Tip: Intelligent Face Detection

If the current picture was created with Intelligent Face Detection, pressing **Q** sets the number of copies to the number of faces detected.

← Note

When pictures are printed via direct USB connection, page size, print quality, and border selections are made using the printer.

3 Repeat steps 1–2 to complete the print order. Press **MENU/OK** to save the print order when settings are complete, or **DISP/BACK** to exit without changing the print order.



4 The total number of prints is displayed in the monitor. Press MENU/ OK to exit.



The pictures in the current print order are indicated by a

icon during playback.



- Remove the memory card to create or modify a print order for the pictures in internal memory.
- Print orders can contain a maximum of 999 pictures.
- If a memory card is inserted ■RESET DPOF OK? containing a print order created by another camera, the message shown at right will be displayed. Pressing MENU/ OR YES GACONO



OK cancels the print order; a new print order must be created as described above.

■ RESET ALL

To cancel the current print order, select **RESET ALL** in the **PRINT ORDER** (DPOF) menu. The confirmation shown at right will



be displayed; press **MENU/OK** to remove all pictures from the order.

Viewing Pictures on a Computer

The supplied FinePixViewer software can be used to copy pictures to a computer, where they can be stored, viewed, organized, and printed. Before proceeding, install FinePixViewer as described below. **Do** NOT **connect the camera to the computer until installation is complete**.

Installing FinePixViewer

FinePixViewer is available in Windows and Macintosh versions. Installation instructions for Windows are on pages 63–64, those for the Macintosh on pages 65–66.

Installing FinePixViewer: Windows

1 Confirm that the computer meets the following system requirements:

OS	Preinstalled versions of Windows Vista, Windows XP Home Edition (Service Pack 2), Windows XP Professional (Service Pack 2), or Windows 2000 Professional (Service Pack 4)			
	• Windows Vista: 800 MHz Pentium 4 or better (3 GHz Pentium 4 or better recommended)			
CPU	• Windows XP: 800 MHz Pentium 4 or better (2 GHz Pentium 4 or better recommended)			
	• Windows 2000: 200 MHz Pentium or better			
	Windows Vista: 512 MB or more (1 GB or more recommended)			
RAM	- Windows XP: 512 MB or more			
	• Windows 2000: 128 MB or more			
Free disk	A minimum of 450 MB required for installation with 600 MB available when FinePixViewer is running (15 GB or			
space	more recommended under Windows Vista, 2 GB or more recommended under Windows XP)			
Video	800×600 pixels or more with 16-bit color or better (1,024 × 768 pixels or more with 32-bit color recommended)			
	Built-in USB port recommended. Operation is not guaranteed with other USB ports.			
Other	• Internet connection (56 kbps or faster recommended) required to use FinePix Internet Service; Internet con-			
	nection and e-mail software required to use e-mail option.			

**** Caution

For information about Windows 7, visit http://www.fujifilm.com/support/download/camera/software/. Other versions of Windows are not supported. Operation is not guaranteed on home-built computers or computers that have been upgraded from earlier versions of Windows.

- **2** Start the computer. Log in to an account with administrator privileges before proceeding.
- **3** Exit any applications that may be running and insert the *FinePix* CD in a CD-ROM drive.

Windows Vista

If an AutoPlay dialog is displayed, click **SETUP.exe**. A "User Account Control" dialog will then be displayed; click **Allow**.

The installer will start automatically; click **Installing FinePixViewer** and follow the on-screen instructions to install FinePixViewer. Note that the Windows CD may be required during installation.

If the Installer Does Not Start Automatically

If the installer does not start automatically, select **Computer** or **My Computer** from the Start menu (Windows Vista/Windows XP) or double-click the **My Computer** icon on the desktop (Windows 2000), then double-click the **FINEPIX** CD icon to open the FINEPIX CD window and double-click **SETUP** or **SETUP.exe**.

- **4** If prompted to install Windows Media Player or DirectX, follow the on-screen instructions to complete installation.
- **5** When prompted, remove the *FinePix* CD from the CD-ROM drive and click **Restart** to restart the computer. Store the *FinePix* CD in a dry location out of direct sunlight in case you need to re-install the software. The version number is printed at the top of the CD label for reference when updating the software or contacting customer support.

Installation is now complete. Proceed to "Connecting the Camera" on page 67.

Installing FinePixViewer: Macintosh

1 Confirm that the computer meets the following system requirements:

CPU	PowerPC or Intel			
Pre-installed versions of Mac OS X version 10.3.9–10.5 (for the latest information, visit http://www.fujifilm.com/)				
RAM	256 MB or more			
Free disk space	e disk space A minimum of 200 MB required for installation with 400 MB available when FinePixViewer is running			
Video	800×600 pixels or more with thousands of colors or better			
	 Built-in USB port recommended. Operation is not guaranteed with other USB ports. Internet connection (56kbps or faster recommended) required to use FinePix Internet Service; Internet connection and e-mail software required to use e-mail option. 			

- 2 After starting the computer and quitting any applications that may be running, insert the FinePix CD in a CD-ROM drive. Double-click the **FinePix CD** icon on the desktop and double-click **Installer for Mac OS X**.
- **3** An installer dialog will be displayed; click **Installing FinePixViewer** to start installation. Enter an administrator name and password when prompted and click **OK**, then follow the on-screen instructions to install FinePixViewer. Click **Exit** to quit the installer when installation is complete.

- 4 Remove the FinePix CD from the CD-ROM drive. Note that you may be unable to remove the CD if Safari is running; if necessary, quit Safari before removing the CD. Store the FinePix CD in a dry location out of direct sunlight in case you need to re-install the software. The version number is printed at the top of the CD label for reference when updating the software or contacting customer support.
- **5** Select **Applications** in the Finder **Go** menu to open the applications folder. Double-click the **Image Capture** icon and select **Preferences...** from the Image Capture application menu.

About Image Capture Law Preferences
Services Preferences
Hide Cohere
Show All Quit Image Capture Mod
Use TWAN Software whenever possible

The Image Capture preferences dialog will be displayed. Choose **Other...** in the **When a camera is connected, open** menu, then select **FPVBridge** in the "Applications/FinePixViewer" folder and click **Open**.



Select **Quit Image Capture** from the Image Capture application menu.

Installation is now complete. Proceed to "Connecting the Camera" on page 67.

Connecting the Camera

1 If the pictures you wish to copy are stored on a memory card, insert the card into the camera (pg. 11). If no card is inserted, pictures will be copied from internal memory.

**** Caution

Loss of power during transfer could result in loss of data or damage to internal memory or the memory card. Charge the battery before connecting the camera

2 Turn the camera off and connect the supplied USB-A/V cable as shown, making sure the connectors are fully inserted. Connect the camera directly to the computer; do not use a USB hub or keyboard.



3 Press the ▶ button for about a second to turn the camera on. FinePixViewer will start automatically and the "Save Image Wizard" will be displayed. Follow the on-screen instructions to copy pictures to the computer. To exit without copying pictures, click **Cancel**.

**** Caution

If FinePixViewer does not start automatically, the software may not be correctly installed. Disconnect the camera and reinstall the software.

For more information on using FinePixViewer, select **How to Use FinePixViewer** in the FinePixViewer **Help** menu.

← Note

The camera will not turn off automatically while connected to a computer.

N Cautions

- Use only memory cards that have been formatted in the camera and contain pictures taken with the camera. If a memory card containing a large number of images is inserted, there may be a delay before FinePixViewer starts and FinePixViewer may be unable to import or save images. Use a memory card reader to transfer pictures.
- Make sure the indicator lamp is out before turning the camera off or disconnecting the USB cable. Failure to observe this precaution could result in loss of data or damage to internal memory or the memory card.
- Disconnect the camera before inserting or removing memory cards.
- Use FinePixViewer to copy voice memos.
- In some cases, it may not be possible to access pictures saved to a network server using FinePixViewer in the same way as on a standalone computer.
- The user bears all applicable fees charged by the phone company or Internet service provider when using services that require an Internet connection.

Disconnecting the Camera

After confirming that the indicator lamp is out, follow the on-screen instructions to turn the camera off and disconnect the USB cable.

Updating FinePixViewer

The latest version of FinePixViewer can be downloaded from http://www.fujifilm.com/.

Uninstalling FinePixViewer

Only uninstall FinePixViewer before reinstalling the software or when it is no longer required. After quitting FinePixViewer and disconnecting the camera, drag the "FinePixViewer" folder from "Applications" into the Trash and select **Empty Trash** in the **Finder** menu (Macintosh), or open the control panel and use "Programs and Features" (Windows Vista) or "Add or Remove Programs" (other versions of Windows) to uninstallFinePixViewer,FinePixResource,andFinePixStudio. Under Windows, one or more confirmation dialogs may be displayed; read the contents carefully before clicking **OK**.

Using the Menus: Shooting Mode

The \mathbf{F} -mode and shooting menus contain settings for a wide range of shooting conditions.

<u>Using the F-Mode Menu</u>

1 Press the **F** button to display the **F**-mode menu.



F-MODE MENU

2 183 ISO AUTO P

3 MAGE SIZE 4:3
EN MAGE QUALITY N

12 FINEPIX COLOR STD

2 Press the selector up or down to highlight the desired menu item.



Press the selector right to display options for the highlighted item.





4 Press the selector up or down to highlight the desired option.



5 Press **MENU/OK** to select the highlighted option.



F-Mode Menu Options

Menu item	Description	Options	Default
[<u>50</u> ISO	Adjust ISO sensitivity. Choose higher values when the subject is poorly lit.	AUTO/AUTO (400)/AUTO (800)/ 64/100/200/400/800/1600/ 3200 ([S])/6400 ([S])	AUTO
■ IMAGE SIZE	Choose image size and aspect ratio (pg. 71).	4:3/L 3:2/L 16:9/ M 4:3/M 3:2/M 16:9/ S 4:3/S 3:2/S 16:9/	4:3
MAGE QUALITY	Choose image quality (pg. 72).	F/N	N
FINEPIX COLOR	Shoot pictures in standard or saturated color or in black-and-white (pg. 72).	STD/Ġ₽/Ġ₽	STD

ISO ISO

Control the camera's sensitivity to light. Higher values can be used to reduce blur when lighting is poor; note, however, that mottling may appear in pictures taken at high sensitivities. If **AUTO**, **AUTO** (800), or **AUTO** (400) is selected, the camera will adjust sensitivity automatically in response to shooting conditions. The maximum values that will be selected by the camera at settings of **AUTO** (800) and **AUTO** (400) are 800 and 400 respectively.

Settings other than **AUTO** are shown by an icon in the display.

← Note

Sensitivity is not reset when the camera is turned off or another shooting mode is selected.



IMAGE SIZE

Choose the size and aspect ratio at which still pictures are recorded. Large pictures can be printed at large sizes with no drop in quality; small pictures require less memory, allowing more pictures to be recorded.

Option	Prints at sizes up to
4:3 (4,000×3,000)	34×25 cm (13.5×10 in.)
3:2 (4,000×2,664)	34×23 cm (13.5×9 in.)
16:9 (4,000 × 2,248)	34×19 cm (13.5×7.5 in.)
M 4:3 (2,816×2,112)	$24 \times 18 \text{ cm } (9.5 \times 7 \text{ in.})$
M 3:2 (2,816×1,864)	24×16 cm (9.5×6 in.)
M 16:9 (2,816 × 1,584)	24×13 cm (9.5×5.5 in.)
S 4:3 (2,048 × 1,536)	17 × 13 cm (7 × 5 in.)
S 3:2 (2,048 × 1,360)	17 × 12 cm (7 × 4.5 in.)
S 16:9 (1,920 × 1,080)	16×9 cm (6.5×3.5 in.)

The number of pictures that can be taken at the selected setting is shown at the bottom of the display (pg. 116).



Aspect Ratio

Pictures with an aspect ratio of 4:3 have the same proportions as the camera display. Pictures with an aspect ratio of 3:2 have the same proportions as a frame of 35-mm film, while an aspect ratio of 16:9 is suited to display on High Definition (HD) devices.



4:3





1

← Note

Image size is not reset when the camera is turned off or another shooting mode is selected.

MAGE QUALITY

Choose how much image files are compressed. Select **FINE** (low compression) for higher image quality, **NORMAL** (high compression) to increase the number of pictures that can be stored.

FINEPIX COLOR

Enhance contrast and color saturation or take pictures in black and white.

Option	Description	
F-STANDARD	Standard contrast and saturation.	
F-STANDAND	Recommended in most situations.	
	Vivid contrast and color. Choose for vivid shots of flowers or en- hanced greens and blues in land-	
Ġ= C CUDOME	for vivid shots of flowers or en-	
GF / -CHROME	hanced greens and blues in land-	
	scapes.	
Ē₽ F -B&W	Take pictures in black and white.	

Settings other than **F-STANDARD** are shown by an icon in the display.

← Notes

- FINEPIX COLOR is not reset when the camera is turned off or another shooting mode is selected.
- The effects of **GF F-CHROME** vary from scene to scene and may be difficult to discern with some subjects. Depending on the subject, the effects of **GF F-CHROME** may not be visible in the display.

Using the Shooting Menu

Press MENU/OK to display the shooting menu.



7 Press the selector up or down to highlight the desired menu item.



3 Press the selector right to display options for the highlighted item.





⚠ Press the selector up or down to highlight the desired option.



Press MENU/OK to select the highlighted option.



Shooting Menu Options

Menu item	Description	Options	Default
SCENE POSITION	Choose a scene for SP mode (pg. 35).	ጭ/ጭ4//❷/♣/▲/ጲ/ (+/ጲ*/◎/盐/ጭ/ሷ/ጞ/ */	•
SELF-TIMER	Take pictures with the self-timer (pg. 75).	10 SEC/2 SEC/OFF	OFF
	Choose how the camera meters exposure (pg. 76).	@/[•]/[]	0
WB WHITE BALANCE	Adjust color for different light sources (pg. 77).	AUTO/□/☀/卷/ ∺/治/治/杂	AUT0
■ HIGH-SPEED SHOOTING	Choose for quick shutter response (pg. 78).	ON/OFF	OFF
■ FOCUSING	Choose a focus mode (pg. 78).	□/ +	+
ATE AF MODE	Choose how the camera selects a focus area (pg. 79).	⊕/+/⊹/⊑	
SHARPNESS	Choose whether to sharpen or soften outlines (pg. 80).	HARD/STD/SOFT	STD
₹ FLASH	Adjust flash brightness (pg. 80).	-¾ EV - +¾ EV in steps of ⅓ EV	0
BRACKETING	Choose the size of the bracketing increment when t is selected in continuous shooting mode (pg. 80).	±1/3 EV / ±2/3 EV / ±1 EV	±1/3 EV
CUSTOM SET	Save settings for P , S , A , and M modes (pg. 45).	_	_
SET SET-UP	Perform basic camera setup such as choosing a language and setting the time and date (pg. 93).	1 / 2 1/ 2 2/ 2 3	_

SELF-TIMER

Choose the duration for the self-timer. The self-timer is available in all shooting modes.

- **10 SEC**: Choose for self-portraits or for group portraits that include the photographer.
- **2SEC**: Choose to avoid blur caused by the camera moving when the shutter button is pressed.
- OFF: Self-timer off.

To use the self-timer, choose **10 SEC** or **2 SEC** from the self-timer menu and follow the steps below.

1 Focus.

Press the shutter button halfway to focus.




**** Caution


Stand behind the camera when using the shutter button. Standing in front of the lens can interfere with focus and exposure.

2 Start the timer.

Press the shutter button the rest of the way down to start the timer. The display shows the number of seconds remaining until the shutter is released. To stop the timer before the picture is taken, press **DISP/BACK**.



The self-timer lamp on the front of the camera will blink immediately before the picture is taken. If the two-second timer is selected, the self-timer lamp will blink as the timer counts down.



Intelligent Face Detection

Because it ensures that the faces of portrait subjects will be in focus, Intelligent Face Detection (pg. 22) is recommended when using the self-timer for group portraits or self-portraits. To use the self-timer with Intelligent Face Detection, select **10 SEC** or **2 SEC** in the self-timer menu and then press the shutter button all the way down to start the timer. The camera will detect faces while the timer is counting down and adjust focus and exposure immediately before the shutter is released. Be careful not to move until the picture has been recorded.

← Note

The self-timer turns off automatically when the picture is taken, a different shooting mode is selected, playback mode is selected, or the camera is turned off.

回 PHOTOMETRY

Choose how the camera meters exposure when Intelligent Face Detection is off.

- MULTI: Automatic scene recognition is used to adjust exposure for a wide range of shooting conditions.
- **SPOT**: The camera meters lighting conditions at the center of the frame. Recommended when the background is much brighter or darker than the main subject. Can be used with focus lock (pg. 24) to meter off-center subjects.
- [] AVERAGE: Exposure is set to the average for the entire frame. Provides consistent exposure across multiple shots with the same lighting, and is particularly effective for landscapes and portraits of subjects dressed in black or white.

WI WHITE BALANCE

For natural colors, choose a setting that matches the light source (for an explanation of "white balance," see the Glossary on page 115).

Option	Description
AUTO	White balance adjusted automatically.
D.	Measure a value for white balance.
*	For subjects in direct sunlight.
*	For subjects in the shade.
₩1	Use under "daylight" fluorescent lights.
₩2	Use under "warm white" fluorescent lights.
岩	Use under "cool white" fluorescent lights.
- Д -	Use under incandescent lighting.

If **AUTO** does not produce the desired results (for example, when taking close-ups), select \square and measure a value for white balance or choose the option that matches the light source.

- At settings other than \square , auto white balance is used with the flash. Lower the flash (pg. 27) to take pictures at other settings.
- Results vary with shooting conditions. Play pictures back after shooting to check colors in the monitor.

■ 🖳: Custom White Balance

Choose 📮 to adjust white balance for unusual lighting conditions. The options at right will be displayed; frame a white object so that it fills



the monitor and press the shutter button all the way down to measure white balance.

If "COMPLETED!" is displayed, press MENU/OK to set white balance to the measured value. This value can be reselected by pressing MENU/OK when custom white balance options are displayed.

If "UNDER" is displayed, raise exposure compensation (pg. 33) and try again.

If "OVER" is displayed, lower exposure compensation and try again.

▼ TipTo give a deliberate color cast to your photographs, measure a value for custom white balance using a colored instead of a white object.

団 HIGH-SPEED SHOOTING

Selecting **ON** reduces focusing time, ensuring a quick shutter response.

← Notes

- Choosing **ON** increases the drain on the battery. Choose **OFF** to save battery power.
- The **EVF/LCD MODE** option in the setup menu is automatically set to **60 fps** when high-speed shooting is on (pg. 94).

FI FOCUSING


Choose how the camera focuses.

- © CONTINUOUS AF: The camera continually adjusts focus to reflect changes in the distance to the subject even when the shutter button is not pressed (note that this increases the drain on the battery). Intelligent Face Detection turns off automatically and AF MODE is fixed at © CENTER. Choose for moving subjects.
- **SINGLE AF**: Focus locks while the shutter button is pressed halfway. Choose for stationary subjects.

M AF MODE

This option controls how the camera selects the focus area when Intelligent Face Detection is off (pg. 21). Regardless of the option selected, the camera will focus on the subject in the center of the monitor when macro mode is on (pg. 26).

• 🔳 CENTER: The camera focuses on the subject in the center of the frame. This option can be used with focus lock.



• **H** MULTI: When the shutter button is pressed halfway, the camera detects high-contrast subjects near the center of the frame and selects the focus area automatically (if the focus frame is not displayed, select

CENTER and use focus lock; pg. 24).







Focus frame

• AREA: The focus position can be chosen manually by pressing the selector up, down, left, or right and pressing MENU/OK when the



focus brackets are in the desired position. Choose for precise focus when the camera is mounted on a tripod. Note that exposure is set for the subject in the center of the frame; to meter an offcenter subject, use AF/AE lock (pg. 24).

• TRACKING: Position the subject in the center focus area and press the shutter button halfway to focus. Program Shift 80 F2.8 Keep the shutter button



pressed to track the subject as it moves through the frame. Choose for erratically moving subjects.

SHARPNESS

Choose whether to sharpen or soften outlines.


 HARD: Use for sharp outlines when photographing such subjects as buildings and text.



- **STANDARD**: Standard sharpness. Best choice in most situations.
- **SOFT**: Use for soft outlines in portraits and similar subjects.

理 FLASH

Adjust flash brightness. Choose from values between +2/3 EV and -2/3 EV. The default setting is ±0. Note that the desired results may



not be achieved depending on shooting conditions and the distance to the subject.

□ BRACKETING

Choose the size of the exposure bracketing increment used when • (bracketing) is selected in continuous shooting mode (pg. 29).



Choose from increments of $\pm \frac{1}{3}$ EV, $\pm \frac{2}{3}$ EV, and ± 1 EV (for an explanation of the term "EV," see the Glossary on page 115).

Using the Menus: Playback Mode

The \mathbf{F} -mode and playback menus are used to manage the pictures in internal memory or on the memory card.

<u>Using the F-Mode Menu</u>

- 1 Press the ▶ button to enter playback mode.
- **2** Press the **F** button to display the **F**-mode menu.





3 Press the selector up or down to highlight the desired menu item.



Press the selector right to display options for the highlighted item.





5 Press the selector up or down to highlight the desired option.



6 Press **MENU/OK** to select the highlighted option.



F-Mode Menu Options

Option	Description	
■ SLIDE SHOW	View pictures in a slide show (see below).	
PRINT ORDER (DPOF)	Select pictures for printing on DPOF- and PictBridge-compatible devices (pg. 57).	

園 SLIDE SHOW

View pictures in an automated slide show. Choose the type of show and press **MENU/OK** to start. Press **DISP/BACK** at any time during the show to view on-screen help. When a movie is displayed, movie playback will begin automatically, and the slide show will continue when the movie ends. The show can be ended at any time by pressing **MENU/OK**.

Option	Displayed in
NORMAL	Press selector left or right to go back or skip ahead one frame. Select FADE-IN for fade transitions between
FADE-IN	frames.
NORMAL [2]	As above, except that camera automatically zooms in on faces selected with Intelligent Face detection.
FADE-IN 🖭	ans above, except that carriera automatically 200ms in ornaces selected with intelligent race detection.
MULTIPLE	Display several pictures at once.

← Note

The camera will not turn off automatically while a slide show is in progress.

Using the Playback Menu

Press **▶** to enter playback mode.



Press **MENU/OK** to display the playback menu.



PLAYBACK MENU

THE BRASE

TO RED EYE REMOVAL

MAGE ROTATE

COPPORT

VOICE MEMO

Press the selector up or down to highlight the desired menu item.



Press the selector right to display options for the highlighted item.





PLAYBACK MENU

Press the selector up or down to highlight the desired option.



Press **MENU/OK** to select the highlighted option.



Playback Menu Options

The following options are available:

The following options are available.			
Option	Description		
m ERASE	Delete all or selected pictures (pg. 50).		
RED-EYE REMOVAL	Create copies with reduced red eye (pg. 84).		
2 IMAGE ROTATE	Rotate pictures (pg. 85).		
■ PROTECT	Protect pictures from accidental deletion (pg. 86).		
COPY COPY	Copy pictures between internal memory and a memory card (pg. 87).		
☑ VOICE MEMO	Add voice memos to pictures (pg. 89).		
□ CROP	Create cropped copies of pictures (pg. 91).		
RESIZE	Create small copies of pictures (pg. 92).		
SII SET-UP	Perform basic camera setup (pg. 93).		

▼ RED EYE REMOVAL

If the current picture is marked with a **!** icon to indicate that it was taken with Intelligent Face Detection, this option can be used to remove redeye. The camera will analyze the image; if red-eye is detected, the image will be processed to create a copy with reduced red-eye.





← Notes

- Red eye may not be removed if the camera is unable to detect a face or the face is in profile. Results may differ depending on the scene. Red eye can not be removed from pictures that have already been processed using red-eye removal or pictures created with other devices.
- The amount of time needed to process the image varies with the number of faces detected.

MAGE ROTATE

By default, pictures taken in tall orientation are displayed in wide orientation. Use this option to display pictures in the correct orientation in the



monitor. It has no effect on pictures displayed on a computer or other device.

- Protected pictures can not be rotated. Remove protection before rotating pictures (pg. 86).
- The camera may not be able to rotate pictures created with other devices.

To rotate a picture, play the picture back and select **DIMAGE ROTATE** in the playback menu (pg. 83).

1 Press the selector down to rotate the picture 90° clockwise, up to rotate the picture 90° counterclockwise.





2 Press **MENU/OK** to confirm the operation (to exit without rotating the picture, press **DISP/BACK**).



The next time the picture is played back, it will automatically be rotated.

PROTECT

Protect pictures from accidental deletion. The following options are available.

■ FRAME

Protect selected pictures.

1 Press the selector left or right to display the desired picture.







Picture not protected

Protected picture

- Press MENU/OK to protect the picture. If the picture is already protected, pressing MENU/OK will remove protection from the image.
- **3** Repeat steps 1–2 to protect additional images. Press **DISP/BACK** to exit when the operation is complete.



■ SET ALL

Press **MENU/OK** to protect all pictures, or press **DISP/BACK** to exit without changing picture status.



■ RESET ALL

Press **MENU/OK** to remove protection from all pictures, or press **DISP/BACK** to exit without changing picture status.



If the number of pictures affected is very large, the display at right will appear in the monitor while the operation is in progress. Press **DISP/BACK**



to exit before the operation is complete.

**** Caution

Protected pictures will be deleted when the memory card or internal memory is formatted (pg. 98).

MY COPY

Copy pictures between internal memory and a memory card.

- 1 Press the selector up or down to highlight INTERNAL MEMORY

 → IN CARD (copy pictures from internal memory to the memory card) or

 INTERNAL MEMORY (copy pictures from a memory card to internal memory).
- **2** Press the selector right to display options for the highlighted item.





3 Press the selector up or down to highlight **FRAME** or **ALL FRAMES**.



4 Press MENU/OK.



Tip: Copying Pictures Between Memory Cards

To copy pictures between two memory cards, insert the source card and copy the pictures to internal memory, then remove the source card, insert the destination card, and copy the pictures from internal memory.

■ FRAME

Copy selected frames.



1 Press the selector left or right to display the desired picture.



7 Press **MENU/OK** to copy the picture.



3 Repeat steps 1–2 to copy additional images. Press **DISP/BACK** to exit when the operation is complete.



■ ALL FRAMES

Press **MENU/OK** to copy all pictures, or press **DISP/BACK** to exit without copying pictures.



**** Cautions

- Copying ends when the destination is full.
- DPOF print information is not copied (pg. 58).

VOICE MEMO


To add a voice memo to a still picture, select **VOICE MEMO** after displaying the picture in playback mode.



← Note


Voice memos can not be added to movies or protected pictures. Remove protection from pictures before recording voice memos (pg. 86).

1 Hold the camera at a distance of about 20 cm (8 in.) and face the microphone.



7 Press **MENU/OK** to start recording.





3 Press **MENU/OK** again to end recording. Recording ends automatically after 30 seconds.






← Notes

- If a voice memo already exists for the current picture, the options at right will be displayed. Select **RE-REC** to replace the existing memo.
- Voice memos are recorded as PCM-format WAV files (pg. 115).



Playing Voice Memos

Pictures with voice memos are indicated by a ② icon during playback. To play the voice memo, press the selector down. To pause, press the selector down again; to end playback, press the selector up. Press the selector left to rewind, right to fast forward. Volume controls can be displayed by pressing the MENU/OK button; press the selector up or down to adjust the volume, and press MENU/OK again to resume playback.




← Note

The camera may not play voice memos recorded with other devices.

N Caution

Do not cover the speaker during playback.




CROP

To create a cropped copy of a picture, play the picture back and select **CROP** in the playback menu (pg. 83).

1 Use the zoom control to zoom in and out and use the selector to scroll the picture until the desired portion is displayed (to exit to singleframe playback without creating a cropped copy, press DISP/BACK).

Zoom indicator





Navigation window shows portion of image currently displayed in monitor

If the size of the final copy will be **S**, **YES** will be displayed in yellow.

▼ Tip: Intelligent Face Detection

If the picture was shot with Intelligent Face Detection (pg. 21), will be displayed in the monitor. Press the button to zoom in on the selected face



2 Press **MENU/OK**. A confirmation dialog will be displayed.





Copy size is shown at the top of the display. Larger crops produce larger copies; all copies have an aspect ratio of 4:3.

3 Press **MENU/OK** to save the cropped copy to a separate file.



← Note

Pictures taken with other cameras can not be cropped.

RESIZE

To create a small copy of a picture, play the picture back and select **RESIZE** in the playback menu (pg. 83).

1 Press the selector up or down to highlight 640 STANDARD or 820 SMALL.



2 Press **MENU/OK** to select the high-lighted option.



3 Press **MENU/OK** to copy the picture at the selected size.



The Setup Menu

Using the Setup Menu

- Display the setup menu.
 - 1.1 Press MENU/OK to display the menu for the current mode.



1.2 Press the selector up or down to highlight SET-UP.



1.3 Press the selector right to display the setup menu.





- **7** Choose a page.
 - 2.1 Press the selector left or right to choose a page.



2.2 Press the selector down to enter the menu.




- **?** Adjust settings.
 - **3.1** Press the selector up or down to highlight a menu item.



3.2 Press the selector right to display options for the highlighted item.





3.3 Press the selector up or down to highlight an option.



3.4 Press MENU/OK to select the highlighted option.





Setup Menu Options

	Menu item	Description	Options	Default
	IMAGE DISP.	Choose how long pictures are displayed after shooting (pg. 95).	CONT/3 SEC/1.5 SEC/ ZOOM/OFF	1.5 SEC
	TRAME NO.	Choose how files are named (pg. 96).	CONT. / RENEW	CONT.
	DUAL IS MODE	Enable image stabilization during shooting (**) CONTINUOUS) or only when the shutter button is pressed halfway (**) 2 SHOOTING ONLY). OFF turns image stabilization off (pg. 17).	« 4 »₁/« 4 »₂/ 0FF	(()) 1
	A≅ AF ILLUMINATOR	Turn the AF-assist illuminator on or off (pg. 25).	ON/OFF	ON
	☑ DIGITAL ZOOM	Enable or disable digital zoom (pg. 97).	ON/OFF	OFF
	EVF/LCD MODE	Choose 30 fps to increase battery life, 60 fps for improved display quality.	30 fps / 60 fps	30 fps
	DATE/TIME	Set the camera clock (pg. 14).	_	_
	OPERATION VOL.	Adjust the volume of camera controls.	◄•1) (high) / •••• (mid) /	40
	SHUTTER VOLUME	Adjust the volume of the shutter sound.	-(low) / -(oFF (mute)	14.1
	PLAYBACK VOLUME	Adjust the volume for movie and voice memo playback (pg. 97).	_	7
	AUTOROTATE PB	Choose 0N to automatically rotate "tall" (portrait-orientation) pictures during playback.	ON/OFF	ON
	LCD BRIGHTNESS	Control the brightness of the display (pg. 97).	- 5 - +5	0
	FORMAT	Format internal memory or memory cards (pg. 98).	_	
	® 言語/LANG.	Choose a language (pg. 14).	See page 120	ENGLISH
£ 2	AUTO POWER OFF	Choose the auto power off delay (pg. 98).	2 MIN/5 MIN/OFF	2 MIN
202	TIME DIFFERENCE	Set the clock to local time (pg. 99).	☆ / +	企
	BACKGROUND COLOR	Choose a color scheme.	_	
	■ BATTERY TYPE	Specify the type of battery used in the camera (pg. 9).	dA/dN/dL	(A)

	Menu item	Description	Options	Default
	DISCHARGE	Discharge rechargeable Ni-MH batteries (pg. 100).		_
	WWW VIDEO SYSTEM	Choose a video mode for connection to a TV (pg. 55).	NTSC/PAL	_
-	RESET	Reset all settings except ATE/TIME, TIME DIFFERENCE, BACKGROUND COLOR, BATTERY TYPE, and VIDEO SYSTEM to default values. A confirmation dialog will be displayed, press the selector left or right to highlight OK and press MENU/OK.		_
	© CUSTOM RESET	Reset all settings for mode C . A confirmation dialog will be displayed, press the selector left or right to highlight OK and press MENU/OK .		_

☑ IMAGE DISP.

Choose an option other than **OFF** to display pictures in the monitor after shooting. Pictures can be displayed for 1.5 s (**1.5 SEC**), 3 s (**3 SEC**), or until the **MENU/OK** button is pressed (**CONTINUOUS** and **ZOOM** (**CONTINUOUS**). If **CONTINUOUS** is selected, the button can be used to check exposure (pg. 48). If **ZOOM** (**CONTINUOUS**) is selected, photos can be zoomed in to check focus and other fine details (see page 47). Note that **ZOOM** (**CONTINUOUS**) is disabled in continuous shooting mode (pg. 29), and that the colors displayed at settings of **1.5 SEC** and **3 SEC** may differ from those in the final picture.

← Note


Pictures taken at continuous shooting modes of \P , \P , and \P are always displayed after shooting. Pictures taken in other continuous shooting modes are recorded without being displayed.

Blink Detection (pg. 23)

At settings other than **OFF**, a warning will be displayed if the camera detects subjects who may have blinked when the picture was taken. If **ZOOM** (**CONTINUOUS**) is selected, you can view these subjects using zoom.

I FRAME NO.

New pictures are stored in image files named using a four-digit file number assigned by adding one to the last file number used. The file number is displayed during playback as shown at right. **FRAME NO.** controls whether file numbering is reset to 0001 when a new memory card is inserted or the current memory card or internal memory is formatted.




- **CONTINUOUS**: Numbering continues from the last file number used or the first available file number, whichever is higher. Choose this option to reduce the number of pictures with duplicate file names.
- RENEW: Numbering is reset to 0001 after formatting or when a new memory card is inserted.

★ Notes

- If the frame number reaches 999-9999, the shutter release will be disabled (pg. 113).
- Selecting RESET (pg. 95) resets FRAME NO. to CONTINUOUS but does not reset frame numbering.
- Frame numbers for pictures taken with other cameras may differ.

QI DIGITAL ZOOM

If **ON** is selected, selecting **T** at the maximum optical zoom position will trigger digital zoom, further magnifying the image. To cancel digital zoom, zoom out to the minimum digital zoom position and select **W**.




**** Caution

Digital zoom produces lower quality images than optical zoom.

TN PLAYBACK VOLUME

Press the selector up or down to choose volume for movie and voice memo playback and press **MENU/OK** to select.



IDENTIFY AND SET OF S

Press the selector up or down to choose display brightness and press **MENU/OK** to select.



■ FORMAT

Format internal memory or a memory card. If a memory card is inserted in the camera, will be displayed in the dialog shown at right



and this option will format the memory card. If no memory card is inserted, will be displayed and this option will format internal memory. Press the selector left to highlight **OK** and press **MENU/OK** to begin formatting.

N Cautions

- All data—including protected pictures—will be deleted. Be sure important files have been copied to a computer or other storage device.
- Do not open the battery cover during formatting.

AUTO POWER OFF

Choose the length of time before the camera turns off automatically when no operations are performed. Shorter times increase battery life; if **OFF** is selected, the camera must be turned off manually. Note that regardless of the option selected, the camera will not turn off automatically when connected to a printer (pg. 57) or computer (pg. 67) or when a slide show is in progress (pg. 82).

■ Tip: Reactivating the Camera

To reactivate the camera after it has turned off automatically, use the **ON/OFF** switch or press the **D** button for about a second (pg. 13).

TIME DIFFERENCE

When travelling, use this option to switch the camera clock instantly from your home time zone to the local time at your destination.

- **1** Specify the difference between local time and your home time zone.
 - **1.1** Press the selector up or down to highlight **+** LOCAL.



1.2 Press the selector right to display the time difference.





1.3 Press the selector left or right to highlight +, –, hours, or minutes; press up or down to edit. The minimum increment is 15 minutes.




1.4 Press **MENU/OK** when settings are complete.



2 Switch between local time and your home time zone.

To set the camera clock to local time, highlight ← LOCAL and press MENU/OK. To set the clock to the time in your home time zone, select ♠ HOME. If ← LOCAL is selected, ← will be displayed in the monitor for three seconds after the camera enters shooting mode, and the date will be displayed in yellow.



After changing time zones, check that the date and time are correct.

■ DISCHARGE (Ni-MH Batteries Only)

The capacity of rechargeable Ni-MH batteries may be temporarily reduced when new, after long periods of disuse, or if they are repeatedly re-



charged before being fully discharged. Capacity can be increased by repeatedly discharging the batteries using the DISCHARGE option and recharging them in a battery charger (sold separately). Do not use DISCHARGE with non-rechargeable batteries, and note that the batteries will not discharge if the camera is powered by an optional AC adapter and DC coupler.

1 Selecting DISCHARGE displays the message shown above. Press MENU/OK.



2 Press the selector left or right to highlight **OK**.




Press MENU/OK to begin discharging the batteries. When the batteries are fully discharged, the battery level indicator will blink red and the camera will turn off. To cancel the process before the batteries are fully discharged, press DISP/BACK.



Optional Accessories

The camera supports a wide range of accessories from FUJIFILM and other manufacturers.



Accessories from FUJIFILM

The following optional accessories are available from FUJIFILM. For the latest information on the accessories available in your region, check with your local FUJIFILM representative or visit http://www.fujifilm.com/products/digital_cameras/index.html.

AC power adapter	AC-5VX (requires CP-04 DC coupler)	Use for extended playback or when copying pictures to a computer (shape of adapter and plug vary with region of sale).	
DC coupler	CP-04	Connect the AC-5VX AC power adapter to the camera.	

Caring for the Camera

To ensure continued enjoyment of the product, observe the following precautions.

Storage and Use

If the camera will not be used for an extended period, remove the battery and memory card. Do not store or use the camera in locations that are:

- exposed to rain, steam, or smoke
- very humid or extremely dusty
- exposed to direct sunlight or very high temperatures, such as in a closed vehicle on a sunny day
- extremely cold
- subject to strong vibration
- exposed to strong magnetic fields, such as near a broadcasting antenna, power line, radar emitter, motor, transformer, or magnet
- in contact with volatile chemicals such as pesticides
- next to rubber or vinyl products

■ Water and Sand

Exposure to water and sand can also damage the camera and its internal circuitry and mechanisms. When using the camera at the beach or seaside, avoid exposing the camera to water or sand. Do not place the camera on a wet surface.

■ Condensation

Sudden increases in temperature, such as occur when entering a heated building on a cold day, can cause condensation inside the camera. If this occurs, turn the camera off and wait an hour before turning it on again. If condensation forms on the memory card, remove the card and wait for the condensation to dissipate.

Cleaning

Use a blower to remove dust from the lens and monitor, then gently wipe with a soft, dry cloth. Any remaining stains can be removed by wiping gently with a piece of FUJIFILM lens-cleaning paper to which a small amount of lens-cleaning fluid has been applied. Care should be taken to avoid scratching the lens or monitor. The camera body can be cleaned with a soft, dry cloth. Do not use alcohol, thinner, or other volatile chemicals.

Traveling

Keep the camera in your carry-on baggage. Checked baggage may suffer violent shocks that could damage the camera.

Troubleshooting

Power and Battery

	Problem	Possible cause	Solution	Page	
		The batteries are exhausted.	Insert fresh or fully-charged spare batteries.	8	
		The batteries are not in the correct orientation.	Re-insert the batteries in the correct orientation.	8	
	The camera does	The battery-chamber cover is not latched.	Latch the battery-chamber cover.	9	
	not turn on.	The AC adapter and DC coupler are not connected properly.	Make sure that the AC adapter and DC coupler are properly connected.	_	
			After inserting the batteries or connecting the AC adapter/DC coupler, wait a few moments before turning the camera on.		
		The batteries are cold.	Warm the batteries by placing them in a pocket or other warm place and re-insert them in the camera immediately before taking a picture.		
ower		There is dirt on the battery terminals.	Clean the terminals with a soft, dry cloth.	_	
upply		The camera is in SRAUTO mode.	Select another shooting mode.	35	
оррту	The batteries run down quickly.	for an extended period, or have been re-	Discharge Ni-MH batteries using the DISCHARGE option and recharge them in a battery charger (sold separately). If the batteries do not hold a charge after repeated discharging and recharging, they have reached the end of their service life and must be replaced.	100	
		HIGH SPEED SHOOTING is on.	Turn Image HIGH SPEED SHOOTING off to reduce the drain on the battery.	78	
		□ CONTINUOUS AF is selected for ■ FO- CUSING.	Select a different focusing option.	78	
	The camera turns	The batteries are exhausted.	Insert fresh or fully-charged spare batteries.	8	
		off suddenly.	The AC adapter or DC coupler has been disconnected.	Make sure that the AC adapter and DC coupler are properly connected.	_

Menus and Displays

Problem	Possible cause	Solution	Page
Menus and displays are	English is not selected for the 図言語/LANG.	Soloct ENGLISH	14, 94
not in English.	option in the setup menu.	Select LINGLISH .	14, 34

Shooting

	Problem	Possible cause	Solution	Page
		Memory is full.	Insert a new memory card or delete pictures.	11, 50
	No picture is taken when	Memory is not formatted.	Format the memory card or internal memory.	98
	taken when	There is dirt on the memory card contacts.	Clean the contacts with a soft, dry cloth.	_
Taking	button is	The memory card is damaged.	Insert a new memory card.	11
pictures	pressed.	The batteries are exhausted.	Insert fresh or fully-charged spare batteries.	8
pictures		The camera has turned off automatically.	Turn the camera on.	13
	The monitor goes dark after shooting.	The flash has fired.	The monitor may darken while the flash charges. Wait for the flash to charge.	27
Focus	The camera	The subject is close to the camera.	Select macro mode.	26
	does not	The subject is far away from the camera.	Cancel macro mode.	20
	focus.	The subject is not suited to autofocus.	Use focus lock.	24

	Problem	Possible cause	Solution	Page
	Face detection not available.	Intelligent Face Detection is not available in the current shooting mode.	Choose a different shooting mode.	35
	riot available.	The subject's face is obscured by sunglasses, a hat, long hair, or other objects.	Remove the obstructions.	
Intelligent Face	No face is	The subject's face occupies only a small area of the frame.	Change the composition so that the subject's face occupies a larger area of the frame.	21
Detection	detected.	The subject's head is tilted or horizontal.	Ask the subject to hold their head straight.	
		The camera is tilted.	Hold the camera straight.	16
		The subject's face is poorly lit.	Shoot in bright light.	_
	Wrong subject selected.	The selected subject is closer to the center of the frame than the main subject.	Recompose the picture or turn face detection off and frame the picture using focus lock.	21, 24
Close-ups	Macro mode is not available.	Macro mode is not available in the current shooting mode.	Choose a different shooting mode.	26, 35
	The flash does	The flash is lowered.	Raise the flash.	27
		The flash is charging.	Wait for the flash to charge.	27
		The flash is not available in the current shooting mode.	Choose a different shooting mode.	35
	lilotille.	The batteries are exhausted.	Insert fresh or fully-charged spare batteries.	8
Flash		The camera is in super macro or continuous shooting mode.	Turn super macro and continuous shooting modes off.	26, 29
	Flash mode not available.	The desired flash mode is not available in the current shooting mode.	Choose a different shooting mode.	35
	The flash does	The subject is not in range of the flash.	Position the subject in range of the flash.	120
	not fully light	The flash window is obstructed.	Hold the camera correctly.	16
	the subject.	Fast shutter speed selected.	Choose a slower shutter speed.	40, 42

	Problem	Possible cause	Solution	Page
		The lens is dirty.	Clean the lens.	103
	Pictures are	The lens is blocked.	Keep objects away from the lens.	16
	blurred.	!AF is displayed during shooting and the focus frame is displayed in red.	Check focus before shooting.	111
		🔯 is displayed during shooting.	Use the flash or a tripod.	27–28
	Pictures are mottled.	The ambient temperature is high and the subject is poorly lit.	This is normal and does not indicate a malfunction.	70
Problem images	Vertical lines appear in pictures.	The camera has been used continuously at high temperatures.	Turn the camera off and wait for it to cool down.	
	Smear appears in pictures.	The sun or another bright object was in the frame.	White or purple vertical lines may appear when a very bright object is framed in the display. This is normal and does not indicate a malfunction. Smear is not recorded in photographs but may appear in movies. If possible, avoid shooting movies with bright objects in or close to the frame.	115
Recording	Pictures are not recorded.	Power was interrupted during shooting.	Turn the camera off before connecting the AC adapter/DC coupler. Leaving the camera on can result in corrupted files or damage to the memory card or internal memory.	
Continuous shooting mode	Only one picture is taken.	The self timer is on and an option 🚡 and 🖳 are selected in continuous shooting mode.	Turn the self-timer off.	75

Playback

	Problem	Possible cause	Solution	Page
Pictures	Pictures are grainy.	The pictures were taken with a different make or model of camera.	_	
	Playback zoom unavailable.	The picture has been resized or cropped to 640 or is from another make or model of camera.	_	47
	No sound in	The camera is in silent mode.	Turn silent mode off.	18
Audio	voice memo	Playback volume is too low.	Adjust playback volume.	97
Addio	and movie	The microphone was obstructed.	Hold the camera correctly during recording.	52, 89
	playback.	The speaker is obstructed.	Hold the camera correctly during playback.	54, 90
Deletion	Selected pictures not deleted.	Some of the pictures selected for deletion are protected.	Remove protection using the device with which it was originally applied.	86
Frame no.	File number- ing is unex- pectedly reset.	The battery-chamber cover was opened while the camera was on.	Turn the camera off before opening the bat- tery-chamber cover.	8

Connections

	Problem	Possible cause	Solution	Page
	Monitor is off.	The camera is connected to a TV.	View pictures on the TV.	56
		The camera is not properly connected.	Connect the camera correctly.	55
	No picture or	An A/V cable was connected during movie playback.	Connect the camera once movie playback has ended.	54, 55
TV	sound.	Input on the television is set to "TV".	Set input to "VIDEO".	
1 V	Souria.	The camera is not set to the correct video standard.	Match the camera \blacksquare VIDEO SYSTEM setting to the TV.	95
		The volume on the television is too low.	Adjust the volume.	_
	No color.	The camera is not set to the correct video standard.	Match the camera \blacksquare VIDEO SYSTEM setting to the TV.	95
Computer	The computer does not recognize the camera.	The camera is not properly connected.	Connect the camera correctly.	67
	Pictures can	The camera is not properly connected.	Connect the camera correctly.	57
	not be printed.	The printer is off.	Turn the printer on.	_
PictBridge	Only one copy is printed. The date is not printed.	The printer is not PictBridge-compatible.	_	_

Miscellaneous

Problem	Possible cause	Solution	Page
Nothing happens when the shutter button is pressed.	Temporary camera malfunction.	Remove and reinsert the batteries or disconnect and reconnect the AC adapter/DC coupler.	
torris pressed.	The batteries are exhausted.	Insert fresh or fully-charged spare batteries.	8
The camera does not function as expected.	Temporary camera malfunction.	Remove and reinsert the batteries or disconnect and reconnect the AC adapter/DC coupler. If the problem persists, contact your FUJIFILM dealer.	Q
I want to use an AC power adapter and DC coupler overseas.	Check the label on the AC power adapter.	The AC power adapter can be used with voltages of 100–240 V. Consult your travel agent for information on plug adapters.	ı

Warning Messages and Displays

The following warnings are displayed in the monitor:

Warning	Description	Solution
□ (red)	Batteries are low.	Insert fresh or fully-charged spare batteries.
□ (blinks red)	Batteries are exhausted.	linsert hesir of fully-charged spare batteries.
ļo;	Slow shutter speed. Picture may be blurred.	Use the flash or mount the camera on a tripod.
!AF (displayed in red with red focus frame)	The camera can not focus.	 Use focus lock to focus on another subject at the same distance, then recompose the picture (pg. 24). If the subject is poorly lit, try focusing at a distance of about 2 m (6.6 ft.). Use macro mode to focus when taking close-ups.
Aperture or shutter speed shown in red	The subject is too bright or too dark. The picture will be over- or under-exposed.	If the subject is dark, use the flash.
BLINK DETECTED	A subject or subjects may have blinked.	Retake the photograph if desired.
FOCUS ERROR		Turn the camera off and then on again, taking care not
TURN OFF THE CAMERA AND TURN ON AGAIN	Camera malfunction.	to touch the lens. If the message persists, contact a
LENS CONTROL ERROR		rojirilim dealer.
NO CARD	No memory card inserted when COPY is selected in the playback menu.	Insert a memory card.
		Format the memory card or internal memory using the FORMAT option in the camera setup menu (pg. 98).
CARD NOT INITIALIZED	The memory card contacts require cleaning.	Clean the contacts with a soft, dry cloth. If the message is repeated, format the memory card (pg. 98). If the message persists, replace the memory card.
	Camera malfunction.	Contact a FUJIFILM dealer.
PROTECTED CARD	The memory card is locked.	Unlock the memory card (pg. 10).

Warning	Description	Solution
BUSY	The memory card is incorrectly formatted.	Use the camera to format the memory card (pg. 98).
	The memory card is not formatted for use in the camera.	Format the memory card (pg. 98).
CARD ERROR	The memory card contacts require cleaning or the memory card is damaged.	Clean the contacts with a soft, dry cloth. If the message is repeated, format the memory card (pg. 98). If the message persists, replace the memory card.
	Incompatible memory card.	Use a compatible memory card.
	Camera malfunction.	Contact a FUJIFILM dealer.
SD MEMORY FULL		
MEMORY FULL] , , , , , , , , , , , , , , , , , , ,	Delete pictures or insert a memory card with more free
	pictures can not be recorded or copied.	space.
INSERT A NEW CARD		
	Memory card error or connection error.	Re-insert the memory card or turn the camera off and then on again. If the message persists, contact a FUJIFILM dealer.
WRITE ERROR	Not enough memory remaining to record additional pictures.	Delete pictures or insert a memory card with more free space.
	The memory card or internal memory is not formatted.	Format the memory card or internal memory (pg. 98).
	The file is corrupt or was not created with the camera.	The file can not be played back.
READ ERROR	The memory card contacts require cleaning.	Clean the contacts with a soft, dry cloth. If the message is repeated, format the memory card (pg. 98). If the message persists, replace the memory card.
	Camera malfunction.	Contact a FUJIFILM dealer.

Warning	Description	Solution				
FRAME NO. FULL	The camera has run out of frame numbers (current frame number is 999-9999).	Format the memory card and select RENEW for the ID FRAME NO. option in the ID SET-UP menu. Take a picture to reset frame numbering to 100-0001, then return to the ID FRAME NO. menu and select CONTINUOUS .				
TOO MANY FRAMES	Date for which more than 4,999 pictures exist selected in sort-by-date view.	Choose a different date.				
PROTECTED FRAME	An attempt was made to add a voice memo to or delete a protected picture.	Remove protection before adding voice memos to or deleting pictures.				
■ ERROR	Voice memo file is corrupt.	The voice memo can not be played back.				
Ennon	Camera malfunction.	Contact a FUJIFILM dealer.				
so no image	The source device selected in the playback	 Select a different source.				
■ NO IMAGE	COPY menu contains no pictures.	Scient à différent source.				
640 CAN NOT CROP	An attempt was made to crop a 640 picture.					
CAN NOT CROP	The picture selected for cropping is damaged or was not created with the camera.	These pictures can not be cropped.				
640 CANNOT EXECUTE	An attempt was made to resize a 640 picture.	640 and 820 images can not be resized.				
320 CANNOT EXECUTE	An attempt was made to resize a 320 picture.	did 620 images can not be resized.				
DPOF FILE ERROR	The DPOF print order on the current memory card contains more than 999 images.	Copy the pictures to internal memory and create a new print order.				
CAN NOT SET DPOF	The picture can not be printed using DPOF.	_				
CAN NOT SET DPOF	Movies can not be printed using DPOF.	_				
CAN NOT ROTATE	The picture is protected.	Remove protection before rotating pictures.				
CAN NOT ROTATE	Movies can not be rotated.	_				

Warning	Description	Solution
PRESS AND HOLD THE DISP BUTTON TO DEACTIVATE SILENT MODE	An attempt was made to adjust the volume with the camera in silent mode.	Exit silent mode before adjusting the volume.
COMMUNICATION ERROR	A connection error occurred while pictures were being printed or copied to a computer or other device.	If antism that the device is turned an and that the LISK
PRINTER ERROR	Printer out of paper or ink, or other printer er-	Check printer (see printer manual for details). To resume printing, turn the printer off and then turn it back on.
PRINTER ERROR RESUME?	ror.	Check printer (see printer manual for details). If printing does not resume automatically, press MENU/OK to resume.
CAN NOT BE PRINTED	An attempt was made to print a movie, a pic-	Movies and some pictures created with other devices can not be printed. If the picture was created with the camera, check the printer manual to confirm that the printer supports the JFIF-JPEG or Exif-JPEG format. If it does not, the pictures can not be printed.

Glossary

Digital zoom: Unlike optical zoom, digital zoom does not increase the amount of visible detail. Instead, details visible using optical zoom are simply enlarged, producing a slightly "grainy" image.

DP0F (Digital Print Order Format): A standard that allows pictures to be printed from "print orders" stored in internal memory or on a memory card. The information in the order includes the pictures to be printed and the number of copies of each picture.



EV (Exposure Value): The exposure value is determined by the sensitivity of the image sensor and the amount of light that enters the camera while the image sensor is exposed. Each time the amount of light doubles, EV increases by one; each time the amount of light is halved, EV decreases by one. The amount of light entering the camera can be controlled by adjusting aperture and shutter speed.

Exif Print: A standard for storing information with pictures for optimal color reproduction during printing.

HDMI (High-Definition Multimedia Interface): An interface standard for the transmission of images and sound that adds audio input to the DVI interface used to connect computers to displays.

JPEG (Joint Photographic Experts Group): A compressed file format for color images. The higher the compression rate, the greater the loss of information and more noticeable drop in quality when the picture is displayed.

Motion JPEG: An AVI (Audio Video Interleave) format that stores sound and JPEG images in a single file. Motion JPEG files can be played in Windows Media Player (requires DirectX 8.0 or later) or QuickTime 3.0 or later.

Smear: A phenomenon specific to CCDs which causes white streaks to appear when very bright light sources, such as the sun or reflected sunlight, appear in the frame.

WAV (Waveform Audio Format): A standard Windows audio file format. WAV files have the extension "*.WAV" and

may be compressed or uncompressed. The camera uses uncompressed WAV. WAV files can be played using Windows Media Player or QuickTime 3.0 or later.

White balance: The human brain automatically adapts to changes in the color of light, with the result that objects that appear white under one light source still appear white when the color of the light source changes. Digital cameras can mimic this adjustment by processing images according to the color of the light source. This process is known as "white balance."

Internal Memory/Memory Card Capacity

The following table shows the recording time or number of pictures available at different image qualities. All figures are approximate; file size varies with the scene recorded, producing wide variations in the number of files that can be stored. The number of exposures or length remaining may not diminish at an even rate.

						(MAGE SIZE	(Still pictu	ures)				
				•	9						7		
		4	:3	3	3:2 16:9			4:3 3:2			16:9		
		FINE	NORMAL	FINE	NORMAL	FINE	NORMAL	FINE	NORMAL	FINE	NORMAL	FINE	NORMAL
	Size	12	M	11	М	9	М	6	М	5 M 4		M	
	File size	6.0 MB	3.1 MB	5.3 MB	2.7 MB	4.5 MB	2.3 MB	3.0 MB	1.6 MB	2.7 MB	1.4 MB	2.3 MB	1.2 MB
	rnal memory oprox. 23 MB)	3	7	4	8	5	10	8	15	9	18	10	21
æ	512 MB	80	160	90	180	100	210	160	310	180	350	210	400
) card	1 GB	150	310	170	340	200	400	310	600	350	670	400	770
ᆲ	2 GB	320	630	360	710	420	840	640	1240	720	1400	840	1620
SHC	4 GB	640	1270	720	1430	860	1680	1280	2490	1450	2800	1690	3250
Ç	8 GB	1300	2560	1460	2870	1720	3380	2580	5000	2910	5620	3400	6530
card	16 GB	2680	5270	3010	5920	3560	6970	5320	10310	6000	11590	7020	13470

		■ IMAGE SIZE (Still pictures)						QUALITY (Movies)			
				E	3						
		4	:3	3	:2	16	:9				
		FINE	NORMAL	FINE	NORMAL	FINE	NORMAL	1280 HD*	640 *	320 °	
	Size		3	M		2	M	720p	VGA	QVGA	
	File size	1.7 MB	0.9 MB	1.5 MB	0.8 MB	1.1 MB	0.6 MB	_	_	_	
	rnal memory oprox. 23 MB)	15	29	17	32	22	41	5 sec.	19 sec.	41 sec.	
as	512 MB	300	560	330	620	430	800	1 min.	6 min.	14 min.	
) card	1 GB	570	1070	640	1180	830	1530	3 min.	12 min.	26 min.	
<u>a</u>	2 GB	1180	2230	1320	2480	1730	3200	7 min.	26 min.	56 min.	
SHICS	4 GB	2360	4460	2650	4970	3480	6400	15 min.	53 min.	112 min.	
) JH	8 GB	4740	8960	5320	9970	6980	12850	31 min.	107 min.	226 min.	
card	16 GB	9780	18470	10960	20560	14400	26490	64 min.	221 min.	908 min.	

^{*} Time given for movies is total length of all movie files. Individual movies can not exceed 2 GB in size or 15 minutes in length, regardless of capacity of memory card.

Specifications

System	
Model	Digital Camera FinePix S2500HD/S2700HD series, S1800/S1900 series, S1600/S1700 series
Effective pixels	12.2 million
CCD	½3-in., square-pixel CCD with primary color filter
Storage media	• Internal memory (approx. 23 MB) • SD/SDHC memory cards (see page 10)
File system	Compliant with Design Rule for Camera File System (DCF), Exif 2.2, and Digital Print Order Forma (DPOF)
File format	Still pictures: Exif 2.2 JPEG (compressed) Audio: monaural WAV *Movies: AVI-format Motion JPEG
Image size (pixels)	• ■ 4:3: 4,000×3,000 (12 M) • ■ 3:2: 4,000×2,664 (11 M) • ■ 16:9: 4,000×2,248 (9 M)
	• ■ 4:3: 2,816×2,112 (6M) • ■ 3:2: 2,816×1,864 (5M) • ■ 16:9: 2,816×1,584 (4M)
	• S 4:3: 2,048 × 1,536 (3 M) • S 3:2: 2,048 × 1,360 (3 M) • S 16:9: 1,920 × 1,080 (2 M)
File size	See page 116–117
Lens (S2500HD/S2700HD series and S1800/S1900 series)	Fujinon 18× optical zoom lens, F/3.1 (wide angle) – 5.6 (telephoto)
Focal length	f=5 mm-90 mm (35-mm format equivalent: 28 mm-504 mm)
Lens (\$1600/\$1700 series)	Fujinon 15 × optical zoom lens, F/3.1 (wide angle) – 5.6 (telephoto)
Focal length	f=5 mm-75 mm (35-mm format equivalent: 28 mm-420 mm)
Digital zoom	• Still pictures: Approx. 6.3 × (\$2500HD/\$2700HD series and \$1800/\$1900 series: up to 113.4 × with optical zoom;
	\$1600/\$1700 series : up to 94.5 × with optical zoom)
	• Movies: 3× (1280 HD); 2× (640/820)
Aperture	F3.1 and F6.4 (wide angle), F5.6 and F11.0 (telephoto) with ND filter
Focus range (distance from	Approx. 40 cm (1.3 ft.)—infinity (wide angle); 2.5 m (8.2 ft.)—infinity (telephoto)
front of lens)	• Macro: approx. 5 cm-3 m/0.2 ft9.8 ft. (wide angle); 1.8 m-3 m/5.9 ft9.8 ft. (telephoto)
	• Super macro: approx. 2 cm – 100 cm/0.1 ft. – 3.3 ft. (wide angle)
	• High-speed shooting : approx. 1.5 m (4.9 ft.)—infinity (wide angle); 3 m (9.8 ft.)—infinity (telephoto)

System	
Sensitivity	Standard output sensitivity equivalent to ISO 64, 100, 200, 400, 800, 1600, 3200, 6400 (3200 and 6400
	available only at image sizes [S]); AUTO, AUTO (400), AUTO (800)
Metering	256-segment through-the-lens (TTL) metering; MULTI, SPOT, AVERAGE
Exposure control	Programmed AE, shutter-priority AE, aperture-priority AE, and manual exposure
Exposure compensation	-2 EV − +2 EV in increments of 1/3 EV (P , S , and A modes)
Scene modes	
	▲ (LANDSCAPE), 🛰 (SPORT), 🖰 (NIGHT), 🖋 (NIGHT (TRIPOD)), ③ (FIREWORKS), 📸 (SUNSET),
	⑤ (SNOW), ▲ (BEACH), ▼ (PARTY), ※ (FLOWER), 図 (TEXT)
Scene recognition	Available (camera automatically selects Q , Q , Q , Q , Q , or Q)
Picture stabilization	Optical stabilization, CCD shift
Intelligent Face Detection	Available
Blink detection	Available
Shutter speed (combined	• P, S, A, M: 8 s – ½,000 s • C+: 1/8 s – ½,000 s • x (+: 3 s – ½,000 s
mechanical and electronic	• ② : 8 s − ½ s • Other modes : ¼ s − ½,000 s
shutter)	
Continuous	• • • • • • • • • • • • • • • • • • •
	• ■: up to 1.3 fps; maximum number of frames varies with image size and available memory
	• 🚡: up to 1.3 fps; last 3 frames recorded • 🛍: up to 3.3 fps; max. 10 frames; size 🔣
	• 🛍: up to 8 fps; max. 20 frames; size 💽
Bracketing	±1/3 EV, ±3/4 EV, ±1 EV
Focus	Mode: Single AF, continuous AF
	Focus-area selection: CENTER, MULTI, AREA, TRACKING
	Autofocus system: Contrast-detect TTL AF
White balance	Automatic scene detection; six manual preset modes for direct sunlight, shade, daylight fluorescent,
	warm white fluorescent, cool white fluorescent, and incandescent lighting; custom white balance
Self-timer	Off, 2 sec, 10 sec
-	

System	
Flash	Manual pop-up flash with CCD-metered auto flash control (using monitor pre-flashes); effective range when sensitivity is set to ${\bf AUTO}$ is approx. $40{\rm cm}-8{\rm m}/1.3{\rm ft.}-26.2{\rm ft.}$ (wide angle) or $2.5{\rm m}-4.4{\rm m}/8.2{\rm ft.}-14.4{\rm ft.}$ (telephoto); effective range in macro mode is approx. $30{\rm cm}-3{\rm m}/1{\rm ft.}-9.8{\rm ft.}$ (wide angle) or $1.8{\rm m}-3{\rm m}/1{\rm ft.}-5.9{\rm ft.}$ (telephoto)
Flash modes	Auto, forced flash, off, slow synchro (red-eye removal off); auto with red-eye removal, forced flash with red-eye removal, off, slow sync with red-eye removal (red-eye removal on)
Electronic viewfinder (EVF)	0.2-in., 200k-dot color LCD viewfinder
Frame coverage	Approx. 99% (shooting), 100% (playback)
Monitor	3.0-in., 230k-dot color LCD monitor
Frame coverage	Approx. 97% (shooting), 100% (playback)
Movies	(1,280×720/720p)/640 (640×480/VGA)/820 (320×240/QVGA); monaural sound; frame rate 30 fps
Shooting options	Instant zoom, Intelligent Face Detection with red-eye removal, high-speed shooting, best framing, frame number memory, and histogram display
Playback options	Intelligent Face Detection, red-eye removal, micro thumbnail, multi-frame playback, sort-by-date, cropping, resize, slide show, image rotation, voice memo, histogram display, and exposure warning
Other options	PictBridge, Exif Print, FinePix COLOR, language selection (Arabic, Simplified Chinese, Traditional Chinese, Czech, Danish, Dutch, English, Farsi, Finnish, French, German, Greek, Hungarian, Italian, Japanese, Korean, Lithuanian, Norwegian, Polish, Portuguese, Russian, Slovak, Spanish, Swedish, Thai, Turkish, and Ukrainian), time difference, battery discharge, auto image rotation for playback

A/V OUT (audio/video output)	NTSC or PAL output with monaural sound				
HDMI output (S2500HD/S2700HD series only)	HDMI Mini Connector				
Digital input/output	USB 2.0 High Speed; shares A/V OUT connector				
Power supply/other					
Power sources	 AA alkaline batteries (x4) AA lithium batteries (x4; available from third-pai AA rechargeable nickel-metal hydride (Ni-MH) b 	, , , ,			
	AC-5VX AC power adapter and CP-04 DC couple	. ,			
Battery life (approximate number of frames that can	Battery type	Approximate number of frames			
	Alkaline (type supplied with camera)	300			
be taken with fresh or fully	Lithium	700			
charged batteries)	Ni-MH	500			
	CIPA standard, measured in a (auto) mode using batteries supplied with camera (alkaline batterie only) and SD memory card.				
		g batteries supplied with Camera (alkaline batter			
Camera dimensions	only) and SD memory card. Note: Number of shots that can be taken with batter	ery varies with battery charge level and will decli			
	only) and SD memory card. Note : Number of shots that can be taken with batte at low temperatures.	ery varies with battery charge level and will decli in. (W \times H \times D), excluding projections			
Camera dimensions Camera weight Shooting weight	only) and SD memory card. Note: Number of shots that can be taken with batter at low temperatures. 110.2 mm × 73.4 mm × 81.4 mm/4.3 in. × 2.9 in. × 3.2	ery varies with battery charge level and will decli in. (W×H×D), excluding projections ories, and memory cards			

Color Television Systems

NTSC (**N**ational **T**elevision **S**ystem **C**ommittee) is a color television telecasting specification adopted mainly in the U.S.A., Canada, and Japan. PAL (**P**hase **A**lternation by **L**ine) is a color television system adopted mainly in European countries and China.

Notices

- Specifications subject to change without notice. FUJIFILM shall not be held liable for damages resulting from errors in this manual.
- Although the monitor is manufactured using advanced high-precision technology, small bright points and anomalous colors (particularly in the vicinity of text) may appear. This is normal for this type of monitor and does not indicate a malfunction; images recorded with the camera are unaffected.
- Digital cameras may malfunction when exposed to strong radio interference (e.g., electric fields, static electricity, or line noise).
- Due to the type of lens used, some distortion may occur at the periphery of images. This is normal.

Memo

Memo

Memo

FUJIFILM

FUJIFILM Corporation 7-3, AKASAKA 9-CHOME, MINATO-KU, TOKYO 107-0052, JAPAN http://www.fujifilm.com/products/digital_cameras/index.html