



PORTATONE
PSR-275
PSR-273

Owner's Manual



SPECIAL MESSAGE SECTION

This product utilizes batteries or an external power supply (adapter). DO NOT connect this product to any power supply or adapter other than one described in the manual, on the name plate, or specifically recommended by Yamaha.

This product should be used only with the components supplied or; a cart, rack, or stand that is recommended by Yamaha. If a cart, etc., is used, please observe all safety markings and instructions that accompany the accessory product.

SPECIFICATIONS SUBJECT TO CHANGE:

The information contained in this manual is believed to be correct at the time of printing. However, Yamaha reserves the right to change or modify any of the specifications without notice or obligation to update existing units.

This product, either alone or in combination with an amplifier and headphones or speaker/s, may be capable of producing sound levels that could cause permanent hearing loss. DO NOT operate for long periods of time at a high volume level or at a level that is uncomfortable. If you experience any hearing loss or ringing in the ears, you should consult an audiologist.

IMPORTANT: The louder the sound, the shorter the time period before damage occurs.

NOTICE:

Service charges incurred due to a lack of knowledge relating to how a function or effect works (when the unit is operating as designed) are not covered by the manufacturer's warranty, and are therefore the owners responsibility. Please study this manual carefully and consult your dealer before requesting service.

ENVIRONMENTAL ISSUES:

Yamaha strives to produce products that are both user safe and environmentally friendly. We sincerely believe that our products and the production methods used to produce them, meet these goals. In keeping with both the letter and the spirit of the law, we want you to be aware of the following:

Battery Notice:

This product MAY contain a small non-rechargeable battery which (if applicable) is soldered in place. The average life span of this type of battery is approximately five years. When replacement becomes necessary, contact a qualified service representative to perform the replacement.

This product may also use "household" type batteries. Some of these may be rechargeable. Make sure that the battery being charged is a rechargeable type and that the charger is intended for the battery being charged.

When installing batteries, do not mix batteries with new, or with batteries of a different type. Batteries MUST be installed correctly. Mismatches or incorrect installation may result in overheating and battery case rupture.

Warning:

Do not attempt to disassemble, or incinerate any battery. Keep all batteries away from children. Dispose of used batteries promptly and as regulated by the laws in your area. Note: Check with any retailer of household type batteries in your area for battery disposal information.

Disposal Notice:

Should this product become damaged beyond repair, or for some reason its useful life is considered to be at an end, please observe all local, state, and federal regulations that relate to the disposal of products that contain lead, batteries, plastics, etc. If your dealer is unable to assist you, please contact Yamaha directly.

NAME PLATE LOCATION:

The name plate is located on the bottom of the product. The model number, serial number, power requirements, etc., are located on this plate. You should record the model number, serial number, and the date of purchase in the spaces provided below and retain this manual as a permanent record of your purchase.

Model

Serial No.

Purchase Date

PLEASE KEEP THIS MANUAL

FCC INFORMATION (U.S.A.)

1. IMPORTANT NOTICE: DO NOT MODIFY THIS UNIT!

This product, when installed as indicated in the instructions contained in this manual, meets FCC requirements. Modifications not expressly approved by Yamaha may void your authority, granted by the FCC, to use the product.

2. IMPORTANT: When connecting this product to accessories and/or another product use only high quality shielded cables. Cable/s supplied with this product **MUST** be used. Follow all installation instructions. Failure to follow instructions could void your FCC authorization to use this product in the USA.

3. NOTE: This product has been tested and found to comply with the requirements listed in FCC Regulations, Part 15 for Class "B" digital devices. Compliance with these requirements provides a reasonable level of assurance that your use of this product in a residential environment will not result in harmful interference with other electronic devices. This equipment generates/uses radio frequencies and, if not installed and used according to the instructions found in the users manual, may cause interference harmful to the operation of other electronic devices. Compliance

with FCC regulations does not guarantee that interference will not occur in all installations. If this product is found to be the source of interference, which can be determined by turning the unit "OFF" and "ON", please try to eliminate the problem by using one of the following measures:

Relocate either this product or the device that is being affected by the interference.

Utilize power outlets that are on different branch (circuit breaker or fuse) circuits or install AC line filter/s.

In the case of radio or TV interference, relocate/reorient the antenna. If the antenna lead-in is 300 ohm ribbon lead, change the lead-in to co-axial type cable.

If these corrective measures do not produce satisfactory results, please contact the local retailer authorized to distribute this type of product. If you can not locate the appropriate retailer, please contact Yamaha Corporation of America, Electronic Service Division, 6600 Orangethorpe Ave, Buena Park, CA90620

The above statements apply **ONLY** to those products distributed by Yamaha Corporation of America or its subsidiaries.

* This applies only to products distributed by YAMAHA CORPORATION OF AMERICA.

(class B)

OBSERVERA!

Apparaten kopplas inte ur växelströmskällan (nätet) så länge som den är ansluten till vägguttaget, även om själva apparaten har stängts av.

ADVARSEL: Netspændingen til dette apparat er IKKE afbrudt, så længe netledningen sidder i en stikkontakt, som er tændt — også selvom der er slukket på apparatets afbryder.

VAROITUS: Laitteen toisiopiiriin kytketty käyttökylkin ei irroita koko laitetta verkosta.

(standby)

Entsorgung leerer Batterien (nur innerhalb Deutschlands)

Leisten Sie einen Beitrag zum Umweltschutz. Verbrauchte Batterien oder Akkumulatoren dürfen nicht in den Hausmüll. Sie können bei einer Sammelstelle für Altbatterien bzw. Sondermüll abgegeben werden. Informieren Sie sich bei Ihrer Kommune.

(battery)

PRECAUTIONS

PLEASE READ CAREFULLY BEFORE PROCEEDING

* Please keep this manual in a safe place for future reference.



WARNING

Always follow the basic precautions listed below to avoid the possibility of serious injury or even death from electrical shock, short-circuiting, damages, fire or other hazards. These precautions include, but are not limited to, the following:

Power supply/AC power adaptor

- Only use the voltage specified as correct for the instrument. The required voltage is printed on the name plate of the instrument.
- Use the specified adaptor (PA-3C or PA-3B or an equivalent recommended by Yamaha) only. Using the wrong adaptor can result in damage to the instrument or overheating.
- Check the electric plug periodically and remove any dirt or dust which may have accumulated on it.
- Do not place the AC adaptor cord near heat sources such as heaters or radiators, and do not excessively bend or otherwise damage the cord, place heavy objects on it, or place it in a position where anyone could walk on, trip over, or roll anything over it.

Do not open

- Do not open the instrument or attempt to disassemble the internal parts or modify them in any way. The instrument contains no user-serviceable parts. If it should appear to be malfunctioning, discontinue use immediately and have it inspected by qualified Yamaha service personnel.

Water warning

- Do not expose the instrument to rain, use it near water or in damp or wet conditions, or place containers on it containing liquids which might spill into any openings.
- Never insert or remove an electric plug with wet hands.

Fire warning

- Do not put burning items, such as candles, on the unit. A burning item may fall over and cause a fire.

If you notice any abnormality

- If the AC adaptor cord or plug becomes frayed or damaged, or if there is a sudden loss of sound during use of the instrument, or if any unusual smells or smoke should appear to be caused by it, immediately turn off the power switch, disconnect the adaptor plug from the outlet, and have the instrument inspected by qualified Yamaha service personnel.



CAUTION

Always follow the basic precautions listed below to avoid the possibility of physical injury to you or others, or damage to the instrument or other property. These precautions include, but are not limited to, the following:

Power supply/AC power adaptor

- When removing the electric plug from the instrument or an outlet, always hold the plug itself and not the cord.
- Unplug the AC power adaptor when not using the instrument, or during electrical storms.
- Do not connect the instrument to an electrical outlet using a multiple-connector. Doing so can result in lower sound quality, or possibly cause overheating in the outlet.

Battery

- Always make sure all batteries are inserted in conformity with the +/- polarity markings. Failure to do so might result in overheating, fire, or battery fluid leakage.
- Always replace all batteries at the same time. Do not use new batteries together with old ones. Also, do not mix battery types, such as alkaline batteries with manganese batteries, or batteries from different makers, or different types of batteries from the same maker, since this can cause overheating, fire, or battery fluid leakage.
- Do not dispose of batteries in fire.

- Do not attempt to recharge batteries that are not intended to be charged.
- When the batteries run out, or if the instrument is not to be used for a long time, remove the batteries from the instrument to prevent possible leakage of the battery fluid.
- Keep batteries away from children.
- If the batteries do leak, avoid contact with the leaked fluid. If the battery fluid should come in contact with your eyes, mouth, or skin, wash immediately with water and consult a doctor. Battery fluid is corrosive and may possibly cause loss of sight or chemical burns.

Location

- Do not expose the instrument to excessive dust or vibrations, or extreme cold or heat (such as in direct sunlight, near a heater, or in a car during the day) to prevent the possibility of panel disfiguration or damage to the internal components.
- Do not use the instrument in the vicinity of a TV, radio, stereo equipment, mobile phone, or other electric devices. Otherwise, the instrument, TV, or radio may generate noise.

- Do not place the instrument in an unstable position where it might accidentally fall over.
- Before moving the instrument, remove all connected adaptor and other cables.
- Use only the stand specified for the instrument. When attaching the stand or rack, use the provided screws only. Failure to do so could cause damage to the internal components or result in the instrument falling over.

Connections

- Before connecting the instrument to other electronic components, turn off the power for all components. Before turning the power on or off for all components, set all volume levels to minimum. Also, be sure to set the volumes of all components at their minimum levels and gradually raise the volume controls while playing the instrument to set the desired listening level.

Maintenance

- When cleaning the instrument, use a soft, dry cloth. Do not use paint thinners, solvents, cleaning fluids, or chemical-impregnated wiping cloths.

Handling caution

- Do not insert a finger or hand in any gaps on the instrument.
- Never insert or drop paper, metallic, or other objects into the gaps on the panel or keyboard. If this happens, turn off the power immediately and unplug the power cord from the AC outlet. Then have the instrument inspected by qualified Yamaha service personnel.
- Do not place vinyl, plastic or rubber objects on the instrument, since this might discolor the panel or keyboard.
- Do not rest your weight on, or place heavy objects on the instrument, and do not use excessive force on the buttons, switches or connectors.
- Do not operate the instrument for a long period of time at a high or uncomfortable volume level, since this can cause permanent hearing loss. If you experience any hearing loss or ringing in the ears, consult a physician.

Yamaha cannot be held responsible for damage caused by improper use or modifications to the instrument, or data that is lost or destroyed.

Always turn the power off when the instrument is not in use.

When using a power adaptor, even when the power switch is in the "STANDBY" position, electricity is still flowing to the instrument at the minimum level. When you are not using the instrument for a long time, make sure you unplug the AC power adaptor from the wall AC outlet.

Make sure to discard used batteries according to local regulations.

- The illustrations and LCD screens as shown in this owner's manual are for instructional purposes only, and may be different from the ones on your instrument.
- Unless otherwise indicated, the example panel control illustrations, Keyboard illustrations and LCD screenshots are taken from the PSR-275.

● The demo-song (or composition) included in this keyboard is as follows:

Composition Title : An Englishman In New York

Composer's Name : Sumner 0590545

Copyright Owner's Name : G M SUMNER LTD

CAUTION : All Rights Reserved, Unauthorized copying, public performance and broadcasting are strictly prohibited regarding the above song.

● COPYRIGHT NOTICE

This product incorporates and bundles computer programs and contents in which Yamaha owns copyrights or with respect to which it has license to use others' copyrights. Such copyrighted materials include, without limitation, all computer software, styles files, MIDI files, WAVE data and sound recordings. Any unauthorized use of such programs and contents outside of personal use is not permitted under relevant laws. Any violation of copyright has legal consequences. **DON'T MAKE, DISTRIBUTE OR USE ILLEGAL COPIES.**

● Trademarks

- Apple and Macintosh are trademarks of Apple Computer, Inc., registered in the U.S. and other countries.
- Windows is the registered trademark of Microsoft® Corporation.

All other trademarks are the property of their respective holders.

Congratulations on your purchase of the Yamaha PSR-275/273 PortaTone!

You now own a portable keyboard that combines advanced functions, great sound and exceptional ease-of-use in a highly compact package. Its outstanding features also make it a remarkably expressive and versatile instrument.

Read this Owner's Manual carefully while playing your new PSR-275/273 in order to take full advantage of its various features.

Main Features

The PSR-275/273 is a sophisticated yet easy-to-use keyboard with the following features and functions:



■ **Stereo Sampled Piano** **page 21**

The PSR-275/273 has a special Portable Grand Piano Voice — created by state-of-the-art stereo sampling technology and using Yamaha's sophisticated AWM (Advanced Wave Memory) tone generation system.



■ **Touch Response** **page 27**

The exceptionally natural Touch Response feature, with a convenient front panel on/off switch, gives you maximum expressive level control over the voices. It also works in conjunction with the Dynamic Filter, which dynamically adjusts the timbre or tone of a voice according to your playing strength — just a like a real musical instrument!



■ **Yamaha Education Suite** **pages 40, 42, 49**

The PSR-275/273 features the new Yamaha Education Suite — a set of learning tools that utilize the latest technology to make studying and practicing music more fun and fulfilling than ever before!



■ **One Touch Setting** **page 25**

One Touch Setting (OTS), for automatically calling up an appropriate voice for playing with the selected Style and Song.



■ **Powerful Speaker System**

The built-in stereo amplifier/speaker system of the PSR-275/273 — with a special Bass Boost feature — provides exceptionally powerful, high-quality sound, letting you hear the full dynamic range of the PSR-275/273's authentic voices.



■ **GM System Level 1**

"GM System Level 1" is an addition to the MIDI standard which ensures that any GM-compatible music data can be accurately played by any GM-compatible tone generator, regardless of manufacturer. The GM mark is affixed to all software and hardware products that support GM System Level.



■ **XGlite**

As its name implies, "XGlite" is a simplified version of Yamaha's high-quality XG tone generation format. Naturally, you can play back any XG song data using an XGlite tone generator. However, keep in mind that some songs may play back differently compared to the original data, due to the reduced set of control parameters and effects.


Contents

| | | | |
|---|-----------|--|-----------|
| Panel Controls and Terminals | 8 | Song Lesson | 49 |
| Setting Up | 10 | • Using the Lesson Feature..... | 49 |
| • Power Requirements | 10 | • Lesson 1 — Timing..... | 51 |
| • Turning On the Power..... | 11 | • Lesson 2 — Waiting..... | 52 |
| • Accessory Jacks | 11 | • Lesson 3 — Minus One | 52 |
| | | • Lesson 4 — Both Hands..... | 53 |
| | | • Grade..... | 53 |
| Quick Guide | 12 | MIDI Functions..... | 54 |
| Step 1 Voices | 12 | • What Is MIDI? | 54 |
| Step 2 Songs | 14 | • Connecting to a Personal Computer..... | 56 |
| Step 3 Style | 16 | • Local Control..... | 57 |
| | | • Using Initial Setup Send with a Sequencer..... | 57 |
| | | • External Clock..... | 57 |
| | | • PC Mode..... | 58 |
| Basic Operation and LCD Display..... | 18 | Function | 59 |
| Portable Grand..... | 21 | • Using the Function parameters..... | 59 |
| • Playing the Portable Grand..... | 21 | Voice List | 61 |
| • Using the Metronome | 21 | Style List | 65 |
| Playing Voices | 23 | Drum Kit List..... | 66 |
| • Playing a Voice | 23 | MIDI Implementation Chart..... | 68 |
| • #000 OTS | 25 | Effect map | 69 |
| • Dual Voice | 25 | Troubleshooting | 70 |
| • Split Voice..... | 26 | Specifications | 71 |
| • Setting the Split Point | 26 | Index | 72 |
| • Touch and Touch Sensitivity..... | 27 | | |
| • Transpose and Tuning..... | 28 | | |
| Effects | 29 | | |
| • Harmony | 29 | | |
| • Reverb | 29 | | |
| • Chorus | 30 | | |
| • Sustain..... | 30 | | |
| Selecting and Playing Styles | 33 | | |
| • Selecting a Style | 33 | | |
| • Playing the Styles | 34 | | |
| • Changing the Tempo | 38 | | |
| • Accompaniment Sections (Main A/B and Fill-ins) | 39 | | |
| • Adjusting the Style Volume..... | 39 | | |
| • Using Auto Accompaniment — Multi Fingering | 40 | | |
| • Dictionary..... | 42 | | |
| Selecting and Playing Songs..... | 45 | | |
| • Selecting a Song..... | 45 | | |
| • Playing the Songs..... | 46 | | |
| • A-B Repeat | 47 | | |
| • Melody Voice Change..... | 48 | | |
| • Adjusting the Song Volume | 48 | | |



Panel Controls and Terminals

■ Front Panel



1 Power switch ([STANDBY/ON])

2 [MASTER VOLUME] dial

This determines the overall volume of the PSR-275/273.

3 [TOUCH] button

This turns the Touch function on and off. (See page 27.) Holding down this button calls up the Time Signet settings.

4 [Dict.] button

This calls up the Dictionary function (See page 42).

5 LESSON [L] (Left) and [R] (Right) buttons

These call up the Lesson exercises for the corresponding hand (left or right) for the selected song. (See page 49.)

6 [FUNCTION] button

This calls up the Function mode (See pages 59).

7 [DEMO] button

This is used to play the Demo song. (See page 14.)

8 [PORTABLE GRAND] button

This instantly calls up the Grand Piano voice. (See page 21.)

9 [METRONOME] button

This turns the metronome on and off. (See page 21.) Holding down this button calls up the Time Signet settings.

10 [PC] button

This convenient control lets you instantly call up the specified MIDI settings for optimum use with a connected computer or other MIDI device. (See page 58.)

11 Numeric keypad, [+ / YES] and [- / NO] buttons

These are used for selecting songs, voices, and styles. (See pages 19.) They are also used for adjusting certain settings and answering certain display prompts.

12 [ACMP ON/OFF] / [A-B REPEAT] button

When the Style mode is selected, this turns the auto accompaniment on and off. (See page 34.) In the Song mode, this calls up the A-B Repeat function. (See page 47.)

13 [SYNC START] / [PAUSE] button

This turns the Sync Start function on and off. (See page 35.) In the Song mode, it is used to temporarily pause song playback. (See page 46.)

14 [START/STOP] button

When the Style mode is selected, this alternately starts and stops the style. (See page 34.) In the Song mode, this alternately starts and stops song playback. (See page 47.)

15 [INTRO/ENDING/rit.] / [REW] button

When the Style mode is selected, this is used to control the Intro and Ending functions. (See page 34.)

When the Song mode is selected, this is used as a “rewind” control, or move the song playback point back toward the beginning.

16 [MAIN/AUTO FILL] / [FF] button

When the Style mode is selected, these are used to change auto accompaniment sections and control the Auto Fill function. (See page 39.) When the Song mode is selected, this is used as a “fast forward” control, or move the song playback point toward the end.

17 [TEMPO/TAP] button

This button is used to call up the Tempo setting, letting you set the Tempo with the numeric keypad or [+]/[-] buttons. (See page 21.) It also allows you to tap out the tempo and automatically start a selected song or style at that tapped speed. (See page 35.)

18 [SONG] button

This is for enabling song selection. (See page 45.)

19 [STYLE] button

This is for enabling style selection. (See page 33.)

20 [VOICE] button

This is for enabling voice selection. (See page 23.) Holding down this button calls up the Melody Voice Change function. (See page 48.)

21 [HARMONY] button

This turns the Harmony effect on and off. (See page 29.)

22 [DUAL] button

This turns the Dual voice on or off. (See page 25.)


23 [SPLIT] button

This turns the Split voice on and off. (See page 26.)

24 [SUSTAIN] button

This turns the Sustain on and off. (See page 30.)

■ Rear Panel



25 PHONES/OUTPUT jack

This is for connection to a set of stereo headphones or to an external amplifier/speaker system. (See page 11.)

26 DC IN 10-12V jack

This is for connection to a PA-3C or PA-3B AC power adaptor. (See page 10.)

27 MIDI IN, MIDI OUT terminals

These are for connection to other MIDI instruments and devices. (See page 56.)

28 SUSTAIN jack

This is for connection to an optional FC4 or FC5 Footswitch for control over sustain, just like the damper pedal on a piano. (See page 11.)



Setting Up



This section contains information about setting up your PSR-275/273 for playing. Make sure to read this section carefully before using the instrument.

Power Requirements

Although the PSR-275/273 will run either from an optional AC adaptor or batteries, Yamaha recommends use of an AC adaptor whenever possible. An AC adaptor is more environmentally friendly than batteries and does not deplete resources.

■ Using an AC Power Adaptor

- ① Make sure that the [STANDBY/ON] switch of the PSR-275/273 is set to STANDBY.
- ② Connect the AC adaptor (PA-3C, PA-3B, or other adaptor specifically recommended by Yamaha) to the DC IN 10-12V jack.
- ③ Plug the AC adaptor into an AC outlet.




⚠ WARNING

- Use **ONLY** a Yamaha PA-3C or PA-3B AC Power Adaptor (or other adaptor specifically recommended by Yamaha) to power your instrument from the AC mains. The use of other adaptors may result in irreparable damage to both the adaptor and the PSR-275/273.
- Unplug the AC Power Adaptor when not using the PSR-275/273, or during electrical storms.

■ Using Batteries

For battery operation the PSR-275/273 requires six 1.5V “D” size, R20P (LR20) or equivalent batteries. When the batteries need to be replaced, the volume may be reduced, the sound may be distorted, and other problems may occur. When this happens, turn the power off and replace the batteries, as described below

- ① Open the battery compartment cover located on the instrument’s bottom panel.
- ② Insert the six new batteries, being careful to follow the polarity markings next to the compartment cover.
- ③ Replace the compartment cover, making sure that it locks firmly in place.




⚠ CAUTION

- When the batteries run down, replace them with a complete set of six new batteries. **NEVER** mix old and new batteries.
- Do not use different kinds of batteries (e.g. alkaline and manganese) at the same time.
- If the instrument is not to be in use for a long time, remove the batteries from it, in order to prevent possible fluid leakage from the battery.
- The effective life of rechargeable batteries may shorter than that of conventional batteries.

Turning On the Power

With the AC power adaptor connected or with batteries installed, simply press the power switch until it locks in the ON position. When the instrument is not in use, be sure to turn the power off. (Press the switch again so that it pops up.)

■ STANDBY
▲ ON




CAUTION

- Even when the switch is in the "STANDBY" position, electricity is still flowing to the instrument at the minimum level. When you are not using the PSR-275/273 for a long time, make sure you unplug the AC power adaptor from the wall AC outlet, and/or remove the batteries from the instrument.

Accessory Jacks


■ Using Headphones

For private practicing and playing without disturbing others, connect a set of stereo headphones to the rear panel PHONES/OUTPUT jack. Sound from the built-in speaker system is automatically cut off when you insert a headphone plug into this jack.



■ Connecting a Keyboard Amplifier or Stereo System

Though the PSR-275/273 is equipped with a built-in speaker system, you can also play it through an external amplifier/speaker system. First, make sure the PSR-275/273 and any external devices are turned off, then connect one end of a stereo audio cable to the LINE IN or AUX IN jack(s) of the other device and the other end to the rear panel PHONES/OUTPUT jack on the PSR-275/273.




CAUTION

- To prevent damage to the speakers, set the volume of the external devices at the minimum setting before connecting them. Failure to observe these cautions may result in electric shock or equipment damage. Also, be sure to set the volumes of all devices at their minimum levels and gradually raise the volume controls while playing the instrument to set the desired listening level.

■ Using a Footswitch

This feature lets you use an optional footswitch (Yamaha FC4 or FC5) to sustain the sound of the voices. The footswitch functions the same way as a damper pedal on an acoustic piano — press and hold down the footswitch as you play the keyboard to sustain the sound.





NOTE

- Make sure that the footswitch plug is properly connected to the SUSTAIN jack before turning on the power.
- Do not press the footswitch while turning the power on. Doing this changes the recognized polarity of the footswitch, resulting in reversed footswitch operation.

■ Using the MIDI Terminals

The PSR-275/273 also features MIDI terminals, allowing you to interface the PSR-275/273 with other MIDI instruments and devices. (For more information, see page 55.)







Playing the Piano

Simply by pressing the [PORTABLE GRAND] button, you can automatically select the Grand Piano voice.

- 1 Press the [PORTABLE GRAND] button.




- 2 Play the keyboard.




Want to find out more? See page 21.

Playing along with the Metronome

- 1 Press the [METRONOME] button.



- 2 Stop the Metronome.




Want to find out more? See page 21.


Selecting and Playing Other Voices

The PSR-275/273 has a huge total of 480 dynamic and realistic instrument voices. Let's try a few of them out now...

❶ Press the [VOICE] button.



❷ Select a voice.



❸ Play the keyboard.




Want to find out more? See page 23.

● Panel Voice List

| No. | Voice Name | No. | Voice Name | No. | Voice Name | No. | Voice Name |
|------------------|-----------------------|----------------|-------------------|-------------------|------------------|-------------------|----------------|
| PIANO | | | | | | | |
| 001 | Grand Piano | 030 | Folk Guitar | 061 | Vox Humana | 090 | Sawtooth Lead |
| 002 | Bright Piano | 031 | 12Strings Guitar | 062 | Air Choir | 091 | Voice Lead |
| 003 | Honky-tonk Piano | 032 | Jazz Guitar | SAXOPHONE | | | |
| 004 | MIDI Grand Piano | 033 | Octave Guitar | 063 | Soprano Sax | 092 | Star Dust |
| 005 | CP 80 | 034 | Clean Guitar | 064 | Alto Sax | 093 | Brightness |
| 006 | Harpsichord | 035 | 60's Clean Guitar | 065 | Tenor Sax | 094 | Analogon |
| E.PIANO | | | | | | | |
| 007 | Galaxy EP | 036 | Muted Guitar | 066 | Breathy Tenor | 095 | Fargo |
| 008 | Funky Electric Piano | 037 | Overdriven Guitar | 067 | Baritone Sax | SYNTH PAD | |
| 009 | DX Modern Elec. Piano | 038 | Distortion Guitar | 068 | Oboe | 096 | Fantasia |
| 010 | Hyper Tines | BASS | | | | 097 | Bell Pad |
| 011 | Venus Electric Piano | 039 | Acoustic Bass | 069 | English Horn | 098 | Xenon Pad |
| 012 | Clavi | 040 | Finger Bass | 070 | Bassoon | 099 | Equinox |
| ORGAN | | | | | | | |
| 013 | Jazz Organ 1 | 041 | Pick Bass | 071 | Clarinet | 100 | Dark Moon |
| 014 | Jazz Organ 2 | 042 | Fretless Bass | TRUMPET | | | |
| 015 | Click Organ | 043 | Slap Bass | 072 | Trumpet | PERCUSSION | |
| 016 | Bright Organ | 044 | Synth Bass | 073 | Muted Trumpet | 101 | Vibraphone |
| 017 | Rock Organ | 045 | Hi-Q Bass | 074 | Trombone | 102 | Marimba |
| 018 | Purple Organ | 046 | Dance Bass | 075 | Trombone Section | 103 | Xylophone |
| 019 | 16'+2' Organ | STRINGS | | | | 104 | Steel Drums |
| 020 | 16'+4' Organ | 047 | String Ensemble | 076 | French Horn | 105 | Celesta |
| 021 | Theater Organ | 048 | Chamber Strings | 077 | Tuba | 106 | Tubular Bells |
| 022 | Church Organ | 049 | Synth Strings | BRASS | | | |
| 023 | Chapel Organ | 050 | Slow Strings | 078 | Brass Section | 107 | Timpani |
| 024 | Reed Organ | 051 | Tremolo Strings | 079 | Big Band Brass | 108 | Music Box |
| ACCORDION | | | | | | | |
| 025 | Traditional Accordion | 052 | Pizzicato Strings | 080 | Mellow Horns | DRUM KITS | |
| 026 | Musette Accordion | 053 | Orchestra Hit | 081 | Synth Brass | 109 | Standard Kit 1 |
| 027 | Bandoneon | 054 | Violin | 082 | Jump Brass | 110 | Standard Kit 2 |
| 028 | Harmonica | 055 | Cello | 083 | Techno Brass | 111 | Room Kit |
| GUITAR | | | | | | | |
| 029 | Classical Guitar | 056 | Contrabass | FLUTE | | | |
| | | 057 | Banjo | 084 | Flute | 112 | Rock Kit |
| | | 058 | Harp | 085 | Piccolo | 113 | Electronic Kit |
| | | CHOIR | | | | 114 | Analog Kit |
| | | 059 | Choir | 086 | Pan Flute | 115 | Dance Kit |
| | | 060 | Vocal Ensemble | 087 | Recorder | 116 | Jazz Kit |
| | | | | 088 | Ocarina | 117 | Brush Kit |
| | | | | SYNTH LEAD | | | |
| | | | | 089 | Square Lead | 118 | Symphony Kit |
| | | | | | | 119 | SFX Kit 1 |
| | | | | | | 120 | SFX Kit 2 |

* This list includes only a portion of the total available voices.




Playing the Songs

The PSR-275/273 is packed with a total of 100 songs, including one Demo song — which has been specially created to showcase the rich and dynamic sounds of the instrument. There are also 99 additional songs, designed to be used with the educational Lesson feature.

Playing the Demo song


Let's play the Demo song now, Repeating with #001.

1 Start the Demo song.



You can also play back songs of other categories. Simply select the appropriate number of the desired song during playback.

2 Stop the Demo song.




NOTE

- Demo Cancel function that allows you to disable the Demo feature. To use this, simultaneously hold down the [DEMO] button and turn the power on ([STANDBY/ON] button). While the power is on in this condition, pressing the [DEMO] button has no effect. To turn Demo Cancel off, simply turn the power off and back on again normally.



Playing a single song

Naturally, you can also individually select and play back the PSR-275/273's songs.


1 Press the [SONG] button.



2 Select a song.



3 Start (and stop) the song.



Want to find out more? See page 45.

Song List


| No. | Song Name (Composer) | No. | Song Name (Composer) |
|------------------|--|---------------------|---|
| DEMO | | DUET | |
| 001 | Englishman In New York | 054 | Row Row Row Your Boat* |
| ORCHESTRA | | 055 | On Top Of Old Smoky* |
| 002 | Danse Des Mirlitons From "The Nutcracker" (P.I. Tchaikovsky) | 056 | We Wish You A Merry Christmas* |
| 003 | "Orphée Aux Enfers" Ouverture (J. Offenbach) | 057 | Scarborough Fair* |
| 004 | Slavonic Dances No.10 (A. Dvořák) | 058 | Im Mai* |
| 005 | La Primavera (From Le Quattro Stagioni) (A. Vivaldi) | 059 | O Christmas Tree* |
| 006 | Méditation De Thais (J. Massenet) | 060 | Mary Had A Little Lamb* |
| 007 | Guillaume Tell (G. Rossini) | 061 | Ten Little Indians (Septimus Winner) |
| 008 | Frühlingslied (F. Mendelssohn) | 062 | Pop Goes The Weasel* |
| 009 | Ungarische Tänze Nr.5 (J. Brahms) | 063 | Twinkle Twinkle Little Star* |
| PIANIST | | 064 | Close Your Hands, Open Your Hands (J.J. Rousseau) |
| 010 | Dolly's Dreaming And Awakening (T.Oesten) | 065 | The Cuckoo* |
| 011 | La Candeur (J.F.Burgmüller) | 066 | O Du Lieber Augustin* |
| 012 | Arabesque (J.F.Burgmüller) | 067 | London Bridge* |
| 013 | Pastorale (J.F.Burgmüller) | CHORD LESSON | |
| 014 | Petite Réunion (J.F.Burgmüller) | 068 | Bill Bailey (Won't You Please Come Home) (H. Cannon) |
| 015 | Innocence (J.F.Burgmüller) | 069 | When Irish Eyes Are Smiling (E.R. Ball) |
| 016 | Progrés (J.F.Burgmüller) | 070 | Down By The Riverside* |
| 017 | Tarentelle (J.F.Burgmüller) | 071 | When The Saints Go Marchin' In* |
| 018 | La Chevaleresque (J.F.Burgmüller) | 072 | Frühlingsstimmen (J. Strauss II) |
| 019 | Etude op.10-3 "Chanson De L'adieu" (F.Chopin) | 073 | Campyong Races (S.C. Foster) |
| 020 | Marcia Alla Turca (L.v. Beethoven) | 074 | Little Brown Jug (Joseph Winner) |
| 021 | Turkish March (W.A. Mozart) | 075 | Loch Lomond* |
| 022 | Valse op.64-1 "Petit Chien" (F.Chopin) | 076 | Oh! Susanna (S.C. Foster) |
| 023 | Menuett (L. Boccherini) | 077 | Greensleeves* |
| 024 | Nocturne op.9-2 (F. Chopin) | 078 | Aura Lee (G. Poulton) |
| 025 | Moments Musicaux op.94-3 (F. Schubert) | 079 | Silent Night (F. Gruber) |
| 026 | The Entertainer (S. Joplin) | 080 | The Danube Waves (I. Ivanovici) |
| 027 | Prelude (Wohltemperierte Klavier 1-1) (J.S. Bach) | 081 | Twinkle Twinkle Little Star* |
| 028 | La Violette (Streabbog) | 082 | Close Your Hands, Open Your Hands (J.J. Rousseau) |
| 029 | Für Elise (L.v. Beethoven) | 083 | The Cuckoo* |
| PRACTICE | | 084 | O Du Lieber Augustin* |
| 030 | America The Beautiful (S.A. Ward) | 085 | London Bridge* |
| 031 | Londonderry Air* | 086 | American Patrol (F.W. Meacham) |
| 032 | Ring De Banjo (S.C. Foster) | 087 | Beautiful Dreamer (S.C. Foster) |
| 033 | Wenn Ich Ein Vöglein Wär ?* | 088 | Battle Hymn Of The Republic* |
| 034 | Die Lorelei (F. Silcher) | 089 | Home Sweet Home (H. Bishop) |
| 035 | Funiculi-Funicula (L. Denza) | 090 | Valse Des Fleurs (From "The Nutcracker") (P.I. Tchaikovsky) |
| 036 | Turkey In The Straw* | 091 | Aloha Oe* |
| 037 | Old Folks At Home (S.C. Foster) | 092 | I've Been Working On The Railroad* |
| 038 | Jingle Bells (J.S. Pierpont) | 093 | My Darling Clementine* |
| 039 | Muss I Denn (F. Silcher) | 094 | Auld Lang Syne* |
| 040 | Liebesträume Nr.3 (F. Liszt) | 095 | Grandfather's Clock (H.C. Work) |
| 041 | Jesu, Joy Of Man's Desiring (J.S. Bach) | 096 | Amazing Grace* |
| 042 | Symphonie Nr.9 (L.v. Beethoven) | 097 | My Bonnie (H.J Fulmer) |
| 043 | Song Of The Pearl Fisher (G. Bizet) | 098 | Yankee Doodle* |
| 044 | Gavotte (F.J. Gossec) | 099 | Joy To The World (G.F. Händel) |
| 045 | String Quartet No.17 2nd mov. "Serenade" (F.J. Haydn) | 100 | Ave Maria (F.Schubert) |
| 046 | Menuett (J.S. Bach) | | |
| 047 | Canon (J. Pachelbel) | | |
| 048 | From "The Magic Flute" (W.A Mozart) | | |
| 049 | Piano Sonate op.27-2 "Mondschein" (L.v. Beethoven) | | |
| 050 | "The Surprise" Symphony (F.J. Haydn) | | |
| 051 | To A Wild Rose (E.A. MacDowell) | | |
| 052 | Air de Toréador "Carmen" (G. Bizet) | | |
| 053 | O Mio Babbino Caro (From "Gianni Schicchi") (G. Puccini) | | |

* indicates that is traditional song.

Changing the volume of the song


This lets you adjust the volume balance between the song and your keyboard performance.

- Press the [FUNCTION] button, until SongVol is indicated in the display.




- Use the [+]/[-] buttons to adjust the song volume.

You can also use the numeric keypad to directly enter the value.



Want to find out more? See page 48.




Using the Style

The powerful yet easy-to-use Style features give you professional instrumental backing for your performances. Simply play chords with your left hand — and the PSR-275/273 automatically produces appropriate bass, chord and rhythm backing. Use your right hand to play melodies, and you'll sound like an entire band!

NOTE

- For more information on playing proper chords for the auto accompaniment, see "Using Auto Accompaniment — Multi Fingering" on page 40 and "Dictionary" on page 42.




Left hand + Right hand


Auto accompaniment
(for example,
bass + guitar + drums)

Melody
(for example,
piano)


1 Press the [STYLE] button.



2 Select a style.




3 Turn the auto accompaniment on.



Looking up Chords in the Dictionary


The convenient Dictionary function teaches you how to play chords by showing you the individual notes. In the example below, we'll learn how to play a GM7 chord...




Learning how to play a specific chord

Example: **G M7**
Root note Chord type


- 1 Press the [Dict.] button.





- 2 Specify the root note of the chord (in this case, G).




- 3 Specify the chord type of the chord (in this case, M7).



- 4 Play the notes of the chord as indicated in the keyboard diagram in the display. The chord name flashes when the chord is played properly.




- 5 To leave the Dictionary function, press the [Dict.] button again.




Want to find out more? See page 42.

- 4 Turn the Sync Start function on.




- 5 Play a chord with your left hand.

The style starts as soon as you play the keyboard. For more on chords, see "Looking up Chords in the Dictionary" above.




- 6 Select a section.

The auto accompaniment has four sections: Intro, Main A/B, and Ending.



- 7 Stop the style.




Want to find out more? See page 34.



Basic Operation and LCD Display

Adjusting the Volume



Turn the [MASTER VOLUME] dial.



Name and Number indication (Song/Style /Voice)

Currently selected name and number (Song, Style or Voice) appear here.

For example, when song is selected:




Function settings and indications

This button lets you call up the various function settings.

| | | |
|----------|----------------|----------------------|
| FUNCTION | | |
| | OVERALL VOLUME |See page 60 |
| | VOLUME |See page 60 |
| | MAIN VOICE |See page 23, 60 |
| | DUAL VOICE |See page 25, 60 |
| | SPLIT VOICE |See page 26, 60 |
| | EFFECT/HARMONY |See page 29, 60 |
| | UTILITY |See page 60 |


Note that the function bar in the LCD indicates the function category (Overall, Volume, etc.) when you select each function, and the currently selected function name and value appears in the LCD.

For example, when Transpos is selected:



Setting values

● Use the numeric [0]-[9] buttons or [+]/[-] buttons.




Decreases the number by one step.

Increases the number by one step.

To continuously change the number up or down, press and hold the appropriate [+]/[-] button. To input a negative value, simultaneously hold the [-] button and enter the number.

Entering one of the modes (Song, Style or Voice)

- Pressing one of the buttons below calls up the appropriate mode — Song, Style or Voice, and the bar in the display indicates the currently selected mode.




- The following indications appear when you press the [VOICE] button in the Song or Style mode.

For selecting a voice in the Song mode.




For selecting a voice in the Style mode.



Entering numbers


- Use the [+]/[-] buttons when you want to change the number in single steps.



To continuously change the number up or down, press and hold the appropriate [+]/[-] button.

- To directly enter the desired number, use numeric buttons [0]-[9].

Ex. Voice number 109: Standard Kit 1



NOTE

- If the first digit or first two digits of the number are "0," (ex., 074 or 005), pressing the [0] button is unnecessary. However, pressing the [0] button is necessary if "0" is part of the number (ex., 105).

[PRESS AND HOLD FOR A WHILE] indication




Buttons having this indication can be used to call up an alternate function when the relevant button is pressed and held.

Hold down this button until the function name appears in the display.

Music Rest


Insert the bottom edge of the included music rest into the slot located at the top rear of the PSR-275/273 control panel.



Basic Operation and LCD Display

NOTATION

Normally, these indicate which keys or notes are played, or which keys to play when using the Dictionary function.



NOTE

- Any notes occurring below or above the staff are indicated by "8va" in the notation.
- In certain cases, a note may not be fully shown in the display.

MEASURE number

Indicates the current measure number of the song or style.

MEASURE 003

BEAT

Indicates the beat when a song or style is playing.





Accompaniment On (ACMP ON)

Indicates when accompaniment is on.

ACMP ON

KEYBOARD

Indicates notes being played currently. Also indicates the notes of a chord — either when playing a chord or when using the Dictionary function.



CHORD

Indicates the chord name when playing in the song or style mode.



DUAL

Indicates that the Dual Voice feature is turned on.

DUAL

HARMONY

Indicates that the Harmony feature is turned on.

HARMONY

SPLIT

Indicates that the Split feature is turned on.

SPLIT

SUSTAIN

Indicates that Sustain is turned on.

SUSTAIN

TOUCH

Indicates that Touch is turned on.

TOUCH





Portable Grand

This convenient function lets you instantly call up the Grand Piano voice.

Playing the Portable Grand

Press the [PORTABLE GRAND] button.



Doing this automatically selects the special “Stereo Sampled Piano” Grand Piano voice.


Using the Metronome

1 Call up the Tempo setting.

Press the [TEMPO/TAP] button.




Current Tempo value



2 Change the value.

Use the numeric keypad to set the desired Tempo value, or use the [+]/[-] buttons to increase or decrease the value.





Restoring the Default Tempo Value

Each song and style has been given a default or standard Tempo setting. If you've changed the Tempo, you can instantly restore the default setting by pressing both [+]/[-] buttons simultaneously (when Tempo is selected).


3 Turn on the Metronome.

Press the [METRONOME] button.

The beat number is indicated as follows (for a time signature of 4/4):



Indicates the beat number in the measure.



To turn the Metronome off, press the [METRONOME] button again.

Setting the Metronome Time Signature

The time signature of the Metronome can be set to various quarter-note based meters.


The Time Signature also can be set in the Function mode (page 60).

Press and hold the [METRONOME] button (until “TimeSig” appears in the display), then press the button on the numeric keypad or [+]/[-] buttons that corresponds to the desired time signature (see chart right).

| Numeric keypad | Time signature |
|----------------|--|
| 01 | 1/4 — Plays only “1” beats (all high clicks) |
| 02 | 2/4 |
| 03 | 3/4 |
| 04 | 4/4 |
| : | : |
| 15 | 15/4 |
| 0 | Plays no “1” beats (all low clicks) |

NOTE

- The time signature changes automatically when a style or song is selected.



Indicates current beat number.

Adjusting the Metronome Volume

You can adjust the volume of the Metronome sound in the *Function mode (page 60)*. The volume range is 000 - 127.




Playing Voices

The PSR-275/273 features a total of 480 authentic voices — all of which have been created with Yamaha’s sophisticated AWM (Advanced Wave Memory) tone generation system. These include 360 XG Lite voices and drum kits.

The PSR-275/273 also has a Dual Voice or Split Voice function that lets you combine two different voices in a layer, or play from separate areas of the keyboard, play the two together across the keyboard.

Playing a Voice

1 Press the [VOICE] button.



2 Select the desired voice number.

The categories of each voice and their numbers are shown on the panel. A complete voice list of the available voices is given on page 61.

VOICE

| | | |
|--------------------------|---------------------------|---------------------------|
| 001~006 PIANO | 059~062 CHOIR | 101~108 PERCUSSION |
| 007~012 E. PIANO | 063~071 SAXOPHONE | 109~120 DRUM KITS |
| 013~024 ORGAN | 072~077 TRUMPET | 121~480 XGLite |
| 025~028 ACCORDION | 078~083 BRASS | 000 OTS |
| 029~038 GUITAR | 084~088 FLUTE | |
| 039~046 BASS | 089~095 SYNTH LEAD | |
| 047~058 STRINGS | 096~100 SYNTH PAD | |

NOTE

- Selecting the #000 OTS voice calls up a convenient feature — automatically selecting an appropriate voice to best match the current style or song.

3 Play the selected voice.

Since either the Style or Song mode is active in the background, you can also play styles or songs, respectively, in the Voice mode by simply pressing the [START/STOP] button. The last selected style, or song will be played.




The following parameteres can be set in the Function mode (page 60).

| CATEGORY | SELECT |
|------------|-------------------|
| Main Voice | Volume |
| | Octave |
| | Reverb Send Level |
| | Chorus Send Level |

#000 OTS

This special “voice” is actually a convenient feature which automatically selects a suitable voice for you when you select a style or a song. The voice is selected to best match the style or song you’ve called up.

Select voice #000 (OTS).




Dual Voice

The Dual Voice function lets you combine two different voices in a layer — one the Main voice, which is selected normally, and the other the Dual voice, which is selected in the *Function mode (page 60)*. You can also set various parameters independently for these voices, such as giving them separate volume, octave, Reverb, and Chorus settings. This lets you create an optimum mix for the voices, and enhance the way they blend together.

The following parameters can be set in the Function mode (page 60).

| CATEGORY | SELECT |
|------------|-------------------|
| Dual Voice | Voice |
| | Volume |
| | Octave |
| | Reverb Send Level |
| | Chorus Send Level |

To turn the Dual Voice on or off, press the [DUAL] button.



Split Voice


The Split Voice function lets you assign two different Voices to opposite areas of the keyboard, and play one Voice with your left hand while your right plays another.

For example, you could play bass with the left hand and play piano with the right. The right-hand (or upper) Voice is selected in the Main Voice mode (page 23), and the left-hand (or lower) Voice is selected in the *Function mode (page 60)*, along with the other Split Voice parameters shown below.

The following parameters can be set in the Function mode (page 60).


| CATEGORY | SELECT |
|-------------|-------------------|
| Split Voice | Voice |
| | Volume |
| | Octave |
| | Reverb Send Level |
| | Chorus Send Level |

To turn the Split Voice on or off, press the [SPLIT] button.



Setting the Split Point

The Split Point determines the highest key for the split voice and sets the split point.



NOTE


- This setting also affects the split point for the accompaniment area.

Split Point can be set in the Function mode (page 60).

Touch and Touch Sensitivity


The PSR-275/273 features a Touch Response function that gives you dynamic, expressive control over the volume of the voices. The Touch Sensitivity parameter lets you set the degree of Touch Response.

- 1 Turn the Touch function on or off as desired by pressing the [TOUCH] button.



- 2 Changing the Touch Sensitivity Value.

Press and hold down the [TOUCH] button, then press the appropriate numbered button on the numeric keypad: 1, 2, 3, or [+]/[-].



Sensitivity can also be set in the Function mode (page 60).

● Settings:

| | |
|-------------------|--|
| 1 (Soft) | This results in limited touch response, and produces a relatively narrow dynamic range, no matter how lightly or strongly you play the keys. |
| 2 (Medium) | This lets you play over a normal dynamic range (soft to loud). |
| 3 (Hard) | This is designed for playing very soft passages, giving you slightly more detailed control in the soft volume range. |

When Touch is turned off, a constant volume (corresponding to a velocity value of 80) is produced.

Restoring the Default Touch Sensitivity Value

The default Touch Sensitivity is 2 (Medium). To restore the default value, press both [+]/[-] buttons simultaneously (when Touch Sensitivity is selected).



The PSR-275/273 is equipped with a wide variety of effects that can be used to enhance the sound of the voices. The PSR-275/273 has three separate effect systems — Harmony, Reverb and Chorus — and each has many different effect types to choose from.



Harmony

The Harmony section features a variety of performance effects that enhance the melodies you play when using the accompaniment styles of the PSR-275/273. A total of twenty-six Harmony types are available. (See page 31.)

Tremolo, Trill and Echo effects can be used even if accompaniment is off. There are five different Harmony Types that automatically create harmony parts (for notes played in the upper area of the keyboard) to match the accompaniment chords.

Turn on/off the Harmony effect.

Press the [HARMONY] button.



IMPORTANT

- For the first five Harmony Types (Duet, Trio, Block, Country, and Octave), chords must be played in the Accompaniment area of the keyboard. The Harmony voice(s) change in pitch to best match the chords you play.
- The speed of the Trill, Tremolo, and Echo effects depends on the Tempo setting (page 31).

NOTE

- Each voice of the PSR-275/273 has its own independent Harmony setting.

Harmony type and Harmony Volume (when Harmony Type 1 - 5 is selected) can be set in the Function mode (page 60).

Reverb

The Reverb effect reproduces the natural ambient “wash” of sound that occurs when a instrument is played in a room or concert hall. A total of nine different Reverb types simulating various different performance environments are available. (See page 32.)

The following parameters can be set in the Function mode (pages 60).

| CATEGORY | SELECT |
|-------------|-------------------|
| Effect | Reverb Type |
| Main Voice | Reverb Send Level |
| Dual Voice | Reverb Send Level |
| Split Voice | Reverb Send Level |

NOTE

- Nine additional Reverb Types are available when controlling the PSR-275/273 from a MIDI device. (For details, See page 69.)
- Each style of the PSR-275/273 has its own independent Reverb setting.

Chorus

The Chorus effect lets you enhance the sound of the voices with the use of pitch modulation. Two basic types are provided: Chorus and Flanger. Chorus produces a thicker, warmer, and more animated sound, whereas Flanger creates a swirling, metallic effect. A total of four Chorus types are available. (See page 32.)

The following parameters can be set in the Function mode (pages 60).


| CATEGORY | SELECT |
|-------------|-------------------|
| Effect | Chorus Type |
| Main Voice | Chorus Send Level |
| Dual Voice | Chorus Send Level |
| Split Voice | Chorus Send Level |

Sustain

The Sustain effect automatically adds a slow, natural decay to the voice sound when the keys are released.






















Turn on/off the Sustain effect.

Press the [SUSTAIN] button.



■ Effect Types

● Harmony Types

| No. | Harmony Type | Display Name | | Description |
|-----|-------------------|--------------|---|--|
| 1 | Duet | Duet | | Harmony types 1 - 5 are pitch-based and add one-, two- or three-note harmonies to the single-note melody played in the right hand. These types only sound when chords are played in the auto accompaniment area of the keyboard. |
| 2 | Trio | Trio | | |
| 3 | Block | Block | | |
| 4 | Country | Country | | |
| 5 | Octave | Octave | | |
| 6 | Trill 1/4 note | Tril1/4 |  | Types 6 - 26 are rhythm-based effects and add embellishments or delayed repeats in time with the auto accompaniment. These types sound whether the auto accompaniment is on or not; however, the actual speed of the effect depends on the Tempo setting (page 38). The individual note values in each type let you synchronize the effect precisely to the rhythm. Triplet settings are also available: 1/6 = quarter-note triplets, 1/12 = eighth-note triplets, 1/24 = sixteenth-note triplets. <ul style="list-style-type: none"> The Trill effect Types (6 - 12) create two-note trills (alternating notes) when two notes are held. The Tremolo effect Types (13 - 19) repeat all held notes (up to four). The Echo effect Types (20 - 26) create delayed repeats of each note played. |
| 7 | Trill 1/6 note | Tril1/6 |  | |
| 8 | Trill 1/8 note | Tril1/8 |  | |
| 9 | Trill 1/12 note | Tril1/12 |  | |
| 10 | Trill 1/16 note | Tril1/16 |  | |
| 11 | Trill 1/24 note | Tril1/24 |  | |
| 12 | Trill 1/32 note | Tril1/32 |  | |
| 13 | Tremolo 1/4 note | Trem1/4 |  | |
| 14 | Tremolo 1/6 note | Trem1/6 |  | |
| 15 | Tremolo 1/8 note | Trem1/8 |  | |
| 16 | Tremolo 1/12 note | Trem1/12 |  | |
| 17 | Tremolo 1/16 note | Trem1/16 |  | |
| 18 | Tremolo 1/24 note | Trem1/24 |  | |
| 19 | Tremolo 1/32 note | Trem1/32 |  | |
| 20 | Echo 1/4 note | Echo1/4 |  | |
| 21 | Echo 1/6 note | Echo1/6 |  | |
| 22 | Echo 1/8 note | Echo1/8 |  | |
| 23 | Echo 1/12 note | Echo1/12 |  | |
| 24 | Echo 1/16 note | Echo1/16 |  | |
| 25 | Echo 1/24 note | Echo1/24 |  | |
| 26 | Echo 1/32 note | Echo1/32 |  | |

Effects

● Reverb Types

| No. | Reverb Type | Display Name | Description |
|-----|-------------|--------------|-------------------------------|
| 1 | Hall 1 | Hall1 | Concert hall reverb. |
| 2 | Hall 2 | Hall2 | |
| 3 | Hall 3 | Hall3 | |
| 4 | Room 1 | Room1 | Small room reverb. |
| 5 | Room 2 | Room2 | |
| 6 | Stage 1 | Stage1 | Reverb for solo instruments. |
| 7 | Stage 2 | Stage2 | |
| 8 | Plate 1 | Plate1 | Simulated steel plate reverb. |
| 9 | Plate 2 | Plate2 | |
| 10 | Off | Off | No effect. |

● Chorus Types

| No. | Chorus Type | Display Name | Description |
|-----|-------------|--------------|---|
| 1 | Chorus 1 | Chorus1 | Conventional chorus program with rich, warm chorusing. |
| 2 | Chorus 2 | Chorus2 | |
| 3 | Flanger 1 | Flanger1 | Pronounced three-phase modulation with a slight metallic sound. |
| 4 | Flanger 2 | Flanger2 | |
| 5 | Off | Off | No effect. |



Selecting and Playing Styles

The PSR-275/273 provides dynamic rhythm/accompaniment patterns (styles) — as well as voice settings appropriate for each style — for various popular musical categories.


A total of 100 different styles are available, in several different categories. Each style is made up of separate “sections” — Intro, Main A and B, and Ending — letting you call up different accompaniment sections as you perform.

The auto accompaniment features that are built into the rhythms add the excitement of instrumental backing to your performance, letting you control the accompaniment by the chords you play. Auto accompaniment effectively splits the keyboard into two areas: The upper is used for playing a melody line, and the lower (set by default to keys F#2 and lower) is for the auto accompaniment function.

The PSR-275/273 also features the convenient Dictionary function (page 42). Dictionary provides you with a built-in “chord encyclopedia” that teaches you how to play any chord you specify by showing you the appropriate notes in the display.

Selecting a Style

1 Press the [STYLE] button.



2 Select the desired style number.

The categories of each styles and their numbers are shown on the panel. A complete style list of the available styles is given on page 65.

STYLE

| | |
|-----------------------------|----------------------------|
| 001~010 8BEAT | 055~058 COUNTRY |
| 011~016 16BEAT | 059~066 LATIN |
| 017~023 BALLAD | 067~077 BALLROOM |
| 024~035 DANCE | 078~087 TRADITIONAL |
| 036~039 DISCO | 088~092 WALTZ |
| 040~047 SWING & JAZZ | 093~100 PIANIST |
| 048~054 R & B | |


Selecting and Playing Styles

■ Use the numeric keypad.

Style numbers can be selected in the same way as with the voices (page 19). You can use the numeric keypad to directly enter the style number, or use the [+]/[-] buttons to step up and down through the styles.


NOTE

- Rhythm sounds and fill-in sections are not available when one of the Pianist styles (#93 - #100) are selected.




Playing the Styles

The panel buttons below function as style controls.



1 Turn on the auto accompaniment.

Press the [ACMP ON/OFF] button to turn on (enable) the auto accompaniment.




2 Start the style.


You can do this in one of the following ways:

■ Pressing the [START/STOP] button

The rhythm starts playing immediately without bass and chord accompaniment. The currently selected Main A or B section will play.



You can select the Main A or B section by pressing the appropriate button — [MAIN A/B] — before pressing the [START/STOP] button. (The display shows the letter of the selected section: “MAIN A” or “MAIN B.”)



■ Using Tap Tempo to Start


This useful feature lets you tap out the speed (tempo) of the style and automatically start the style at that tapped speed.



Simply tap the [TEMPO/TAP] button four times (or three times for a 3/4 time style), and the style starts automatically at the tempo you tapped. You can also change the tempo while the style is playing by tapping the [TEMPO/TAP] button twice at the desired tempo.

■ Using Sync Start

The PSR-275/273 also has a Sync Start function that allows you to start the style by simply pressing a key on the keyboard. To use Sync Start, first press the [SYNC START] button (the beat mark flashes to indicate Sync Start stand-by), then press any key on the keyboard. (When auto accompaniment is on, play a key or chord in the auto accompaniment area of the keyboard.)




Selecting and Playing Styles

Starting with an Intro section


Each style has its own two- or four-measure Intro section. When used with the auto accompaniment, many of the Intro sections also include special chord changes and embellishments to enhance your performance.

To start with an Intro section:

- 1) Press the [MAIN/AUTO FILL] button — to select which section (A or B) is to follow the Intro.



- 2) Press the [INTRO/ENDING/rit.] button.




To actually start the Intro section, press the [START/STOP] button.

Using Sync Start with an Intro section


You can also use the Sync Start function with the special Intro section of the selected style.

To use Sync Start with an Intro section:


- 1) Press the [MAIN/AUTO FILL] button — to select which section (A or B) is to follow the Intro.



- 2) Press the [INTRO/ENDING/rit.] button.



- 3) Press the [SYNC START] button to enable Sync Start, and start the Intro section and accompaniment by playing any key on the keyboard. (When auto accompaniment is on, play a key or chord in the auto accompaniment area of the keyboard.)



3 Change chords using the auto accompaniment feature.

Try playing a few successive chords with your left hand, and notice how the bass and chord accompaniment change with each chord you play. (Refer to page 40 for more information on how to use auto accompaniment.)

HINT

- The [ACMP ON/OFF] button can also be used to turn off and on the bass/chord accompaniment while playing — allowing you to create dynamic rhythmic breaks in your performance.

NOTE

- Chords played in the auto accompaniment area of the keyboard are also detected and played when the style is stopped. In effect, this gives you a “split keyboard,” with bass and chords in the left hand and the normally selected voice in the right.

4 Stop the style.


You can do this in one of three ways:

■ Pressing the [START/STOP] button

The style stops playing immediately.

■ Using an Ending section

Press the [INTRO/ENDING/rit.] button. The style stops after the Ending section is finished.



■ Pressing the [SYNC START] button

This immediately stops the style and automatically enables Sync Start, letting you restart the style by simply playing a chord or key in the auto accompaniment area of the keyboard.

To have the Ending section gradually slow down (ritardando) as it is playing, press the [INTRO/ENDING/rit.] button twice quickly.




Changing the Tempo

The tempo of style playback can be adjusted over a range of 32 - 280 bpm (beats per minute).

1 Call up the Tempo setting.

Press the [TEMPO/TAP] button.




NOTE

- When style playback is stopped and a different style is selected, the tempo returns to the default setting of the new style. When switching styles during playback, the last tempo setting is maintained. (This allows you to keep the same tempo, even when changing styles.)

2 Change the value.

Use the numeric keypad to set the desired Tempo value, or use the [+]/[-] buttons to increase or decrease the value.



Restoring the Default Tempo Value

Each song and style has been given a default or standard Tempo setting. If you've changed the Tempo, you can instantly restore the default setting by pressing both [+]/[-] buttons simultaneously (when Tempo is selected).

HINT

- You can also use the convenient Tap Tempo function to change the tempo by "tapping" a new one in real time. (See page 35.)

About the Beat Display


This section of the display provides a convenient, easy-to-understand indication of the rhythm — for song and style playback. The flashing “handclap” icons indicate both the downbeats and upbeats of a measure as follows:

| | |
|--|--|
| | Indicates the first beat of the measure (downbeat) |
| | Indicates an upbeat |
| | Indicates a downbeat (other than the first beat) |

Accompaniment Sections (Main A/B and Fill-ins)

While the style is playing, you can add variation in the rhythm/accompaniment by pressing the [MAIN/AUTO FILL] button. This switches between the Main A and Main B sections, automatically playing a fill-in pattern to smoothly lead into the next section. For example, if the Main A section is currently playing, pressing this button automatically plays a fill-in pattern, followed by the Main B section. (See illustration below.)

You can also select either the Main A or B section to start by pressing the [MAIN/AUTO FILL] button before starting the style.




About the Fill-in Patterns

If you press the [MAIN/AUTO FILL] button before beat 4...

...a fill-in pattern plays immediately until the end of the measure...

...and the Main A or B section begins here.



If you press the [MAIN/AUTO FILL] button here, after beat 4...

...a fill-in pattern plays from here...

...and the Main A or B section begins here.

Adjusting the Style Volume

The playback volume of the style can be adjusted in the *Function mode* (page 60). This volume control affects only the Style volume. The volume range is 000 - 127.

NOTE

- Style Volume cannot be changed unless the Style mode is active.

Selecting and Playing Styles

| Chord Name/[Abbreviation] | Normal Voicing | Chord (C) | Display |
|--|---|-----------|----------|
| Major [M] | 1 - 3 - 5 | C | C |
| Add ninth [(9)] | 1 - 2 - 3 - 5 | C(9) | C(9) |
| Sixth [6] | 1 - (3) - 5 - 6 | C6 | C6 |
| Sixth ninth [6(9)] | 1 - 2 - 3 - (5) - 6 | C6(9) | C6(9) |
| Major seventh [M7] | 1 - 3 - (5) - 7 or 1 - (3) - 5 - 7 | CM7 | CM7 |
| Major seventh ninth [M7(9)] | 1 - 2 - 3 - (5) - 7 | CM7(9) | CM7(9) |
| Major seventh add sharp eleventh [M7(#11)] | 1 - (2) - 3 - #4 - 5 - 7 or 1 - 2 - 3 - #4 - (5) - 7 | CM7(#11) | CM7(#11) |
| Flatted fifth [(b5)] | 1 - 3 - b5 | C(b5) | Cb5 |
| Major seventh flatted fifth [M7b5] | 1 - 3 - b5 - 7 | CM7b5 | CM7b5 |
| Suspended fourth [sus4] | 1 - 4 - 5 | Csus4 | Csus4 |
| Augmented [aug] | 1 - 3 - #5 | Caug | Caug |
| Major seventh augmented [M7aug] | 1 - (3) - #5 - 7 | CM7aug | CM7aug |
| Minor [m] | 1 - b3 - 5 | Cm | Cm |
| Minor add ninth [m(9)] | 1 - 2 - b3 - 5 | Cm(9) | Cm(9) |
| Minor sixth [m6] | 1 - b3 - 5 - 6 | Cm6 | Cm6 |
| Minor seventh [m7] | 1 - b3 - (5) - b7 | Cm7 | Cm7 |
| Minor seventh ninth [m7(9)] | 1 - 2 - b3 - (5) - b7 | Cm7(9) | Cm7(9) |
| Minor seventh add eleventh [m7(11)] | 1 - (2) - b3 - 4 - 5 - (b7) | Cm7(11) | Cm7(11) |
| Minor major seventh [mM7] | 1 - b3 - (5) - 7 | CmM7 | CmM7 |
| Minor major seventh ninth [mM7(9)] | 1 - 2 - b3 - (5) - 7 | CmM7(9) | CmM7(9) |
| Minor seventh flatted fifth [m7b5] | 1 - b3 - b5 - b7 | Cm7b5 | Cm7b5 |
| Minor major seventh flatted fifth [mM7b5] | 1 - b3 - b5 - 7 | CmM7b5 | CmM7b5 |
| Diminished [dim] | 1 - b3 - b5 | Cdim | Cdim |
| Diminished seventh [dim7] | 1 - b3 - b5 - 6 | Cdim7 | Cdim7 |
| Seventh [7] | 1 - 3 - (5) - b7 or 1 - (3) - 5 - b7 | C7 | C7 |
| Seventh flatted ninth [7(b9)] | 1 - b2 - 3 - (5) - b7 | C7(b9) | C7(b9) |
| Seventh add flatted thirteenth [7(b13)] | 1 - 3 - 5 - b6 - b7 | C7(b13) | C7(b13) |
| Seventh ninth [7(9)] | 1 - 2 - 3 - (5) - b7 | C7(9) | C7(9) |
| Seventh add sharp eleventh [7(#11)] | 1 - (2) - 3 - #4 - 5 - b7 or 1 - 2 - 3 - #4 - (5) - b7 | C7(#11) | C7(#11) |
| Seventh add thirteenth [7(13)] | 1 - 3 - (5) - 6 - b7 | C7(13) | C7(13) |
| Seventh sharp ninth [7(#9)] | 1 - #2 - 3 - (5) - b7 | C7(#9) | C7(#9) |
| Seventh flatted fifth [7b5] | 1 - 3 - b5 - b7 | C7b5 | C7b5 |
| Seventh augmented [7aug] | 1 - 3 - #5 - b7 | C7aug | C7aug |
| Seventh suspended fourth [7sus4] | 1 - 4 - (5) - b7 | C7sus4 | C7sus4 |
| One plus two plus five [1+2+5] | 1 - 2 - 5 | C1+2+5 | C |


NOTE

- Notes in parentheses can be omitted.
- Playing two same root keys in the adjacent octaves produces accompaniment based only on the root.
- A perfect fifth (1 + 5) produces accompaniment based only on the root and fifth which can be used with both major and minor chords.
- The chord fingerings listed are all in "root" position, but other inversions can be used — with the following exceptions:
 - m7, m7b5, 6, m6, sus4, aug, dim7, 7b5, 6(9), 1+2+5.
- Inversion of the 7sus4 and m7(11) chords are not recognized if the notes shown in parentheses are omitted.
- The auto accompaniment will sometimes not change when related chords are played in sequence (e.g. some minor chords followed by the minor seventh).
- Two-note fingerings will produce a chord based on the previously played chord.

Dictionary


The Dictionary function is essentially a built-in “chord book” that shows you the individual notes of chords. It is ideal when you know the name of a certain chord and want to quickly learn how to play it.

1 Press the [Dict.] button.




2 Specify the root of the chord.

Press the key on the keyboard that corresponds to the desired chord root (as printed on the panel).




Pressing this key selects the root G.




3 Specify the type of the chord (major, minor, seventh, etc.).

Press the key on the keyboard that corresponds to the desired chord type (as printed on the panel).



Pressing this key selects the major seventh chord type (M7).




NOTE

- For a few specific chords, not all notes may be shown in the notation section of the display. This is due to space limitations in the display.
- You can also show the inversion of chord when using [+]/[-] button.

4 Play the chord.


Play the chord (as indicated in the display) in the chord area of the keyboard. The chord name flashes in the display when the correct notes are held down. (Inversions for many of the chords are also recognized.)



To leave the Dictionary function, press the [Dict.] button again.

..... What is a Chord?

The simple answer: Three or more notes played simultaneously is a chord. (Two notes played together is an “interval” — an interval being the distance between two different notes. This is also referred to as a “harmony.”) Depending on the intervals between the three or more notes, a chord can sound beautiful or muddy and dissonant.



The organization of notes in the example at left — a triad chord — produces a pleasant, harmonious sound. Triads are made up of three notes and are the most basic and common chords in most music.

In this triad, the lowest note is the “root.” The root is the most important note in the chord, because it anchors the sound harmonically by determining its “key” and forms the basis for how we hear the other notes of the chord.

The second note of this chord is four semitones higher than the first, and the third is three semitones higher than the second. Keeping our root note fixed and changing these notes by a semitone up or down (sharp or flat), we can create four different chords.

| | | | |
|--|---|---|--|
| <p>Major chord (ex. C)</p> <p>Minor 3rd Major 3rd</p> | <p>Minor chord (ex. Cm)</p> <p>Major 3rd Minor 3rd</p> | <p>Augmented chord (ex. Caug)</p> <p>Major 3rd Major 3rd</p> | <p>Diminished chord (ex. Cdim)</p> <p>Minor 3rd Minor 3rd</p> |
|--|---|---|--|

Keep in mind that we can also change the “voicing” of a chord — for example, change the order of the notes (called “inversions”), or play the same notes in different octaves — without changing the basic nature of the chord itself.

Inversion examples for the key of C



Beautiful sounding harmonies can be built in this manner. The use of intervals and chords is one of the most important elements in music. A wide variety of emotions and feelings can be created depending on the types of chords used and the order in which they are arranged.

..... Writing Chord Names

Knowing how to read and write chord names is an easy yet invaluable skill. Chords are often written in a kind of shorthand that makes them instantly recognizable (and gives you the freedom to play them with the voicing or inversion that you prefer). Once you understand the basic principles of harmony and chords, it's very simple to use this shorthand to write out the chords of a song.


First, write the root note of the chord in an uppercase letter. If you need to specify sharp or flat, indicate that to the right of the root. The chord type should be indicated to the right as well. Examples for the key of C are shown below.

| | | | |
|---|-------------|-----------------|------------------|
| Major chord | Minor chord | Augmented chord | Diminished chord |
| C | Cm | Caug | Cdim |
| For simple major chords, the type is omitted. | | | |

One important point: Chords are made up of notes “stacked” on top of each other, and the stacked notes are indicated in the chord name of the chord type as a number — the number being the distance of the note from the root. (See the keyboard diagram below.) For example, the minor 6th chord includes the 6th note of the scale, the major 7th chord has the 7th note of the scale, etc.

The Intervals of the Scale

To better understand the intervals and the numbers used to represent them in the chord name, study this diagram of the C major scale:



Other Chords

Csus4

5th 4th

C7

Dominant 7th Major chord

Cm7

Dominant 7th Minor chord

CM7

7th Major chord

Cm7b5

Dominant 7th Diminished chord

Cm6

Minor chord 6th

C(9)

9th

Cdim7

Diminished 7th (double flatted 7th) Diminished chord

* Bbb = A




Selecting and Playing Songs

The Song mode features 100 special songs that have been created using the rich and dynamic sounds of the PSR-275/273.

The songs are generally for your listening enjoyment; however, you can also play along with them on the keyboard. The songs of the PSR-275/273 can also be used with the powerful Lesson feature (page 49), a convenient tool that makes learning songs fun and easy.

Selecting a Song

1 Press the [SONG] button.




2 Select the desired song number.

The categories of each song and their numbers are shown on the panel. A complete list of the available songs is given on page 15.

| SONG | |
|---------|--------------|
| 001 | DEMO |
| 002~009 | ORCHESTRA |
| 010~029 | PIANIST |
| 030~053 | PRACTICE |
| 054~067 | DUET |
| 068~100 | CHORD LESSON |


■ Use the numeric keypad.

Song numbers can be selected in the same way as with the voices (page 19). You can use the numeric keypad to directly enter the song number, or use the [+]/[-] buttons to step up and down through the song.




Playing the Songs

The Panel buttons below function as Song controls.



1 Start the selected song.

Press the [START/STOP] button. As the song plays back, the measure number and playing keys are shown in the display.



NOTE

- You can play along with the song using the currently selected voice, or even select a different voice for playing along. Simply call up the Voice mode while the song is playing back and select the desired voice. (See page 23.)

2 Stop the song.


Press the [START/STOP] button. If playback was started by pressing the [START/STOP] button, the selected song stops automatically.

A-B Repeat

The convenient A-B Repeat function is an ideal aid for practicing and learning. It allows you to specify a phrase of a song (between point A and point B) and repeat it — while you play or practice along with it.

1 While playing a song, set point A (the start point).

During playback, press the [A-B REPEAT] button once, at the beginning point to be repeated.




NOTE

- The A and B points can only be specified at the beginning of a measure (beat 1), and not at any point in the middle of a measure.
- To set the A point to the beginning of a song, press the [A-B REPEAT] button before starting playback.

2 Set point B (the end point).

As the song continues playing, press the [A-B REPEAT] button once again, at the ending point to be repeated. The selected phrase repeats indefinitely until stopped.




HINT

- If you're repeat practicing a particularly difficult section, try slowing down the Tempo to an appropriate speed to make it easier to play and master the part. You may also want to slow down the Tempo while setting the A and B points; this makes it easier to accurately set the points.
- You can also set the A-B Repeat function when the song is stopped. Simply use the [REW] and [FF] buttons to select the desired measures, pressing the [A-B REPEAT] button for each point, then start playback.


3 Pause or stop playback as needed.

Use the [PAUSE] button or [START/STOP] button. Stopping playback does not cancel the set A/B points or the A-B Repeat function.



4 Turn off the A-B Repeat function.

Press the [A-B REPEAT] button.



Selecting and Playing Songs

Melody Voice Change

The PSR-275/273 lets you play a melody on the keyboard along with each of the songs, either with the original melody voice or one of your own selection. The convenient Melody Voice Change feature takes this one step further — it lets you replace the original voice used for the melody of the song with the panel voice of your own selection. For example, if the current voice selected on the panel is piano but the song's melody is being played by a flute voice, using Melody Voice Change will change the flute melody voice to piano.

1 Select the desired song.

Press the [SONG] button, then use the numeric keypad or [+]/[-] buttons to select the desired song. (See page 45.)

2 Select the desired voice.

Press the [VOICE] button, then use the numeric keypad or [+]/[-] buttons to select the desired voice. (See page 23.)

3 Press and hold down the [VOICE] button for at least one second.

“MELODY VOICE CHANGE” appears in the display, indicating that the selected panel voice has replaced the song's original melody voice.



NOTE

- Playing a voice which is selected by the melody voice change may differ from the original voice, since the voice is added as an effect for the selected song.

Adjusting the Song Volume

The playback volume of the song can be adjusted in the *Function mode* (page 60). This volume control affects only the Song volume. The volume range is 000 - 127.

NOTE

- Song Volume cannot be changed unless the Song mode is active. (This function becomes Style Volume when the Style mode is active.)



Song Lesson

The Lesson feature provides an exceptionally fun and easy-to-use way to learn how to read music and play the keyboard. Lesson lets you practice the left- and right-hand parts of each song independently, step by step, until you've mastered them and are ready to practice with both hands together. These practices are divided into four Lesson steps, as described below. Lessons 1 - 3 apply to each hand; press the appropriate button, [L] (left) or [R] (right) to select the desired part for practice.

■ Lesson 1 — Timing

This lesson step lets you practice just the timing of the notes — any note can be used, as long as you play in rhythm.

■ Lesson 2 — Waiting

In this lesson step, the PSR-275/273 waits for you to play the correct notes before continuing playback of the song.

■ Lesson 3 — Minus One

This lesson step plays back the song with one part muted, letting you play and master the missing part yourself — in rhythm and at the proper tempo.


■ Lesson 4 — Both Hands

Lesson 4 is a “Minus One” practice essentially the same as Lesson 3, except that both the left- and right-hand parts are muted — letting you play and master both hands at the same time.

Using the Lesson Feature


1 Select one of the Lesson songs.

Press the [SONG] button, then use the numeric keypad or [+] / [-] buttons to select the desired song.




2 Select the part you wish to work on (left or right) and the Lesson step.

If you want to work on the right-hand part, press the [R] button; to work on the left, press the [L] button. Pressing either button repeatedly cycles through the available Lesson steps in order: Lesson 1 → Lesson 2 → Lesson 3 → Off → Lesson 1, etc. The selected Lesson step is indicated in the display.




To select Lesson 4, press both [L] and [R] buttons simultaneously.




3 Start the Lesson.

The Lesson and song playback start automatically (following a lead-in count) as soon as the Lesson step is selected. When the Lesson is finished, your performance “grade” is shown in the display (if the Grade function is turned on; page 53). After a short pause, the Lesson begins again automatically.



4 Press the [START/STOP] button to stop the Lesson.



The PSR-275/273 exits from the Lesson feature automatically when the [START/STOP] button is pressed.

Lesson 1 — Timing

This lesson step lets you practice just the timing of the notes — any note can be used, as long as you play in rhythm. Pick a note to play. For the left hand, use a note in the auto accompaniment area or play the appropriate left-hand note; for the right, play a note above F#2. Simply concentrate on playing each note in time with the rhythmic accompaniment.


NOTE

- The melody note does not sound unless your playing is in time with the rhythm.

1 Select one of the Lesson songs.

2 Select Lesson 1.

Press the [L] or [R] button (repeatedly, if necessary) until Lesson 1 is indicated.




3 Play the appropriate melody or chord with the song.

After the lead-in, the song starts automatically, and the appropriate notes appear in the display. In Lesson 1, simply play one note repeatedly in time with the music.

Regarding chords and the use of the left hand, the PSR-275/273 actually has two different types of songs: 1) songs with normal left-hand chords, and 2) songs in which the left hand plays arpeggios or melodic figures in combination with the right.

In the case of the first type, play the chords with your left hand in the auto accompaniment area of the keyboard.



Lesson 2 — Waiting

In this lesson step, the PSR-275/273 waits for you to play the correct notes before continuing playback of the song. This lets you practice reading the music at your own pace. The notes to be played are shown in the display, one after another, as you play them correctly.

1 Select one of the Lesson songs.

2 Select Lesson 2.

Press the [L] or [R] button (repeatedly, if necessary) until Lesson 2 is indicated.



[r2] Waiting

3 Play the appropriate melody or chord with the song.

After the lead-in, the song starts automatically, and the appropriate notes appear in the display. In Lesson 2, play the correct notes at your own pace, until you can master playing them in rhythm.

Lesson 3 — Minus One

This lesson step lets you practice one part of the song in rhythm at the proper tempo. The PSR-275/273 plays back the song accompaniment with one part muted (either the left part or the right)—letting you play and master the missing part yourself. The notes you are to play are shown continuously in the display as the song plays back.

1 Select one of the Lesson songs.

2 Select Lesson 3.

Press the [L] or [R] button (repeatedly, if necessary) until Lesson 3 is indicated.



[r3] MinusOne

3 Play the appropriate part with the song.

After the lead-in, the song starts automatically, and the appropriate notes appear in the display. In Lesson 3, listen carefully to the un-muted part, and play the muted part yourself.

Lesson 4 — Both Hands

Lesson 4 is a “Minus One” practice essentially the same as Lesson 3, except that both the left- and right-hand parts are muted — letting you play and master both hands at the same time. Go on to this lesson step after you’ve mastered each hand’s part in the previous three lesson steps. Practice both hands in time with the rhythm along with the notation in the display.

1 Select one of the Lesson songs.

2 Select Lesson 4.

Press the [L] and [R] buttons simultaneously, so that Lesson 4 is indicated.



[L-R] BothHand

3 Play both the left- and right-hand parts with the song.

After the lead-in, the song starts automatically, and the appropriate notes appear in the display. In Lesson 4, both parts (left and right) are muted, letting you play the entire song by yourself.

Grade

The Lesson feature has a built-in evaluation function that monitors your practicing of the Lesson songs, and just like a real teacher, it indicates how well you did each exercise. Four grades are assigned, depending on your performance: “Try Again,” “Good,” “Very Good!,” and “Excellent!”




MIDI Functions

The PSR-275/273 is MIDI-compatible, featuring MIDI IN and MIDI OUT terminals and providing a variety of MIDI-related controls. By using the MIDI functions you can expand your musical possibilities. This section explains what MIDI is, and what it can do, as well as how you can use MIDI on your PSR-275/273.

What Is MIDI?


No doubt you have heard the terms “acoustic instrument” and “digital instrument.” In the world today, these are the two main categories of instruments. Let’s consider an acoustic piano and a classical guitar as representative acoustic instruments. They are easy to understand. With the piano, you strike a key, and a hammer inside hits some strings and plays a note. With the guitar, you directly pluck a string and the note sounds. But how does a digital instrument go about playing a note?

Acoustic guitar note production



Pluck a string and the body resonates the sound.

Digital instrument note production



Based on playing information from the keyboard, a sampling note stored in the tone generator is played through the speakers.

As shown in the illustration above, in an electronic instrument the sampling note (previously recorded note) stored in the tone generator section (electronic circuit) is played based on information received from the keyboard. So then what is the information from the keyboard that becomes the basis for note production?

For example, let’s say you play a “C” quarter note using the grand piano sound on the PSR-275/273 keyboard. Unlike an acoustic instrument that puts out a resonated note, the electronic instrument puts out information from the keyboard such as “with what voice,” “with which key,” “about how strong,” “when was it pressed,” and “when was it released.” Then each piece of information is changed into a number value and sent to the tone generator. Using these numbers as a basis, the tone generator plays the stored sampling note.

● Example of Keyboard Information

| | |
|---|---|
| Voice number (with what voice) | 01 (grand piano) |
| Note number (with which key) | 60 (C3) |
| Note on (when was it pressed) and note off (when was it released) | Timing expressed numerically (quarter note) |
| Velocity (about how strong) | 120 (strong) |

GM System Level 1

“GM System Level 1” is an addition to the MIDI standard which ensures that any GM-compatible music data can be accurately played by any GM-compatible tone generator, regardless of manufacturer. The GM mark is affixed to all software and hardware products that support GM System Level 1. The PSR-275/273 supports GM System Level 1.



MIDI is an acronym that stands for Musical Instrument Digital Interface, which allows electronic musical instruments to communicate with each other, by sending and receiving compatible Note, Control Change, Program Change and various other types of MIDI data, or messages.

The PSR-275/273 can control a MIDI device by transmitting note related data and various types of controller data. The PSR-275/273 can be controlled by the incoming MIDI messages which automatically determine tone generator mode, select MIDI channels, voices and effects, change parameter values and of course play the voices specified for the various parts.

MIDI messages can be divided into two groups: Channel messages and System messages. Below is an explanation of the various types of MIDI messages which the PSR-275/273 can receive/transmit.

● Channel Messages

The PSR-275/273 is an electronic instrument that can handle 16 channels. This is usually expressed as “it can play 16 instruments at the same time.” Channel messages transmit information such as Note ON/OFF, Program Change, for each of the 16 channels.

| Message Name | PSR-275/273 Operation/Panel Setting |
|----------------|--|
| Note ON/OFF | Messages which are generated when the keyboard is played. Each message includes a specific note number which corresponds to the key which is pressed, plus a velocity value based on how hard the key is struck. |
| Program Change | Voice number (along with corresponding bank select MSB/LSB settings, if necessary). |
| Control Change | Messages that are used to change some aspect of the sound (volume, etc.). |

● System Messages


This is data that is used in common by the entire MIDI system. System messages include messages like Exclusive Messages that transmit data unique to each instrument manufacturer and Realtime Messages that control the MIDI device.

| Message Name | PSR-275/273 Operation/Panel Setting |
|-------------------|-------------------------------------|
| Exclusive Message | Reverb setting, etc. |
| Realtime Messages | Clock, Start/stop operations |

The messages transmitted/received by the PSR-275/273 are shown in the MIDI Implementation Chart on page 68.

MIDI Terminals

In order to exchange MIDI data between multiple devices, each device must be connected by a cable. The MIDI terminals of the PSR-275/273 are located on the rear panel.



| | |
|----------|---|
| MIDI IN | Receives MIDI data from another MIDI device. |
| MIDI OUT | Transmits the PSR-275/273's keyboard information as MIDI data to another MIDI device. |


NOTE

- Special MIDI cables (sold separately) must be used for connecting to MIDI devices. They can be bought at music stores, etc.
- Never use MIDI cables longer than about 15 meters. Cables longer than this can pick up noise which can cause data errors.


Connecting to a Personal Computer

By connecting your PSR-275/273's MIDI terminals to a personal computer, you can have access to a wide variety of music software.

- When using a MIDI interface device installed in the personal computer, connect the MIDI terminals of the personal computer and the PSR-275/273.



- When using a MIDI interface with a Macintosh series computer, connect the RS-422 terminal of the computer (modem or printer terminal) to the MIDI interface, as shown in the diagram below.



NOTE


- When using a Macintosh series computer, set the MIDI interface clock setting in the application software to match the setting of the MIDI interface you are using. For details, refer to the owner's manual for the software you are using.

NOTE

Viewing the Notation for MIDI Channel 1

- The PSR-275/273 has a special function that lets you view the notes of the MIDI data (channel 1 only) on the display.

- When connecting to a computer with a USB interface, use the Yamaha UX16 USB/MIDI Interface. Connect the UX16 and the computer with a standard USB cable, then make the proper MIDI connections between the PSR-275/273 and the UX16.



Local Control

This function lets you enable or disable keyboard control over the PSR-275/273's voices in the *Function mode* (page 60). This would come in handy, for example, when recording notes to MIDI sequencer. If you are using the sequencer to play back the voices of the PSR-275/273, you would want to set this to “off” — in order to avoid getting “double” notes, both from the keyboard and from the sequencer. Normally, when playing the PSR-275/273 by itself, this should be set to “on.”

CAUTION

- No sound is output from the PSR-275/273 when Local ON/OFF is set to OFF.

Using Initial Setup Send with a Sequencer

The most common use for the Initial Setup Send function is in recording a song on a sequencer that is intended for playback with the PSR-275/273. Essentially, this takes a “snapshot” of the PSR-275/273 settings and sends that data to the sequencer. By recording this “snapshot” at the start of the song (before any actual performance data), you can instantly restore the necessary settings on the PSR-275/273 in the *Function mode* (page 60). Provided there is a pause in the song, you could also do this in the middle of a song — for example, completely changing the PSR-275/273 settings for the next section of the song.

NOTE

- When the Initial Setup Send operation is completed, the PSR-275/273 automatically returns to the previous panel condition.

External Clock

This determines whether the style and song playback functions are controlled by the PortaTone's internal clock (off) or by MIDI clock data from an external sequencer or computer (on).

This should be set to on when you want to have style or song playback follow the external device (such as a rhythm machine or a sequencer). The default setting is off.

These settings can be made in the Function mode (page 60).


CAUTION

- If External Clock is set to ON, style or song playback will not start unless external clock are received.

MIDI LSB Receive Cancel

Determines whether the LSB data of Bank Select is received or not. Press and hold the lowest key and turn on the power to change the setting (LSB is ignored).

To restore MIDI LSB Receive Cancel to normal (LSB is recognized), turn on the power again normally.



MIDI Functions


PC Mode

The PC Mode lets you instantly reconfigure the MIDI control settings for use with a computer or MIDI device.

| | PC mode is on | PC mode is off |
|--------------|---------------|----------------|
| LOCAL ON/OFF | OFF | ON |

■ To turn the PC mode on or off:

Press the [PC] button and then press the appropriate [+]/[-] button. This switches between the PC Mode on/off settings.



[on] PC Mode

CAUTION

- No sound is output from the PSR-275/273 when Local ON/OFF is set to OFF.





Function

The PSR-275/273 has a variety of settings in the Function parameters. These give you detailed control over many of the PSR-275/273's features.



Using the Function parameters

1 Select a Function name.

Press the [FUNCTION] button, repeatedly if necessary, until appropriate Function name is appear in the display.



2 Input the appropriate value or use the [+]/[-] buttons to set the selected Function.



NOTE

- To input a negative value, simultaneously hold the [-] button and enter the number.

● Function parameters

| CATEGORY | SELECT | Display | Range/ Settings | Description | |
|--------------------|--------------------------|-----------------|--------------------|---|---|
| Overall | Transpose | <i>TransPos</i> | -12-12 | This determines the transposition of the entire PSR-275/273 sound. | * |
| | Tuning | <i>Tuning</i> | -100-100 | This determines the pitch of the entire PSR-275/273 sound . | * |
| | Split Point | <i>SplitPnt</i> | 000-127 | This determines the highest key for the Split voice and sets the Split "point" — in other words, the key that separates the Split (lower) and Main (upper) voices. (The Split voice sounds up to and including the Split Point key.) The default Split Point is 054 (F#2). The Split Point setting and Accompaniment Split Point setting are automatically set to the same value. | * |
| | Touch Sensitivity | <i>TouchSns</i> | 1-3 | A setting of "1" results in limited touch response; this setting produces a relatively narrow dynamic range, no matter how lightly or strongly you play the keys. "2" lets you play over a normal dynamic range (soft to loud), while "3" is designed for playing very soft passages, giving you slightly more detailed control in the soft volume range. When Touch is turned off (page 27), a constant velocity value of 80 is produced (total velocity range = 0-127). | * |
| Volume | Style Volume | <i>StyleVol</i> | 0-127 | This determines the volume of the style, letting you create an optimum mix with your performance. | * |
| | Song Volume | <i>SongVol</i> | 0-127 | This determines the volume of the Song. | * |
| | Metronome Volume | <i>MtrVol</i> | 0-127 | This determines the volume of the Metronome. | * |
| | Metronome Time Signature | <i>TimeSig</i> | 0-15 | This determines the time signature of the Metronome. | * |
| Main Voice | Volume | <i>M.Vol</i> | 0-127 | This determines the volume of the Main voice, letting you create an optimum mix with the Dual or Split voice. | * |
| | Octave | <i>M.Octave</i> | -2-2 (octave) | This determines the octave range for the Main voice. Use this to set the most suitable range for the Main voice. | * |
| | Reverb Send Level | <i>M.RevLvl</i> | 0-127 | This determines how much of the Main voice's signal is sent to the Reverb effect. Higher values result in a louder Reverb effect. | * |
| | Chorus Send Level | <i>M.ChoLvl</i> | 0-127 | This determines how much of the Main voice's signal is sent to the Chorus effect. Higher values result in a louder Chorus effect. | * |
| Dual Voice | Voice | <i>D.Voice</i> | 1-480 | This select the dual voice. | * |
| | Volume | <i>D.Volume</i> | 0-127 | This determines the volume of the Dual voice, letting you create an optimum mix with the Main voice. | * |
| | Octave | <i>D.Octave</i> | -2-2 (octave) | This determines the octave range for the Dual voice. Use this to create an octave layer for the Dual voice. | * |
| | Reverb Send Level | <i>D.RevLvl</i> | 0-127 | This determines how much of the Dual voice's signal is sent to the Reverb effect. Higher values result in a louder Reverb effect for the Dual voice. | * |
| | Chorus Send Level | <i>D.ChoLvl</i> | 0-127 | This determines how much of the Dual voice's signal is sent to the Chorus effect. Higher values result in a louder Chorus effect for the Dual voice. | * |
| Split Voice | Voice | <i>S.Voice</i> | 1-480 | This select the split voice. | * |
| | Volume | <i>S.Volume</i> | 0-127 | This determines the volume of the Split voice, letting you create an optimum mix with the Main voice. | * |
| | Octave | <i>S.Octave</i> | -2-2 (octave) | This determines the octave range for the Split voice. Use this to set the most suitable range for the Split (lower) voice. | * |
| | Reverb Send Level | <i>S.RevLvl</i> | 0-127 | This determines how much of the Split voice's signal is sent to the Reverb effect. Higher values result in a louder Reverb effect for the Split voice. | * |
| | Chorus Send Level | <i>S.ChoLvl</i> | 0-127 | This determines how much of the Split voice's signal is sent to the Chorus effect. Higher values result in a louder Chorus effect for the Split voice. | * |
| Effect/ Harmony | Reverb Type | <i>Reverb</i> | 1-9 | This determines the Reverb type (See the list on page 32). | * |
| | Chorus Type | <i>Chorus</i> | 1-5 | This determines the Chorus type, including "off" (See the list on page 32). | * |
| | Harmony Type | <i>HarmType</i> | 1-26 | This determines the Harmony type (See the list on page 31). | * |
| | Harmony Volume | <i>HarmVol</i> | 0-127 | This determines the level of the Harmony effect when Harmony type 1-5 is selected, letting you create the optimum mix with the original melody note. | * |
| Utility | Local On/Off | <i>Local</i> | On/Off | This determines the Local on or off. Press the [+]/[-] buttons to set Local Control to on or off. | |
| | External Clock | <i>ExtClock</i> | On/Off | This determines the External clock or Internal clock. Press the [+]/[-] buttons to set External clock or Internal clock. | |
| | Initial Setup Send | <i>InitSend</i> | YES/NO | This lets you save PortaTone initial data to another device (such as a sequencer, computer, or MIDI data filer). Use the [+]/YES button to transmit the data. | |

* The "*" mark indicates that the setting can be restored to default value by pressing both [+]/[-] buttons simultaneously.

Voice List

| Voice No. | Bank Select | | MIDI Program Change# | Voice Name |
|-------------------|-------------|-----|----------------------|----------------|
| | MSB | LSB | | |
| SYNTH LEAD | | | | |
| 089 | 0 | 112 | 80 | Square Lead |
| 090 | 0 | 112 | 81 | Sawtooth Lead |
| 091 | 0 | 112 | 85 | Voice Lead |
| 092 | 0 | 112 | 98 | Star Dust |
| 093 | 0 | 112 | 100 | Brightness |
| 094 | 0 | 115 | 81 | Analogon |
| 095 | 0 | 119 | 81 | Fargo |
| SYNTH PAD | | | | |
| 096 | 0 | 112 | 88 | Fantasia |
| 097 | 0 | 113 | 100 | Bell Pad |
| 098 | 0 | 112 | 91 | Xenon Pad |
| 099 | 0 | 112 | 94 | Equinox |
| 100 | 0 | 113 | 89 | Dark Moon |
| PERCUSSION | | | | |
| 101 | 0 | 112 | 11 | Vibraphone |
| 102 | 0 | 112 | 12 | Marimba |
| 103 | 0 | 112 | 13 | Xylophone |
| 104 | 0 | 112 | 114 | Steel Drums |
| 105 | 0 | 112 | 8 | Celesta |
| 106 | 0 | 112 | 14 | Tubular Bells |
| 107 | 0 | 112 | 47 | Timpani |
| 108 | 0 | 112 | 10 | Music Box |
| DRUM KITS | | | | |
| 109 | 127 | 0 | 0 | Standard Kit 1 |
| 110 | 127 | 0 | 1 | Standard Kit 2 |
| 111 | 127 | 0 | 8 | Room Kit |
| 112 | 127 | 0 | 16 | Rock Kit |
| 113 | 127 | 0 | 24 | Electronic Kit |
| 114 | 127 | 0 | 25 | Analog Kit |
| 115 | 127 | 0 | 27 | Dance Kit |
| 116 | 127 | 0 | 32 | Jazz Kit |
| 117 | 127 | 0 | 40 | Brush Kit |
| 118 | 127 | 0 | 48 | Symphony Kit |
| 119 | 126 | 0 | 0 | SFX Kit 1 |
| 120 | 126 | 0 | 1 | SFX Kit 2 |

● XGlite Voice List

| Voice No. | Bank Select | | MIDI Program Change# | Voice Name |
|--------------|-------------|-----|----------------------|----------------------------|
| | MSB | LSB | | |
| PIANO | | | | |
| 121 | 0 | 0 | 0 | Grand Piano |
| 122 | 0 | 1 | 0 | Grand Piano KSP |
| 123 | 0 | 40 | 0 | Piano Strings |
| 124 | 0 | 41 | 0 | Dream |
| 125 | 0 | 0 | 1 | Bright Piano |
| 126 | 0 | 1 | 1 | Bright Piano KSP |
| 127 | 0 | 0 | 2 | Electric Grand Piano |
| 128 | 0 | 1 | 2 | Electric Grand Piano KSP |
| 129 | 0 | 32 | 2 | Detuned CP80 |
| 130 | 0 | 0 | 3 | Honky-tonk Piano |
| 131 | 0 | 1 | 3 | Honky-tonk Piano KSP |
| 132 | 0 | 0 | 4 | Electric Piano 1 |
| 133 | 0 | 1 | 4 | Electric Piano 1 KSP |
| 134 | 0 | 32 | 4 | Chorus Electric Piano 1 |
| 135 | 0 | 0 | 5 | Electric Piano 2 |
| 136 | 0 | 1 | 5 | Electric Piano 2 KSP |
| 137 | 0 | 32 | 5 | Chorus Electric Piano 2 |
| 138 | 0 | 41 | 5 | DX + Analog Electric Piano |
| 139 | 0 | 0 | 6 | Harpsichord |
| 140 | 0 | 1 | 6 | Harpsichord KSP |
| 141 | 0 | 35 | 6 | Harpsichord 3 |
| 142 | 0 | 0 | 7 | Clavi |
| 143 | 0 | 1 | 7 | Clavi KSP |

| Voice No. | Bank Select | | MIDI Program Change# | Voice Name |
|------------------|-------------|-----|----------------------|------------------------------|
| | MSB | LSB | | |
| CHROMATIC | | | | |
| 144 | 0 | 0 | 8 | Celesta |
| 145 | 0 | 0 | 9 | Glockenspiel |
| 146 | 0 | 0 | 10 | Music Box |
| 147 | 0 | 64 | 10 | Orgel |
| 148 | 0 | 0 | 11 | Vibraphone |
| 149 | 0 | 1 | 11 | Vibraphone KSP |
| 150 | 0 | 0 | 12 | Marimba |
| 151 | 0 | 1 | 12 | Marimba KSP |
| 152 | 0 | 64 | 12 | Sine Marimba |
| 153 | 0 | 97 | 12 | Balimba |
| 154 | 0 | 98 | 12 | Log Drums |
| 155 | 0 | 0 | 13 | Xylophone |
| 156 | 0 | 0 | 14 | Tubular Bells |
| 157 | 0 | 96 | 14 | Church Bells |
| 158 | 0 | 97 | 14 | Carillon |
| 159 | 0 | 0 | 15 | Dulcimer |
| 160 | 0 | 35 | 15 | Dulcimer 2 |
| 161 | 0 | 96 | 15 | Cimbalom |
| 162 | 0 | 97 | 15 | Santur |
| ORGAN | | | | |
| 163 | 0 | 0 | 16 | DrawOrg |
| 164 | 0 | 32 | 16 | Detuned DrawOrg |
| 165 | 0 | 33 | 16 | 60's DrawOrg 1 |
| 166 | 0 | 34 | 16 | 60's DrawOrg 2 |
| 167 | 0 | 35 | 16 | 70's DrawOrg 1 |
| 168 | 0 | 37 | 16 | 60's DrawOrg 3 |
| 169 | 0 | 40 | 16 | 16+2"2/3 |
| 170 | 0 | 64 | 16 | Organ Bass |
| 171 | 0 | 65 | 16 | 70's DrawOrg 2 |
| 172 | 0 | 66 | 16 | Cheezy Organ |
| 173 | 0 | 67 | 16 | DrawOrg 3 |
| 174 | 0 | 0 | 17 | Percussive Organ |
| 175 | 0 | 24 | 17 | 70's Percussive Organ |
| 176 | 0 | 32 | 17 | Detuned Percussive Organ |
| 177 | 0 | 33 | 17 | Light Organ |
| 178 | 0 | 37 | 17 | Percussive Organ 2 |
| 179 | 0 | 0 | 18 | Rock Organ |
| 180 | 0 | 64 | 18 | Rotary Organ |
| 181 | 0 | 65 | 18 | Slow Rotary |
| 182 | 0 | 66 | 18 | Fast Rotary |
| 183 | 0 | 0 | 19 | Church Organ |
| 184 | 0 | 32 | 19 | Church Organ 3 |
| 185 | 0 | 35 | 19 | Church Organ 2 |
| 186 | 0 | 40 | 19 | Notre Dame |
| 187 | 0 | 64 | 19 | Organ Flute |
| 188 | 0 | 65 | 19 | Tremolo Organ Flute |
| 189 | 0 | 0 | 20 | Reed Organ |
| 190 | 0 | 40 | 20 | Puff Organ |
| 191 | 0 | 0 | 21 | Accordion |
| 192 | 0 | 0 | 22 | Hamonica |
| 193 | 0 | 32 | 22 | Harmonica 2 |
| 194 | 0 | 0 | 23 | Tango Accordion |
| 195 | 0 | 64 | 23 | Tango Accordion 2 |
| GUITAR | | | | |
| 196 | 0 | 0 | 24 | Nylon Guitar |
| 197 | 0 | 96 | 24 | Ukulele |
| 198 | 0 | 0 | 25 | Steel Guitar |
| 199 | 0 | 35 | 25 | 12-string Guitar |
| 200 | 0 | 40 | 25 | Nylon & Steel Guitar |
| 201 | 0 | 41 | 25 | Steel Guitar with Body Sound |
| 202 | 0 | 96 | 25 | Mandolin |
| 203 | 0 | 0 | 26 | Jazz Guitar |
| 204 | 0 | 32 | 26 | Jazz Amp |
| 205 | 0 | 0 | 27 | Clean Guitar |
| 206 | 0 | 32 | 27 | Chorus Guitar |

| Voice No. | Bank Select | | MIDI Program Change# | Voice Name |
|-----------------|-------------|-----|----------------------|----------------------------------|
| | MSB | LSB | | |
| 207 | 0 | 0 | 28 | Muted Guitar |
| 208 | 0 | 40 | 28 | Funk Guitar 1 |
| 209 | 0 | 41 | 28 | Muted Steel Guitar |
| 210 | 0 | 45 | 28 | Jazz Man |
| 211 | 0 | 0 | 29 | Overdriven Guitar |
| 212 | 0 | 43 | 29 | Guitar Pinch |
| 213 | 0 | 0 | 30 | Distortion Guitar |
| 214 | 0 | 40 | 30 | Feedback Guitar |
| 215 | 0 | 41 | 30 | Feedback Guitar 2 |
| 216 | 0 | 0 | 31 | Guitar Harmonics |
| 217 | 0 | 65 | 31 | Guitar Feedback |
| 218 | 0 | 66 | 31 | Guitar Harmonics 2 |
| BASS | | | | |
| 219 | 0 | 0 | 32 | Acoustic Bass |
| 220 | 0 | 40 | 32 | Jazz Rhythm |
| 221 | 0 | 45 | 32 | Velocity Crossfade Upright Bass |
| 222 | 0 | 0 | 33 | Finger Bass |
| 223 | 0 | 18 | 33 | Finger Dark |
| 224 | 0 | 40 | 33 | Bass & Distorted Electric Guitar |
| 225 | 0 | 43 | 33 | Finger Slap Bass |
| 226 | 0 | 45 | 33 | Finger Bass 2 |
| 227 | 0 | 65 | 33 | Modulated Bass |
| 228 | 0 | 0 | 34 | Pick Bass |
| 229 | 0 | 28 | 34 | Muted Pick Bass |
| 230 | 0 | 0 | 35 | Fretless Bass |
| 231 | 0 | 32 | 35 | Fretless Bass 2 |
| 232 | 0 | 33 | 35 | Fretless Bass 3 |
| 233 | 0 | 34 | 35 | Fretless Bass 4 |
| 234 | 0 | 0 | 36 | Slap Bass 1 |
| 235 | 0 | 32 | 36 | Punch Thumb Bass |
| 236 | 0 | 0 | 37 | Slap Bass 2 |
| 237 | 0 | 43 | 37 | Velocity Switch Slap |
| 238 | 0 | 0 | 38 | Synth Bass 1 |
| 239 | 0 | 40 | 38 | Techno Synth Bass |
| 240 | 0 | 0 | 39 | Synth Bass 2 |
| 241 | 0 | 6 | 39 | Mellow Synth Bass |
| 242 | 0 | 12 | 39 | Sequenced Bass |
| 243 | 0 | 18 | 39 | Click Synth Bass |
| 244 | 0 | 19 | 39 | Synth Bass 2 Dark |
| 245 | 0 | 40 | 39 | Modular Synth Bass |
| 246 | 0 | 41 | 39 | DX Bass |
| STRING | | | | |
| 247 | 0 | 0 | 40 | Violin |
| 248 | 0 | 8 | 40 | Slow Violin |
| 249 | 0 | 0 | 41 | Viola |
| 250 | 0 | 0 | 42 | Cello |
| 251 | 0 | 0 | 43 | Contrabass |
| 252 | 0 | 0 | 44 | Tremolo Strings |
| 253 | 0 | 8 | 44 | Slow Tremolo Strings |
| 254 | 0 | 40 | 44 | Suspense Strings |
| 255 | 0 | 0 | 45 | Pizzicato Strings |
| 256 | 0 | 0 | 46 | Orchestral Harp |
| 257 | 0 | 40 | 46 | Yang Chin |
| 258 | 0 | 0 | 47 | Timpani |
| ENSEMBLE | | | | |
| 259 | 0 | 0 | 48 | Strings 1 |
| 260 | 0 | 3 | 48 | Stereo Strings |
| 261 | 0 | 8 | 48 | Slow Strings |
| 262 | 0 | 35 | 48 | 60's Strings |
| 263 | 0 | 40 | 48 | Orchestra |
| 264 | 0 | 41 | 48 | Orchestra 2 |
| 265 | 0 | 42 | 48 | Tremolo Orchestra |
| 266 | 0 | 45 | 48 | Velocity Strings |
| 267 | 0 | 0 | 49 | Strings 2 |
| 268 | 0 | 3 | 49 | Stereo Slow Strings |
| 269 | 0 | 8 | 49 | Legato Strings |

| Voice No. | Bank Select | | MIDI Program Change# | Voice Name |
|-------------------|-------------|-----|----------------------|----------------------------|
| | MSB | LSB | | |
| 270 | 0 | 40 | 49 | Warm Strings |
| 271 | 0 | 41 | 49 | Kingdom |
| 272 | 0 | 0 | 50 | Synth Strings 1 |
| 273 | 0 | 0 | 51 | Synth Strings 2 |
| 274 | 0 | 0 | 52 | Choir Aahs |
| 275 | 0 | 3 | 52 | Stereo Choir |
| 276 | 0 | 32 | 52 | Mellow Choir |
| 277 | 0 | 40 | 52 | Choir Strings |
| 278 | 0 | 0 | 53 | Voice Oohs |
| 279 | 0 | 0 | 54 | Synth Voice |
| 280 | 0 | 40 | 54 | Synth Voice 2 |
| 281 | 0 | 41 | 54 | Choral |
| 282 | 0 | 64 | 54 | Analog Voice |
| 283 | 0 | 0 | 55 | Orchestra Hit |
| 284 | 0 | 35 | 55 | Orchestra Hit 2 |
| 285 | 0 | 64 | 55 | Impact |
| BRASS | | | | |
| 286 | 0 | 0 | 56 | Trumpet |
| 287 | 0 | 32 | 56 | Warm Trumpet |
| 288 | 0 | 0 | 57 | Trombone |
| 289 | 0 | 18 | 57 | Trombone 2 |
| 290 | 0 | 0 | 58 | Tuba |
| 291 | 0 | 0 | 59 | Muted Trumpet |
| 292 | 0 | 0 | 60 | French Horn |
| 293 | 0 | 6 | 60 | French Horn Solo |
| 294 | 0 | 32 | 60 | French Horn 2 |
| 295 | 0 | 37 | 60 | Horn Orchestra |
| 296 | 0 | 0 | 61 | Brass Section |
| 297 | 0 | 35 | 61 | Trumpet & Trombone Section |
| 298 | 0 | 0 | 62 | Synth Brass 1 |
| 299 | 0 | 20 | 62 | Resonant Synth Brass |
| 300 | 0 | 0 | 63 | Synth Brass 2 |
| 301 | 0 | 18 | 63 | Soft Brass |
| 302 | 0 | 41 | 63 | Choir Brass |
| REED | | | | |
| 303 | 0 | 0 | 64 | Soprano Sax |
| 304 | 0 | 0 | 65 | Alto Sax |
| 305 | 0 | 40 | 65 | Sax Section |
| 306 | 0 | 0 | 66 | Tenor Sax |
| 307 | 0 | 40 | 66 | Breathy Tenor Sax |
| 308 | 0 | 0 | 67 | Baritone Sax |
| 309 | 0 | 0 | 68 | Oboe |
| 310 | 0 | 0 | 69 | English Horn |
| 311 | 0 | 0 | 70 | Bassoon |
| 312 | 0 | 0 | 71 | Clarinet |
| PIPE | | | | |
| 313 | 0 | 0 | 72 | Piccolo |
| 314 | 0 | 0 | 73 | Flute |
| 315 | 0 | 0 | 74 | Recorder |
| 316 | 0 | 0 | 75 | Pan Flute |
| 317 | 0 | 0 | 76 | Blown Bottle |
| 318 | 0 | 0 | 77 | Shakuhachi |
| 319 | 0 | 0 | 78 | Whistle |
| 320 | 0 | 0 | 79 | Ocarina |
| SYNTH LEAD | | | | |
| 321 | 0 | 0 | 80 | Square Lead |
| 322 | 0 | 6 | 80 | Square Lead 2 |
| 323 | 0 | 8 | 80 | LM Square |
| 324 | 0 | 18 | 80 | Hollow |
| 325 | 0 | 19 | 80 | Shroud |
| 326 | 0 | 64 | 80 | Mellow |
| 327 | 0 | 65 | 80 | Solo Sine |
| 328 | 0 | 66 | 80 | Sine Lead |
| 329 | 0 | 0 | 81 | Sawtooth Lead |
| 330 | 0 | 6 | 81 | Sawtooth Lead 2 |
| 331 | 0 | 8 | 81 | Thick Sawtooth |

Voice List

| Voice No. | Bank Select | | MIDI Program Change# | Voice Name |
|----------------------|-------------|-----|----------------------|----------------------|
| | MSB | LSB | | |
| 332 | 0 | 18 | 81 | Dynamic Sawtooth |
| 333 | 0 | 19 | 81 | Digital Sawtooth |
| 334 | 0 | 20 | 81 | Big Lead |
| 335 | 0 | 96 | 81 | Sequenced Analog |
| 336 | 0 | 0 | 82 | Calliope Lead |
| 337 | 0 | 65 | 82 | Pure Pad |
| 338 | 0 | 0 | 83 | Chiff Lead |
| 339 | 0 | 0 | 84 | Charang Lead |
| 340 | 0 | 64 | 84 | Distorted Lead |
| 341 | 0 | 0 | 85 | Voice Lead |
| 342 | 0 | 0 | 86 | Fifths Lead |
| 343 | 0 | 35 | 86 | Big Five |
| 344 | 0 | 0 | 87 | Bass & Lead |
| 345 | 0 | 16 | 87 | Big & Low |
| 346 | 0 | 64 | 87 | Fat & Perky |
| 347 | 0 | 65 | 87 | Soft Whirl |
| SYNTH PAD | | | | |
| 348 | 0 | 0 | 88 | New Age Pad |
| 349 | 0 | 64 | 88 | Fantasy |
| 350 | 0 | 0 | 89 | Warm Pad |
| 351 | 0 | 0 | 90 | Poly Synth Pad |
| 352 | 0 | 0 | 91 | Choir Pad |
| 353 | 0 | 66 | 91 | Itopia |
| 354 | 0 | 0 | 92 | Bowed Pad |
| 355 | 0 | 0 | 93 | Metallic Pad |
| 356 | 0 | 0 | 94 | Halo Pad |
| 357 | 0 | 0 | 95 | Sweep Pad |
| SYNTH EFFECTS | | | | |
| 358 | 0 | 0 | 96 | Rain |
| 359 | 0 | 65 | 96 | African Wind |
| 360 | 0 | 66 | 96 | Carib |
| 361 | 0 | 0 | 97 | Sound Track |
| 362 | 0 | 27 | 97 | Prologue |
| 363 | 0 | 0 | 98 | Crystal |
| 364 | 0 | 12 | 98 | Synth Drum Comp |
| 365 | 0 | 14 | 98 | Popcorn |
| 366 | 0 | 18 | 98 | Tiny Bells |
| 367 | 0 | 35 | 98 | Round Glockenspiel |
| 368 | 0 | 40 | 98 | Glockenspiel Chimes |
| 369 | 0 | 41 | 98 | Clear Bells |
| 370 | 0 | 42 | 98 | Chorus Bells |
| 371 | 0 | 65 | 98 | Soft Crystal |
| 372 | 0 | 70 | 98 | Air Bells |
| 373 | 0 | 71 | 98 | Bell Harp |
| 374 | 0 | 72 | 98 | Gamelimba |
| 375 | 0 | 0 | 99 | Atmosphere |
| 376 | 0 | 18 | 99 | Warm Atmosphere |
| 377 | 0 | 19 | 99 | Hollow Release |
| 378 | 0 | 40 | 99 | Nylon Electric Piano |
| 379 | 0 | 64 | 99 | Nylon Harp |
| 380 | 0 | 65 | 99 | Harp Vox |
| 381 | 0 | 66 | 99 | Atmosphere Pad |
| 382 | 0 | 0 | 100 | Brightness |
| 383 | 0 | 0 | 101 | Goblins |
| 384 | 0 | 64 | 101 | Goblins Synth |
| 385 | 0 | 65 | 101 | Creeper |
| 386 | 0 | 67 | 101 | Ritual |
| 387 | 0 | 68 | 101 | To Heaven |
| 388 | 0 | 70 | 101 | Night |
| 389 | 0 | 71 | 101 | Glisten |
| 390 | 0 | 96 | 101 | Bell Choir |
| 391 | 0 | 0 | 102 | Echoes |
| 392 | 0 | 0 | 103 | Sci-Fi |
| WORLD | | | | |
| 393 | 0 | 0 | 104 | Sitar |
| 394 | 0 | 32 | 104 | Detuned Sitar |

| Voice No. | Bank Select | | MIDI Program Change# | Voice Name |
|----------------------|-------------|-----|----------------------|-----------------------|
| | MSB | LSB | | |
| 395 | 0 | 35 | 104 | Sitar 2 |
| 396 | 0 | 97 | 104 | Tamboura |
| 397 | 0 | 0 | 105 | Banjo |
| 398 | 0 | 28 | 105 | Muted Banjo |
| 399 | 0 | 96 | 105 | Rabab |
| 400 | 0 | 97 | 105 | Gopichant |
| 401 | 0 | 98 | 105 | Oud |
| 402 | 0 | 0 | 106 | Shamisen |
| 403 | 0 | 0 | 107 | Koto |
| 404 | 0 | 96 | 107 | Taisho-kin |
| 405 | 0 | 97 | 107 | Kanoon |
| 406 | 0 | 0 | 108 | Kalimba |
| 407 | 0 | 0 | 109 | Bagpipe |
| 408 | 0 | 0 | 110 | Fiddle |
| 409 | 0 | 0 | 111 | Shanai |
| PERCUSSIVE | | | | |
| 410 | 0 | 0 | 112 | Tinkle Bell |
| 411 | 0 | 96 | 112 | Bonang |
| 412 | 0 | 97 | 112 | Altair |
| 413 | 0 | 98 | 112 | Gamelan Gongs |
| 414 | 0 | 99 | 112 | Stereo Gamelan Gongs |
| 415 | 0 | 100 | 112 | Rama Cymbal |
| 416 | 0 | 0 | 113 | Agogo |
| 417 | 0 | 0 | 114 | Steel Drums |
| 418 | 0 | 97 | 114 | Glass Percussion |
| 419 | 0 | 98 | 114 | Thai Bells |
| 420 | 0 | 0 | 115 | Woodblock |
| 421 | 0 | 96 | 115 | Castanets |
| 422 | 0 | 0 | 116 | Taiko Drum |
| 423 | 0 | 96 | 116 | Gran Cassa |
| 424 | 0 | 0 | 117 | Melodic Tom |
| 425 | 0 | 64 | 117 | Melodic Tom 2 |
| 426 | 0 | 65 | 117 | Real Tom |
| 427 | 0 | 66 | 117 | Rock Tom |
| 428 | 0 | 0 | 118 | Synth Drum |
| 429 | 0 | 64 | 118 | Analog Tom |
| 430 | 0 | 65 | 118 | Electronic Percussion |
| 431 | 0 | 0 | 119 | Reverse Cymbal |
| SOUND EFFECTS | | | | |
| 432 | 0 | 0 | 120 | Fret Noise |
| 433 | 0 | 0 | 121 | Breath Noise |
| 434 | 0 | 0 | 122 | Seashore |
| 435 | 0 | 0 | 123 | Bird Tweet |
| 436 | 0 | 0 | 124 | Telephone Ring |
| 437 | 0 | 0 | 125 | Helicopter |
| 438 | 0 | 0 | 126 | Applause |
| 439 | 0 | 0 | 127 | Gunshot |
| 440 | 64 | 0 | 0 | Cutting Noise |
| 441 | 64 | 0 | 1 | Cutting Noise 2 |
| 442 | 64 | 0 | 3 | String Slap |
| 443 | 64 | 0 | 16 | Flute Key Click |
| 444 | 64 | 0 | 32 | Shower |
| 445 | 64 | 0 | 33 | Thunder |
| 446 | 64 | 0 | 34 | Wind |
| 447 | 64 | 0 | 35 | Stream |
| 448 | 64 | 0 | 36 | Bubble |
| 449 | 64 | 0 | 37 | Feed |
| 450 | 64 | 0 | 48 | Dog |
| 451 | 64 | 0 | 49 | Horse |
| 452 | 64 | 0 | 50 | Bird Tweet 2 |
| 453 | 64 | 0 | 55 | Maou |
| 454 | 64 | 0 | 64 | Phone Call |
| 455 | 64 | 0 | 65 | Door Squeak |
| 456 | 64 | 0 | 66 | Door Slam |
| 457 | 64 | 0 | 67 | Scratch Cut |
| 458 | 64 | 0 | 68 | Scratch Split |

| Voice No. | Bank Select | | MIDI Program Change# | Voice Name |
|-----------|-------------|-----|----------------------|---------------------|
| | MSB | LSB | | |
| 459 | 64 | 0 | 69 | Wind Chime |
| 460 | 64 | 0 | 70 | Telephone Ring 2 |
| 461 | 64 | 0 | 80 | Car Engine Ignition |
| 462 | 64 | 0 | 81 | Car Tires Squeal |
| 463 | 64 | 0 | 82 | Car Passing |
| 464 | 64 | 0 | 83 | Car Crash |
| 465 | 64 | 0 | 84 | Siren |
| 466 | 64 | 0 | 85 | Train |
| 467 | 64 | 0 | 86 | Jet Plane |
| 468 | 64 | 0 | 87 | Starship |
| 469 | 64 | 0 | 88 | Burst |

| Voice No. | Bank Select | | MIDI Program Change# | Voice Name |
|-----------|-------------|-----|----------------------|----------------|
| | MSB | LSB | | |
| 470 | 64 | 0 | 89 | Roller Coaster |
| 471 | 64 | 0 | 90 | Submarine |
| 472 | 64 | 0 | 96 | Laugh |
| 473 | 64 | 0 | 97 | Scream |
| 474 | 64 | 0 | 98 | Punch |
| 475 | 64 | 0 | 99 | Heartbeat |
| 476 | 64 | 0 | 100 | Footsteps |
| 477 | 64 | 0 | 112 | Machine Gun |
| 478 | 64 | 0 | 113 | Laser Gun |
| 479 | 64 | 0 | 114 | Explosion |
| 480 | 64 | 0 | 115 | Firework |

Style List

| Style No. | Style Name |
|---------------|--------------|
| 8BEAT | |
| 001 | 8BeatModern |
| 002 | 60'sGtrPop |
| 003 | 8BeatAdria |
| 004 | 60's8Beat |
| 005 | 8Beat |
| 006 | OffBeat |
| 007 | 60'sRock |
| 008 | HardRock |
| 009 | RockShuffle |
| 010 | 8BeatRock |
| 16BEAT | |
| 011 | 16Beat |
| 012 | PopShuffle |
| 013 | GuitarPop |
| 014 | 16BtUptempo |
| 015 | KoolShuffle |
| 016 | HipHopLight |
| BALLAD | |
| 017 | PianoBallad |
| 018 | LoveSong |
| 019 | 6/8ModernEP |
| 020 | 6/8SlowRock |
| 021 | OrganBallad |
| 022 | PopBallad |
| 023 | 16BeatBallad |
| DANCE | |
| 024 | EuroTrance |
| 025 | Ibiza |
| 026 | SwingHouse |
| 027 | Clubdance |
| 028 | ClubLatin |
| 029 | Garage1 |
| 030 | Garage2 |
| 031 | TechnoParty |
| 032 | UKPop |
| 033 | HipHopGroove |
| 034 | HipShuffle |
| 035 | HipHopPop |

| Style No. | Style Name |
|-------------------------|----------------|
| DISCO | |
| 036 | 70'sDisco |
| 037 | LatinDisco |
| 038 | SaturdayNight |
| 039 | DiscoHands |
| SWING & JAZZ | |
| 040 | BigBandFast |
| 041 | BigBandBallad |
| 042 | JazzClub |
| 043 | Swing1 |
| 044 | Swing2 |
| 045 | Five/Four |
| 046 | Dixieland |
| 047 | Ragtime |
| R & B | |
| 048 | Soul |
| 049 | DetroitPop |
| 050 | 6/8Soul |
| 051 | CrocoTwist |
| 052 | Rock&Roll |
| 053 | ComboBoogie |
| 054 | 6/8Blues |
| COUNTRY | |
| 055 | CountryPop |
| 056 | CountrySwing |
| 057 | Country2/4 |
| 058 | Bluegrass |
| LATIN | |
| 059 | BrazilianSamba |
| 060 | BossaNova |
| 061 | Tijuana |
| 062 | DiscoLatin |
| 063 | Mambo |
| 064 | Salsa |
| 065 | Beguine |
| 066 | Reggae |
| BALLROOM | |
| 067 | VienneseWaltz |
| 068 | EnglishWaltz |

| Style No. | Style Name |
|--------------------|------------------|
| 069 | Slowfox |
| 070 | Foxtrot |
| 071 | Quickstep |
| 072 | Tango |
| 073 | Pasodoble |
| 074 | Samba |
| 075 | ChaChaCha |
| 076 | Rumba |
| 077 | Jive |
| TRADITIONAL | |
| 078 | USMarch |
| 079 | 6/8March |
| 080 | GermanMarch |
| 081 | PolkaPop |
| 082 | OberPolka |
| 083 | Tarantella |
| 084 | Showtune |
| 085 | ChristmasSwing |
| 086 | ChristmasWaltz |
| 087 | ScottishReel |
| WALTZ | |
| 088 | SwingWaltz |
| 089 | JazzWaltz |
| 090 | CountryWaltz |
| 091 | OberWalzer |
| 092 | Musette |
| PIANIST | |
| 093 | Stride |
| 094 | PianoSwing |
| 095 | Arpeggio |
| 096 | Habanera |
| 097 | SlowRock |
| 098 | 8BeatPianoBallad |
| 099 | 6/8PianoMarch |
| 100 | PianoWaltz |

Drum Kit List

- " " indicates that the drum sound is the same as "Standard Kit 1".
- Each percussion voice uses one note.
- The MIDI Note # and Note are actually one octave lower than keyboard Note # and Note. For example, in "109: Standard Kit 1", the "Seq Click H" (Note# 36/Note C1) corresponds to (Note# 24/Note C0).
- Key Off: Keys marked "O" stop sounding the instant they are released.
- Voices with the same Alternate Note Number (*1 - 4) cannot be played simultaneously. (They are designed to be played alternately with each other.)

| | Voice No. | | 109 | | 110 | | 111 | | 112 | | 113 | | 114 | |
|-----|------------|------|-------------|------------------|----------------|----------------|-------------|----------|----------------|------------|-------------|--|-------------|--|
| | MSB/LSB/PC | | 127/000/000 | | 127/000/001 | | 127/000/008 | | 127/000/016 | | 127/000/024 | | 127/000/025 | |
| | Keyboard | MIDI | Key Off | Alternate assign | Standard Kit 1 | Standard Kit 2 | Room Kit | Rock Kit | Electronic Kit | Analog Kit | | | | |
| | 25 | C# 0 | 13 | C# -1 | | | | | | | | | | |
| | 26 | D 0 | 14 | D -1 | | | | | | | | | | |
| | 27 | D# 0 | 15 | D# -1 | | | | | | | | | | |
| | 28 | E 0 | 16 | E -1 | | | | | | | | | | |
| | 29 | F 0 | 17 | F -1 | | | | | | | | | | |
| | 30 | F# 0 | 18 | F# -1 | | | | | | | | | | |
| | 31 | G 0 | 19 | G -1 | | | | | | | | | | |
| | 32 | G# 0 | 20 | G# -1 | | | | | | | | | | |
| | 33 | A 0 | 21 | A -1 | | | | | | | | | | |
| | 34 | A# 0 | 22 | A# -1 | | | | | | | | | | |
| | 35 | B 0 | 23 | B -1 | | | | | | | | | | |
| | 36 | C 1 | 24 | C 0 | | | | | | | | | | |
| C1 | 37 | C# 1 | 25 | C# 0 | | | | | | | | | | |
| D1 | 38 | D 1 | 26 | D 0 | O | | | | | | | | | |
| E1 | 39 | D# 1 | 27 | D# 0 | | | | | | | | | | |
| F1 | 40 | E 1 | 28 | E 0 | O | | | | | | | | | |
| G1 | 41 | F 1 | 29 | F 0 | O | | | | | | | | | |
| A1 | 42 | F# 1 | 30 | F# 0 | | | | | | | | | | |
| B1 | 43 | G 1 | 31 | G 0 | | | | | | | | | | |
| C2 | 44 | G# 1 | 32 | G# 0 | | | | | | | | | | |
| D2 | 45 | A 1 | 33 | A 0 | | | | | | | | | | |
| E2 | 46 | A# 1 | 34 | A# 0 | | | | | | | | | | |
| F2 | 47 | B 1 | 35 | B 0 | | | | | | | | | | |
| G2 | 48 | C 2 | 36 | C 1 | | | | | | | | | | |
| A2 | 49 | C# 2 | 37 | C# 1 | | | | | | | | | | |
| B2 | 50 | D 2 | 38 | D 1 | | | | | | | | | | |
| C3 | 51 | D# 2 | 39 | D# 1 | | | | | | | | | | |
| D3 | 52 | E 2 | 40 | E 1 | | | | | | | | | | |
| E3 | 53 | F 2 | 41 | F 1 | | | | | | | | | | |
| F3 | 54 | F# 2 | 42 | F# 1 | 1 | | | | | | | | | |
| G3 | 55 | G 2 | 43 | G 1 | | | | | | | | | | |
| A3 | 56 | G# 2 | 44 | G# 1 | 1 | | | | | | | | | |
| B3 | 57 | A 2 | 45 | A 1 | | | | | | | | | | |
| C4 | 58 | A# 2 | 46 | A# 1 | 1 | | | | | | | | | |
| D4 | 59 | B 2 | 47 | B 1 | | | | | | | | | | |
| E4 | 60 | C 3 | 48 | C 2 | | | | | | | | | | |
| F4 | 61 | C# 3 | 49 | C# 2 | | | | | | | | | | |
| G4 | 62 | D 3 | 50 | D 2 | | | | | | | | | | |
| A4 | 63 | D# 3 | 51 | D# 2 | | | | | | | | | | |
| B4 | 64 | E 3 | 52 | E 2 | | | | | | | | | | |
| C5 | 65 | F 3 | 53 | F 2 | | | | | | | | | | |
| D5 | 66 | F# 3 | 54 | F# 2 | | | | | | | | | | |
| E5 | 67 | G 3 | 55 | G 2 | | | | | | | | | | |
| F5 | 68 | G# 3 | 56 | G# 2 | | | | | | | | | | |
| G5 | 69 | A 3 | 57 | A 2 | | | | | | | | | | |
| A5 | 70 | A# 3 | 58 | A# 2 | | | | | | | | | | |
| B5 | 71 | B 3 | 59 | B 2 | | | | | | | | | | |
| C6 | 72 | C 4 | 60 | C 3 | | | | | | | | | | |
| D6 | 73 | C# 4 | 61 | C# 3 | | | | | | | | | | |
| E6 | 74 | D 4 | 62 | D 3 | | | | | | | | | | |
| F6 | 75 | D# 4 | 63 | D# 3 | | | | | | | | | | |
| G6 | 76 | E 4 | 64 | E 3 | | | | | | | | | | |
| A6 | 77 | F 4 | 65 | F 3 | | | | | | | | | | |
| B6 | 78 | F# 4 | 66 | F# 3 | | | | | | | | | | |
| C7 | 79 | G 4 | 67 | G 3 | | | | | | | | | | |
| D7 | 80 | G# 4 | 68 | G# 3 | | | | | | | | | | |
| E7 | 81 | A 4 | 69 | A 3 | | | | | | | | | | |
| F7 | 82 | A# 4 | 70 | A# 3 | | | | | | | | | | |
| G7 | 83 | B 4 | 71 | B 3 | O | | | | | | | | | |
| A7 | 84 | C 5 | 72 | C 4 | O | | | | | | | | | |
| B7 | 85 | C# 5 | 73 | C# 4 | | | | | | | | | | |
| C8 | 86 | D 5 | 74 | D 4 | O | | | | | | | | | |
| D8 | 87 | D# 5 | 75 | D# 4 | | | | | | | | | | |
| E8 | 88 | E 5 | 76 | E 4 | | | | | | | | | | |
| F8 | 89 | F 5 | 77 | F 4 | | | | | | | | | | |
| G8 | 90 | F# 5 | 78 | F# 4 | | | | | | | | | | |
| A8 | 91 | G 5 | 79 | G 4 | | | | | | | | | | |
| B8 | 92 | G# 5 | 80 | G# 4 | 2 | | | | | | | | | |
| C9 | 93 | A 5 | 81 | A 4 | 2 | | | | | | | | | |
| D9 | 94 | A# 5 | 82 | A# 4 | | | | | | | | | | |
| E9 | 95 | B 5 | 83 | B 4 | | | | | | | | | | |
| F9 | 96 | C 6 | 84 | C 5 | | | | | | | | | | |
| G9 | 97 | C# 6 | 85 | C# 5 | | | | | | | | | | |
| A9 | 98 | D 6 | 86 | D 5 | | | | | | | | | | |
| B9 | 99 | D# 6 | 87 | D# 5 | | | | | | | | | | |
| C10 | 100 | E 6 | 88 | E 5 | | | | | | | | | | |
| D10 | 101 | F 6 | 89 | F 5 | | | | | | | | | | |
| E10 | 102 | F# 6 | 90 | F# 5 | | | | | | | | | | |
| F10 | 103 | G 6 | 91 | G 5 | | | | | | | | | | |

Drum Kit List

| | | Voice No. | | | | 109 | 115 | 116 | 117 | 118 | 119 | 120 | |
|-----|------|------------|------|-------|-------|----------------|------------------|-----------------|--------------------|-----------------|------------------|---------------------|-------------|
| | | MSB/LSB/PC | | | | 127/000/000 | 127/000/027 | 127/000/032 | 127/000/040 | 127/000/048 | 126/000/000 | 126/000/001 | |
| | | Keyboard | | MIDI | | Standard Kit 1 | Dance Kit | Jazz Kit | Brush Kit | Symphony Kit | SFX Kit 1 | SFX Kit 2 | |
| | | Note# | Note | Note# | Note | | | | | | | | |
| | | | | | | Key Off | Alternate assign | | | | | | |
| | | 25 | C# 0 | 13 | C# -1 | | 3 | Surdo Mute | | | | | |
| | | 26 | D 0 | 14 | D -1 | | 3 | Surdo Open | | | | | |
| | | 27 | D# 0 | 15 | D# -1 | | | Hi Q | | | | | |
| | | 28 | E 0 | 16 | E -1 | | | Whip Slap | | | | | |
| | | 29 | F 0 | 17 | F -1 | | 4 | Scratch Push | | | | | |
| | | 30 | F# 0 | 18 | F# -1 | | 4 | Scratch Pull | | | | | |
| | | 31 | G 0 | 19 | G -1 | | | Finger Snap | | | | | |
| | | 32 | G# 0 | 20 | G# -1 | | | Click Noise | | | | | |
| | | 33 | A 0 | 21 | A -1 | | | Metronome Click | | | | | |
| | | 34 | A# 0 | 22 | A# -1 | | | Metronome Bell | | | | | |
| | | 35 | B 0 | 23 | B -1 | | | Seq Click L | | | | | |
| | | 36 | C 1 | 24 | C 0 | | | Seq Click H | | | | | |
| C1 | C#1 | 37 | C# 1 | 25 | C# 0 | | | Brush Tap | | | | | |
| D1 | D#1 | 38 | D 1 | 26 | D 0 | O | | Brush Swirl | | | | | |
| E1 | E#1 | 39 | D# 1 | 27 | D# 0 | | | Brush Slap | | | | | |
| F1 | F#1 | 40 | E 1 | 28 | E 0 | O | | Brush Tap Swirl | Reverse Cymbal | | | | |
| G1 | G#1 | 41 | F 1 | 29 | F 0 | O | | Snare Roll | | | | | |
| A1 | A#1 | 42 | F# 1 | 30 | F# 0 | | | Castanet | Hi Q 2 | | | | |
| B1 | B#1 | 43 | G 1 | 31 | G 0 | | | Snare H Soft | AnSD Snappy | SD Jazz H Light | Brush Slap L | | |
| C2 | C#2 | 44 | G# 1 | 32 | G# 0 | | | Sticks | | | | | |
| D2 | D#2 | 45 | A 1 | 33 | A 0 | | | Bass Drum Soft | AnBD Dance-1 | | Bass Drum L | | |
| E2 | E#2 | 46 | A# 1 | 34 | A# 0 | | | Open Rim Shot | AnSD OpenRim | | | | |
| F2 | F#2 | 47 | B 1 | 35 | B 0 | | | Bass Drum Hard | AnBD Dance-2 | | Gran Cassa | | |
| G2 | G#2 | 48 | C 2 | 36 | C 1 | | | Bass Drum | AnBD Dance-3 | BD Jazz | BD Jazz | Gran Cassa Mute | |
| A2 | A#2 | 49 | C# 2 | 37 | C# 1 | | | Side Stick | Analog Side Stick | | Cutting Noise | Phone Call | |
| B2 | B#2 | 50 | D 2 | 38 | D 1 | | | Snare M | AnSD Q | SD Jazz L | Brush Slap | Cutting Noise 2 | |
| C3 | C#3 | 51 | D# 2 | 39 | D# 1 | | | Hand Clap | | | Marching Sn M | Door Squeak | |
| D3 | D#3 | 52 | E 2 | 40 | E 1 | | | Snare H Hard | AnSD Ana+Acoustic | SD Jazz M | Brush Tap | Door Slam | |
| E3 | E#3 | 53 | F 2 | 41 | F 1 | | | Floor Tom L | Analog Tom 1 | Jazz Tom 1 | Brush Tom 1 | Scratch Cut | |
| F3 | F#3 | 54 | F# 2 | 42 | F# 1 | 1 | | Hi-Hat Closed | Analog HH Closed 3 | | Jazz Tom 1 | Scratch | |
| G3 | G#3 | 55 | G 2 | 43 | G 1 | | | Floor Tom H | Analog Tom 2 | Jazz Tom 2 | Brush Tom 2 | Wind Chime | |
| A3 | A#3 | 56 | G# 2 | 44 | G# 1 | 1 | | Hi-Hat Pedal | Analog HH Closed 4 | | Jazz Tom 2 | Telephone Ring 2 | |
| B3 | B#3 | 57 | A 2 | 45 | A 1 | | | Low Tom | Analog Tom 3 | Jazz Tom 3 | Brush Tom 3 | | |
| C4 | C#4 | 58 | A# 2 | 46 | A# 1 | 1 | | Hi-Hat Open | Analog HH Open 2 | | Jazz Tom 3 | | |
| D4 | D#4 | 59 | B 2 | 47 | B 1 | | | Mid Tom L | Analog Tom 4 | Jazz Tom 4 | Brush Tom 4 | | |
| E4 | E#4 | 60 | C 3 | 48 | C 2 | | | Mid Tom H | Analog Tom 5 | Jazz Tom 5 | Brush Tom 5 | | |
| F4 | F#4 | 61 | C# 3 | 49 | C# 2 | | | Crash Cymbal 1 | Analog Cymbal | | Jazz Tom 5 | | |
| G4 | G#4 | 62 | D 3 | 50 | D 2 | | | High Tom | Analog Tom 6 | Jazz Tom 6 | Brush Tom 6 | | |
| A4 | A#4 | 63 | D# 3 | 51 | D# 2 | | | Ride Cymbal 1 | | | Jazz Tom 6 | | |
| B4 | B#4 | 64 | E 3 | 52 | E 2 | | | Chinese Cymbal | | | Hand Cym.Short L | | |
| C5 | C#5 | 65 | F 3 | 53 | F 2 | | | Ride Cymbal Cup | | | Flute Key Click | Car Engine Ignition | |
| D5 | D#5 | 66 | F# 3 | 54 | F# 2 | | | Tambourine | | | | Car Tires Squeal | |
| E5 | E#5 | 67 | G 3 | 55 | G 2 | | | Splash Cymbal | | | | Car Passing | |
| F5 | F#5 | 68 | G# 3 | 56 | G# 2 | | | Cowbell | Analog Cowbell | | | Car Crash | |
| G5 | G#5 | 69 | A 3 | 57 | A 2 | | | Crash Cymbal 2 | | | Hand Cym. H | Siren | |
| A5 | A#5 | 70 | A# 3 | 58 | A# 2 | | | Vibraslap | | | | Train | |
| B5 | B#5 | 71 | B 3 | 59 | B 2 | | | Ride Cymbal 2 | | | Hand Cym.Short H | Jet Plane | |
| C6 | C#6 | 72 | C 4 | 60 | C 3 | | | Bongo H | | | | Starship | |
| D6 | D#6 | 73 | C# 4 | 61 | C# 3 | | | Bongo L | | | | Burst | |
| E6 | E#6 | 74 | D 4 | 62 | D 3 | | | Conga H Mute | Analog Conga H | | | Roller Coaster | |
| F6 | F#6 | 75 | D# 4 | 63 | D# 3 | | | Conga H Open | Analog Conga M | | | Submarine | |
| G6 | G#6 | 76 | E 4 | 64 | E 3 | | | Conga L | Analog Conga L | | | | |
| A6 | A#6 | 77 | F 4 | 65 | F 3 | | | Timbale H | | | | | |
| B6 | B#6 | 78 | F# 4 | 66 | F# 3 | | | Timbale L | | | | | |
| C7 | C#7 | 79 | G 4 | 67 | G 3 | | | Agogo H | | | | | |
| D7 | D#7 | 80 | G# 4 | 68 | G# 3 | | | Agogo L | | | | | |
| E7 | E#7 | 81 | A 4 | 69 | A 3 | | | Cabasa | | | Shower | Laugh | |
| F7 | F#7 | 82 | A# 4 | 70 | A# 3 | | | Maracas | Analog Maracas | | Thunder | Scream | |
| G7 | G#7 | 83 | B 4 | 71 | B 3 | O | | Samba Whistle H | | | Wind | Punch | |
| A7 | A#7 | 84 | C 5 | 72 | C 4 | O | | Samba Whistle L | | | Stream | Heartbeat | |
| B7 | B#7 | 85 | C# 5 | 73 | C# 4 | | | Guiro Short | | | Bubble | FootSteps | |
| C8 | C#8 | 86 | D 5 | 74 | D 4 | O | | Guiro Long | | | Feed | | |
| D8 | D#8 | 87 | D# 5 | 75 | D# 4 | | | Claves | Analog Claves | | | | |
| E8 | E#8 | 88 | E 5 | 76 | E 4 | | | Wood Block H | | | | | |
| F8 | F#8 | 89 | F 5 | 77 | F 4 | | | Wood Block L | | | | | |
| G8 | G#8 | 90 | F# 5 | 78 | F# 4 | | | Cuica Mute | Scratch Push | | | | |
| A8 | A#8 | 91 | G 5 | 79 | G 4 | | | Cuica Open | Scratch Pull | | | | |
| B8 | B#8 | 92 | G# 5 | 80 | G# 4 | | 2 | Triangle Mute | | | | | |
| C9 | C#9 | 93 | A 5 | 81 | A 4 | | 2 | Triangle Open | | | | | |
| D9 | D#9 | 94 | A# 5 | 82 | A# 4 | | | Shaker | | | | | |
| E9 | E#9 | 95 | B 5 | 83 | B 4 | | | Jingle Bell | | | | | |
| F9 | F#9 | 96 | C 6 | 84 | C 5 | | | Bell Tree | | | | Dog | Machine Gun |
| G9 | G#9 | 97 | C# 6 | 85 | C# 5 | | | | | | | Horse | Laser Gun |
| A9 | A#9 | 98 | D 6 | 86 | D 5 | | | | | | | Bird Tweet 2 | Explosion |
| B9 | B#9 | 99 | D# 6 | 87 | D# 5 | | | | | | | | Firework |
| C10 | C#10 | 100 | E 6 | 88 | E 5 | | | | | | | | |
| D10 | D#10 | 101 | F 6 | 89 | F 5 | | | | | | | | |
| E10 | E#10 | 102 | F# 6 | 90 | F# 5 | | | | | | | | |
| F10 | F#10 | 103 | G 6 | 91 | G 5 | | | | | | Maou | | |

NOTE:

*1 By default (factory settings) the PSR-275/273 ordinarily functions as a 16-channel multi-timbral tone generator, and incoming data does not affect the panel voices or panel settings. However, the MIDI messages listed below do affect the panel voices, auto accompaniment, and songs.

- MIDI Master Tuning
- System exclusive messages for changing the Reverb Type and Chorus Type.

*2 Messages for these control change numbers cannot be transmitted from the PSR-275/273 itself. However, they may be transmitted when playing the accompaniment, song or using the Harmony effect.

*3 Exclusive

<GM System ON> F0H, 7EH, 7FH, 09H, 01H, F7H

- This message automatically restores all default settings for the instrument, with the exception of MIDI Master Tuning.

<MIDI Master Volume> F0H, 7FH, 7FH, 04H, 01H, II, mm, F7H

- This message allows the volume of all channels to be changed simultaneously (Universal System Exclusive).
- The values of "mm" is used for MIDI Master Tuning. (Values for "II" are ignored.)

<MIDI Master Tuning> F0H, 43H, 1nH, 27H, 30H, 00H, 00H, mm, II, cc, F7H

- This message simultaneously changes the tuning value of all channels.
- The values of "mm" and "II" are used for MIDI Master Tuning.
- The default value of "mm" and "II" are 08H and 00H, respectively. Any values can be used for "n" and "cc."

<Reverb Type> F0H, 43H, 1nH, 4CH, 02H, 01H, 00H, mmH, IIH, F7H

- mm : Reverb Type MSB
- II : Reverb Type LSB

Refer to the Effect Map (page 69) for details.

<Chorus Type> F0H, 43H, 1nH, 4CH, 02H, 01H, 20H, mmH, IIH, F7H

- mm : Chorus Type MSB
- II : Chorus Type LSB

Refer to the Effect Map (page 69) for details.

*4 When the accompaniment is started, an FAH message is transmitted. When accompaniment is stopped, an FCH message is transmitted. When the clock is set to External, both FAH (accompaniment start) and FCH (accompaniment stop) are recognized.

*5 Local ON/OFF

<Local ON> Bn, 7A, 7F

<Local OFF> Bn, 7A, 00

Value for "n" is ignored.

Effect map

- * If the received value does not contain an effect type in the TYPE LSB, the LSB will be directed to TYPE 0.
- * The numbers in parentheses in front of the Effect Type names correspond to the number indicated in the display.
- * By using an external sequencer, which is capable of editing and transmitting the system exclusive messages and parameter changes, you can select the Reverb and Chorus effect types which are not accessible from the PSR-275/273 panel itself. When one of the effects is selected by the external sequencer, "-" will be shown on the display.

REVERB

| TYPE MSB | TYPE LSB | | | | | | | | | |
|-----------|-----------|----|----|----|-----------|-----------|----|----------|----|--|
| | 00 | 01 | 02 | 08 | 16 | 17 | 18 | 19 | 20 | |
| 000 | No Effect | | | | | | | | | |
| 001 | (1)Hall1 | | | | (2)Hall2 | (3)Hall3 | | | | |
| 002 | Room | | | | | (4)Room1 | | (5)Room2 | | |
| 003 | Stage | | | | (6)Stage1 | (7)Stage2 | | | | |
| 004 | Plate | | | | (8)Plate1 | (9)Plate2 | | | | |
| 005 - 127 | No Effect | | | | | | | | | |

CHORUS

| TYPE MSB | TYPE LSB | | | | | | | | | |
|-----------|-----------|----|------------|-------------|----|-------------|----|----|----|--|
| | 00 | 01 | 02 | 08 | 16 | 17 | 18 | 19 | 20 | |
| 000 - 063 | No Effect | | | | | | | | | |
| 064 | Thru | | | | | | | | | |
| 065 | Chorus | | (2)Chorus2 | | | | | | | |
| 066 | Celeste | | | | | (1)Chorus1 | | | | |
| 067 | Flanger | | | (3)Flanger1 | | (4)Flanger2 | | | | |
| 068 - 127 | No Effect | | | | | | | | | |

Troubleshooting

| Problem | Possible Cause and Solution |
|---|--|
| When the PSR-275/273 is turned on or off, a popping sound is temporarily produced. | This is normal and indicates that the PSR-275/273 is receiving electrical power. |
| When using a mobile phone, noise is produced. | Using a mobile phone in close proximity to the PSR-275/273 may produce interference. To prevent this, turn off the mobile phone or use it further away from the PSR-275/273. |
| There is no sound even when the keyboard is played or when a song is being played back. | Check that nothing is connected to the PHONES/OUTPUT jack on the rear panel. When a set of headphones is plugged into this jack, no sound is output. |
| | Check the Local Control on/off or PC Mode on/off. (See page 57, 58.) |
| Playing keys in the right hand area of the keyboard does not produce any sound. | When using the Dictionary function (page 42), the keys in the right hand area are used only for entering the chord root and type. |
| The sound of the voices or rhythms seems unusual or strange. | The battery power is too low. Replace the batteries. (See page 10.) |
| The auto accompaniment doesn't turn on, even when pressing the [ACMP ON/OFF] button. | Make sure the Style mode is active before using the auto accompaniment. Press the [STYLE] button to enable style operations. |
| The style or song does not play back even when pressing the [START/STOP] button. | Check the External Clock on/off. (See page 57.) |
| The style or song does not sound properly. | Make sure that the Style Volume or Song Volume (page 39) is set to an appropriate level. |
| When playing back one of the Pianist styles (#93 - #100), the rhythm cannot be heard. | This is normal. The Pianist styles have no drums or bass — only piano accompaniment. The accompaniment of the style can only be heard when accompaniment is set to ON and keys are played in the auto accompaniment area of the keyboard. |
| Not all of the voices seem to sound, or the sound seems to be cut off. | The PSR-275/273 is polyphonic up to a maximum of 32 notes. If the Dual voice or Split voice is being used and a style or song is playing back at the same time, some notes/sounds may be omitted (or "stolen") from the accompaniment or song. |
| A strange "flanging" or "doubling" sound occurs when using the PSR-275/273 with a sequencer. (This may also sound like a "dual" layered sound of two voices, even when Dual is turned off.) | When using the style with a sequencer, set MIDI Echo (or the relevant control) to "off." (Refer to the owner's manual of your particular device and/or software for details.) |
| The footswitch (for sustain) seems to produce the opposite effect. For example, pressing the footswitch cuts off the sound and releasing it sustains the sounds. | The polarity of the footswitch is reversed. Make sure that the footswitch plug is properly connected to the SUSTAIN jack before turning on the power. |
| The sound of the voice changes from note to note. | The AWM tone generation method uses multiple recordings (samples) of an instrument across the range of the keyboard; thus, the actual sound of the voice may be slightly different from note to note. |

Specifications

Keyboards

- 61 standard-size keys (C1 - C6), with Touch Response.

Display

- Large multi-function LCD display (backlit)

Setup

- STANDBY/ON
- MASTER VOLUME : MIN - MAX

Panel Controls

- SONG, VOICE, STYLE, Dict., PC, LESSON L, R, METRONOME, PORTABLE GRAND, DEMO, FUNCTION, TOUCH, HARMONY, DUAL, SPLIT, SUSTAIN, TEMPO/TAP, [0]-[9], [+](YES), [-](NO)

Voice

- 108 panel voices + 12 drum kits + 360 XG Lite voices
- Polyphony : 32
- DUAL
- SPLIT

Style

- 100 styles
- Style Control : ACMP ON/OFF, SYNC START, START/STOP, INTRO/ENDING/rit., MAIN/AUTO FILL
- Fingering : Multi fingering
- Style Volume

Yamaha Educational Suite

- Dictionary
- Lesson 1-4

Function

- Overall : Transpose, Tuning, Split Point, Touch Sensitivity
- Volume : Style Volume, Song Volume, Metronome Volume, Metronome Time Signature
- Main Voice : Volume, Octave, Reverb Send Level, Chorus Send Level
- Dual Voice : Voice, Volume, Octave, Reverb Send Level, Chorus Send Level
- Split Voice : Voice, Volume, Octave, Reverb Send Level, Chorus Send Level
- Effect/Harmony : Reverb Type, Chorus Type, Harmony Type, Harmony Volume
- Utility : Local On/Off, External Clock, Initial Setup Send

Effects

- Reverb : 9 types
- Chorus : 4 types
- Harmony : 26 types

Song

- 100 Songs
- Song Volume

MIDI

- Local On/Off
- Initial Setup Send
- External Clock

Auxiliary jacks

- PHONES/OUTPUT, DC IN 10-12V, MIDI IN/OUT, SUSTAIN

Amplifier

- 2.7W + 2.7W

Speakers

- 12cm x 2

Power Consumption (when using PA-3C power adaptor)

- 10 W

Power Supply

- Adaptor : Yamaha PA-3C AC power adaptor
- Batteries : Six "D" size, R20P (LR20) or equivalent batteries

Dimensions (W x D x H)

- 933 x 370 x 129 mm (36-3/4" x 14-5/8" x 5")

Weight

- 5.3 kg (11 lbs. 11 oz.)

Supplied Accessories

- Music Rest
- Owner's Manual
- Song Book

Optional Accessories

- Headphones : HPE-150
- AC power adaptor : PA-3B/3C
- Footswitch : FC4, FC5
- Keyboard stand : L-2C

* Specifications and descriptions in this owner's manual are for information purposes only. Yamaha Corp. reserves the right to change or modify products or specifications at any time without prior notice. Since specifications, equipment or options may not be the same in every locale, please check with your Yamaha dealer.

* The colors of the battery compartment cover and the instrument itself may differ depending on the particular model.

Panel controls and terminals

| | |
|-------------------|-----------|
| +/- | 8, 19 |
| A-B REPEAT | 8, 46 |
| ACMP ON/OFF | 8, 34 |
| DC IN 10-12V | 9, 10 |
| DEMO | 8, 14 |
| Dict. | 8, 42 |
| DUAL | 9, 25 |
| FF | 9, 46 |
| FUNCTION | 8, 18, 59 |
| HARMONY | 9, 29 |
| INTRO/ENDING/rit. | 9, 34 |
| LESSON | 8, 50 |
| MAIN/AUTO FILL | 9, 34 |
| MASTER VOLUME | 8, 18 |
| METRONOME | 8, 21 |
| MIDI IN | 9, 55 |
| MIDI OUT | 9, 55 |
| NO | 8 |
| Numeric keypad | 8, 19 |
| PAUSE | 8, 46 |
| PC | 8, 58 |
| PHONES/OUTPUT | 9, 11 |
| PORTABLE GRAND | 8, 21 |
| REW | 9, 46 |
| SONG | 9, 45, 49 |
| SPLIT | 9, 26 |
| STANDBY/ON | 8, 11 |
| START/STOP | 8, 34, 46 |
| STYLE | 9, 33 |
| SUSTAIN | 9, 11, 30 |
| SYNC START | 8, 34 |
| TEMPO/TAP | 9, 21, 38 |
| TOUCH | 8, 27 |
| VOICE | 9, 23 |
| YES | 8 |

Misc.

| | |
|----------|----|
| #000 OTS | 25 |
|----------|----|

A

| | |
|---------------------------|----|
| A-B repeat | 47 |
| AC Power adaptor | 10 |
| accessory jacks | 11 |
| accompaniment sections | 39 |
| Accompaniment Split Point | 26 |

B

| | |
|--------------|--------|
| Batteries | 10 |
| Beat display | 20, 38 |

C

| | |
|-----------------------|----|
| Chord Names | 44 |
| Chord Type | 44 |
| Chords, About | 43 |
| Chords, Fingered | 40 |
| Chords, Single Finger | 40 |
| Chorus | 30 |

D

| | |
|----------------------|----|
| DEMO Cancel | 14 |
| Demo song | 14 |
| Dictionary | 42 |
| Drum Kit Voice Chart | 66 |
| Dual Voice | 25 |

E

| | |
|----------------|----|
| Effects | 29 |
| Ending | 34 |
| External Clock | 57 |

F

| | |
|-----------------|--------|
| Fill-in | 39 |
| Fingered chords | 40 |
| Footswitch | 11 |
| Function | 18, 59 |

G

| | |
|-------------------|----|
| GM System Level 1 | 54 |
| Grade | 53 |

H

| | |
|------------|----|
| Harmony | 29 |
| Headphones | 11 |

I

| | |
|--------------------|----|
| Indicator | 20 |
| Initial Setup Send | 57 |
| Internal Clock | 57 |
| Intro | 36 |

K

| | |
|----------|----|
| Keyboard | 20 |
|----------|----|

L

| | |
|--------------------|----|
| Left | 50 |
| Lesson | 49 |
| Level, chorus send | 30 |
| Level, reverb send | 29 |
| Local on/off | 57 |

M

| | |
|---------------------------|----|
| Main A/B | 39 |
| Main Voice | 23 |
| Master Volume | 18 |
| Melody Voice Change | 48 |
| Metronome | 21 |
| MIDI | 54 |
| MIDI channels | 55 |
| MIDI Implementation Chart | 68 |
| MIDI LSB Receive cancel | 57 |
| MIDI terminals | 55 |
| Multi Fingering | 40 |
| Music Rest | 19 |

N

| | |
|----------|----|
| Notation | 20 |
|----------|----|

O

| | |
|-------------------|----|
| Octave | 20 |
| Octave, dual | 25 |
| Octave, main | 23 |
| Octave, split | 26 |
| One Touch Setting | 25 |

P

| | |
|----------------|----|
| PC | 58 |
| Portable Grand | 21 |

Q

| | |
|-------------|----|
| Quick Guide | 12 |
|-------------|----|

R

| | |
|------------|----|
| Reverb | 29 |
| Right | 50 |
| Ritardando | 37 |
| Root | 43 |

S

| | |
|--------------------------|----|
| sections (accompaniment) | 39 |
| Single Finger chords | 40 |
| Song Volume | 48 |
| songs, playing | 46 |
| songs, selecting | 45 |

| | |
|------------------------|----|
| Specifications..... | 71 |
| Split Point..... | 26 |
| Split Voice..... | 26 |
| Style Volume..... | 39 |
| styles, playing..... | 34 |
| styles, selecting..... | 33 |
| Sustain..... | 30 |
| Sync Start..... | 35 |

T

| | |
|------------------------|--------|
| Tap..... | 35 |
| Tempo..... | 21, 38 |
| Time Signature..... | 22 |
| Touch Sensitivity..... | 27 |
| Transpose..... | 28 |
| Troubleshooting..... | 70 |
| Tuning..... | 28 |

V

| | |
|------------------------------------|----|
| Voice List..... | 61 |
| voices, Drum Kit..... | 66 |
| voices, selecting and playing..... | 23 |
| voices, XG Lite..... | 62 |
| Volume, dual..... | 25 |
| Volume, harmony..... | 29 |
| Volume, main..... | 23 |
| Volume, Metronome..... | 22 |
| Volume, Song..... | 48 |
| Volume, split..... | 26 |
| Volume, Style..... | 39 |

X

| | |
|-------------------------|----|
| XG Lite Voice List..... | 62 |
|-------------------------|----|

Limited Warranty

90 DAYS LABOR

1 YEAR PARTS

Yamaha Corporation of America, hereafter referred to as Yamaha, warrants to the original consumer of a product included in the categories listed below, that the product will be free of defects in materials and/or workmanship for the periods indicated. This warranty is applicable to all models included in the following series of products:

PSR SERIES OF PORTATONE ELECTRONIC KEYBOARDS

If during the first 90 days that immediately follows the purchase date, your new Yamaha product covered by this warranty is found to have a defect in material and/or workmanship, Yamaha and/or its authorized representative will repair such defect without charge for parts or labor.

If parts should be required after this 90 day period but within the one year period that immediately follows the purchase date, Yamaha will, subject to the terms of this warranty, supply these parts without charge. However, charges for labor, and/or any miscellaneous expenses incurred are the consumers responsibility. Yamaha reserves the right to utilize reconditioned parts in repairing these products and/or to use reconditioned units as warranty replacements.

THIS WARRANTY IS THE ONLY EXPRESS WARRANTY WHICH YAMAHA MAKES IN CONNECTION WITH THESE PRODUCTS. ANY IMPLIED WARRANTY APPLICABLE TO THE PRODUCT, INCLUDING THE WARRANTY OF MERCHANT ABILITY IS LIMITED TO THE DURATION OF THE EXPRESS WARRANTY. YAMAHA EXCLUDES AND SHALL NOT BE LIABLE IN ANY EVENT FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES.

Some states do not allow limitations that relate to implied warranties and/or the exclusion of incidental or consequential damages. Therefore, these limitations and exclusions may not apply to you.

This warranty gives you specific legal rights. You may also have other rights which vary from state to state.

CONSUMERS RESPONSIBILITIES

If warranty service should be required, it is necessary that the consumer assume certain responsibilities:

1. Contact the Customer Service Department of the retailer selling the product, or any retail outlet authorized by Yamaha to sell the product for assistance. You may also contact Yamaha directly at the address provided below.
2. Deliver the unit to be serviced under warranty to: the retailer selling the product, an authorized service center, or to Yamaha with an explanation of the problem. Please be prepared to provide proof purchase date (sales receipt, credit card copy, etc.) when requesting service and/or parts under warranty.
3. Shipping and/or insurance costs are the consumers responsibility.* Units shipped for service should be packed securely.

*Repaired units will be returned PREPAID if warranty service is required within the first 90 days.

IMPORTANT: Do NOT ship anything to ANY location without prior authorization. A Return Authorization (RA) will be issued that has a tracking number assigned that will expedite the servicing of your unit and provide a tracking system if needed.

4. Your owners manual contains important safety and operating instructions. It is your responsibility to be aware of the contents of this manual and to follow all safety precautions.

EXCLUSIONS

This warranty does not apply to units whose trade name, trademark, and/or ID numbers have been altered, defaced, exchanged removed, or to failures and/or damages that may occur as a result of:

1. Neglect, abuse, abnormal strain, modification or exposure to extremes in temperature or humidity.
2. Improper repair or maintenance by any person who is not a service representative of a retail outlet authorized by Yamaha to sell the product, an authorized service center, or an authorized service representative of Yamaha.
3. This warranty is applicable only to units sold by retailers authorized by Yamaha to sell these products in the U.S.A., the District of Columbia, and Puerto Rico. This warranty is not applicable in other possessions or territories of the U.S.A. or in any other country.

Please record the model and serial number of the product you have purchased in the spaces provided below.

Model _____ Serial # _____ Sales Slip # _____

Purchased from _____ Date _____
(Retailer)

YAMAHA CORPORATION OF AMERICA
Electronic Service Division
6600 Orangethorpe Avenue
Buena Park, CA 90620

KEEP THIS DOCUMENT FOR YOUR RECORDS. DO NOT MAIL!

For details of products, please contact your nearest Yamaha representative or the authorized distributor listed below.

Pour plus de détails sur les produits, veuillez-vous adresser à Yamaha ou au distributeur le plus proche de vous figurant dans la liste suivante.

Die Einzelheiten zu Produkten sind bei Ihrer unten aufgeführten Niederlassung und bei Yamaha Vertragshändlern in den jeweiligen Bestimmungsländern erhältlich.

Para detalles sobre productos, contacte su tienda Yamaha más cercana o el distribuidor autorizado que se lista debajo.

NORTH AMERICA

CANADA

Yamaha Canada Music Ltd.
135 Milner Avenue, Scarborough, Ontario,
M1S 3R1, Canada
Tel: 416-298-1311

U.S.A.

Yamaha Corporation of America
6600 Orangethorpe Ave., Buena Park, Calif. 90620,
U.S.A.
Tel: 714-522-9011

CENTRAL & SOUTH AMERICA

MEXICO

**Yamaha de Mexico S.A. De C.V.,
Departamento de ventas**
Javier Rojo Gomez No.1149, Col. Gpe Del
Moral, Deleg. Iztapalapa, 09300 Mexico, D.F.
Tel: 686-00-33

BRAZIL

Yamaha Musical do Brasil LTDA.
Av. Rebouças 2636, São Paulo, Brasil
Tel: 011-853-1377

ARGENTINA

Yamaha de Panamá S.A. Sucursal de Argentina
Viamonte 1145 Piso 2-B 1053,
Buenos Aires, Argentina
Tel: 1-4371-7021

PANAMA AND OTHER LATIN AMERICAN COUNTRIES/ CARIBBEAN COUNTRIES

Yamaha de Panamá S.A.
Torre Banco General, Piso 7, Urbanización Marbella,
Calle 47 y Aquilino de la Guardia,
Ciudad de Panamá, Panamá
Tel: +507-269-5311

EUROPE

THE UNITED KINGDOM

Yamaha-Kemble Music (U.K.) Ltd.
Sherbourne Drive, Tilbrook, Milton Keynes,
MK7 8BL, England
Tel: 01908-366700

IRELAND

Danfay Ltd.
61D, Sallynoggin Road, Dun Laoghaire, Co. Dublin
Tel: 01-2859177

GERMANY

Yamaha Music Central Europe GmbH
Siemensstraße 22-34, 25462 Rellingen, Germany
Tel: 04101-3030

SWITZERLAND/LIECHTENSTEIN

**Yamaha Music Central Europe GmbH,
Branch Switzerland**
Seefeldstrasse 94, 8008 Zürich, Switzerland
Tel: 01-383 3990

AUSTRIA

**Yamaha Music Central Europe GmbH,
Branch Austria**
Schleiergasse 20, A-1100 Wien, Austria
Tel: 01-60203900

THE NETHERLANDS

**Yamaha Music Central Europe,
Branch Nederland**
Clarissenhof 5-b, 4133 AB Vianen, The Netherlands
Tel: 0347-358 040

BELGIUM/LUXEMBOURG

**Yamaha Music Central Europe GmbH,
Branch Belgium**
Rue de Geneve (Genevastraat) 10, 1140 - Brussels,
Belgium
Tel: 02-726 6032

FRANCE

**Yamaha Musique France, S.A.
Division Professionnelle**
BP 70-77312 Marne-la-Vallée Cedex 2, France
Tel: 01-64-61-4000

ITALY

**Yamaha Musica Italia S.P.A.
Combo Division**
Viale Italia 88, 20020 Lainate (Milano), Italy
Tel: 02-935-771

SPAIN/PORTUGAL

Yamaha-Hazen Música, S.A.
Ctra. de la Coruna km. 17, 200, 28230
Las Rozas (Madrid), Spain
Tel: 91-639-8888

GREECE

Philippos Nakas S.A. The Music House
147 Skiathou Street, 112-55 Athens, Greece
Tel: 01-228 2160

SWEDEN

Yamaha Scandinavia AB
J. A. Wettergrens Gata 1
Box 30053
S-400 43 Göteborg, Sweden
Tel: 031 89 34 00

DENMARK

YS Copenhagen Liaison Office
Generatorvej 8B
DK-2730 Herlev, Denmark
Tel: 44 92 49 00

FINLAND

F-Musiikki Oy
Kluuvikatu 6, P.O. Box 260,
SF-00101 Helsinki, Finland
Tel: 09 618511

NORWAY

Norsk filial av Yamaha Scandinavia AB
Grini Næringspark 1
N-1345 Østerås, Norway
Tel: 67 16 77 70

ICELAND

Skifan HF
Skeifan 17 P.O. Box 8120
IS-128 Reykjavik, Iceland
Tel: 525 5000

OTHER EUROPEAN COUNTRIES

Yamaha Music Central Europe GmbH
Siemensstraße 22-34, 25462 Rellingen, Germany
Tel: +49-4101-3030

AFRICA

**Yamaha Corporation,
Asia-Pacific Music Marketing Group**
Nakazawa-cho 10-1, Hamamatsu, Japan 430-8650
Tel: +81-53-460-2312

MIDDLE EAST

TURKEY/CYPRUS

Yamaha Music Central Europe GmbH
Siemensstraße 22-34, 25462 Rellingen, Germany
Tel: 04101-3030

OTHER COUNTRIES

Yamaha Music Gulf FZE
LB21-128 Jebel Ali Freezone
P.O.Box 17328, Dubai, U.A.E.
Tel: +971-4-881-5868

ASIA

HONG KONG

Tom Lee Music Co., Ltd.
11/F., Silvercord Tower 1, 30 Canton Road,
Tsimshatsui, Kowloon, Hong Kong
Tel: 2737-7688

INDONESIA

**PT. Yamaha Music Indonesia (Distributor)
PT. Nusantik**
Gedung Yamaha Music Center, Jalan Jend. Gatot
Subroto Kav. 4, Jakarta 12930, Indonesia
Tel: 21-520-2577

KOREA

Yamaha Music Korea Ltd.
Tong-Yang Securities Bldg. 16F 23-8 Yoido-dong,
Youngdungpo-ku, Seoul, Korea
Tel: 02-3770-0661

MALAYSIA

Yamaha Music Malaysia, Sdn., Bhd.
Lot 8, Jalan Perbandaran, 47301 Kelana Jaya,
Petaling Jaya, Selangor, Malaysia
Tel: 3-703-0900

PHILIPPINES

Yupangco Music Corporation
339 Gil J. Puyat Avenue, P.O. Box 885 MCPO,
Makati, Metro Manila, Philippines
Tel: 819-7551

SINGAPORE

Yamaha Music Asia Pte., Ltd.
11 Ubi Road #06-00, Meiban Industrial Building,
Singapore
Tel: 65-747-4374

TAIWAN

Yamaha KHS Music Co., Ltd.
3F, #6, Sec.2, Nan Jing E. Rd. Taipei.
Taiwan 104, R.O.C.
Tel: 02-2511-8688

THAILAND

Siam Music Yamaha Co., Ltd.
121/60-61 RS Tower 17th Floor,
Ratchadaphisek RD., Dindaeng,
Bangkok 10320, Thailand
Tel: 02-641-2951

THE PEOPLE'S REPUBLIC OF CHINA AND OTHER ASIAN COUNTRIES

**Yamaha Corporation,
Asia-Pacific Music Marketing Group**
Nakazawa-cho 10-1, Hamamatsu, Japan 430-8650
Tel: +81-53-460-2317

OCEANIA

AUSTRALIA

Yamaha Music Australia Pty. Ltd.
Level 1, 99 Queensbridge Street, Southbank,
Victoria 3006, Australia
Tel: 3-9693-5111

NEW ZEALAND

Music Houses of N.Z. Ltd.
146/148 Captain Springs Road, Te Papapa,
Auckland, New Zealand
Tel: 9-634-0099

COUNTRIES AND TRUST

TERRITORIES IN PACIFIC OCEAN

**Yamaha Corporation,
Asia-Pacific Music Marketing Group**
Nakazawa-cho 10-1, Hamamatsu, Japan 430-8650
Tel: +81-53-460-2312

HEAD OFFICE Yamaha Corporation, Pro Audio & Digital Musical Instrument Division
Nakazawa-cho 10-1, Hamamatsu, Japan 430-8650
Tel: +81-53-460-3273



Yamaha PK CLUB (Portable Keyboard Home Page, English only)

<http://www.yamahaPKclub.com/>

Yamaha Manual Library

<http://www2.yamaha.co.jp/manual/english/>

M.D.G., Pro Audio & Digital Musical Instrument Division, Yamaha Corporation
© 2003 Yamaha Corporation

WA07030 ???PO???.?-01A0 Printed in China