



PORTATONE

PSR-E303

YPT-300



Owner's Manual



SPECIAL MESSAGE SECTION

This product utilizes batteries or an external power supply (adapter). DO NOT connect this product to any power supply or adapter other than one described in the manual, on the name plate, or specifically recommended by Yamaha.

This product should be used only with the components supplied or; a cart, rack, or stand that is recommended by Yamaha. If a cart, etc., is used, please observe all safety markings and instructions that accompany the accessory product.

SPECIFICATIONS SUBJECT TO CHANGE:

The information contained in this manual is believed to be correct at the time of printing. However, Yamaha reserves the right to change or modify any of the specifications without notice or obligation to update existing units.

This product, either alone or in combination with an amplifier and headphones or speaker/s, may be capable of producing sound levels that could cause permanent hearing loss. DO NOT operate for long periods of time at a high volume level or at a level that is uncomfortable. If you experience any hearing loss or ringing in the ears, you should consult an audiologist.

IMPORTANT: The louder the sound, the shorter the time period before damage occurs.

NOTICE:

Service charges incurred due to a lack of knowledge relating to how a function or effect works (when the unit is operating as designed) are not covered by the manufacturer's warranty, and are therefore the owners responsibility. Please study this manual carefully and consult your dealer before requesting service.

ENVIRONMENTAL ISSUES:

Yamaha strives to produce products that are both user safe and environmentally friendly. We sincerely believe that our products and the production methods used to produce them, meet these goals. In keeping with both the letter and the spirit of the law, we want you to be aware of the following:

Battery Notice:

This product MAY contain a small non-rechargeable battery which (if applicable) is soldered in place. The average life span of this type of battery is approximately five years. When replacement becomes necessary, contact a qualified service representative to perform the replacement.

This product may also use "household" type batteries. Some of these may be rechargeable. Make sure that the battery being charged is a rechargeable type and that the charger is intended for the battery being charged.

When installing batteries, do not mix batteries with new, or with batteries of a different type. Batteries MUST be installed correctly. Mismatches or incorrect installation may result in overheating and battery case rupture.

Warning:

Do not attempt to disassemble, or incinerate any battery. Keep all batteries away from children. Dispose of used batteries promptly and as regulated by the laws in your area. Note: Check with any retailer of household type batteries in your area for battery disposal information.

Disposal Notice:

Should this product become damaged beyond repair, or for some reason its useful life is considered to be at an end, please observe all local, state, and federal regulations that relate to the disposal of products that contain lead, batteries, plastics, etc. If your dealer is unable to assist you, please contact Yamaha directly.

NAME PLATE LOCATION:

The name plate is located on the bottom of the product. The model number, serial number, power requirements, etc., are located on this plate. You should record the model number, serial number, and the date of purchase in the spaces provided below and retain this manual as a permanent record of your purchase.

Model

Serial No.

Purchase Date

PLEASE KEEP THIS MANUAL

92-BP (bottom)

FCC INFORMATION (U.S.A.)

1. IMPORTANT NOTICE: DO NOT MODIFY THIS UNIT!

This product, when installed as indicated in the instructions contained in this manual, meets FCC requirements. Modifications not expressly approved by Yamaha may void your authority, granted by the FCC, to use the product.

2. IMPORTANT: When connecting this product to accessories and/or another product use only high quality shielded cables. Cable/s supplied with this product MUST be used. Follow all installation instructions. Failure to follow instructions could void your FCC authorization to use this product in the USA.

3. NOTE: This product has been tested and found to comply with the requirements listed in FCC Regulations, Part 15 for Class "B" digital devices. Compliance with these requirements provides a reasonable level of assurance that your use of this product in a residential environment will not result in harmful interference with other electronic devices. This equipment generates/uses radio frequencies and, if not installed and used according to the instructions found in the users manual, may cause interference harmful to the operation of

other electronic devices. Compliance with FCC regulations does not guarantee that interference will not occur in all installations. If this product is found to be the source of interference, which can be determined by turning the unit "OFF" and "ON", please try to eliminate the problem by using one of the following measures:

Relocate either this product or the device that is being affected by the interference.

Utilize power outlets that are on different branch (circuit breaker or fuse) circuits or install AC line filter/s.

In the case of radio or TV interference, relocate/reorient the antenna. If the antenna lead-in is 300 ohm ribbon lead, change the lead-in to co-axial type cable.

If these corrective measures do not produce satisfactory results, please contact the local retailer authorized to distribute this type of product. If you can not locate the appropriate retailer, please contact Yamaha Corporation of America, Electronic Service Division, 6600 Orangethorpe Ave, Buena Park, CA90620

The above statements apply ONLY to those products distributed by Yamaha Corporation of America or its subsidiaries.

* This applies only to products distributed by YAMAHA CORPORATION OF AMERICA.

(class B)

OBSERVERA!

Apparaten kopplas inte ur växelströmskällan (nätet) så länge som den är ansluten till vägguttaget, även om själva apparaten har stängts av.

ADVARSEL: Netbspændingen til dette apparat er IKKE afbrudt, så længe netledningen sidder i en stikkontakt, som er t endt — også selvom der er slukket på apparatets afbryder.

VAROITUS: Laitteen toisiopiiriin kytketty käyttökytin ei irroita koko laitetta verkosta.

(standby)

Entsorgung leerer Batterien (nur innerhalb Deutschlands)

Leisten Sie einen Beitrag zum Umweltschutz. Verbrauchte Batterien oder Akkumulatoren dürfen nicht in den Hausmüll. Sie können bei einer Sammelstelle für Altbatterien bzw. Sondermüll abgegeben werden. Informieren Sie sich bei Ihrer Kommune.

(battery)

PRECAUTIONS

PLEASE READ CAREFULLY BEFORE PROCEEDING

* Please keep this manual in a safe place for future reference.



WARNING

Always follow the basic precautions listed below to avoid the possibility of serious injury or even death from electrical shock, short-circuiting, damages, fire or other hazards. These precautions include, but are not limited to, the following:

Power supply/AC power adaptor

- Only use the voltage specified as correct for the instrument. The required voltage is printed on the name plate of the instrument.
- Use the specified adaptor (PA-3B, PA-3C or an equivalent recommended by Yamaha) only. Using the wrong adaptor can result in damage to the instrument or overheating.
- Check the electric plug periodically and remove any dirt or dust which may have accumulated on it.
- Do not place the AC adaptor cord near heat sources such as heaters or radiators, and do not excessively bend or otherwise damage the cord, place heavy objects on it, or place it in a position where anyone could walk on, trip over, or roll anything over it.

Do not open

- Do not open the instrument or attempt to disassemble the internal parts or modify them in any way. The instrument contains no user-serviceable parts. If it should appear to be malfunctioning, discontinue use immediately and have it inspected by qualified Yamaha service personnel.

Water warning

- Do not expose the instrument to rain, use it near water or in damp or wet conditions, or place containers on it containing liquids which might spill into any openings.
- Never insert or remove an electric plug with wet hands.

Fire warning

- Do not put burning items, such as candles, on the unit. A burning item may fall over and cause a fire.

If you notice any abnormality

- If the AC adaptor cord or plug becomes frayed or damaged, or if there is a sudden loss of sound during use of the instrument, or if any unusual smells or smoke should appear to be caused by it, immediately turn off the power switch, disconnect the adaptor plug from the outlet, and have the instrument inspected by qualified Yamaha service personnel.



CAUTION

Always follow the basic precautions listed below to avoid the possibility of physical injury to you or others, or damage to the instrument or other property. These precautions include, but are not limited to, the following:

Power supply/AC power adaptor

- When removing the electric plug from the instrument or an outlet, always hold the plug itself and not the cord.
- Unplug the AC power adaptor when not using the instrument, or during electrical storms.
- Do not connect the instrument to an electrical outlet using a multiple-connector. Doing so can result in lower sound quality, or possibly cause overheating in the outlet.

Battery

- Always make sure all batteries are inserted in conformity with the +/- polarity markings. Failure to do so might result in overheating, fire, or battery fluid leakage.
- Always replace all batteries at the same time. Do not use new batteries together with old ones. Also, do not mix battery types, such as alkaline batteries with manganese batteries, or batteries from different makers, or different types of batteries from the same maker, since this can cause overheating, fire, or battery fluid leakage.
- Do not dispose of batteries in fire.

- Do not attempt to recharge batteries that are not intended to be charged.
- When the batteries run out, or if the instrument is not to be used for a long time, remove the batteries from the instrument to prevent possible leakage of the battery fluid.
- Keep batteries away from children.
- If the batteries do leak, avoid contact with the leaked fluid. If the battery fluid should come in contact with your eyes, mouth, or skin, wash immediately with water and consult a doctor. Battery fluid is corrosive and may possibly cause loss of sight or chemical burns.

Location

- Do not expose the instrument to excessive dust or vibrations, or extreme cold or heat (such as in direct sunlight, near a heater, or in a car during the day) to prevent the possibility of panel disfiguration or damage to the internal components.
- Do not use the instrument in the vicinity of a TV, radio, stereo equipment, mobile phone, or other electric devices. Otherwise, the instrument, TV, or radio may generate noise.
- Do not place the instrument in an unstable position where it might accidentally fall over.

- Before moving the instrument, remove all connected adaptor and other cables.
- Use only the stand specified for the instrument. When attaching the stand or rack, use the provided screws only. Failure to do so could cause damage to the internal components or result in the instrument falling over.

Connections

- Before connecting the instrument to other electronic components, turn off the power for all components. Before turning the power on or off for all components, set all volume levels to minimum. Also, be sure to set the volumes of all components at their minimum levels and gradually raise the volume controls while playing the instrument to set the desired listening level.

Maintenance

- When cleaning the instrument, use a soft, dry cloth. Do not use paint thinners, solvents, cleaning fluids, or chemical-impregnated wiping cloths.

Handling caution

- Do not insert a finger or hand in any gaps on the instrument.

- Never insert or drop paper, metallic, or other objects into the gaps on the panel or keyboard. If this happens, turn off the power immediately and unplug the power cord from the AC outlet. Then have the instrument inspected by qualified Yamaha service personnel.
- Do not place vinyl, plastic or rubber objects on the instrument, since this might discolor the panel or keyboard.
- Do not rest your weight on, or place heavy objects on the instrument, and do not use excessive force on the buttons, switches or connectors.
- Do not operate the instrument for a long period of time at a high or uncomfortable volume level, since this can cause permanent hearing loss. If you experience any hearing loss or ringing in the ears, consult a physician.

Saving data

Saving and backing up your data

- The panel settings and some other types of data will be lost if the power is turned off before they are saved. Be sure to save data you want to keep to the internal Flash Memory (page 29) before turning off the power. Saved data may be lost due to malfunction or incorrect operation. Save the important data to your computer. For information on sending the data, see page 63.

Yamaha cannot be held responsible for damage caused by improper use or modifications to the instrument, or data that is lost or destroyed.

Always turn the power off when the instrument is not in use.

When using a power adaptor, even when the power is off, electricity is still flowing to the instrument at the minimum level. When you are not using the instrument for a long time, make sure you unplug the AC power adaptor from the wall AC outlet.

Make sure to discard used batteries according to local regulations.

- The illustrations and LCD screens as shown in this owner's manual are for instructional purposes only, and may appear somewhat different from those on your instrument.
- Unless otherwise indicated, the example panel control illustrations, Keyboard illustrations and LCD screenshots are taken from the PSR-E303.

● Copyright Notice

The following is the title, credits, and copyright notices for the song pre-installed in this electronic.

Can You Feel The Love Tonight

from Walt Disney Pictures' THE LION KING

Music by Elton John

Lyrics by Tim Rice

© 1994 Wonderland Music Company, Inc.

All Rights Reserved Used by Permission

● COPYRIGHT NOTICE

This product incorporates and bundles computer programs and contents in which Yamaha owns copyrights or with respect to which it has license to use others' copyrights. Such copyrighted materials include, without limitation, all computer software, style files, MIDI files, WAVE data, musical scores and sound recordings. Any unauthorized use of such programs and contents outside of personal use is not permitted under relevant laws. Any violation of copyright has legal consequences. DON'T MAKE, DISTRIBUTE OR USE ILLEGAL COPIES.

● Trademarks

- Windows is the registered trademark of Microsoft® Corporation.
- All other trademarks are the property of their respective holders.

*Congratulations and thank you for purchasing
the Yamaha PSR-E303/YPT-300 PORTATONE!*

*Please read this owner's manual carefully before using the instrument
in order to take full advantage of its various features.*

*Make sure to keep this manual in a safe and handy place even after you finish reading,
and refer to it often when you need to better understand an operation or function.*

Panel logos



GM System Level 1

“GM System Level 1” is an addition to the MIDI standard which ensures that any GM-compatible music data can be accurately played by any GM-compatible tone generator, regardless of manufacturer. The GM mark is affixed to all software and hardware products that support GM System Level.



XGlite

As its name implies, “XGlite” is a simplified version of Yamaha’s high-quality XG tone generation format. Naturally, you can play back any XG song data using an XGlite tone generator. However, keep in mind that some songs may play back differently compared to the original data, due to the reduced set of control parameters and effects.



Stereo Sampled Piano

The instrument has a special Portable Grand Piano Voice—created by state-of-the-art stereo sampling technology and using Yamaha’s sophisticated AWM (Advanced Wave memory) tone generation system.



Yamaha Education Suite 5

The instrument features the new Yamaha Education Suite—a set of learning tools that utilize the latest technology to make studying and practicing music more fun and fulfilling than ever before!




Touch Response

The exceptionally natural Touch Response feature, with a convenient front panel on/off switch, gives you maximum expressive level control over the voices.

Supplied Accessories

The PSR-E303/YPT-300 package includes the following items. Please check that you have them all.

- Music rest
- Owner’s manual (this book)



Contents

Panel logos	6
Supplied Accessories	6
Setting Up	8
Power Requirements	8
Connecting headphones (PHONES/OUTPUT Jack)	9
Connecting a footswitch (SUSTAIN Jack)	9
Using the MIDI Terminals	9
Turn on the power	9
Panel Controls and Terminals	10
Front Panel	10
Rear Panel	10

— Quick Guide —

Step 1	
Changing the Voices	12
Try playing a variety of instrument Voices	12
Playing Two Voices Simultaneously—Dual	13
Playing Different Voices with the Left and Right Hands—Split	14
Playing the Grand Piano Voice	15
Drum kits	15
Step 2	
Fun Sounds	17
Step 3	
Play With The Metronome	18
Start the metronome	18
Step 4	
Playing Songs	20
Select and Listen to a Specific Song	20
Step 5	
Play with a Style	22
Selecting a rhythm of a Style	22
Playing with a Style	23
Step 6	
Record your own performance	25
Recording Your Performance	25
Recording to a specified track	26
Deleting User Songs	28

Backup and Initialization	29
Backup	29
Initialization	29
Basic Operation and Displays	30
Basic Operation	30
Display	32
Song Lesson	33
Lesson 1 (Listen & Learn)	33
Lesson 2 (Timing)	35
Lesson 3 (Waiting)	36

Song settings	37
Changing the Melody Voice	37
Song Volume	37
Mute	38
Practice Makes Perfect	39

Play With a Variety of Effects	40
Adding Harmony	40
Adding Reverb	41
Adding Chorus	42
Adding Panel Sustain	42

Handy Performance Features	43
Touch Response Sensitivity	43
Setting the Split Point	44
Transpose	44
Tuning	45
One Touch Setting	45
Changing the tempo of the Song/Style	46
Adjusting the Voice Parameters	46

Style (Auto Accompaniment) Functions	47
Various ways to start and stop Style playback	47
Pattern Variation (Sections)	49
Adjusting the Style Volume	51

Playing Auto Accompaniment Chords	52
Easy Chords	52
Standard Chords	52
Looking up Chords Using the Chord Dictionary	54

Function Settings	56
Select the item and change the value	56

About MIDI	58
What is MIDI?	58
What You Can Do With MIDI	58
Transferring Performance Data To and From Another Instrument	59
Transferring data between the PSR-E303/YPT-300 and a computer	61

Troubleshooting	64
Voice List	65
Maximum Polyphony	65
Drum Kit List	71
Style List	74
Effect Type List	75
MIDI Implementation Chart	76
MIDI Data Format	78
Effect map	78
Specifications	79
Index	80

Be sure to do the following operations **BEFORE** turning on the power.

Power Requirements

Although the instrument will run either from an optional AC adaptor or batteries, Yamaha recommends use of an AC adaptor whenever possible. An AC adaptor is more environmentally friendly than batteries and does not deplete resources.

Using an AC Power Adaptor

- 1 Make sure that the power of the instrument is off (the backlit display is off).

⚠ WARNING


- Use **ONLY** a Yamaha PA-3B or PA-3C AC Power Adaptor (or other adaptor specifically recommended by Yamaha) to power your instrument from the AC mains. The use of other adaptors may result in irreparable damage to both the adaptor and the instrument.

- 2 Connect the AC adaptor (PA-3B, PA-3C or other adaptor specifically recommended by Yamaha) to the power supply jack.

- 3 Plug the AC adaptor into an AC outlet.

⚠ CAUTION

- Unplug the AC Power Adaptor when not using the instrument, or during electrical storms.




Using Batteries

- 1 Open the battery compartment cover located on the instrument's bottom panel.
- 2 Insert the six new alkaline batteries, being careful to follow the polarity markings on the side of the compartment.
- 3 Replace the compartment cover, making sure that it locks firmly in place.

⚠ CAUTION

- Never connect or disconnect the AC power adaptor when the batteries are installed in the instrument and the power is on. Doing so will turn the power off, possibly resulting in loss of the data being transferred and the data currently in the transfer destination during transferring or recording a data.




For battery operation the instrument requires six 1.5V "AA" size, LR6 or equivalent batteries. (Alkaline batteries are recommended.) When battery power becomes too low for proper operation, the volume may be reduced, the sound may be distorted, and other problems may occur. When this happens, make sure to replace all batteries, following the precautions listed below. If necessary, also make sure to save all important User data (see page 29), since custom panel settings are lost when the batteries are removed.

⚠ CAUTION

- Use alkaline batteries for this instrument. Other types of batteries (including rechargeable batteries) may have sudden drops of power when battery power becomes low, possibly resulting in loss of data in the flash memory.
- Make sure to install the batteries with the proper orientation, maintaining the correct polarity (as shown). Incorrect battery installation may result in heat, fire and/or leaking of corrosive chemicals.
- When the batteries run down, replace them with a complete set of six new batteries. NEVER mix old and new batteries. Do not use different kinds of batteries (e.g. alkaline and manganese) at the same time.
- If the instrument is not to be in use for a long time, remove the batteries from it, in order to prevent possible fluid leakage from the battery.
- Please use the power adaptor when transferring data to flash memory. Batteries (including rechargeable types) can be drained rapidly by this type of operation. If the batteries do become drained during a data transfer, both the data being transferred and the data currently in the transfer destination will be lost.

Make all necessary connections BEFORE turning the power on.

Connecting headphones (PHONES/OUTPUT Jack)



The PSR-E303/YPT-300 speakers are automatically shut off when a plug is inserted into this jack. The PHONES/OUTPUT jack also functions as an external output.

You can connect the PHONES/OUTPUT jack to a keyboard amplifier, stereo system, mixer, tape recorder, or other line-level audio device to send the instrument's output signal to that device.


WARNING

- Avoid listening with the headphones at high volume for long periods of time; doing so may not only result in ear fatigue, it may be damaging to your hearing.

CAUTION

- To prevent damage to the speakers, set the volume of the external devices at the minimum setting and turn power off the devices before connecting them. Failure to observe these precautions may result in electric shock or equipment damage. Also, be sure to set the volumes of all devices at their minimum levels and gradually raise the volume controls while playing the instrument to set the desired listening level.

Connecting a footswitch (SUSTAIN Jack)




The sustain function lets you produce a natural sustain as you play by pressing an optional footswitch. Plug the Yamaha FC4 or FC5 footswitch into this jack and use it to switch sustain on and off.

NOTE

- Make sure that the footswitch plug is properly connected to the SUSTAIN jack before turning on the power.
- Do not press the footswitch while turning the power on. Doing this changes the recognized polarity of the footswitch, resulting in reversed footswitch operation.

Using the MIDI Terminals




The instrument also features MIDI terminals, allowing you to interface the instrument with other MIDI instruments or computers. (For more information, see page 58.)

NOTE

- MIDI cables (sold separately) must be used for connecting to MIDI devices. They can be bought at music stores, etc.

Turn on the power

Turn down the volume by turning the [MASTER VOLUME] control to the left and press the [STANDBY/ON] switch to turn on the power. Pressing the switch again turns the power off.



Backup data in the flash memory (page 29) is loaded to the instrument when the power is turned on. If no backup data exists on flash memory, all instrument settings are restored to the initial factory defaults when the power is turned on.

CAUTION

- When using a power adaptor, even when the power is off, a small amount of electricity is still being consumed by the instrument. When you are not using the instrument for a long time, make sure to unplug the AC power adaptor from the wall AC outlet, and/or remove the batteries from the instrument.

CAUTION

- Never attempt to turn the power off when a "Writing!" message is shown in the display. Doing so can damage the flash memory and result in a loss of data.

Panel Controls and Terminals

■ Front Panel

- ① [STANDBY/ON] switch page 9, 30
- ② [MASTER VOLUME] control pages 9, 30

When the lesson mode

- ③ LESSON PART
 - [L] button page 34
 - [R] button page 34

When the recording mode

- ③ [REC TRACK 2] button page 27
- [REC TRACK 1] button page 27

- ④ [LISTEN & LEARN] button page 34
- ⑤ [TIMING] button page 35
- ⑥ [WAITING] button page 36
- ⑦ [FUNCTION] button pages 56, 31
- ⑧ [SONG] button pages 20, 31
- ⑨ [STYLE] button pages 22, 31
- ⑩ [VOICE] button pages 12, 31
- ⑪ Number buttons [0]-[9], [+ / YES], [- / NO] page 31
- ⑫ [DEMO] button page 21
- ⑬ [METRONOME ON/OFF] button page 18

When the Song mode

- ⑭ [A-B REPEAT] button page 39
- ⑮ [REW] button page 21
- ⑯ [FF] button page 21
- ⑰ [PAUSE] button page 21

When the Style mode


- ⑭ [ACMP ON/OFF] button page 23
- ⑮ [INTRO/ENDING/rit.] button page 49
- ⑯ [MAIN/AUTO FILL] button page 49
- ⑰ [SYNC START] button page 23



- ⑰ [TEMPO/TAP] button page 46
- ⑱ [REC] button page 25
- ⑲ [START/STOP] button page 30
- ⑳ [PORTABLE GRAND] button page 15
- ㉑ [SOUND EFFECT KIT] button page 17
- ㉒ [REVERB ON/OFF] button page 41
- ㉓ [SPLIT ON/OFF] button page 14
- ㉔ [DUAL ON/OFF] button page 13
- ㉕ [HARMONY ON/OFF] button page 40
- ㉖ [TOUCH ON/OFF] button page 43

■ Rear Panel


- ⑳ MIDI IN/OUT terminals page 58
- ㉑ SUSTAIN jack page 9
- ㉒ PHONES/OUTPUT jack page 9
- ㉓ DC IN 12V jack page 8

■ Front Panel





■ Rear Panel






Changing the Voices

Try playing a variety of instrument Voices

In addition to the piano Voice, a wide variety of other instrument Voices can be selected and played, including guitar, trumpet and flute. The Voice selected here becomes the Main Voice.


1 Press the [VOICE] button.

The Voice number and name are displayed.




2 Select a Voice.

Select the desired Voice by using the number buttons [0]-[9], [+], [-]. Refer to the Voice List on page 65.




3 Play the keyboard.



Try selecting and playing different Voices.

Playing Two Voices Simultaneously—Dual

You can select a second Voice which will play in addition to the Main Voice selected on the previous page. This second Voice is known as the Dual Voice.





Two Voices sound at the same time

Play the Dual Voice

Press the [DUAL ON/OFF] button to turn the Dual function on.

When Dual is on, you can play a Dual Voice in a layer with the Main Voice.


To turn the Dual Voice off and play only the Main Voice, press the [DUAL ON/OFF] button again.




Selecting a Dual Voice

The best-suited Dual Voice is automatically selected whenever you turn Dual on, but you can select any of the available Dual Voices.

- 1 Press and hold the [DUAL ON/OFF] button for longer than a second. “D. Voice” appears in the display for a few seconds, then the Dual Voice will appear.



Hold for longer than a second.



NOTE

- You can also access the Dual Voice setting display by pressing the [FUNCTION] button several times, then selecting Dual Voice.


- 2 Select a Dual Voice.

Select the desired Dual Voice by using the number buttons [0]-[9], [+], [-].

Refer to the Voice List on page 65.

Playing Different Voices with the Left and Right Hands—Split

In the Split mode you can play different Voices to the left and right of the keyboard “Split Point.” The main and Dual Voices can be played to the right of the Split Point, while the Voice played to the left of the Split Point is known as the “Split Voice”




Play the Split Voice

Press the [SPLIT ON/OFF] button to turn the Split function on.

When Split is on you can play a Split Voice to the left of the Split Point.

When you don't want to play a Split Voice, press the [SPLIT ON/OFF] button to turn Split off.



NOTE


- The Split Point setting can be changed as required (page 44).

Select a Split Voice

You can select a different Split Voice by following the procedure outlined below.

1 Press and hold the [SPLIT ON/OFF] button for longer than a second.

“S. Voice” appears in the display for a few seconds, then the Split Voice will appear.



NOTE

- You can also access the Split Voice setting display by pressing the [FUNCTION] button several times, then selecting the Split Voice.

2 Select a Split Voice

Select the desired Split Voice by using the number buttons [0]-[9], [+], [-].

Refer to the Voice List on page 65.

Playing the Grand Piano Voice

When you simply want to play a piano Voice, all you have to do is press one convenient button.

Press the [PORTABLE GRAND] button.


The Voice “Grand Piano 001” will automatically be selected as the Main Voice.




Drum kits

Drum kits are collections of drum and percussion instruments.

When drum kits (Voice number 109-121) are selected, you can play different percussion sounds directly from the keyboard.




1 Press the [VOICE] button.



2 Select the desired Drum kit.


Select one of the Voice numbers from 109-121 by using the number buttons [0]-[9], [+], [-].



Example: 109 Standard Kit 1

[109] Std.Kit1

3 Try out each key.



You'll hear bongo drums, congas, maracas, and more—a comprehensive variety of drum and percussion sounds.

Details on the instruments and key assignments of each drum kit can be found in the Drum Kit List on page 71.


● Drum Kit List

109	Standard Kit 1	116	Jazz Kit
110	Standard Kit 2	117	Brush Kit
111	Room Kit	118	Symphony Kit
112	Rock Kit	119	SFX Kit 1
113	Electronic Kit	120	SFX Kit 2
114	Analog Kit	121	Sound Effect Kit
115	Dance Kit		

Fun Sounds

This instrument also includes a wide range of unique sound effects. Try out each key and enjoy the sounds! As you try out the various keys you'll hear the sound of a dog barking, running water, a creaking door and many other unique effects.

Press the **[SOUND EFFECT KIT]** button.



Try out each key and enjoy the sounds. Don't forget the black keys!

You'll be able to play various sound effects from the keyboard: barking, braying, yelling, and much more.

After trying out these sounds, press the **[PORTABLE GRAND]** button to reset the instrument Voice to the default setting of Voice "001 Grand Piano."



— Quick Guide —

Play With The Metronome



Start the metronome

The instrument includes a metronome with adjustable tempo and time signature. Play and set the tempo that is most comfortable for you.

Starting the metronome

Turn the metronome on and start it by pressing the [METRONOME ON/OFF] button.


To stop the metronome, press the [METRONOME ON/OFF] button again.




Displays the current beat.

Setting the metronome tempo

1 Press the [TEMPO/TAP] button to display the tempo.



2 Set the metronome tempo by using the number buttons [0]-[9], [+], [-].
The tempo can be adjusted between 32-280.




Setting the Metronome Time Signature

A chime will sound on the first beat of each measure, while a metronome click will sound on all others. You can also set the time signature to “00,” in which case the chime will not sound and the click sound will be heard on all beats.

- 1 Press and hold the [METRONOME ON/OFF] button for longer than a second**

The time signature appears in the display.



Hold for longer than a second.

- 2 Set the time signature by using the number buttons [0]-[9], [+], [-].**


The metronome can be set for time signatures of 0 to 15 beats.



- The time signature cannot be changed for Songs and Styles, because each has a fixed time signature.

Setting the Metronome Volume

- 1 Press the [FUNCTION] button a number of times until “MetroVol” appears.**



- 2 Set the metronome volume by using the number buttons [0]-[9], [+], [-].**



— Quick Guide —


Playing Songs

Select and Listen to a Specific Song

This instrument has 102 built-in Songs.
Listening to a Song

1 Press the [SONG] button.


The Song number and name are displayed.



Appears when the Song mode is active.

2 Select the desired Song by using the number buttons [0]-[9], [+], [-].

Refer to the Song List on next page.



001-102	Built in Songs (see next page)
103-107	User Songs (Songs you record yourself).
108-	Songs transferred from a computer on page 63




- You can play Songs recorded from the instrument or transferred from a computer. The procedure for playing these Songs is the same as that of the built-in Songs.


3 Press the [START/STOP] button.

The Song will begin playing.

You can stop playback at any time by pressing the [START/STOP] button.



● Other Operations



[REW] button Fast-reverses the Song if pressed during playback (no sound is heard during fast reverse). Decreases the measure number if pressed while playback is stopped.


[FF] button Fast-forwards the Song if pressed during playback. Increases the measure number if pressed while playback is stopped.

[PAUSE] button Temporarily stops playback. Press this button a second time to resume playback from the point at which it was stopped.

● Using the [DEMO] button

Press the [DEMO] button to play Songs 001, 002, 003, 004, 025, 041, 064, 084, 081 in sequence, and playback will continue repeatedly starting again from the first Song 001.

You can stop playback at any time by pressing the [DEMO] button.



● Song List

No.	Song Name	No.	Song Name	No.	Song Name
TOP PICKS					
001	Castaway	036	Yankee Doodle (Traditional)	069	Pastorale (J. F. Burgmüller)
002	Can You Feel the Love Tonight (The Lion King) (Elton John)	037	Muffin Man (Traditional)	070	The Last Rose of Summer (Traditional)
003*	CLUBWORK	038	Ten Little Indians (Traditional)	071	Annie Laurie (Traditional)
CLASSICAL MELODIES					
004*	Waltz (The Sleeping Beauty) (P. I. Tchaikovsky)	039	When the Saints Go Marching In (Traditional)	072	Jeanie with the Light Brown Hair (S. C. Foster)
005*	Air (Orchestral Suite) (J. S. Bach)	040	Little Brown Jug (Traditional)	073	The Entertainer (S. Joplin)
006*	Minuetto/Boccherini (L. Boccherini)	041	Down by the Riverside (Traditional)	PIANO ENSEMBLE	
007*	Siciliano/J. S. Bach (J. S. Bach)	042	When Irish Eyes Are Smiling (E. R. Ball)	074	Londonderry Air (Traditional)
008*	Menuet (L'Arlésienne) (G. Bizet)	043	Oh! Susanna (S. C. Foster)	075	Die Lorelei (F. Silcher)
009*	Slavonic Dances op.72-2 (A. Dvořák)	044	Battle Hymn of the Republic (Traditional)	076	Home Sweet Home (H. R. Bishop)
010*	Largo (From the New World) (A. Dvořák)	045	American Patrol (F. W. Meacham)	077	Old Folks at Home (S. C. Foster)
011*	Pizzicato Polka (J. Strauss II)	046	I've Been Working on the Railroad (Traditional)	078	Scarborough Fair (Traditional)
012*	Romanze/Beethoven (L. v. Beethoven)	047	My Darling Clementine (Traditional)	079	Loch Lomond (Traditional)
013*	Swan Lake (P. I. Tchaikovsky)	048	Camptown Races (S. C. Foster)	080	Twinkle Twinkle Little Star (Traditional)
014*	Sicilienne/Fauré (G. Fauré)	049	Red River Valley (Traditional)	081	Three Blind Mice (Traditional)
015*	Méditation (Thaïs) (J. Massenet)	050	Jingle Bells (J. S. Pierpont)	082	Wenn ich ein Vöglein wär (Traditional)
016*	Serenade/Haydn (F. J. Haydn)	PIANO SOLO		083	Believe Me If All Those Endearing Young Charms (Traditional)
017*	Grand March (Aida) (G. Verdi)	051	Für Elise (L. v. Beethoven)	084	Funiculi Funicula (L. Denza)
018*	Danza dell'Ore (La Gioconda) (A. Ponchielli)	052	Valse op.64-1 "Petit Chien" (F. Chopin)	085	Nocturne op.9-2 (F. Chopin)
019*	Le Cygne (Le Carnaval des Animaux) (C. Saint-Saëns)	053	Menuett/Beethoven (L. v. Beethoven)	086	Etude op.10-3 "Chanson de l'adieu" (F. Chopin)
020*	L'éléphant (Le Carnaval des Animaux) (C. Saint-Saëns)	054	Andante grazioso (Sonata K.331) (W. A. Mozart)	087	Ave Maria/J. S. Bach - Gounod (J. S. Bach/C. F. Gounod)
021*	Fossiles (Le Carnaval des Animaux) (C. Saint-Saëns)	055	24 Preludes op.28-7 (F. Chopin)	088	Jesus bleibt meine Freude (J. S. Bach)
022*	Wachet auf, ruft uns die Stimme BWV. 645 (J. S. Bach)	056	Melodie (Album für die Jugend) (R. Schumann)	089	Menuett BWV. Anh.114 (J. S. Bach)
TRADITIONAL MELODIES					
023*	Greensleeves (Traditional)	057	Fröhlicher Landmann (Album für die Jugend) (R. Schumann)	090	Piano Concerto No.21 2nd mov. (W. A. Mozart)
024*	Beautiful Dreamer (S. C. Foster)	058	Von fremden Ländern und Menschen (Kinderszenen) (R. Schumann)	091	Der Vogelfänger bin ich ja (W. A. Mozart)
025*	Amazing Grace (Traditional)	059	Träumerei (Kinderszenen) (R. Schumann)	092	Romanze (Serenade K.525) (W. A. Mozart)
026*	Ring de Banjo (S. C. Foster)	060	Thema (Impromptus D.935-3) (F. Schubert)	093	Die Schlittenfahrt K.605-3 (W. A. Mozart)
027*	O du lieber Augustin (Traditional)	061	Menuett BWV. Anh.116 (J. S. Bach)	094	Ave Verum Corpus (W. A. Mozart)
028*	London Bridge (Traditional)	062	Invention Nr.1 (J. S. Bach)	095	Liebesträume Nr.3 (F. Liszt)
029*	Aura Lee (Traditional)	063	Gavotte/J. S. Bach (J. S. Bach)	096	O Mio Babbino Caro (G. Puccini)
030*	Aloha Oe (Q. Liliuokalani)	064	Arietta/Grieg (E. Grieg)	097	Chanson du Toreador (G. Bizet)
031	Turkey in the Straw (Traditional)	065	To a Wild Rose (E. A. MacDowell)	098	Frühlingslied (F. Mendelssohn)
032	On Top of Old Smoky (Traditional)	066	Tango/Albeniz (I. Albéniz)	099	Ode to Joy (L. v. Beethoven)
033	Grandfather's Clock (H. C. Work)	067	La Fille aux Cheveux de Lin (C. A. Debussy)	100	O Christmas Tree (Traditional)
034	Pop Goes the Weasel (Traditional)	068	La Chevaleresque (J. F. Burgmüller)	101	Deck the Halls (Traditional)
035	Mary Had a Little Lamb (Traditional)			102	Silent Night (F. Gruber)

• Songs with an asterisk mark (*) are ones which do not have a left part. Therefore, the lesson is applicable only for the right hand.
 • Some of the classic and/or traditional songs have been edited for length or for ease in learning, and may not be exactly the same as the original.




Play with a Style

Selecting a rhythm of a Style

The Style feature provides backing and rhythm parts in a wide variety of musical categories, including rock, blues, techno and much more. Here's how to play a rhythm of a Style. The rhythm sound consists of percussion instruments.

1 Press the [STYLE] button.



The Style number and name are displayed.



2 Select a Style.

Select the desired Style by using the number buttons [0]-[9], [+], [-].


Refer to the Style List on page 74.



3 Press the [START/STOP] button.

The Style rhythm will start.

You can stop playback at any time by pressing the [START/STOP] button.



NOTE

- Since the Pianist category Styles (098-106) have no rhythm parts, no sound will be produced if you start rhythm-only playback. To use these Styles, turn on the auto accompaniment and play the keyboard as described on pages 23-24. (The bass and chord accompaniment parts will sound.)

Playing with a Style


On the previous page, you've learned how to select your favorite rhythm of a Style. Here, you'll learn how to expand on that rhythm with bass and chord backing, and use all of it as your accompaniment as you play.

1 Press the [STYLE] button and then select a Style.

2 Turn auto accompaniment on.

Press the [ACMP ON/OFF] button.


Press the [ACMP ON/OFF] button again to turn the auto accompaniment off.



● **When auto accompaniment is on ...**

The keys to the left of the Split Point (54; F#2) will play only chords.


This is known as the “Auto Accompaniment range.”



- You can change the Split Point. Refer to “Setting the Split Point” on page 44.

3 Turn SYNC START on.

Press the [SYNC START] button.




When the Sync Start standby mode is engaged, Style playback will begin as soon as you play a chord in the accompaniment range of the keyboard. You can turn off Sync Start standby mode by pressing the [SYNC START] button.

4 The Style will begin playing as soon as you play a chord in the accompaniment range of the keyboard.


Not sure how to play chords? No problem! This instrument is capable of playing chords even if you only play one key.

Try playing one, two or three keys (any notes will do) in the auto accompaniment range of the keyboard. Different keys will produce different results.


Refer to page 52 for detailed instructions for playing chords.



5 Try playing other chords with your left hand and play a melody with your right hand.



6 You can stop playback at any time by pressing the [START/STOP] button.




Record your own performance

Recording Your Performance

You can record up to five of your own performances as User Songs (User 1-5: Song numbers 103-107). Think of each User Song as a kind of basket or drawer for storing your recording. Remember that you can also record a Style (containing chord changes) along with your own performance.

1 Press the [REC] button.



NOTE

- A total of approximately 10,000 notes or 5,500 chord changes can be recorded to the five User Songs.

NOTE


- Accompaniment cannot be turned on or off once the [REC] button is pressed.

After you've selected the desired User Song for recording, you can select a Style to be recorded as well. To do this, press the [STYLE] button and select the Style number while the ACMP indication is on.

You can turn off the Record mode by pressing the [REC] button again (L and R stop flashing).

2 Start recording.

When you play the keyboard, recording will begin.



By playing keys to the left of the Split Point when the Auto Accompaniment is set to on, the Style starts sounding and is recorded with your performance.

When Auto Accompaniment is set to off, only your keyboard performance is recorded.

CAUTION

- If all User Songs (Song numbers 103-107) contain recorded data, Song 103 will automatically be selected. In this case, you will record over and erase any previous data in Song 103, so be careful that you won't be erasing any material you want to keep!

3 Stop recording.

Pressing the [START/STOP] button stops recording and writes the data to the User Song. (A “Writing!” message is shown.)

To playback the newly recorded performance, press the [START/STOP] button.

- In order to record with the Style, turn the Auto Accompaniment to on (see Steps 1-2 on page 23), and then record according to the instructions.

ACMP ON (The “ACMP ON” lights.)

- In order to record only your performance, turn the Auto Accompaniment to off and record according to the normal steps.

ACMP ON (The “ACMP ON” is unlit.)

CAUTION

- Never attempt to turn the power off when a “Writing!” message is shown in the display. Doing so can damage the flash memory and result in a loss of data.

CAUTION

- Keep in mind that any kind of power failure during recording—such as the power being turned off, the AC adaptor being plugged/unplugged or the batteries running down—will result in data loss.

NOTE


- Use the Microsoft Downloader to backup the User Songs to a computer (page 62).

Recording to a specified track

The User Songs are organized into two tracks: Track 1 and Track 2. You can specify the track you want to record to.

About track recording

If you start recording by specifying a track, the track will be overwritten (existing data in the track is deleted and replaced with the new recording).



NOTE


- Record following the steps in the previous page, and your performance will be recorded to Track 1 and the Style (if you are playing one) will be recorded to Track 2.

NOTE

- You cannot record the metronome click, or the Transpose and Tuning settings.
- The settings and buttons below cannot be changed, or if changed, the new settings cannot be recorded if entered during the recording process.

ACMP ON/OFF, split point, reverb type, chorus type, harmony type, [FUNCTION] button, [PORTABLE GRAND] button, [SOUND EFFECT KIT] button.

Only your keyboard performance can be recorded to Track 1. Either a Style or your performance can be recorded to Track 2, resulting in a User Song like that depicted below.



Specifying track recording

1 Turn ACMP (auto accompaniment) on or off, depending on what you want to record.

If you want to record Style playback, turn ACMP on. If you want to record only your own keyboard performance, turn ACMP off.


2 Specify the track you want to record.

Specify the track 2 when you want to record the Style.


When you want to record your own keyboard performance, you can specify either track.

● Recording to Track 1

Press the [REC] button and [REC TRACK 1] button simultaneously.




Press simultaneously




Flashes when track 1 is selected for recording.

● Recording to Track 2

Press the [REC] button and [REC TRACK 2] button simultaneously.



Press simultaneously




Flashes when track 2 is selected for recording.

Lights when recorded data exists.

Turns off when there is no recorded data, or when Mute is set to on (page 38) to turn off playback of the track.

3 Press the [+], [-] buttons to select the User Song you want to record.



If you want to record Style playback to Track 2, press the [STYLE] button and select the desired Style.

4 Start recording

Perform steps **2** and **3** on pages 25-26.

By playing keys to the left of the Split Point when the Auto Accompaniment is set to on, the Style starts sounding and is recorded. Only your performance is recorded by playing the keyboard (any key is OK) when the Auto Accompaniment is set to off.

NOTE

- Keep in mind that both Tracks 1 and 2 will be overwritten with new data if you record without specifying the tracks.
- The both "L" and "R" flashes, this indicates that you have specified Track 1 when the Auto Accompaniment is on. If you want to record your own performance, press the [TRACK 2] button to stop the "L" flashing. If you want to record a Style, press the [REC] button to cancel the recording, and repeat the procedure from the beginning.

NOTE

- You can record a new track while listening to a previously recorded track (the track indication will appear). You can also mute recorded tracks (the track will disappear) while recording a new track by pressing the desired track button.


Deleting User Songs

Deleting an entire User Song



- You cannot delete a specific track from a User Song.


- 1 Press the [SONG] button and select the User Song you want to delete by using the number buttons [0]-[9], [+], [-].**



[103] User 1

- 2 Press and hold the [REC] button for longer than a second.**

The Song Delete display appears.





[YES] ClrUser1

Hold for longer than a second.

You can cancel the delete operation by pressing the [-/NO] button.

- 3 Press the [+ / YES] button.**

A confirmation message will appear on the display.





[YES] Sure?

You can cancel the delete operation by pressing the [-/NO] button.

- 4 Press the [+ / YES] button to delete the Song.**

“Writing!” message will appear while the track is being deleted.



[] Writing!

Backup and Initialization

Backup

Some internal parameters will revert to their default values if not saved before the power is turned off.

In order to backup these parameters press and hold the [FUNCTION] button for longer than a second.



Hold for longer than a second.

● Parameters that are saved in backup:

- User Songs*
- Touch Response on/off setting
- The following Function settings: Tuning, Split Point, Touch Sensitivity, Style Volume, Song Volume, Metronome Volume, Demo Cancel, Panel Sustain


* The User Songs are automatically backed up when recording is completed, ensuring that the data is not deleted even when you fail to backup.

Initialization

This function erases all backup data in the instrument's flash memory and restores the initial default settings. The following initialization procedures are provided.


Backup Clear

To clear data backed up to the internal flash memory (described above), turn the power on by pressing the [STANDBY/ON] switch while holding the highest white key on the keyboard. The backed up data will be erased and the default values restored.



Flash Clear

To clear Song data that has been transferred to the internal flash memory from a computer, simultaneously hold down the highest white key and the three highest black keys on the keyboard and turn the power on by pressing the [STANDBY/ON] switch.



⚠ CAUTION

- When you execute the Backup Clear operation, backup parameters will be cleared. You can save the backup parameters (containing the five User Songs) by using Musicsoft Downloader to transfer them to a computer. Refer to the section "Transferring a user file from the PSR-E303/YPT-300 to a computer" on page 63.

⚠ CAUTION

- When you execute the Flash Clear operation, Song data you have purchased and downloaded will also be cleared. Make sure to save your important data by transferring to a computer using Musicsoft Downloader (page 63).

Basic Operation and Displays

Basic Operation

Turning the power on



Turn down the volume by turning the [MASTER VOLUME] control to the left and press the [STANDBY/ON] switch to turn on the power.

Press the [STANDBY/ON] switch again to turn the power OFF.




Adjusting the volume

Turn the [MASTER VOLUME] dial.



About the [START/STOP] button


Press the [START/STOP] button after pressing the [SONG] or [STYLE] button to start playback of the selected Song or Style (rhythm).



The "Press & Hold" Symbol




The "Press & Hold" symbol that appears next to some buttons indicates that the button can be pressed and held for longer than a second to call up a related or different function.



Press a button to select a basic function

- SONG** Press the [SONG] button to select a Song.
- STYLE** Press the [STYLE] button to select a Style.
- VOICE** Press the [VOICE] button to select a Voice.

When you select a basic function, the name and number of the currently selected Song, Style and Voice is shown. From this display, you can select the desired Song, Style or Voice.




Set the number or value

● **Number buttons [0]-[9]**

The number buttons can be used to directly enter a Song, Style or Voice number or parameter value. For numbers that start with one or two zeroes, the first zeroes can be omitted

Example: Selecting Voice 002, Bright Piano.



Press number buttons [0], [0], [2].


Function Settings (page 56)

The [FUNCTION] button contains 32 settings. Each time you press the [FUNCTION] button, the setting item is selected in sequence, and the value of the selected item can be changed in the display.



● **[+], [-] buttons**

Press the [+] button briefly to increase the value by 1, or press the [-] button briefly to decrease the value by 1. Press and hold either button to continuously increase or decrease the value in the corresponding direction.



Display

The Main display shows all of the current basic settings for Song, Style and Voice. It also includes a range of indicators that show the on/off status for various functions.

Notation

Displays the melody and chord notes of a Song when the Song lesson function is in use, or the notes of chords you specify when the Dictionary function is in use. At other times the notes you play on the keyboard are displayed.



- Any notes occurring below or above the staff are indicated by "8va" in the notation.
- For a few specific chords, not all notes may be shown in the notation section of the display. This is due to space limitations in the display.

Song/recording track display

Information related to the Song/recording tracks is shown here. (See pages 25 and 38.)


- Lit:** Track contains data
- Unlit:** Track is muted or contains no data
- Flashing:** Track is selected as recording track

Measure

Indicates the current measure during playback of a Song. MEASURE 003

Beat Display

Indicates the beat of the current Style or Song with flashing arrows. >>>>



Chord Display

Indicates the name of the chord currently being played back, or the name of the chord being played on the keyboard. [

ACMP ON

Appears when the auto accompaniment is on. ACMP ON

Keyboard Display

Indicates notes currently being played. Indicates the melody and chord notes of a Song when the Song lesson function is in use. Also indicates the notes of a chord—either when playing a chord or when using the Dictionary function.

DUAL

Appears when the Dual function is on (page 13). DUAL

HARMONY

Appears when the Harmony function is on (page 40). HARMONY

SPLIT

Appears when the Split function is on (page 14). SPLIT

REVERB

Appears when Reverb is on (page 41). REVERB

TOUCH RESPONSE


Appears when Touch Response is on (page 43). TOUCH

Song Lesson

Yamaha Education Suite 5

You can select any Song you like and use it for a left-hand, right-hand, or both-hands lesson. Song Lesson lets you learn how to play Songs in three easy steps. Songs that can be used with the Lesson feature include Songs transferred from a computer to flash memory (SMF Format 0 only; see page 61). The procedure for transferring songs are described on page 63.

■ Lesson Flow



■ The practice methods:

Lesson 1 (Listen & Learn) Listen and learn the melody or rhythm of a selected Song.

Lesson 2 (Timing) Learn to play the notes at the correct timing along with the Song.

Lesson 3 (Waiting) Learn to play the correct notes.

Lesson 1 (Listen & Learn)

There's no need to play the keyboard in Lesson 1.

The model melody/chords (in other words, the musical material you should learn) of the part you selected will sound. Listen to it carefully and learn it well.




- User Songs cannot be used for the lesson.

1 Select the desired Song for your lesson.

Press the [SONG] button, and then select a Song (referring to the Song list on page 21) by using the number buttons [0]-[9], [+], and [-]. If you want to practice a Song you've transferred from a computer, select one of the Songs beginning from Song number 108.



- You cannot select the part during Song playback before Lesson 1 starts. If a Song is currently being played back, stop the Song first, then continue from Step 2.




The instrument includes 102 built in Songs. Some Songs (as shown below) are intended for use as right-hand lessons, and cannot be used for left-hand or both-hands lessons.

● Songs for right-hand lesson


Song numbers: 003-030

2 Select the part you want to practice.

Press the [R] button for a right-hand lesson, [L] button for a left-hand lesson, or press both the [R] and [L] buttons simultaneously for a both-hands lesson. The selected part is displayed.




A “No LPart” message is shown in the display if you select the left part in one of the Songs 003-030, which do not have left part data. These Songs cannot be used for left-hand or both-hands lessons.



- For songs transferred from a computer, the “No LPart” indication does not appear, even when there is no left hand part in the song.

3 Start Lesson 1.

Press the [LISTEN & LEARN] button to start Lesson 1. The melody of the part you selected in Step 2 will sound. Listen to it carefully and learn it well.



The notation and key positions of the model melody are shown in the display.



- Even after Lesson 1 has started and the Song is playing, you can still select the part.
- When the melody Voice of the Song is changed, the key position shown in the display may be shifted (in octave units), depending on the Voice selected.
- You can select Lessons 1-3 by pressing the [LISTEN & LEARN], [TIMING] and [WAITING] buttons, respectively.

4 Stop the Lesson mode.


You can stop the Lesson mode at any time by pressing the [START/STOP] button.

Lesson 2 (Timing)

In this lesson, try playing the notes with the correct timing. Simply concentrate on playing each note in time with the rhythmic accompaniment. The correct notes sound even if you play wrong notes as long as you play in time with the rhythm.

1 Select a Song for your lesson.

2 Select the part you want to practice.



NOTE


- You cannot use Dual or Split Voices during lessons.
- The Split Point is fixed and it cannot be changed. For the left-hand lesson, it is fixed at 59 or B2; for the left-hand chord lesson, it is fixed at 54 or F#2.

NOTE

- You cannot select the part during Song playback before Lesson 2 starts. If a Song is currently being played back, stop the Song first, then continue from Step 2.

3 Start Lesson 2.

Press the [TIMING] button to start Lesson 2.



NOTE

- Even after Lesson 2 has started and the Song is playing, you can still select the part.

Play the notes shown in the display.

In Lesson 2, simply play each note in time with the music.

4 Stop the Lesson mode.

You can stop the Lesson mode at any time by pressing the [START/STOP] button.



Grade

When the lesson Song has played all the way through in Lesson mode 2 or 3, your performance will be evaluated in four levels: OK, Good, Very Good, or Excellent.

OK
Good
Very Good
Excellent

Lesson 3 (Waiting)


In this mode, try playing the correct notes. The notes you should play appear in the score and the keyboard on the display. The Song pauses until you play the right note.

1 Select a Song for your lesson.




- You cannot select the part during Song playback before Lesson 3 starts. If a Song is currently being played back, stop the Song first, then continue from Step 2.

2 Select the part you want to practice.



3 Start Lesson 3.

Press the [WAITING] button to start Lesson 3.




- Even after Lesson 3 has started and the Song is playing, you can still select the part.

Play the notes shown in the display.
Try playing the correct notes.

4 Stop the Lesson mode.

You can stop the Lesson mode at any time by pressing the [START/STOP] button.



Song settings

Changing the Melody Voice

You can change a Song's melody Voice to any other Voice you prefer.




- You cannot change the melody Voice of a User Song.

1 Select the Song and play it.

Refer to the section "Playing Songs" on page 20.

2 Select a desired Voice by using the number buttons [0]-[9], [+], [-].




The selected Voice sounds when you play the keyboard.

If a Song has played through and stopped during this procedure, press the [START/STOP] button to start playback again.

3 Press and hold the [VOICE] button for longer than a second.


"SONG MELODY VOICE" appears in the display for a few seconds, indicating that the Voice selected in Step 2 has replaced the Song's original melody Voice.




Song Volume

This procedure allows you to adjust the balance between Song playback and the notes you play on the keyboard by setting the volume of the playback sound.


1 Press the [SONG] button.



2 Press the [FUNCTION] button a number of times until “SongVol” appears.



3 Set the Song Volume by pressing the number buttons [0]-[9], [+], [-].



NOTE


- Press the [+] and [-] buttons simultaneously to instantly reset the value to its default setting (100).

Mute


You can mute Track 1 or Track 2 during Song playback.

- Track 1 can be muted by pressing the [REC TRACK 1] button during Song playback.
- Track 2 can be muted by pressing the [REC TRACK 2] button during Song playback.

You can cancel the mute function by pressing the corresponding track buttons, [TRACK 1] or [TRACK 2] again during Song playback, or by selecting any other Song.



Pressing one of the Track buttons [TRACK 1] or [TRACK 2] will mute the corresponding track during Song playback.




Lit—track contains data.


Unlit—track is muted or contains no data.

Practice Makes Perfect

You can repeatedly practice a section you find difficult. This function lets you specify a section of a Song you want to practice—"A" is the start point and "B" is the end point—for repeat playback.




- 1 Play the Song and press the [A-B REPEAT] button at the beginning of the section you want to repeat (the "A" point). "A-REPEAT" will be displayed.




- The repeat start and end points can be specified in one-measure increments.
- You can also set the A-B Repeat function when the Song is stopped. Simply use the [REW] and [FF] buttons to select the desired measures, pressing the [A-B REPEAT] button for each point, then start playback.
- If you want to set the start point "A" at the very beginning of the Song press the [A-B REPEAT] button before starting playback of the Song.

- 2 Press the [A-B REPEAT] button a second time at the end of the section you want to repeat (the "B" point). The specified A-B section of the Song will now play repeatedly, letting you practice the section over and over.



You can stop repeat playback by pressing the [A-B REPEAT] button. The A-B REPEAT mode will be canceled and normal playback of the Song will continue.





- The A-B Repeat function will be canceled when you select another Song or Style mode.

Play With a Variety of Effects

Adding Harmony

This feature adds harmony notes as well as tremolo or echo effects to the Main Voice.



- 1 Press the [HARMONY] button to turn harmony on.
When you don't want to add harmony notes, press the [HARMONY ON/OFF] button again to turn Harmony off.



NOTE

- When you press the [HARMONY ON/OFF] button to turn this feature on, the appropriate Harmony type for the currently selected Main Voice is automatically selected.

- 2 Press and hold the [HARMONY ON/OFF] button for longer than a second.
“HarmType” appears in the display for a few seconds, followed by the Harmony Type.




NOTE

- You can also access the Harmony Type setting display by pressing the [FUNCTION] button several times.
- Harmony will be turned off if the Chord Dictionary function is used.

- 3 Select a desired Harmony Type by using the number buttons [0]-[9], [+], [-].

Refer to the Harmony Type list on page 75.

Try playing the keyboard with the harmony function. The effect and operation of each Harmony Type is different—refer to the section “How to sound each Harmony Type” on the next page as well as the Harmony Type List for details.




● How to sound each Harmony Type

• Harmony type 01-05



Press the right-hand keys while playing chords in the auto accompaniment range of the keyboard when the Auto Accompaniment is on (page 23).


• Harmony type 06-12 (Trill)



Hold down two keys.


You can adjust the Harmony Volume in the Function Settings (page 56).

• Harmony type 13-19 (Tremolo)



Keep holding down the keys.

• Harmony type 20-26 (Echo)



Keep holding down the keys.

NOTE


- The harmony notes can be added only to the Main Voice, not to Dual or Split Voices.
- The keys left of the Split Point of the keyboard produce no harmony notes when the auto accompaniment is on (ACMP ON is lit).

Adding Reverb

Reverb adds the ambience of a room or concert hall to the sound that you play on the keyboard.

To add Reverb

Press the [REVERB ON/OFF] button to turn Reverb on. Reverb is normally on. You can check how the selected Reverb Type sounds by playing the keyboard. To turn Reverb off, press the [REVERB ON/OFF] button again.



Appears when Reverb is on.

Select a Reverb Type

The ideal type is automatically selected whenever you select a Song or Style, but you can select any of the available Reverb Types.

- 1 Press and hold the [REVERB ON/OFF] button for longer than a second. “REVERB” appears in the display for a few seconds, followed by the Reverb Type.




Hold for longer than a second.



Currently selected Reverb Type

- 2** Select the desired Reverb Type by using the number buttons [0]-[9], [+], [-]. Refer to the Reverb Type list on page 75 for details. You can adjust the Reverb depth in the Function Settings (page 56).




- You can also access the Reverb Type setting display by pressing the [FUNCTION] button several times.

Adding Chorus

This effect makes the Voice sound richer, warmer and more spacious. The best-suited Chorus type is automatically selected whenever you select a Voice; however, you can select any of the available types.

- 1** Press the [FUNCTION] button a number of times until the “Chorus” appears. “Chorus” appears in the display for a few seconds, followed by the Chorus Type.





- 2** Select a desired Chorus Type by using the number buttons [0]-[9], [+], [-]. Refer to the Chorus Type list on page 75 for details. You can adjust the Chorus depth independently for the Main, Dual and Split Voices in the Function Settings (page 56).



Adding Panel Sustain

This function adds a fixed sustain to the keyboard Voices.

- 1** Press the [FUNCTION] button a number of times until the “Sustain” item appears.



- 2** Press the [+] button to turn the Panel Sustain on. Panel Sustain will be added to the notes you play on the keyboard when the Panel Sustain is on. To turn it off, press the [-] button.





- See the section “Connecting a footswitch (SUSTAIN Jack)” on page 9 for information on applying sustain with the optional footswitch.

Handy Performance Features

Touch Response Sensitivity

Touch Response



NOTE

- The Touch Response function cannot be used for some Voices (such as organ), even if the Touch Response icon appears in the display.


Press the [TOUCH ON/OFF] button to turn Touch Response on.

When Touch Response is on, you can control the volume of notes according to how hard you play the keys. Touch Response is normally on. Press the [TOUCH ON/OFF] button again to turn the Touch Response off. When Touch Response is off, the same volume will be produced no matter how hard you play the keys.


Setting the Touch Sensitivity

When Touch Response is on, you can adjust the sensitivity of the keyboard in response to keyboard dynamics in three steps. Higher values produce greater (easier) volume variation in response to keyboard dynamics—in other words, greater sensitivity.

- 1 Press and hold the [TOUCH ON/OFF] button for longer than a second. “TouchSns” appears in the display for a few seconds, followed by the current Touch Sensitivity value.




- 2 Select a Touch Sensitivity setting between 1 and 3 by using the number buttons [0]-[9], [+], [-].




Setting the Split Point

The Split Point setting can be changed as desired.



The initial default Split Point is key number 54 (the F#2 key), but you can change it to another key. When you change the Split Point, the auto accompaniment range also changes.

- 1 Press the [FUNCTION] button a number of times until “SplitPnt” appears.



NOTE


- Press the [+] and [-] buttons simultaneously to instantly reset the value to its default setting (54 or F#2).

- 2 Set the Split Point by using the number buttons [0]-[9], [+], [-].


Transpose

The overall pitch of the instrument can be shifted up or down by a maximum of 1 octave in semitone increments.

- 1 Press the [FUNCTION] button a number of times until the “Transpos” appears.



- 2 Use the number buttons [0]-[9], [+], [-] to set the Transpose value between -12 and +12 as required.




NOTE

- The pitch of the Drum Kits Voices (Voice numbers 109-121) cannot be changed.
- Press the [+] and [-] buttons simultaneously to instantly reset the value to its default setting (00).


Tuning

You can fine tune the pitch of the entire instrument. The overall tuning of the instrument can be shifted up or down by a maximum of 100 cents in 1-cent increments (100 cents = 1 semitone).

- 1 Press the [FUNCTION] button a number of times until “Tuning” appears.



- 2 Use the number buttons [0]-[9], [+] and [-] to set the Tuning value between -100 and +100 as required.




NOTE

- The pitch of the Drum Kits Voices (Voice numbers 109-121) cannot be changed.
- Press the [+] and [-] buttons simultaneously to instantly reset the value to its default setting (000).

One Touch Setting

Sometimes selecting the ideal Voice to play with a Song or Style can be confusing. The One Touch Setting feature automatically selects the most suitable Voice for you when you select a Style or Song. Simply select Voice number “000” to activate this feature.

- 1 Press the [VOICE] button, and then select Voice number “000” by using the number buttons [0]-[9], [+], [-].




This turns the One Touch Setting feature on. One Touch Setting will be turned off if you select any other Voice number.

Changing the tempo of the Song/Style

Songs and Styles can be played at any tempo you desire—fast or slow.

- 1 Press the [TEMPO/TAP] button to call up the Tempo setting in the display after selecting a Style/Song.




- 2 Set the Tempo by using the number buttons [0]-[9], [+], [-].

You can also set the Tempo by simply tapping the [TEMPO/TAP] button at the required tempo—four times for time signatures in 4, and three times for time signatures in 3.

You can change the Tempo during Style/Song playback by pressing the [TEMPO/TAP] button just twice.



- Press the [+] and [-] buttons simultaneously to instantly reset the value to the default tempo of a Style or Song.



Adjusting the Voice Parameters

The volume, octave (the pitch of the instrument can be shifted by up or down in octaves) and Chorus Send Level can be individually adjusted for the Main, Dual, and Split Voices.

● Main Voice Parameters (page 57)

- Main Voice Volume
- Main Voice Octave
- Main Voice Chorus Send Level

● Dual Voice Parameters (page 57)

- Dual Voice Volume
- Dual Voice Octave
- Dual Voice Chorus Send Level

● Split Voice Parameters (page 57)

- Split Voice Volume
- Split Voice Octave
- Split Voice Chorus Send Level

You can adjust each of the parameters above in the Function settings (page 56).

Style (Auto Accompaniment) Functions

Various ways to start and stop Style playback


Starting Style playback

The following three methods can be used to start Style playback. In all cases you will need to press the [ACMP ON/OFF] button to turn auto accompaniment on before actually starting Style playback. Whichever method you choose, you can press the [INTRO/ENDING/rit.] before starting playback. To begin your performance, an introduction will play automatically, then will automatically switch to the MAIN section when finished.

■ Immediate Start

Press the [START/STOP] button to begin rhythm-only playback of the selected Style.

The bass and chords will begin playing as soon as you play a chord in the accompaniment range of the keyboard.





Immediate Start

■ Chord Start

Press the [SYNC START] button and the beat arrows will begin flashing, indicating that the Sync Start “standby” mode has been engaged.

The bass and chords will begin playing as soon as you play a chord in the accompaniment range of the keyboard.



Style playback begins when you play a chord



■ Tap Start

You can supply a count-in at any tempo you like to start playback. Simply tap the [TEMPO/TAP] button at any tempo—4 times for time signatures in 4, and 3 times for time signatures in 3—and the selected Style rhythm will begin playing at the tapped tempo.

The bass and chords will begin playing as soon as you play a chord in the accompaniment range of the keyboard.



Start at the tapped tempo



Appears when the auto accompaniment is on


STYLE ACMP ON/OFF INTRO/ENDING/rit. MAIN/AUTO FILL

Stopping Style playback

The following three methods can be used to stop Style playback.



■ Immediate Stop

Playback will stop as soon as you press the [START/STOP] button.



■ Stop and Enter Sync Start Mode


If you press the [SYNC START] button during Style playback, playback will stop immediately and the Sync Start standby mode will be engaged (beat arrows will flash).



Sync Start standby

■ Play the Ending and Stop


Press the [INTRO/ENDING/rit.] button to begin playing an ending section. Playback will stop when the ending has played all the way through.



If you press the [INTRO/ENDING/rit.] button a second time (while the ending is playing), the ending will play in ritardando (the tempo will gradually get slower).

Pattern Variation (Sections)

The instrument features a wide variety of Style “sections” (patterns) that allow you to vary the arrangement of the accompaniment to match the Song you are playing.



● INTRO section

This is used for the beginning of the Song
When the intro finishes playing, accompaniment shifts to the main section.
The length of the intro (in measures) differs depending on the selected Style.

● MAIN section

This is used for playing the main part of the Song. It plays a main accompaniment pattern, and repeats indefinitely until another section’s button is pressed. There are two variations on the basic pattern (A and B), and the Style playback sound changes harmonically based on the chords you play with your left hand.

● Fill-in section

This is automatically added before changing the section A and B.



● ENDING section

This is used for the ending of the Song. When the ending is finished, the auto accompaniment stops automatically. The length of the ending (in measures) differs depending on the selected Style.

1 Press the [STYLE] button and then select a Style.

2 Turn auto accompaniment on.


Press the [ACMP ON/OFF] button.




Appears when the auto accompaniment is on.

3 Turn SYNC START on.


Press the [SYNC START] button.



4 Press the [MAIN/AUTO FILL] button.




5 Press the [INTRO/ENDING/rit.] button.




6 As soon as you play a chord with your left hand, the Intro of the selected Style starts.

For this example, play a C major chord (as shown below). For information on how to enter chords, see “Playing Auto Accompaniment Chords” on page 52.




7 Press the [MAIN/AUTO FILL] button.



When the fill-in is finished, it leads smoothly into the selected main section A/B.

8 Press the [INTRO/ENDING/rit.] button.




This switches to the ending section.

When the ending is finished, the auto accompaniment stops automatically. You can have the ending gradually slow down (ritardando) by pressing the [INTRO/ENDING/rit.] button again while the ending is playing back.


Adjusting the Style Volume

This procedure allows you to adjust the balance between Style playback and the notes you play on the keyboard by setting the volume of the playback sound.

- 1** Press the [STYLE] button.
- 2** Press the [FUNCTION] button a number of times until the “StyleVol” appears.



- 3** Set the Style volume by using the number buttons [0]-[9], [+], [-].



- Press the [+] and [-] buttons simultaneously to instantly reset the value to its default setting (100).

Playing Auto Accompaniment Chords

You've learned in the section "Play with a Style (Accompaniment)" on page 22 that the "feel" of the Style changes every time you play a chord on the left-hand side of the keyboard. Here, you'll learn the types of the chords and how to play them in greater detail. The examples of chords are given here in the key of C.

There are two basic ways (below) you can play the chords on the left-hand side of the keyboard, while playing the Style (page 23)

- Easy Chords
- Standard Chords

Split Point—default setting: 54 (F#2)




Easy Chords

This method lets you easily play chords in the accompaniment range of the keyboard using only one, two, or three fingers.



- Root notes and the corresponding keys



C

- To play a major chord
Press the root note of the chord.

C₇

- To play a seventh chord
Press the root note together with the nearest white key to the left of it.

C_m

- To play a minor chord
Press the root note together with the nearest black key to the left of it.

C_{m7}

- To play a minor seventh chord
Press the root note together with the nearest white and black keys to the left of it (three keys altogether).

Standard Chords

This method lets you produce accompaniment by playing chords using normal fingerings in the accompaniment range of the keyboard.

C 	C(9) 	C₆ 	C₆(9) 	CM₇ 	CM₇(9) 	CM₇(#11) 	C(♭5) 	CM₇♭5
C_{sus4} 	C_{aug} 	CM₇aug 	C_m 	C_m(9) 	C_{m6} 	CM₇ 	CM₇(9) 	CM₇(11)
C_mM₇ 	C_mM₇(9) 	CM₇♭5 	C_mM₇♭5 	C_{dim} 	C_{dim}7 	C₇ 	C₇(♭9) 	C₇(♭13)
C₇(9) 	C₇(#11) 	C₇(13) 	C₇(#9) 	C₇♭5 	C₇aug 	C₇sus4 	C₁₊₂₊₅ 	

* Notes enclosed in parentheses are optional; the chords will be recognized without them.

● **Recognized Standard Chords Chart**

Chord Name/[Abbreviation]	Normal Voicing	Chord (C)	Display
Major [M]	1 - 3 - 5	C	C
Add ninth [(9)]	1 - 2 - 3 - 5	C(9)	C(9)
Sixth [6]	1 - (3) - 5 - 6	C6	C6
Sixth ninth [6(9)]	1 - 2 - 3 - (5) - 6	C6(9)	C6(9) *
Major seventh [M7]	1 - 3 - (5) - 7 or 1 - (3) - 5 - 7	CM7	CM7
Major seventh ninth [M7(9)]	1 - 2 - 3 - (5) - 7	CM7(9)	CM7(9) *
Major seventh add sharp eleventh [M7(#11)]	1 - (2) - 3 - #4 - 5 - 7 or 1 - 2 - 3 - #4 - (5) - 7	CM7(#11)	CM7(#11)*
Flatted fifth [(b5)]	1 - 3 - b5	C(b5)	Cb5 *
Major seventh flatted fifth [M7b5]	1 - 3 - b5 - 7	CM7b5	CM7b5 *
Suspended fourth [sus4]	1 - 4 - 5	Csus4	Csus4
Augmented [aug]	1 - 3 - #5	Caug	Caug
Major seventh augmented [M7aug]	1 - (3) - #5 - 7	CM7aug	CM7aug *
Minor [m]	1 - b3 - 5	Cm	Cm
Minor add ninth [m(9)]	1 - 2 - b3 - 5	Cm(9)	Cm(9)
Minor sixth [m6]	1 - b3 - 5 - 6	Cm6	Cm6
Minor seventh [m7]	1 - b3 - (5) - b7	Cm7	Cm7
Minor seventh ninth [m7(9)]	1 - 2 - b3 - (5) - b7	Cm7(9)	Cm7(9)
Minor seventh add eleventh [m7(11)]	1 - (2) - b3 - 4 - 5 - (b7)	Cm7(11)	Cm7(11) *
Minor major seventh [mM7]	1 - b3 - (5) - 7	CmM7	CmM7
Minor major seventh ninth [mM7(9)]	1 - 2 - b3 - (5) - 7	CmM7(9)	CmM7(9) *
Minor seventh flatted fifth [m7b5]	1 - b3 - b5 - b7	Cm7b5	Cm7b5
Minor major seventh flatted fifth [mM7b5]	1 - b3 - b5 - 7	CmM7b5	CmM7b5 *
Diminished [dim]	1 - b3 - b5	Cdim	Cdim
Diminished seventh [dim7]	1 - b3 - b5 - 6	Cdim7	Cdim7
Seventh [7]	1 - 3 - (5) - b7 or 1 - (3) - 5 - b7	C7	C7
Seventh flatted ninth [7(b9)]	1 - b2 - 3 - (5) - b7	C7(b9)	C7(b9)
Seventh add flatted thirteenth [7(b13)]	1 - 3 - 5 - b6 - b7	C7(b13)	C7(b13)
Seventh ninth [7(9)]	1 - 2 - 3 - (5) - b7	C7(9)	C7(9)
Seventh add sharp eleventh [7(#11)]	1 - (2) - 3 - #4 - 5 - b7 or 1 - 2 - 3 - #4 - (5) - b7	C7(#11)	C7(#11)
Seventh add thirteenth [7(13)]	1 - 3 - (5) - 6 - b7	C7(13)	C7(13)
Seventh sharp ninth [7(#9)]	1 - #2 - 3 - (5) - b7	C7(#9)	C7(#9)
Seventh flatted fifth [7b5]	1 - 3 - b5 - b7	C7b5	C7b5 *
Seventh augmented [7aug]	1 - 3 - #5 - b7	C7aug	C7aug
Seventh suspended fourth [7sus4]	1 - 4 - (5) - b7	C7sus4	C7sus4
One plus two plus five [1+2+5]	1 - 2 - 5	C1+2+5	C *




- Notes in parentheses can be omitted.
- Playing two same root keys in the adjacent octaves produces accompaniment based only on the root.
- A perfect fifth (1+5) produces accompaniment based only on the root and fifth which can be used with both major and minor chords.
- The chord fingerings listed are all in "root" position, but other inversions can be used—with the following exceptions: m7, m7b5, 6, m6, sus4, aug, dim7, 7b5, 6(9), 1+2+5
- Inversion of the 7sus4 and m7(11) chords are not recognized if the notes shown in parentheses are omitted.
- The auto accompaniment will sometimes not change when related chords are played in sequence (e.g. some minor chords followed by the minor seventh).
- Two-note fingerings will produce a chord based on the previously played chord.

* These chords are not shown in the Chord Dictionary function.


Looking up Chords Using the Chord Dictionary

The Dictionary function is essentially a built-in “chord dictionary” that shows you the individual notes of chords. It is ideal when you know the name of a certain chord and want to quickly learn how to play it.


- 1 Press and hold the [WAITING] button for longer than a second. “Dict.” will appear in the display.



- 2 As an example, we’ll learn how to play a GM7 (G major seventh) chord. Press the “G” key in the section of the keyboard labeled “ROOT.” (The note doesn’t sound.) The root note you set is shown in the display.



- 3 Press the “M7” (major seventh) key in the section of the keyboard labeled “CHORD TYPE.” (The note doesn’t sound.) The notes you should play for the specified chord (root note and chord type) are shown in the display, both as notation and in the keyboard diagram.



NOTE

• Major chords are usually indicated by the root name only. For example, the indication “C” in a score refers to a “C Major” chord. To look up the fingering for a major chord press the root key and then the M chord type key.


To call up possible inversions of the chord, press the [+]/[-] buttons.

- 4 Try playing a chord in the auto accompaniment section of the keyboard, checking the indications in the display. When you’ve played the chord properly, a bell sound signals your success and the chord name in the display flashes.

About chords

Playing two or more notes together simultaneously creates a “chord.”


Playing a note together with two other notes spaced three notes (steps) apart—such as the notes C, E and G—creates a harmonious sound. Chords like these are called “triads” and they play an important role in most music.




Taking the chord above as an example, the lowest note of this triad is called the “root note.” This is the central note sound, and it supports or anchors the rest of the notes chord.

You’ll notice that the middle note of the chord above (E) is the third step in the succession of scale notes—C, D, then E. There are two types of “thirds” in chords: major thirds and minor thirds.

Major third—four half steps from the root




Minor third—three half steps from the root




We’ll also alter the top note of our original chord and make three additional chords, as shown below. (The captions indicate the intervals between each of the notes.)


Major chord




Minor chord



Augmented chord




Diminished chord



The basic characteristics of the chord sound are same, no matter if we change the order of the notes from bottom to top, or if we add other same name notes in different octaves. Beautiful sounding harmonies can be built in this manner, and emotional music can be created by playing different chords one after the other according to commonly accepted rules. Harmony determines the nature of chords, and music is created based on harmony.


Chord names

From the chord name, you can tell at a glance what type of chord it is and which notes make up the chord. Understanding the basic structure of chords is very useful—once you’re familiar with this, you’ll be quickly and easily play chords by looking at the names that appear above the notation.




Chord types (These chords are among those that can be recognized by the Fingered method.)


Suspended 4th




7th




Minor 7th




Major 7th




Minor/major 7th




7th, flatted 5th



Minor 7th, flatted 5th



7th, suspended 4th



Function Settings


The [FUNCTION] button gives you access to a variety of operations related to adjusting or enhancing the sound and making settings for connection to external devices.

Select the item and change the value

There are 32 different items that can be set.


1 Press the [FUNCTION] button a number of times until desired item appears.

Each time the [FUNCTION] button is pressed 32 function items are displayed in sequence. The description and display sample is provided on the Function Setting List on page 56-57.




2 Set the value by using the number buttons [0]-[9], [+], [-].

For on/off settings or the PC Mode setting, use [+]/[-] buttons.



3 If necessary, hold the [FUNCTION] button for longer than a second to save your settings to flash memory.

(Refer to “Backup” on page 29)



● Function Setting List

Item	Display	Range/settings	Description
Style Volume	<i>StyleVol</i>	000-127	Determines the volume of the Style.
Song Volume	<i>SongVol</i>	000-127	Determines the volume of the Song.
Transpose	<i>TransPos</i>	-12-00-12	Determines the pitch of the instrument by semitone increments.
Tuning	<i>Tuning</i>	-100-000-100	Sets the pitch of the instrument's sound in 1-cent increments.
Split Point	<i>SplitPnt</i>	000-127 (C-2-G8)	Determines the highest key for the Split Voice and sets the Split “point”—in other words, the key that separates the Split (lower) and Main (upper) Voices. The Split Point setting and Accompaniment Split Point setting are automatically set to the same value.

Item	Display	Range/settings	Description
Touch Sensitivity	<i>TouchSns</i>	1 (Soft) 2 (Medium) 3 (Hard)	When Touch Response is on, this determines the sensitivity of the feature.
Main Voice Volume	<i>M.VOLUME</i>	000-127	Determines the volume of the Main Voice.
Main Voice Octave	<i>M.Octave</i>	-2-0-2	Determines the octave range for the Main Voice.
Main Voice Chorus Send Level	<i>M.Chorus</i>	000-127	Determines how much of the Main Voice's signal is sent to the Chorus effect.
Dual Voice	<i>D.Voice</i>	001-482	Selects the Dual Voice.
Dual Voice Volume	<i>D.VOLUME</i>	000-127	Determines the volume of the Dual Voice.
Dual Voice Octave	<i>D.Octave</i>	-2-0-2	Determines the octave range for the Dual Voice.
Dual Voice Chorus Send Level	<i>D.Chorus</i>	000-127	Determines how much of the Dual Voice's signal is sent to the Chorus effect.
Split Voice	<i>S.Voice</i>	001-482	Selects the Split Voice.
Split Voice Volume	<i>S.VOLUME</i>	000-127	Determines the volume of the Split Voice.
Split Voice Octave	<i>S.Octave</i>	-2-0-2	Determines the octave range for the Split Voice.
Split Voice Chorus Send Level	<i>S.Chorus</i>	000-127	Determines how much of the Split Voice's signal is sent to the Chorus effect.
Reverb Type	<i>Reverb</i>	01-10	Determines the Reverb type, including off (10). Refer to the Reverb Type list on page 75.
Reverb Level	<i>RevLevel</i>	000-127	Determines how much of the Voice's signal is sent to the Reverb effect.
Chorus Type	<i>Chorus</i>	1-5	Determines the Chorus Type, including off (05). Refer to the Chorus Type list on page 75.
Panel Sustain	<i>Sustain</i>	ON/OFF	Determines whether or not Panel Sustain is always applied to the Main/Dual/Split Voices. Panel Sustain is applied continuously when ON, or not applied when OFF.
Harmony Type	<i>HarmType</i>	01-26	Determines the Harmony Type. Refer to the Harmony Type list on page 75.
Harmony Volume	<i>HarmVol</i>	000-127	Determines the volume of the Harmony effect when Harmony type 1-5 is selected.
PC Mode	<i>PC mode</i>	OFF/PC1/PC2	Optimizes the MIDI settings when you connect to a computer (page 60).
Local On/Off	<i>Local</i>	ON/OFF	Determines whether the instrument's keyboard controls the internal tone generator (ON) or not (OFF).
External Clock	<i>ExtClock</i>	ON/OFF	Determines whether the instrument synchronizes to the internal clock (OFF) or an external clock (ON).
Initial Setup Send	<i>InitSend</i>	YES/NO	Lets you send the data of the panel settings to a computer. Use the [+] button to transmit the data.
Time Signature	<i>TimeSig</i>	00-15	Determines the time signature of the Metronome.
Metronome Volume	<i>MetroVol</i>	000-127	Determines the volume of the Metronome.
Lesson Track (R)	<i>R-Part</i>	01-16	Determines the guide track number for your right hand lesson. The setting is only effective for Songs in SMF format 0 transferred from a computer. Refer to the section "Using Transferred Songs for Lessons" on page 63.
Lesson Track (L)	<i>L-Part</i>	01-16	Determines the guide track number for your left hand lesson. The setting is only effective for Songs in SMF format 0 transferred from a computer. Refer to the section "Using Transferred Songs for Lessons" on page 63.
Demo Cancel	<i>D-Cancel</i>	ON/OFF	Determines whether Demo cancel is enabled or not. When this is set to ON, the Demo Song will not play, even if the [DEMO] button is pressed.

About MIDI

The instrument features a MIDI terminals that can be connected to other MIDI instruments and devices for expanded musical functionality.

What is MIDI?

MIDI (Musical Instrument Digital Interface) is a world-standard interface for communication between electronic musical instruments and music devices. When MIDI-equipped instruments are connected via a MIDI cable, it becomes possible to transfer performance and setting data between them for significantly enhanced performance and production potential.



CAUTION

- *Connect the PSR-E303/YPT-300 to external equipment only after turning off power for all devices. Then, turn on the power, first to the PSR-E303/YPT-300, then to the connected external equipment.*


What You Can Do With MIDI

- Transferring performance and setting data between the PSR-E303/YPT-300 and MIDI-equipped instruments or computers. (page 59)
- Transferring the data between the PSR-E303/YPT-300 and computers. (page 61)


Transferring Performance Data To and From Another Instrument

By connecting the PSR-E303/YPT-300 to other MIDI devices or a computer, the performance data of the instrument can be used on those other MIDI devices or computer, and also the performance data from other MIDI devices and computer can be received and sounded with the PSR-E303/YPT-300.

- When the instrument is connected with another MIDI device, it transmits/receives performance data.



- When the instrument is connected with a computer, it transmits/receives performance data.



■ MIDI settings

These settings should be made when transmitting/receiving performance data to a connected MIDI device or computer.

Local Settings

Local Control determines whether or not notes played on the instrument are sounded by its internal tone generator system; the internal tone generator is active when local control is on, and inactive when local control is off.

- On** This is the normal setting in which notes played on the instrument's keyboard are sounded by the internal tone generator system. Data received via the instrument's MIDI terminal will also be played by the internal tone generator.
- Off** With this setting the instrument itself produces no sound (keyboard performance, Harmony, or Style playback), but the performance data is transmitted via the MIDI terminal. Data received via the instrument's MIDI terminal will also be played by the internal tone generator.

You can set the Local Control in the Function Settings (page 56).

NOTE

- If you can't get any sound out of the instrument, Local Control may be the most likely cause. Playing the keyboard results in no sound when Local is set to OFF.

External Clock Settings

These settings determine whether the instrument is synchronized to its own internal clock (OFF), or to a clock signal from an external device (ON).

On..... The instrument's time based functions will be synchronized to the clock from an external device connected to the MIDI terminal.

Off..... The instrument uses its own internal clock (default).

You can set the External Clock in the Function Settings (page 56).



- If External Clock is ON and no clock signal is being received from an external device, the Song, Style, and metronome functions will not start.

PC Mode

The PC settings instantly reconfigure all important MIDI settings (as shown below). The selections are PC1, PC2 and OFF.

● The chart of PC Settings

	PC1	PC2*	OFF
LOCAL	Off	Off	On
EXTERNAL CLOCK	On	Off	Off
SONG OUT**	Off	Off	On
STYLE OUT***	Off	Off	On
KEYBOARD OUT****	Off	On	On

* Set the PC mode to PC2 when using Digital Music Notebook. Digital Music Notebook is a major new multimedia platform for music tuition and performance. Visit the website below for more information on the latest version of Digital Music Notebook and how to install it.

www.digitalmusicnotebook.com

** Determines whether Song data is transmitted (ON) via MIDI or not (OFF) during Song playback.

*** Determines whether Style data is transmitted (ON) via MIDI or not (OFF) during Style playback.

**** Determines whether keyboard performance data of the instrument is transmitted (ON) or not (OFF).




- Song Out, Style Out and Keyboard Out can only be changed by the PC setting. They cannot be set independently.
- Copyrighted Songs and User Songs cannot be used with Song Out.

1 Press and hold the [DEMO] button for longer than a second to call up the PC Mode.



Hold for longer than a second.




2 Select PC1, PC2, or OFF by using the [+], [-] buttons.

Remote Control of MIDI Devices

You can also use this instrument as a remote control device for the Digital Music Notebook application on your computer (via the MIDI connection)—controlling playback, stop and transport functions from the panel.

● Remote control keys

PSR-E303/YPT-300: To use the remote control functions, simultaneously hold down the lowest two keys on the keyboard (C1 and C#1) and press the appropriate key (shown below).



- Remote control of MIDI devices will function independently of the PC2 mode.

PSR-E303/YPT-300 Panel Setting Transmission (Initial Send)

Sends the PSR-E303/YPT-300 panel settings to an external MIDI device. When recording a PSR-E303/YPT-300 performance to an external sequencer or similar equipment, you can use this function to send the current PSR-E303/YPT-300 panel settings so that when the sequence is played back the original panel settings are automatically restored. You can set Initial Send in the Function settings (page 56).

Transferring data between the PSR-E303/YPT-300 and a computer

The PSR-E303/YPT-300 includes 102 preset Songs, but you can load other Songs from your computer and use them in the same way as the preset Songs as long as the loaded Song is SMF format 0*. Loaded Song data will be stored in Song numbers beginning with 108. In order to perform the operations described in this section you will need to use a computer connected to the Internet to download the free Musicsoft Downloader application from the URL listed below.

* The SMF (Standard MIDI File) format is one of the most common and widely compatible sequence formats used for storing sequence data. Most commercially available MIDI sequence data is provided in SMF Format 0.

Installing Musicsoft Downloader

You can download the “Musicsoft Downloader” application from the following website. Make sure that your computer has an Internet connection.

<http://music.yamaha.com/download/>

● The minimum computer requirements for Musicsoft Downloader operation are as follows:

- OS : Windows 98SE/Me/2000/XP Home Edition/XP Professional
- CPU : 233 MHz or higher; Intel® Pentium®/Celeron® processor family (500 MHz or more is recommended)
- Memory : 64 MB or more (256 MB or more is recommended)
- Hard Disk : at least 128 MB of free space (at least 512 MB of free space is recommended)
- Display : 800 x 600 HighColor (16-bit)
- Other : Microsoft® Internet Explorer®5.5 or higher



• Visit the Yamaha website for more information on the latest version of Musicsoft Downloader (version 5.2.0 or higher) and how to install it.


Connecting a personal computer

After installing the Musicsoft Downloader application on your computer, connect the PSR-E303/YPT-300 as described below.

A Yamaha UX16 or similar USB-MIDI interface (sold separately) will be necessary for MIDI connection between the PSR-E303/YPT-300 and a USB-equipped computer.

Make sure to purchase a Yamaha UX16 or a quality USB-MIDI interface at a musical instrument store, computer store or electrical appliance store.

If you use the UX16 interface, install the driver supplied with the interface on your computer.



Transferring data from a computer

You can transmit Song files from your computer to your PSR-E303/YPT-300's Flash Memory.

For details about how to transmit Song data using the Musicsoft Downloader application, refer to the Online help topic "Transferring Data Between the Computer and Instrument (for unprotected data)" of the Musicsoft Downloader.

● Data that can be loaded to the PSR-E303/YPT-300 from a computer

- Songs : 99 Songs max (Song numbers 108-)
- Data : 373 kilobytes
- Data Format : SMF Format 0
- File : 05PK.USR (user file)
***.MID (MIDI Song)

NOTE

- The Musicsoft Downloader application may not be able to access the instrument in the following cases:
 - During Style playback
 - During Song playback

CAUTION

- Use the power adaptor when transferring data. The data can be corrupted if the batteries fail during the transfer.
- Never turn the power off and never plug/unplug the AC power adaptor during data transmission. Not only will the data fail to be transferred and saved, but operation of the flash memory may become unstable and its contents may disappear completely when the power is turned on or off.

NOTE

- Close the window to exit from the Musicsoft Downloader and re-enable control of the instrument.

Transferring a user file from the PSR-E303/YPT-300 to a computer

You can transfer backup data (page 29), including the five User Songs stored to the instrument, to a computer as a "user file" by using Musicsoft Downloader. For details about how to transmit Song data using the Musicsoft Downloader application, refer to the Online help topic "Transferring Data Between the Computer and Instrument (for unprotected data)" in the application.

● Data that can be transferred to a computer from the PSR-E303/YPT-300

- User file (05PK.USR: backup data containing five User Songs)
- Songs transferred from a computer

NOTE

- Preset Song data cannot be transmitted from the PSR-E303/YPT-300.
- Do not rename the user file on the computer. If you do so, it will not be recognized when transferred to the instrument.

CAUTION

- The backup data, including the five User Songs is transmitted/received as a single file. As a result, all backup data (including the five Songs) will be overwritten every time you transmit or receive. Keep this in mind when transferring data.

● Erasing Transferred Song Data from the PSR-E303/YPT-300 Memory

To erase all Songs transferred from the computer, use "flash clear" function on page 29.

To erase specific Songs transferred from the computer, use the Delete function on Musicsoft Downloader.

● Using Transferred Songs for Lessons

In order to use Songs (only SMF format 0) transferred from a computer for lessons it is necessary to specify which channels are to be played back as the right-hand and left-hand parts. Refer to the "Lesson Track (R)" or "Lesson Track (L)" in the Function Setting List on page 57. The procedure for setting the "guide track" is as follows: Select a transferred Song you want to use for lessons. Press the [FUNCTION] button a number of times until the "R-Part" or "L-Part" appears in the display, and then use the number buttons [0]-[9], [+], [-] to select the channel you want to play back as the specified right- or left-hand part.

We recommend that you select channel 1 for the right-hand part and channel 2 for the left-hand part.

Troubleshooting

Problem	Possible Cause and Solution
When the instrument is turned on or off, a popping sound is temporarily produced.	This is normal and indicates that the instrument is receiving electrical power.
When using a mobile phone, noise is produced.	Using a mobile phone in close proximity to the instrument may produce interference. To prevent this, turn off the mobile phone or use it further away from the instrument.
There is no sound even when the keyboard is played or when a Song or Style is being played back.	Check that nothing is connected to the PHONES/OUTPUT jack on the rear panel. When a set of headphones is plugged into this jack, no sound is output.
	Check the Local Control on/off. (See page 59.)
Playing keys in the right hand area of the keyboard does not produce any sound.	When using the Dictionary function (page 54), the keys in the right hand area are used only for entering the chord root and type.
<ul style="list-style-type: none"> • The volume is too soft. • The sound quality is poor. • The rhythm stops unexpectedly or will not play. • The recorded data of the Song, etc. does not play correctly. • The LCD display suddenly goes dark, and all panel settings are reset. 	The batteries are low or dead. Replace all six batteries with completely new ones, or use the optional AC adaptor.
The Style or Song does not play back when the [START/STOP] button is pressed.	Is External Clock set to ON? Make sure External Clock is set to OFF; refer to "External Clock Settings" on page 60.
The Style does not sound properly.	Make sure that the Style Volume (page 51) is set to an appropriate level.
	Is the Split Point set at an appropriate key for the chords you are playing? Set the Split Point at an appropriate key (page 44). Is the "ACMP ON" indicator showing in the display? If it is not showing press the [ACMP ON/OFF] button so that it does show.
No rhythm accompaniment plays when the [START/STOP] button is pressed after selecting Style number 098-106 (Pianist).	This is not a malfunction. Style number 098-106 (Pianist) have no rhythm parts, so no rhythm will play. The other parts will begin playing when you play a chord in the accompaniment range of the keyboard if auto accompaniment is turned on.
Not all of the voices seem to sound, or the sound seems to be cut off.	The instrument is polyphonic up to a maximum of 32 notes. If the Dual voice or Split voice is being used and a style or Song is playing back at the same time, some notes/sounds may be omitted (or "stolen") from the accompaniment or Song.
The footswitch (for sustain) seems to produce the opposite effect. For example, pressing the footswitch cuts off the sound and releasing it sustains the sounds.	The polarity of the footswitch is reversed. Make sure that the footswitch plug is properly connected to the SUSTAIN jack before turning on the power.
The sound of the voice changes from note to note.	This is normal. The AWM tone generation method uses multiple recordings (samples) of an instrument across the range of the keyboard; thus, the actual sound of the voice may be slightly different from note to note.
The ACMP ON indicator does not appear when the [ACMP ON/OFF] button is pressed.	Always press the [STYLE] button first when you are going to use any style-related function.
The harmony doesn't sound.	The method of sounding the harmony effect (01-26) differs depending on the selected type. For Types 01-05, turn the Auto Accompaniment on and play it by pressing a chord in the auto accompaniment section of the keyboard, then play some keys in the right-hand side to get the harmony effect. For Types 06-26, turning the Auto Accompaniment on or off has no effect. However, it is necessary to play two notes simultaneously for Types 06-12.
The part indications, such as Right, Left and Both Hands, do not appear—even when pressing the [R] or [L] buttons for the Lesson.	Make sure that you are not pressing the [R] or [L] buttons while the Song is playing. If you press one of the part buttons while playing the Song and before starting the Lesson, these buttons serve to mute the corresponding Song tracks. Stop the Song first, then select the desired part and start the Lesson.

Voice List

Voice No.	Bank Select		MIDI Program Change# (1 - 128)	Voice Name
	MSB (0 - 127)	LSB (0 - 127)		
SAXOPHONE				
063	0	112	67	Tenor Sax
064	0	112	66	Alto Sax
065	0	112	65	Soprano Sax
066	0	112	68	Baritone Sax
067	0	114	67	Breathy Tenor Sax
068	0	112	69	Oboe
069	0	112	72	Clarinet
070	0	112	70	English Horn
071	0	112	71	Bassoon
TRUMPET				
072	0	112	57	Trumpet
073	0	112	60	Muted Trumpet
074	0	112	58	Trombone
075	0	113	58	Trombone Section
076	0	112	61	French Horn
077	0	112	59	Tuba
BRASS				
078	0	112	62	Brass Section
079	0	113	62	Big Band Brass
080	0	119	62	Mellow Horns
081	0	112	63	Synth Brass
082	0	113	63	80's Brass
083	0	114	63	Techno Brass
FLUTE				
084	0	112	74	Flute
085	0	112	73	Piccolo
086	0	112	76	Pan Flute
087	0	112	75	Recorder
088	0	112	80	Ocarina
SYNTH LEAD				
089	0	112	81	Square Lead
090	0	112	82	Sawtooth Lead
091	0	112	86	Voice Lead
092	0	112	99	Star Dust
093	0	112	101	Brightness
094	0	115	82	Analogon
095	0	119	82	Fargo
SYNTH PAD				
096	0	112	89	Fantasia
097	0	113	101	Bell Pad
098	0	112	92	Xenon Pad
099	0	112	95	Equinox
100	0	113	90	Dark Moon
PERCUSSION				
101	0	112	12	Vibraphone
102	0	112	13	Marimba
103	0	112	14	Xylophone
104	0	112	115	Steel Drums

Voice No.	Bank Select		MIDI Program Change# (1 - 128)	Voice Name
	MSB (0 - 127)	LSB (0 - 127)		
105	0	112	9	Celesta
106	0	112	11	Music Box
107	0	112	15	Tubular Bells
108	0	112	48	Timpani
DRUM KITS				
109	127	0	1	Standard Kit 1
110	127	0	2	Standard Kit 2
111	127	0	9	Room Kit
112	127	0	17	Rock Kit
113	127	0	25	Electronic Kit
114	127	0	26	Analog Kit
115	127	0	28	Dance Kit
116	127	0	33	Jazz Kit
117	127	0	41	Brush Kit
118	127	0	49	Symphony Kit
119	126	0	1	SFX Kit 1
120	126	0	2	SFX Kit 2
121	126	0	113	Sound Effect Kit

● XGlite Voice/XGlite Optional Voice* List

Voice No.	Bank Select		MIDI Program Change# (1 - 128)	Voice Name
	MSB (0 - 127)	LSB (0 - 127)		
PIANO				
122	0	0	1	Grand Piano
123	0	1	1	Grand Piano KSP
124	0	40	1	Piano Strings
125	0	41	1	Dream
126	0	0	2	Bright Piano
127	0	1	2	Bright Piano KSP
128	0	0	3	Electric Grand Piano
129	0	1	3	Electric Grand Piano KSP
130	0	32	3	Detuned CP80
131	0	0	4	Honky-tonk Piano
132	0	1	4	Honky-tonk Piano KSP
133	0	0	5	Electric Piano 1
134	0	1	5	Electric Piano 1 KSP
135	0	32	5	Chorus Electric Piano 1
136	0	0	6	Electric Piano 2
137	0	1	6	Electric Piano 2 KSP
*138	0	32	6	Chorus Electric Piano 2
139	0	41	6	DX + Analog Electric Piano
140	0	0	7	Harpsichord
141	0	1	7	Harpsichord KSP
142	0	35	7	Harpsichord 3
143	0	0	8	Clavi
144	0	1	8	Clavi KSP

Voice No.	Bank Select		MIDI Program Change# (1 - 128)	Voice Name
	MSB (0 - 127)	LSB (0 - 127)		
CHROMATIC				
145	0	0	9	Celesta
146	0	0	10	Glockenspiel
147	0	0	11	Music Box
148	0	64	11	Orgel
149	0	0	12	Vibraphone
150	0	1	12	Vibraphone KSP
151	0	0	13	Marimba
152	0	1	13	Marimba KSP
153	0	64	13	Sine Marimba
154	0	97	13	Balimba
155	0	98	13	Log Drums
156	0	0	14	Xylophone
157	0	0	15	Tubular Bells
158	0	96	15	Church Bells
159	0	97	15	Carillon
160	0	0	16	Dulcimer
161	0	35	16	Dulcimer 2
162	0	96	16	Cimbalom
163	0	97	16	Santur
ORGAN				
164	0	0	17	Drawbar Organ
165	0	32	17	Detuned Drawbar Organ
166	0	33	17	60's Drawbar Organ 1
167	0	34	17	60's Drawbar Organ 2
168	0	35	17	70's Drawbar Organ 1
169	0	37	17	60's Drawbar Organ 3
170	0	40	17	16+2'2/3
171	0	64	17	Organ Bass
172	0	65	17	70's Drawbar Organ 2
173	0	66	17	Cheezy Organ
174	0	67	17	Drawbar Organ 3
175	0	0	18	Percussive Organ
176	0	24	18	70's Percussive Organ
177	0	32	18	Detuned Percussive Organ
178	0	33	18	Light Organ
179	0	37	18	Percussive Organ 2
180	0	0	19	Rock Organ
181	0	64	19	Rotary Organ
182	0	65	19	Slow Rotary
183	0	66	19	Fast Rotary
184	0	0	20	Church Organ
185	0	32	20	Church Organ 3
186	0	35	20	Church Organ 2
187	0	40	20	Notre Dame
188	0	64	20	Organ Flute
189	0	65	20	Tremolo Organ Flute
190	0	0	21	Reed Organ

Voice No.	Bank Select		MIDI Program Change# (1 - 128)	Voice Name
	MSB (0 - 127)	LSB (0 - 127)		
191	0	40	21	Puff Organ
192	0	0	22	Accordion
193	0	0	23	Harmonica
194	0	32	23	Harmonica 2
195	0	0	24	Tango Accordion
196	0	64	24	Tango Accordion 2
GUITAR				
197	0	0	25	Nylon Guitar
198	0	43	25	Velocity Guitar Harmonics
199	0	96	25	Ukulele
200	0	0	26	Steel Guitar
201	0	35	26	12-string Guitar
202	0	40	26	Nylon & Steel Guitar
203	0	41	26	Steel Guitar with Body Sound
204	0	96	26	Mandolin
205	0	0	27	Jazz Guitar
206	0	32	27	Jazz Amp
207	0	0	28	Clean Guitar
208	0	32	28	Chorus Guitar
209	0	0	29	Muted Guitar
210	0	40	29	Funk Guitar 1
211	0	41	29	Muted Steel Guitar
212	0	45	29	Jazz Man
213	0	0	30	Overdriven Guitar
214	0	43	30	Guitar Pinch
215	0	0	31	Distortion Guitar
216	0	40	31	Feedback Guitar
217	0	41	31	Feedback Guitar 2
218	0	0	32	Guitar Harmonics
219	0	65	32	Guitar Feedback
220	0	66	32	Guitar Harmonics 2
BASS				
221	0	0	33	Acoustic Bass
222	0	40	33	Jazz Rhythm
223	0	45	33	Velocity Crossfade Upright Bass
224	0	0	34	Finger Bass
225	0	18	34	Finger Dark
226	0	40	34	Bass & Distorted Electric Guitar
227	0	43	34	Finger Slap Bass
228	0	45	34	Finger Bass 2
229	0	65	34	Modulated Bass
230	0	0	35	Pick Bass
231	0	28	35	Muted Pick Bass
232	0	0	36	Fretless Bass
233	0	32	36	Fretless Bass 2
234	0	33	36	Fretless Bass 3
235	0	34	36	Fretless Bass 4
236	0	0	37	Slap Bass 1

Voice List

Voice No.	Bank Select		MIDI Program Change# (1 - 128)	Voice Name
	MSB (0 - 127)	LSB (0 - 127)		
237	0	32	37	Punch Thumb Bass
238	0	0	38	Slap Bass 2
239	0	43	38	Velocity Switch Slap
240	0	0	39	Synth Bass 1
241	0	40	39	Techno Synth Bass
242	0	0	40	Synth Bass 2
243	0	6	40	Mellow Synth Bass
244	0	12	40	Sequenced Bass
245	0	18	40	Click Synth Bass
246	0	19	40	Synth Bass 2 Dark
*247	0	40	40	Modular Synth Bass
248	0	41	40	DX Bass
STRINGS				
249	0	0	41	Violin
250	0	8	41	Slow Violin
251	0	0	42	Viola
252	0	0	43	Cello
253	0	0	44	Contrabass
254	0	0	45	Tremolo Strings
255	0	8	45	Slow Tremolo Strings
256	0	40	45	Suspense Strings
257	0	0	46	Pizzicato Strings
258	0	0	47	Orchestral Harp
259	0	40	47	Yang Chin
260	0	0	48	Timpani
ENSEMBLE				
261	0	0	49	Strings 1
262	0	3	49	Stereo Strings
263	0	8	49	Slow Strings
264	0	35	49	60's Strings
265	0	40	49	Orchestra
266	0	41	49	Orchestra 2
267	0	42	49	Tremolo Orchestra
268	0	45	49	Velocity Strings
269	0	0	50	Strings 2
270	0	3	50	Stereo Slow Strings
271	0	8	50	Legato Strings
272	0	40	50	Warm Strings
273	0	41	50	Kingdom
274	0	0	51	Synth Strings 1
275	0	0	52	Synth Strings 2
276	0	0	53	Choir Aahs
277	0	3	53	Stereo Choir
278	0	32	53	Mellow Choir
279	0	40	53	Choir Strings
280	0	0	54	Voice Oohs
281	0	0	55	Synth Voice
282	0	40	55	Synth Voice 2
283	0	41	55	Choral

Voice No.	Bank Select		MIDI Program Change# (1 - 128)	Voice Name
	MSB (0 - 127)	LSB (0 - 127)		
284	0	64	55	Analog Voice
285	0	0	56	Orchestra Hit
286	0	35	56	Orchestra Hit 2
287	0	64	56	Impact
BRASS				
288	0	0	57	Trumpet
289	0	32	57	Warm Trumpet
290	0	0	58	Trombone
291	0	18	58	Trombone 2
292	0	0	59	Tuba
293	0	0	60	Muted Trumpet
294	0	0	61	French Horn
295	0	6	61	French Horn Solo
296	0	32	61	French Horn 2
297	0	37	61	Horn Orchestra
298	0	0	62	Brass Section
299	0	35	62	Trumpet & Trombone Section
300	0	0	63	Synth Brass 1
301	0	20	63	Resonant Synth Brass
302	0	0	64	Synth Brass 2
303	0	18	64	Soft Brass
304	0	41	64	Choir Brass
REED				
305	0	0	65	Soprano Sax
306	0	0	66	Alto Sax
307	0	40	66	Sax Section
308	0	0	67	Tenor Sax
309	0	40	67	Breathy Tenor Sax
310	0	0	68	Baritone Sax
311	0	0	69	Oboe
312	0	0	70	English Horn
313	0	0	71	Bassoon
314	0	0	72	Clarinet
PIPE				
315	0	0	73	Piccolo
316	0	0	74	Flute
317	0	0	75	Recorder
318	0	0	76	Pan Flute
319	0	0	77	Blown Bottle
320	0	0	78	Shakuhachi
321	0	0	79	Whistle
322	0	0	80	Ocarina
SYNTH LEAD				
323	0	0	81	Square Lead
324	0	6	81	Square Lead 2
325	0	8	81	LM Square
326	0	18	81	Hollow
327	0	19	81	Shroud
328	0	64	81	Mellow

Voice No.	Bank Select		MIDI Program Change# (1 - 128)	Voice Name
	MSB (0 - 127)	LSB (0 - 127)		
329	0	65	81	Solo Sine
330	0	66	81	Sine Lead
331	0	0	82	Sawtooth Lead
332	0	6	82	Sawtooth Lead 2
333	0	8	82	Thick Sawtooth
334	0	18	82	Dynamic Sawtooth
335	0	19	82	Digital Sawtooth
336	0	20	82	Big Lead
337	0	96	82	Sequenced Analog
338	0	0	83	Calliope Lead
339	0	65	83	Pure Pad
340	0	0	84	Chiff Lead
341	0	0	85	Charang Lead
342	0	64	85	Distorted Lead
343	0	0	86	Voice Lead
344	0	0	87	Fifths Lead
345	0	35	87	Big Five
346	0	0	88	Bass & Lead
347	0	16	88	Big & Low
348	0	64	88	Fat & Perky
349	0	65	88	Soft Whirl
SYNTH PAD				
350	0	0	89	New Age Pad
351	0	64	89	Fantasy
352	0	0	90	Warm Pad
353	0	0	91	Poly Synth Pad
354	0	0	92	Choir Pad
355	0	66	92	Itopia
356	0	0	93	Bowed Pad
357	0	0	94	Metallic Pad
358	0	0	95	Halo Pad
359	0	0	96	Soft Sweep Pad
SYNTH EFFECTS				
360	0	0	97	Rain
361	0	65	97	African Wind
362	0	66	97	Carib
363	0	0	98	Sound Track
364	0	27	98	Prologue
365	0	0	99	Crystal
366	0	12	99	Synth Drum Comp
367	0	14	99	Popcorn
368	0	18	99	Tiny Bells
369	0	35	99	Round Glockenspiel
370	0	40	99	Glockenspiel Chimes
371	0	41	99	Clear Bells
372	0	42	99	Chorus Bells
373	0	65	99	Soft Crystal
374	0	70	99	Air Bells
375	0	71	99	Bell Harp

Voice No.	Bank Select		MIDI Program Change# (1 - 128)	Voice Name
	MSB (0 - 127)	LSB (0 - 127)		
376	0	72	99	Gamelimba
377	0	0	100	Atmosphere
378	0	18	100	Warm Atmosphere
379	0	19	100	Hollow Release
380	0	40	100	Nylon Electric Piano
381	0	64	100	Nylon Harp
382	0	65	100	Harp Vox
383	0	66	100	Atmosphere Pad
384	0	0	101	Brightness
385	0	0	102	Goblins
386	0	64	102	Goblins Synth
387	0	65	102	Creeper
388	0	67	102	Ritual
389	0	68	102	To Heaven
390	0	70	102	Night
391	0	71	102	Glisten
392	0	96	102	Bell Choir
393	0	0	103	Echoes
394	0	0	104	Sci-Fi
WORLD				
395	0	0	105	Sitar
396	0	32	105	Detuned Sitar
397	0	35	105	Sitar 2
398	0	97	105	Tamboura
399	0	0	106	Banjo
400	0	28	106	Muted Banjo
401	0	96	106	Rabab
402	0	97	106	Gopichant
403	0	98	106	Oud
404	0	0	107	Shamisen
405	0	0	108	Koto
406	0	96	108	Taisho-kin
407	0	97	108	Kanoon
408	0	0	109	Kalimba
409	0	0	110	Bagpipe
410	0	0	111	Fiddle
411	0	0	112	Shanai
PERCUSSIVE				
412	0	0	113	Tinkle Bell
413	0	96	113	Bonang
414	0	97	113	Altair
415	0	98	113	Gamelan Gongs
416	0	99	113	Stereo Gamelan Gongs
417	0	100	113	Rama Cymbal
418	0	0	114	Agogo
419	0	0	115	Steel Drums
420	0	97	115	Glass Percussion
421	0	98	115	Thai Bells
422	0	0	116	Woodblock

Voice List

Voice No.	Bank Select		MIDI Program Change# (1 - 128)	Voice Name
	MSB (0 - 127)	LSB (0 - 127)		
423	0	96	116	Castanets
424	0	0	117	Taiko Drum
425	0	96	117	Gran Cassa
426	0	0	118	Melodic Tom
427	0	64	118	Melodic Tom 2
428	0	65	118	Real Tom
429	0	66	118	Rock Tom
430	0	0	119	Synth Drum
431	0	64	119	Analog Tom
432	0	65	119	Electronic Percussion
433	0	0	120	Reverse Cymbal
SOUND EFFECTS				
434	0	0	121	Fret Noise
435	0	0	122	Breath Noise
436	0	0	123	Seashore
437	0	0	124	Bird Tweet
438	0	0	125	Telephone Ring
439	0	0	126	Helicopter
440	0	0	127	Applause
441	0	0	128	Gunshot
442	64	0	1	Cutting Noise
443	64	0	2	Cutting Noise 2
444	64	0	4	String Slap
445	64	0	17	Flute Key Click
446	64	0	33	Shower
447	64	0	34	Thunder
448	64	0	35	Wind
449	64	0	36	Stream
450	64	0	37	Bubble
451	64	0	38	Feed
452	64	0	49	Dog
453	64	0	50	Horse
454	64	0	51	Bird Tweet 2
455	64	0	56	Maou
456	64	0	65	Phone Call
457	64	0	66	Door Squeak
458	64	0	67	Door Slam
459	64	0	68	Scratch Cut
460	64	0	69	Scratch Split
461	64	0	70	Wind Chime
462	64	0	71	Telephone Ring 2
463	64	0	81	Car Engine Ignition
464	64	0	82	Car Tires Squeal
465	64	0	83	Car Passing
466	64	0	84	Car Crash
467	64	0	85	Siren
468	64	0	86	Train
469	64	0	87	Jet Plane
470	64	0	88	Starship
471	64	0	89	Burst

Voice No.	Bank Select		MIDI Program Change# (1 - 128)	Voice Name
	MSB (0 - 127)	LSB (0 - 127)		
472	64	0	90	Roller Coaster
473	64	0	91	Submarine
474	64	0	97	Laugh
475	64	0	98	Scream
476	64	0	99	Punch
477	64	0	100	Heartbeat
478	64	0	101	Footsteps
479	64	0	113	Machine Gun
480	64	0	114	Laser Gun
481	64	0	115	Explosion
482	64	0	116	Firework

The voice number with an asterisk (*) is XGlite optional voice.

Drum Kit List

- " " indicates that the drum sound is the same as "Standard Kit 1".
- Each percussion voice uses one note.
- The MIDI Note # and Note are actually one octave lower than keyboard Note # and Note. For example, in "109: Standard Kit 1", the "Seq Click H" (Note# 36/Note C1) corresponds to (Note# 24/Note C0).
- Key Off: Keys marked "O" stop sounding the instant they are released.
- Voices with the same Alternate Note Number (*1 ... 4) cannot be played simultaneously. (They are designed to be played alternately with each other.)

	Voice No.					109	110	111	112	113
	MSB(0-127) / LSB(0-127) / PC(1-128)					127/0/1	127/0/2	127/0/9	127/0/17	127/0/25
	Keyboard	MIDI		Key off	Alternate assign	Standard Kit 1	Standard Kit 2	Room Kit	Rock Kit	Electronic Kit
Note#	Note	Note#	Note							
	25	C# 0	13	C# -1		3	Surdo Mute			
	26	D 0	14	D -1		3	Surdo Open			
	27	D# 0	15	D# -1			Hi Q			
	28	E 0	16	E -1			Whip Slap			
	29	F 0	17	F -1		4	Scratch Push			
	30	F# 0	18	F# -1		4	Scratch Pull			
	31	G 0	19	G -1			Finger Snap			
	32	G# 0	20	G# -1			Click Noise			
	33	A 0	21	A -1			Metronome Click			
	34	A# 0	22	A# -1			Metronome Bell			
	35	B 0	23	B -1			Seq Click L			
	36	C 1	24	C 0			Seq Click H			
	37	C# 1	25	C# 0			Brush Tap			
	38	D 1	26	D 0	O		Brush Swirl			
	39	D# 1	27	D# 0			Brush Slap			
	40	E 1	28	E 0	O		Brush Tap Swirl			Reverse Cymbal
	41	F 1	29	F 0	O		Snare Roll			
	42	F# 1	30	F# 0			Castanet			Hi Q 2
	43	G 1	31	G 0			Snare H Soft	Snare H Soft 2	SD Rock H	Snare L
	44	G# 1	32	G# 0			Sticks			
	45	A 1	33	A 0			Bass Drum Soft			Bass Drum H
	46	A# 1	34	A# 0			Open Rim Shot	Open Rim Shot 2		
	47	B 1	35	B 0			Bass Drum Hard		Bass Drum H	BD Rock
	48	C 2	36	C 1			Bass Drum	Bass Drum 2	BD Rock	BD Gate
	49	C# 2	37	C# 1			Side Stick			
	50	D 2	38	D 1			Snare M	Snare M 2	SD Room L	SD Rock L
	51	D# 2	39	D# 1			Hand Clap			
	52	E 2	40	E 1			Snare H Hard	Snare H Hard 2	SD Room H	SD Rock Rim
	53	F 2	41	F 1			Floor Tom L	Room Tom 1	Rock Tom 1	SD Rock H
	54	F# 2	42	F# 1	1		Hi-Hat Closed			E Tom 1
	55	G 2	43	G 1			Floor Tom H	Room Tom 2	Rock Tom 2	E Tom 2
	56	G# 2	44	G# 1	1		Hi-Hat Pedal			
	57	A 2	45	A 1			Low Tom	Room Tom 3	Rock Tom 3	E Tom 3
	58	A# 2	46	A# 1	1		Hi-Hat Open			
	59	B 2	47	B 1			Mid Tom L	Room Tom 4	Rock Tom 4	E Tom 4
	60	C 3	48	C 2			Mid Tom H	Room Tom 5	Rock Tom 5	E Tom 5
	61	C# 3	49	C# 2			Crash Cymbal 1			
	62	D 3	50	D 2			High Tom	Room Tom 6	Rock Tom 6	E Tom 6
	63	D# 3	51	D# 2			Ride Cymbal 1			
	64	E 3	52	E 2			Chinese Cymbal			
	65	F 3	53	F 2			Ride Cymbal Cup			
	66	F# 3	54	F# 2			Tambourine			
	67	G 3	55	G 2			Splash Cymbal			
	68	G# 3	56	G# 2			Cowbell			
	69	A 3	57	A 2			Crash Cymbal 2			
	70	A# 3	58	A# 2			Vibraslap			
	71	B 3	59	B 2			Ride Cymbal 2			
	72	C 4	60	C 3			Bongo H			
	73	C# 4	61	C# 3			Bongo L			
	74	D 4	62	D 3			Conga H Mute			
	75	D# 4	63	D# 3			Conga H Open			
	76	E 4	64	E 3			Conga L			
	77	F 4	65	F 3			Timbale H			
	78	F# 4	66	F# 3			Timbale L			
	79	G 4	67	G 3			Agogo H			
	80	G# 4	68	G# 3			Agogo L			
	81	A 4	69	A 3			Cabasa			
	82	A# 4	70	A# 3			Maracas			
	83	B 4	71	B 3	O		Samba Whistle H			
	84	C 5	72	C 4	O		Samba Whistle L			
	85	C# 5	73	C# 4			Guiro Short			
	86	D 5	74	D 4	O		Guiro Long			
	87	D# 5	75	D# 4			Claves			
	88	E 5	76	E 4			Wood Block H			
	89	F 5	77	F 4			Wood Block L			
	90	F# 5	78	F# 4			Cuica Mute			Scratch Push
	91	G 5	79	G 4			Cuica Open			Scratch Pull
	92	G# 5	80	G# 4	2		Triangle Mute			
	93	A 5	81	A 4	2		Triangle Open			
	94	A# 5	82	A# 4			Shaker			
	95	B 5	83	B 4			Jingle Bell			
	96	C 6	84	C 5			Bell Tree			
	97	C# 6	85	C# 5						
	98	D 6	86	D 5						
	99	D# 6	87	D# 5						
	100	E 6	88	E 5						
	101	F 6	89	F 5						
	102	F# 6	90	F# 5						
	103	G 6	91	G 5						

Drum Kit List

	Voice No.				Key off	Alternate assign	109	114	115	116	117
	MSB(0-127) / LSB(0-127) / PC(1-128)						127/0/1	127/0/26	127/0/28	127/0/33	127/0/41
	Keyboard Note#	Note	MIDI Note#	Note			Standard Kit 1	Analog Kit	Dance Kit	Jazz Kit	Brush Kit
	25	C# 0	13	C# -1		3	Surdo Mute				
	26	D 0	14	D -1		3	Surdo Open				
	27	D# 0	15	D# -1			Hi Q				
	28	E 0	16	E -1			Whip Slap				
	29	F 0	17	F -1		4	Scratch Push				
	30	F# 0	18	F# -1		4	Scratch Pull				
	31	G 0	19	G -1			Finger Snap				
	32	G# 0	20	G# -1			Click Noise				
	33	A 0	21	A -1			Metronome Click				
	34	A# 0	22	A# -1			Metronome Bell				
	35	B 0	23	B -1			Seq Click L				
	36	C 1	24	C 0			Seq Click H				
C1	37	C# 1	25	C# 0			Brush Tap				
D1	38	D 1	26	D 0	O		Brush Swirl				
E1	39	D# 1	27	D# 0			Brush Slap				
	40	E 1	28	E 0	O		Brush Tap Swirl	Reverse Cymbal	Reverse Cymbal		
F1	41	F 1	29	F 0	O		Snare Roll				
	42	F# 1	30	F# 0			Castanet	Hi Q 2	Hi Q 2		
G1	43	G 1	31	G 0			Snare H Soft	SD Rock H	AnSD Snappy	SD Jazz H Light	
	44	G# 1	32	G# 0			Sticks			Brush Slap L	
A1	45	A 1	33	A 0			Bass Drum Soft	Bass Drum H	AnBD Dance-1		
	46	A# 1	34	A# 0			Open Rim Shot		AnSD OpenRim		
B1	47	B 1	35	B 0			Bass Drum Hard	BD Analog L	AnBD Dance-2		
C2	48	C 2	36	C 1			Bass Drum	BD Analog H	AnBD Dance-3	BD Jazz	
	49	C# 2	37	C# 1			Side Stick	Analog Side Stick	Analog Side Stick	BD Jazz	
D2	50	D 2	38	D 1			Snare M	Analog Snare 1	AnSD Q	SD Jazz L	
	51	D# 2	39	D# 1			Hand Clap			Brush Slap	
E2	52	E 2	40	E 1			Snare H Hard	Analog Snare 2	AnSD Ana+Acoustic	SD Jazz M	
	53	F 2	41	F 1			Floor Tom L	Analog Tom 1	Analog Tom 1	Brush Tap	
F2	54	F# 2	42	F# 1	1		Hi-Hat Closed	Analog HH Closed 1	Analog HH Closed 3	Jazz Tom 1	
G2	55	G 2	43	G 1			Floor Tom H	Analog Tom 2	Analog Tom 2	Brush Tom 1	
	56	G# 2	44	G# 1	1		Hi-Hat Pedal	Analog HH Closed 2	Analog HH Closed 4	Jazz Tom 2	
A2	57	A 2	45	A 1			Low Tom	Analog Tom 3	Analog Tom 3	Brush Tom 2	
	58	A# 2	46	A# 1	1		Hi-Hat Open	Analog HH Open	Analog HH Open 2	Jazz Tom 3	
B2	59	B 2	47	B 1			Mid Tom L	Analog Tom 4	Analog Tom 4	Brush Tom 3	
	60	C 3	48	C 2			Mid Tom H	Analog Tom 5	Analog Tom 5	Jazz Tom 4	
C3	61	C# 3	49	C# 2			Crash Cymbal 1	Analog Cymbal	Analog Cymbal	Brush Tom 4	
	62	D 3	50	D 2			High Tom	Analog Tom 6	Analog Tom 6	Jazz Tom 5	
D3	63	D# 3	51	D# 2			Ride Cymbal 1			Brush Tom 5	
E3	64	E 3	52	E 2			Chinese Cymbal			Jazz Tom 6	
	65	F 3	53	F 2			Ride Cymbal Cup			Brush Tom 6	
F3	66	F# 3	54	F# 2			Tambourine				
G3	67	G 3	55	G 2			Splash Cymbal				
	68	G# 3	56	G# 2			Cowbell	Analog Cowbell	Analog Cowbell		
A3	69	A 3	57	A 2			Crash Cymbal 2				
	70	A# 3	58	A# 2			Vibraslap				
B3	71	B 3	59	B 2			Ride Cymbal 2				
C4	72	C 4	60	C 3			Bongo H				
	73	C# 4	61	C# 3			Bongo L				
D4	74	D 4	62	D 3			Conga H Mute	Analog Conga H	Analog Conga H		
	75	D# 4	63	D# 3			Conga H Open	Analog Conga M	Analog Conga M		
E4	76	E 4	64	E 3			Conga L	Analog Conga L	Analog Conga L		
F4	77	F 4	65	F 3			Timbale H				
	78	F# 4	66	F# 3			Timbale L				
G4	79	G 4	67	G 3			Agogo H				
	80	G# 4	68	G# 3			Agogo L				
A4	81	A 4	69	A 3			Cabasa				
	82	A# 4	70	A# 3			Maracas	Analog Maracas	Analog Maracas		
B4	83	B 4	71	B 3	O		Samba Whistle H				
	84	C 5	72	C 4	O		Samba Whistle L				
C5	85	C# 5	73	C# 4			Guiro Short				
	86	D 5	74	D 4	O		Guiro Long				
D5	87	D# 5	75	D# 4			Claves	Analog Claves	Analog Claves		
E5	88	E 5	76	E 4			Wood Block H				
	89	F 5	77	F 4			Wood Block L				
F5	90	F# 5	78	F# 4			Cuica Mute	Scratch Push	Scratch Push		
G5	91	G 5	79	G 4			Cuica Open	Scratch Pull	Scratch Pull		
	92	G# 5	80	G# 4		2	Triangle Mute				
A5	93	A 5	81	A 4		2	Triangle Open				
	94	A# 5	82	A# 4			Shaker				
B5	95	B 5	83	B 4			Jingle Bell				
	96	C 6	84	C 5			Bell Tree				
C6	97	C# 6	85	C# 5							
	98	D 6	86	D 5							
	99	D# 6	87	D# 5							
	100	E 6	88	E 5							
	101	F 6	89	F 5							
	102	F# 6	90	F# 5							
	103	G 6	91	G 5							

		Voice No.				109	118	119	120	121		
		MSB(0-127) / LSB(0-127) / PC(1-128)				127/0/1	127/0/49	126/0/1	126/0/2	126/0/13		
		Keyboard		MIDI		Key off	Alternate assign	Standard Kit 1	Symphony Kit	SFX Kit 1	SFX Kit 2	Sound Effect Kit
		Note#	Note	Note#	Note							
		25	C# 0	13	C# -1		3	Surdo Mute				
		26	D 0	14	D -1		3	Surdo Open				
		27	D# 0	15	D# -1			Hi Q				
		28	E 0	16	E -1			Whip Slap				
		29	F 0	17	F -1		4	Scratch Push				
		30	F# 0	18	F# -1		4	Scratch Pull				
		31	G 0	19	G -1			Finger Snap				
		32	G# 0	20	G# -1			Click Noise				
		33	A 0	21	A -1			Metronome Click				
		34	A# 0	22	A# -1			Metronome Bell				
		35	B 0	23	B -1			Seq Click L				
		36	C 1	24	C 0			Seq Click H				
C1	C#1	37	C# 1	25	C# 0			Brush Tap				
D1	D#1	38	D 1	26	D 0	O		Brush Swirl				
E1		39	D# 1	27	D# 0			Brush Slap				
F1	F#1	40	E 1	28	E 0	O		Brush Tap Swirl				
G1	G#1	41	F 1	29	F 0	O		Snare Roll				
A1	A#1	42	F# 1	30	F# 0			Castanet				Drum Loop
B1		43	G 1	31	G 0			Snare H Soft				
C2	C#2	44	G# 1	32	G# 0			Sticks				
D2	D#2	45	A 1	33	A 0			Bass Drum Soft	Bass Drum L			
E2		46	A# 1	34	A# 0			Open Rim Shot				
F2	F#2	47	B 1	35	B 0			Bass Drum Hard	Gran Cassa			
G2	G#2	48	C 2	36	C 1			Bass Drum	Gran Cassa Mute	Cutting Noise	Phone Call	Heartbeat
A2	A#2	49	C# 2	37	C# 1			Side Stick		Cutting Noise 2	Door Squeak	Footsteps
B2		50	D 2	38	D 1			Snare M	Marching Sn M		Door Slam	Door Squeak
C3	C#3	51	D# 2	39	D# 1			Hand Clap		String Slap	Scratch Cut	Door Slam
D3	D#3	52	E 2	40	E 1			Snare H Hard	Marching Sn H		Scratch	Applause
E3		53	F 2	41	F 1			Floor Tom L	Jazz Tom 1		Wind Chime	Camera
F3	F#3	54	F# 2	42	F# 1	1		Hi-Hat Closed			Telephone Ring 2	Horn
G3	G#3	55	G 2	43	G 1			Floor Tom H	Jazz Tom 2			Hiccup
A3	A#3	56	G# 2	44	G# 1	1		Hi-Hat Pedal				Cuckoo Clock
B3		57	A 2	45	A 1			Low Tom	Jazz Tom 3			Stream
C4	C#4	58	A# 2	46	A# 1	1		Hi-Hat Open				Frog
D4	D#4	59	B 2	47	B 1			Mid Tom L	Jazz Tom 4			Rooster
E4		60	C 3	48	C 2			Mid Tom H	Jazz Tom 5			Dog
F4	F#4	61	C# 3	49	C# 2			Crash Cymbal 1	Hand Cym. L			Cat
G4	G#4	62	D 3	50	D 2			High Tom	Jazz Tom 6			Owl
A4	A#4	63	D# 3	51	D# 2			Ride Cymbal 1	Hand Cym.Short L			Horse Gallop
B4		64	E 3	52	E 2			Chinese Cymbal		Flute Key Click	Car Engine Ignition	Horse Neigh
C5	C#5	65	F 3	53	F 2			Ride Cymbal Cup			Car Tires Squeal	Cow
D5	D#5	66	F# 3	54	F# 2			Tambourine			Car Passing	Lion
E5		67	G 3	55	G 2			Splash Cymbal			Car Crash	Scratch
F5	F#5	68	G# 3	56	G# 2			Cowbell			Siren	Yo!
G5	G#5	69	A 3	57	A 2			Crash Cymbal 2	Hand Cym. H			Train
A5	A#5	70	A# 3	58	A# 2			Vibraslap			Jet Plane	Get up!
B5		71	B 3	59	B 2			Ride Cymbal 2	Hand Cym.Short H		Starship	Whoow!
C6		72	C 4	60	C 3			Bongo H			Burst	
D6		73	C# 4	61	C# 3			Bongo L			Roller Coaster	
E6		74	D 4	62	D 3			Conga H Mute			Submarine	
F6		75	D# 4	63	D# 3			Conga H Open				
G6		76	E 4	64	E 3			Conga L				
A6		77	F 4	65	F 3			Timbale H				
B6		78	F# 4	66	F# 3			Timbale L				Huuuah!
C7		79	G 4	67	G 3			Agogo H				
D7		80	G# 4	68	G# 3			Agogo L		Shower	Laugh	
E7		81	A 4	69	A 3			Cabasa		Thunder	Scream	
F7		82	A# 4	70	A# 3			Maracas		Wind	Punch	
G7		83	B 4	71	B 3	O		Samba Whistle H		Stream	Heartbeat	
A7		84	C 5	72	C 4	O		Samba Whistle L		Bubble	Footsteps	
B7		85	C# 5	73	C# 4			Guiro Short		Feed		
C8		86	D 5	74	D 4	O		Guiro Long				
D8		87	D# 5	75	D# 4			Claves				
E8		88	E 5	76	E 4			Wood Block H				
F8		89	F 5	77	F 4			Wood Block L				
G8		90	F# 5	78	F# 4			Cuica Mute				Uh!+Hit
A8		91	G 5	79	G 4			Cuica Open				
B8		92	G# 5	80	G# 4		2	Triangle Mute				
C9		93	A 5	81	A 4		2	Triangle Open				
D9		94	A# 5	82	A# 4			Shaker				
E9		95	B 5	83	B 4			Jingle Bell				
F9		96	C 6	84	C 5			Bell Tree		Dog	Machine Gun	
G9		97	C# 6	85	C# 5					Horse	Laser Gun	
A9		98	D 6	86	D 5					Bird Tweet 2	Explosion	
B9		99	D# 6	87	D# 5						Firework	
C10		100	E 6	88	E 5							
D10		101	F 6	89	F 5							
E10		102	F# 6	90	F# 5							
F10		103	G 6	91	G 5				Maou			

Style List






















Style No.	Style Name
8 Beat	
001	8BeatModern
002	60'sGtrPop
003	8BeatAdria
004	60's8Beat
005	8Beat
006	OffBeat
007	60'sRock
008	HardRock
009	RockShuffle
010	8BeatRock
16 Beat	
011	16Beat
012	PopShuffle
013	GuitarPop
014	16BtUptempo
015	KoolShuffle
016	HipHopLight
Ballad	
017	PianoBallad
018	LoveSong
019	6/8ModernEP
020	6/8SlowRock
021	OrganBallad
022	PopBallad
023	16BeatBallad
Dance	
024	EuroTrance
025	Ibiza
026	SwingHouse
027	Clubdance
028	ClubLatin
029	Garage1
030	Garage2
031	TechnoParty
032	UKPop
033	HipHopGroove
034	HipShuffle
035	HipHopPop
Disco	
036	70'sDisco
037	LatinDisco
038	SaturdayNight
039	DiscoHands

Style No.	Style Name
Swing & Jazz	
040	BigBandFast
041	BigBandBallad
042	JazzClub
043	Swing1
044	Swing2
045	Five/Four
046	Dixieland
047	Ragtime
R & B	
048	Soul
049	DetroitPop
050	6/8Soul
051	CrocoTwist
052	Rock&Roll
053	ComboBoogie
054	6/8Blues
Country	
055	CountryPop
056	CountrySwing
057	Country2/4
058	Bluegrass
Latin	
059	BrazilianSamba
060	BossaNova
061	Tijuana
062	DiscoLatin
063	Mambo
064	Salsa
065	Beguine
066	Reggae
Ballroom	
067	VienneseWaltz
068	EnglishWaltz
069	Slowfox
070	Foxtrot
071	Quickstep
072	Tango
073	Pasodoble
074	Samba
075	ChaChaCha
076	Rumba
077	Jive

Style No.	Style Name
Traditional	
078	USMarch
079	6/8March
080	GermanMarch
081	PolkaPop
082	OberPolka
083	Tarantella
084	Showtune
085	ChristmasSwing
086	ChristmasWaltz
087	ScottishReel
Waltz	
088	SwingWaltz
089	JazzWaltz
090	CountryWaltz
091	OberWalzer
092	Musette
Children	
093	Learning2/4
094	Learning4/4
095	Learning6/8
096	Fun 3/4
097	Fun 4/4
Pianist	
098	Stride
099	PianoSwing
100	PianoBoogie
101	Arpeggio
102	Habanera
103	SlowRock
104	8BeatPianoBallad
105	6/8PianoMarch
106	PianoWaltz

Effect Type List

● Harmony Types

No.	Harmony Type	Description	
01	Duet	If you want to sound one of the harmony types 01-05, play keys to the right side of the Split Point while playing chords in the left side of the keyboard after turning Auto Accompaniment on. One, two or three notes of harmony are automatically added to the note you play. When playing back a Song that includes chord data, harmony is applied whichever keys are played.	
02	Trio		
03	Block		
04	Country		
05	Octave		
06	Trill 1/4 note		If you keep holding down two different notes, the notes alternate (in a trill) continuously.
07	Trill 1/6 note		
08	Trill 1/8 note		
09	Trill 1/12 note		
10	Trill 1/16 note		
11	Trill 1/24 note		
12	Trill 1/32 note		If you keep holding down a single note, the note is repeated continuously. (The repeat speed differs depending on the selected type.)
13	Tremolo 1/4 note		
14	Tremolo 1/6 note		
15	Tremolo 1/8 note		
16	Tremolo 1/12 note		
17	Tremolo 1/16 note		
18	Tremolo 1/24 note		If you keep holding down a note, echo is applied to the note played. (The echo speed differs depending on the selected type.)
19	Tremolo 1/32 note		
20	Echo 1/4 note		
21	Echo 1/6 note		
22	Echo 1/8 note		
23	Echo 1/12 note		
24	Echo 1/16 note		
25	Echo 1/24 note		
26	Echo 1/32 note		

● Reverb Types

No.	Reverb Type	Description
01-03	Hall 1-3	Concert hall reverb.
04-05	Room 1-2	Small room reverb.
06-07	Stage 1-2	Reverb for solo instruments.
08-09	Plate 1-2	Simulated steel plate reverb.
10	Off	No effect.

● Chorus Types

No.	Chorus Type	Description
1-2	Chorus 1-2	Conventional chorus program with rich, warm chorusing.
3-4	Flanger 1-2	This produces a rich, animated wavering effect in the sound.
5	Off	No effect.

MIDI Implementation Chart

YAMAHA [PORTATONE] Date:15-Nov-2004
 Model YPT-300/PSR-E303 MIDI Implementation Chart Version:1.0

Function...	Transmitted	Recognized	Remarks
Basic Channel Default Changed	1 - 16 x	1 - 16 x	
Mode Default Messages Altered	3 x *****	3 x x	
Note Number : True voice	0 - 127 *****	0 - 127 0 - 127	
Velocity Note ON Note OFF	0 9nH, v=1-127 x	0 9nH, v=1-127 x	
After Touch Key's Ch's	x x	x x	
Pitch Bend	x	o	
0, 32	o	o	Bank Select
1	x *1	o	Modulation wheel
6	x *1	o	Data Entry (MSB)
38	x *1	x	Data Entry (LSB)
7, 10	o	o	
11	x *1	o	Expression
64	o	o	Sustain
71, 73, 74	x *1	o	

72	o				o	Release Time
84	x	*1			o	Portamento Cntrl
91,93	o				o	Effect 1,3 Depth
96,97	x				o	RPN Inc,Dec
100,101	x				o	RPN LSB,MSB
Prog Change : True #	o	0 - 127	o	0 - 127		
System Exclusive	o	*****				
: Song Pos.	x				x	
: Song Sel.	x				x	
: Tune	x				x	
System : Clock	o				o	
Real Time: Commands	o				o	
Aux :All Sound OFF	x				o	(120,126,127)
:Reset All Cntrls	x				o	(121)
:Local ON/OFF	x				o	(122)
:All Notes OFF	x				o	(123-125)
Mes- :Active Sense	o				o	
sages:Reset	x				x	

*1 Refer to #2 on page 78.

Mode 1 : OMNI ON , POLY Mode 2 : OMNI ON , MONO o : Yes
 Mode 3 : OMNI OFF , POLY Mode 4 : OMNI OFF , MONO x : No

Specifications

Keyboards

- 61 standard-size keys (C1-C6), with Touch Response

Display

- LCD display (backlit)

Setup

- STANDBY/ON
- MASTER VOLUME: MIN-MAX

Panel Controls

- [L]/[REC TRACK 2], [R]/[REC TRACK 1], [LISTEN & LEARN], [TIMING], [WAITING], [A-B REPEAT]/[ACMP ON/OFF], [REW]/[INTRO/ENDING/rit.], [FF]/[MAIN/AUTO FILL], [TEMPO/TAP], [REC], [PAUSE]/[SYNC START], [START/STOP], [SONG], [STYLE], [VOICE], [FUNCTION], [PORTABLE GRAND], [SOUND EFFECT KIT], [REVERB ON/OFF], [DEMO], [METRONOME ON/OFF], [SPLIT ON/OFF], [DUAL ON/OFF], [HARMONY ON/OFF], [TOUCH ON/OFF], number buttons [0]-[9], [+]/YES, [-]/NO

Voice

- 108 panel voices + 12 drum kits + 1 sound effect kit + 359 XGlite voices + 2 XGlite optional voices
- Polyphony: 32
- DUAL
- SPLIT

Style

- 106 preset Styles
- Style Control:
 - ACMP ON/OFF, SYNC START, START/STOP, INTRO/ENDING/rit., MAIN/AUTO FILL
- Fingering: Multi fingering
- Style Volume

Education Feature

- Chord Dictionary
- Lesson 1-3

Function

- Style Volume, Song Volume, Transpose, Tuning, Split Point, Touch Sensitivity, Main voice (Volume, Octave, Chorus Send Level), Dual voice (Voice, Volume, Octave, Chorus Send Level), Split voice (Voice, Volume, Octave, Chorus Send Level), Reverb Type, Reverb level, Chorus Type, Panel Sustain, Harmony Type, Harmony Volume, PC mode (PC1/PC2/Off), Local On/Off, External Clock, Initial Setup Send, Time Signature, Metronome Volume, Lesson Track (R), Lesson Track (L), Demo Cancel

Effects

- Reverb: 9 types
- Chorus: 4 types
- Harmony: 26 types

Song

- 102 Preset Songs + 5 User Songs + Flash Memory
- Song Clear
- Song Volume

Recording

- Song
 - User Song: 5 Songs
 - Recording Tracks: 1, 2

MIDI

- Local On/Off
- Initial Setup Send
- External Clock
- PC mode

Auxiliary jacks

- PHONES/OUTPUT, DC IN 12V, MIDI IN/OUT, SUSTAIN

Amplifier

- 2.5W + 2.5W

Speakers

- 12cm x 2

Power Consumption

- 10W (When using PA-3C power adaptor)

Power Supply

- Adaptor: Yamaha PA-3B/3C AC power adaptor
- Batteries: Six "AA" size, LR6 or equivalent batteries

Dimensions (W x D x H)

- 945 x 370 x 128 mm
(37-1/4" x 14-5/8" x 5-1/16")

Weight

- 4.9kg (10 lbs. 13 oz.) (not including batteries)

Supplied Accessories

- Music Rest
- Owner's Manual

Optional Accessories

- AC Power Adaptor: PA-3B/PA-3C
- USB-MIDI Interface: UX16
- Footswitch: FC4/FC5
- Keyboard Stand: L-2C/L-2L
- Headphones: HPE-150/HPE-30

* Specifications and descriptions in this owner's manual are for information purposes only. Yamaha Corp. reserves the right to change or modify products or specifications at any time without prior notice. Since specifications, equipment or options may not be the same in every locale, please check with your Yamaha dealer.

Panel Controls and Terminals

A-B REPEAT button	39
ACMP ON/OFF button	23
DEMO button	21
DUAL ON/OFF button	13
FF button	21
FUNCTION button	31, 56
HARMONY ON/OFF button	40
INTRO/ENDING/rit. Button	49
L button	34
LISTEN & LEARN button	34
MAIN/AUTO FILL button	49
MASTER VOLUME control	9, 30
METRONOME ON/OFF button	18
number buttons 0-9, +/YES, -/NO	31
PAUSE button	21
PORTABLE GRAND button	15
R button	34
REC button	25
REC TRACK 1 button	27
REC TRACK 2 button	27
REVERB ON/OFF button	41
REW button	21
SONG button	20, 31
SOUND EFFECT KIT button	17
SPLIT ON/OFF button	14
STANDBY/ON switch	9, 30
START/STOP button	30
STYLE button	22, 31
SYNC START button	23
TEMPO/TAP button	46
TIMING button	35
TOUCH ON/OFF button	43
VOICE button	12, 31
WAITING button	36
DC IN 12V jack	8
MIDI IN/OUT terminal	58
PHONES/OUTPUT jack	9
SUSTAIN jack	9

Alphabetical Order

A	
AB Repeat	39
AC Power Adaptor	8
ACMP ON/OFF	23
Auto Accompaniment	23
Auto accompaniment range	23-24
B	
Backup	29
Backup Clear	29
Battery	8
Beat Display	32
C	
Cancel	28
Chord	24, 52-53, 55
Chord Dictionary	54
Chord Display	32, 53
Chorus	42
Chorus Send Level (Dual)	57
Chorus Send Level (Main)	57
Chorus Send Level (Split)	57
Chorus Type List	75
Computer	59-63
D	
Delete (Song)	28
Demo	21
Display	32
Drum Kit	15
Drum Kit List	71
Dual	13
E	
Ending	48, 50
External Clock	57, 60
F	
FF	21
Flash Clear	29
Flash Memory	63
Footswitch (Sustain jack)	9
Function Setting List	56-57
G	
Grade	35
H	
Harmony	40-41
Harmony Type List	75
Harmony Volume	57

- I**
- Initial Send 57
 - Initialization 29
 - Intro 47, 50
- K**
- Keyboard Display 32
- L**
- Lesson 33-36
 - Lesson track R/L for transferred songs 57, 63
 - Local 57, 59
- M**
- Main/Auto fill 49-50
 - Master Volume Control 9, 30
 - Measure 32
 - Melody Voice 37
 - Metronome 18-19
 - Metronome Volume 19
 - MIDI 58
 - Music Rest 6
 - Musicsoft Downloader 61-62
 - Mute 38
- N**
- NO 28
 - Notation 32
- O**
- Octave (Dual) 57
 - Octave (Main) 57
 - Octave (Split) 57
 - One Touch Setting 45
 - Option 79
- P**
- Panel Sustain 42
 - Part 34
 - Pause 21
 - PC setting 60
 - Press and Hold for a while 30
- R**
- Recording 25-27
 - Remote Control 61
 - Reverb 41
 - Reverb Level 57
 - Reverb Type List 75
 - Rew 21
 - Rhythm 22
 - Root 52, 54
- S**
- Save data to computer 63
 - SMF Format 0 61
 - Song 20
 - Song List 21
 - Song Volume 37
 - Split 14
 - Split Point 14, 44
 - Start 30
 - Stop 30
 - Style 22-23, 47-50
 - Style List 74
 - Style Volume 51
 - Supplied Accessories 6, 79
 - Synchro Start 23, 47
- T**
- Tempo 46
 - Time Signature 19
 - Touch Response 43
 - Touch sensitivity 43
 - Track 26, 32, 38
 - Track Rec 26-27
 - Transfer 59, 63
 - Transpose 44
 - Tuning 45
 - Turn Auto accompaniment on or off 23
- U**
- User File 63
 - User Song 25-26
- V**
- Voice 12-14
 - Voice List 65
- X**
- XGlite 6
- Y**
- YES 28

Limited Warranty

90 DAYS LABOR

1 YEAR PARTS

Yamaha Corporation of America, hereafter referred to as Yamaha, warrants to the original consumer of a product included in the categories listed below, that the product will be free of defects in materials and/or workmanship for the periods indicated. This warranty is applicable to all models included in the following series of products:

PSR, YPT SERIES OF PORTATONE ELECTRONIC KEYBOARDS

If during the first 90 days that immediately follows the purchase date, your new Yamaha product covered by this warranty is found to have a defect in material and/or workmanship, Yamaha and/or its authorized representative will repair such defect without charge for parts or labor.

If parts should be required after this 90 day period but within the one year period that immediately follows the purchase date, Yamaha will, subject to the terms of this warranty, supply these parts without charge. However, charges for labor, and/or any miscellaneous expenses incurred are the consumers responsibility. Yamaha reserves the right to utilize reconditioned parts in repairing these products and/or to use reconditioned units as warranty replacements.

THIS WARRANTY IS THE ONLY EXPRESS WARRANTY WHICH YAMAHA MAKES IN CONNECTION WITH THESE PRODUCTS. ANY IMPLIED WARRANTY APPLICABLE TO THE PRODUCT, INCLUDING THE WARRANTY OF MERCHANT ABILITY IS LIMITED TO THE DURATION OF THE EXPRESS WARRANTY. YAMAHA EXCLUDES AND SHALL NOT BE LIABLE IN ANY EVENT FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES.

Some states do not allow limitations that relate to implied warranties and/or the exclusion of incidental or consequential damages. Therefore, these limitations and exclusions may not apply to you.

This warranty gives you specific legal rights. You may also have other rights which vary from state to state.

CONSUMERS RESPONSIBILITIES

If warranty service should be required, it is necessary that the consumer assume certain responsibilities:

1. Contact the Customer Service Department of the retailer selling the product, or any retail outlet authorized by Yamaha to sell the product for assistance. You may also contact Yamaha directly at the address provided below.
2. Deliver the unit to be serviced under warranty to: the retailer selling the product, an authorized service center, or to Yamaha with an explanation of the problem. Please be prepared to provide proof purchase date (sales receipt, credit card copy, etc.) when requesting service and/or parts under warranty.
3. Shipping and/or insurance costs are the consumers responsibility.* Units shipped for service should be packed securely.

*Repaired units will be returned PREPAID if warranty service is required within the first 90 days.

IMPORTANT: Do NOT ship anything to ANY location without prior authorization. A Return Authorization (RA) will be issued that has a tracking number assigned that will expedite the servicing of your unit and provide a tracking system if needed.

4. Your owners manual contains important safety and operating instructions. It is your responsibility to be aware of the contents of this manual and to follow all safety precautions.

EXCLUSIONS

This warranty does not apply to units whose trade name, trademark, and/or ID numbers have been altered, defaced, exchanged removed, or to failures and/or damages that may occur as a result of:

1. Neglect, abuse, abnormal strain, modification or exposure to extremes in temperature or humidity.
2. Improper repair or maintenance by any person who is not a service representative of a retail outlet authorized by Yamaha to sell the product, an authorized service center, or an authorized service representative of Yamaha.
3. This warranty is applicable only to units sold by retailers authorized by Yamaha to sell these products in the U.S.A., the District of Columbia, and Puerto Rico. This warranty is not applicable in other possessions or territories of the U.S.A. or in any other country.

Please record the model and serial number of the product you have purchased in the spaces provided below.

Model _____ Serial # _____ Sales Slip # _____

Purchased from _____ Date _____
(Retailer)

YAMAHA CORPORATION OF AMERICA
Electronic Service Division
6600 Orangethorpe Avenue
Buena Park, CA 90620

KEEP THIS DOCUMENT FOR YOUR RECORDS. DO NOT MAIL!

For details of products, please contact your nearest Yamaha representative or the authorized distributor listed below.

Pour plus de détails sur les produits, veuillez-vous adresser à Yamaha ou au distributeur le plus proche de vous figurant dans la liste suivante.

Die Einzelheiten zu Produkten sind bei Ihrer unten aufgeführten Niederlassung und bei Yamaha Vertragshändlern in den jeweiligen Bestimmungsländern erhältlich.

Para detalles sobre productos, contacte su tienda Yamaha más cercana o el distribuidor autorizado que se lista debajo.

NORTH AMERICA

CANADA

Yamaha Canada Music Ltd.
135 Milner Avenue, Scarborough, Ontario,
M1S 3R1, Canada
Tel: 416-298-1311

U.S.A.

Yamaha Corporation of America
6600 Orangethorpe Ave., Buena Park, Calif. 90620,
U.S.A.
Tel: 714-522-9011

CENTRAL & SOUTH AMERICA

MEXICO

Yamaha de México S.A. de C.V.
Calz. Javier Rojo Gómez #1149,
Col. Guadalupe del Moral
C.P. 09300, México, D.F., México
Tel: 55-5804-0600

BRAZIL

Yamaha Musical do Brasil Ltda.
Av. Reboucas 2636-Pinheiros CEP: 05402-400
Sao Paulo-SP, Brasil
Tel: 011-3085-1377

ARGENTINA

Yamaha Music Latin America, S.A.
Sucursal de Argentina
Viamonte 1145 Piso2-B 1053,
Buenos Aires, Argentina
Tel: 1-4371-7021

PANAMA AND OTHER LATIN AMERICAN COUNTRIES/ CARIBBEAN COUNTRIES

Yamaha Music Latin America, S.A.
Torre Banco General, Piso 7, Urbanización Marbella,
Calle 47 y Aquilino de la Guardia,
Ciudad de Panamá, Panamá
Tel: +507-269-5311

EUROPE

THE UNITED KINGDOM

Yamaha-Kemble Music (U.K.) Ltd.
Sherbourne Drive, Tilbrook, Milton Keynes,
MK7 8BL, England
Tel: 01908-366700

IRELAND

Danfay Ltd.
61D, Sallynoggin Road, Dun Laoghaire, Co. Dublin
Tel: 01-2859177

GERMANY

Yamaha Music Central Europe GmbH
Siemensstraße 22-34, 25462 Rellingen, Germany
Tel: 04101-3030

SWITZERLAND/LIECHTENSTEIN

Yamaha Music Central Europe GmbH,
Branch Switzerland
Seefeldstrasse 94, 8008 Zürich, Switzerland
Tel: 01-383 3990

AUSTRIA

Yamaha Music Central Europe GmbH,
Branch Austria
Schleiergasse 20, A-1100 Wien, Austria
Tel: 01-60203900

POLAND

Yamaha Music Central Europe GmbH
Sp.z o.o. Oddzial w Polsce
ul. 17 Stycznia 56, PL-02-146 Warszawa, Poland
Tel: 022-868-07-57

THE NETHERLANDS

Yamaha Music Central Europe,
Branch Nederland
Clarissenhof 5-b, 4133 AB Vianen, The Netherlands
Tel: 0347-358 040

BELGIUM/LUXEMBOURG

Yamaha Music Central Europe GmbH,
Branch Belgium
Rue de Geneve (Genevastraat) 10, 1140 - Brussels,
Belgium
Tel: 02-726 6032

FRANCE

Yamaha Musique France
BP 70-77312 Marne-la-Vallée Cedex 2, France
Tel: 01-64-61-4000

ITALY

Yamaha Musica Italia S.P.A.
Viale Italia 88, 20020 Lainate (Milano), Italy
Tel: 02-935-771

SPAIN/PORTUGAL

Yamaha-Hazen Música, S.A.
Ctra. de la Coruna km. 17, 200, 28230
Las Rozas (Madrid), Spain
Tel: 91-639-8888

GREECE

Philippos Nakas S.A. The Music House
147 Skiathou Street, 112-55 Athens, Greece
Tel: 01-228 2160

SWEDEN

Yamaha Scandinavia AB
J. A. Wettergrens Gata 1
Box 30053
S-400 43 Göteborg, Sweden
Tel: 031 89 34 00

DENMARK

YS Copenhagen Liaison Office
Generatorvej 6A
DK-2730 Herlev, Denmark
Tel: 44 92 49 00

FINLAND

F-Musiikki Oy
Kluuvikatu 6, P.O. Box 260,
SF-00101 Helsinki, Finland
Tel: 09 618511

NORWAY

Norsk filial av Yamaha Scandinavia AB
Grini Næringspark 1
N-1345 Østerås, Norway
Tel: 67 16 77 70

ICELAND

Skifan HF
Skeifan 17 P.O. Box 8120
IS-128 Reykjavik, Iceland
Tel: 525 5000

OTHER EUROPEAN COUNTRIES

Yamaha Music Central Europe GmbH
Siemensstraße 22-34, 25462 Rellingen, Germany
Tel: +49-4101-3030

AFRICA

Yamaha Corporation,
Asia-Pacific Music Marketing Group
Nakazawa-cho 10-1, Hamamatsu, Japan 430-8650
Tel: +81-53-460-2312

MIDDLE EAST

TURKEY/CYPRUS

Yamaha Music Central Europe GmbH
Siemensstraße 22-34, 25462 Rellingen, Germany
Tel: 04101-3030

OTHER COUNTRIES

Yamaha Music Gulf FZE
LB21-128 Jebel Ali Freezone
P.O.Box 17328, Dubai, U.A.E.
Tel: +971-4-881-5868

ASIA

THE PEOPLE'S REPUBLIC OF CHINA

Yamaha Music & Electronics (China) Co.,Ltd.
25/F., United Plaza, 1468 Nanjing Road (West),
Jingan, Shanghai, China
Tel: 021-6247-2211

HONG KONG

Tom Lee Music Co., Ltd.
11/F., Silvercord Tower 1, 30 Canton Road,
Tsimshatsui, Kowloon, Hong Kong
Tel: 2737-7688

INDONESIA

PT. Yamaha Music Indonesia (Distributor)
PT. Nusantara
Gedung Yamaha Music Center, Jalan Jend. Gatot
Subroto Kav. 4, Jakarta 12930, Indonesia
Tel: 21-520-2577

KOREA

Yamaha Music Korea Ltd.
Tong-Yang Securities Bldg. 16F 23-8 Yoido-dong,
Youngdungpo-ku, Seoul, Korea
Tel: 02-3770-0660

MALAYSIA

Yamaha Music Malaysia, Sdn., Bhd.
Lot 8, Jalan Perbandaran, 47301 Kelana Jaya,
Petaling Jaya, Selangor, Malaysia
Tel: 3-78030900

PHILIPPINES

Yupangco Music Corporation
339 Gil J. Puyat Avenue, P.O. Box 885 MCPO,
Makati, Metro Manila, Philippines
Tel: 819-7551

SINGAPORE

Yamaha Music Asia Pte., Ltd.
#03-11 A-Z Building
140 Paya Lebar Road, Singapore 409015
Tel: 747-4374

TAIWAN

Yamaha KHS Music Co., Ltd.
3F, #6, Sec.2, Nan Jing E. Rd. Taipei.
Taiwan 104, R.O.C.
Tel: 02-2511-8688

THAILAND

Siam Music Yamaha Co., Ltd.
891/1 Siam Motors Building, 15-16 floor
Rama 1 road, Wangmai, Pathumwan
Bangkok 10330, Thailand
Tel: 02-215-2626

OTHER ASIAN COUNTRIES

Yamaha Corporation,
Asia-Pacific Music Marketing Group
Nakazawa-cho 10-1, Hamamatsu, Japan 430-8650
Tel: +81-53-460-2317

OCEANIA

AUSTRALIA

Yamaha Music Australia Pty. Ltd.
Level 1, 99 Queensbridge Street, Southbank,
Victoria 3006, Australia
Tel: 3-9693-5111

NEW ZEALAND

Music Houses of N.Z. Ltd.
146/148 Captain Springs Road, Te Papapa,
Auckland, New Zealand
Tel: 9-634-0099

COUNTRIES AND TRUST TERRITORIES IN PACIFIC OCEAN

Yamaha Corporation,
Asia-Pacific Music Marketing Group
Nakazawa-cho 10-1, Hamamatsu, Japan 430-8650
Tel: +81-53-460-2312

HEAD OFFICE Yamaha Corporation, Pro Audio & Digital Musical Instrument Division
Nakazawa-cho 10-1, Hamamatsu, Japan 430-8650
Tel: +81-53-460-3273



Yamaha PK CLUB (Portable Keyboard Home Page, English Only)
<http://www.yamahaPKclub.com/>

Yamaha Manual Library
<http://www.yamaha.co.jp/manual/english/>

U.R.G., Pro Audio & Digital Musical Instrument Division, Yamaha Corporation
© 2005 Yamaha Corporation

A0
???PO???.?-01

WD56610 Printed in China