



***DYMO Label
Software
User Guide***

Version 7

DYMO Corporation
44 Commerce Road
Stamford, CT 06902-4561
Phone: (203) 355-9000
Fax: (203) 355-9090

Equipment Information

Description: Direct Thermal Printer

Models: LabelWriter 300, 310, 320, 330, 330 Turbo, 400, 400 Turbo, Twin Turbo, Duo

Certification

This device has been tested and complies with the requirements of:

UL 1950

EN60950: Low Voltage Directive Product Safety

FCC Part 15 Class B

EN55022: Radiated and Conducted Emissions B

EN50082-1: Generic Immunity ESD, RF, and Transient Susceptibility

Copyright

© 2004-2005 DYMO Corporation. All rights reserved. Version 7.2 Revised 05/05.

No part of this document or the software may be reproduced or transmitted in any form or by any means or translated into another language without the prior written consent of DYMO Corporation.

Trademarks

LabelWriter is a registered trademark of DYMO Corporation. DYMO is a registered trademark of Esselte Corporation. All other trademarks are the property of their respective holders.

Contents

Chapter 1

Introduction	1
Software	1
Hardware	1
Labels	1
Installing the LabelWriter	2
Registering the Software	2
Getting Help	2

Chapter 2

Getting Started	3
The Label Editor	3
Creating a New Label	4

Chapter 3

Using the Label Designer	11
Starting the Designer	11
Design Objects	11
Creating a New Label File	13
Opening an Existing Label File	13
Adding an Object	14
Deleting Objects	14

Chapter 4

Working with Lists	15
How the Address Book Works	15
Using the Address Book	16
Creating a New List	17
Opening an Existing List	17
Using the Mac OS Address Book (Macintosh)	18

Chapter 5

Printing Labels Using Smart Paste	19
About Smart Paste	19
Printing Multiple Labels Using Smart Paste	21

Chapter 6
Using the LabelWriter Printer with Other Applications 23

- Add-In for Microsoft Word 23
- Additional Windows Application Add-Ins 24
- Printing Directly from Other Applications 25

Chapter 7
Using the Tape Editor 27

- The Tape Editor 27
- Designing a Label 28
- Printing from Other Applications 34
- Print Settings 36

Chapter 8
Maintenance and Troubleshooting 41

- Caring for the LabelWriter Printer 41
- Performing a Printer Self-Test 42
- Obtaining Technical Support 42

Appendix A
Technical Specifications 45

- Printer Specifications 45
- Developer and SDK Information 46
- Documentation Feedback 46

Chapter 1

Introduction

Congratulations on purchasing the DYMO LabelWriter® printer. After just a short time, you will realize how many of your daily tasks will be simplified by using the LabelWriter printer.

Your LabelWriter printer will help you to address letters; label file folders, CD/DVDs, video cassettes, packages, and name tags. With a little imagination, you will think of hundreds of ways to use the LabelWriter printer to make your job easier and more efficient.

This User Guide provides instructions for DYMO Label Software on the Windows and Macintosh platforms. For the most part, the software operates in the same way on both platforms. Any differences in features, procedures, or commands are noted within the text.

Software

DYMO Label Software includes many features that make it flexible and easy to use. The software now contains two editors: Label Editor and Tape Editor. The Label Editor is much the same as previous versions of the software, allowing you to design and print DYMO die-cut labels.

With this release, DYMO Label Software includes a Tape Editor, allowing you to design and print labels on D1 tape printers. The Tape Editor is only available if you have a DYMO tape printer installed on your computer, such as the DYMO LabelWriter Duo. For instructions on using the Tape Editor, see *Chapter 7, Using the Tape Editor* on page 27.

In addition, DYMO has integrated the Label Software into Microsoft® Word allowing you to print labels quickly and easily from within Word. For Windows, the software has also been integrated with Microsoft® Outlook®, Palm™ Desktop, and WordPerfect®.

Hardware

The LabelWriter printer uses advanced *thermal* printing technology to print on specially treated labels. This means you will never have to replace toner, ink cartridges, or a ribbon to print labels.

Direct thermal printing works by transferring heat from a thermal print head to specially treated labels. The thermal print head contains a row of miniature heating elements that press against the treated label. As a heating element touches the specially treated label, a thermal reaction causes the specific point on the label to turn black.

Labels

The only supplies you will ever need for this printer are the labels. We recommend you only use DYMO-brand labels. Using labels other than DYMO-brand labels may void your warranty.

How long your labels will last depends on how the labels are used. Thermal labels are susceptible to fading in two ways:

- Exposure to direct sunlight, to fluorescent light for an extended period of time, or to extreme heat will cause fading.
- Contact with plasticizers (for example, labels placed on plastic ring binders) will cause fading.

In its original packaging, the label shelf life is 18 months. When labels are used for short-term applications (envelopes, packages, and so on), fading is not a problem. When labels are used to label files in a file cabinet, fading is very gradual over many years. Labels applied to the edge of a notebook that is then placed on a shelf in the sun will show signs of fading within a few months.

To prolong label life when not in use, keep the labels stored in a cool, dry place and in the black bag in which they were shipped.

Installing the LabelWriter

Your LabelWriter printer shipped with a *Quick Start Guide* in addition to this User Guide. Follow the instructions in the *Quick Start Guide* to install your printer and DYMO Label Software.

Registering the Software

We highly recommend that you register your DYMO Label Software so that you can receive customer support and product updates.

Both Windows and Macintosh users can register the software by selecting **Register** from the **Help** menu. However, the first time Windows users start DYMO Label Software, you will be asked to register. If you choose not to register the software at this time, you will be prompted the next several times you start the program.

To register the software

- 1 Complete all of the required fields on the registration form.
- 2 Choose to register over the Internet or print the registration form for mail or fax registration. If you register over the Internet, wait a few seconds while your information is sent to DYMO.
- 3 To register by mail or fax, print the completed registration form, and mail or fax the form to the location printed on the form.


Getting Help

Before making labels, you should know about the various help resources available to you. DYMO Label Software includes extensive online Help. At times in this manual you will be directed to the online Help for more detail or instructions on various topics.

To access the online Help, do one of the following

- ▶ In DYMO Label Software, click **Help Contents** from the **Help** menu.
- ▶ (Windows) Click **Start**, point to **Programs > DYMO Label**, and then click **Help with DYMO Label Software**.
- ▶ (Windows) Press **F1** in most windows and dialog boxes for context-sensitive help.

(Windows) The **DYMO Label** menu also includes **Internet Shortcuts** that access specific areas of the DYMO Web site, including label ordering, support, and more.



These shortcuts are also available from the **Help** menu in DYMO Label Software.

Chapter 2

Getting Started

DYMO Label Software is a general-purpose label printing program that is specifically designed to help you get the most benefit from your LabelWriter printer. The program includes:

- Many pre-designed labels for commonly used tasks
- A built-in Designer you can use to create your own label designs (see page 11)
- A built-in Address Book that lets you save addresses or other types of lists (see page 15)
- Add-ins to print directly from the following programs:
 - Microsoft Word
 - Microsoft Outlook (Windows only)
 - Palm Desktop (Windows only)
 - WordPerfect (Windows only)
- A Smart Paste function allowing you to automatically print multiple labels by copying text from other applications directly into the current label (see page 19)
- Database connectivity allowing you to print from an Access, Paradox, dBase, or Excel database (see page 25) (Windows only)

The Label Editor

This section introduces some basic features available in the Label Editor.


To start the software in Windows

- ▶ Click **Start**, point to **Programs > DYMO Label**, and then click **DYMO Label**.

To start the software in Mac OS X

- ▶ Open the **DYMO Label** folder and double-click .

The DYMO Label Software window appears containing a blank label.



For Windows users, the first time you open DYMO Label Software, you are prompted to register the software. See "Registering the Software" on page 2. All users are also asked to enter a return address and select a default logo, such as your company's logo.

Creating a New Label

This tutorial guides you through the steps necessary to create, print, and save a customized label. The best way to start is to learn how to modify one of the pre-designed labels included with the software. In this tutorial, you will customize a shipping label with a graphic.

NOTE You can print the shipping label on most of the LabelWriter printers. If you have a LabelWriter 300 printer, select this shipping label and follow the tutorial anyway. This tutorial will give you valuable information on how to access the various text and design objects, and change their attributes.


Choosing a Label File

The first step is to choose a label file as the basis for your new label.

To choose a label file

- 1 Select the arrow next to the **Label Files** drop-down list.


A list of the most recently used label files appears.



If necessary, click **More** to access all the pre-designed labels. Notice that all label files are listed with the label type first, then any important objects on the label, and finally the part number of the label.

- 2 Select the **Shipping with graphic (30256)** label.

The **Shipping with graphic** label appears in the main window.




Changing the Graphic

The next step is to customize the graphic. As you will see in this step, each piece of information on a label is an object (for example, the return address, the recipient address, the line, and so on).


When you double-click an object, a Settings dialog box appears where you can change the object's attributes.

To change the graphic


- 1 Double-click the graphic that appears on the label.
The **Graphic Settings** dialog box appears.



- 2 Select **File** under **Select Graphics Source**.
The **Insert Image** button changes to read **Select File**.
- 3 Click **Select File**.
The File open dialog box appears listing the contents of the default Clipart folder.
- 4 Select the **Miscellaneous** folder and click **Open**. The contents of the Miscellaneous folder appear.
- 5 Select **Comput1.bmp** from the Miscellaneous folder.
A preview showing the contents of the Comput1.bmp graphic file appears in the dialog box.
- 6 Click **Open**.
The Comput1.bmp graphic appears in the **Graphic Settings** dialog box.



- 7 Click **OK**.
The computer graphic is placed on the label replacing the telephone graphic.




Changing the Return Address


Next, you change the return address.

To enter a return address

- 1 Click the text in the label's upper-right corner.
The flashing cursor appears where the default text had been.



- 2 Enter the following text:
COMPUTEK EUROPE B.V.
Max Euwelaan 104
3046 MA ROTTERDAM
The Netherlands
- 3 Click anywhere outside the text object.
The new return address appears on the label.



Changing the Recipient Address

Next, you enter a recipient's address.

To enter the recipient's address

- 1 Click once on the address object in the middle of the label.
The flashing cursor appears where the default text had been.
(Windows) To help identify objects, a hint appears when you move the pointer over an object.

- 2 Enter the following address.

Elsbeth Meijjer
Airportplein 7
NL-3045 AP ROTTERDAM
The Netherlands

Elsbeth Meijjer's address now appears as the recipient's address on the label.


Changing the Font

You may want to modify the font used for the recipient address or return address.

To change the font

- 1 Click the recipient address object. The address text is highlighted.
- 2 Select **Times New Roman** from the Font drop-down list.
- 3 Select **B** from the **Formatting** toolbar.

The recipient address appears in the new font and style.



Printing the Label


Now that you have customized the label, you are ready to print.

NOTE You can only print this shipping label on most LabelWriter printers. If you have a LabelWriter 300, review this section even though you will not be able to actually print the label.

Before you print the label, make sure:

- The LabelWriter printer is connected to your computer and turned on.
- You have properly loaded shipping labels in the printer. If necessary, see the *Quick Start Guide* for information on how to set up your printer and load the labels.


To print the label

- 1 Enter the number of copies of this label to print in the **Copies** field on the Main toolbar.
- 2 Click  on the Main toolbar.

Saving the Label

Now that you have created your shipping label, you can save it as a label file. Saved labels will automatically appear in the **Label Files** drop-down list.

To save the label

- 1 Click  on the Main toolbar. The **Save File** dialog box appears.
- 2 Enter **MyShip** as the new name for the file and click **Save**.

Notice that your new label file, MyShip, is added to the top of the **Label Files** drop-down list as the most recently used label and also alphabetically in the list of labels below.

To use a label file you created, choose it from the **Label Files** drop-down list.

NOTE To access your label files from the Label Files list, you must store them in the Label Files folder. A default Label Files folder is created for you when the software is installed. For Windows, the folder is located in C:\Documents and Settings\All Users\Documents\DYMO Label\Label Files. For Macintosh, the folder is located in the DYMO Label folder where you installed the application.

Now that you can open, edit, print, and save a shipping label, you are ready to modify and use most other label files.

Chapter 3


Using the Label Designer

The Label Editor allows you to easily design labels for your specific needs using a simple-to-use Label Designer. You can also modify any of the pre-designed label files included with the software. The Designer allows you to change the appearance and content of labels. You can add or modify text (including addresses), barcodes, sequential numbers, date-time stamps, lines, rectangles, and circles or ellipses (Macintosh). The following figures are examples of custom label designs.




Starting the Designer

When the Designer is active, the Designer toolbar appears below the Formatting toolbar.



To start the Label Designer, do one of the following

- ▶ Create a new label file. See "Creating a New Label" on page 4. The Designer toolbar automatically appears.
- ▶ With a label file open, click .

Design Objects

A label created in DYMO Label Software can contain various text and design objects. Each object has certain attributes, such as size, position, font, and so on. You can select the attributes that you want in the object's Settings dialog box. For more information on modifying object attributes, see the online Help.

This section describes each of the objects available on the Designer toolbar.

Text



The text object is useful for displaying information that remains unchanged every time you print a new label (for example, "Hello my name is" on name badges or your return address on shipping labels).

Text objects can also be used for *variable* text (text that changes from label to label). This is useful for part numbers, book titles, and many other non-address items you might save as a list in the Address Book. For more information on variable text, see the online Help.

Address



The address object is similar to the text object, but is designed to print information that changes with each label printed, such as names and addresses. Address objects can also display POSTNET barcodes. You can change the font settings (font, size, style, and so on) for text in address objects and control the text's position. You can also apply special effects to the text.

Address objects are by default variable text objects. Address objects can also be fixed text objects. Address text is saved as part of the label in fixed text objects. The address is not saved with the label in variable text address objects. (See "How the Address Book Works" on page 15 for more information.)

Graphic



The graphic object allows you to add your company logo and other favorite graphics to labels. You can import many popular graphic formats, position them anywhere on the label, resize them, and even specify one as the default graphic. You can also copy a graphic from a graphics application (such as Microsoft Paint or CorelDRAW), and then paste it onto a label. You can import a graphic directly from a file or (Windows only) capture an image from a video device connected to your computer.

NOTE If you defined a default logo file, the graphic file you specified is automatically displayed in any new graphic objects you add. See the online Help for information about defining a default logo file.

Lines



You can use the horizontal and vertical line objects to improve a label's appearance. Horizontal lines also function well as visual dividers on labels (for example, between the sender and recipient's address on shipping labels). You can specify the thickness of the lines, and you can also hide lines that appear on labels.

Rectangle



The rectangle object, like the line objects, is primarily used as a design element to enhance a label's appearance. A rectangle can be used to create a border around other objects. You can specify shades of gray to fill the rectangle. You can also specify the thickness of the rectangle border.

Ellipse



(Macintosh) The ellipse object, like the line objects, is primarily used as a design element to enhance a label's appearance. An ellipse can be used to create a border around other objects. You can specify shades of gray to fill the ellipse. You can also specify the thickness of the border.

Barcode



The barcode object displays and prints a barcode on your label. You can use a barcode object to display fixed information that you enter or variable information obtained from another object. When you link a barcode object to another object, the barcode object encodes the information contained in the linked object. Furthermore, if you change the information in the linked object, the barcode object automatically encodes the new information.

For example, you may want to link the barcode object to a part number text object on a label. When you update the part number in the linked text object, the barcode object is automatically updated as well.

You can choose from many standard barcode symbologies, including Code 39, Code 128, Codabar, UPC A/E, EAN 8/13, ITF-14, POSTNET, PLANET, and Interleaved 2 of 5 barcodes. You can choose to include or exclude human-readable text (alphanumeric information) and specify the font settings for the text. You can also select the barcode size and position. See the online Help for more information about the barcode symbologies supported.

Counter



The counter object automatically numbers a series of labels. For example, you could use a counter object to automatically serialize a bunch of raffle tickets. You can specify text you want to appear before and after the counter (for example, “Disk # of ten”), as well as the starting number and the increments for counting (1, 10, 100, and so on). You can also specify the font settings for the counter information, as well as other attributes.

Date-Time



The date-time object stamps the current date and/or time on labels using any one of several of pre-defined formats. As with counter objects, you can specify the text you want to appear in front of and behind the date-time (for example, “Today’s date is”). You can choose from a variety of date formats, including European formats. You can include or exclude the time and use the 24-hour time format (13:00, 22:00, and so on). You can control the font settings and other attributes for the date-time information.

Curved Text




The curved text object is similar to the text object, but allows you to place the text along a curve. This object can be used for placing text around the perimeter of a round CD label or for simply adding text in an arc on any label. You can choose to display the text as a full circle or as a semi-circle along the top or bottom of the label. You can also choose to mirror the text. As with the text object, the curved text object can be used as a variable text object and you can control the font settings and object position.

Creating a New Label File

DYMO Label Software includes a blank label file for every type of label available. When you create a new label, you select one of these blank labels as a starting point.

To create a new label


- 1 Click . The **New Label** dialog box appears.
- 2 Select a label that most closely matches the type of label you wish to create and click **OK**. The blank label opens in the label workspace and the Designer toolbar appears.

NOTE You can filter the number of labels displayed by selecting **Portrait** or **Landscape** in the **New Label** dialog box.

Opening an Existing Label File

To use a label file you have saved to disk, you simply open it. You can then print the label as is, or modify it to suit your needs. For convenience, the most recently saved label files appear at the top of the Label Files drop-down list.

To open an existing label file

- 1 Click . The **Open File** dialog box appears.
- 2 Select the file you wish to open and click **Open**.
The label opens in the label workspace.

Adding an Object

When you place a new object on a label, the new object displays certain default settings. For example, new address and text objects display text describing how to modify the objects.

Although the various types of objects are different, the steps for placing the objects on a label are nearly identical. The only difference is the tool button you select from the Designer toolbar to place the desired object.

To add an object

- 1 Click the object that you wish to add on the Designer toolbar. The new object appears in the upper-left corner of the label.
- 2 Resize and move the object where you want it on the label using the cursor.

NOTE If you defined a default logo file, the graphic file you specified appears in all new graphic objects you place. See the online Help for information about defining a default logo file.

Deleting Objects

When you delete an object, the object's contents (text, graphics, barcode, and so on) are also deleted.

To delete an object

- 1 Select the object.
- 2 Select **Cut** from the **Edit** menu.

Chapter 4

Working with Lists

DYMO Label Software includes a built-in Address Book that allows you to maintain lists of addresses routinely used to generate labels. Additionally, if you have Mac OS version 10.2 or later, you can print labels using the addresses already stored in your Mac OS address book.

You can also use the built-in Address Book to store information other than addresses. This information (for example, a list of product numbers or video titles) can be linked to a variable text object or barcode object (for example, to print a barcode label for all your product numbers).

This chapter describes how to use the built-in Address Book to create, edit, and print entries on labels. Refer to the online Help for more detailed information on using the Address Book.

How the Address Book Works

The Address Book allows you to create address or data list files. Address list entries are automatically sorted using the first line of the address. If this line is a person's name, the entry is listed and sorted by the last name. However, if the first line is a company name, the entry is sorted by the company name. Data lists are sorted by the first few characters of each entry's first line.

The Address Book items can be used with address and variable text objects. Address objects are by default variable text objects and the currently selected Address Book entry is displayed in the object. This means that the actual content that prints in an address object is not necessarily the same each time the label is printed. For example, if you select ten entries from the Address Book and then click print with an address label open, ten address labels will print, one for each selected entry in the Address Book. When you save an address label, only the formatting is saved, not a specific address. When that address label is opened the next time, the then currently selected Address Book entry appears in the address object.

You can, however, define an address object as a *fixed* address object, meaning that the actual address that is currently in the object is saved as part of the label when you save and close the label. The next time you open the label, the object contains the same address. The Fixed Address setting allows you to create and save labels for a recipient that you use frequently.


A text object normally contains static text (text that is the same each time the label prints), but it can become a variable text object by selecting the Function as Variable Text object setting. A variable text object behaves in much the same manner as an address object. A variable text object can be used to print labels from list entries. For example, you can print price tags from a parts list or name tags from an attendance list.

When you open a label with a variable address object or variable text object, the currently selected Address Book entry is automatically displayed. As you select different Address Book entries, each newly selected entry is automatically displayed in the object. If you then decide you want to print the currently selected address on a different label, just open the new label and the same address appears in that label's format (as long as the new label contains an address or variable text object). The formatting from the previous label is not copied to the new label, only the text which takes on the formatting of the new label.


Using the Address Book

The Address Book is displayed in a panel at the bottom of the DYMO Label main window. You can display or hide the panel using the Address Book button on the Action bar.

To display the Address Book

- ▶ Click  or select **Open** from the **Address Book** menu.

The last list file that was opened appears in the Address Book panel of the Main window. The first time you open the Address Book, the **Sample List** entries appear.




Using Lists with Multiple Variable Objects

You can use the Address Book to enter information into objects that can contain variable text on the current label. Variable text objects are text objects where you have selected the Variable Text field in the Text Setting dialog box, or barcode objects. If the current label contains more than one variable object, you need to select the object into which you want the selected Address Book entry to appear.

To insert address data into a label with multiple variable objects

- 1 Select the list entries you wish to print.

The Pick Variable Object dialog box appears listing the objects available on the current label.



- 2 Select the object you want to link to the Address Book and then click **OK**.

If the current label does not contain a variable object, you are prompted to open a label that does contain one of these objects. This prompt appears because the program automatically links Address Book entries to variable objects. You can still work in Address Book without a variable object on the current label, but Address Book will not link to the current label.

Rotating Names in Address Lists

The Address Book automatically sorts addresses by the last name. For example, if you enter the following address:

Elsbeth Meijjer
 Airportplein 7
 NL-3045 AP ROTTERDAM
 The Netherlands

The Address Book displays **Meijjer, Elsbeth** in the **Entries** list.

In some cases, the Address Book incorrectly identifies which name is the last name or incorrectly identifies a company name as a person's name. This is easily fixed using Rotate Name.

To rotate the name

- 1 Select the entries that are displayed incorrectly.
- 2 Click to rotate the words in the entry's first line so that they display correctly.

Creating a New List

When you create a new list file, Address Book gives you the option of importing addresses or data (for new address lists or data list files, respectively) into the new file.

A new list file is created with the specified name and stored in the default list file folder. The new file name appears at the top of the **Address Book** panel.

Opening an Existing List

If you have more than one address or data list file, you can select the list you want to use to create labels. Also, if you want to import addresses or data into a file, you must first open the file into which you want to import the data.

For information on importing and exporting list data, see the online Help.

Using the Mac OS Address Book (Macintosh)

If you are running Mac OS version 10.2 or later, you can print addresses you already have stored in the Mac OS address book. However, unlike the built-in Address Book, you cannot add or change the addresses in the Mac OS address book from within DYMO Label Software. You must make changes using the Mac OS address book application.

NOTE Make sure that your Mac OS Address Book My Card record contains your country of residence. This country information is used to determine the correct address format for your labels. Refer to the Mac OS Address Book online Help for more information about My Card.

To print from the Mac OS Address Book

- 1 Select **Use Mac Address Book** from the Address Book menu.
You can also choose this menu item from the Address Book drop-down menu.
- 2 Select the address that you wish to use.
The address is placed on the current label.

If your address book is large, you can display the addresses from a single group to locate an address more quickly.

Chapter 5

Printing Labels Using Smart Paste

The Smart Paste command allows you to quickly print multiple labels from a list created in a word processing, spreadsheet, or other similar program.

The text and address objects can be used to print text from other applications. For the text object, you must select the Function as Variable Text Object setting on the Text Settings dialog box to copy text into this object. The address object is ready to use with Smart Paste by default.


About Smart Paste

This section describes how text from different sources can be printed on labels using the Smart Paste command.

Spreadsheet Text


When copying and pasting rows of text from a spreadsheet program using Smart Paste, each row is treated as a separate label and each cell in the row is treated as a separate line on the label.

For example, the rows in the following spreadsheet:



	A	B	C
1	DYMO Corp.	44 Commerce Road	Stamford, CT 06902
2	Esselte	48 South Service Road	Melville, NY 11471
3			
4			
5			

will print two three-line labels: one for DYMO and one for Esselte.



Text File

Many programs can create a text file, such as a text editing program, a database application, and so on. When you export text from a database, you usually create a delimited file with each entry separated by comma or tab characters, and a carriage return/line feed at the end of each entry.


The Smart Paste command recognizes the delimiter characters and will insert a line break on the label. When a comma is used as a delimiter, make sure the text that contains any commas that you want to print on the label is enclosed in quotation marks. The carriage return/line feed will start a new label.

NOTE The separator character may be different for countries other than the United States. When using Smart Paste, the list separator character is based on the Windows list separator (or regional setting) being used.


For example, the following lines of text (delimited using commas):

DYMO Corp., 44 Commerce Road, "Stamford, CT 06902"
Esselte, 48 South Service Road, "Melville, NY 11471"

will print two three-line labels: one for DYMO and one for Esselte.



In another example, the following three lines of text are printed as three two-line labels:




Multi-Line Text from a Word Processor


When copying text from a word processor, you will typically have multi-line text. In this case, the text for each label is separated by either a single blank line or a carriage return/line feed.

If a blank line is contained in the text, Smart Paste reads the text as multiple labels separated by a single blank line. If no blank line is found, the text is read as multiple, one-line labels.

For example, the following two addresses are separated by a single blank line and Smart Paste will print two three-line labels.



However, the following three lines of text contain no blank lines. So, Smart Paste will print three one-line labels.



Printing Multiple Labels Using Smart Paste


When you use Smart Paste to print multiple labels, the labels will be formatted using the font, size, and style currently selected for the text or address object receiving the text. You can use Smart Paste to print text from the clipboard or a file.

Printing from the Clipboard

You can use Smart Paste to print labels using data copied to the clipboard.

To print multiple labels from the clipboard

- 1 Create a label as described in *Chapter 2, Getting Started*.
- 2 Make sure you have at least one text or address object on the label.
If using a text object for the paste, select **Function as Variable Text Object** on the Text Settings dialog box.
- 3 Copy the text you wish to print as labels to the clipboard.
- 4 Select **Smart Paste**, and then **From Clipboard** from the **Edit** menu.
A dialog box appears telling you how many labels will be printed.



- 5 Click **Yes**. The labels begin printing.


Printing from a File

You can use Smart Paste to print data saved in a CSV or text file.

To print multiple labels from a file

- 1 Save the data you wish to print as labels as a CSV or text file.
- 2 Create a label as described in *Chapter 2, Getting Started*.
- 3 Make sure you have at least one text or address object on the label.
If using a text object for the paste, select **Function as Variable Text Object** on the Text Settings dialog box.

- 4 Select **Smart Paste**, and then **From File** from the **Edit** menu.
The File Open dialog box appears.
- 5 Navigate to and open the file you exported as CSV or text.
A dialog box appears telling you how many labels will be printed.



- 6 Click **Yes**. The labels begin printing.

Using the LabelWriter Printer with Other Applications

This chapter describes how to use your LabelWriter printer with other application programs. The chapter covers:

- Printing labels from Microsoft Word using the Word Add-In.
- Printing labels using other Add-Ins for Windows applications.
- Using Merge Print from Database for database connectivity.
- Using the LabelWriter printer driver to print labels directly from other programs.

Add-In for Microsoft Word


DYMO Label Software includes an add-in program that enables you to quickly print mailing labels from a Microsoft Word document. The add-in works with Microsoft Word 97, 2000, XP, and 2003 for Windows and Microsoft Word X and 2004 for Macintosh.

The Word Add-in is automatically installed as part of the DYMO Label Software. When properly installed, you will see a small LabelWriter printer button on the main toolbar of Microsoft Word. If you don't see this icon, you'll need to reinstall your DYMO Label Software.

Don't worry, none of your customized label files will be changed. Simply reinstall DYMO Label Software from your DYMO Label Software CD-ROM.


CAUTION When you reinstall the DYMO LabelWriter Software, all of the pre-designed label files are also reinstalled. If you have made any changes to the pre-designed label files and have not saved the changes with a new file name, copy the changed label files to another location before you reinstall the software so you don't lose your changes. Then once the installation is complete, copy the label files back into the Labels folder.

Using the Word Add-In


When the Word Add-in is properly installed, you will see the LabelWriter  button in the main toolbar of Microsoft Word.

NOTE When you start Word the first time after you install the Word Add-In, a macro warning dialog box may appear asking if you wish to trust macros from DYMO Corporation. This dialog box is displayed because of your Macro Security setting within Word. In the warning dialog box, select the **Always trust macros from this source check box**, and then select the **Enable Macros** check box. The Word Add-In will now work properly and you will not see this warning again.

To start using the Word Add-in

- 1 Open Microsoft Word and type an address.
- 2 Click  on the Word toolbar or select **DYMO LabelWriter** from the **Tools** menu.

The DYMO LabelWriter dialog box appears with the address from your document automatically placed in the **Recipient Address** field.

If your document contains more than one address and you want to make sure the Word Add-In uses the correct one, select the address in your Word document before you click .

Printing the Address

Once the DYMO LabelWriter dialog box appears, you can select from a number of different address and shipping label files, depending on how you want the label to look.

To print the label


- 1 Select the desired label file from the **Label Files** drop-down list.
- 2 To change the address, edit the address in the Recipient Address dialog box.
- 3 Click **Print Label** to print the label.

If you are printing a shipping label file, it will include the return address that has already been defined for the file.

Additional Windows Application Add-Ins

In addition to the Microsoft Word Add-In, you can install add-ins for several Windows-based contact management applications. Each application is described in this section and full details for installing and using the add-ins is included in the online Help.

About Microsoft Outlook, Palm Desktop, and WordPerfect Add-Ins

Similar to the Microsoft Word Add-In, the Microsoft Outlook, Palm Desktop, and WordPerfect Add-ins are automatically installed at the same time as DYMO Label Software. When an add-in is installed correctly, you will see a  tool button in the main toolbar of the application. Microsoft Outlook requires one additional step to enable the add-in from within Outlook. See “Enabling the Outlook Add-In” later in this section.

If you don't see this tool button, you will need to reinstall your DYMO Label Software.

CAUTION When you reinstall the DYMO LabelWriter Software, all of the pre-designed label files are also reinstalled. If you have made any changes to the pre-designed label files and have not saved the changes with a new file name, copy the changed label files to another location before you reinstall the software so you don't lose your changes. Then once the installation is complete, copy the label files back into the Labels folder.

Enabling the Outlook Add-In

The Outlook Add-In works on Windows systems with Outlook 97, 98, 2000, XP, and 2003.

NOTE The Outlook Add-In does not work with Microsoft Outlook Express.

If the LabelWriter tool button appears in your Outlook toolbar automatically, you can begin using the Add-In. If a tool button is not present, you'll need to enable the Outlook Add-In from the Outlook Add-In Manager.

To enable the Outlook Add-In

- 1** Choose the **Options** command from the **Tools** menu in Outlook.
The **Options** dialog box appears.
- 2** Select the **Other** tab and then click **Advanced Options**.
The **Advanced Options** dialog box appears.
For Outlook 97, also select the **General** tab.
- 3** Click **Add-In Manager**.
- 4** Check the **DYMO LabelWriter** item in the **Add-In Manager** list (you might have to scroll down the list to display this item).
If DYMO LabelWriter does not appear, click the **Install** button and then select from the list of files. Click **OK**.
- 5** Click **OK** in each of the dialog boxes you opened.
- 6** Exit from Outlook and then restart the program.

The Outlook Add-In automatically adds a LabelWriter printer button to the Outlook toolbar and adds the DYMO LabelWriter command to the Tools menu.

About the Database Add-In

DYMO Label Software includes a database add-in that enables you to print information from a variety of databases onto labels. Once you install the add-in, you can quickly print address, shipping, file folder, and other labels from the data in your database.

When selected, the database add-in is automatically installed when the DYMO Label Software is installed. You access the database add-in from the **Merge Print from Database** command on the **File** menu in DYMO Label Software.

The complete instructions for using the database add-in are available in the online Help.

Printing Directly from Other Applications

At times you may want to print labels directly from another program to your LabelWriter printer, without using DYMO Label Software or the LabelWriter add-ins. One example could be if you maintain address lists within Microsoft Word or Access and want to print them all on labels without importing the list to the DYMO Label Software Address Book.

Printing labels directly from applications like these is quite easy because the LabelWriter printers come with standard Windows and Mac OS printer drivers that work with virtually any application.

Detailed instructions on printing directly from Microsoft Word can be found in the online Help. Even if you are using a different application program than Word, reviewing the instructions in the online Help will give you an understanding of how to use the LabelWriter printer driver with your favorite program.

Chapter 7

Using the Tape Editor

The DYMO Label Software Tape Editor is used to design and print labels on the DYMO LabelWriter Duo Tape printer. Using the Tape Editor, you can print text on your D1 tape labels in a variety of fonts, sizes, and styles. You can add borders, graphics, special characters, and barcodes. You can also add a date and time stamp to your labels.


This chapter gives you an overview of creating and printing labels using the Tape Editor. For more information on any of these features, refer to the online Help.

The Tape Editor


The Tape Editor is only available when you have a DYMO tape printer installed on your system, such as the LabelWriter Duo.

The basic functionality of DYMO Label Software is the same in both the Label Editor and the Tape Editor, such as opening and saving files, using Smart Paste to print multiple labels, and so on. So when the Tape Editor is active, the only differences you will see are those specific to designing and printing D1 tape labels. Become familiar with all the features of the software by reading through the other sections in this User Guide.

To use the Tape Editor

- 1 Open DYMO Label Software.
- 2 Click  on the left side of the main window.

The Tape Editor appears with a new blank label.



Designing a Label


In this section, we will show you how to print a label for a file folder tab using the Tape Editor. You can format the label text and then save the label for future use.

When designing a label, the first items to consider are the width of the label tape onto which you will print and the length of the area where you will place the label. For this example, we will create a label that will fit on a file folder tab. The total label length must be no more than 3 1/2" (8.5 cm) and we will print on label tape with a width of 1/2" (12 mm).


To create a label

- 1 Start DYMO Label Software.

The main window appears.




- 2 Select **19 mm** from the **Tape Width** drop-down menu.




The text area of the main window changes in size based on the tape width you select.

- 3 Select **Fixed At** and enter **8.5 cm** in the **Label Length Fixed At** text box.






Notice that the size of the input area changes on the ruler.

- 4 Type **2005 Annual Budget Projections** in the main window.



As the line of text becomes too long for a fixed width label at the current font size, the font size will automatically decrease to fit the text on one line.

- 5 To center the text, click .
- 6 Click  or select **Save** from the **File** menu.
The Save File dialog box appears.
- 7 Type a name for the label and click **Save**.
Now let's print the label.
- 8 Click  or select **Print** from the **File** menu.

Now that you have created and saved your label, the following sections will introduce additional features you can use to customize your labels.

Additional Formatting Features


To further customize your labels, you can add borders, symbols, graphics, barcodes, and even date and time stamps. You can also choose to print the label vertically.

Adding Borders


You can choose to add one of several pre-defined borders to your label. When you add a border, it surrounds the text and may cause the text to decrease in size.

To add a border

- 1 Place the cursor anywhere on the label.
- 2 Select a border style from the **Borders** drop-down menu.




The selected border surrounds the text. If necessary, the font size of the text is decreased to fit the label.




Adding Special Characters

You can choose to add a special character or symbol to the label.

To add a special character

- 1 Place the cursor at the point on the label where you want the character to appear.
- 2 Click  or select **Symbol** from the **Insert** menu.

The Symbol dialog box appears.




- 3 Choose the font that contains the special character you wish to insert from the **Font** drop-down list.

The Symbol, Dingbats, and Wingdings fonts contain many unique characters you can add to your labels.

- 4 Select the symbol you wish to insert and click **Insert**.
- 5 Click **Close** to close the Symbol dialog box.

The character you selected appears on the label in a size that matches the text font size.




Adding Special Font Effects

In addition to the standard font styles (bold, italic, underline, and strikeout), you can make your text stand out using a shadow or outline style. With the outline style, you choose the fill pattern.

To add a shadow effect to your text


- 1 Highlight the text on your label that you wish to appear with a shadow effect.
- 2 Select **Font** from the **Format** menu. The Font dialog appears.
- 3 Select **Shadow** under **Effects** and click **OK**.

The highlighted text now appears on the label with a shadow effect.



To add an outline effect to your text with a fill pattern


- 1 Highlight the text on your label to which you wish to apply an outline effect.
- 2 Select **Font** from the **Format** menu. The Font dialog box appears.
- 3 Select **Outline** under **Effects**.
- 4 Select a fill pattern from the **Fill Pattern** drop-down menu.
- 5 Click **OK**. The highlighted text now appears on the label with an outline effect.




Adding a Date and Time Stamp

You can choose to add a date and/or time stamp to the label. The date and time is entered as text and will be the actual system date and time when you added the stamp to the label. For example, if today's date is 24 Oct 2002 and you add the date to a label design today, save the label, and then open it tomorrow, 24 Oct 2002 will still appear on the label.


To add a date and time stamp

- 1 Place the cursor at the point on the label where you want the date and/or time stamp to appear.
- 2 Click  or select **Date & Time** from the **Insert** menu.

The Date and Time dialog box appears.




- 3 Select the date and/or time format you wish to insert from the drop-down list and click **OK**. The date and/or time appears on the label in the format you selected.



Adding Graphics


You can add a graphic to your label from the clipboard or from a file. If the graphic is in a file, the format can be BMP, JPG, PCX, PNG, TIF, WMF, or EMF. When inserted on the label, the graphic will be scaled automatically to the size of the surrounding text while maintaining the aspect ratio.

To add a graphic from the clipboard

- 1 Copy the graphic to the clipboard from another application.
- 2 Place the cursor at the point on the label where you want the graphic to appear.
- 3 Click  or select **Paste** from the **Edit** menu.

The graphic appears on the label at the cursor position.


To add a graphic from a file

- 1 Place the cursor at the point on the label where you want the graphic to appear.
- 2 Click  on the **Standard** toolbar or select **Graphic** from the **Insert** menu.

The Open File dialog box appears.

- 3 Select the graphic file you wish to insert and click **Open**.


The graphic you selected appears on the label.




Adding a Barcode

You can choose to add a barcode to your label. This feature can be very useful, for example, if you are labeling inventory items that will be scanned with a barcode reader. You can choose to print the barcode with or without the human-readable text.

To add a barcode


- 1 Place the cursor at the point on the label where you want the barcode to appear.
- 2 Click  or select **Barcode** from the **Insert** menu.

The Barcode Settings dialog box appears.



- 3 Type the text you wish displayed as a barcode in the **Data** field.
- 4 Select the type of barcode from the **Symbology** drop-down menu.
- 5 Select whether you want the actual text to appear above the barcode, below the barcode or not at all under **Human Readable Text**.
- 6 If you selected above or below, click the **Font** button to choose the font for the text.
- 7 Select the size of the barcode under **Barcode Size**.

- 8 Click **OK** to insert the barcode on the label.



The barcode is placed on the label as a single object. To remove the barcode, you can use the backspace key or highlight the barcode and select **Cut** from the **Edit** menu.


Printing Vertically

You can print your label vertically, for example, to be placed on the spine of a binder or a video tape. When you print vertically, the text on your label is reformatted to fit in a single column on the label. You may wish to center the text on the label as well.

To print vertically

- 1 Select the **Vertical Label** check box on the Formatting toolbar to select Vertical.

A warning dialog box appears informing you that the text will be reformatted.



NOTE If the contents of the label are too long to fit vertically on a fixed width label, the excess content is truncated. This action cannot be undone once you click Yes.

- 2 Click **Yes**.

The text of your label is now displayed in a single vertical column.

Printing from Other Applications

The DYMO Label Software installation wizard installs a standard Windows printer driver on your computer so the DYMO LabelWriter Duo Tape printer will appear in your list of printers. This printer can be used to print directly from other applications, such as Microsoft Word or Access, in the same manner as you would use any other printer.

To successfully print to the DYMO LabelWriter Duo Tape printer, you need to set the correct page size, orientation, and margins for the tape cassette currently in the printer. Table 1 gives the paper size and margin settings for each of the label sizes supported by the DYMO Label printers.


Table 1. LabelWriter Duo Tape Printer Page Size and Margin Settings

Paper Name	Paper Height	Paper Width	Top Margin	Bottom Margin	Left Margin	Right Margin
Address Label	1" (24 mm)	3.5" (89 mm)	0.23" (5.8 mm)	0.24" (6.1 mm)	0.4" (10.2 mm)	0.39" (9.9 mm)
Large Pendaflex	0.5" (12 mm)	3.5" (89 mm)	0.09" (2.3 mm)	0.10" (2.6 mm)	0.4" (10.2 mm)	0.39" (9.9 mm)
Small Pendaflex	0.5" (12 mm)	3.5" (89 mm)	0.09" (2.3 mm)	0.10" (2.6 mm)	0.4" (10.2 mm)	0.39" (9.9 mm)
1/3 File	0.5" (12 mm)	3.5" (89 mm)	0.09" (2.3 mm)	0.10" (2.6 mm)	0.4" (10.2 mm)	0.39" (9.9 mm)
1/5 File	0.5" (12 mm)	2" (51 mm)	0.09" (2.3 mm)	0.10" (2.6 mm)	0.4" (10.2 mm)	0.39" (9.9 mm)
6 mm Label	0.25" (6 mm)	3.5" (89 mm)	0.04" (1 mm)	0.04" (1 mm)	0.4" (10.2 mm)	0.39" (9.9 mm)
9 mm Label	0.375" (9 mm)	3.5" (89 mm)	0.03" (1 mm)	0.04" (1 mm)	0.4" (10.2 mm)	0.39" (9.9 mm)
12 mm Label	0.5" (12 mm)	3.5" (89 mm)	0.09" (2.3 mm)	0.10" (2.6 mm)	0.4" (10.2 mm)	0.39" (9.9 mm)
19 mm Label	0.75" (19 mm)	3.5" (89 mm)	0.11" (2.8 mm)	0.11" (2.8 mm)	0.4" (10.2 mm)	0.39" (9.9 mm)
24 mm Label	1" (24 mm)	3.5" (89 mm)	0.23" (5.8 mm)	0.24" (6.1 mm)	0.4" (10.2 mm)	0.39" (9.9 mm)

This section shows you how to print from within Microsoft Word to a DYMO Label printer. However, printing from applications other than Word follows the same basic steps.

To print from Microsoft Word

- 1** Type the text to be printed into a Microsoft Word document.
- 2** Select **Print** from the **File** menu.
The Print dialog box appears.
- 3** Select **DYMO LabelWriter Duo Tape** from the list of printers, if not already selected, and click **Close**.
- 4** Select **Page Setup** or **Print Setup** from the **File** menu.
The Page Setup dialog box appears.
- 5** On the **Margins** tab, enter the margin values for the top, bottom, left, and right margins based on the labels you have loaded in the printer.
Refer to Table 1 for the correct settings.
- 6** Click the **Paper Size** tab.

- 7 Select the label size you have loaded in the printer from the **Paper size** drop-down list.
The width and height values should now match the values for that label size shown in Table 1.
- 8 Select **Landscape** under **Orientation** and click **OK**.
- 9 Click  to print the label.

Print Settings

This section discusses several printer settings that may optimize your printing.


Tape Cassette Color Setting

The LabelWriter Duo tape printer adjusts its print settings based on the color of the label tape. To optimize the print quality, make sure you set the tape cassette color setting to match the color of the tape in the printer.

To set the tape cassette color

- 1 Select **Tape Cassette Color** from the **Format** menu.

A list of possible tape color combinations appears.



- 2 Select the tape color combination that matches the tape cassette in the printer.

Depending upon the selection you make, the background color in the main window may change so that you get a better idea of how your printed label will look.

Chain Printing

When printing multiple labels, the chain printing feature will automatically print a dashed cut-line between each label to indicate where each label should be cut.


DYMO Corp.		Esselte
44 Commerce Road		48 South Service Road
Stamford, CT 06902		Melville, NY 11471

You have the option of chain printing or automatically cutting each label after printing.

To change the chain print setting

- 1 Select **Options** from the **Edit** menu.

The Options dialog box appears.



- 2 Select one of the following:
 - **Cut each label as printed** — Automatically cuts each label after printing.
 - **Print cut marks between labels** — Prints labels in a continuous stream with dotted lines between each label for cutting.
- 3 Click **OK** to apply the new setting.

Label Alignment


As a label is printed, blank space is added at the beginning of the label and at the end of the label. Normally, the space is the same on both ends of the label. However, you have the option of printing the label with less space at the beginning or at end of the label.



To change the label alignment

- 1 Select **Options** from the **Edit** menu.

The Options dialog box appears.



- 2 Select an alignment from the **Label Alignment** drop-down list.
- 3 Click **OK** to apply the new setting.

Continuous Mode Printing


Continuous mode printing prints multiple labels with no space between the labels. This is especially helpful for conserving label tape. Continuous mode printing is turned off by default.

NOTE Continuous mode printing only applies to printing from other applications. This selection has no effect when printing from the DYMO Label software.

To set continuous mode printing

- 1 Right-click the LabelWriter printer from the **Printers and Faxes** control panel.
The printer option menu appears.
- 2 Select **Properties**, and then **Advanced**.

The Advanced Options dialog box appears.



NOTE You can also get to this dialog box by selecting **Printer Setup** from the **File** menu.

3 Select **Enabled** from the **Continuous Paper** drop-down list and click **OK**.

The labels will now print continuously with no space between labels.

Chapter 8

Maintenance and Troubleshooting

This chapter describes how to take care of your LabelWriter printer and offers suggestions for identifying problems that can occur when you using the printer. If you can't solve a problem, this chapter also describes how to contact DYMO for technical support.

Caring for the LabelWriter Printer

The LabelWriter printer is designed to give you long and trouble-free service, while requiring very little maintenance. You'll get the best possible performance from your LabelWriter printer if you follow the setup instructions that appear in the *Quick Start Guide* and the procedures described in this section.

You can easily clean your LabelWriter printer using the following items:

- Lint-free cloth.
- Isopropyl alcohol, diluted dishwashing detergent, or diluted glass cleaner. (If you use glass cleaner, make sure it does not contain ammonia.)
- Small, soft brush, such as a paint brush.
- LabelWriter cleaning card. One cleaning card is included in your printer package. To purchase additional cleaning cards, visit www.dymo.com.

To keep your LabelWriter printer working properly, you should clean it from time to time. Dusting the outside of the printer occasionally will help keep foreign matter from getting inside the printer. However, it is still a good idea to periodically perform some basic interior maintenance.

To clean the exterior and interior of your printer

- 1 Turn off the printer and disconnect the power cord.
- 2 Use the lint-free cloth to wipe the exterior of the printer. Remove dirt and smudges with one of the cleaning solutions mentioned above.
- 3 Open the top cover.
- 4 Use a small, soft brush/cotton swab to whisk away paper dust and other stray particles from the inside of the printer.
- 5 Remove the roll of labels to clean under the roll.
- 6 If you have a LabelWriter cleaning card, follow the instructions printed on its packaging and feed it through the printer mechanism.
- 7 Reconnect the power cord and turn on the printer.
- 8 Reload the roll of labels and close the top cover.

Performing a Printer Self-Test

If you experience problems with broken characters or other print quality issues, you should perform a printer self-test. The self-test verifies that all elements of the print head are in working condition.

To perform a self test for the LabelWriter 300

- 1 Turn off the printer using the switch on the back.
- 2 Press and hold down the form-feed button.
- 3 Turn on the printer and then release the form-feed button.

Your LabelWriter will print vertical lines along the width of the printer. To change the test pattern being printed, press the form-feed button.

- 4 To stop the self test, turn the printer off.

To perform a self-test for LabelWriter 320

- 1 Press and hold down the form-feed button on the front of the LabelWriter for 10 seconds.

The LED light begins flashing red and green, and starts printing vertical lines along the width of the printer. The test pattern automatically changes every 3/4 inch (19 mm).

- 2 Release the form-feed button.
- 3 To stop the self-test, press and release the form-feed button.

To perform a self-test for the LabelWriter 330, 330 Turbo, 400, 400 Turbo, Twin Turbo, and Duo

- 1 Press and hold down the form-feed button on the front of the printer for 10 seconds.
- 2 Release the form-feed button.

The printer will begin printing vertical lines along the width of the printer. The test pattern will automatically change every 3/4 inch (19 mm).

- 3 To stop the self-test, press and release the form-feed button.

Obtaining Technical Support

If you experience problems with the set up or use of your printer, carefully read this manual and consult the online Help to make sure you have not missed something that is covered in the documentation.

If you cannot resolve your problem by consulting the documentation, you can obtain additional information and assistance from DYMO.

Contacting DYMO

DYMO maintains an Internet Web site, www.dymo.com, that offers support for each printer. The following table provides a list of telephone numbers to reach DYMO Sales and Support departments. You can also reach DYMO at www.dymo.com.

Country	Telephone Support	Fax Support
Australia	1800/ 633 868	1800/ 817 558
België/Belgique	02/ 713 38 08	+31/ 20/ 581 93 80
Canada	(800) 263-6105	
Czech Republik	02/619 12 720	+02/619 12 730
Danmark	35 25 65 08	+31/ 20/ 581 93 80
Deutschland	069/ 66 56 85 29	+31/ 20/ 581 93 80
España/Portugal	91/662 31 49	+31/ 20/ 581 93 80
France	01/69 32 49 32	+31/ 20/ 581 93 80
Hong Kong	+852 2527 1928	
Hungaria	1 424 6600	1 424 6601
Ireland	+353 14118934	
Italia	02/ 45 28 13 08	+31/ 20/ 581 93 80
Mexico	+01 5368 2066	
Nederland	020/581 93 86	020/ 581 93 80
New Zealand	0800 803 966	0800 737 212
Norge	22 97 17 10	+31/ 20/ 581 93 80
Österreich	01/ 599 14 20 12	02/627-400-160
Polska	00800/311 12 50	+31/ 20/ 581 93 80
Schweiz/Suisse	01/342 04 66	+31/ 20/ 581 93 80
Slovakia	(+420) 2/619 12 720	(+420) 2/619 12 730
Suomi	09 229 07 04	+31/ 20/ 581 93 80
Sverige	08/ 632 00 57	+31/ 20/ 581 93 80
Turkey	212/ 286 26 30 PBX	212/ 286 26 28
United Kingdom	(+44) 020/ 7341 55 29	+31/ 20/ 581 93 80
United States	(203) 588-2500	

Appendix A

Technical Specifications

This section gives the printer specifications for all the LabelWriter printers. You will also find information on DYMO's Software Development Kit which will allow you to use the LabelWriter printer and software with your application.

Printer Specifications

	300	330	330 Turbo	310	320	400	400 Turbo	Twin Turbo	Duo ^a
Print Method	Direct Thermal								
Print Resolution	300 dots per inch (11.8 dots per mm)								
Print Speed (labels/min for address label in text mode)	16	16	32	8	16	40	55	55	55
Maximum Print Width	1.57" 40 mm	2.25" 56 mm	2.25" 56 mm	1.57" 40 mm	2.25" 56 mm	2.25" 56 mm	2.25" 56 mm	2.25" 56 mm	2.25" 56 mm
Maximum Media Width	2.44" (62 mm) in all printers								
Maximum Label Length	User-definable								
Interface	USB (USB Spec 1.1 protocol); Serial (Bi-directional, RS232) serial			USB (USB Spec 1.1 protocol)		USB 2.0 Full Speed Printer Class Device			
Serial Printer Settings	115,200 baud, 8 data bits, no parity, hardware handshaking			N/A	N/A	N/A	N/A	N/A	N/A
Dimensions (WHD)	4 7/8" (12.4 cm) x 5 3/4" (14.6 cm) x 7 1/4" (18.4 cm)								(183 mm) x (140 mm)
Weight	1 1/2 pounds (0.68 kg)								(1.35 kg)
Average Print Head Life	2,000,000 linear inches (over 31 miles) 50800 linear meters								
Printer Power Requirements	100-240 V ~ 850 mA 47-63 Hz, Class II ^b	24 VDC 1.0 A				24 VDC 1.75 A			
Rated Duty Cycle (labels per hour)	1000 labels							1000 labels per side	1000 labels
Regulatory Approvals	CE, FCC, cTUVus, GS and C-Tick								
Warranty	Two Year Limited								

a. Label printer specifications

b. The LabelWriter printer's internal power supply allows you to use it Worldwide with an appropriate adapter.

Developer and SDK Information

DYMO provides various types of information designed to help developers create products that work with the LabelWriter printers and DYMO Label Software. Below are some notes for those interested in developing products that work with LabelWriter printers.

- Keep in mind that LabelWriter printers use standard printer drivers. Therefore, printing to a LabelWriter is no different than printing on a laser printer, except that the pages are smaller.
- In cases where you want to automate printing and take advantage of the label printing power built into DYMO Label Software, a Software Developer's Kit (SDK) is included in your LabelWriter CD. The SDK provides OLE, direct DLL calls, and Dynamic Data Exchange (DDE) interfaces. For more information, visit www.dymo.com/developers.

You can check the Developer's forum on the DYMO Web site at www.dymo.com/developers for the latest news. Also, you can join the Developer's mailing list to obtain developer-specific news and announcements.

Documentation Feedback

We are constantly working to produce the highest quality documentation for our products. We welcome your feedback. Send us your comments or suggestions about our online Help, printed, or PDF manuals.

Please include the following information with your feedback:

- Product name and version number
- Type of document: printed manual, PDF, or online Help
- Topic title (for online Help) or page number (for printed or PDF manuals)
- Brief description of content (for example, step-by-step instructions that are inaccurate, information that requires clarification, areas where more detail is needed, and so on)
- Suggestions for how to correct or improve the documentation

We also welcome your suggestions for additional topics you would like to see covered in the documentation.

Send email feedback to:

[**documentation@dymo.com**](mailto:documentation@dymo.com)

Please keep in mind that this email address is only for documentation feedback. If you have a technical question, please contact Customer Service.

A

- adding
 - barcodes 33
 - borders 29
 - date and time 31
 - graphics 32
 - special characters 30
 - special fonts 31
- address book
 - About 15
 - creating new 17
 - opening lists 17
 - rotating names 17
 - using Mac OS address book 18
- address objects 12
 - placing new 14
- alignment, label 37

B

- barcode objects 12
 - placing new 14
- barcodes, adding 33
- BMP 32

C

- chain printing 36
- Codabar 13
- Code 128 13
- Code 39 13
- continuous mode printing 38
- counter objects 13
 - placing new 14
- creating a label 28
- Creating a New List 17
- curved text objects 13

D

- Database Add-In 25
- date-time objects 13
 - placing new 14
- Default Logo File 4
- Default Return Address 4
- delimited files, printing 19
- designer 11
- designer toolbar 11

- DYMO Label Software
 - starting 5

E

- EAN 8/13 13
- ellipse objects 12
- EMF 32

F

- fonts, special effects 31
- form-feed button 42

G

- graphic objects 12
 - placing new 14
- graphics, adding 32

H

- help 2, 42
- horizontal line objects 12
 - placing new 14

I

- Interleaved 2 of 5 13
- ITF-14 13

J

- JPG 32

L

- label alignment 37
- Label Designer 11
 - starting 11
- label files 11
 - opening 5
 - saving 9
- labels 11
 - opening 13
 - printing 8
 - shelf life 2
 - storage 2
- LabelWriter printer
 - taking care of 41
- line objects 12

M

Mac OS Address Book 18
main toolbar 11
Merge Print from Database 25
Microsoft
 Access 25
 Outlook 24
 Outlook Express 24
 Word 23, 25
multi-line text 20

O

objects
 about 11
 address 12
 barcode 12
 counter 13
 curved text 13
 date-time 13
 ellipse 12
 graphic 12
 horizontal line 12
 placing new 14
 rectangle 12
 text 11
 vertical line 12
opening
 address book lists 17
 label files 5, 13
outline font 31
Outlook Add-In 23, 24

P

Palm Desktop 24
PCX 32
placing new objects on labels 14
PLANET 13
PNG 32
POSTNET 13
print settings 36
 chain printing 36
 continuous mode printing 38
 label alignment 37
 tape cassette color 36
printer
 maintenance 41
 self-test 42
 specifications 45
 testing 42

printing

 chain printing 36
 continuous mode 38
 from a list 34
 labels 8
 multiple labels 21
 vertically 34

R

rectangle objects 12
 placing new 14
register the software 2
return address 4
Rotate Name 17

S

saving
 label files 9
self-test 42
shadow font 31
Smart Paste 19
spreadsheets, printing from 19
storing labels 2

T

tape cassettes
 color settings 36
technical support 42
text files, printing from 19
text objects 11
 placing new 14
thermal printing 1
TIF 32

U

UPC A/E 13
using with other programs 23

V

variable
 objects 16
 text objects 16
vertical line objects 12
 placing new 14

W

WMF 32
Word Add-in 23
WordPerfect 24