



Cisco Unified IP Conference Phone 8831 and 8831NR User Guide for Cisco Unified Communications Manager

First Published: 2014-11-20

Last Modified: 2020-04-28

Americas Headquarters

Cisco Systems, Inc.
170 West Tasman Drive
San Jose, CA 95134-1706
USA
<http://www.cisco.com>
Tel: 408 526-4000
800 553-NETS (6387)
Fax: 408 527-0883

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The following information is for FCC compliance of Class A devices: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio-frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case users will be required to correct the interference at their own expense.

The following information is for FCC compliance of Class B devices: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If the equipment causes interference to radio or television reception, which can be determined by turning the equipment off and on, users are encouraged to try to correct the interference by using one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Modifications to this product not authorized by Cisco could void the FCC approval and negate your authority to operate the product.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.


Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

All printed copies and duplicate soft copies of this document are considered uncontrolled. See the current online version for the latest version.

Cisco has more than 200 offices worldwide. Addresses and phone numbers are listed on the Cisco website at www.cisco.com/go/offices.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: www.cisco.com/go/trademarks. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1721R)

© 2020 Cisco Systems, Inc. All rights reserved.



CONTENTS

CHAPTER 1

Preface 1

- Introduction 1
- Additional Information 2
- Safety and Performance Information 2
 - Power Outage 2
 - External Devices 2
 - Cisco Product Security Overview 3
 - Phone Behavior During Times of Network Congestion 3
- Accessibility Features 3

CHAPTER 2

Features of Your Cisco Unified IP Conference Phone 5

- Features Overview 5
- New and Changed Information 6
 - New and Changed May 2020 6
 - New Information for Firmware Release 10.3(1)SR3 6
 - New Information May 2016 6
- Buttons and Hardware 6
 - LED State Definitions 7
 - Display Control Unit 8
 - Sound Base 9
 - Wireless Extension Microphone and Charger Kit 10
 - Wireless Microphone LED 11
 - Wired Extension Microphone Kit 12
- Phone Screen 13
 - Phone Screen Cleaning 14
- Phone Connections 14

Connect Mini-USB Cable to DCU	15
Install Ferrite Bead on Network Cable	16
Wireless Microphone Setup and Use	17
Pair the Wireless Microphone	18
Set the Wireless Microphone range	18
Power Off the Wireless Microphone	19
Recharge the Wireless Microphone Battery	19
General IP Phone Information	19
Power-Saving Mode	19
Feature Availability	20
Accessibility Features	20
Hearing Impaired Accessibility Features	20
Vision-Impaired and Blind Accessibility Features	22
Mobility-Impaired Accessibility Features	23
Cisco Unified Communications Manager Accessibility Features	24
Additional Options	25

CHAPTER 3

Applications	27
Services	27
Access Services	27
Call History	27
View Call History	28
View Call Record Details	28
Dial from Call History	28
Edit Phone Number	29
Clear Call History	29
Delete Call Record	29
Preferences	30
Ringtones	30
Change Ringtone	30
Contrast	30
Adjust Contrast	30
Linked Mode	31
Link Conference Phones	31

IP Phone Information	32
Administrator Settings	33

CHAPTER 4**Contacts 35**

Contacts Overview	35
Corporate Directory	35
Dial Contact from Search	35
Dial Contact from Search During an Active Call	36
Personal Directory	36
Personal Directory Options	37
Sign In and Out of Personal Directory	37
Add Personal Directory Entry	37
Search for Entry in Personal Directory	38
Dial Number from Personal Directory	38
Delete Personal Directory Entry	39
Edit Personal Directory Entry	39
Fast-Dial Codes with Personal Directory	39
Assign Fast-Dial Code to PAB from the Phone	39
Place Call Using Fast-Dial Code	40
Delete Fast-Dial Code	40

CHAPTER 5**Messages 41**

Access Voicemail	41
Voice Message Identification	41
Access Voice Messages	41

CHAPTER 6**Calling Features 43**

Softkey Feature Map	43
Survivable Remote Site Telephony Overview	44
Answer	46
Call Back	47
Set Up Call Back Notification	47
Call Forward	47
Forward Calls	48

Call Park	48
Park Call	48
Call Pickup	49
Answer Call Using Pickup	49
Answer Call Using Group Pickup and Group Pickup Number	49
Answer Call Using Group Pickup and Phone Number	50
Answer Call Using Other Pickup	50
cBarge	50
Join Conference on Shared Line	50
Conference	51
Add Third Party to Conference	51
View Conference Participants	51
Remove Conference Participants	52
Divert	52
Divert Call	52
Do Not Disturb	52
Turn DND On and Off	53
Enhanced Room Coverage	53
Pair Wireless Microphone	54
Unpair Wireless Microphone	55
Cisco Extension Mobility	55
Enable Extension Mobility	56
Hold	56
Hold Active Call	56
Switch Between Active and Multiple Holding Calls	57
Hold Active Call and Answer New Incoming Call	57
Hold Reversion	57
Respond to Hold Reversion Notification	58
Meet Me Conference	58
Host Meet Me Conference	58
Join Meet Me Conference	58
Mobile Connect	59
Enable Mobile Connect	59
Switch IP Phone Call to Mobile Phone	59

Switch Mobile Call to IP Phone	60
Monitoring and Recording	60
Multiple Calls per Line	60
Multiple Incoming Calls	60
Call Ended on Line with Multiple Calls	60
Outbound Call Maximum	60
Answer Second Call on Same Line	61
Switch Between Calls on Same Line	61
Create Conference with Two Calls on Same Line	61
Transfer Two Calls on Same Line	61
Shared Line	62
Mute	62
Mute IP Phone Sound Base	62
Mute IP Phone DCU	63
On-Hook Dialing	63
Dial Number On-Hook	63
Plus Dialing	63
Dial International Number	63
Privacy	64
Enable Privacy on Shared Line	64
Quality Reporting Tool	64
Report IP Phone Problems	64
Redial	65
Redial Number	65
Shared Lines	65
Transfer	65
Transfer Call to Another Number	65
Cisco WebDialer	66
Use WebDialer with Another Online Corporate Directory	66
Change WebDialer Preferences	66
Sign In to the Cisco Unified Communications Self Care Portal	67

CHAPTER 7**Troubleshooting 69**

General Troubleshooting	69
-------------------------	----

Phone Administration Data 70
 Quality Reporting Tool 70


CHAPTER 8

Cisco One-Year Limited Hardware Warranty Terms 71
 Warranty Overview 71
 View Cisco Information Packet 71
 Cisco One-Year Limited Hardware Warranty Terms 72

CHAPTER 9

Product Safety and Security 73
 Safety and Performance Information 73
 Power Outage 73
 External Devices 73
 Ways to Provide Power to Your Phone 74
 Phone Behavior During Times of Network Congestion 74
 UL Warning 74
 Product Label 74
 Compliance Statements 74
 Compliance Statements for the European Union 74
 CE Marking 74
 Compliance Statements for the USA 75
 Part 15 Radio Device 75
 Compliance Statements for Canada 75
 Compliance Statements for New Zealand 75
 Permit to Connect (PTC) General Warning 75
 Compliance Statement for Argentina 75
 Compliance Information for Brazil 76
 Compliance Statement for Singapore 76
 Compliance Information for Japan 76
 FCC Compliance Statements 76
 FCC Part 15.19 Statement 76
 FCC Part 15.21 Statement 76
 FCC RF Radiation Exposure Statement 77
 FCC Receivers and Class B Digital Statement 77
 Cisco Product Security Overview 77

[Important Online Information](#) 77



CHAPTER 1

Preface

- [Introduction, on page 1](#)
- [Additional Information, on page 2](#)
- [Safety and Performance Information, on page 2](#)
- [Accessibility Features, on page 3](#)

Introduction

This guide provides you with an overview of the features available on your Cisco Unified IP Conference Phone 8831 and 8831NR. You can read it completely for a solid understanding of the capabilities of your phone or refer to the table below for pointers to commonly used sections.

If You Want to...	Then...
Review safety information	See Safety and Performance Information, on page 2 .
Connect the phone	See Phone Connections, on page 14 .
Use the phone after it is installed	Start with Features of Your Cisco Unified IP Conference Phone, on page 5 .
Learn what the phone buttons mean	See Buttons and Hardware, on page 6 .
Learn about the display screen	See Phone Screen, on page 13 .
Make calls	See Calling Features, on page 43 .
Put calls on hold	See Hold, on page 56 .
Mute calls	See Mute, on page 62 .
Transfer calls	See Transfer, on page 65 .
Make conference calls	See Conference, on page 51 .
Share a phone number	See Shared Lines, on page 65 .
Change the ring volume or type	See Ringtones, on page 30 .
View your missed calls	See Call History, on page 27 .

If You Want to...	Then...
Listen to your voice messages	See Messages, on page 41 .

Additional Information

You can access the most current Cisco documentation at this URL:

<http://www.cisco.com/c/en/us/support/collaboration-endpoints/unified-ip-phone-8800-series/tsd-products-support-series-home.html>

You can access the Cisco website at this URL:

<http://www.cisco.com/>

You can access the most current licensing information at this URL:

http://www.cisco.com/en/US/products/ps12965/products_licensing_information_listing.html

Safety and Performance Information

The following sections provide information about the impact of power outages and external devices on your Cisco Unified IP Phone.

Power Outage

Your access to emergency service through the phone depends on the phone being powered. If there is a power interruption, Service and Emergency Calling Service dialing will not function until power is restored. In case of a power failure or disruption, you may need to reset or reconfigure the equipment before using the Service or Emergency Calling Service dialing.

External Devices

Cisco recommends using good quality external devices such as headsets, cables, and connectors that are shielded against unwanted radio frequency (RF) and audio frequency (AF) signals.



Note

Not all Cisco IP Telephony products support external devices, cords or cables. For more information, consult the documentation for your phone.

Depending on the quality of these devices and their proximity to other devices such as mobile phones or two-way radios, some audio noise may still occur. In these cases, Cisco recommends that you take one or more of these actions:

- Move the external device away from the source of the RF or AF signals.
- Route the external device cables away from the source of the RF or AF signals.
- Use shielded cables for the external device, or use cables with a better shield and connector.

- Shorten the length of the external device cable.
- Apply ferrites or other such devices on the cables for the external device.

Cisco cannot guarantee the performance of external devices, cables, and connectors.



Caution In European Union countries, use only external speakers, microphones, and headsets that are fully compliant with the EMC Directive [89/336/EC].

Cisco Product Security Overview

This product contains cryptographic features and is subject to United States and local country laws governing import, export, transfer, and use. Delivery of Cisco cryptographic products does not imply third-party authority to import, export, distribute, or use encryption. Importers, exporters, distributors, and users are responsible for compliance with U.S. and local country laws. By using this product you agree to comply with applicable laws and regulations. If you are unable to comply with U.S. and local laws, return this product immediately.

Further information regarding U.S. export regulations may be found at <http://www.bis.doc.gov/index.php/regulations/export-administration-regulations-ear>.

Phone Behavior During Times of Network Congestion

Anything that degrades network performance can affect phone audio and, in some cases, can cause a call to drop. Sources of network degradation can include, but are not limited to, the following activities:

- Administrative tasks, such as an internal port scan or security scan
- Attacks that occur on your network, such as a Denial of Service attack


Accessibility Features

The Cisco Unified IP Conference Phones 8831 and 8831NR provide accessibility features for the vision impaired, the blind, and the hearing and mobility impaired.

For detailed information about the features on these phones, see <http://www.cisco.com/c/en/us/support/collaboration-endpoints/unified-ip-phone-8800-series/products-technical-reference-list.html>.

You can also find more information about accessibility at this Cisco website:

<http://www.cisco.com/web/about/responsibility/accessibility/index.html>



CHAPTER 2

Features of Your Cisco Unified IP Conference Phone

- [Features Overview, on page 5](#)
- [New and Changed Information, on page 6](#)
- [Buttons and Hardware, on page 6](#)
- [Phone Screen, on page 13](#)
- [Phone Connections, on page 14](#)
- [Wireless Microphone Setup and Use, on page 17](#)
- [General IP Phone Information, on page 19](#)
- [Feature Availability, on page 20](#)
- [Accessibility Features, on page 20](#)
- [Additional Options, on page 25](#)

Features Overview

The Cisco Unified IP Conference Phones 8831 and 8831NR are full-featured single line conference stations that provides voice communication over an IP network. It functions much like a digital business phone, allowing you to place and receive calls and to access features such as mute, hold, transfer, and call forward. In addition, because conference stations connect to your data network, they offer enhanced IP telephony features, including access to network information, network services, and customizable features and services.

The conference station provides a backlit LCD screen and a variety of other sophisticated functions. Optional microphone extension kits provide enhanced room coverage that can be further expanded by linking two units together.

The Cisco Unified IP Conference Phone 8831 supports wired and wireless microphones. The Cisco Unified IP Conference Phone 8831NR supports only wired microphones.

In addition to basic call-handling features, your conference station can provide enhanced productivity features that extend your call-handling capabilities. Depending on configuration, the conference station supports:

- Access to network data, XML applications, and web-based services.
- Online customizing of conference station features and services from Cisco Unified Communications Self Care Portal.

New and Changed Information

You can use the information in the following sections to understand what has changed in the document. Each section contains the major changes.

New and Changed May 2020

Update	Description
Product Safety and Security, on page 73	Added the missing chapter.
Additional Information, on page 2	Moved from a separate chapter to the end of Features of Your Cisco Unified IP Conference Phone, on page 5

New Information for Firmware Release 10.3(1)SR3

Feature	Affected Sections
Cisco Unified IP Conference Phone 8831NR Support	Features Overview, on page 5 Wireless Extension Microphone and Charger Kit, on page 10 Wireless Microphone Setup and Use, on page 17 Linked Mode, on page 31 Enhanced Room Coverage, on page 53 Additional Options, on page 25
Accessibility information added	Accessibility Features, on page 20

New Information May 2016

The following new information was added to describe the wireless microphones:

- [Wireless Microphone LED, on page 11](#)
- [Wireless Microphone Setup and Use, on page 17](#) section and subsections

Buttons and Hardware

The Conference Phone has two primary components:

- Display Control Unit (DCU)
- Sound Base

In addition, the following optional extension kits can be added to or used with the conference phone:

- Wired Microphone Extension Kit
- Wireless Microphone Extension Kit and Charger

For your conference phone to work, it must be connected to the corporate IP telephony network.

LED State Definitions

LEDs on the Sound Base and DCU provide information about the state of the conference phone.

For example, green flashing lights on the Sound Base and on the DCU Call button indicate that there is an incoming call. If the conference phone is on mute, then an incoming call will still flash green on the Call button, but the LED for the DCU mute button is solid red, the sound base LEDs are solid red, and the mute button on the Sound Base is also solid red.

The following table is a guide to the behaviour of the LEDs on the sound base and the DCU.

Table 1: Conference Phone LED State Table

Media Path Status	Call on Focus	Sound Base				Display Control Unit (DCU)			
		Base LEDs (3)		Mute Button		DCU Call Button		DCU Mute Button	
Off	No call								
Off	No call, with VM					red	solid		
Off	DND flash	green	flash			green	flash		
Off	Incoming call	green	flash			green	flash		
Off	Hold Revert Call	green	flash			green	flash		
Off	Hold Call	green	pulse			green	pulse		
Off	Hold Remote Call					red	pulse		
Off	Remote in use Call					red	solid		
Unmuted	Ringout/Connected Call	green	solid			green	solid		
Unmuted	DNDFlash	green	solid			green	flash		
Unmuted	Incoming Call	green	solid			green	flash		
Unmuted	Hold Revert Call	green	solid			green	flash		
Muted	Ringout/Connected	red	solid	red	solid	green	solid	red	solid
Muted	DND Flash	red	solid	red	solid	green	flash	red	solid
Muted	Incoming Call	red	solid	red	solid	green	flash	red	solid

Media Path Status	Call on Focus	Sound Base				Display Control Unit (DCU)			
		Base LEDs (3)		Mute Button		DCU Call Button		DCU Mute Button	
Muted	Hold Revert Call	red	solid	red	solid	green	flash	red	solid
Deep Sleep Mode	Deep Sleep Mode			gray	solid				

Display Control Unit

The Display Control Unit (DCU) is tethered to the Sound Base via a micro USB connector.

You can use the graphic and table below to identify buttons and hardware on the DCU.



Table 2: Display Control Unit Buttons and Softkeys

	Item	Description
1	Phone screen	LCD screen that displays conference phone menus and features.
2	Softkeys	Four programmable keys.
3	Navigation bar with Select key	2-way Navigation bar and Select key that allows you to scroll menus and select items on the display.

	Item	Description
4	Call button	LED backlit call button. Press this key to: <ul style="list-style-type: none"> • Go Off Hook • Answer an incoming call • Obtain a dial tone to initiate a call • Resume a call • Release a call
5	Keypad	Allows you to dial phone numbers and enter letters.
6	Mute button	Toggles the Mute feature. A red backlight indicates a call is on mute.
7	Volume rocker	2-way rocker switch that raises the volume of the speaker.



Note For details on DCU LED behavior, see [LED State Definitions, on page 7](#).

Sound Base


The Sound Base provides 360 degree audio coverage via four built-in microphones and supports a full duplex speaker phone.

To provide enhanced room coverage, two sound base units can be linked together.

You can use the graphic and table below to identify buttons and connections on the Sound Base.



Table 3: Sound Base Buttons

	Item	Description
1, 2, 3	LED indicators	Three LED indicators provide call status information. For details on LED behaviour, see LED State Definitions, on page 7 .
4	Mute button 	Backlit mute button.

Wireless Extension Microphone and Charger Kit

The optional wireless extension microphone and charger kit unit contains two omni-directional wireless microphones, a charger unit, and two country-specific AC power clip adaptors for powering the charger unit. Connecting a microphone kit enhances the room coverage of the conference station.



Note The Cisco Unified IP Conference Phone 8831NR does not support wireless microphones.






Table 4: Wireless Microphone and Charger Buttons and Features

Item	Description
1	Omni-directional wireless microphones
2	LED charge status indicator
3	Charger tray
4	Mute button
5	Battery compartment
6	Charging contacts



Note See the FCC ID approval number under the Battery Cover for CP-MIC-WRLS-S-US= Wireless Microphone. FCC ID: LDKMICWR0776



Note See the Canada IC approval number under the Battery Cover for the CP-MIC-WRLS-S-US= Wireless Microphone. IC: 2461B-MICWR0776

Wireless Microphone LED

The Wireless Microphone has a single, tricolor LED.

Color	Meaning
Red	When the microphone is in the charger, the battery is charging.
Green, flashing	When the microphone is not in the charger, the microphone is paired with the base
Green, steady	When the microphone is in the charger, the battery is fully charged.
Red, amber, and green, flashing in sequence	The microphone is not paired with the base.

Wired Extension Microphone Kit

The optional wired extension microphone kit includes two wired omni-directional microphones. Connecting a microphone kit enhances the room coverage of the conference phone. The sound base has two wired microphone ports and you can connect one or both wired microphones.

If the conference phone is connected to another sound base in Linked Mode, the primary base station supports one or two wireless microphones, or it supports one wired microphone. The secondary unit supports only one wired microphone; a wireless microphone cannot be connected to a secondary Sound Base. You cannot mix microphone kits: if you plan to connect a microphone to both sound bases, they must both be wired microphones.



Note Wired and wireless microphones cannot be used at the same time, and the wireless microphones have a higher priority. Attempting to connect a wired microphone to a conference phone that has paired or connected channels results in a warning to the user that the wired microphone is disabled. To solve this problem, unpair any paired or connected wireless microphones before connecting a wired microphone.



Table 5: Wired Microphone Buttons

Item	Description
1	Mute button.

Phone Screen

The DCU contains the LCD phone screen. The idle or home screen displays information about the status of calls and features.

If the conference phone is in an offline state, the idle screen displays the message `Phone is not registered` and the **Apps** softkey remains available.

You can use the graphic and table below to identify the features and functions available on the screen.












Table 6: Phone Screen Layout.

	Item	Description
1	Header	Displays date, time, and current directory number. Displays menu name when applicable.
2	Line details and other phone information	Displays line label, call details, and status messages such as missed calls, message waiting, and line forwarding information.
3	Call State icon	Indicates the status of a call, such as ringing, hold, encrypted or connected call.
4	Softkey labels	Displays softkeys for currently available features or actions.
5, 6	Feature icons	These icons are displayed when an associated feature, such as extension microphones (5) or Link mode (6) is connected.

Phone Screen Icons

Table 7: Phone Screen Icons

Icon	Description
	On hook
	Off hook
	Ringing in
	Connected
	Hold
	Shared line
	Microphone connected
	Linked mode
	Encrypted

Phone Screen Cleaning



Caution

Use only a soft, dry cloth to wipe your conference station display screen. Do not use any liquids or powders on the phone, as they can contaminate phone components and cause failures.

Phone Connections

The Sound Base contains the network and power connection for the phone. The base also contains the mini-USB connection for the DCS, the wired microphone ports, and the daisy chain port for the Linked Mode feature.

You can use the graphic and table below to identify connections and ports on the Sound Base.





Table 8: Sound Base Connections and Ports

	Item	Description
1	Network port	Network port (10/100 SW) connection. IEEE 802.3af power enabled.
2	Wall power	Local power connection.
3	Mini USB port	Connects the base station to the DCU. Attention When connecting the USB cable, firmly press down on the ferrite bead to ensure it seats correctly between the posts.
4	Wired microphone ports	Two RJ11 microphone ports. An optional wired microphone can be connected to each port.
5	Linked Mode daisy chain port	Supports the connection of two base stations in Linked Mode.

Connect Mini-USB Cable to DCU

The following images show how to install the USB cable.

Install Ferrite Bead on Network Cable




Procedure

-
- Step 1** Insert the mini-USB connector into the port on the base of the phone.
 - Step 2** Seat the ferrite bead between the posts and press the bead down firmly.
 - Step 3** Thread the cable in the cable channel. Make sure that you leave some slack in the cable.
-

Install Ferrite Bead on Network Cable

The following images show how to install the ferrite bead on the network cable.



Procedure

-
- Step 1** Align the ferrite bead with the head of the network cable and move the ferrite bead along the cable until there is a gap of 1.0 mm +/- 0.3 mm between the bead and the connector.
- Step 2** Place the cable into the ferrite bead channel and loop the cable around the ferrite bead so that the cable exits the bottom of the bead.
- Step 3** Hold the cable in the ferrite bead channel and close the ferrite bead. Snap the latch closed.
-

Wireless Microphone Setup and Use

When you remove the wireless microphone from the charger, the microphone automatically turns on and tries to connect to the base. If the microphone is not paired, then pair it to the phone.

The Cisco Unified IP Conference Phone 8831NR does not support wireless microphones.

When battery is removed from the microphone or the battery dies, the microphone unpairs from the phone. Pair it to the phone again.

You can only charge the wireless microphone battery in the charger. You cannot use the wireless microphone when it is in the charger.

LEDs on the wireless microphone base indicate the connection status of the microphone, and an icon will also be displayed on the conference phone screen. The LEDs and the display screen also indicate the mute status of the wireless microphone.

If the conference phone is connected to another sound base in Linked Mode, you can connect a single wireless microphone to the primary base. Only a single wired microphone can be connected to the secondary sound base.



Note Wired and wireless microphones cannot be used at the same time, and the wireless microphones have a higher priority. Attempting to connect a wired microphone to a conference phone that has paired or connected channels results in a warning to the user that the wired microphone is disabled. To solve this problem, unpair any paired or connected wireless microphones before connecting a wired microphone.

Pair the Wireless Microphone

You must pair the wireless microphone with the base before it can be used.

Before you begin

The wireless microphone must be turned off. See [Power Off the Wireless Microphone, on page 19](#)

Procedure

- Step 1** On the base, press **Apps**.
 - Step 2** Select **Admin Settings > Wireless Microphone** and select **Wireless Microphone 1** or **Wireless Microphone 2**.
 - Step 3** Press **Pair**.
 - Step 4** On the wireless microphone, hold the **Mute** button until the LED is solid red and then release the button.
The base pairs with the microphone and the result is displayed on the screen.
-

Set the Wireless Microphone range

You can change the baseband power and effective RF range of the wireless microphones. By default, the range is set to High.

Procedure

- Step 1** On the base, press **Apps**.
 - Step 2** Select **Admin Settings > Wireless Microphone > Wireless Microphone Range**
 - Step 3** Select **Low**, **Medium**, or **High**
 - Step 4** Press **Select**.
-

Power Off the Wireless Microphone

You should turn off the wireless microphone when you do not need it, to preserve battery life.

Procedure

- Step 1** Press and hold the **Mute** button for 10 seconds.
- Step 2** Release the button when the LED turns red.
-

Recharge the Wireless Microphone Battery

You can only charge the wireless microphone battery in the charger. You cannot use the wireless microphone when it is in the charger.

While the battery is charging, the LED lights red. When the battery is fully charged, the LED lights green.

When you remove the wireless microphone from the charger, the microphone automatically turns on and tries to connect to the base. If the microphone is not paired, you need to pair the microphone.

Procedure

Place the microphone in the charger. The microphone automatically unlinks from the base and turns off.

General IP Phone Information

Power-Saving Mode

Your conference station supports the Cisco EnergyWise (EW) program. Your system administrator sets up sleep (power down) and wake (power up) times for your conference station to save energy. In the sleep state, the LED for the sound base Mute button becomes solid gray, and the DCU powers off.

Ten minutes before the scheduled sleep time, you receive a message that the conference station will power down at a specific time. If the power-saving mode is enabled by your system administrator, you hear your ringtone play. The ringtone plays according to the following schedule:

- At 10 minutes before power down, the ringtone plays four times
- At 7 minutes before power down, the ringtone plays four times
- At 4 minutes before power down, the ringtone plays four times
- At 30 seconds before power down, the ringtone plays 15 times or until the phone powers down

If your conference station is inactive (idle) at the sleep time, it powers down. If your conference station is active (for example, on a call), it waits until it has been inactive for a period of time before removing power.

After the conference station goes to sleep, press the Mute button on the sound base to wake the conference station up. You cannot wake the conference station using the DCU. After the conference station is inactive for a period of time, it goes back to sleep. At the set wake time, the conference station powers up.

Wake and sleep times are also linked to the configured days that you normally work. If your requirements change (for example, your work hours or work days change), contact your system administrator to have your conference station reconfigured.

For more information about EnergyWise and your conference station, contact your system administrator.

Feature Availability

Depending on the conference station system configuration, features included in this guide might not be available to you or might work differently on the conference station. For information, contact your system administrator.

Accessibility Features

The Cisco Unified IP Conference Phone 8831 and 8831NR provides accessibility features for the blind, and the visually, hearing, and mobility impaired. Because many of these features are standard, they can be used by users with disabilities without requiring any special configuration.

The term *phone support pages* refers to the web pages that users can access to set up certain features. For Cisco Unified Communications Manager (Release 10.0 and later), these pages are the Self Care Portal. For Cisco Unified Communications Manager (Release 9.1 and earlier), these pages are the User Options web pages.

Cisco is committed to designing and delivering accessible products and technologies to meet the needs of your organization. You can find more information about Cisco and its commitment to accessibility at this URL: <http://www.cisco.com/go/accessibility>

Hearing Impaired Accessibility Features

Your conference phone comes with standard accessibility features that require little or no setup.




Table 9: Hearing-Impaired Accessibility Features

Item	Accessibility Feature	Description
1	Visual message-waiting indicator	<p>When you have a message, a message is displayed on the phone screen. Your phone also provides an audible message-waiting indicator.</p> <p>To change the audible voice-message indicator, sign in to the Self Care portal and access the message-indicator settings. You can change each setting to on or off.</p> <p>Your administrator can also change your settings.</p>
2	Visual notification of phone state	<p>The phone screen displays the current state and the LED bar displays:</p> <ul style="list-style-type: none"> • Green, solid—Active call • Green, flashing—Incoming call • Green, pulsing—Held call • Red, solid—Muted call
3	Adjustable ringtone, pitch, and volume	<ul style="list-style-type: none"> • Select Applications > Preferences to change the ringtone. • Adjust the volume level for the phone ring. When not in a call, press Volume to raise or lower the volume. <p>Your administrator can also change your settings.</p>

Vision-Impaired and Blind Accessibility Features

Your phone comes with standard accessibility features that require little or no setup.




Table 10: Vision-Impaired and Blind Accessibility Features

Item	Accessibility Feature	Description
1, 11	High-contrast visual and audible alert of incoming call	Alerts you to an incoming call. The LED flashes during incoming calls. Colors indicate your phone's status: <ul style="list-style-type: none"> • Green, solid—Active call • Green, flashing—Incoming call • Green, pulsing—Held call • Red, solid—Muted call
2, 8, 10	Mute button	Use the Mute button to toggle the microphone on or off. When the microphone is muted, the button lights red. When you turn on Mute, your phone beeps once; when you turn off Mute, your phone beeps twice.
3	Back-lit grayscale LCD screen with adjustable contrast on the Cisco IP Phone	Allows you to adjust your phone screen's contrast.

Item	Accessibility Feature	Description
4	Softkeys <ul style="list-style-type: none"> • These are large buttons just below the LCD. 	Provide access to special functions. The functions are displayed on the LCD.
5	Navigation Cluster (includes the Navigation bar and the Select button) <ul style="list-style-type: none"> • The Navigation cluster is located to the right of the keypad. 	Use the Navigation bar to move up and down in the phone LCD. The Select button is in the center of the Navigation bar.
6	Standard 12-key layout	Allows you to use existing or familiar key positions. Key 5 has a nib.
7	Volume key <ul style="list-style-type: none"> • This key is located to the left of the keypad. 	Allows you to increase or decrease the ring volume or the sound. Press up on the rocker key to increase the volume. Press down on the rocker key to decrease the volume.

Mobility-Impaired Accessibility Features

Your conference phone comes with standard accessibility features that require little or no setup.




Table 11: Mobility-Impaired Accessibility Features

Item	Accessibility Feature	Description
1	LED	Indicates your phone's status: <ul style="list-style-type: none"> • Green, solid—Active call • Green, flashing—Incoming call • Green, pulsing—Held call • Red, solid—Muted call
2	Tactile-discernible buttons and functions, including a nib on Key 5	Allow you to easily locate your phone's keys. For example, Key 5 has a nib, which you can use to locate other key positions.

Cisco Unified Communications Manager Accessibility Features

The following table provides information on the Cisco Unified Communications Manager (Cisco Unified CM) accessibility features. For more information, see the user guide applicable to your phone.

Accessibility Feature	Description	Configuration Requirements
Programmable Line Key (PLK)	<p>You can use the line buttons to initiate, answer, or switch to a call on a particular line. A limited number of features, such as speed dial, extension mobility, privacy, Busy Lamp Field (BLF) speed dial, Do Not Disturb (DND), and Service URLs, get assigned to these buttons.</p> <p>The PLK feature expands the features that can be assigned to the line buttons to include those that softkeys normally control; for example New Call, Call Back, End Call, and Forward All. When these features are configured on the line buttons, they are always visible, so you can have a “hard” New Call key.</p> <p>You can access features easily that may be assigned to softkeys normally, which can be too small and difficult to use.</p>	<p>Standard on all Cisco IP Phones; configuration is required.</p> <p>Your administrator assigns PLKs to your phone.</p>


Accessibility Feature	Description	Configuration Requirements
Audible Message Waiting Indicator (AMWI)	<p>Cisco Unified IP Phones can send a line-specific stutter dial tone when a voice message is waiting on the phone. You hear it only when using the line with the waiting messages. When you go off hook (on the line for which a voice message has been left), the stutter dial tone is heard.</p> <p>You can change the audible voice-message indicator setting by logging in to your phone support pages, and changing the audible message-indicator setting to On or Off.</p>	<p>Standard on all Cisco IP Phones.</p> <p>Configuration is required:</p> <ul style="list-style-type: none"> • administrator • phone support pages
Do Not Disturb (Alert and Reject)	<p>Your administrator configures the phone to turn on all audible and visual notifications, turn on ringer only, or to choose the type of alert a phone should play for incoming calls.</p>	<p>Standard on all Cisco IP Phones; configuration is required.</p>
Busy Lamp Field	<p>You can use the Busy Lamp Field (BLF) feature to monitor the call state of a directory number (DN) associated with a speed-dial button, call log, or directory listing on the phone.</p> <p>In addition, you can use BLF pickup to monitor incoming calls on a directory number.</p> <p>When the DN receives an incoming call, the system alerts the you so that you can then pick up the call.</p>	<p>Standard on all Cisco IP Phones; configuration is required.</p>
<p>Phone support pages:</p> <ul style="list-style-type: none"> • User Options web pages (Cisco Unified CM 9.1 and earlier) • Self Care Portal (Cisco Unified CM 10.0 and later) 	<p>The Cisco IP Phone is a network device that enables you to do the following actions:</p> <ul style="list-style-type: none"> • Share information with other network devices in your company, including your personal computer. • Use your computer to log in to your phone support pages, where you can subscribe to services, set up speed dial and call forwarding numbers, configure ring settings, and create a personal address book. 	<p>Standard on all Cisco IP Phones; configuration is required.</p>

Additional Options

Your system administrator can configure your Cisco Unified IP Conference Phone 8831 and 8831NR to use specific button and softkey templates along with special services and features, if appropriate. This table

provides an overview of some configuration options that you might want to discuss with your administrator based on your calling needs and work environment.

If You...	Then...	For More Information...
Need to handle more calls on the conference station line	Ask your administrator to configure your line to support more calls. Note Your conference station supports a maximum of 6 calls.	Contact your administrator or phone support team.
Want to use one extension for several phones	Request a shared line. This allows you, for example, to use one extension for your desk phone and lab phone.	See Shared Lines, on page 65
Share conference stations or office space with coworkers	Consider using: <ul style="list-style-type: none"> • Call Park to store and retrieve calls without using the transfer feature. • Call Pickup to answer calls ringing on another phone. • A shared line to view or join coworkers' calls. • Cisco Extension Mobility to apply the conference station number and user profile to a shared conference station. 	Contact your administrator about these features and see the following: <ul style="list-style-type: none"> • Call Park, on page 48 • Call Pickup, on page 49 • Shared Lines, on page 65 • Cisco Extension Mobility, on page 55
Want to temporarily apply the conference station number and settings to a shared conference station	Ask your administrator about the Cisco Extension Mobility Service.	See Cisco Extension Mobility, on page 55
Want to extend the area covered by audio	Ask your administrator about: <ul style="list-style-type: none"> • Linking to another Conference Station sound base • Adding a Wireless Extension Microphone Kit • Adding a Wired Extension Microphone Kit Note The Cisco Unified IP Conference Phone 8831NR does not support wireless microphones.	See <ul style="list-style-type: none"> • Linked Mode, on page 31 • Enhanced Room Coverage, on page 53



CHAPTER 3

Applications

- [Services, on page 27](#)
- [Call History, on page 27](#)
- [Preferences, on page 30](#)
- [Linked Mode, on page 31](#)
- [IP Phone Information, on page 32](#)
- [Administrator Settings, on page 33](#)

Services

Conference Station services can include special telephony features, network data, and web-based information. The services available for your phone depend on the system configuration and the services you are subscribed to. For more information, contact your system administrator.

Access Services

Procedure

- Step 1** Press **Apps**.
 - Step 2** Use the Navigation bar and Select button to scroll and select the service you want to access.
 - Step 3** Press the **Select** softkey, or press **Exit** to return to the Applications screen.
-

Call History

Call History allows you to view information about calls made to and from the conference station. A call state icon is displayed to indicate the type of call:

- Received
- Placed
- Missed

The history stores a maximum of 50 records for each history type.

The caller ID displays with the call icon. If the caller ID is unavailable, then the phone number displays. If the phone number is unavailable, then the message `Unknown` displays. All Call History items are integrated into one list and are ordered by time (latest to oldest).

You can dial a number directly from the Call History list.

If set up by your administrator, the Call History logs the received and placed calls from shared lines. To view the call history logs, open the Call History screen.


View Call History

Procedure

- Step 1** Press **Apps**.
 - Step 2** Use the Navigation bar and Select button to scroll and select **Call History**.
-

View Call Record Details

Procedure

- Step 1** Press **Apps**.
 - Step 2** Use the Navigation bar and Select button to scroll and select **Call History**.
 - Step 3** Select a call record and press **Details**.
If the **Details** softkey is not visible on the screen, press **More** first.
 - Step 4** Press  to return to the Call History list.
-



Dial from Call History

Procedure

- Step 1** Press **Apps**.
 - Step 2** Use the Navigation bar and Select button to scroll and select **Call History**.
 - Step 3** From the Call History list, select the call you want to dial and press **Call**.
-

Edit Phone Number

Procedure

- Step 1** Press **Apps**.
- Step 2** Use the Navigation bar and Select button to scroll and select **Call History**.
- Step 3** Select the call you want to edit.
- Step 4** Press **Edit Dial**
- Step 5** Press >> to move the cursor to the right and press << to move the cursor to the left.
- Press the Up arrow of the Navigation bar to place the cursor before the left-most character.
 - Press the Down arrow of the navigation bar to place the cursor after the right-most character.
- Step 6** Press  to delete numbers.
- Step 7** Press **Dial** to dial the edited number.
- Step 8** Press  to return to the Call History list.
-

Clear Call History

Procedure

- Step 1** Press **Apps**.
- Step 2** Use the Navigation bar and Select button to scroll and select **Call History**.
- Step 3** Press **Clear**.
- Step 4** Press **Delete** to delete the Call History list, or press **Cancel** to go back to the Call History screen.
-

Delete Call Record

Procedure

- Step 1** Press **Apps**.
- Step 2** Use the Navigation bar and Select button to scroll and select **Call History**.
- Step 3** Select the call you want to delete.
- Step 4** Press **Del Call**.
- Step 5** Press **Delete** to delete the call, or press **Cancel** to go back to the Call History screen.
-


Preferences

Ringtones

You can customize how the conference station indicates an incoming call and a new voice mail message. You can also adjust the ringer volume. In addition to the default ringtone, you can customize your phone to have up to six distinctive ring tones. Ring tone preferences can be set directly on your phone or from Cisco Unified Communications Manager Self Care Portal.

Change Ringtone

Procedure

- Step 1** Press **Apps**.
 - Step 2** Use the Navigation bar and Select button to scroll and select **Preferences**.
 - Step 3** Select **Ringtone**.
 - Step 4** Select a ringtone.
 - Step 5** Press **Play** to play the selected ringtone.
 - Step 6** Press **Set** to select the ringtone.
 - Step 7** Press **Apply** to confirm your selection, or press **Cancel** to go back to the Ringtone screen.
 - Step 8** Press  to return to the Preferences screen.
-

Contrast

You can adjust the contrast level of the LCD screen. The default contrast level is 50%.

Adjust Contrast

Procedure

- Step 1** Press **Apps**.
 - Step 2** Use the Navigation bar and Select button to scroll and select **Preferences**.
 - Step 3** Select **Contrast**.
 - Step 4** To increase contrast, press the up arrow on the Navigation bar. To decrease contrast, press the down arrow.
 - Step 5** Press **Save** to set the contrast level, or press **Cancel** to exit.
-

Linked Mode

Two conference phone Sound Base units can be linked together to expand the audio coverage area. One Sound Base acts as the primary device, and the other unit acts as the dependant or secondary device.

In Linked Mode, the primary base station supports either one wireless or one wired microphone. The secondary unit supports only one wired microphone. You cannot mix microphone kits: if you plan to connect a microphone to both sound bases, they must both be wired microphones.

The Cisco Unified IP Conference Phone 8831 supports wired and wireless microphones. The Cisco Unified IP Conference Phone 8831NR supports only wired microphones.

The voice, dial tone, ringer, and base LED features synchronize between the two devices when linked together. You can link two sound bases while a call is active.

When Linked Mode is active, the linked mode icon displays in the idle and the call screens.

The following table summarizes the best practice to follow when deploying your conference phones in Linked Mode. If the devices are linked in this manner, the system software automatically detects which device is to be used as the primary and which is the secondary one.

Table 12: Linked Mode Setup Best Practice

Component	Connect to Primary	Connect to Secondary
Display Control Unit (DCU)	Yes	No
Network cable	Yes	No
Wall power	Yes	No
Optional Wired Microphone	Yes	Yes
Optional Wireless Microphone	Yes	No



Note If a DCU is connected to the secondary device, it will display a prompt indicating that it is a dummy DCU, but will otherwise not function.



Caution When using a Sound Base in Linked Mode, the primary base unit must be connected using the CP-PWR-CUBE-3 external power supply.

If two devices are linked after both are registered, the user can select which is the primary device.

A secondary device receives upgrades to firmware seamlessly from the primary device.

Link Conference Phones

Use a daisy cable to connect two sound base units in Linked mode. This procedure describes the best practice for connecting the two units.

Procedure

Step 1 Connect the DCU to the conference phone to be used as the primary unit.

Step 2 Connect the network cable to the conference phone to be used as the primary unit.

Step 3 Connect the power cable to the primary device and plug into a wall plug.

The secondary Sound Base does not need to be plugged into external power, but in Linked Mode the primary unit must be connected to external power.

Step 4 Use the provided daisy cable to connect the primary unit to the secondary sound base.

Voice, dial tone, ringer and base LEDs synchronize between the two units.

Related Topics

[Linked Mode](#), on page 31

IP Phone Information


Phone Information allows you to view the following model information for your phone:

- Model Number
- IP Address
- MAC Address
- Active Load
- Inactive Load
- Last Upgrade
- Active Server
- Stand-by Server
- Mic 1 status
- Mic 2 status
- Wireless Mic 1 RF ID
- Wireless Mic 2 RF ID
- System RF ID
- Linked Mode status
- Backlight On Time
- Backlight On Duration
- Backlight Idle Timeout
- Days Backlight Not Active

To access information about your phone press **Apps** and scroll to Phone Information.

Administrator Settings

For information on accessing and changing the Administrator Settings, contact your system administrator.



CHAPTER 4

Contacts

- [Contacts Overview](#), on page 35
- [Corporate Directory](#), on page 35
- [Personal Directory](#), on page 36

Contacts Overview

Depending on configuration, the conference station provides corporate and personal contacts directories:

- **Corporate Contacts:** Supports a global corporate directory that you can access on the conference station. Your system administrator sets up and maintains this feature.
- **Personal Contacts:** If available, supports a personal address book. You can configure and access entries from your conference station and from Cisco Unified Communications Manager Self Care Portal.

Corporate Directory

You can use a corporate directory to place calls to coworkers. You can dial a call from the corporate directory even if you are on another call.

The system administrator sets up and maintains the directory.

Tips

Use the numbers on your keypad to enter characters on the conference station screen and use the Navigation bar to move between input fields.

Dial Contact from Search

Procedure

- Step 1** Press **Contacts**.
- Step 2** Use the Navigation bar and Select button to scroll and select **Corporate Directory**.
- Step 3** Select any of these criteria to search for a coworker:

- First name
- Last name
- Number

Step 4 Enter the search criteria information, press **Search**, and select a contact.

Step 5 To dial a contact, perform one of these actions:

- Press **Dial**.
 - Press the contact label number.
 - Press the **Call** key on the DCU.
-

Dial Contact from Search During an Active Call

Procedure

Step 1 Press **Contacts**.

Step 2 Use the Navigation bar and Select button to scroll and select **Corporate Directory**.

Step 3 Select any of these criteria to search for a coworker:

- First name
- Last name
- Number

Step 4 Enter the information, then select **Search > Dial**.

Step 5 Perform one of these actions to handle the original call:

- Dial the second call to automatically put the first call on hold.
 - Press **Transfer** to transfer the first party to the second and drop yourself from the call. To complete the action, press **Transfer** again after dialing.
 - Press **Conference** to create a conference call with all parties, including you. To complete the action, press **Conference** again after dialing.
 - Press **End Call** to disconnect the first call and dial the second.
-

Personal Directory

The personal directory, or address book (PAB), contains a list of your personal contacts.

The PAB supports a maximum of 99 entries. For each entry you can store:

- Contact name
- Phone number

There are two ways to set up and maintain your personal directory:

- Directly on the conference station
- Using Cisco Unified Communications Manager Self Care Portal

The system administrator provides the user ID and the PIN that you use to log into the personal directory.

Tips

- Personal Directory automatically logs you out after a certain amount of time. This time limit can vary. For more information, contact your system administrator.
- Use the numbers on the keypad to enter characters on the conference station screen.
- Use the Navigation bar button on the conference station to move between input fields.

The conference station may be set up for international call logging, which is indicated by a plus (+) symbol on the call logs, redial, or call directory entries. For more information, contact your system administrator.

Personal Directory Options

The following sections describe the personal directory options.

Sign In and Out of Personal Directory

The conference station automatically logs you out of the PAB after a certain amount of time. This time limit can vary. For more information, contact your system administrator.

Procedure

- Step 1** Press **Contacts**.
 - Step 2** Use the Navigation pad and Select button to scroll and select **Personal Directory**.
 - Step 3** Enter the user ID and PIN provided by your system administrator and press **Submit**.
 - Step 4** To logout, select **Log Out**, press **Select**, and then press **OK**.
-

Add Personal Directory Entry

Procedure

- Step 1** Press **Contacts**.
- Step 2** Sign in to Personal Directory.

- Step 3** Select **Personal Address Book**.
The Search for an entry screen displays.
- Step 4** Press **Submit**.
- Step 5** Press **New**. You may need to press **More** first.
- Step 6** Enter the Name information.
- Step 7** Press **Phones** and enter the phone numbers.
Make sure you include any required access codes, such as 9 or 1.
- Step 8** Press **Submit** to add the entry to your personal directory.

Related Topics

- [Sign In and Out of Personal Directory](#), on page 37
- [Assign Fast-Dial Code to PAB from the Phone](#), on page 39

Search for Entry in Personal Directory

Procedure

- Step 1** Press **Contacts**.
- Step 2** Sign in to Personal Directory.
- Step 3** Select **Personal Address Book**.
- Step 4** Select the search criteria and press **Submit**.

Related Topics

- [Sign In and Out of Personal Directory](#), on page 37
- [Dial Number from Personal Directory](#), on page 38

Dial Number from Personal Directory

Procedure

- Step 1** Press **Contacts**.
- Step 2** Sign in to Personal Directory.
- Step 3** Select **Personal Address Book** and search for an entry.
- Step 4** Select the personal address book entry that you want to dial.
- Step 5** Press **Select**.
- Step 6** Press **Dial**.
-

Delete Personal Directory Entry

Procedure

- Step 1** Press **Contacts**.
 - Step 2** Sign in to Personal Directory.
 - Step 3** Select **Personal Address Book** and search for an entry.
 - Step 4** Press **Select**.
 - Step 5** Press **Edit**.
 - Step 6** Press **Delete**.
 - Step 7** Press **OK** to confirm the deletion.
-

Edit Personal Directory Entry

Procedure

- Step 1** Press **Contacts**.
 - Step 2** Sign in to Personal Directory.
 - Step 3** Select **Personal Address Book** and search for an entry.
 - Step 4** Press **Select**.
 - Step 5** Press **Edit**.
 - Step 6** Modify the entry information.
 - Step 7** Press **Phones** to modify a phone number.
 - Step 8** Press **Update**.
-

Fast-Dial Codes with Personal Directory

Fast-Dial codes enable you to place calls quickly. You can assign a fast-dial code to an existing PAB entry, or you can assign a code directly to a phone number. Fast-Dial codes that are assigned to numbers rather than to PAB entries are labeled “raw” in Cisco Unified Communications Manager Self Care Portal. The following sections describe using the fast-dial codes with Personal Directory.

Assign Fast-Dial Code to PAB from the Phone

Procedure

- Step 1** Sign in to Personal Directory.
- Step 2** Use the Navigation bar and Select button to scroll and select an option.
- Step 3** Enter the name information and press **Submit**.

- Step 4** Select the name, then press **Select**.
 - Step 5** Press **FastDial**.
 - Step 6** Use the Navigation bar combined with **Next** and **Previous** to scroll and select a code.
 - Step 7** Press **Select** for a new fast-dial code that you want to assign to the number.
-

Place Call Using Fast-Dial Code


Procedure

- Step 1** Sign in to Personal Directory.
 - Step 2** Select **Personal Fast Dials**.
 - Step 3** Scroll to the fast dial code that you want to dial.
 - Step 4** Press **Dial**.
-

Delete Fast-Dial Code

Procedure

- Step 1** Sign in to Personal Directory.
 - Step 2** Select **Personal Fast Dials** and search for a fast-dial code.
 - Step 3** Select the fast-dial code to delete.
 - Step 4** Press **Remove**.
-



CHAPTER 5

Messages

- [Access Voicemail, on page 41](#)
- [Voice Message Identification, on page 41](#)
- [Access Voice Messages, on page 41](#)

Access Voicemail

Procedure

- Step 1** Press **Msgs**.
- Step 2** Follow the voice prompts.
-

Voice Message Identification


If you have a voice message, the Call button on the DCU is red and the phone screen displays the New Voicemail status message. You can also configure an audible message indicator using Cisco Unified Communications Manager Self Care Portal. If you have configured an audible message indicator, listen for a stutter tone when you try to place a call.

Access Voice Messages

Procedure

Press **Msgs** to listen to voice messages.

You may need to press **More** first.



CHAPTER 6

Calling Features

- [Softkey Feature Map, on page 43](#)
- [Answer, on page 46](#)
- [Call Back, on page 47](#)
- [Call Forward, on page 47](#)
- [Call Park, on page 48](#)
- [Call Pickup, on page 49](#)
- [cBarge, on page 50](#)
- [Conference, on page 51](#)
- [Divert, on page 52](#)
- [Do Not Disturb, on page 52](#)
- [Enhanced Room Coverage, on page 53](#)
- [Cisco Extension Mobility, on page 55](#)
- [Hold, on page 56](#)
- [Hold Reversion, on page 57](#)
- [Meet Me Conference, on page 58](#)
- [Mobile Connect, on page 59](#)
- [Monitoring and Recording, on page 60](#)
- [Multiple Calls per Line, on page 60](#)
- [Mute, on page 62](#)
- [On-Hook Dialing, on page 63](#)
- [Plus Dialing, on page 63](#)
- [Privacy, on page 64](#)
- [Quality Reporting Tool, on page 64](#)
- [Redial, on page 65](#)
- [Shared Lines, on page 65](#)
- [Transfer, on page 65](#)
- [Cisco WebDialer, on page 66](#)
- [Sign In to the Cisco Unified Communications Self Care Portal, on page 67](#)

Softkey Feature Map

Depending upon how your system administrator sets up your phone, not all features may be available to you, some features may be accessed from a different softkey, or additional softkey features are available.

The following table provides a guide to some of the softkey features that are commonly available for various call states. Also shown is the function of the Call button for the matching state.

Table 13: Feature Map

Call State	Softkey 1	Softkey 2	Softkey 3	Softkey 4	Call Button
Idle	Redial	New Call	Apps	More1	Off hook
	Contacts	Msgs	Fwd All	More2	
Ring in	Answer	Divert			Answer
On hook (pre-dial)	Cancel	Call		X	Dial
Off hook	Redial	Cancel	Apps	More1	On hook
	Contacts	Msgs	Calls	More2	
Ring out	Cancel	Callback			On hook
Connected	Hold	End Call	Apps	More1	On hook
	Contacts	Transfer	Conf	More2	
	ConfList	Park		Top	
On hold	Resume	New Call	Apps	More1	Resume
	Contacts	Msgs	Divert	Top	
Connected (multiple calls)	Hold	End Call	Apps	More1	On hook
	Contacts	Swap or Calls	Transfer	More2	
	Conf	ConfList	Park	Top	



Note The ConfList softkey displays only if you are in a conference.



Note The Calls softkey displays when more than two calls are connected. Pressing Calls loads a call list.

Survivable Remote Site Telephony Overview

If communication between the conference station and the Cisco Unified Communications Manager is interrupted, you receive an alert message on your phone. If you are on an active call, the call remains established, and you enter a failover situation. The Survivable Remote Site Telephony (SRST) feature handles this failover.

While in failover, not all the features of conference station are available. The following table describes typical features and feature availability. For more information about feature availability during failover, contact your system administrator.

When the conference station loses connectivity, it may display a message similar to this: SRST . Some features unavailable.

Table 14: Feature Support During Failover

Feature	Supported	Notes
New Call	Yes	
End Call	Yes	
Redial	Yes	
Answer	Yes	
Hold	Yes	
Resume	Yes	
Call Forward	No	This also applies to other forwarding features such as Call Forward All, Call Forward Busy, and Call Forward No Answer. If you press CFwdAll , the phone does not ring for all incoming calls.
Conference	Yes	
Conference to Active Calls (Join)	No	The Active Calls softkey is not displayed.
Conference List	No	
Transfer	Yes	Consult only.
Transfer to Active Calls (Direct Transfer)	No	
Auto Answer	Yes	
Call Waiting	Yes	
Caller ID	Yes	
Audible Message Waiting Indicator	Yes	
Unified Session Presentation	Yes	Conference is the only feature supported.
Voicemail	Yes	Your voicemail will not be synchronized with other users in the Cisco Unified Communications Manager cluster.
To Voicemail (Divert)	No	The Divert softkey is not displayed.

Feature	Supported	Notes
Park Monitoring	No	The Park softkey is not displayed.
Barge	No	You see the message That feature is not currently available.
Enhanced Message Waiting Indication	No	Message count badges do not appear on the phone screen. Only the Message Waiting icon displays.
Directed Call Park	No	The softkey is not displayed.
Hold Reversion	No	Calls remain on hold indefinitely.
Remote Hold	No	Calls appear as Local Hold calls.
Meet Me	No	The Meet Me softkey is not displayed.
PickUp	No	The softkey causes no action.
Group PickUp	No	The softkey causes no action.
Other PickUp	No	The softkey causes no action.
Malicious Call ID	No	The softkey causes no action.
QRT	No	The softkey causes no action.
Mobility	No	The softkey causes no action.
Privacy	No	The softkey causes no action.
Call Back	No	The Call Back softkey is not displayed.

Answer

Answer allows you to answer the oldest call that is available on the conference station, including Hold Reversion and Park Reversion calls that are in an alerting state. Incoming calls always have priority over Held or Park Reversion calls.

When you get a call, you see a notification on the conference station screen. The call notification remains visible for a preset amount of time. If there are multiple, simultaneous incoming calls, an incoming call list window is displayed, and you can select which call to answer.

To answer a call, press Answer or press the Call key.

If an incoming call has been call forwarded from another phone or conference station, you may see additional information to identify that the call has been forwarded. Your system administrator controls the amount of additional information displayed. Additional information can identify the person who forwarded the call to you and the caller information.

When you receive a call, the phone number that displays on the screen contains the string of digits that you can dial to contact the caller. The digit string can contain the following digits, if required:

- Code to obtain an outside line (for example, if you have to dial 9)
- Long-distance code
- Area code
- City code
- Telephone number

The conference station saves the complete digit string in the call history and you can save the number in your Personal Address Book.

Call Back

Call Back allows you to receive an audio and a visual notification on your conference station when a busy or unavailable party becomes available.

For more information, contact your system administrator.

Set Up Call Back Notification

Procedure

- Step 1** Press **Call back** while listening to the busy tone or ring sound. A confirmation screen displays on the phone.
 - Step 2** Press **Exit** to exit the confirmation screen. Your phone alerts you when the line is free.
 - Step 3** Press **Call** to place the call again.
-

Call Forward

Call Forward allows you to forward incoming calls from the conference station to another number.

There are two types of call forwarding features that the system administrator can set up for the conference station:

- Unconditional call forwarding (Call Forward All): Applies to all calls that you receive.
- Conditional call forwarding (Call Forward No Answer, Call Forward Busy, Call Forward No Coverage): Applies to certain calls that you receive.

If configured, you can set up Call Forward All from the conference station. Call Forward All can also be accessed remotely from your Cisco Unified Communications Manager Self Care Portal. Conditional call forwarding rules can only be accessed from Cisco Unified Communications Manager Self Care Portal.

When forwarding calls from your conference station:

- Enter the call forward target number exactly as you would dial it from the conference station. For example, enter an access code or the area code, if necessary.
- Call forwarding is line specific. If a call reaches you on a line where call forwarding is not enabled, the call rings as usual.
- For more details about the following configurable call forward options, contact your system administrator:
 - Allow calls placed from the call forward target number to the conference station to ring through, rather than be forwarded.
 - Prevent you from creating a call forward loop or exceeding the maximum number of links in a call forwarding chain.

Forward Calls

Procedure

- Step 1** Press **Fwd All**.
- Step 2** Enter the target phone number.
Depending on how your voicemail system is set up, you may be able to press **Msgs** to forward all calls to voicemail.
A visual confirmation displays on the screen while call forwarding is active.
- Step 3** To cancel call forwarding, press **Fwd OFF**.
- Step 4** To forward calls remotely or to set conditions on fall forwarding, go to your Cisco Unified Communications Manager Self Care Portal.
-

Call Park

Call Park allows you to use the conference station to park (temporarily store) a call. The parked call can be retrieved from another phone in the Cisco Unified Communications Manager system, such as a phone at a coworker's desk or in a conference room.

You retrieve a parked call by entering the parking number for the call into another phone in the Cisco Unified Communications Manager system.

Your system administrator sets up the parking number for the conference station.

Park Call

Procedure

- Step 1** During a call, press the **Park**.

The conference station screen displays the call park number where the system stored your call.

- Step 2** Note the call park number displayed on the screen. This number is used to retrieve the call.
You have a limited time to retrieve a parked call before it reverts to ringing at the original number.
- Step 3** From any other Cisco Unified IP Phone or conference station in your network, enter the call park number to retrieve the call.
-

Call Pickup

Call Pickup allows you to answer a call that is ringing on a coworker's phone by redirecting the call to your phone.

You might use Call Pickup if you share call-handling tasks with coworkers.

The ways to pick up a call are:

- **Pickup:** Allows you to answer a call that is ringing on another phone within your call pickup group. If multiple calls are available for pick up, the conference station picks up the oldest call first.
- **Group Pickup:** Allows you to answer a call on a phone that is outside your call pickup group by:
 - Using a group pickup number that is provided by your system administrator.
 - Dialing the number of the ringing phone.
- **Other Pickup:** Allows you to answer a call that is ringing on another phone within in your call pickup group or in an associated call pickup group.

Your system administrator assigns you to a call pickup group and sets the call pickup softkeys.

Answer Call Using Pickup

Procedure

- Step 1** Press **Pickup** to transfer a ringing call within your pickup group to the conference station.
- Step 2** If the call rings, press **Answer** to connect to the call.
-

Answer Call Using Group Pickup and Group Pickup Number

Procedure

- Step 1** Press **Group Pickup** to answer a call on a phone outside your pickup group.
- Step 2** Enter the group pickup number.

- Step 3** If the call rings, press **Answer** to connect to the call.
-

Answer Call Using Group Pickup and Phone Number

Procedure

- Step 1** Press **Group Pickup**.
- Step 2** Enter the number of the phone line with the call that you want to pick up.
For example, if the call is ringing on line 12345, enter **12345**.
- Step 3** If the call rings, press **Answer** to connect.
-

Answer Call Using Other Pickup

Procedure

- Step 1** Press **OPickup** to transfer a call in your pickup group or in an associated group to the conference station.
- Step 2** If the call rings, press **Answer** to connect.
-

cBarge

The cBarge feature allows you to add yourself to a call on a shared line and create a standard (ad hoc) conference.

Join Conference on Shared Line

Procedure

Press **cBarge**.
You may need to press **More** first.

Conference

Conference allows you to talk simultaneously with multiple parties.

When you are talking on a call, use Conference to dial another party and add them to the call.

Before completing a conference procedure, you can press **Cancel** to cancel the procedure.

As the conference host, you can remove individual participants from the conference. You can also view a list of participants.

The conference ends when all the participants hang up.

Add Third Party to Conference

Before you begin

Before you can add a party to the conference, you must be on an active call and not on hold.

Procedure

- Step 1** Press **Conf**.
 - Step 2** Enter the phone number for the party you want to add.
If you have several held calls, you can press **Calls** to display a caller list and add a caller to the conference.
 - Step 3** After the new party answers, press **Conf**.
The conference begins.
 - Step 4** (Optional) Repeat these steps to add more parties, if desired.
-

View Conference Participants

Procedure

While in a conference, press **ConfList** to view a list of the last 16 participants who have joined the conference.

The maximum number of participants that can be displayed is 16. If there are more than 16 participants, only the most recent 16 participants to join display.

Remove Conference Participants

Procedure

Step 1 While in a conference, press **ConfList** to view a list of participants.

Step 2 Highlight the participant that you want to remove and then press **Remove**.

Note Only the most recent 16 conference participants display.

Divert

Divert allows you to send an active or ringing call to your voicemail system or to a predetermined phone number. Your system administrator configures this feature and sets the receiving phone number.

Divert Call

Procedure

Press **Divert** to send an active call, an incoming call, or a held call to either your voicemail system or to a predetermined phone number set up by your system administrator.

Do Not Disturb

Do Not Disturb (DND) allows you to turn off notification of incoming calls. The ringer, as well as audible and visual notifications, can be turned off.

Depending on how your administrator has configured this feature, incoming calls are either immediately rejected, or the caller information displays on screen.

The system administrator configures the DND softkey, but you can change your DND options from Cisco Unified Communications Manager Self Care Portal.

DND interacts with other types of calls:

- If both DND and Call Forward All are enabled, calls are forwarded without any visual or audible confirmation.
- DND does not affect priority calls.

Turn DND On and Off

Procedure

-
- Step 1** Press **DND** to turn on DND.
Visual confirmation displays briefly.
- Step 2** Press **DND** again to turn off DND.
Visual confirmation displays briefly.
-

Enhanced Room Coverage

Optional microphone extension kits provide enhanced room coverage that can be further expanded by linking two units together in Linked Mode. This feature allows you to use the conference station in a larger room, or to enhance the audio and voice experience for larger groups of in-person attendees.

The Cisco Unified IP Conference Phone 8831 supports wired and wireless microphones. The Cisco Unified IP Conference Phone 8831NR supports only wired microphones.

When two conference station base units are linked together to expand the audio coverage area, one conference station acts as the primary device and the other sound base is the dependant or secondary device. In Linked Mode, the primary base station supports one or two wireless microphones, or it supports one wired microphone. The secondary unit supports only one wired microphone; a wireless microphone cannot be connected to a secondary Sound Base. You cannot mix microphone types on the devices. Consult the following tables for allowable configurations.

Table 15: Deployment Configurations for Enhanced Room Coverage with a Single Phone

	Wired Extension Microphone	Wireless Extension Microphone
Number and type of connected microphones	1 or 2	--
	--	1 or 2

Table 16: Deployment Configurations for Enhanced Room Coverage in Linked Mode

	Primary Sound Base	Secondary Sound Base
Wired Extension Microphone	--	--
Wired Extension Microphone	--	1
Wired Extension Microphone	1	--
Wired Extension Microphone	1	1
Wireless Extension Microphone	--	--

	Primary Sound Base	Secondary Sound Base
Wireless Extension Microphone	1 or 2	--

Voice, dial tone, ringer, and base LED features synchronize between the two devices in Linked Mode.



Note Use a daisy cable to connect two sound base units in Linked Mode.

Related Topics

[Linked Mode](#), on page 31

Pair Wireless Microphone

Before you begin

The microphone must be in the off state before you can pair it to the conference station. A microphone is off if the microphone's LED is off. To turn off the wireless microphone, hold down the microphone button until the microphone LED turns solid red, then release.

Procedure

-
- Step 1** Choose **Apps > Admin Settings > Wireless Microphones**.
- Step 2** Select either Wireless Microphone 1 or Wireless Microphone 2.
- If the selected channel is available, a `Pair microphone 1?` or `Pair microphone 2?` prompt displays, and the **Pair** softkey displays.
- If a microphone is already linked to a particular channel, pairing cannot be initiated on the selected channel and the dialog shows that the microphone is linked.
- Step 3** Press **Pair**.
- If the channel is ready to pair, the pairing process begins and a text message displays.
- Step 4** Put the microphone that corresponds to the selected channel in pairing mode by pressing the microphone's Mute button until the LED lights solid red.
- If pairing succeeds, the screen reverts to the Wireless Microphones Menu, and the message `Mic X Paired Successfully!` displays.
- If pairing times out or fails, the status is updated and you can cancel or retry.
- Step 5** Press **Cancel** to revert to the Wireless Microphones Menu.
- Step 6** Press **Retry** to start the pairing process again.

Related Topics

[Unpair Wireless Microphone](#), on page 55

Unpair Wireless Microphone

If you need to connect a wired microphone to the conference station, any wireless microphones must be unpaired first. You can also use this procedure to unpair a microphone that is no longer in use.



Note This option is not available if the microphone is connected. To enable the unpair command, place the wireless microphone in its charger or turn it off.

Procedure

- Step 1** Choose **Applications > Admin Settings > Wireless Microphones**.
- Step 2** Select either Wireless Microphone 1 or Wireless Microphone 2.
If the selected channel is paired, the **Unpair** softkey displays.
- Step 3** Press **Unpair**.
A verification prompt with the options to Cancel or **Unpair** displays.
- Step 4** Press **Unpair** to continue to unpair the microphone.
The microphone channel's registration information in the base deletes. If you view the microphone channel's status in phone info menu, the status value and RFID are empty.
- Step 5** Press return to revert to the wireless microphones menu and stop the process.

Related Topics

[Pair Wireless Microphone](#), on page 54

Cisco Extension Mobility

Cisco Extension Mobility allows you to temporarily configure a Cisco Unified IP Phone or Conference Station to use as your own. After you log in to Extension Mobility, the new device adopts your user profile, features, established services, and web-based settings. Your system administrator must configure Extension Mobility for you.

The Cisco Extension Mobility ChangePIN feature allows you to change your PIN from your Cisco Unified IP Phone.

**Note**

- Extension Mobility automatically logs you out after a certain amount of time. Your system administrator establishes this time limit.
- Changes that you make to your Extension Mobility profile from Cisco Unified Communications Manager Self Care Portal take effect immediately if you are logged in to Extension Mobility on the physical device; otherwise, changes take effect the next time you log in.
- Changes that you make to a phone or conference station from Cisco Unified Communications Manager Self Care Portal take effect immediately if you are logged out of Extension Mobility; otherwise, changes take effect after you log out.
- Local settings controlled by the phone are not maintained in your Extension Mobility profile.

Enable Extension Mobility

Procedure


-
- Step 1** Press **Apps**.
- Step 2** Select **EM Service**.
- Step 3** Enter your user ID and PIN.
- The user ID and PIN are provided by your system administrator
- Step 4** If prompted, select a device profile.
- Step 5** To sign out, press **Apps**.
- Step 6** Select **Services**.
- Step 7** Select **EM Service**.
- Step 8** At the prompt, press **Yes**.
-

Hold

Hold allows you to put an active call into a held state. Your phone allows one active call at a time; other calls are put on hold.

Hold Active Call

Procedure

-
- Step 1** To put an active call on hold, press **Hold**.
- The Hold icon  displays as a status icon.

- Step 2** If there is only one call on hold and you are not on an active call, press **Resume**.
- Step 3** If you are already on an active call, press **Swap**.
The holding call becomes active, and the active call is placed on hold.
-

Switch Between Active and Multiple Holding Calls

Procedure

- Step 1** If you are on an active call and there are multiple calls on hold, the **Calls** softkey becomes available and a call list of holding calls displays on the screen.
- Step 2** Use the Navigation bar to highlight the call you want to make active, press **Resume**.
The current active call is placed on hold and the selected call is now active.
-

Hold Active Call and Answer New Incoming Call

Procedure

To place an active call on hold and answer an incoming call, press **Answer**.

Hold Reversion

Hold Reversion provides a notification that a call is left on hold. Hold reversion notifications are similar to new call notifications.

Depending on the configuration of the conference station, you may see one or more of the following:

- An animated icon that appears as an incoming call for two seconds and then as a hold icon for two more seconds.
- A single ring that repeats at regular intervals.
- The Call button on the DCU flashes green.
- The LEDs on the sound base flash green.

Respond to Hold Reversion Notification

Procedure

Press **Answer**

Meet Me Conference

If enabled by your system administrator, you can call a predetermined number at a scheduled time to host or join a Meet Me conference.

The Meet Me conference begins when the host connects. Participants who call the conference before the host has joined hear a busy tone and must dial again.



Note The conference ends when all participants hang up; the conference does not automatically end when the host disconnects.

Host Meet Me Conference

Procedure

- Step 1** Obtain a Meet Me phone number from your system administrator.
 - Step 2** Distribute the Meet Me phone number to participants.
 - Step 3** When you are ready to start the meeting, press **MeetMe**.
You may need to press **More** first.
 - Step 4** Dial the Meet Me phone number.
-

Join Meet Me Conference

Procedure

- Step 1** Dial the Meet Me phone number provided by the conference host.
 - Step 2** If you hear a busy tone, the host has not yet joined the conference. In this case, disconnect and try your call again.
-

Mobile Connect

Mobile Connect allows you to use your mobile phone to handle calls associated with the conference station phone number.

To set up Mobile Connect, use the Cisco Unified Communications Manager Self Care Portal to set up remote destinations and create access lists to allow or block calls from specific phone numbers from being passed to the remote destinations.

When you enable Mobile Connect:

- The conference station and remote destinations receive calls simultaneously.
- When you answer the call on the conference station, the remote destinations stop ringing, disconnect, and display a missed call message.
- When you answer the call on one remote destination, the other remote destinations and the conference station stop ringing, disconnect, and a missed call message displays on the other remote destinations.

Enable Mobile Connect

Procedure

- Step 1** Press **More**.
- Step 2** Press **Mobility** to display the current remote destination status (Enabled or Disabled).
- Step 3** Press **Select** to change the status.
- Step 4** Press **Exit**.
-

Switch IP Phone Call to Mobile Phone

Procedure

- Step 1** Press **More**.
- Step 2** Press **Mobility**.
- Step 3** Select **To mobile**.
- Step 4** Answer the in-progress call on your mobile phone.

You cannot use the conference station for any other calls while this call is still in progress.

The Call button LED lights solid red, and the calling party number displays on the phone.

Switch Mobile Call to IP Phone

Procedure

- Step 1** Press **Call** on the conference station.
 - Step 2** Hang up the call on your mobile phone to disconnect the mobile phone, but not the call.
 - Step 3** Press **Resume** on the conference station within 5 to 10 seconds and start talking on the conference station.
-

Monitoring and Recording

The Monitoring and Recording feature allows you to monitor and record calls. Your system administrator enables this feature, which can be set up for automatic recording of all calls or recording of calls on an individual call basis.

You can start or stop a recording by pressing the Record softkey on your phone.

Users might receive audible alerts during call monitoring and recording. By default, the person who monitors and records the call does not receive an audible alert.

Secure monitoring and recording is also available. For details on this aspect of the feature, contact your system administrator.

Multiple Calls per Line

The conference station has a single line and supports a maximum of six calls. Unless you are in a conference, only one call can be connected at any time; other calls are automatically placed on hold.

Multiple Incoming Calls

If there is a second incoming call on the line, while the first call rings, a navigable incoming call list window displays on the screen. The call list window updates automatically if there are additional incoming calls, or if an incoming call is cancelled.

Call Ended on Line with Multiple Calls

If there are multiple calls on the line when a call completes, the next call in the call list gains focus.

Outbound Call Maximum

The conference station supports a maximum of 6 outbound calls.

Answer Second Call on Same Line

Procedure

To answer a second call on your conference station line, press **Answer**.

Any active call is placed on hold, and the second call is answered.

Switch Between Calls on Same Line

Procedure

- Step 1** Press **Swap** to switch between two calls on the same line.
 - Step 2** If there are more than two calls on the line, select a call from the call list and press **Resume**.
-

Create Conference with Two Calls on Same Line

Procedure

- Step 1** With two connected calls on the same line, select a call to make it the active call. The second call is put on hold.
 - Step 2** Press **Conference**.
 - Step 3** Press **Calls** to view the call list and select the caller to add to the conference.
 - Step 4** Wait for the call to connect.
 - Step 5** Press **Conference** to add the participant to your call. The conference begins.
 - Step 6** (Optional) Repeat to add additional participants.
-

Transfer Two Calls on Same Line

Before you begin

You must be on an active call to transfer calls.

Procedure

- Step 1** Press **Transfer**.

- Step 2** Enter phone number for the transfer destination.
- When you have reached the maximum number of calls for your line, pressing **Transfer** allows you to select the calls from a list of calls on the line.
- Step 3** Wait for the recipient to answer.
- Step 4** Press **Transfer** again.
-

Shared Line

If the conference station is registered on a shared line you can handle multiple calls in the following ways:

- If there are two or more remote calls on the shared line, the caller ID field on the conference station indicates the number of remote calls on the line, and the state of the call. Press Calls to display the call list window.
- If at least one call on the shared line is on hold, the Call button LED flashes red. Press Resume to make the call active, or use the Navigation bar to choose a call to resume from the call list. For example, if a remote call on the shared line is placed on hold the Call button on your conference station will flash red.

Mute

Mute allows you to block audio input for the conference station, so that you can hear other parties on the call but they cannot hear you.

The conference station can be muted in two ways:

- Press the Mute button on the Sound Base.
- Press the Mute button on the DCU.

If connected, the optional extension microphones can also be used to mute the conference station. In Linked Mode, the Mute button on the secondary sound base behaves the same as the Mute button on the primary unit.

LED indicators on both the sound base and the DCU indicate the mute status of the conference station:

- Solid, red base LEDs and red base Mute button: muted.
- Solid, red DCU Mute button: muted.

Mute IP Phone Sound Base

Procedure

- Step 1** Press **Mute** to turn Mute on.
The **Mute** button is backlit by a solid, red light, and the sound base LEDs light red.
- Step 2** Press **Mute** again to turn Mute off.
-

Mute IP Phone DCU

Procedure

- Step 1** Press **Mute** to turn Mute on.
The **Mute** button is backlit by a solid, red light, and a mute icon displays on the screen.
- Step 2** Press **Mute** again to turn Mute off.
-

On-Hook Dialing

On-hook dialing allows you to enter a phone number before getting a dial tone and then press the Call button to complete the call.

Dial Number On-Hook

Procedure

- Step 1** Enter a phone number.
- Step 2** Press **Dial**.
-

Plus Dialing

Plus Dialing allows you to press and hold the star (*) key for at least 1 second to insert a plus (+) sign as the first digit in a phone number when dialing an international number.

A phone number with the + sign in it can be selected and dialed without the need to add digits for international calls.

Dial International Number

Before you begin

Before dialing an international call or using Plus Dialing, enter any local access code, such as 8 or 9 if applicable.

Procedure

- Step 1** Press and hold star (*) for at least 1 second.
The plus (+) sign displays as the first digit in the phone number.

The corresponding key tone stops to indicate that the * has changed to a + sign.

Step 2 Dial the international number, including the country code.

Privacy

If configured, the Privacy feature allows you to prevent others who share your line from seeing information about your calls. Your system administrator configures this feature.

If the phone that shares your line has Privacy enabled, you can make and receive calls using the shared line as usual.

Enable Privacy on Shared Line

Before you begin

Before you can use this feature, it must be enabled by your system administration.

Procedure

Step 1 Press **More**.

Step 2 Use the Navigation bar and Select button to scroll to the **Private** softkey.

- Press **Private** to enable this feature.
 - Press **Private** to disable this feature if it is currently enabled.
-

Quality Reporting Tool

Your system administrator may temporarily configure the conference station with the Quality Reporting Tool (QRT) to troubleshoot performance problems. Invoking the QRT reports a problem with the current call to the system administrator.

Report IP Phone Problems

Procedure

Step 1 Press **More**.

Step 2 Use the Navigation bar and Select button to locate and select **QRT**.

The information is sent to your system administrator.

Redial

Redial allows you to call the most recently dialed phone number.

Redial Number

Procedure

To redial the last number you called, press **Redial**.

Shared Lines

Shared lines allow you to use one phone number for multiple devices.

A shared line is useful if you have multiple devices and want one phone number, share call-handling tasks with coworkers, or handle calls on behalf of a manager. The other devices that share your line are referred to as remote devices, and a call that is being handled by a device that shares your line is referred to as a remote call.

When a call comes in on the shared line, the conference station rings and your coworker's device rings. Either you or your coworker can answer the call, place the call on hold, or transfer the call.

The Call button on the DCU has an LED that indicates the call state. For example:

- Remote in use: solid red LED.
- Remote hold: pulsing red LED

Your call history shows the status for all calls on the shared line. For example, if a call rings on a shared line and you answer the call, your coworkers who share the line see that the call was answered remotely. Your call history identifies calls that were Placed, Received, or Missed.

Transfer

Transfer allows you to redirect a connected call from the conference station to another number.

Before completing a transfer procedure, you can press **Cancel** to cancel the procedure.

Transfer Call to Another Number

Before you begin

The call must be active to be transferred.

Procedure

- Step 1** Press **Transfer**.
- Step 2** Enter the destination number.
- Step 3** Wait for the recipient to answer.
- Step 4** Press **Transfer** again.
- The transfer completes.
-

Cisco WebDialer

Cisco WebDialer allows you to click-to-dial contacts from the Cisco Unified Communications Manager Directory. Your system administrator sets up this feature for you.

Use WebDialer with Another Online Corporate Directory

Procedure

- Step 1** Sign in to a WebDialer-enabled corporate directory and search for coworkers.
- Step 2** Select the number that you want to dial.
- Step 3** When prompted, enter your user ID and password.
- Step 4** If this is your first time using WebDialer, review the preferences on the Make Call window.
- Step 5** Select **Dial**.
- The call is now placed on your phone line.
- Step 6** To end a call, select **Hang up** in the Make Call window or press **End Call** on your conference station.
-

Change WebDialer Preferences

Procedure

- Step 1** Sign in to your User Option web pages.
- Step 2** Initiate a call using WebDialer to access the Make Call window.
- The Make Call window displays the first time that you use WebDialer (after you select the number that you want to dial).
- Step 3** Select one of the following options from the Make Call window:
- Preferred language: Determines the language used for WebDialer settings and prompts.

- Use preferred device: Identifies the Cisco Unified IP Phone (calling device) and directory number (calling line) that you use to place WebDialer calls.

If you have one phone with a single line, the appropriate phone and line are automatically selected.

Step 4 If the phone and line do not select automatically, choose a phone or line.

If you have more than one phone of the same type, the list identifies the phone by device type and MAC address. To display the MAC address on your phone, select **Apps > Phone Information**.

Step 5 If you have an Extension Mobility profile, select **Extension Mobility** from the Calling Device drop-down menu in the Make Call window.

Step 6 Ensure that you do not select **Do not display call information** or **Disable Auto Close**.

- Do not display call confirmation: If selected, the WebDialer Make Call window does not display the next time WebDialer is used. Calls will automatically dial after you select a contact from the Cisco directory.
- Disable Auto Close: If selected, the call window does not close automatically after 15 seconds.

Sign In to the Cisco Unified Communications Self Care Portal

Your phone is a network device that can share information with other network devices in your company, including your personal computer. You can use your computer to sign in to the Cisco Unified Communications Self Care Portal, where you can control features, settings, and services for your phone. For example, you can manage your phone display language, set up services, add entries to your personal address book, and set up speed-dial codes.

Before you can access any of your options, such as speed dial or personal address book, you must sign in. When you finish using the portal, sign out.



Note Some features may not be available for your phone, and thus you can't set the features up in the Self Care Portal.

Sometimes, you can access the Cisco Unified Communications Self Care Portal without signing in.

For assistance in using the portal, see the *Cisco Unified Communications Self Care Portal User Guide* at http://www.cisco.com/en/US/products/sw/voicesw/ps556/products_user_guide_list.html.

Procedure


Step 1 Obtain the portal URL, user ID, and default password from your administrator.

Typically, the portal URL is **http://ip_address or hostname/ucmuser**.

Step 2 Open a web browser on your computer and enter the URL.

Step 3 If prompted to accept security settings, select **Yes** or **Install Certificate**.

- Step 4** Enter your user ID in the **Username** field.
 - Step 5** Enter your password in the **Password** field.
 - Step 6** Select **Login**.
 - Step 7** Select **Logout** to sign out.
-



CHAPTER 7

Troubleshooting

- [General Troubleshooting](#), on page 69
- [Phone Administration Data](#), on page 70
- [Quality Reporting Tool](#), on page 70

General Troubleshooting

This section provides information to help you troubleshoot general problems with the conference station. For more information, see your system administrator.

Symptom	Explanation
You cannot hear a dial tone or complete a call.	One or more of the following factors might apply: <ul style="list-style-type: none">• You must log into the Cisco Extension Mobility Service.• The conference station has time-of-day restrictions that prevent you from using some features during certain hours of the day.
A conference station button is unresponsive.	Your system administrator may have disabled the button on the conference station.
The softkey that you want to use does not appear.	One or more of the following factors might apply: <ul style="list-style-type: none">• You must change the line state (for example, go off-hook or have a connected call).• You must press More to reveal additional softkeys.• The conference station is not configured to support the feature associated with that softkey. Contact your administrator for more information.

Symptom	Explanation
Barge fails and results in a fast busy tone.	One or more of the following factors might apply: <ul style="list-style-type: none"> You cannot barge an encrypted call if the conference station you are using is not configured for encryption. When your barge attempt fails for this reason, the conference station plays a fast busy tone. You have toggled on the Privacy softkey.
You are disconnected from a call that you joined using Barge.	You will be disconnected from a call that you have joined using Barge if the call is put on hold, transferred, or turned into a conference call.
Cisco CallBack fails.	The other party might have call forwarding enabled.

Phone Administration Data


Your system administrator might ask you to access administration data on the conference station for troubleshooting purposes.

If You Are Asked To...	Then...
Access network configuration data	Choose Apps > Admin Settings > Network Configuration , and then navigate to the item that you want to view.
Access status data	Choose Apps > Admin Settings > Status , and then navigate to the item that you want to view.
Access model information	Choose Apps > Admin Settings > Phone Information , and then navigate to the item that you want to view.

Quality Reporting Tool

Your system administrator may temporarily configure the conference station with the Quality Reporting Tool (QRT) to troubleshoot performance problems. You can press QRT to submit information to your system administrator. Depending on your configuration, use the QRT to:

- Immediately report an audio problem on a current call.
- Select a general problem from a list of categories and choose reason codes.



CHAPTER 8

Cisco One-Year Limited Hardware Warranty Terms

- [Warranty Overview, on page 71](#)
- [View Cisco Information Packet, on page 71](#)
- [Cisco One-Year Limited Hardware Warranty Terms, on page 72](#)

Warranty Overview

There are special terms applicable to your hardware warranty and various services that you can use during the warranty period. Your formal Warranty Statement, including the warranties and license agreements applicable to Cisco software, is available on Cisco.com.

View Cisco Information Packet

Follow these steps to access and download the Cisco Information Packet and your warranty and license agreements from Cisco.com.

Procedure

- Step 1** Launch your browser, and go to this URL:
http://www.cisco.com/en/us/products/prod_warranties_listing.html
The Warranties and License Agreements page appears.
- Step 2** To read the *Cisco Information Packet*, follow these steps:
- a) Click the **Information Packet Number** field, and make sure that the part number 78-5235-03B0 is highlighted.
 - b) Select the language in which you would like to read the document.
 - c) Click **Go**.
 - d) The Cisco Limited Warranty and Software License page from the Information Packet appears.
 - e) Read the document online, or click the **PDF** icon to download and print the document in Adobe Portable Document Format (PDF).

Note You must have Adobe Acrobat Reader to view and print PDF files. You can download the reader from <http://www.adobe.com>

Step 3

To read translated and localized warranty information about your product, follow these steps:

- a) Enter this part number in the Warranty Document Number field: **78-10747-01C0**
- b) Select the language in which you would like to view the document.
- c) Click **Go**. The Cisco warranty page appears.
- d) Read the document online, or click the **PDF** icon to download and print the document in Adobe Portable Document Format (PDF).

You can also contact the Cisco service and support website for assistance: http://www.cisco.com/public/Support_root.shtml

Cisco One-Year Limited Hardware Warranty Terms

Special terms apply to your hardware warranty and services that you can use during the warranty period.

Your formal Warranty Statement, including the warranties and license agreements applicable to Cisco software, is available on Cisco.com at the following URL:

http://www.cisco.com/en/US/docs/general/warranty/English/1Y1DEN__.html



CHAPTER 9

Product Safety and Security

- [Safety and Performance Information, on page 73](#)
- [Compliance Statements, on page 74](#)
- [Cisco Product Security Overview, on page 77](#)
- [Important Online Information, on page 77](#)

Safety and Performance Information

Power Outage

Your access to emergency service through the phone requires that the phone receive power. If a power interruption occurs, service or emergency calling service dialing does not function until power is restored. If a power failure or disruption occurs, you may need to reset or reconfigure the equipment before you can use service or emergency calling service dialing.

External Devices

We recommend that you use good-quality external devices that are shielded against unwanted radio frequency (RF) and audio frequency (AF) signals. External devices include headsets, cables, and connectors.

Depending on the quality of these devices and their proximity to other devices, such as mobile phones or two-way radios, some audio noise may still occur. In these cases, we recommend that you take one or more of these actions:

- Move the external device away from the source of the RF or AF signals.
- Route the external device cables away from the source of the RF or AF signals.
- Use shielded cables for the external device, or use cables with a better shield and connector.
- Shorten the length of the external device cable.
- Apply ferrites or other such devices on the cables for the external device.

Cisco cannot guarantee the performance of external devices, cables, and connectors.

**Caution**

In European Union countries, use only external speakers, microphones, and headsets that are fully compliant with the EMC Directive [89/336/EC].

Ways to Provide Power to Your Phone

You can provide power to your phone in one of these ways:

- Use the power adapter that comes with your phone.

If you are not sure whether your network supports PoE, check with your administrator.

Phone Behavior During Times of Network Congestion

Anything that degrades network performance can affect phone audio and, in some cases, can cause a call to drop. Sources of network degradation can include, but are not limited to, the following activities:

- Administrative tasks, such as an internal port scan or security scan
- Attacks that occur on your network, such as a Denial of Service attack

UL Warning

The LAN/Ethernet cable or other cables attached to the device should not be extended outside of the building.

Product Label

The product label is located on the bottom of the device.

Compliance Statements

Compliance Statements for the European Union

CE Marking

The following CE mark is affixed to the equipment and packaging.



EU Authorized Representative:
Edgard Vangeel
Cisco Systems Belgium
De Kleetlaan 6A
B 1831 Diegem
Belgium

380728

Compliance Statements for the USA

Part 15 Radio Device



Caution The Part 15 radio device operates on a non-interference basis with other devices operating at this frequency. Any changes or modification to said product not expressly approved by Cisco, including the use of non-Cisco antennas, could void the user's authority to operate this device.

Compliance Statements for Canada

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device. Privacy of communications may not be ensured when using this phone.

This product meets the applicable Innovation, Science and Economic Development Canada technical specifications.

Avis de Conformité Canadien

Cet appareil est conforme aux normes RSS exemptes de licence RSS d'Industry Canada. Le fonctionnement de cet appareil est soumis à deux conditions : (1) ce périphérique ne doit pas causer d'interférence et (2) ce périphérique doit supporter les interférences, y compris celles susceptibles d'entraîner un fonctionnement non souhaitable de l'appareil. La protection des communications ne peut pas être assurée lors de l'utilisation de ce téléphone.

Le présent produit est conforme aux spécifications techniques applicables d'Innovation, Sciences et Développement économique Canada.

Compliance Statements for New Zealand

Permit to Connect (PTC) General Warning

The grant of a Telepermit for any item of terminal equipment indicates only that Telecom has accepted that the item complies with minimum conditions for connection to its network. It indicates no endorsement of the product by Telecom, nor does it provide any sort of warranty. Above all, it provides no assurance that any item will work correctly in all respects with another item of Telepermitted equipment of a different make or model, nor does it imply that any product is compatible with all of Telecom's network services.

Compliance Statement for Argentina

Advertencia

No utilizar una fuente de alimentación con características distintas a las expresadas ya que podría ser peligroso.

Compliance Information for Brazil

Art. 6º - 506

This equipment is a secondary type device, that is, it is not protected against harmful interference, even if the interference is caused by a device of the same type, and it also cannot cause any interference to primary type devices.

For more information, go to this URL: <http://www.anatel.gov.br>

Este equipamento opera em caráter secundário, isto é, não tem direito a proteção contra interferência prejudicial, mesmo de estações do mesmo tipo, e não pode causar interferência a sistemas operando em caráter primário.

Site Anatel: <http://www.anatel.gov.br>

Model	Certificate Number
8831	0382-14-1086

Compliance Statement for Singapore



Compliance Information for Japan



VCCI Compliance for Class B Equipment

FCC Compliance Statements

The Federal Communications Commission requires compliance statements for the following:

FCC Part 15.19 Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Part 15.21 Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC RF Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. End users must follow the specific operating instructions for satisfying RF exposure compliance. This transmitter must be at least 20 cm from the user and must not be collocated or operating in conjunction with any other antenna or transmitter.

FCC Receivers and Class B Digital Statement

This product has been tested and complies with the specifications for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used according to the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which is found by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment or devices
- Connect the equipment to an outlet other than the receiver's
- Consult a dealer or an experienced radio/TV technician for assistance

Cisco Product Security Overview

This product contains cryptographic features and is subject to U.S. and local country laws that govern import, export, transfer, and use. Delivery of Cisco cryptographic products does not imply third-party authority to import, export, distribute, or use encryption. Importers, exporters, distributors, and users are responsible for compliance with U.S. and local country laws. By using this product, you agree to comply with applicable laws and regulations. If you are unable to comply with U.S. and local laws, return this product immediately.

Further information regarding U.S. export regulations can be found at <https://www.bis.doc.gov/policiesandregulations/ear/index.htm>.

Important Online Information

End User License Agreement

The End User License Agreement (EULA) is located here: <https://www.cisco.com/go/eula>

Regulatory Compliance and Safety Information

Regulatory Compliance and Safety Information (RCSI) is located here:

https://www.cisco.com/c/en/us/td/docs/voice_ip_comm/cuipph/all_models/regulatory_compliance/english/install/guide/iphrcsi3.html

