bizhub PRESS C1070/C1070P/C1060/C71hc bizhub PRO C1060L

<Quick Guide for Fiery Color Server>, <Quick Guide for IC-602>,

<Safety Information>, HTML User's Guide Errata, Additional Information, and Modification Information

Thank you very much for your purchase of this product.

The following descriptions need to be modified, added, or changed in the User's Guide < Quick Guide for Fiery Color Server>, < Quick Guide for IC-602>, < Safety Information>, and HTML version of the User's Guide. Please make the corrections given in the tables below.

Please keep this document with care so that it is readily available for reference.

KONICA MINOLTA, INC.

<Errata 1>

User's Guide/Changes	Incorrect	Correct
<quick color="" fiery="" for="" guide="" server=""> Page 3-8 3.1 Installing the Printer Driver In a Macintosh environment "Installation" Step 3</quick>	Double-click the [Fiery Printer Driver Installer.dmg] file, then double-click the [Fiery Printer Driver Installer.pkg].	Double-click the [Fiery Printer Driver.dmg] file, then double-click the [Fiery Printer Driver.pkg].

<Errata 2>

User's Guide/Changes	Incorrect	Correct
<quick color="" fiery="" for="" guide="" server=""> Page 3-19 3.2 Installing Applications "Starting Fiery Remote Scan" Step 1</quick>	 • In Windows 8.1/Server 2012 R2, on the Start window, click ♠, then click [All Apps] - [Fiery Hot Folders]. • In Macintosh, select [Go] menu - [Applications] - [Fiery] - [Fiery], then double-click [Fiery Remote Scan]. 	 In Windows 8.1/Server 2012 R2, on the Start window, click ♠, then click [All Apps] - [Fiery Remote Scan 6]. In Macintosh, select [Go] menu - [Applications] - [Fiery], then double-click [Fiery Remote Scan].

<Errata 3>

User's Guide/Changes	Incorrect	Correct
<html guide="" user's=""> Home > Application > PageScope Web Connection: Web Tool of Image Controller IC-602 > Configuration of Administrator Mode Screen > Mainte- nance Tab > Online Assistance</html>	Access the documentation over the LAN. http://(IP address of the PC)/ pswc_help/wc_help.html The administrator is required to set up the online documentation to be available over the LAN server. Use a PC on which Microsoft IIS or another Web server is running, and set up the Web server to have the folder "/pswc_help/" accessible. Make sure to copy the entire pswc_help folder, which is installed using the installer CD, to the Web server.	The following method cannot be used to enter the URL of online documentation by way of PageScope Web Connection. Access the documentation over the LAN.

<Errata 4>

User's Guide/Changes	Incorrect	Correct
<html guide="" user's=""> Home > Utilize useful functions > Using Direct Print Function Tips</html>	■ The file formats usable in PageS-cope Direct Print are PDF/TIFF/PS/PCL/ASCII text/XPS.	■ The file formats usable in PageScope Direct Print are PDF/TIFF/PS/PCL/ASCII text/EPS/PPML. However, if no controller is connected, only TIFF is the usable file format.

<Errata 5>

User's Guide/Changes	Incorrect	Correct
<html guide="" user's=""> Home > FAQ > Application > Q14</html>	A14. The data file formats that are supported for printing directly from the image controller are PDF, TIFF, PS, PCL, ASCII (Text), and XPS.	A14. The data file formats that are supported for printing directly from the image controller are PDF, TIFF, PS, PCL, ASCII (Text), EPS, and PPML.

<Errata 6>

User's Guide/Changes	Incorrect	Correct
<html guide="" user's=""> Home > Print > Image Controller IC-602 > Basic Printing Methods and Major Printer Functions > Basic Printing Methods > For Mac OS X Step 3</html>	When the setting items are not displayed, click (*) on the right side of [Printer].	When the setting items are not displayed, click (▼) on the right side of [Printer].

<Errata 7>

User's Guide/Changes	Incorrect	Correct
<html guide="" user's=""> Home > Settings and Adjustments > Adjustments > Finisher Adjustment (with Finisher FS-532) > Staple Finisher (Main) Adjustment</html>	Objects of Adjustment	
Staple Paper Width Adj.: Adjusting the Staple Paper Width	Custom (148 - 219 mm)	Custom (139 - 219 mm)
FD Alignment Plate Adj.: Adjusting the Insertion of the Alignment Unit of Staple Stacker	Custom (148 - 230 mm)	Custom (139 - 230 mm)
Exit Guide Paper Width Adj.: Adjusting the Width of Exit Guides of the Finisher	Custom (148 - 219 mm)	Custom (139 - 219 mm)
Rewind Paddle Descent Adj.: Adjusting the Rewind Paddle Descent	Custom (148 - 219 mm)	Custom (139 - 219 mm)

<Errata 8>

User's Guide/Changes	Incorrect	Correct
<html guide="" user's=""> Home > Configuration > Machine Configuration > Banner Tray Unit MK- 740 Output extension tray</html>	Used to mount on Finisher FS-532 or Finisher FS-612.	Used to mount on Finisher FS-531 or Finisher FS-612.

<Errata 9>

User's Guide/Changes	Incorrect	Correct
<html guide="" user's=""> Home > Settings and Adjustments > Utility/Counter > List of Setting Items (bizhub PRESS C1070 / bizhub PRESS C1060, bizhub PRO C1060L) [06 Security Warning Display]</html>	Display, Not Display	Display, Not Display
Home > Settings and Adjustments > Utility/Counter > List of Setting Items (bizhub PRESS C1070P / bizhub PRESS C71hc) [06 Security Warning Display]	Display, Not Display	Display, Not Display

<Errata 10>

User's Guide/Changes	Incorrect	Correct
<safety information=""> Page 1-3 1.2 Energy Star®</safety>	Applicable products are bizhub PRESS C1070 and bizhub PRESS C1060.	Applicable products are bizhub PRESS C1070, bizhub PRESS C1060, and bizhub PRO C1060L.

<Additional Information 1>

Directory of User's Guide	Added description
-	Saddle Stitcher SD-513 and its mountable devices, Creaser Unit CR-101, Trimmer Unit TU-503, and Folding Unit FD-504 are added as options provided for this machine. For details, refer to [User's Guide <saddle sd-513="" stitcher="">].</saddle>

<Additional Information 2>

Directory of User's Guide	Before	After
<html guide="" user's=""> Home > Utilize useful functions > Using Direct Print Function Using Direct Print Function</html>	PageScope Direct Print allows you to directly print a PDF or TIFF file without starting an application. You can preset the job settings and reduce the burden of making print settings.	PageScope Direct Print allows you to directly print a PDF or TIFF file without starting an application. You can preset the job settings and reduce the burden of making print settings. PageScope Direct Print can be downloaded from the following URL: http://www.biz.konicaminolta.com/download/en/utilities/

<Additional Information 3>

Directory of User's Guide	Added description
<html guide="" user's=""> Home > Paper and Originals > Replenish Paper > Loading Banner Paper in Banner Tray Unit MK-740 > Loading Banner Paper into Feeding Extension Tray</html>	NOTICE In order to prevent the sheets from sticking together, separate each sheet off a paper bundle, and then load only required number of sheets. If a long period of time has elapsed with the paper being kept loaded, separate the sheets again one by one, and then reload them before printing.

<Additional Information 4>

Directory of User's Guide	Added description
<html guide="" user's=""> <quick color="" fiery="" for="" guide="" server=""> <quick for="" guide="" ic-602=""></quick></quick></html>	 This machine does not support these operating systems. Windows 2003, Windows 2003 R2, Windows 8, Mac OS X 10.5, Mac OS X 10.6 Printer drivers, Color Centro, and Job Centro support Windows 10. Printer drivers support Mac OS X 10.11.

<Additional Information 5>

Directory of User's Guide	Added description
<html guide="" user's=""> <quick for="" guide="" ic-602=""></quick></html>	 Upgrade Kit UK-206 is not available. Although the design of some screens may differ, that does not interrupt your operation. Within the process to install Color Centro, you can install .NET Framework 3.5 also.

<Additional Information 6>

Directory of User's Guide	Added description
<html guide="" user's=""></html>	 On the [Connect Printer] screen of Job Centro, you can add a maximum of 50 printers to the list. On Color Centro, a new colorimeter FD-9 is available. Color Centro has modes only for bizhub PRESS C71hc. For details, refer to the following description.

Color Centro: Modes only for bizhub PRESS C71hc

By using special modes, you can utilize the unique gamut of bizhub PRESS C71hc.

These modes reproduce vivid colors by emphasizing colors.

Mode	Color space	Characteristics
Saturation mode	RGB	Remarkable vividness (A little bit bold)
	CMYK	Impressive and clear vividness (Bold only in high-chroma areas)
Soft mode	RGB	High visibility in detail in very dark shadow areas
	СМҮК	Similarity to offset printing Adherence to color values

To use these modes, import respective color configurations.

The [Color Configuration Management] screen - [File] - [Import/Export]

My Documents\KONICA MINOLTA\Color Centro\Color Configuration

Mode	Color configuration	
Wode	For Exact Color	For G7 Calibration
Saturation mode	C71hc_Saturation_Mode	C71hc_Saturation_Mode G7
Soft mode	C71hc_Soft_Mode	C71hc_Soft_Mode G7

Select a color configuration, according to the advanced calibration that you use. A false selection may cause problems in color reproduction.

Use the prepared color configurations for any type of paper.

These color configurations can reproduce vivid colors for any type of paper by using the same settings.

<Additional Information 7>

Directory of User's Guide	Before	After
<html guide="" user's=""> Home > Settings and Adjustments > Adjustments > Density Balance Adjustment Home > Settings and Adjustments > Adjustments > Color Density Control</html>	-	Addition of Spectrophotometer FD-9
Example 1: Home > Settings and Adjustments > Adjustments > Density Balance Adjustment > Outputting the Density Balance Chart	To use the Spectrophotometer i1-iSisXL, select [Type 1] or [Type 2] in [Measure Spectrophotometer-1 (i1-iSisXL)].	To use the Spectrophotometer i1-iSisXL or Spectrophotometer FD-9, select [Type 1] or [Type 2] in [Measure Spectrophotometer-1 (i1-iSisXL/FD-9)].
Example 2: Home > Settings and Adjustments > Adjustments > Color Density Control > Adj. of Color Sensor for Each Paper Type: Registering the Sensor Adjustment Data That is Adjusted to Paper Type (Color Sensor Adjustment Data for Each Paper Type)	Use the ProfileMaker Measure Tool when the Spectrophotometer i1-iSisXL or i1-Pro/i1-Pro2 is used. Use Color Care measure when the Spectrophotometer FD-5 BT is used.	Use the ProfileMaker Measure Tool when the Spectrophotometer i1-iSisXL or i1-Pro/i1-Pro2 is used. Use Color Care measure or FD-S2w when the Spectrophotometer FD-5 BT is used. Use FD-S2w when the Spectrophotometer FD-9 is used.

<Additional Information 8>

Directory of User's Guide	Before	After
<html guide="" user's=""> Home > Settings and Adjustments > Adjustments > Color Density Control > Periodical Adjustment (Automatic Adjustment): Setting Color Density Control Automatically</html>	For periodical adjustment (automatic adjustment), the following settings are required: [Adjustment Execution Timing] [Chart Tray Setting] [Switch Color(1st or 2nd)]	For periodical adjustment (automatic adjustment), the following settings are required: [Adjustment Execution Timing] [Chart Tray Setting] [Switch Color(1st or 2nd)] [Adjustment Interval]: To set the interval of the adjustment, select [ON] and specify a desired number of sheets between 100 and 9999.
	(Between step 10 and step 11)	(Between step 10 and step 11) If you select [ON] in [Periodical Adj. Execution] in step 5, select [ON] or [OFF] at the right of [Adjustment Interval]. (The rest is omitted.)

<Additional Information 9>

Directory of User's Guide	Added description
<html guide="" user's=""> Home > Machine Information > MACHINE Screen > Both Sides Adj. > Procedure of Both Sides Adjust NOTICE</html>	■ When adjustment charts are output in the [Scan Meas.] Adjustment, [Gap] Adjustment, or [Chart Adjustment], [Full Color] is basically selected for the color setting. Select [Black] if all pages of the output matter are monochrome printed.

<Additional Information 10>

Directory of User's Guide	Added description
<html guide="" user's=""> Home > Settings and Adjustments > Utility/Counter > Administrator Set- ting > Controller Administrator Setting > System Setting > Software Switch Setting: Setting the Software Switch</html>	Switches have been added to Software Switch Setting in Administrator Setting (Controller Administrator Setting). Also, the Switch 78 has been modified as described below.

Switch No.	Problem/Requirement	Solution reached when turned On
78	The quality of thumbnails displayed by Job Centro has been improved for clear display. However, the HDD space may decrease when the file capacity increases. An option to suppress quality improvement should be provided.	Setting value: Off: Improve the quality On: Do not improve the quality If turned On, the characters and lines of thumbnails may not fully legible.
97	Unnecessary tab paper should be output during Printgroove printing.	Setting value: Off: Do not output On: Output
98	The spine should not be blank when [Cover Print 2 in 1] is selected in perfect binding.	Setting value: Off: Blank On: Not blank
103	The texts of color setting information should be printed in black only.	Setting value: Off: Do not print all texts in black On: Print all texts in black
112	In addition to the Switch 40 setting, the print position setting (Lead/Center/Rear) of PageScope Direct Print should be allowed.	Setting value: Off: Do not follow the print position setting. On: Follow the print position setting. [Restrictions] • Switch 40 needs to be turned On. • This setting is available for PS and PDF. • The "Full Bleed" printing is always selected.
113	When using EQUIOS, returning the job results for proof printing should be enabled.	Setting value: Off: Disabled On: Enable
114	To specify the fold function, the feed direction is fixed to Short Edge in the current specification. However, Long Edge should also be enabled if it is in the fold enable range.	Setting value: Off: Fixed to Short Edge. On: Enables Long Edge only in the fold enable range.
115	When a job is saved in the following setting and the result is checked using a job ticket, etc., [Image Position] is set to OFF. • [Image Position] is set to [Center]. • [Print Mode] is set to [Hold]. [Center] should be held without changing the setting to OFF.	Setting value: Off: Sets [Image Position] to OFF. On: Holds [Image Position] to [Center]. [Restrictions] This function is only applied when the PS Plug-in driver, Job Centro, or PageScope Direct Print is used. Setting to On may slightly displace an image to the right.
116	When importing a PDF file using APPE, images should be generated on the basis of print area sizes.	Setting value: Off: On the basis of PDF original sizes On: On the basis of print area sizes (same as for CPSI) [Restrictions] • This setting is available for standard-size originals only.

Switch No.	Problem/Requirement	Solution reached when turned On
118	When the Envelope Fusing Unit is installed, color chart printing should be enabled.	Setting value: Off: Disables color chart printing. On: Enables color chart printing.
124	In PageScope Direct Print, the "Fit to Paper Size" function should be enabled for reduction only.	Setting value: Off: Reduced or enlarged according to the paper size On: Reduced according to the paper size (not enlarged) [Restrictions] • A specific condition is required to use this function. For details, contact your service representative.
125	In PageScope Direct Print, fitting to the print area should also be available when using the "Fit to Paper Size" function.	Setting value: Off: Fit to the paper size On: Fit to the print area [Restrictions] • A specific condition is required to use this function. For details, contact your service representative.
126	2-Sided printing should be enabled in Poster Printing.	Setting value: Off: 2-Sided printing is not enabled On: 2-Sided printing is enabled [Restrictions] • A specific condition is required to use this function. For details, contact your service representative.
127	I want to print transparent objects of Microsoft Office applications in high resolution. When printing in high resolution, it should be possible to reduce the conspicuousness of the dots that appear according to the transparency percentage.	Setting value: Off: Disables high resolution. On: Enables high resolution. [Important] Setting to On necessarily spools jobs for PostScript printing regardless of the MFP setting. [Restrictions] This setting is applied only to diagrams or shapes. This setting does not affect the transparency of images or pictures.
128	JPEG files should be supported in PageScope Direct Print (and PageScope Mobile).	Setting value: Off: Does not support JPEG files. On: Supports JPEG files. [Important] After changing this setting, you need to turn off the sub power switch and then turn it back on in order to retain the setting.
129	Only A3-size sheets should be folded in half when an original containing both A3 and A4 sizes is output.	Setting value: Off: Disables half-fold and output. On: Enables half-fold and output only for A3-size sheets.
130	The number of copies and the number of pages for a job should be printed on a banner page in the PS Plug-in driver.	Setting value: Off: Does not print the number of copies and the number of pages for a job on a banner page. On: Prints the number of copies and the number of pages for a job on a banner page. [Restrictions] This setting is available only for PS, PDF, and TIFF. This setting cannot be combined with booklet splitting.

Switch No.	Problem/Requirement	Solution reached when turned On
131	Banner pages in the PS Plug-in driver are output before normal jobs, but should be output after such jobs are completed.	Setting value: Off: Prints data in the following order: banner pages > jobs. On: Prints data in the following order: jobs > banner pages.
132	The following two conflicting functions can be set simultaneously for a PCL job. • Specify Text Margin • Horizontal Motion Index By default, [Specify Text Margin] has priority in the PCL-compliant specifications, but [Horizontal Motion Index], the HP-compatible specification, should be set to be given priority.	Turn this switch on to change to the HP-compatible specifications. Setting value: Off: Prioritizes [Specify Text Margin]. (PCL-compliant specifications) On: Prioritizes [Horizontal Motion Index]. (HP-compatible specifications)
135	When the front door is open and no paper is loaded, the status remains set to [Ready] in Printgroove.	Changing to On may return to the normal status.
136	When a job to which the paper type link is set to ON is imported while Composite Overprint for APPE is enabled (other than OFF) in Job Centro, an error occurs.	Changing to On may prevent this error from occurring.
138	If the paper size over the maximum printing area is specified when poster printing is conducted using PageScope Direct Print, the image is displaced approximately 3 mm and printed. The displacement should be cleared by setting the left margin to "0".	Changing to On may prevent the displacement from occurring. [Restrictions] This function is only applied when poster printing (Partial, Divided, or Central Divided) is specified.
142	When special colors included in a specific PDF file on Job Centro (2.0) are processed using CPSI, this processing may be stopped during RIP processing.	Changing to On may prevent this error from occurring. However, CMM (Color Management Module) is not applied, so special color processing is canceled.

<Additional Information 11>

Directory of User's Guide	Before	After
<html guide="" user's=""> Home > Copy > Application</html>	(Not described)	[180 Deg. Rotation] has been added as a setting item of Application.
<html guide="" user's=""> Home > Copy > Application > Stamp: Copying with Additional Information Printed > Numbering: Printing Annotation Number for Management Step 5</html>	Specify [Format], [Detail Setting] (Text Size, Start Number, Color), and [Print Pos. Setting] for Set Number- ing.	Specify [Format], [Detail Setting] (Text Size, Print Page, Start Number, and Color), and [Print Pos. Setting] for Set Numbering. (The following description is added to the table that shows setting options and descriptions.) [Print Page] Press this key to select [Cover Only] or [All Pages].

<Additional Information 12>

Directory of User's Guide	Before	After
<html guide="" user's=""> Home > Job Operation > Check Job History > Displaying Output History No. 2</html>	[File Name] Displays the file name when applied.	[File Name] Displays the file name when applied. The file name can be hidden (indicated by asterisks (*)). For details, contact your service representative.

<Additional Information 13>

Directory of User's Guide	Before	After
<html guide="" user's=""> Home > Copy > Copy Assist Functions > Proof Copy: Outputting a Single Set to Check Setting Conditions</html>	Before making a large amount of copies in the multiple sets, press Proof Copy on the control panel to scan the original and output only one set for confirmation.	Before making a large amount of copies in the multiple sets, press Proof Copy on the control panel to scan the original and output only one set for confirmation. When [Separate Scan] is enabled, only one set can be output for confirmation as needed.

<Additional Information 14>

Directory of User's Guide	Added description
<html guide="" user's=""> Home > Copy > Basic Settings > Paper Setting > Overview of Paper Setting [Process Adj.]</html>	[Back on Top Output Timing Adj.]: 0 to +10

<Additional Information 15>

Directory of User's Guide	Added description
<html guide="" user's=""> Home > Setting and Adjustment > Utility/Counter > User Setting > System Setting > Paper Tray Setting > Paper Setting: Registering the Paper Conditions Process Adjustment</html>	[Back on Top Output Timing Adj.]: 0 to +10

<Modification Information 1>

Directory of User's Guide	Before	After
<html guide="" user's=""> Home > Settings and Adjustments > Utility/Counter > Administrator Setting > System Setting > Expert Adjustment > Process Adjustment > Maximum Density Adjustment: Adjusting the Maximum Density for Y, M, C, and K Step 3 Step 4</html>	(Step 3) Select the desired density value for <yellow>, <magenta>, <cyan>, and <black>, respectively. When Relay Unit RU-509 is not mounted, go to step 8. Density Measurement Result (Rough Value), [Measurement History], and [Print Mode] is displayed when Relay Unit RU-509 is mounted. (Step 4) Press [Print Mode].</black></cyan></magenta></yellow>	(Step 3) Select the desired density value for <yellow>, <magenta>, <cyan>, and <black>, respectively. (The remainder is deleted.) (Step 4) Press [Print Mode]. When the Relay Unit RU-509 is not mounted, print charts on the prespecified paper, conduct measurement using your spectrophotometer, then repeat manual adjustment until the target result is obtained. After adjustment has been completed, proceed to step 8.</black></cyan></magenta></yellow>